

RX

Customised to your machine

Model: 3G3RX

200 V Class Three-Phase Input 0.4 to 55 kW

400 V Class Three-Phase Input 0.4 to 132 kW

USER'S MANUAL



OMRON

Introduction

Thank you for choosing the general-purpose Inverter RX Series. This User's Manual (hereinafter called "this manual") describes the parameter setting methods required for installation/wiring and operation of the RX model, as well as troubleshooting and inspection methods.

- This manual should be delivered to the actual end user of the product.
- After reading this manual, keep it handy for future reference.
- This manual describes the specifications and functions of the product as well as the relations between them. You should assume that anything not described in this manual is not possible with the product.

- Intended readers

This manual is intended for:

Those with knowledge of the workings of electricity (qualified electric engineers or the equivalent), and also in charge of:

- Introducing the control equipment
- Designing the control system
- Installing and/or connecting the control equipment
- Field management

Read and Understand this Manual

Please read and understand this manual before using the product. Please consult your OMRON representative if you have any questions or comments.

Warranty and Limitations of Liability

WARRANTY
<p>OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year (or other period if specified) from date of sale by OMRON.</p> <p>OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.</p>

LIMITATIONS OF LIABILITY
<p>OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY.</p> <p>In no event shall the responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.</p> <p>IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR, OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED, AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE, OR INAPPROPRIATE MODIFICATION OR REPAIR.</p>

Application Considerations

SUITABILITY FOR USE

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of products in the customer's application or use of the products.

At the customer's request, OMRON will provide applicable third party certification documents identifying ratings and limitations of use that apply to the products. This information by itself is not sufficient for a complete determination of the suitability of the products in combination with the end product, machine, system, or other application or use.

The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of the products, nor is it intended to imply that the uses listed may be suitable for the products:

- Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this manual.
- Nuclear energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations.
- Systems, machines, and equipment that could present a risk to life or property.

Please know and observe all prohibitions of use applicable to the products.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCTS ARE PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

PROGRAMMABLE PRODUCTS

OMRON shall not be responsible for the user's programming of a programmable product, or any consequence thereof.

Disclaimers

CHANGE IN SPECIFICATIONS

<p>Product specifications and accessories may be changed at any time based on improvements and other reasons.</p>

<p>It is our practice to change model numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the products may be changed without any notice. When in doubt, special model numbers may be assigned to fix or establish key specifications for your application on your request. Please consult with your OMRON representative at any time to confirm actual specifications of purchased products.</p>
--

DIMENSIONS AND WEIGHTS

<p>Dimensions and weights are nominal and are not to be used for manufacturing purposes, even when tolerances are shown.</p>
--

PERFORMANCE DATA

<p>Performance data given in this manual is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of OMRON's test conditions, and the users must correlate it to actual application requirements. Actual performance is subject to the OMRON Warranty and Limitations of Liability.</p>

ERRORS AND OMISSIONS

<p>The information in this manual has been carefully checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical, or proofreading errors, or omissions.</p>



Safety Precautions

■ Indications and Meanings of Safety Information









In this user's manual, the following precautions and signal words are used to provide information to ensure the safe use of the RX Inverter.









The information provided here is vital to safety. Strictly observe the precautions provided.

■ Meanings of Signal Words

 DANGER	Indicates an imminently hazardous situation which, if not avoided, is likely to result in serious injury or may result in death. Additionally there may be severe property damage.
 CAUTION	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or in property damage.

■ Alert Symbols in this Document

 DANGER	
	Turn off the power supply and implement wiring correctly. Not doing so may result in a serious injury due to an electric shock.
	Wiring work must be carried out only by qualified personnel. Not doing so may result in a serious injury due to an electric shock.
	Do not change wiring and slide switches (SW1), put on or take off Digital Operator and optional devices, replace cooling fans while the input power is being supplied. Doing so may result in a serious injury due to an electric shock.
	Be sure to ground the unit. Not doing so may result in a serious injury due to an electric shock or fire. (200-V class: type-D grounding, 400-V class: type-C grounding)
	Do not remove the terminal block cover during the power supply and 10 minutes after the power shutoff. Doing so may result in a serious injury due to an electric shock.
	Do not operate the Digital Operator or switches with wet hands. Doing so may result in a serious injury due to an electric shock.
	Inspection of the Inverter must be conducted after the power supply has been turned off. Not doing so may result in a serious injury due to an electric shock. The main power supply is not necessarily shut off even if the emergency shutoff function is activated.

 CAUTION	
	<p>Do not connect resistors to the terminals (PD/+1, P/+, N/-) directly. Doing so might result in a small-scale fire, heat generation or damage to the unit.</p>
	<p>Install a stop motion device to ensure safety. Not doing so might result in a minor injury. (A holding brake is not a stop motion device designed to ensure safety.)</p>
	<p>Be sure to use a specified type of braking resistor/regenerative braking unit. In case of a braking resistor, install a thermal relay that monitors the temperature of the resistor. Not doing so might result in a moderate burn due to the heat generated in the braking resistor/regenerative braking unit. Configure a sequence that enables the Inverter power to turn off when unusual overheating is detected in the braking resistor/regenerative braking unit.</p>
	<p>The Inverter has high voltage parts inside which, if short-circuited, might cause damage to itself or other property. Place covers on the openings or take other precautions to make sure that no metal objects such as cutting bits or lead wire scraps go inside when installing and wiring.</p>
	<p>Do not touch the Inverter fins, braking resistors and the motor, which become too hot during the power supply and for some time after the power shutdown. Doing so may result in a burn.</p>
	<p>Take safety precautions such as setting up a molded-case circuit breaker (MCCB) that matches the Inverter capacity on the power supply side. Not doing so might result in damage to property due to the short circuit of the load.</p>
	<p>Do not dismantle, repair or modify this product. Doing so may result in an injury.</p>

Precautions for Safe Use

■Installation and Storage

Do not store or use the product in the following places.

- Locations subject to direct sunlight.
- Locations subject to ambient temperature exceeding the specifications.
- Locations subject to relative humidity exceeding the specifications.
- Locations subject to condensation due to severe temperature fluctuations.
- Locations subject to corrosive or flammable gases.
- Locations subject to exposure to combustibles.
- Locations subject to dust (especially iron dust) or salts.
- Locations subject to exposure to water, oil, or chemicals.
- Locations subject to shock or vibration.

■Transporting, Installation, and Wiring

- Do not drop or apply strong impact on the product. Doing so may result in damaged parts or malfunction.
- Do not hold by the front cover and terminal block cover, but hold by the fins during transportation.
- Do not connect an AC power supply voltage to the control input/output terminals. Doing so may result in damage to the product.
- Be sure to tighten the screws on the terminal block securely.
Wiring work must be done after installing the unit body.
- Do not connect any load other than a three-phase inductive motor to the U, V, and W output terminals.
- Take sufficient shielding measures when using the product in the following locations. Not doing so may result in damage to the product.
 - Locations subject to static electricity or other forms of noise.
 - Locations subject to strong magnetic fields.
 - Locations close to power lines.

■Operation and Adjustment

- Be sure to confirm the permissible range of motors and machines before operation because the inverter speed can be changed easily from low to high.
- Provide a separate holding brake if necessary.
- If the Drive Programming stops during multi-function output, the output status is held. Take safety precautions such as stopping peripheral devices.
- If the clock command is used in Drive Programming, an unexpected operation may occur due to weak battery. Take measures such as detecting a weak battery by a check that the clock data returns to the initial setting and stopping the inverter or programs. When the LCD Digital Operator is removed or disconnected, Drive Programming is in a waiting status by the clock command.

■Maintenance and Inspection

- Be sure to confirm safety before conducting maintenance, inspection or parts replacement.
- The capacitor service life is influenced by the ambient temperature. Refer to "Smoothing Capacitor Life Curve" described in the manual. When a capacitor reaches the end of its service life and does not work as the product, you need to replace the capacitor.
- When disposing of LCD digital operators and wasted batteries, follow the applicable ordinances of your local government. When disposing of the battery, insulate it using tape.



Precautions for Safe Use

The following display must be indicated when products using lithium primary batteries (with more than 6 ppb of perchlorate) are transport to or through the State of California, USA.

Perchlorate Material - special handling may apply.
See www.dtsc.ca.gov/hazardouswaste/perchlorate

The 3G3AX-OP05 has the lithium primary battery (with more than 6 ppb of perchlorate).
Label or mark the above display on the exterior of all outer shipping packages of your products when exporting your products which the 3G3AX-OP05 are installed to the State of California, USA.

- Do not short + and –, charge, disassemble, heat, put into the fire, or apply strong impact on the battery. The battery may leak, explode, produce heat or fire. Never use the battery which was applied strong impact due to such as fall on the floor, it may leak.
- UL standards establish that the battery shall be replaced by an expert engineer. The expert engineer must be in charge of the replacement and also replace the battery according to the method described in this manual.
- When the display of LCD Digital Operator can not be recognized due to the service life, replace the LCD Digital Operator.

Precautions for Correct Use

■Installation

- Mount the product vertically on a wall with the product's longer sides upright.
The material of the wall has to be noninflammable such as a metal plate.

■Main Circuit Power Supply

- Confirm that the rated input voltage of the Inverter is the same as AC power supply voltage.

■Error Retry Function

- Do not come close to the machine when using the error retry function because the machine may abruptly start when stopped by an alarm.
- Be sure to confirm the RUN signal is turned off before resetting the alarm because the machine may abruptly start.

■Non-Stop Function at Momentary Power Interruption

- Do not come close to the machine when selecting restart in the non-stop function at momentary power interruption selection (b050) because the machine may abruptly start after the power is turned on.

■Operation Stop Command


- Provide a separate emergency stop switch because the STOP key on the Digital Operator is valid only when function settings are performed.
- When checking a signal during the power supply and the voltage is erroneously applied to the control input terminals, the motor may start abruptly. Be sure to confirm safety before checking a signal.

■Product Disposal

- Comply with the local ordinance and regulations when disposing of the product.

Warning Labels

Warning labels are located on the Inverter as shown in the following illustration.
Be sure to follow the instructions.



Warning Description

危険 — けが・感電のおそれがあります。

WARNING — Risk of electric shock.


- 据え付け、運転の前には必ず取扱説明書をお読み下さい。
- 通電中及び電源遮断後10分以内はフロントカバーを外さないで下さい。
- Read manual before installing.
- Wait 10 minutes for capacitor discharge after disconnecting power supply.

Checking Before Unpacking


■Checking the Product

On delivery, be sure to check that the delivered product is the Inverter RX model that you ordered. Should you find any problems with the product, immediately contact your nearest local sales representative or OMRON sales office.

●Checking the Nameplate



●Checking the Model



■Checking the Accessories

Note that this manual is the only accessory included with the RX model. Mounting screws and other necessary parts must be provided by the user.

Revision History

■ A manual revision code appears as a suffix to the catalog number located at the lower left of the front and back covers.

Cat. No. I560-E2-05

↑
Revision code

Revision code	Revision date	Description
01	April 2009	First version
04	February 2012	Major changes
05	December 2012	Minor changes

About This Manual

This User's Manual is compiled chapter by chapter for user's convenience as follows.
Understanding the following configuration ensures more effective use of the product.

	Overview
Chapter 1 Overview	Describes features and names of parts.
Chapter 2 Design	Provides external dimensions, installation dimensions, peripheral device design/selection instructions, and other information necessary for design.
Chapter 3 Operation	Describes names of parts, the Inverter's operations, including how to use the keys on the Digital Operator, and the monitor function.
Chapter 4 Functions	Describes the functions of the Inverter.
Chapter 5 Maintenance Operations	Describes the causes and their countermeasures if the Inverter fails, including the solutions to possible troubles (troubleshooting).
Chapter 6 Inspection and Maintenance	Describes items for periodical inspection and/or maintenance for the Inverter.
Chapter 7 Specifications	Provides Inverter specifications, as well as the specifications and dimensions of peripheral devices.
Appendix	Describes the summarized parameter settings as a reference for users who have used this Inverter and understood the functions.

Introduction.....	1
Read and Understand this Manual	2
Safety Precautions	5
Precautions for Safe Use.....	7
Precautions for Correct Use	9
Checking Before Unpacking	11
Revision History.....	12
About This Manual.....	13
 Chapter 1 Overview	
1-1 Functions	1-1
1-2 Appearance and Names of Parts.....	1-4
 Chapter 2 Design	
2-1 Installation.....	2-1
2-2 Wiring.....	2-5
 Chapter 3 Operation	
3-1 Operation Method	3-3
3-2 LCD Display.....	3-4
3-3 Test Run Procedure.....	3-5
3-4 Operation	3-6
3-5 Read/Write function and operation	3-13
3-6 Test Run Operation	3-14
3-7 Part Names and Descriptions of the Digital Operator	3-17
3-8 Parameter Transition	3-19
3-9 Parameter List	3-21
 Chapter 4 Functions	
4-1 Monitor Mode.....	4-1
4-2 Function Mode	4-8
4-3 Functions When PG Option Board (3G3AX-PG01) Is Used.....	4-123
4-4 Communication Function	4-145
 Chapter 5 Maintenance Operations	
5-1 Protective Functions and Troubleshooting	5-1
5-2 Warning Function.....	5-10
 Chapter 6 Inspection and Maintenance	
6-1 Inspection and Maintenance.....	6-1

Contents

Chapter 7 Specifications

7-1	Standard Specification List.....	7-1
7-2	Dimensional Drawing	7-7
7-3	Options.....	7-15

Chapter App Appendix

Appendix-1	Parameter List	App-1
Appendix-2	Product Life Curve	App-47
Appendix-3	Life Alarm Output.....	App-48
Appendix-4	EC Declaration of Conformity	App-49

Index.....	Index-1
------------	---------

Chapter 1

Overview

1-1	Functions	1-1
1-2	Appearance and Names of Parts	1-4

1-1 Functions

RX Inverter Models

Rated voltage	Enclosure rating	Max. applicable motor capacity	Model
3-phase 200 V AC	IP20	0.4 kW	3G3RX-A2004
		0.75 kW	3G3RX-A2007
		1.5 kW	3G3RX-A2015
		2.2 kW	3G3RX-A2022
		3.7 kW	3G3RX-A2037
		5.5 kW	3G3RX-A2055
		7.5 kW	3G3RX-A2075
		11 kW	3G3RX-A2110
		15 kW	3G3RX-A2150
		18.5 kW	3G3RX-A2185
		22 kW	3G3RX-A2220
		30 kW	3G3RX-A2300
		37 kW	3G3RX-A2370
		45 kW	3G3RX-A2450
		55 kW	3G3RX-A2550
3-phase 400 V AC	IP20	0.4 kW	3G3RX-A4004
		0.75 kW	3G3RX-A4007
		1.5 kW	3G3RX-A4015
		2.2 kW	3G3RX-A4022
		4.0 kW	3G3RX-A4040
		5.5 kW	3G3RX-A4055
		7.5 kW	3G3RX-A4075
		11 kW	3G3RX-A4110
		15 kW	3G3RX-A4150
		18.5 kW	3G3RX-A4185
		22 kW	3G3RX-A4220
		30 kW	3G3RX-A4300
		37 kW	3G3RX-A4370
		45 kW	3G3RX-A4450
		55 kW	3G3RX-A4550
	IP00	75 kW	3G3RX-B4750
		90 kW	3G3RX-B4900
		110 kW	3G3RX-B411K
		132 kW	3G3RX-B413K

International Standards Models (EC Directives and UL/cUL Standards)

The RX Inverter meets the EC Directives and UL/cUL standard requirements for worldwide use.

Classification		Applicable standard
EC Directives	EMC Directive	EN61800-3: 2004
	Low-voltage Directive	EN61800-5-1: 2007
UL/cUL Standards		UL508C

Human Environment-friendly, High-performance, General-purpose Inverters Suitable for Various Advanced Applications

■High Performance

High Starting Torque

With the vector control and auto-tuning functions, the RX Series has achieved high starting torque in excess of 200% at 0.3 Hz.

Trip Suppression

This Inverter features two trip suppression functions: "Overcurrent trip suppression function" to suppress overcurrent trip during acceleration, and "Overvoltage suppression function during deceleration" to suppress overvoltage trip during deceleration. Therefore, the RX Series provides tough operational capabilities regardless of the severe time setting of acceleration and deceleration.

■Various Applications

Sensor-less Vector Control at 0 Hz

The RX Series provides sensor-less vector control, which is useful for up/down applications. It can provide a high torque of 150%, even at a speed reference of 0 Hz (150% torque is available when the Inverter capacity is increased by one rank). This function contributes to simplification of control programs and extension of the service life of the brake.

Emergency Shutoff Function

By switching the dedicated switch (SW1) this function enables you to change the multi-function input (input 3) to the emergency shutoff input. You can directly turn off a motor control power module without operating the software. This function simplifies construction of safety applications.

Built-in Braking Circuit (up to 22 kW)

The Inverter models with 22 kW or lower capacity incorporate a braking transistor, enabling space-saving configuration for applications that need rapid acceleration and stop.

Restart Speed Search Function

For a free-running motor (e.g. a fan motor), this function checks the direction of rotation and frequency, enabling smooth restart of the motor.

High-torque Multi-operation

The RX Series enables balanced torque control for the whole system, in proportion to multiple motor loads.

Deceleration Stop During Power Failure

During a power failure or momentary power interruption, the RX Series can decelerate and stop a motor by using the motor braking energy.

■ Human Environment-friendly Features

More Simplified Parameter Settings and View

- Only parameters that have been changed from the default settings can be viewed.
- With the user setting function, only 12 parameters for frequent use can be viewed.

Compliance With Safety Standards

The RX Series meets the requirements of the CE and UL/cUL and complies with various standards.

The RoHS Directive


The standard model meets the requirements of the RoHS Directive.

Easily Meets the Requirements Specified by the Ministry of Land, Infrastructure and Transport of Japan

The RX Series incorporates a zero-phase reactor (radio noise filter) as a standard specification. When an optional DC reactor is added, the RX Series meets the requirements specified by the Ministry of Land, Infrastructure and Transport of Japan.


1-2 Appearance and Names of Parts

When the product is unpacked, it appears as below. (Example of 3G3RX-A2150/A4150 to A2220/A4220)



Open the terminal block cover and you can connect cables to the main circuit terminal block, as well as the control circuit terminal block.

Also, open the front cover and you can mount the optional board.







Chapter 2

Design





2-1	Installation	2-1
2-2	Wiring	2-5

2-1 Installation

DANGER

	Turn off the power supply and implement wiring correctly. Not doing so may result in a serious injury due to an electric shock.
	Wiring work must be carried out only by qualified personnel. Not doing so may result in a serious injury due to an electric shock.
	Do not change wiring and slide switches (SW1), put on or take off Digital Operator and optional devices, replace cooling fans while the input power is being supplied. Doing so may result in a serious injury due to an electric shock.
	Be sure to ground the unit. Not doing so may result in a serious injury due to an electric shock or fire. (200-V class: type-D grounding, 400-V class: type-C grounding)

CAUTION

	Do not connect resistors to the terminals (PD/+1, P/+, N/-) directly. Doing so might result in a small-scale fire, heat generation or damage to the unit.
	Install a stop motion device to ensure safety. Not doing so might result in a minor injury. (A holding brake is not a stop motion device designed to ensure safety.)
	Be sure to use a specified type of braking resistor/regenerative braking unit. In case of a braking resistor, install a thermal relay that monitors the temperature of the resistor. Not doing so might result in a moderate burn due to the heat generated in the braking resistor/regenerative braking unit. Configure a sequence that enables the Inverter power to turn off when unusual overheating is detected in the braking resistor/regenerative braking unit.
	The Inverter has high voltage parts inside which, if short-circuited, might cause damage to itself or other property. Place covers on the openings or take other precautions to make sure that no metal objects such as cutting bits or lead wire scraps go inside when installing and wiring.

Safety Information

■ Installation and Storage

Do not store or use the product in the following places.

- Locations subject to direct sunlight.
- Locations subject to ambient temperature exceeding the specifications.
- Locations subject to relative humidity exceeding the specifications.
- Locations subject to condensation due to severe temperature fluctuations.
- Locations subject to corrosive or flammable gases.
- Locations subject to exposure to combustibles.
- Locations subject to dust (especially iron dust) or salts.
- Locations subject to exposure to water, oil, or chemicals.
- Locations subject to shock or vibration.

■ Transporting, Installation, and Wiring

- Do not drop or apply strong impact on the product. Doing so may result in damaged parts or malfunction.
 - Do not hold by the front cover and terminal block cover, but hold by the fins during transportation.
 - Do not connect an AC power supply voltage to the control input/output terminals. Doing so may result in damage to the product.
 - Be sure to tighten the screws on the terminal block securely.
- Wiring work must be done after installing the unit body.
- Do not connect any load other than a three-phase inductive motor to the U, V, and W output terminals.
 - Take sufficient shielding measures when using the product in the following locations. Not doing so may result in damage to the product.

Locations subject to static electricity or other forms of noise.


Locations subject to strong magnetic fields.

Locations close to power lines.

Precautions for Use

■ Installation

- Install the Inverter vertically on the wall.
- Install the Inverter on a nonflammable wall surface material, like metal.




■ Main Circuit Power Supply


- Confirm that the rated input voltage of the Inverter matches the AC power supply voltage.

■ Installation Environment

- Increased ambient temperatures will shorten the life of the Inverter.
- Keep the Inverter away from heating elements (such as a braking resistor, DC reactor, etc.).
If the Inverter is installed in an enclosure, keep the ambient temperature within the range of the specifications, taking dimensions and ventilation into consideration.



- When several RX models are installed in an enclosure and a ventilation fan is mounted in the enclosure, be careful about the layout of the Inverters and the air intake apertures. Depending on the internal layout of the panel, the Inverter's cooling effect may deteriorate, resulting in an increase in ambient temperature. Also, use thorough caution in making sure that the Inverter's ambient temperature is within the allowable operating temperature range.



- Before installing the Inverter, place a cover over all the ventilation openings to shield them from foreign objects. After completing the installation process, be sure to remove the covers from the Inverter before operation.

- Below is the heat radiation according to the Inverter capacity.

Inverter capacity (kw)	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5
Load with 70% loss (W)	64	76	102	127	179	242	312	435	575	698
Load with 100% loss (W)	70	88	125	160	235	325	425	600	800	975
Efficiency at rated output (%)	85.1	89.5	92.3	93.2	94.0	94.4	94.6	94.8	94.9	95.0


Inverter capacity (kw)	22	30	37	45	55	75	90	110	132
Load with 70% loss (W)	820	1100	1345	1625	1975	2675	3375	3900	4670
Load with 100% loss (W)	1150	1550	1900	2300	2800	3800	4800	5550	6650
Efficiency at rated output (%)	95.0	95.0	95.1	95.1	95.1	95.2	95.2	95.2	95.2

- To raise the carrier frequency, reduce the output current (or derate the rated current).

Backing Plate

■ Inverter with 22 kW or Lower Capacity


When running cables, cut the points between the backing plate and unnecessary portions with nippers or a wire cutter, and remove.



■ Inverter with 30 kW or Higher Capacity


For Connection Without Cable Conduit

Make a cut in the rubber bushing of the backing plate with nippers or a wire cutter, and insert a cable.



For Connection With Cable Conduit

Remove the rubber bushing from the conduit connecting portions, and connect the cable conduit.




* Do not remove the rubber bushing unless you connect a cable conduit.

Otherwise, the cable sheath may be damaged by the inner edge of the backing plate, resulting in short-circuit or ground fault.


2-2 Wiring

Standard Connection Diagram



*1 L is the common reference for analog input and also for analog output.

■ Main Circuit Terminals

Terminal symbol	Terminal name	Description
R/L1, S/L2, T/L3	Main power supply input terminal	Connect the input power supply.
U/T1, V/T2, W/T3	Inverter output terminal	Connect to the 3-phase motor.
PD/+1, P/+	External DC reactor terminal	Remove the short-circuit bar between terminals "PD/+1" and "P/+", and connect the optional power factor improvement DC reactor.
P/+, RB	Braking resistor connection terminals	Connect optional external braking resistors. (The RB terminal is provided for the Inverters with 22 kW or lower capacity.)
P/+, N/-	Regenerative braking unit connection terminal	Connect optional regenerative braking units.
G 	Ground terminal	Inverter case ground terminal. Connect this terminal to the ground. type-D (200-V class), type-C (400-V class)

■ Control Circuit Terminal

	Terminal symbol	Terminal name	Description	Specifications
Analog Frequency reference input	H	Frequency reference power supply output	+10 V DC power supply for the O terminal.	Allowable load current: 20 mA max.
	O	Frequency reference input (Voltage)	With a 0 to 10 V DC voltage input, the frequency reaches the maximum at 10 V. Set at A014 if the maximum frequency needs to be achieved at lower than 10 V.	Input impedance 10 k Ω Allowable input voltage range: -0.3 to +12 V DC
	O2	Auxiliary frequency reference input (Voltage)	With a 0 to ± 10 V DC voltage input, the O2 signal is added to the frequency reference signal of the O or OI terminal. By changing the setting, the frequency reference can be input even with the O2 terminal independently.	Input impedance 10 k Ω Allowable input voltage range: 0 to ± 12 V DC
	OI	Frequency reference input (Current)	With a 4 to 20 mA DC current input, the maximum frequency is set at 20 mA. The OI signal is only active when the AT terminal is ON. Allocate the AT function to the multi-function input terminal.	Input impedance 100 Ω Allowable max. current: 24 mA
	L	Frequency reference common	Common terminal for the frequency setting signals (O, O2 and OI) and the analog output terminals (AM and AMI). Do not connect this terminal to the ground.	


Continued to the next page

		Terminal symbol	Terminal name	Description	Specifications
Analog	Monitor output	AM	Multi-function analog output (Voltage)	This terminal outputs a signal selected from the "0 to 10 V DC Voltage Output" monitor items: Output frequency, Output current, Output torque (with/without sign), Output voltage, Input power, Electronic thermal load rate, LAD frequency, Motor temperature, and Fin temperature.	Allowable max. current: 2 mA
		AMI	Multi-function analog output (Current)	This terminal outputs a signal selected from the "4 to 20 mA DC Current Output" monitor items: Output frequency, Output current, Output torque (without sign), Output voltage, Input power, Electronic thermal load rate, LAD frequency, Motor temperature, and Fin temperature.	Allowable load impedance: 250 Ω max.
Digital (contact)	Monitor output	FM	Multi-function digital output	This terminal outputs a signal selected from the "0 to 10 V DC Voltage Output (PWM)" monitor items: Output frequency, Output current, Output torque (without sign), Output voltage, Input power, Electronic thermal load rate, LAD frequency, Motor temperature, Fin temperature, Digital output frequency, and Digital current monitor. "Digital output frequency", and "Digital current monitor" output a digital pulse at 0/10 V DC pulse voltage and 50% duty ratio.	Allowable max. current: 1.2 mA Max. frequency: 3.6 kHz
	Power supply	P24	Internal 24 V DC	24 V DC power supply for contact input signal. When the source logic is selected, this terminal functions as the contact input common terminal.	Allowable max. output current: 100 mA
		CM1	Input common	Common terminal for the interface power supply P24 terminal, thermistor input TH terminal and digital monitor FM terminal. When the sink logic is selected, this terminal functions as the contact input common terminal. Do not connect this terminal to the ground.	

Continued to the next page

		Terminal symbol	Terminal name	Description	Specifications	
Digital (contact)	Contact input	RUN command	FW	Forward rotation command terminal	When the FW signal is ON, the motor runs forward. When it is OFF, the motor decelerates and stops.	[Contact input ON condition] Voltage between each input terminal and the PLC terminal :18 V DC or more
		Function / Selection	1 2 3 4 5 6 7 8	Multi-function input	Select 8 functions from among the 61 functions and allocate them to terminals 1 to 8. Note: Only terminals 1 and 3 can be used for the emergency shutoff function. For details, refer to "Emergency Shutoff Function" (page 2-9).	Input impedance between each input terminal and the PLC terminal: 4.7 kΩ Allowable max. voltage: Voltage between each input terminal and the PLC terminal: 27 V DC Load current at 27 V DC power supply voltage: Approx. 5.6 mA
			PLC	Multi-function input common	The sink and source logic for contact input can be switched by connecting a short-circuit bar on the control terminal block. Short-circuiting P24 and PLC ⇒ Sink logic, Short-circuiting PLC and CM1 ⇒ Source logic To activate contact input via an external power supply, remove the short-circuit bar and connect PLC terminal to the external interface circuit.	
	Open collector output	Status / Factor	11 12 13 14 15	Multi-function output	Select 5 functions from among 45, and allocate them to terminals 11 through 15. If an alarm code is selected in C062, terminals 11 to 13, or terminals 11 to 14 always output an alarm factor code (e.g. Inverter trip). The signal between each terminal and CM2 always corresponds to the sink or source logic.	Between each terminal and CM2 Voltage drop 4 V max. at power-on Max. allowable voltage: 27 V DC
			CM2	Multi-function output common	Common terminals for multi-function output terminals 11 to 15.	Max. allowable current: 50 mA
Digital (contact)	Relay output Status, alarm, etc.		AL2 AL1	Relay output	Select the desired functions from among 45 functions, and allocate them. SPDT contact output. By factory default, the relay output (AL2, AL1) contact selection (C036) is set at NC contact between AL2-AL0, and NO contact between AL1-AL0.	Contact max. capacity AL2-AL0 250 V AC, 2 A (Resistance) 0.2 A (Induction) AL1-AL0 250 V AC, 1 A (Resistance) 0.2 A (Induction) Contact min. capacity 100 V AC, 10 mA 5 V DC, 100 mA
			AL0	Relay output common		

Continued to the next page

			Terminal symbol	Terminal name	Description	Specifications
Analog	Analog input	Sensor	TH	External thermistor input Terminal	Connect an external thermistor to this terminal, to trip the Inverter when a temperature error occurs. The CM1 terminal functions as the common terminal. [Recommended thermistor characteristics] Allowable rated power: 100 mW min. Impedance at temperature error: 3 k Ω Temperature error detection level is adjustable between 0 and 9999 Ω .	Allowable input voltage range 0 to 8 V DC [Input circuit] 

Slide Switch (SW1) Settings

The built-in slide switch is used to enable or disable the emergency shutoff function. (Factory Default: Disabled)

* For the location of the slide switch, refer to (page 2-11).

Emergency Shutoff Function (Factory Default: Disabled)

• This function is intended to turn off the Inverter output (stop switching the main element) via only the multi-function input terminal of the hardware circuit without going through the CPU software.

* This function stops switching of the main element. The circuit is not electrically turned off. While the power supply is ON, do not touch the Inverter terminals and power cable (e.g. motor cable). Doing so may result in electric shock, injury or ground fault.

• When this function is enabled, the multi-function input terminals 1 and 3 are exclusively used for this function. No other function can be allocated to these terminals. If another function has been allocated, it will automatically be disabled, and terminals 1 and 3 are changed to the emergency shutoff terminals.

Function of multi-function input terminal 1

Reset signal (RS) / NO contact (Fixed)

This signal is used to reset the Inverter, and to reset the emergency shutoff trip [E37.*].

Function of multi-function input terminal 3

Emergency shutoff signal (EMR) / NC contact (Fixed)

This signal is used to turn off the Inverter output without using the built-in CPU.

With this signal input, the Inverter activates an emergency shutoff trip [E37. *].

* If multi-function input terminal 3 has not been connected or disconnected, or if the signal logic is not matched, the Inverter activates an emergency shutoff trip [E37. *]. After checking the cable connection and the signal logic, input the reset signal (RS).

Emergency shutoff trip [E37. *] can be reset only by the reset signal (RS) via multi-function input terminal 1. (It cannot be reset with the Digital Operator.)

• To enable this function, set the slide switch SW1 lever in the Inverter to [ON].

(With the factory default setting, slide switch SW1 is [OFF]. [This function is disabled.])

* Before operating slide switch SW1, make sure that the input power supply is OFF.

Slide switch SW1 setting and status of multi-function input terminals 1 and 3								
Slide switch (SW1) setting	Multi-function input terminal 1				Multi-function input terminal 3			
	Multi-function input 1 selection [C001]		Multi-function input 1 operation selection [C011] ^{*1}		Multi-function input 3 selection [C003]		Multi-function input 3 operation selection [C013] ^{*1 *2}	
SW1 OFF Emergency shutoff: Disabled (factory default)	[Can be selected randomly] ^{*4}		[Can be selected randomly] ^{*4}		[Can be selected randomly] ^{*4}		[Can be selected randomly] ^{*4}	
	Factory default	01 (RV)	Factory default	00 (NO)	Factory default	12 (EXT)	Factory default	00 (NO)
SW1 ON Emergency shutoff: Enabled ^{*5}	Automatic allocation to multi-function input terminals 1 and 3, and the input terminal with 18 (RS) setting ^{*3}							
	Fixed function (Cannot be changed)	18 (RS)	Fixed function (Cannot be changed)	00 (NO)	Fixed function (Cannot be changed)	64 (EMR)	Fixed function (Cannot be changed)	01 (NC)
Turning SW1 on, and then off Emergency shutoff: Disabled ^{*3 *5}	[Can be selected randomly] ^{*4}		[Can be selected randomly] ^{*4}		[Can be selected randomly] ^{*4}		[Can be selected randomly] ^{*4}	
	Holds setting while SW1 is ON.	18 (RS)	Holds setting while SW1 is ON.	00 (NO)	Emergency shutoff function: Reset	no (no allocation)	Holds setting while SW1 is ON.	01 (NC)

*1. With the terminal with input terminal selection [18 (RS)], NO/NC selection is fixed to [00 (NO)].

*2. When [C003] is [64 (EMR)], [C013] is fixed to [01 (NC)].


*3. If [18 (RS)] has been allocated to a multi-function input terminal (except for 3) other than terminal 1 before switch SW1 is set to "ON", the input terminal selection for the relevant terminal will be automatically changed to "no (no allocation)" by setting SW1 to "ON". This is done in order to prevent duplicated allocation of this function. Then, even if SW1 is reset to [OFF], the initial allocation cannot be restored. The User should Re-allocate the terminal function.

Example) When the multi-function input terminal 2 [C002] is [18 (RS)], setting SW1 to [ON] changes the [C002] setting to [no (no allocation)]. [18 (RS)] will be allocated to the multi-function input terminal 1 [C001].

Then, even if SW1 is reset to [OFF], the multi-function input terminal 2 [C002] setting is [no (no allocation)], and the multi-function input terminal 1 [C001] setting is [18 (RS)].

*4. Input terminal selection [64 (EMR)] cannot be selected with the Digital Operator. When slide switch SW1 is set to [ON], this function will be automatically allocated.

- *5. Once slide switch SW1 is set to [ON], allocation of multi-function input terminals 1 and 3 will not be restored, even if SW1 is reset to [OFF] afterward. Re-allocate the terminal function.



Wiring the Main Circuit Terminals

■ Main Power Supply Input Terminals (R/L1, S/L2, T/L3)

- Use an earth leakage breaker for circuit (wiring) protection between the power supply and the main power supply terminals (R/L1, S/L2, T/L3).
- An earth leakage breaker may malfunction due to the effect of high frequency. Use an earth leakage breaker with a large high-frequency sensitivity current rating.
- If the Inverter protection function is activated, a malfunction or accident may have occurred to your system. Connect a magnetic contactor to turn off the Inverter power supply.
- Do not start or stop the Inverter by switching ON/OFF the magnetic contactor connected on the Inverter power supply input (primary) side and output (secondary) side.
To start or stop the Inverter via an external signal, use the operation command (FW or RV) on the control circuit terminal block.
- This Inverter uses a 3-phase power supply. A single-phase power supply cannot be used.
- Do not use this Inverter with a phase loss power input. Doing so may damage the Inverter.
By factory default, the phase loss input protection is disabled. If a phase of power supply input is interrupted, the Inverter reverts to the following status:

R/L1-phase or T/L3-phase is interrupted: The Inverter does not operate.

S/L2-phase is interrupted: The Inverter reverts to single-phase operation, causing a trip (due to undervoltage, overcurrent, etc.) or damage to the Inverter.

Even if the power input is under a phase loss condition, the internal capacitor is charged with voltage, causing an electric shock or injury.

When changing the cable connections, refer to the instructions on page 2-1.

- In the following cases, the internal converter module may be damaged. Use caution to avoid them:
Imbalance of power supply voltage is 3% or more.
Power supply capacity is ten times or more than the Inverter capacity, and also 500 kVA or more.
Rapid change in power supply voltage.

Example) When several Inverters are connected with a short bus.
When the phase advance capacitor is turned on/off.

- Do not turn power on/off more than once every 3 minutes.
Doing so may damage the Inverter.

■ Inverter Output Terminals (U/T1, V/T2, W/T3)

- For connection of the output terminal, use the applicable cable or a cable with a larger diameter. Otherwise, the output voltage between the Inverter and the motor may drop. Particularly during low-frequency output, a voltage drop occurs with the cable, resulting in motor torque reduction.
- Do not mount a phase advance capacitor or surge absorber. These devices cause the Inverter to trip, or may cause damage to the capacitor or surge absorber.
- If the cable length exceeds 20 m (particularly, with 400-V class), a surge voltage may be generated at the motor terminal due to stray capacitance or inductance of the cable, causing the motor to burn out.
- To connect several motors, provide a thermal relay for each.
- The RC value of each thermal relay should be 1.1 times of the motor rated current. The relay may trip easily depending on the cable length. In this case, connect an AC reactor to the Inverter output.

■ DC Reactor Connection Terminal (PD/+1, P/+)

- This terminal is used to connect the optional DC reactor for power factor improvement. By factory default, a short-circuit bar has been connected between the terminals PD/+1 and P/+. Before connecting the DC reactor, remove this short-circuit bar.
- The length of the DC reactor connection cable should be 5 m or less.

If the DC reactor is not used, do not remove the short-circuit bar.


If you remove the short-circuit bar without connecting the DC reactor, no power is supplied to the Inverter main circuit, disabling operation.

■ External Braking Resistor Connection Terminal (P/+, RB)/Regenerative Braking Unit Connection Terminal (P/+, N/-)

- The Inverters with 22 kW or lower capacity incorporate a regenerative braking circuit. To improve braking capability, mount the optional external braking resistor to this terminal. Do not mount a resistor whose resistance is lower than the specified value. Doing so may damage the regenerative braking circuit.
- The Inverters with 30 kW or higher capacity do not incorporate a regenerative braking circuit. To improve braking capability, the optional regenerative braking unit and braking resistor are required. In this case, connect the regenerative braking unit terminals (+, -) to the Inverter terminals (P/+, N/-).
- The cable length should be 5 m or less. Twist the two wires.
- Do not connect any device other than the optional regenerative braking unit or external braking resistor to this terminal.


■ Ground Terminal (G)

- To prevent electric shock, be sure to ground the Inverter and the motor.
- According to the Electric Apparatus Engineering Regulations, the 200-V class Inverter should be connected to the grounding electrodes under type-D grounding conditions (conventional type 3 grounding: ground resistance 100 Ω or less), the 400-V class Inverter should be connected to the grounding electrodes under type-C grounding conditions (conventional special type 3 grounding: ground resistance 10 Ω or less).
- For the ground cable, use the applicable cable or a cable with a larger diameter. Make the cable length as short as possible.
- When several Inverters are connected, the ground cable must not be connected across several Inverters, and must not be looped. Otherwise, the Inverters may malfunction.



■ Installing Screws in the Main Circuit Terminal Block

- For the main circuit terminal blocks of 3G3RX-A2055/-A2075/-A4055/-A4075, be sure to install the terminal block screw washers with their grooved sides aligned vertically, as shown below. Not doing so may result in a contact failure or fire.
(Intended terminals: R/L1, S/L2, T/L3, PD/+1, P/+, N/-, U/T1, V/T2, W/T3, RB)



■ Arrangement of Main Circuit Terminals

The terminal arrangement on the Inverter main circuit terminal block is shown below.

Terminal arrangement						Applicable model																					
<div><div><div><div>RoTo</div><div></div></div><div>CHARGE LED indicator</div></div><div><div><div>PD/+1P/+ short-circuit bar</div><div></div></div><div>PD/+1 - P/+ short-circuit bar</div></div></div> <table><tr><td>R/L1</td><td>S/L2</td><td>T/L3</td><td>U/T1</td><td>V/T2</td><td>W/T3</td></tr><tr><td>PD/+1</td><td>P/+</td><td>N/-</td><td>RB</td><td>G</td><td>G</td></tr></table> <p>When not using the DC reactor, keep the PD/+1 - P/+ short-circuit bar attached.</p> <p>[EMC filter function switching method]</p> <div><div><div><div></div><div>Dummy plug (green)</div></div><div><div>Filter enable pin (J61)</div><div>Short plug</div></div><div><div>Filter disable pin (J62)</div></div></div><p>In order to enable the EMC filter function, set up the plug inserted into the filter enable pin (J61) and filter disable pin (J62) as shown in the table below. Confirm that electrical power has been disconnected before performing this setup. Not doing so may result in electric shock. Also, use with the plug inserted.</p><table><tr><th></th><th>Filter enable pin (J61)</th><th>Filter disable pin (J62)</th></tr><tr><td>EMC filter disabled</td><td>Dummy plug (green)</td><td>Short plug</td></tr><tr><td>EMC filter enabled (factory default)</td><td>Short plug</td><td>Dummy plug (green)</td></tr></table></div>						R/L1	S/L2	T/L3	U/T1	V/T2	W/T3	PD/+1	P/+	N/-	RB	G	G		Filter enable pin (J61)	Filter disable pin (J62)	EMC filter disabled	Dummy plug (green)	Short plug	EMC filter enabled (factory default)	Short plug	Dummy plug (green)	3G3RX-A2004 to A2037 3G3RX-A4004 to A4037 Ro,To: M4 Ground terminal: M4 Others: M4
R/L1	S/L2	T/L3	U/T1	V/T2	W/T3																						
PD/+1	P/+	N/-	RB	G	G																						
	Filter enable pin (J61)	Filter disable pin (J62)																									
EMC filter disabled	Dummy plug (green)	Short plug																									
EMC filter enabled (factory default)	Short plug	Dummy plug (green)																									
<div><div><div><div>CHARGE LED indicator</div><div><div>RB</div><div>RoTo</div><div></div></div></div></div><table><tr><td>R/L1</td><td>S/L2</td><td>T/L3</td><td>PD/+1</td><td>P/+</td><td>N/-</td><td>U/T1</td><td>V/T2</td><td>W/T3</td></tr></table><div><div><div><div>G</div><div></div></div><div>Ground terminal with short-circuit bar (shaded area) for EMC filter function switching</div></div><div><div><div>PD/+1P/+ short-circuit bar</div><div></div></div><div>PD/+1 - P/+ short-circuit bar</div></div><div><div><div>G</div><div></div></div><div>Ground terminal</div></div></div><p>When not using the DC reactor, keep the PD/+1 - P/+ short-circuit bar attached.</p><p>[EMC filter function switching method]</p><div><div><div></div><div>EMC filter enabled (factory default)</div></div><div><div></div><div>EMC filter disabled</div></div></div></div>						R/L1	S/L2	T/L3	PD/+1	P/+	N/-	U/T1	V/T2	W/T3	3G3RX-A2055, A2075 3G3RX-A4055, A4075 Ro,To: M4 Ground terminal: M5 Others: M5												
R/L1	S/L2	T/L3	PD/+1	P/+	N/-	U/T1	V/T2	W/T3																			
<div><div><div></div><div>EMC filter enabled (factory default)</div></div><div><div></div><div>EMC filter disabled</div></div></div>						3G3RX-A2110 3G3RX-A4110 Ro,To: M4 Ground terminal: M6 Others: M5																					

Terminal arrangement		Applicable model
<div><div>CHARGE LED indicator</div><div><div><div>R/L1</div><div>S/L2</div><div>T/L3</div><div>PD/+1</div><div>P/+</div><div>N/-</div><div>U/T1</div><div>V/T2</div><div>W/T3</div></div><div><div><div><div>G</div><div></div></div></div><div><div>PD/+1 - P/+ short-circuit bar</div><div>When not using the DC reactor, keep the PD/+1 - P/+ short-circuit bar attached.</div></div><div><div><div>G</div><div></div></div></div></div></div></div>		<div>3G3RX-A2150 to A2185</div> <div>3G3RX-A4150 to A4220</div> <div>Ro,To: M4</div> <div>Ground terminal: M6</div> <div>Others: M6</div>
<div><div>[EMC filter function switching method]</div><div><div><div><div>EMC filter enabled (factory default)</div></div><div><div>EMC filter disabled</div></div></div></div></div>		<div>3G3RX-A2220</div> <div>Ro,To: M4</div> <div>Ground terminal: M6</div> <div>Others: M8</div>
<div><div>CHARGE LED indicator</div><div><div><div><div>G</div><div></div></div><div><div>R/L1</div><div>S/L2</div><div>T/L3</div><div>PD/+1</div><div>P/+</div><div>N/-</div><div>U/T1</div><div>V/T2</div><div>W/T3</div></div><div><div><div><div>G</div><div></div></div></div><div><div>PD/+1 - P/+ short-circuit bar</div><div>When not using the DC reactor, keep the PD/+1 - P/+ short-circuit bar attached.</div></div></div></div></div></div>		<div>3G3RX-A2300</div> <div>Ro, To: M4</div> <div>Ground terminal: M6</div> <div>Others: M8</div>
<div><div>Ground terminal with short-circuit bar (shaded area) for EMC filter function switching</div><div>[EMC filter function switching method]</div><div><div><div><div>EMC filter enabled (factory default)</div></div><div><div>EMC filter disabled</div></div></div></div></div>		<div>3G3RX-A4300</div> <div>Ro,To: M4</div> <div>Ground terminal: M6</div> <div>Others: M6</div>
<div><div><div><div>EMC filter enabled (factory default)</div></div><div><div>EMC filter disabled</div></div></div></div>		<div>3G3RX-A2370</div> <div>3G3RX-A4370</div> <div>Ro,To: M4</div> <div>Ground terminal: M8</div> <div>Others: M8</div>

Terminal arrangement	Applicable model
<div><p>CHARGE LED indicator</p><p>R/L1 S/L2 T/L3 PD/+1 P/+ N/- U/T1 V/T2 W/T3 G</p><p>PD/+1-P/+ short-circuit bar</p><p>When not using the DC reactor, keep the PD/+1-P/+ short-circuit bar attached.</p><p>Ground terminal with short-circuit bar (shaded area) for EMC filter function switching</p><p>[EMC filter function switching method]</p><p>EMC filter enabled (factory default)</p><p>EMC filter disabled</p></div>	<div><p>3G3RX-A2450 3G3RX-A4450 3G3RX-A4550</p><p>Ro,To: M4 Ground terminal: M8 Others: M8</p></div>
<div><p>CHARGE LED indicator</p><p>R/L1 S/L2 T/L3 PD/+1 P/+ N/- U/T1 V/T2 W/T3</p><p>PD/+1 - P/+ short-circuit bar</p><p>When not using the DC reactor, keep the PD/+1 - P/+ short-circuit bar attached.</p><p>Ground terminal with short-circuit bar (shaded area) for EMC filter function switching</p><p>[EMC filter function switching method]</p><p>EMC filter enabled (factory default)</p><p>EMC filter disabled</p></div>	<div><p>3G3RX-A2550</p><p>Ro,To: M4 Ground terminal: M8 Others: M10</p></div>

■ Recommended Cable Size, Wiring Device and Crimp Terminal

For Inverter wiring, crimp terminal and terminal screw tightening torque, refer to the table below.

2	Motor output (kW)	Applicable Inverter model	Power cable (mm ²) R, S, T, U, V, W, PD/+1, P/+, N/-	Ground cable (mm ²)	External braking resistor between PD/+1 and RB (mm ²)	Terminal screw size	Crimp terminal	Tightening torque N•m	Circuit breaker or fuse	Applicable device
										Earth leakage breaker (ELB)
Design	0.4	3G3RX-A2004	1.25	1.25	1.25	M4	1.25-4	1.2 (max.1.8)	Fuse (Type J)	30 A
	0.75	3G3RX-A2007	1.25	1.25	1.25	M4	1.25-4	1.2 (max.1.8)		30 A
	1.5	3G3RX-A2015	2	2	2	M4	2-4	1.2 (max.1.8)		30 A
	2.2	3G3RX-A2022	2	2	2	M4	2-4	1.2 (max.1.8)		30 A
	3.7	3G3RX-A2037	3.5	3.5	3.5	M4	3.5-4	1.2 (max.1.8)		30 A
	5.5	3G3RX-A2055	5.5	5.5	5.5	M5	R5.5-5	2.4 (4.0 max.)	Fuse (Type J) or Inverse time circuit breaker	100 A
	7.5	3G3RX-A2075	8	8	8	M5	R8-5	2.4 (4.0 max.)		100 A
	11	3G3RX-A2110	14	14	14	M6	R14-6	4.0 (4.4 max.)		100 A
	15	3G3RX-A2150	22	22	22	M6	22-6	4.5 (4.9 max.)		125 A
	18.5	3G3RX-A2185	30	22	30	M6	38-6	4.5 (4.9 max.)		125 A
	22	3G3RX-A2220	38	30	38	M8	38-8	8.1 (8.8 max.)		125 A
	30	3G3RX-A2300	60 (22 × 2)	30	—	M8	60-8	8.1 (8.8 max.)		225 A
	37	3G3RX-A2370	100 (38 × 2)	38	—	M8 *1	100-8	8.1 (20.0 max.)		225 A
	45	3G3RX-A2450	100 (38 × 2)	38	—	M8 *1	100-8	8.1 (20.0 max.)		250 A
	55	3G3RX-A2550	150 (60 × 2)	60	—	M10	150-10	19.6 (22.0 max.)		300 A

	Motor output (kW)	Applicable Inverter model	Power cable (mm ²) R, S, T, U, V, W, PD/+1, P/+, N/-	Ground cable (mm ²)	External braking resistor between PD/+1 and RB (mm ²)	Terminal screw size	Crimp terminal	Tightening torque N•m	Circuit breaker or fuse	Applicable device
										Earth leakage breaker (ELB)
400-V class	0.4	3G3RX-A4004	1.25	1.25	1.25	M4	1.25-4	1.2 (max.1.8)	Fuse (Type J)	20 A
	0.75	3G3RX-A4007	1.25	1.25	1.25	M4	1.25-4	1.2 (max.1.8)		20 A
	1.5	3G3RX-A4015	2	2	2	M4	2-4	1.2 (max.1.8)		20 A
	2.2	3G3RX-A4022	2	2	2	M4	2-4	1.2 (max.1.8)		20 A
	4.0	3G3RX-A4040	2	2	2	M4	2-4	1.2 (max.1.8)		20 A
	5.5	3G3RX-A4055	3.5	3.5	3.5	M5	R2-5	2.4 (4.0 max.)	Inverse time circuit Breaker	40 A
	7.5	3G3RX-A4075	3.5	3.5	3.5	M5	3.5-5	2.4 (4.0 max.)		40 A
	11	3G3RX-A4110	5.5	5.5	5.5	M6	R5.5-6	4.0 (4.4 max.)		40 A
	15	3G3RX-A4150	8	8	8	M6	8-6	4.5 (4.9 max.)		75 A
	18.5	3G3RX-A4185	14	14	14	M6	14-6	4.5 (4.9 max.)		75 A
	22	3G3RX-A4220	14	14	14	M6	14-6	4.5 (4.9 max.)		75 A
	30	3G3RX-A4300	22	22	-	M6	22-6	4.5 (4.9 max.)		100 A
	37	3G3RX-A4370	38	22	—	M8 *1	38-8	8.1 (20.0 max.)		100 A
	45	3G3RX-A4450	38	22	—	M8 *1	38-8	8.1 (20.0 max.)		150 A
	55	3G3RX-A4550	60	30	—	M8 *1	R60-8	8.1 (20.0 max.)		150 A
	75	3G3RX-B4750	100 (38 x 2)	38	—	M10 *1	100-10	20.0 (22.0 max.)		225 A
	90	3G3RX-B4900	100 (38 x 2)	38	—	M10 *1	100-10	20.0 (22.0 max.)		225 A
	110	3G3RX-B411K	150 (38 x 2)	60	—	M10 *1	150-10	20.0 (35.0 max.)		300 A
	132	3G3RX-B413K	80 x 2	80	—	M10 *1	80-10	20.0 (35.0 max.)		350 A

*1. When the cable is connected without using the crimp terminal (bare wires), use the square washer included with the product.

Note: The cable size is based on the HIV cable (75°C heat resistance).

■ Connection for Separating Inverter Control Circuit Power Supply from Main Power Supply

If the Inverter protection circuit is activated to turn off the magnetic contactor of the Inverter input power supply, the power to the Inverter control circuit is also turned off, and the alarm signal cannot be kept on.

If the alarm signal must be kept on, use control circuit power supply terminals Ro and To.

Connect control circuit power supply terminals Ro and To to the primary circuit of the magnetic contactor according to the following procedure.

(Connection method)

Incoming electricity specifications

200-V class:

200 to 240 V (+10%, -15%)

50, 60 Hz $\pm 5\%$


(282 to 339 V DC)

400-V class:

380 to 480 V (+10%, -15%)

50, 60 Hz $\pm 5\%$

(537 to 678 V DC)




* To separate the control circuit power supply (Ro, To) from the main circuit power supply (R/L1, S/L2, T/L3), observe the following instructions:

- For wiring between terminals Ro and To (terminal screw size: M4), use a cable of 1.25 mm² or more.
- Connect a 3 A fuse to the control circuit power supply cable.
- If the control circuit power supply (Ro, To) is turned on before the main circuit power supply (R/L1, S/L2, T/L3), ground fault detection at power-on is disabled.
- To use a DC power supply for the control circuit power supply (Ro, To), set the multi-function output terminal contact selection (C031 to C036) for the multi-function output terminals (11 to 15) and relay output terminals (AL2, AL1, AL0) to "00". If the multi-function output terminal contact selection is set to "01", the output signal may chatter when the DC power supply is turned off.
- Tightening torque for terminals Ro and To
M4: 1.2 N•m (1.4 max.)

Wiring Control Circuit Terminals

- Terminals L and CM1 are insulated from each other via the input and output signal common terminals.
Do not short-circuit or ground these common terminals.
Do not ground these common terminals via external equipment. (Check the external equipment ground conditions.)
- For wiring the control circuit terminals, use twisted shielded cables (recommended size: 0.75 mm²), and connect the shielded cable to each common terminal.
- The control circuit terminal connection cables should be 20 m or less.
- Separate the control circuit terminal connection cables from the main circuit cable (power cable) and the relay control circuit cable.
- For the connection of the TH (thermistor input) terminal, twist cables with the terminal CM1 individually, and separate them from other PLC common cables.
Since a weak current flows through the thermistor, the thermistor connection cable must be separated from the main circuit cable (power cable). The thermistor connection cable should be 20 m or less.



- To use a relay for the multi-function output terminal, connect a surge-absorbing diode in parallel with the coil.
- Do not short-circuit the analog power supply terminals (between H and L) and/or the interface power supply terminals (between P24 and CM1).
Doing so may result in failure of the Inverter.

Arrangement of the Control Circuit Terminal Block

	H	O2	AM	FM	TH	FW	8	CM1	5	3	1	14	13	11	AL1
L	O	OI	AMI	P24	PLC	CM1	7	6	4	2	15	CM2	12	AL0	AL2

Terminal screw size M3 Tightening torque 0.7 N·m (0.8 max.)

Selecting the Input Control Logic

By factory default the terminal FW and the multi-function input terminal are set to source logic (PNP).

To change the input control logic to sink logic (PNP), remove the short-circuit bar between the terminals PLC and CM1 on the control circuit terminal block, and connect it between the terminals P24 and PLC.

■ Selecting the Sequence Input Method (Sink/Source Logic)

	When the Inverter's internal interface power supply is used	When external power supply is used (Remove the short-circuit bar from the control terminal block.)
Sink logic		
Source logic		

■ Selecting the Sequence Output Method (Sink/Source Logic)

Sink logic		Source logic	
------------	--	--------------	--

Wiring the Digital Operator

- The RX Series Inverter can be operated with the optional 3G3AX-OP01 or 3G3AX-OP05 as well as the standard Digital Operator.
- To use the Digital Operator apart from the Inverter body, place an order for the optional cable 3G3AX-CAJOP300-EE (3 m).
- The optional cable should be 3 m or less. Using a cable longer than 3 m may cause malfunction.

Conforming to EC Directives

■Conforming Standards

- | | |
|------------------------|--------------------|
| •EMC directive | EN 61800-3: 2004 |
| •Low-voltage directive | EN 61800-5-1: 2007 |

■Concept of Conformity

EMC Directive

OMRON products are the electrical devices incorporated and used in various machines or manufacturing equipment. For this reason, we make efforts to conform our products to their related EMC standards so that the machines or equipment which have incorporated our products should easily conform to the EMC standards. The RX models have conformed to the EMC directive EN 61800-3 by following the installation and wiring method as shown below. Your machines or equipment, however, vary in type, and in addition, EMC performance depends on the configuration, wiring, or location of the devices or control panels which incorporate the EC directive conforming products. This in turn does not allow us to confirm the condition and the conformity in which our products are used. Therefore, we appreciate confirmation of the final EMC conformity for the whole machine or equipment on your own.

Wiring the Power Supply

- Keep the ground cable as short as possible.
- Keep the cable between the Inverter and the noise filter as short as possible.

Connecting a Motor to the Inverter

- When connecting a motor to the Inverter, be sure to use shield braided cables.
- Keep the cables as short as possible.

Low-voltage Directive

The RX models have conformed to the EMC directive EN61800-5-1 by performing the machine installation and wiring as shown below.

- The RX models are an open type device. Be sure to install it inside the control panel.
- The power supply and voltage (SELV) with reinforced or double insulation should be used for wiring to the control circuit terminals.
- To satisfy requirements of the LVD (low-voltage) directive, the Inverter must be protected with a molded case circuit breaker (MCCB) in case a short-circuiting accident occurs. Be sure to install a molded case circuit breaker (MCCB) on the power supply side of the Inverter.
- Use one molded case circuit breaker (MCCB) per Inverter.
- Use the crimp-type terminal with an insulation sleeve to connect to the main circuit terminals.

EMC Filters

■Warnings and Instructions

- The 3G3RX frequency inverters meet the limits of EN61800-3, C1/C2/C3, for radiated interference, if the specified line filter is used and installation is performed according to our instructions, and internal line filter is disabled.
- The motor cable should be kept as short as possible in order to avoid electromagnetic emission as well as capacitive currents. The quick voltage changes of the OMRON inverter series cause capacitive currents through the motor cable stray capacitances.
The cable length increases the capacitive current and electromagnetic emission.
It is recommended that the motor cable length does not exceed 50m in any case, also depending on the inverter power range.
It is recommended to install output AC-Reactors (motor chokes) if the cable length exceeds 50m.
- The EMC filters contain capacitors between the phases and the phases to ground as well as discharging resistors. After switching off the line voltage you should wait a minimum of 60 seconds before removing protective covers or touching terminals to avoid **electric shock!**
- The protective conductor connection between filter and drive is recommended without interruptions such as plug or contactors. If power plug or contactor become necessary they should be of the highest quality to provide negligible losses.
- The use of ground fault monitoring devices is not recommended. Should they be compulsory in certain applications for safety reasons, you should choose monitoring devices which are suited for DC-, AC- and HF- ground currents. Standard ground monitoring devices may fail due to the switching nature of the inverter control.
- The line filters have been developed for use in grounded systems.
Use in ungrounded systems is not recommended.

If installed according to the following directions indicated in this section, the frequency inverter comply with the following standards:

Emissions: EN 61800-3 (EN 55011 group 1, Category C1/C2/C3 [Class B/A])

Immunity: EN61800-3, industrial environments

■EMC compliant Installation of Drive Systems

Introduction

This document describes the electromagnetically compatible setup of your drive system with OMRON 3G3RX series inverters. (Electro Magnetic Compatibility = EMC). Read this information carefully and follow the instructions. If necessary, provide this information to third parties. HF interference results from rapid switching of electric currents and voltages. All AC, DC and servo drives very rapidly switch large currents and voltages in the process to supply connected electric motors. They become major sources of interference, generating both line-conducted and radiated interference. The additional use of line filters, also called interference suppression filters, and installation in a metal housing or a switch cabinet further improve the existing interference immunity. For the best possible damping of interference, special line filters have been developed which guarantee you easy assembly and installation along with the necessary electrical reliability. However, effective EMC countermeasures is only ensured if the suitable filter is selected for the particular drive and installed in accordance with these EMC recommendations.

Selection of line filter to reduce line-conducted interference


To reduce line-conducted interference, use the appropriate line filter for each frequency inverter. The below table show you a list of the available line filters for OMRON 3G3RX frequency inverter. The line filters up to 46A (200V class) or 58A (400V class) rated current are built in footprint style, they are fitted behind the respective frequency inverter, and thus require no additional surface space for installation. These filters are intended for installation in switch cabinets as standard. Vertical mounting next to the frequency inverter is also possible. The line filters from 64A (200V class) or 75A (400V class) rated current are built only in booktype style, and can be installed beside the frequency inverter.

Voltage	Inverter model	Listed filter	Voltage	Inverter model	Listed filter
3 x 200V	3G3RX-A2004	AX-FIR2018-RE	3 x 400V	3G3RX-A4004	AX-FIR3010-RE
	3G3RX-A2007			3G3RX-A4007	
	3G3RX-A2015			3G3RX-A4015	
	3G3RX-A2022			3G3RX-A4022	
	3G3RX-A2037			3G3RX-A4040	
	3G3RX-A2055	AX-FIR2053-RE		3G3RX-A4055	AX-FIR3030-RE
	3G3RX-A2075			3G3RX-A4075	
	3G3RX-A2110			3G3RX-A4110	
	3G3RX-A2150	AX-FIR2110-RE		3G3RX-A4150	AX-FIR3053-RE
	3G3RX-A2185			3G3RX-A4185	
	3G3RX-A2220			3G3RX-A4220	
	3G3RX-A2300	AX-FIR2145-RE		3G3RX-A4300	AX-FIR3064-RE
	3G3RX-A2370	AX-FIR3250-RE		3G3RX-A4370	AX-FIR3100-RE
	3G3RX-A2450			3G3RX-A4450	AX-FIR3130-RE
	3G3RX-A2550			AX-FIR3320-RE	3G3RX-A4550
			3G3RX-B4750		
			3G3RX-B4900		
			3G3RX-B411K	AX-FIR3320-RE	
			3G3RX-B413K		

Filter installation

The connecting cable between filter and frequency inverter must be as short as possible and laid separate from other cables/lines. As user you must ensure that the HF impedance between frequency inverter, filter and ground is as small as possible:

Make sure that the connections are metallic and have the largest possible areas. Remove paint and insulating material between the individual mounting points. Use conductive contact grease as anticorrosive. Anodized and yellow-chromated surfaces, e.g. cable/standard-section rail, screws, etc., have a large HF-impedance, although sometimes could be confused with uncoated surfaces.



Single grounding point: Ensure that the ground terminal (PE) of the filter is grounded to the same point or backplate like the ground terminal (PE) of the frequency inverter. An HF ground connection via metal contact between the housings of the filter and the frequency inverter, or solely via cable shield, is not permitted as protective conductor connection. The filter must be solidly and permanently connected with the ground potential so as to avoid the danger of electric shock upon touching the filter if a fault occurs. The metallic backplate of the control cabinet accounts as a single connection point (given the advice about coatings influence.)

You can achieve highest filter installation quality by considering:


Lowest impedance to ground: Connecting it with a grounding conductor of the lowest impedance or parallel/multiple short ground connections if not possible. The cross section of each single protective conductor terminal must be designed for the required nominal load.

Avoid ground loops: Conductor loops act like antennas, especially when they encompass large areas. Consequently: (1) Avoid unnecessary conductor loops and (2) Avoid parallel arrangement of "clean" and interference-prone conductors over longer distances.

Use EMC filters only in grounded systems: The line filters have been developed for use in grounded systems. Use of the line filters in ungrounded systems or locations without proper ground quality is not recommended, because in these applications: (1) Low current to ground increases, (2) The effect of the filter is reduced and (3) The amount of line-conducted and radiated interference increases in proportion to elementary frequency in frequency inverter.

Consider motor cable length: The amount of line-conducted interference also increases as motor cable length increases. Output chokes may be required to countermeasure this effect.

Disconnect internal RFI filter: Always when using external mount EMC filter make sure internal filter is disabled (figure corresponds to a 400V, 55kW case.)



Minimizing radiated interference

The 3G3RX frequency inverters meet the limits of EN61800-3, C1/C2/C3, for radiated interference, if the specified line filter is used and installation is performed according to our instructions, and internal line filter is disabled. Installing inverters only with integrated filters will achieve a limited C3 class category, of application in a limited range of systems, and with limited cable lengths and allowable carrier frequencies.

Achievable line conducted interference limits classes:


Test standard	Test	Comment
EN61800-3: 2004	Conducted emissions Category C1/C2 25m motor cable	Pass
EN61800-3: 2004	Conducted emissions Category C2 100m motor cable	Pass
EN61800-3: 2004	Radiated emissions Category C1/C2 25m motor cable	Pass
EN61800-3: 2004	Radiated emissions Category C2 100m motor cable	Pass

Maximizing immunity. Control and signal lines

Using EMC compliant cables for control signals: To ensure reliable operation of the frequency inverter, analog and digital control lines (encoder connection, all analog inputs, the serial interfaces, etc.) should be laid shielded. You should allow the effective shielding surface to remain as large as possible, i.e., do not move the shield further away than absolutely necessary. As a general rule, the shield has to be applied on both sides on PE, unless differently stated in the device manufacturers documentation. As a basic principle, the shielding of these lines should not be interrupted. Using this shielding can reduce the interference coupled into and out of the cable. The effectiveness of the shielding heavily depends on the construction and the material of the shielding. The screening effectiveness can be characterized by the so called transfer impedance. This effectiveness or performance can be improved by keeping the transfer impedance as low as possible. The transfer impedance is mainly affected by the following variables:

- The cable covering, which is the cable area actually covered by the shielding. It is normally indicated as a percentage value and should be at least 85%.
- The shielding's design. Possible design alternatives are braided cables or shieldings made of metal conduit. These two types should be preferred when shielding is to be implemented.
- The contact (or transition) resistance between the individual stranded conductors of the shielding. The performance of the shielding improves if the resistance is kept as low as possible.


The following diagram shows the transfer impedance for various cable types. By comparing the cables individual design, the shielding effectiveness can be estimated and a suitable cable be chosen.



Controller signal shields connect only to the ends: Single end or both but never midway.

Control signals are not emitter, therefore the target is to create a coverage acting as antenna for the radiated emissions and drain them through single point to the ground... multiple shielding points at different potentials will create undesirable recirculating noise currents through ground loops.

Ensure controller signals shield continuity: Control lines should remain without interruptions directly connecting signal source and signal reception. Should the case this is not possible (terminal box, plug connector or contactor / relay absolutely needed) then this elements should be selected of the highest quality and adequate for the signal to be managed (it is not the same a START/STOP 24VDC signal, than a 5VDC TTL encoder signal, than a 1Vpp sinusoidal signal of a SINCOS technology encoder from lower to highest sensivity to connection quality). As well, shield should be guaranteed continuity by passthrough contact, and never become grounded in this interruption point. We recommend high quality connectors that handle the shielding.



Encoders and sensors from the field: In this case follow the recommendations of the manufacturer of the sensor device. Most encoders and sensors with shielded cables will recommend 360° wrapping of the shield both at the sensing end and at the inverter end. For many of them, the shielding and grounding will be integral to the body of the sensor.

Direct connection as much as possible: Direct connection to the communications port of the control unit is mandatory to reduce connection impedance. This is very important, if there is a long distance between the system and you expect there can be different PE-Potential between the systems.

Shield surface maximization: The effective shield area of these lines to remain as large as possible; i.e., do not move the shield of conductors further away than absolutely necessary. Avoid pigtailed as much as possible. Avoid long unshielded cable runs.


Control system in the same cabinet - Connect shield in both sides, never midway: All analog and digital control lines are laid shielded. With compact systems, if the frequency inverter and the control unit area in the same control cabinet connected at the same PE-Potential, the screen should be connected on both sides of the cable with PE (potential is same).

Control system in separate cabinet - Connect shield only one side: All analog and digital control lines are laid shielded. With distributed systems, if the communications control unit is not in the same cabinet and there is a distance between the systems, we recommend to put the screen only on the side of the frequency inverter, to avoid ground loops because different PE potential.


Distance between sensitive signals and interference sources: The distance between an interference source and an interference sink (interference-threatened device) essentially determines the effects of the emitted interference on the interference sink. The interference field emitted by the frequency inverter falls sharply with increasing distance. Please note that the emitted interference field (frequency range 30 MHz - 1 GHz) of a drive (drive system) is measured at a distance of 10 m in accordance with EN61800-3. Every device placed closer than 10 m to a source of interference will thus be impacted by appreciably higher interference amplitudes. For this reason, you should use only interference-free devices and maintain a minimum distance of 0.25 m from the drive. Devices which react sensitively to interference from electric and magnetic fields should be kept at least a distance of 0.25 m from the following components:

- Frequency inverter
- EMC input/output filters
- Input or output reactors/transformer
- Motor cable (even if shielded)
- External braking resistor and its wiring (even if shielded)
- AC/DC commutator motors, including any attached separate fans
- DC intermediate circuit coupling/wiring (even if shielded)
- Connected inductors like relays, contactors, solenoid valves, brakes (even if shielded)

Avoid parallel runs of power and control lines: The parallel running in same conduit without proper distance of power lines (even shielded cables) and control lines is not allowed. This is source of most of EMC disturbance coupling.



Crossing power lines and control lines: Should power and control lines have to cross unavoidably each other, then they should be layout with a 90° crossing.



If control system recommendations conflict with these in this section: Always follow additional recommendations of control system manufacturer. If these recommendations happen to conflict with those in this section is usually because the control system has a different internal power and isolation structure. If the conflicting recommendation is to connect the shield to a proprietary point other than PE (power ground point) in the control connector, please respect so, and **DO NOT CONNECT THE SHIELD TO PE** on the inverter side, only follow control system manufacturer recommendations (as those are done to maximize immunity for the characteristic control system structure).

Installing the motor cable

If you use an EMC line filter or would like to observe certain limits of line-conducted interference, the motor cable which you use must be shielded. The shield is to be grounded on both sides, over a large area. For this purpose, turn the shield through 180°, for instance, and make large-area contact (360°) with the metal PG screw connections.


Use only copper mesh cable (CV) with 85% coverage. Foil shields often have a higher coupling impedance than mesh shields and are therefore unsuitable.



Some motors have terminal boxes and PG screw connections of plastic. In these cases, the shield should be connected on the motor side to the motor housing, with as large an area as possible, by means of a cable clamp.

Some motors have a rubber gasket between terminal box and motor housing. Very often, the terminal boxes, and particularly the threads for the metal PG screw connections, are painted. Make sure there is always a good metallic connection between the shielding of the motor cable, the metal PG screw connection, the terminal box and the motor housing, and carefully remove this paint if necessary.

The shielding should not be interrupted at any point in the cable. If the use of reactors, contactors, terminals or safety switches in the motor output is necessary, i.e., if the shield must be interrupted, then the unshielded section should be kept as small as possible. It is better to install the reactor, contactor, terminal or safety switch in a metal housing with as much HF damping as possible. The shield connection to the metal housing should again be made with the smallest possible HF impedance, as already described.




Should no shielded motor cable be available, lay the unshielded cable in a metal tube having the best possible shielding effect, for example. The metal tube should have good HF contact with the frequency inverter and the motor housing, e.g., by means of appropriate clamping. Safety grounding always takes precedence over HF grounding. If, for example, a braking chopper / rheostat is to be connected to the DC intermediate circuit, then this connecting line, too, must be shielded. The shield is to be connected on both sides, with a large area (e.g. to the protective ground terminal of the rheostat). Follows EMC compliant installation for motor.


Shielding and grounding layout in control cabinets

Observe the requirements of European standard EN60204-1, "Electrical Equipment of Industrial Machinery". You get optimum EMC only if you properly arrange and mount the OMRON 3G3RX frequency inverter, the appropriate line filter, and the other equipment which might be necessary, on a metal mounting plate, in accordance with the following mounting instructions.

The following figure shows a 3G3RX 400V 1.5kW inverter installed with a footprint filter, and some additional devices (ferrite to minimize high frequency emissions from motor cable and DC reactor to countermeasure harmonic distortion effect in supply network).



The following figure shows a 3G3RX 400V 55kW inverter installed with a booktype filter, and some additional devices (ferrite to minimize high frequency emissions from motor cable and DC reactor to countermeasure harmonic distortion effect in supply network).



■ Additional notes

Influence of motor cable length

Shielded motor cables have quite a high cable capacity towards ground, which increases linearly as cable length increases. A typical rule-of-thumb figure is 200 pF per meter of cable. But these figures vary among different types of cables and are also dependent on the current-carrying capacity. Long motor cables can give rise to the following:

Frequency inverter and servo amplifiers give a pulse-width-modulated square-wave output voltage with quite steep slopes, which causes high reverse-charging currents in the cable capacities towards ground. This reverse-charging current must be additionally supplied by the device. Unwanted switch-off due to overload may occur.

- Long motor cables produce more line-conducted interference.
- Long motor cables lead to the triggering of a ground fault monitoring device that may be present.
- Long motor cables lead to thermal overload of the line filter due to the higher line-conducted interference.

If a motor output choke of appropriate size is used, you have the following advantages:

- It can counteract unwanted shut-off due to overload, described above.
- The thermal load on the EMC line filter is reduced.

Multiple motor applications

In multiple motor applications, i.e., a frequency inverter feeds several motors connected in parallel, you should try to minimize the effective cable capacity and/or the effective length of the shielded cable. You can achieve this by creating a neutral cross-connecting point from which you can supply all motors.

Layout to be done so that the shielding is maintained over the entire length of the cable, if possible, or is only very briefly interrupted. It is better to install this neutral cross-connecting point in a metal housing with as much HF damping as possible. The shield connection from/to the metal housing should again be made with the smallest possible HF impedance, as already described.

Influence of ground fault monitoring devices

In the line filter, capacitors are placed between the phases and ground, which can cause larger charge currents to flow to ground when the filter is first switched on. The amount of this flow has already been minimized by constructional circuit details. Nevertheless, ground fault monitoring devices possibly present may be triggered. Ground currents with high-frequency components and DC components may also flow under normal operating conditions. If faults occur, large DC-carrying ground currents may flow, possibly preventing the ground fault monitoring device from responding. For this reason, the use of ground fault monitoring devices is not recommended.

But should they be prescribed in certain applications for safety reasons, you should choose monitoring devices which are suited for DC, AC and HF ground currents. In addition, you should ensure that their responsiveness and time characteristics are adjustable, so that a disturbance is not immediately caused the first time the frequency inverter is switched on.

Components susceptible to interference

The following components must be classified as particularly susceptible to interference from electromagnetic fields. Special attention should therefore be paid to them during installation:

- Sensors with analog output voltages (< 1 volt)
- Load cells
- Tractive force meters
- Torque measuring hubs
- Resistance thermometer PT100
- Thermoelements
- Anemometers
- Piezoelectric sensors
- AM radios (only long and medium wave)
- Video cameras and TV sets
- Office PCs
- Compact proximity switches and filling level sensors
- Inductive proximity switches and metal detectors

- Ripple control transmitters, baby talkers, etc., i.e. all communication devices which use low-voltage systems as transmission medium
- Devices which do not comply with the pertinent EMC requirements

Built-in filter specifications

3G3RX-E1F includes an embedded EMC filter. However, when using the inverter in Europe, you should comply with the following specifications and requirements to meet the EMC Directive and other standards in Europe:

- Power supply requirements:
 - a. Voltage fluctuation must be -15% to +10% or less.
 - b. Voltage imbalance must be +/- 3% or less.
 - c. Frequency variation must be +/- 4% or less.
 - d. Total harmonic distortion (THD) of voltage must be +/- 10% or less.
- Wiring requirements:
 - a. A shielded wire (screened cable) must be used for motor wiring, and the length of the cable must be according to the following table.
 - b. The carrier frequency must be set according to the following table to meet EMC requirements.
 - c. The main circuit wiring must be separated from the control circuit wiring.
- Environmental requirements:
 - a. Ambient temperature must be within the range -10°C to +40°C.
 - b. Relative humidity must be within the range 20% to 90% (non-condensing).
 - c. Vibrations must be 5.9 m/s² (0.6 G) (10 to 55 Hz) or less. (0.4 to 22 kW)
2.94 m/s² (0.3 G) (10 to 55 Hz) or less. (30 to 132 kW)
 - d. The inverter must be installed indoors (not exposed to corrosive gases and dust) at an altitude of 1000 m or less.





Model	Cat.	Cable length (m)	Carrier frequency (kHz)	Model	Cat.	Cable length (m)	Carrier frequency (kHz)
3G3RX-A2004	C3	5	2.5	3G3RX-A4004	C3	5	2.5
3G3RX-A2007	C3	5	2.5	3G3RX-A4007	C3	5	2.5
3G3RX-A2015	C3	5	2.5	3G3RX-A4015	C3	5	2.5
3G3RX-A2022	C3	5	2.5	3G3RX-A4022	C3	5	2.5
3G3RX-A2037	C3	5	2.5	3G3RX-A4040	C3	5	2.5
3G3RX-A2055	C3	1	1	3G3RX-A4055	C3	1	2.5
3G3RX-A2075	C3	1	1	3G3RX-A4075	C3	1	2.5
3G3RX-A2110	C3	1	1	3G3RX-A4110	C3	1	2.5
3G3RX-A2150	C3	1	1	3G3RX-A4150	C3	1	2.5
3G3RX-A2185	C3	1	1	3G3RX-A4185	C3	1	2.5
3G3RX-A2220	C3	5	2.5	3G3RX-A4220	C3	1	2.5
3G3RX-A2300	C3	5	2.5	3G3RX-A4300	C3	1	2.5
3G3RX-A2370	C3	5	2.5	3G3RX-A4370	C3	1	2.5
3G3RX-A2450	C3	5	2.5	3G3RX-A4450	C3	5	2.5
3G3RX-A2550	C3	5	2.5	3G3RX-A4550	C3	5	2.5
				3G3RX-A4750	C3	10	2.5
				3G3RX-A4900	C3	10	2.5
				3G3RX-B411K	C3	10	2.5
				3G3RX-B413K	C3	10	2.5

Chapter 3



Operation

3-1	Operation Method	3-3
3-2	LCD Display	3-4
3-3	Test Run Procedure	3-5
3-4	Operation	3-6
3-5	Read/Write function and operation	3-13
3-6	Test Run Operation	3-14
3-7	Part Names and Descriptions of the Digital Operator	3-17
3-8	Parameter Transition	3-19
3-9	Parameter List	3-21

⚠ DANGER

	Do not change wiring and slide switches (SW1), put on or take off Digital Operator and optional devices, replace cooling fans while the input power is being supplied. Doing so may result in a serious injury due to an electric shock.
	Do not remove the terminal block cover during the power supply and 10 minutes after the power shutoff. Doing so may result in a serious injury due to an electric shock.
	Do not operate the Digital Operator or switches with wet hands. Doing so may result in a serious injury due to an electric shock.
	Inspection of the Inverter must be conducted after the power supply has been turned off. Not doing so may result in a serious injury due to an electric shock. The main power supply is not necessarily shut off even if the emergency shutoff function is activated.

⚠ CAUTION

	Do not touch the Inverter fins, braking resistors and the motor, which become too hot during the power supply and for some time after the power shutoff. Doing so may result in a burn.
	Take safety precautions such as setting up a molded-case circuit breaker (MCCB) that matches the Inverter capacity on the power supply side. Not doing so might result in damage to property due to the short circuit of the load.

Safety Information

■ Operation and Adjustment

- Be sure to confirm the permissible range of motors and machines before operation because the Inverter speed can be changed easily from low to high.
- Provide a separate holding brake if necessary.

Precautions for Use

■Error Retry Function

- Do not come close to the machine when using the error retry function because the machine may abruptly start when stopped by an alarm.
- Be sure to confirm the RUN signal is turned off before resetting the alarm because the machine may abruptly start.

■Non-Stop Function at Momentary Power Interruption

- Do not come close to the machine when selecting restart in the non-stop function at momentary power interruption selection (b050) because the machine may abruptly start after the power is turned on.


■Operation Stop Command

- Provide a separate emergency stop switch because the STOP key on the Digital Operator is valid only when function settings are performed.
- When checking a signal with the main power supply applied, if a signal voltage is erroneously applied to the control input terminals, the motor may start abruptly. Be sure to confirm safety before checking a signal.

The features and the requirements for each operation method are also given below:

■ To enter the RUN command/frequency reference via the Digital Operator

This action operates the Inverter via a key sequence of the standard or optional Digital Operator. When operating the Inverter only via the Digital Operator, the Inverter does not need to be connected to the control circuit terminal block.



■ To enter the RUN command/frequency reference from the control circuit terminal block


This action operates the Inverter by connecting the external signals (from the frequency setting device, starting switch, etc.) to the control circuit terminal block.

The operation starts by turning ON the RUN command (FW, RV) while the input power supply is turned ON.

Note: that the frequency can be set using a voltage signal or a current signal from the control circuit terminal block, which can be selected according to the system. For details, refer to "Control Circuit Terminal" (page 2-6).

(Requirements for operation)

- RUN command: Switch, Relay etc.
- Frequency reference: External signal (e.g. 0 to 10 V DC, -10 to 10 V DC, 4 to 20 mA)



■ **To enter the RUN command/frequency reference in a combination of Sources from the Digital Operator and the control circuit terminal block**

The RUN command/frequency reference sources can be selected individually from the Digital Operator as well as the control circuit terminal block.

3-2 LCD Display


Backlight

There are two backlight colors in the LCD display, white and orange. They reflect the state of the inverter as follows:

Backlight Color	Contents
White	Normal (not related to inverter driving/stop)
Orange	Warning (Parameter mismatch)
White <-> Orange (Alternate blinking for one second)	Trip (The same as ALARM LED)






Details of LCD Display

The first line of LCD monitor always displays the Display Mode, the Motor Selected, the Inverter RUN Status and the Display Selection.











Item	Content of Display	Content
Display Mode	MONITOR-A	Monitor-A mode
	MONITOR-B	Monitor-B mode
	FUNCTION	Function mode
	TRIP	Trip (error) mode
	WARNING	Warning mode (Alarm)
	OPTION	LCD Configuration Mode
Motor selected	M1	Motor 1 (SET multifunction = OFF)
	M2	Motor 2 (SET multifunction = ON)
Inverter RUN Status	STOP	Stopped
	FWD	Forward running
	REV	Reverse running
Display Selection (b037)	ALL	Display all
	UTL	Function individual display
	USR	User setting display
	CMP	Data compare display
	BAS	Basic display

3-3 Test Run Procedure

Item	Description	Reference page
Installation and Mounting	Install the Inverter according to the installation conditions. • Make sure that the installation conditions are met.	2-1
Wiring and Connection	Connect to the power supply and peripheral devices. • Select peripheral devices that meet the specifications, and wire correctly.	2-5
Power On	Check the following before turning on the power. • Make sure that an appropriate power supply voltage is supplied and that the power input terminals (R/L1, S/L2, and T/L3) are wired correctly. • 3G3RX-A2□: 3-phase 200 to 240 V AC • 3G3RX-A4□: 3-phase 380 to 480 V AC • Make sure that the motor output terminals (U/T1, V/T2, and W/T3) are connected to the motor correctly. • Make sure that the control circuit terminals and the control device are wired correctly and that all control terminals are turned off. • Set the motor to no-load status (i.e., not connected to the mechanical system). • After checking the above, turn on the power.	
Display Status Check	Make sure that there are no faults in the Inverter. • When the power is turned on normally, the display shows: • RUN LED indicator : OFF ALARM LED indicator : OFF • POWER LED indicator : ON • Data display : Displays the set value in d001. • If an error occurs, the error code is displayed on the data display. In this case, refer to "Chapter 5 Maintenance Operations" and make the necessary changes to remedy.	
Parameter Initialization	Initialize the parameters. • Set parameter No. b084 to "2", and set parameter No. b180 to "1".	
Parameter Settings	Set the parameters required for a test run. • Set the motor capacity selection (H003) and the motor pole number selection (H004).	
No-load Operation	Start the no-load motor via the Digital Operator. • Display parameter No. F001, set the output frequency using the  key,  key and the  key, and press the  key to confirm the change. Then, press the  key to rotate the motor.	
Actual Load Operation	Connect the mechanical system and operate via the Digital Operator. • If there are no difficulties with the no-load operation, connect the mechanical system to the motor and operate via the Digital Operator.	
Operation	Refer to "Chapter 4 Functions", and set the necessary parameters.	

3-4 Operation



1- Changing the Display Modes

LCD digital operator has four display modes which can be changed from one to another by pressing the  or  key at Navigation level. Moreover, there are 3 other models called Read mode, Write mode and Option mode. In any display mode, it moves to Read mode or Write mode via  key or  key, and moves to Option mode after pressing ,  and  at the same time. It returns to display modes via  key.

Each mode has its own layers, where contents and parameters settings cannot be changed at Navigation level.

When pressing  key at Navigation level, a cursor will appear on below layer.

- LCD Navigation levels

To move among the different Navigation levels press keys  or  .
The outline of each mode is shown below.

Monitor Mode A

The "d" group inverter parameters and "F~U" group inverter parameter are displayed on the same screen in this mode. The content of "d" group parameter is displayed with big font characters. The function code such as "F001" and contents of "F~U" parameters are displayed, without the function name.

Monitor Mode B (Monitor x 4)

In this mode, four "d" group inverter parameters can be displayed at the same screen. The function codes of these parameters are not displayed.

Function Mode (setting)


In this mode, "F~U" group parameters can be displayed and set. Function code, function name, parameter content and parameter range are shown.

Note: "d" group inverter parameter cannot be set and displayed in this mode.







Trip Mode


Trip information and warning information are displayed in this mode. With inverter trip or a warning happens, the trip screen will be displayed from any display modes.






In Option Mode, Read Mode and Write Mode, the LED or WARNING LED will light up.





2- Option Mode


1- Please press ,  and  key at the same time to enter into the OPTION MODE. The cursor will appear in the first row of the Option Mode menu. Use  or  key to move between the option Mode menu. To return to the navigator layer, press the  key.










2- Select the Language option and press the  key. The cursor will appear in the Language option value. Use the  or  key to select the value to set. Press the  key to store the new value. Press the  key to cancel the new value.



3- The cursor will appear in the second row. (2. Date and Time).




4- Pressing the  key, it enters to the Date and Time layer. Use the  or  key for moving between the Day, Month, Year, Hour, etc...data. When the cursor is over the selected data, pressing  or  key to change the value. The change will be stored after pressing the  key.



The settings available in this mode are:

1. Language
2. Date and Time
3. Read Lock
4. INV Type Select
5. R/W Storage Mode
6. Backlight Auto-off
7. Backlight Flicker
8. Operator Reset
9. Check Mode

Use  or  for moving between the Option Mode Menu.







3- Details of Option Mode



Item	Content	Setting range	Default
Language	Setting language	01: English 02: German 03: French 04: Spanish 05: Italian 06: Portuguese 07: Japanese 08: Chinese 09: Turkish 10: Russian	01
Date and Time	Setting Date and Time for the LCD digital operator	Date: 2000/1/1-2099/12/31 Time: 00:00 - 23:59 Format 1-3	2009/01/01 00:00 1
Read Lock	Set "Read lock" disable to enable, in order to protect the parameter saved in LCD digital operator from being overwritten.	01: Enable 02: Disable	02
INV Type Select	Please select the correct INV type using LCD digital operator. otherwise, "COM ERROR" will be displayed automatically.	01: Type 1 (MX2, LX, RX) 02: Type 2 (JX)	01
R/W Storage Mode	Sets the number of parameter sets for READ/WRITE mode.	01: Single 02: Quad	02
Backlight Auto-Off	When LCD digital operator remains without key operations for 1 minute, LCD backlight will be turned off. When a key is pressed it will be turned on. The Backlight Auto-Off function does not work when trip happened.	01: Off 02: 1 minute	01
Backlight Flicker	The Orange backlight will be enabled or disabled.	01: Enable 02: Disable	01
Operator Reset	Use this function to return to default settings of LCD digital operator. The next items will be reset: 1- Language: English 2: Date and Time: 2009/01/01 THU 00:00 3: Time format: 01:YY/MM/DD 4: Read lock: Disable 5: R/W Storage Mode: Quad 6: Backlight Auto-Off: Off 7: Backlight Flicker: Enable After this, date and time setting is required.	01: YES 02: NO	02
Check Mode	Check if LED and key etc. are normal or not.	Key&Led Check, LCD Check, EEPROM Check, RTC Check, Serial Loopback, Debug Mode, Firmware Version.	-


Note: Please do not execute the EEPROM check. Otherwise, the data (parameters/Drive program) saved in LCD digital operator will be erased..





4- Monitor-A Display Mode


1- Please select monitor mode A by using the  or  key at the navigation layer. The cursor will be displayed in the Monitor-A pressing the  key.









2- After that, use the  or  key to select the function code to be displayed into the Monitor-A.





Use  or  key to move the cursor to the function code (F001 in this case) and use the  or  key to change the function code.







3- Use the  key to access to the function code value. With the  or  key the value can be changed. The changes will be stored after pressing the  key or cancelled pressing the  key.







5- Monitor-B Display Mode


1- Please select the Display Mode Monitor-B using the  or  key at the navigation layer.





2- After pressing the  key the cursor will appear on the first row of the four "d" group inverter parameters. Use the  or  key to move between the four Monitor-B inverter parameters.





3- Pressing the  key the cursor will appear on the function code of the "d" inverter parameters selected. Use the  or  key to select other function code.









- Pressing the  key, the function code is selected, and then displayed on the Monitor-B display Mode.


- Pressing the  key, the change will be cancelled.




6- Function Mode



1- Please select Function Mode by using the  or  key at the navigation level.




2- Pressing the  key the cursor will appear in the function code. Then use the , ,  or  key to select the function that will be changed.








3- After that, pressing  key the cursor will appear in the parameter value. Use the  or  key to select the value to be set.


- To store the parameter value, press the  key.
- Pressing the  key, changes will be cancelled.








7- Trip Mode

1- Select the  or  key to select trip mode at the navigation layer.

2- Pressing the  key, the past trip information (6 trip errors) and the warning information (1 time), that are recorded on the inverter, will be displayed. Trip information is composed in two pages. For change from page 1 (P1) to page 2 (P2), press the  or  key.

Pressing 6 times the  key, it will be displayed the Warning Mode.



Note: When a trip happens, ALARM LED will be light on. Press the  key to reset the inverter.



3-5 Read/Write function and operation


LCD digital operator can read and save inverter parameter settings and copy them to another inverter. Specifically LCD digital operator can save four inverter's parameter sets or one inverter's parameter set and its Drive Programming. It can be selected via the R/W Storage Mode in the LCD configuration Option Mode.


3

Note: If Read operation cannot be executed, please check the Read Lock option in the LCD configuration Option Mode.

R/W Storage Mode - Single READ/WRITE function

When the R/W Storage Mode is selected to "01: Single" (this is done in the LCD configuration: Option Mode), the function Read or Write is executed immediately after pressing  or  key.

After pressing the  key in any display mode, except Write mode and Option mode, the inverter's parameter configuration are read and saved into LCD digital operator Drive Programming program will be transferred to the LCD digital operator automatically after parameter reading is finished. If the inverter supports Drive Programming function, it returns to the previous display after read function is completed.

After pressing the  key in any display mode except Read mode and Option mode, the parameter settings stored in LCD digital operator are transferred to the inverter. If the inverter supports Drive Programming, it will be transferred to the inverter automatically after the parameter copy is finished. It will return to the previous display after write function is completed.

R/W Storage Mode - Quad READ function

When the R/W storage mode is selected to 02: Quad option, it will be possible to handle four sets of inverter parameters or read/write an Drive Programming program independently. In this case, LCD digital operator can save four sets of inverter parameters or one set of inverter parameters and one Drive Programming program. Please note that one Drive Programming program takes up three sets of inverter parameters, which are No.2, No.3 and No.4.

Note: Refer to "LCD Line Digital Operator User's Manual" for more information.

3-6 Test Run Operation

Power On

■Checkpoints Before Turning On the Power

- Make sure that an appropriate power supply voltage is supplied and that the power input terminals (R/L1, S/L2, and T/L3) are wired correctly.
3G3RX- A2□: 3-phase 200 to 240 V AC
3G3RX- A4□: 3-phase 380 to 480 V AC
- Make sure that the motor output terminals (U/T1, V/T2, and W/T3) are connected to the motor correctly.
- Make sure that the control circuit terminals and the control device are wired correctly and that all control terminals are turned off.
- Set the motor to no-load status (i.e., not connected to the mechanical system).

■Power On


















- After checking the above, turn on the power.





Display Status Check

- When the power is turned on normally, the display shows:
[Normal] RUN LED indicator (during RUN) : ON ALARM LED indicator : OFF
POWER LED indicator : ON
Data display : Displays the set value in d001
- If an error occurs, refer to "Chapter 5 Maintenance Operations" and make the necessary changes to remedy.
[Fault] RUN LED indicator (during RUN) : OFF ALARM LED indicator : ON
POWER LED indicator : ON
Data display : An error code, such as "E01", is displayed.
(The display varies depending on the type of error.)

Parameter Initialization

- Initialize the parameters using the following procedure.
- To initialize the parameters, set parameter b084 to "2" and parameter b180 to "1".

Key sequence	Display example	Description
		Power On
		Press the Prev. Page or Next Page key until function mode is displayed.
		Press the Set key to enter function mode.
		With the Prev. Page, Next Page, Up and Down keys write the parameter b084.
		Press the Set key to enter b084 parameter.
		With the Prev. Page, Next Page, Up and Down keys put the parameter b084 to 2.
		Press the Set key to change the parameter b084 to 2.
		With the Prev. Page, Next Page, Up and Down keys write the parameter b180.
		Press the Set key to enter b180 parameter.

Key sequence	Display example	Description
		With the Prev. Page, Next Page, Up and Down keys put the parameter b180 to 1.
		Press the Set key to change the parameter b180 to 1 and initialize parameters.

No-load Operation

- Start the no-load motor (i.e., not connected to the mechanical system) using the Digital Operator.

■ Stopping the Motor

- After completing the no-load operation, press the STOP/RESET key. The motor will stop.

Actual Load Operation

- After checking the operation with the motor in the no-load status, connect the mechanical system and operate with an actual load.

■ Connecting the Mechanical System

- After confirming that the motor has stopped completely, connect the mechanical system.
- Be sure to tighten all the screws when fixing the motor axis and the mechanical system.

■ Operation via the Digital Operator


- Because a possible error may occur during operation, make sure that the STOP/RESET key on the Digital Operator is easily accessible.
- Use the Digital Operator to operate the Inverter the same way as in no-load operation.













■ Checking the Operating Status








- After making sure that the operating direction is correct and that the Inverter is operating smoothly at a slow speed, increase the frequency reference.
- By changing the frequency reference or the rotation direction, make sure that there is no vibration or abnormal sound from the motor.
Make sure that the output current (output current monitor [d002]) is not excessive.

3-7 Part Names and Descriptions of the Digital Operator

Part Names and Descriptions



	Name	Function
	POWER LED indicator	Light on when the power is supplied to the LCD digital operator.
	RUN LED indicator	Light on when the Inverter is running.
	WARNING LED indicator	Light on when set value is incorrect.
	ALARM LED indicator	Light on when the Inverter trips.
	Remote LED	Light on when the REMOTE key makes the compulsion operation function effective. It doesn't light when the compulsion operation function is effective by input terminal OPE. (Press the key more than 2 seconds)
	Key Enabled LED	Light on only when operation command is set in LCD digital operator.
	LCD Display	Displays relevant data, such as frequency reference, output current, and set values.
	LOCAL REMOTE key	It changes from Local to Remote mode. Press the key during 2 seconds to change from Local to Remote or Remote to Local. When it is in Local the OPE led will be ON. Use Local to control the motor with LCD digital operator keys (Run Fwd, Run Rev and Stop/Reset).
	READ key	It transfers inverter parameters to the LCD digital operator's memory.
	WRITE key	It copies one Parameter Set or a Parameter Set + Drive Programming saved in LCD digital operator to the inverter.
	ESC key	It returns to the above layer.
	SET key	It jumps to the below layer or stores the change introduces on the edit layer (after that it jumps to the above layer).

	Name	Function
	UP key	It is used to move up the cursor, it increases a function code in 1 or increases a parameter value.
	DOWN key	It is used to move down the cursor, it decreases a function code in 1 or it decreases a value.
	PREV. PAGE key	It is used to move the cursor to the left, or it moves to previous mode when the display is a navigation level.
	NEXT PAGE key	It is used to move the cursor to the right, or it moves to the next mode when the display is a navigation level.
	FWD RUN key	It is used to run forward the motor only when the operation command (A002) is reset in Digital operator.
	REV RUN key	It is used to run reverse the motor only when the operation command (A002) is set in Digital operator.
	STOP/RESET key	It is used to stop the motor or reset an alarm. It is also possible to invalidate the STOP key by B087 parameter. Besides it does not response when LCD digital operator is reading or writing the parameters from/to the inverter.

Display System and Key Sequence of Each Code

- This section explains the examples of typical operation (Basic display, Complete display) and the extended function mode U as a special operation.
This operation can be performed when other display modes are selected.

The display indicates the setting of "b038" when the power is turned on. For details, refer to "Initial Screen Selection (Initial Screen at Power-ON)" (page 4-56).
When "b038 = 1" (factory default), output frequency monitor "d001" is displayed.

Note: The Digital Operator display varies depending on the settings of display selection "b037", initial screen selection "b038", and user parameter automatic setting function selection "b039". For details, refer to "Display Selection" (page 4-53), "Initial Screen Selection (Initial Screen at Power-ON)" (page 4-56), "User Parameter Automatic Setting Function" (page 4-57).


Item	Function code	Data	Description
Display selection	b037	00	Complete display (factory default)
		01	Individual display of functions
		02	User setting
		03	Data comparison display
		04	Basic display
Initial screen selection (Power On)	b038	000	Screen when the Enter key was pressed last
		001-060	d001-d060 displayed
		201	F001 (Output frequency setting/monitor)
		202	Monitor screen
User parameter automatic setting function selection	b039	00	Disabled (factory default)
		01	Enabled

3-8 Parameter Transition

■ Operation Example for Complete Display (Default: "b037 = 00")


Displays all parameters.

3
Operation



■ User Functions



The extended function mode U is the parameter to optionally register (or automatically record) other extended function codes, and differs in operation from other extended function modes.



3-9 Parameter List

Monitor Mode (d□□□)

•The default setting displays "d001" at power-on. To select the optional display, change the setting in "b038".

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
d001	Output frequency monitor	0.00 to 400.00	—	Yes	Hz	4-1
d002	Output current monitor	0.0 to 9999.0	—	—	A	4-1
d003	Rotation direction monitor	FWD: Forward STOP: Stop REV: Reverse	—	—	—	4-1
d004	PID feedback value monitor	0.00 to 999000.00 (Enabled when the PID function is selected)	—	—	—	4-1
d005	Multi-function input monitor	 <p>Example FW, Multi-function input terminals 7, 2, 1: ON Multi-function input terminals 8, 6, 5, 4, 3: OFF</p>	—	—	—	4-2
d006	Multi-function output monitor	 <p>Example Multi-function output terminals 12, 11: ON Relay output terminal AL2, Multi-function output terminals 15, 14, 13: OFF</p>	—	—	—	4-2
d007	Output frequency monitor (after conversion)	0.00 to 39960.00 (Output frequency × Conversion factor of b086)	—	Yes	—	4-2
d008	Real frequency monitor	-400.00 to 400.00	—	—	Hz	4-3
d009	Torque reference monitor	-200 to 200	—	—	%	4-3
d010	Torque bias monitor	-200 to 200	—	—	%	4-3
d012	Output torque monitor	-200 to 200	—	—	%	4-3
d013	Output voltage monitor	0.0 to 600.0	—	—	V	4-3
d014	Input power monitor	0.0 to 999.9	—	—	W	4-4
d015	Power ON time monitor	0.0 to 999999.9	—	—	—	4-4
d016	Total RUN time	0 to 999999	—	—	h	4-4
d017	Power ON time monitor	0 to 999999	—	—	h	4-4
d018	Fin temperature monitor	-020. to 200.0	—	—	°C	4-4

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
d019	Motor temperature monitor	-020. to 200.0	—	—	°C	4-5
d022	Life assessment monitor	 <div>1: Main circuit board capacitor service life 2: Cooling fan rpm reduction</div>	—	—	—	4-5
d023	Program counter	0 to 1024	—	—	—	—
d024	Program number	0 to 9999	—	—	—	—
d025	Drive programming monitor (UM0)	-2147483647 to 2147483647	—	—	—	—
d026	Drive programming monitor (UM1)	-2147483647 to 2147483647	—	—	—	—
d027	Drive programming monitor (UM2)	-2147483647 to 2147483647	—	—	—	—
d028	Pulse counter monitor	0 to 2147483647	—	—	—	4-6
d029	Position command monitor	-1073741823 to 1073741823 when HAPR is selected -268435456 to 268435456 when APR2 is selected.	—	—	—	4-6
d030	Current position monitor	-1073741823 to 1073741823 when HAPR is selected -268435456 to 268435456 when APR2 is selected.	—	—	—	4-6 4-137
d031	Clock	Setting Data and Time for the LCD digital operator	—	—	—	—
d060	Inverter mode	00 to 01	—	—	—	—
d080	Fault frequency monitor	0 to 65535	—	—	Time	4-6
d081	Fault monitor 1 (Latest)	Error code (condition of occurrence) →Output frequency [Hz] → Output current [A] →Internal DC voltage [V] →RUN time [h] →ON time [h]	—	—	—	4-7
d082	Fault monitor 2					4-7
d083	Fault monitor 3					4-7
d084	Fault monitor 4					4-7
d085	Fault monitor 5					4-7
d086	Fault monitor 6					4-7
d090	Warning monitor	Warning code 0 to 385	—	—	—	4-7
d102	DC voltage monitor	0.0 to 999.9	—	—	V	4-7
d103	Regenerative braking load rate monitor	0.0 to 100.0	—	—	%	4-7
d104	Electronic thermal monitor	0.0 to 100.0	—	—	%	4-7

Basic Function Mode (F□□□)

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
F001	Output frequency setting/monitor	0.0/Starting frequency to 1st/2nd/3rd max. frequency 0.00 to 400.00	0.00	Yes	Hz	4-8
F002	Acceleration time 1	0.01 to 3600.00	10.00	Yes	s	4-8
F202	* 2nd acceleration time 1	0.01 to 3600.00	10.00	Yes	s	4-8
F302	* 3rd acceleration time 1	0.01 to 3600.00	10.00	Yes	s	4-8
F003	Deceleration time 1	0.01 to 3600.00	10.00	Yes	s	4-8
F203	* 2nd deceleration time 1	0.01 to 3600.00	10.00	Yes	s	4-8
F303	* 3rd deceleration time 1	0.01 to 3600.00	10.00	Yes	s	4-8
F004	Operator rotation direction selection	00: FWD (Forward) 01: REV (Reverse)	00	No	—	4-9

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Extended Function Mode

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page	
Basic setting	A001	Frequency reference selection 00: VR (Digital Operator (FREQ adjuster)) (Enabled when 3G3AX-OP01 is used.) 01: Terminal 02: Digital Operator (F001) 03: RS485 (ModBus communication) 04: Option 1 05: Option 2 06: Pulse train frequency 07: EzSQ (Drive programming) 10: (Math) Operation function result	01	No	—	4-10 4-144	
	A002	RUN command selection 01: Terminal 02: Digital Operator (F001) 03: RS485 (ModBus communication) 04: Option 1 05: Option 2	01	No	—	4-11	
	A003	Base frequency	30 to Maximum frequency [A004]	50	No	Hz	4-11 4-112
	A203	* 2nd set base frequency	30 to 2nd maximum frequency [A204]	50			4-11
	A303	* 3rd set base frequency	30 to 3rd maximum frequency [A304]	50			
	A004	Maximum frequency	A003 to 400	50	No	Hz	4-12
	A204	* 2nd maximum frequency	A203 to 400	50			
A304	* 3rd maximum frequency	A303 to 400	50				
Analog input, Others	A005	O/OI selection 00: [O]/[O2] Switches between O/OI via terminal AT 01: [O]/[O2] Switches between O/O2 via terminal AT 02: [O]/VR Switches between O/FREQ adjuster via terminal AT (Enabled only when 3G3AX-OP01 is used) 03: [OI]/VR Switches between OI/FREQ adjuster via terminal AT (Enabled only when 3G3AX-OP01 is used) 04: [O2]/VR Switches between O2/FREQ adjuster via terminal AT (Enabled only when 3G3AX-OP01 is used)	00	No	—	4-12	
	A006	O2 selection 00: [O2] only 01: [O/OI-P] auxiliary frequency reference (not reversible) 02: [O/OI-PM] auxiliary frequency reference (reversible) 03: [OFF] O2 disabled	03	No	—	4-12	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Analog input, Others	A011	O start frequency	0.00 to 400.00	0.00	No	Hz	4-14
	A012	O end frequency	0.00 to 400.00	0.00	No	Hz	
	A013	O start ratio	0 to 100	0	No	%	
	A014	O end ratio	0 to 100	100	No	%	
	A015	O start selection	00: External start frequency (A011 set value) 01: 0 Hz	01	No	—	
	A016	O, O2, OI sampling	1 to 30 31 (with 500 ms filter ± 0.1 Hz hysteresis)	31	No	—	4-15
	A017	Drive Programming (EzSQ) Selection	0: Disable 1: [PRG] start 2: Always ON	00	No	—	—
Multi-step speed, Jogging	A019	Multi-step speed selection	00: Binary: 16-step selection with 4 terminals 01: Bit: 8-step selection with 7 terminals	00	No	—	4-16
	A020	Multi-step speed reference 0	0.00 to Max. Frequency [A004]	6.00	Yes	Hz	4-8 4-16
	A220	* 2nd multi-step speed reference 0	0.00 to Max. Frequency [A204]	6.00	Yes	Hz	
	A320	* 3rd multi-step speed reference 0	0.00 to Max. Frequency [A304]	6.00	Yes	Hz	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Multi-step speed, Jogging	A021	Multi-step speed reference 1	0.00	Yes	Hz	4-16
	A022	Multi-step speed reference 2	0.00			
	A023	Multi-step speed reference 3	0.00			
	A024	Multi-step speed reference 4	0.00			
	A025	Multi-step speed reference 5	0.00			
	A026	Multi-step speed reference 6	0.00			
	A027	Multi-step speed reference 7	0.00			
	A028	Multi-step speed reference 8	0.00/Starting frequency to Max. frequency			
	A029	Multi-step speed reference 9	0.00			
	A030	Multi-step speed reference 10	0.00			
	A031	Multi-step speed reference 11	0.00			
	A032	Multi-step speed reference 12	0.00			
	A033	Multi-step speed reference 13	0.00			
	A034	Multi-step speed reference 14	0.00			
	A035	Multi-step speed reference 15	0.00			
A038	Jogging frequency	0.00/Starting frequency to 9.99	6.00	Yes	Hz	4-18
A039	Jogging stop selection	00: FRS (Free running on jogging stop/ Disabled in operation) 01: DEC (Deceleration stop on jogging stop/ Disabled in operation) 02: DB (DC injection braking on jogging stop/ Disabled in operation) 03: FRS (RUN) (Free running on jogging stop/Enabled in operation) 04: DEC (RUN) (Deceleration stop on jogging stop/Enabled in operation) 05: DB (RUN) (DC injection braking on jogging stop/Enabled in operation)	04	No	—	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
V/f characteristics	A041	Torque boost selection	00: Manual torque boost 01: Automatic torque boost	00	No	—	4-19
	A241	* 2nd torque boost selection		00			
	A042	Manual torque boost voltage	0.0 to 20.0	1.0	Yes	%	
	A242	* 2nd manual torque boost voltage		1.0			
	A342	* 3rd manual torque boost voltage		1.0			
	A043	Manual torque boost frequency	0.0 to 50.0	5.0	Yes	%	
	A243	* 2nd manual torque boost frequency		5.0			
	A343	* 3rd manual torque boost frequency		5.0			
	A044	V/f characteristics selection	00: VC (Constant torque characteristics) 01: VP (Special reduced torque characteristics) 02: Free V/f (characteristics) 03: SLV (Sensorless vector control) 04: 0SLV (0-Hz sensorless vector control) 05: V2 (Sensor vector control)	00	No	—	4-21
	A244	* 2nd V/f characteristics selection	00: VC (Constant torque characteristics) 01: VP (Special reduced torque characteristics) 02: Free V/f (characteristics) 03: SLV (Sensorless vector control) 04: 0SLV (0-Hz sensorless vector control) 05: V2 (Sensor vector control)	00			
	A344	* 3rd V/f characteristics selection	00: VC (Constant torque characteristics) 01: VP (Special reduced torque characteristics)	00			
A045	Output voltage gain	20 to 100	100	Yes	%	4-24	
V/f characteristics	A046	Automatic torque boost voltage compensation gain	0 to 255	100	Yes	—	4-20
	A246	* 2nd automatic torque boost voltage compensation gain	0 to 255	100			
	A047	Automatic torque boost slip compensation gain	0 to 255	100	Yes	—	
	A247	* 2nd automatic torque boost slip compensation gain	0 to 255	100			

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
DC injection braking	A051	DC injection braking selection 00: OFF (Disabled) 01: ON (Enabled) 02: ON (FQ) (Frequency control [A052 set value])	00	No	—	4-24 4-112
	A052	DC injection braking frequency	0.50	No	Hz	4-24
	A053	DC injection braking delay time	0.0	No	s	
DC injection braking	A054	DC injection braking power	0 to 100 (0.4 to 55 kW)	50	No	%
			0 to 80 (75 to 132 kW)	40	No	%
	A055	DC injection braking time	0.0 to 60.0	0.5	No	s
	A056	DC injection braking method selection 00: Edge operation 01: Level operation	01	No	—	4-24
	A057	Startup DC injection braking power	0 to 100 (0.4 to 55 kW) 0 to 80 (75 to 132 kW)	0	No	%
	A058	Startup DC injection braking time	0.0 to 60.0	0.0	No	s
	A059	DC injection braking carrier frequency	0.5 to 15.0 (0.4 to 55 kW)	5.0	No	kHz
			0.5 to 10.0 (75 to 132 kW)	3.0	No	kHz
	A059					
Upper/Lower limiter, Jump	A061	Frequency upper limit	0.00/Frequency lower limit to Max. frequency	0.00	No	Hz
	A261	* 2nd frequency upper limit	0.00/2nd frequency lower limit to 2nd Max. frequency	0.00		
	A062	Frequency lower limit	0.00/Starting frequency to Frequency upper limit	0.00	No	Hz
	A262	* 2nd frequency lower limit	0.00/Starting frequency to 2nd frequency upper limit	0.00		
Upper/Lower limit, Jump	A063	Jump frequency 1	Jump frequency: 0.0 to 400.0 Jump frequency width: 0.0 to 10.0	0.00	No	Hz
	A064	Jump frequency width 1		0.50		
	A065	Jump frequency 2		0.00		
	A066	Jump frequency width 2		0.50		
	A067	Jump frequency 3		0.00		
	A068	Jump frequency width 3		0.50		
	A069	Acceleration stop frequency	0.00 to 400.00	0.00	No	Hz
	A070	Acceleration stop time	0.0 to 60.0	0.0	No	s

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
PID control	A071	PID selection 00: OFF (Disabled) 01: ON (+) (Enabled) 02: ON (+/-) (Reverse output enabled)	00	No	—	4-31
	A072	PID P gain	1.0	Yes	—	
	A073	PID I gain	1.0	Yes	s	
	A074	PID D gain	0.00	Yes	s	
	A075	PID scale	1.00	No	Time	
	A076	PID feedback selection 00: OI 01: O 02: Modbus (RS485 communication) 03: Pulse (Pulse train frequency) 10: Math (Operation function output)	00	No	—	
	A077	Reverse PID function 00: OFF (Deviation = Target value - Feedback value) 01: ON (Deviation = Feedback value - Target value)	00	No	—	
	A078	PID output limit function	0.0	No	%	
PID control	A079	PID feedforward selection 00: Disabled 01: O 02: OI 03: O2	00	No	—	4-31
AVR	A081	AVR selection 00: Always ON 01: Always OFF 02: OFF during deceleration	02	No	—	4-35
	A082	AVR voltage selection 200-V class: 200/215/220/230/240 400-V class: 380/400/415/440/460/480	200/400	No	V	
RUN mode, Acceleration/Deceleration functions	A085	RUN mode selection 00: Normal operation 01: Energy-saving operation 02: Automatic operation	00	No	—	4-36
	A086	Energy-saving response/accuracy adjustment 0.0 to 100.0	50.0	Yes	—	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
RUN mode, Acceleration/Deceleration functions	A092	Acceleration time 2	0.01 to 3600.00	10.00	Yes	s	4-37
	A292	* 2nd acceleration time 2		10.00			
	A392	* 3rd acceleration time 2		10.00			
	A093	Deceleration time 2		10.00			
	A293	* 2nd deceleration time 2		10.00			
	A393	* 3rd deceleration time 2		10.00			
	A094	2-step acceleration/ deceleration selection	00: 2CH-Terminal (Switched via multi-function input 09) 01: Preset FQ (Switched by setting) 02: FWD-REV (Enabled only when switching forward/reverse)	00	No	—	
	A294	* 2nd 2-step acceleration/ deceleration selection		00			
	A095	2-step acceleration frequency	0.00 to 400.00	0.00	No	Hz	
	A295	* 2nd 2-step acceleration frequency		0.00			
	A096	2-step deceleration frequency		0.00	No	Hz	
	A296	* 2nd 2-step deceleration frequency		0.00			
	A097	Acceleration pattern selection	00: Line 01: S-curve 02: U-curve 03: inv. U curve 04: EL-S curve	01	No	—	4-38
	A098	Deceleration pattern selection		01	No	—	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
External frequency adjustment	A101	OI start frequency	0.00	No	Hz	4-14
	A102		0.00	No	Hz	
	A103	OI start ratio	20	No	%	
	A104	OI end ratio	100	No	%	
	A105	OI start selection	00: Start FQ (Use OI start frequency [A101]) 01: 0 Hz	No	—	4-15
	A111	O2 start frequency	0.00	No	Hz	
External frequency adjustment	A112	O2 end frequency	0.00	No	Hz	
	A113	O2 start ratio	-100	No	%	
Accel/Decel	A131	Acceleration curve parameter	01 (small curve) to 10 (large curve)	No	—	4-38
	A132	Deceleration curve parameter		No	—	
Operation frequency	A141	Operation frequency input A setting	00: Operator (Digital Operator (F001)) 01: VR (Digital Operator (FREQ adjuster)) (Enabled when 3G3AX-OP01 is used.) 02: O (Input O) 03: OI (Input OI) 04: Modbus (RS485 communication) 05: Option 1 06: Option 2 07: Pulse (Pulse train frequency)	02	No	4-41
	A142	Operation frequency input B setting		03	No	
	A143	Operator selection	00: ADD (Addition (A + B)) 01: SUB (Subtraction (A - B)) 02: MUL (Multiplication (A × B))	00	No	
	A145	Frequency addition amount	0.00 to 99.99 100.0 to 400.0	0.00	No	4-41
	A146	Frequency addition direction	00: ADD (Add A145 value to output frequency) 01: SUB (Subtract A145 value from output frequency)	00	No	
Acceleration/Deceleration	A150	EL-S-curve ratio 1 during acceleration	0 to 50	10	No	4-39
	A151	EL-S-curve ratio 2 during acceleration	0 to 50	10	No	
	A152	EL-S-curve ratio 1 during deceleration	0 to 50	10	No	
	A153	EL-S-curve ratio 2 during deceleration	0 to 50	10	No	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Momentary power interruption/Trip restart	b001	Retry selection 00: TRIP (Alarm) 01: 0 Hz start 02: f-match (Frequency matching start) 03: f-match Trip (Trip after frequency matching deceleration stop) 04: Actv. f-match (Active Frequency Matching restart)	00	No	—	4-42
	b002	Allowable momentary power interruption time	1.0	No	s	
	b003	Retry wait time	1.0	No	s	4-87
	b004	Momentary power interruption/undervoltage trip during stop selection 00: OFF (Disabled) 01: ON (Enabled) 02: Decel-OFF (Disabled during stop and deceleration stop)	00	No	—	4-42
	b005	Momentary power interruption retry time selection 00: 16 times 01: No limit	00	No	—	
Momentary power interruption/Trip restart	b006	Input phase loss protection selection 00: OFF (Disabled) 01: ON (Enabled)	01	No	—	4-46
	b007	Frequency matching lower limit frequency setting 0.00 to 400.00	0.00	No	Hz	4-42 4-71 4-87
	b008	Trip retry selection 00: TRIP (Alarm) 01: 0 Hz start 02: f-match (Frequency matching start) 03: f-match Trip (Trip after frequency matching deceleration stop) 04: Actv. f-match (Active Frequency Matching restart)	00	No	—	4-42
	b009	Undervoltage retry time selection 00: 16 times 01: No limit	00	No	—	4-42
	b010	Overvoltage/overcurrent retry time selection 1 to 3	3	No	Time	
	b011	Trip retry wait time 0.3 to 100.0	1.0	No	s	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
b012	Electronic thermal level	0.20 × Rated current to 1.00 × Rated current	Rated current	No	A	4-46
b212	* 2nd electronic thermal level					
b312	* 3rd electronic thermal level					
b013	Electronic thermal characteristics selection	00: Reduced TRQ (Reduced torque characteristics) 01: Const TRQ (Constant torque characteristics) 02: Free set (Free setting)	00	No	—	4-46
b213	* 2nd electronic thermal characteristics selection					
b313	* 3rd electronic thermal characteristics selection					
b015	Free setting, electronic thermal frequency 1	0 to 400	0	No	Hz	4-46
b017	Free setting, electronic thermal frequency 2					
b019	Free setting, electronic thermal frequency 3					
b016	Free setting, electronic thermal current 1	0.0 to Rated current	0.0	No	A	4-46
b018	Free setting, electronic thermal current 2					
b020	Free setting, electronic thermal current 3					

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Overload limit, Overcurrent Protection	b021	Overload limit selection 00: OFF (Disabled) 01: ON-Acc/Cnst (Enabled in acceleration/constant speed operation) 02: ON-Cnst (Enabled in constant speed operation) 03: ON-A/C(R) (Enabled in acceleration/constant speed operation (Accelerates during regeneration))	01	No	—	4-49
	b022	Overload limit level 0.20 × Rated current to 2.00 × Rated current (0.4 to 55 kW) 0.20 × Rated current to 1.80 × Rated current (75 to 132 kW)	1.50 × Rated current	No	A	
	b023	Overload limit parameter 0.10 to 30.00	1.00	No	s	
	b024	Overload limit selection 2 00: OFF (Disabled) 01: ON-Acc/Cnst (Enabled in acceleration/constant speed operation) 02: ON-Cnst (Enabled in constant speed operation) 03: ON-A/C(R) (Enabled in acceleration/constant speed operation (Accelerates during regeneration))	01	No	—	
	b025	Overload limit level 2 0.20 × Rated current to 2.00 × Rated current (0.4 to 55 kW) 0.20 × Rated current to 1.80 × Rated current (75 to 132 kW)	1.50 × Rated current	No	A	
	b026	Overload limit parameter 2 0.10 to 30.00	1.00	No	s	4-51
	b027	Overcurrent suppression function 00: OFF (Disabled) 01: ON (Enabled)	00	No	—	
	b028	Active Frequency Matching restart level 0.20 × Rated current to 2.00 × Rated current (0.4 to 55 kW) 0.20 × Rated current to 1.80 × Rated current (75 to 132 kW)	Rated current	No	A	
	b029	Active Frequency Matching restart parameter 0.10 to 30.00	0.50	No	s	
	b030	Starting frequency at Active Frequency Matching restart 00: Off FQ (Frequency at interruption) 01: Max.FQ (Max. frequency) 02: Set FQ (Set frequency)	00	No	—	4-43 4-71
Lock	b031	Soft lock selection 00: Lock (SFT) (Data other than b031 cannot be changed when terminal SFT is ON) 01: Only FQ (SFT) (Data other than b031 and the specified frequency parameter cannot be changed when terminal SFT is ON) 02: Lock (Data other than b031 cannot be changed) 03: Only FQ (Data other than b031 and the specified frequency parameter cannot be changed) 10: RUN chg mode (Data other than parameters changeable during operation cannot be changed)	01	No	—	4-51

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Others	b034	RUN time/Power ON time setting	0 to 65535	0	No	h	4-52
	b035	Rotation direction limit selection	00: FREE (Forward and Reverse are enabled) 01: FWD (Only Forward is enabled) 02: REV (Only Reverse is enabled)	00	No	—	4-52
	b036	Reduced voltage startup selection	0 (Reduced voltage startup time: small) to 255 (Reduced voltage startup time: large)	6	No	—	4-53
	b037	Display selection	00: All (Complete display) 01: Utilized (Individual display of functions) 02: User (User setting) 03: Compare (Data comparison display) 04: Basic (Basic display)	00	No	—	4-53
	b038	Initial screen selection	000 to 202	001	No	—	4-56
	b039	User parameter automatic setting function selection	00: OFF (Disabled) 01: ON (Enabled)	00	No	—	4-57
Torque limit	b040	Torque limit selection	00: 4-quadrant (Four-quadrant separate setting) 01: TRQ input (Terminal switch) 02: [O] input (Analog input) 03: Option 1 04: Option 2	00	No	—	4-57 4-59
	b041	Torque limit 1 (Four-quadrant mode forward power running)	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) no (Torque limit disabled)	150	No	%	4-57 4-59
	b042	Torque limit 2 (Four-quadrant mode reverse regeneration)	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) no (Torque limit disabled)	150	No	%	4-57 4-59
	b043	Torque limit 3 (Four-quadrant mode reverse power running)	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) no (Torque limit disabled)	150	No	%	
	b044	Torque limit 4 (Four-quadrant mode forward regeneration)	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) no (Torque limit disabled)	150	No	%	
	b045	Torque LADSTOP selection	00: OFF (Disabled) 01: ON (Enabled)	00	No	—	4-59
Others	b046	Reverse rotation prevention selection	00: OFF (Disabled) 01: ON (Enabled)	00	No	—	4-59
	b049	Dual rate selection	00: CT (Constant torque) 01: VT (Variable torque)	00	No	—	—

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Others	b050	Selection of non-stop function at momentary power interruption 00: OFF (Disabled) 01: V-Cnst (STOP) (Enabled (deceleration stop)) 02: NS1 (Enabled (without recovery)) 03: NS2 (Enabled (with recovery))	00	No	—	4-60
	b051	Starting voltage of non-stop function at momentary power interruption	220/ 440	No	V	
	b052	Stop deceleration level of non-stop function at momentary power interruption	360/ 720	No	V	
	b053	Deceleration time of non-stop function at momentary power interruption	1.00	No	s	
	b054	Deceleration starting width of non-stop function at momentary power interruption	0.00	No	Hz	
	b055	Proportional gain setting of non-stop function at momentary power interruption	0.20	Yes	—	
	b056	Integral time setting of non-stop function at momentary power interruption	0.100	Yes	s	4-63

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Others	b060	Window comparator O upper limit level Setting range: 0 to 100 Lower limit: Lower limit level + Hysteresis width × 2	100	Yes	%	4-66
	b061	Window comparator O lower limit level Setting range: 0 to 100 Upper limit: Upper limit level - Hysteresis width × 2	0	Yes	%	
	b062	Window comparator O hysteresis width Setting range: 0 to 10 Upper limit: (Upper limit level - Lower limit level) × 2	0	Yes	%	
	b063	Window comparator OI upper limit level Setting range: 0 to 100 Lower limit: Lower limit level + Hysteresis width × 2	100	Yes	%	
	b064	Window comparator OI lower limit level Setting range: 0 to 100 Upper limit: Upper limit level - Hysteresis width × 2	0	Yes	%	
	b065	Window comparator OI hysteresis width Setting range: 0 to 10 Upper limit: (Upper limit level - Lower limit level) × 2	0	Yes	%	
	b066	Window comparator O2 upper limit level Setting range: -100 to 100 Lower limit: Lower limit level + Hysteresis width × 2	100	Yes	%	4-66
	b067	Window comparator O2 lower limit level Setting range: -100 to 100 Upper limit: Upper limit level - Hysteresis width × 2	-100	Yes	%	
	b068	Window comparator O2 hysteresis width Setting range: 0 to 10 Upper limit: (Upper limit level - Lower limit level) × 2	0	Yes	%	
	b070	Analog operation level at O disconnection 0 to 100/no (ignored)	no	No	—	
	b071	Analog operation level at OI disconnection 0 to 100/no (ignored)	no	No	—	
	b072	Analog operation level at O2 disconnection -100 to 100/no (ignored)	no	No	—	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page	
Others	b078	Integrated power clear	Cleared with the Enter key after changing to 01	00	Yes	—	4-4
	b079	Integrated power display gain	1 to 1000	1	No	—	
	b082	Starting frequency	0.10 to 9.99	0.50	No	Hz	4-68
	b083	Carrier frequency	0.5 to 15.0 (0.4 to 55 kW) *Derating enabled	5.0	No	kHz	4-68 4-120
			0.5 to 10.0 (75 to 132 kW) *Derating enabled	3.0	No	kHz	
	b084	Initialization selection	00: no (Clears the trip monitor) 01: Trip data (Initializes data) 02: Parameters (Clears the trip monitor and initializes data) 03: Trip+Param (Clears the trip monitor and parameters) 04: Trp+Prm+EzSQ (Clears the trip monitor, parameters and Drive program)	00	No	—	4-70
	b085	Initialization parameter selection	01 *Do not change.	01	No	—	
	b086	Frequency conversion coefficient	0.1 to 99.9	1.0	Yes	—	4-2
	b087	STOP key selection	00: ON (Enabled) 01: OFF (Disabled) 02: Only RESET (Disabled only during stop)	00	No	—	4-70
	b088	Free-run stop selection	00: 0 Hz start 01: f-match (Frequency matching start) 02: Actv. f-match (Active Frequency Matching restart)	00	No	—	4-71
	b089	Automatic carrier reduction	00: OFF (Disabled) 01: ON (Enabled)	00	No	—	4-73
	b090	Usage rate of regenerative braking function	0.0 to 100.0	0.0	No	%	4-74
	b091	Stop selection	00: Decel-Stop (Deceleration → Stop) 01: Free-RUN (Free-run stop)	00	No	—	4-70
	b092	Cooling fan control	00: Alws-ON (Always ON) 01: ON in RUN (ON during RUN)	01	No	—	4-74
	b095	Regenerative braking function operation selection	00: OFF (Disabled) 01: RUN-ON (Enabled (Disabled during stop)) 02: Alws-ON (Enabled (Enabled during stop))	00	No	—	
	b096	Regenerative braking function ON level	330 to 380 660 to 760	360/ 720	No	V	
	b098	Thermistor selection	00: Disabled 01: PTC enabled 02: NTC enabled	00	No	—	4-75
	b099	Thermistor error level	0 to 9999	3000	No	Ω	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Vf free setting	b100	Free V/f frequency 1	0 to Free V/f frequency 2	0	No	Hz
	b101	Free V/f voltage 1	0.0 to 800.0	0.0	No	V
	b102	Free V/f frequency 2	0 to Free V/f frequency 3	0	No	Hz
	b103	Free V/f voltage 2	0.0 to 800.0	0.0	No	V
	b104	Free V/f frequency 3	0 to Free V/f frequency 4	0	No	Hz
	b105	Free V/f voltage 3	0.0 to 800.0	0.0	No	V
	b106	Free V/f frequency 4	0 to Free V/f frequency 5	0	No	Hz
	b107	Free V/f voltage 4	0.0 to 800.0	0.0	No	V
	b108	Free V/f frequency 5	0 to Free V/f frequency 6	0	No	Hz
	b109	Free V/f voltage 5	0.0 to 800.0	0.0	No	V
	b110	Free V/f frequency 6	0 to Free V/f frequency 7	0	No	Hz
	b111	Free V/f voltage 6	0.0 to 800.0	0.0	No	V
	b112	Free V/f frequency 7	0 to 400	0	No	Hz
	b113	Free V/f voltage 7	0.0 to 800.0	0.0	No	V
Others	b120	Brake control selection	00: OFF (Disabled) 01: ON (Enabled)	00	No	—
	b121	Brake wait time for release	0.00 to 5.00	0.00	No	s
	b122	Brake wait time for acceleration	0.00 to 5.00	0.00	No	s
	b123	Brake wait time for stopping	0.00 to 5.00	0.00	No	s
	b124	Brake wait time for confirmation	0.00 to 5.00	0.00	No	s
	b125	Brake release frequency	0.00 to 400.00	0.00	No	Hz
	b126	Brake release current	0.0 to 2.00 × Rated current (0.4 to 55 kW) 0.0 to 1.80 × Rated current (75 to 132 kW)	Rated current	No	—
	b127	Brake input frequency	0.00 to 400.00	0.00	No	Hz

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Others	b130	Overvoltage protection function selection during deceleration 00: OFF (Disabled) 01: V-const (DC voltage kept constant) 02: Accel (Acceleration enabled)	01	No	—	4-78
	b131	Overvoltage protection level during deceleration 200-V class: 330 to 390 400-V class: 660 to 780	380/ 760	No	V	
	b132	Overvoltage protection parameter	1.00	No	s	
	b133	Overvoltage protection proportional gain setting	0.50	Yes	—	
	b134	Overvoltage protection integral time setting	0.060	Yes	s	
	b164	Auto return initial display 00: OFF 01: ON	00	No	—	—
	b166	Data Read/Write selection 00: R/W OK (Read/Write OK) 01: R/W Protected (Read/Write Protected)	00	No	—	—
	b180	Initialize trigger 00: No action 01: Initialize	00	No	—	—

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Multi-function input terminals	C001	Multi-function input 1 selection ^{*1}	01: RV (reverse) 02: CF1 (multi-step speed setting binary 1) 03: CF2 (multi-step speed setting binary 2) 04: CF3 (multi-step speed setting binary 3) 05: CF4 (multi-step speed setting binary 4) 06: JG (jogging) 07: DB (external DC injection braking) 08: SET (2nd control) 09: 2CH (2-step acceleration/deceleration)	No	—	4-79
	C002	Multi-function input 2 selection	11: FRS (free-run stop) 12: EXT (external trip) 13: USP (USP function) 14: CS (commercial switch) 15: SFT (soft lock) 16: AT (analog input switching) 17: SET3 (3rd control) 18: RS (reset)			
	C003	Multi-function input 3 selection ^{*1}	20: STA (3-wire start) 21: STP (3-wire stop) 22: F/R (3-wire forward/reverse) 23: PID (PID enabled/disabled) 24: PIDC (PID integral reset) 26: CAS (control gain switching) 27: UP (UP/DWN function accelerated) 28: DWN (UP/DWN function decelerated) 29: UDC (UP/DWN function data clear) 31: OPE (forced operator)			
	C004	Multi-function input 4 selection	32: SF1 (multi-step speed setting bit 1) 33: SF2 (multi-step speed setting bit 2) 34: SF3 (multi-step speed setting bit 3) 35: SF4 (multi-step speed setting bit 4) 36: SF5 (multi-step speed setting bit 5) 37: SF6 (multi-step speed setting bit 6) 38: SF7 (multi-step speed setting bit 7) 39: OLR (overload limit switching)			
	C005	Multi-function input 5 selection	40: TL (torque limit enabled) 41: TRQ1 (torque limit switching 1) 42: TRQ2 (torque limit switching 2) 43: PPI (P/PI switching) 44: BOK (Brake confirmation) 45: ORT (orientation) 46: LAC (LAD cancel) 47: PCLR (position deviation clear) 48: STAT (pulse train position command input permission)			
	C006	Multi-function input 6 selection	50: ADD (frequency addition) 51: F-TM (forced terminal block) 52: ATR (torque command input permission) 53: KHC (integrated power clear) 54: SON (servo ON) 55: FOC (preliminary excitation) 56: MI1 (Drive programming input 1) 57: MI2 (Drive programming input 2) 58: MI3 (Drive programming input 3) 59: MI4 (Drive programming input 4)			
	C007	Multi-function input 7 selection	60: MI5 (Drive programming input 5) 61: MI6 (Drive programming input 6) 62: MI7 (Drive programming input 7) 63: MI8 (Drive programming input 8) 65: AHD (analog command held) 66: CP1 (position command selection 1) 67: CP2 (position command selection 2) 68: CP3 (position command selection 3) 69: ORL (zero return limit signal)			
	C008	Multi-function input 8 selection	70: ORG (zero return startup signal) 71: FOT (forward driving stop) 72: ROT (reverse driving stop) 73: SPD (speed/position switching) 74: PCNT (pulse counter) 75: PCC (pulse counter clear) 82: PRG (Drive program start) no: NO (no allocation)			

^{*1}1. C001 and C003 are forcibly rewritten into 18 (RS) and 64 (EMR), respectively, when the emergency shutoff function is enabled (SW1 = ON). (64 cannot be set optionally.)
When SW1 is turned ON once and then OFF, C003 has no allocations ("no").

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Multi-function input terminals	C011	Multi-function input 1 operation selection	00: NO 01: NC	00	No	—	4-81
	C012	Multi-function input 2 operation selection		00			
	C013	Multi-function input 3 operation selection		00			
	C014	Multi-function input 4 operation selection		00			
	C015	Multi-function input 5 operation selection		00			
	C016	Multi-function input 6 operation selection		00			
	C017	Multi-function input 7 operation selection		00			
	C018	Multi-function input 8 operation selection		00			
	C019	FW terminal operation selection		00			

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Multi-function output terminal	C021	Multi-function output terminal 11 selection 00: RUN (signal during RUN) 01: FA1 (constant speed arrival signal) 02: FA2 (over set frequency arrival signal) 03: OL (overload warning) 04: OD (excessive PID deviation) 05: AL (alarm output) 06: FA3 (set-frequency-only arrival signal) 07: OTQ (overtorque) 08: IP (signal during momentary power interruption)	00	No	—	4-95
	C022	Multi-function output terminal 12 selection 09: UV (signal during undervoltage) 10: TRQ (torque limit) 11: RNT (RUN time over) 12: ONT (Power ON time over) 13: THM (thermal warning) 19: BRK (brake release) 20: BER (brake error) 21: ZS (0 Hz signal) 22: DSE (excessive speed deviation)	21			
	C023	Multi-function output terminal 13 selection 23: POK (position ready) 24: FA4 (set frequency exceeded 2) 25: FA5 (set frequency only 2) 26: OL2 (overload warning 2) 27: ODc (analog O disconnection detection) 28: OIdc (analog OI disconnection detection) 29: O2Dc (analog O2 disconnection detection) 31: FBV (PID FB status output) 32: NDc (network error)	03			
	C024	Multi-function output terminal 14 selection 33: LOG1 (logic operation output 1) 34: LOG2 (logic operation output 2) 35: LOG3 (logic operation output 3) 36: LOG4 (logic operation output 4) 37: LOG5 (logic operation output 5) 38: LOG6 (logic operation output 6) 39: WAC (capacitor life warning signal) 40: WAF (cooling fan life warning signal) 41: FR (starting contact signal) 42: OHF (fin overheat warning)	07			
	C025	Multi-function output terminal 15 selection 43: LOC (light load detection signal) 44: MO1 (Drive programming output 1) 45: MO2 (Drive programming output 2) 46: MO3 (Drive programming output 3) 47: MO4 (Drive programming output 4) 48: MO5 (Drive programming output 5) 49: MO6 (Drive programming output 6) 50: IRDY (operation ready signal) 51: FWR (forward run signal)	01			
	C026	Relay output (AL2, AL1) function selection 52: RVR (reverse run signal) 53: MJA (fatal fault signal) 54: WCO (window comparator O) 55: WCOI (window comparator OI) 56: WCO2 (window comparator O2) 63: OPO (Option board output) no: Not used (When C062 is used to select the alarm code output, the multi-function output terminals 11 to 13, or 11 to 14 are forcibly changed to AC0 to AC2 or AC0 to AC3 [Acn 'Alarm code output'], respectively.)	05			

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Analog monitor	C027 FM selection	When inverter is in sensor vector control (A044=05) the real motor speed from the motor encoder (d008 monitor) is used instead of the output frequency. 00: Output FQ (Output frequency) 01: Output I (Output current) 02: Output TRQ (Output torque) 03: Pulse FQ (Digital output frequency) 04: Output V (Output voltage) 05: Power 06: Thermal (Thermal load rate) 07: LAD-FQ (LAD frequency) 08: Pulse I (Digital current monitor) 09: Motor tmp (Motor temperature) 10: Heatsink tmp (Fin temperature) 12: YA0 (Drive programming) 19: OP1 (Option board 1) 20: OP2 (Option board 2)	00	No	—	4-109 4-118
	C028 AM selection	When inverter is in sensor vector control (A044=05) the real motor speed from the motor encoder (d008 monitor) is used instead of the output frequency. 00: Output FQ (Output frequency) 01: Output I (Output current) 02: Output TRQ (Output torque) 04: Output V (Output voltage) 05: Power 06: Thermal (Thermal load rate) 07: LAD-FQ (LAD frequency) 08: Pulse I (Digital current monitor) 09: Motor tmp (Motor temperature) 10: Heatsink tmp (Fin temperature) 11: Out TRQ sign (Output torque <signed>) 13: YA1 (Drive programming) 19: OP1 (Option board 1) 20: OP2 (Option board 2)	00	No	—	4-110 4-118
	C029 AMI selection	When inverter is in sensor vector control (A044=05) the real motor speed from the motor encoder (d008 monitor) is used instead of the output frequency. 00: Output FQ (Output frequency) 01: Output I (Output current) 02: Output TRQ (Output torque) 04: Output V (Output voltage) 05: Power 06: Thermal (Thermal load rate) 07: LAD-FQ (LAD frequency) 09: Motor tmp (Motor temperature) 10: Heatsink tmp (Fin temperature) 14: YA2 (Drive programming)	00	No	—	
	C030 Digital current monitor reference value	0.20 × Rated current to 2.00 × Rated current (Under 55 kW) 0.20 × Rated current to 1.50 × Rated current (Over 75 kW)	Rated current	Yes	A	4-109

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Multi-function output terminal	C031	Multi-function output terminal 11 contact selection	00	No	—	4-96
	C032	Multi-function output terminal 12 contact selection				
	C033	Multi-function output terminal 13 contact selection				
	C034	Multi-function output terminal 14 contact selection				
	C035	Multi-function output terminal 15 contact selection				
	C036	Relay output (AL2, AL1) contact selection	01			
Level and output terminal status	C038	Light load signal output mode	01	No	—	4-106
	C039	Light load detection level	Rated current	No	A	
	C040	Overload warning signal output mode	01	No	—	4-49
	C041	Overload warning level	Rated current	No	A	
	C042	Arrival frequency during acceleration	0.00	No	Hz	4-98
	C043	Arrival frequency during deceleration	0.00	No	Hz	
	C044	PID deviation excessive level	3.0	No	%	4-31
	C045	Arrival frequency during acceleration 2	0.00	No	Hz	4-98
	C046	Arrival frequency during deceleration 2	0.00	No	Hz	
	C052	PID FB upper limit	100.0	No	%	4-31
	C053	PID FB lower limit	0.0	No	%	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Level and output terminal status	C055	Overtorque level (Forward power running)	0 to 200 (0.4 to 55 kW)	200	No	%
			0 to 180 (75 to 132 kW)			
	C056	Overtorque level (Reverse regeneration)	0 to 200 (0.4 to 55 kW)	200	No	%
			0 to 180 (75 to 132 kW)			
	C057	Overtorque level (Reverse power running)	0 to 200 (0.4 to 55 kW)	200	No	%
			0 to 180 (75 to 132 kW)			
	C058	Overtorque level (Forward regeneration)	0 to 200 (0.4 to 55 kW)	200	No	%
			0 to 180 (75 to 132 kW)			
	C061	Thermal warning level	0 to 100	80	No	%
Communication function	C062	Alarm code selection	00: OFF (Disabled) 01: 3-bit 02: 4-bit	00	No	—
	C063	0 Hz detection level	0.00 to 100.00	0.00	No	Hz
	C064	Fin overheat warning level	0 to 200	120	No	°C
	C071	Communication speed selection (Baud rate selection)	02: Loop-back test 03: 2400 bps 04: 4800 bps 05: 9600 bps 06: 19200 bps	05	No	—
	C072	Communication station No. selection	1 to 247	1	No	—
	C073	Communication bit length selection	7: 7-bit 8: 8-bit	8	No	—
	C074	Communication parity selection	00: No parity 01: Even 02: Odd	00	No	—
	C075	Communication stop bit selection	1: 1-bit 2: 2-bit	1	No	—
	C076	Communication error selection	00: Trip 01: Decel-Trip (Trip after deceleration stop) 02: Ignore 03: Free-RUN (Free-run stop) 04: Decel-Stop (Deceleration stop)	02	No	—
	C077	Communication error timeout	0.00 to 99.99	0.00	No	s
	C078	Communication wait time	0 to 1000	0	No	ms
	C079	Communication method selection	00: ASCII 01: ModBus-RTU	01	No	—

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Adjustment	C081	O adjustment	0 to 65535	Factory default	Yes	—
	C082	OI adjustment	0 to 65535	Factory default	Yes	—
	C083	O2 adjustment	0 to 65535	Factory default	Yes	—
	C085	Thermistor adjustment	0.0 to 1000.0	Factory default	Yes	4-75
	C091	Debug mode selection	Use "00". * Do not change.	00	No	—
Others	C101	UP/DWN selection	00: Not save (Do not store the frequency data) 01: Save (Store the frequency data)	00	No	—
	C102	Reset selection	00: ON-RESET (Trip reset at power-on) 01: OFF-RESET (Trip reset when the power is OFF) 02: On in Trip (Enabled only during trip (Reset when the power is ON)) 03: Trip RESET (Trip reset only)	00	Yes	—
	C103	Reset frequency matching selection	00: 0 Hz start 01: f-match (Frequency matching start) 02: Actv, f-match (Active Frequency Matching restart)	00	No	—
Meter adjustment	C105	FM gain setting	50 to 200	100	Yes	%
	C106	AM gain setting	50 to 200	100	Yes	%
	C107	AMI gain setting	50 to 200	100	Yes	%
	C109	AM bias setting	0 to 100	0	Yes	%
	C110	AMI bias setting	0 to 100	20	Yes	%
Terminal	C111	Overload warning level 2	0.0 to 2.00 × Rated current (0.4 to 55 kW) 0.0 to 1.80 × Rated current (75 to 132 kW)	Rated current	No	A
Adjustment	C121	O zero adjustment	0 to 65535	Factory default	Yes	—
	C122	OI zero adjustment	0 to 65535	Factory default	Yes	—
	C123	O2 zero adjustment	0 to 65535	Factory default	Yes	—

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page	
Output terminal operation function	C130	Output 11 ON delay	0.0 to 100.0	0.0	No	s	4-108
	C131	Output 11 OFF delay	0.0 to 100.0	0.0			
	C132	Output 12 ON delay	0.0 to 100.0	0.0			
	C133	Output 12 OFF delay	0.0 to 100.0	0.0			
	C134	Output 13 ON delay	0.0 to 100.0	0.0			
	C135	Output 13 OFF delay	0.0 to 100.0	0.0			
	C136	Output 14 ON delay	0.0 to 100.0	0.0			
	C137	Output 14 OFF delay	0.0 to 100.0	0.0			
	C138	Output 15 ON delay	0.0 to 100.0	0.0			
	C139	Output 15 OFF delay	0.0 to 100.0	0.0			
	C140	Relay output ON delay	0.0 to 100.0	0.0			
	C141	Relay output OFF delay	0.0 to 100.0	0.0			
Output terminal operation function	C142	Logic output signal 1 selection 1	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00	No	—	4-102
	C143	Logic output signal 1 selection 2	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00			
	C144	Logic output signal 1 operator selection	00: AND 01: OR 02: XOR	00			
	C145	Logic output signal 2 selection 1	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00			
	C146	Logic output signal 2 selection 2	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00			
	C147	Logic output signal 2 operator selection	00: AND 01: OR 02: XOR	00			
	C148	Logic output signal 3 selection 1	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00			
	C149	Logic output signal 3 selection 2	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00			
Output terminal operation function	C150	Logic output signal 3 operator selection	00: AND 01: OR 02: XOR	00	No	—	4-102
	C151	Logic output signal 4 selection 1	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00			

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Output terminal operation function	C152	Logic output signal 4 selection 2	Same as options for C021 to C026 (excluding LOG1 to LOG6)	No	—	4-102
	C153	Logic output signal 4 operator selection	00: AND 01: OR 02: XOR			
	C154	Logic output signal 5 selection 1	Same as options for C021 to C026 (excluding LOG1 to LOG6)			
	C155	Logic output signal 5 selection 2	Same as options for C021 to C026 (excluding LOG1 to LOG6)			
	C156	Logic output signal 5 operator selection	00: AND 01: OR 02: XOR			
	C157	Logic output signal 6 selection 1	Same as options for C021 to C026 (excluding LOG1 to LOG6)			
	C158	Logic output signal 6 selection 2	Same as options for C021 to C026 (excluding LOG1 to LOG6)			
	C159	Logic output signal 6 operator selection	00: AND 01: OR 02: XOR			
Input terminal response	C160	Input terminal response time 1	0 to 200 (× 2 ms)	No	ms	4-108
	C161	Input terminal response time 2	0 to 200 (× 2 ms)			
	C162	Input terminal response time 3	0 to 200 (× 2 ms)			
	C163	Input terminal response time 4	0 to 200 (× 2 ms)			
	C164	Input terminal response time 5	0 to 200 (× 2 ms)			
	C165	Input terminal response time 6	0 to 200 (× 2 ms)			
	C166	Input terminal response time 7	0 to 200 (× 2 ms)			
	C167	Input terminal response time 8	0 to 200 (× 2 ms)			
	C168	FW terminal response time	0 to 200 (× 2 ms)			
Others	C169	Multi-step speed/ position determination time	0 to 200 (× 2 ms)	No	ms	4-16 4-137

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
H001	Auto-tuning selection	00: OFF (Disabled) 01: ON (STOP) 02: ON (Rotation)	00	No	—	4-111
H002	Motor parameter selection	00: Standard motor parameter 01: Auto-tuning parameter 02: Auto-tuning parameter (online auto-tuning enabled)	00	No	—	4-111 4-113 4-115
H202	* 2nd motor parameter selection		00			
H003	Motor capacity selection	0.20 to 160.0	Factory default	No	kW	4-19 4-111 4-115 4-118
H203	* 2nd motor capacity selection		Factory default			
H004	Motor pole number selection	2/4/6/8/10	4	No	Pole	
H204	* 2nd motor pole number selection		4			
H005	Speed response	0.001 to 80.000	1.590	Yes	—	4-89 4-92
H205	* 2nd speed response		1.590			
H006	Stabilization parameter	0 to 255	100	Yes	—	4-120
H206	* 2nd stabilization parameter		100			
H306	* 3rd stabilization parameter		100			
H020	Motor parameter R1	0.001 to 65.535	Depends on the motor capacity.	No	Ω	
H220	* 2nd motor parameter R1		Depends on the motor capacity.			
H021	Motor parameter R2	0.001 to 65.535	Depends on the motor capacity.	No	Ω	4-115
H221	* 2nd motor parameter R2		Depends on the motor capacity.			
H022	Motor parameter L	0.01 to 655.35	Depends on the motor capacity.	No	mH	
H222	* 2nd motor parameter L		Depends on the motor capacity.			

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Control parameter	H023	Motor parameter IO	0.01 to 655.35	Depends on the motor capacity.	No	A	4-115
	H223	* 2nd motor parameter IO		Depends on the motor capacity.			
	H024	Motor parameter J	0.001 to 9999.000	Depends on the motor capacity.	No	kgm ²	
	H224	* 2nd motor parameter J		Depends on the motor capacity.			
	H030	Motor parameter R1 (auto-tuning data)	0.001 to 65.535	Depends on the motor capacity.	No	Ω	4-111 4-115
	H230	* 2nd motor parameter R1 (auto-tuning data)		Depends on the motor capacity.			
	H031	Motor parameter R2 (auto-tuning data)	0.001 to 65.535	Depends on the motor capacity.	No	Ω	
	H231	* 2nd motor parameter R2 (auto-tuning data)		Depends on the motor capacity.			
	H032	Motor parameter L (auto-tuning data)	0.01 to 655.35	Depends on the motor capacity.	No	mH	
	H232	* 2nd motor parameter L (auto-tuning data)		Depends on the motor capacity.			
H033	Motor parameter IO (auto-tuning data)	0.01 to 655.35	Depends on the motor capacity.	No	A		
H233	* 2nd motor parameter IO (auto-tuning data)		Depends on the motor capacity.				

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Control parameter	H034	Motor parameter J (auto-tuning data)	0.001 to 9999.000	Depends on the motor capacity.	No	kgm ²	4-111 4-115
	H234	* 2nd motor parameter J (auto-tuning data)		Depends on the motor capacity.			
	H050	PI proportional gain	0.0 to 1000.0	100.0	Yes	—	4-89 4-92
	H250	* 2nd PI proportional gain		100.0			
	H051	PI integral gain	0.0 to 1000.0	100.0	Yes	—	
	H251	*2nd PI integral gain		100.0			
	H052	P proportional gain	0.01 to 10.00	1.00	Yes	—	
	H252	*2nd P proportional gain		1.00			
	H060	Limit at 0 Hz	0.0 to 100.0	100.0	Yes	%	4-117
	H260	* 2nd limit at 0 Hz		100.0			
	H061	Boost amount at SLV startup, 0 Hz	0 to 50	50	Yes	%	
	H261	* 2nd boost amount at SLV startup, 0 Hz		50			
	H070	For PI proportional gain switching	0.0 to 1000.0	100.0	Yes	—	4-89
	H071	For PI integral gain switching	0.0 to 1000.0	100.0	Yes	—	
	H072	For P proportional gain switching	0.00 to 10.00	1.00	Yes	—	
	H073	Gain switching time	0 to 9999	100	Yes	ms	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
P001	Operation selection at option 1 error	00: Trip 01: RUN (Continues operation)	00	No	—	4-111
P002	Operation selection at option 2 error	00: Trip 01: RUN (Continues operation)	00	No	—	
P011	Encoder pulses	128 to 65535	1024	No	Pulse	4-124 4-133 4-134
P012	V2 control mode selection	00: ASR (speed control mode) 01: APR (pulse train position control mode) 02: APR2 (absolute position control mode) 03: HAPR (High resolution absolute position control mode)	00	No	—	4-124 4-136
P013	Pulse train mode selection	00: Mode 1 01: Mode 2 02: Mode 3	00	No	—	4-127
P014	Orientation stop position	0 to 4095	0	No	—	4-134
P015	Orientation speed setting	Starting frequency to Max. frequency (upper limit: 120.0)	5.00	No	Hz	
P016	Orientation direction setting	00: FWD (Forward side) 01: REV (Reverse side)	00	No	—	
P017	Position ready range setting	0 to 10000	5	No	Pulse	4-127 4-134
P018	Position ready delay time setting	0.00 to 9.99	0.00	No	s	4-127 4-134
P019	Electronic gear setting position selection	00: FB (Position feedback side) 01: REF (Position command side)	00	Yes	—	4-128 4-129
P020	Electronic gear ratio numerator	1 to 9999	1	Yes	—	
P021	Electronic gear ratio denominator	1 to 9999	1	Yes	—	
P022	Position control feedforward gain	0.00 to 655.35	0.00	Yes	—	
P023	Position loop gain	0.00 to 100.00	0.50	Yes	rad/s	4-124 4-128 4-129 4-134 4-136
P024	Position bias amount	-2048 to 2048	0	Yes	rad/s	4-128
P025	Secondary resistance compensation enable/disable selection	00: OFF (Disabled) 01: ON (Enabled)	00	No	—	4-114
P026	Overspeed error detection level	0.0 to 150.0	135.0	No	%	5-7
P027	Speed deviation error detection level	0.00 to 120.00	7.50	No	Hz	4-124

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
P028	Motor gear ratio numerator	1 to 9999	1	No	—	4-133
P029	Motor gear ratio denominator	1 to 9999	1	No	—	
P031	Acceleration/ deceleration time input type	00: OPE (Digital Operator) 01: Option 1 02: Option 2 03: EzSQ (Drive Programming)	00	No	—	4-8
P032	Orientation stop position input type	00: OPE (Digital Operator) 01: Option 1 02: Option 2	00	No	—	—
P033	Torque reference input selection	00: O (Terminal O) 01: OI (Terminal OI) 02: O2 (Terminal O2) 03: OPE (Digital Operator) 06: Option 1 07: Option 2	00	No	—	4-126
P034	Torque reference setting	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW)	0	Yes	%	
P035	Polarity selection at torque reference via O2	00: Sign (Signed) 01: Direction (Depends on the RUN direction)	00	No	—	
P036	Torque bias mode	00: OFF (None) 01: OPE (Digital Operator) 02: O2 (Terminal O2) 05: Option 1 06: Option 2	00	No	—	4-126 4-127
P037	Torque bias value	-200 to +200 (0.4 to 55 kW) -180 to +180 (75 to 132 kW)	0	Yes	%	
P038	Torque bias polarity selection	00: Sign (Signed) 01: Direction (Depends on the RUN direction)	00	No	—	
P039	Speed limit value in torque control (forward)	0.00 to Maximum frequency	0.00	Yes	Hz	4-126
P040	Speed limit value in torque control (reverse)	0.00 to Maximum frequency	0.00	Yes	Hz	
P044	DeviceNet comm Watch dog timer	0.00 to 99.99	1.00	No	s	—
P045	Operation setting at communications error	00: Trip 01: Decel-Trip (Trip after deceleration stop) 02: Ignore 03: Free RUN 04: Decel-Stop (Deceleration stop)	00	No	—	—

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
P046	Instance Number	0: Basic speed I/O 1: Extended speed I/O 2: Extended speed and Torque control 3: Special I/O 4: Extended control I/O 5: Extended control I/O and multifunction I/O monitor 6: Flexible format 7: Extended speed and Acceleration control 8-20: Not used	1	No	—	—
P048	Operation setting at idle mode detection	00: Trip 01: Decel-Trip (Trip after deceleration stop) 02: Ignore 03: Free RUN 04: Decel-Stop (Deceleration stop)	00	No	—	—
P049	Polarity setting for rotation speed	0/2/4/6/8/10/12/14/16/18/20/22/24/26/28/30/32/34/36/38	0	No	—	—
P055	Pulse train frequency scale	1.0 to 50.0	25.0	No	kHz	4-144
P056	Pulse train frequency filter time constant	0.01 to 2.00	0.10	No	s	
P057	Pulse train frequency bias amount	-100 to 100	0	No	%	
P058	Pulse train frequency limit	0 to 100	100	No	%	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Absolute position control	P060	Multi-step position command 0	Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	0	Yes	— 4-136
	P061	Multi-step position command 1	Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	0		
	P062	Multi-step position command 2	Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	0		
	P063	Multi-step position command 3	Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	0		
	P064	Multi-step position command 4	Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	0		
	P065	Multi-step position command 5	Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	0		
	P066	Multi-step position command 6	Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	0		
	P067	Multi-step position command 7	Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	0		
	P068	Zero return mode	00: Low speed 01: High speed 1 02: High speed 2	00	Yes	—
	P069	Zero return direction selection	00: FWD (Forward side) 01: REV (Reverse side)	00	Yes	—
	P070	Low-speed zero return frequency	0.00 to 10.00	0.00	Yes	Hz
	P071	High-speed zero return frequency	0.00 to Maximum frequency	0.00	Yes	Hz
	P072	Position range specification (forward)	0 to 268435455 (at P012 = 02) 0 to 1073741823 (at P012 = 03)	268435455	Yes	— 4-136

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
P073	Position range specification (reverse)	-268435455 to 0 (at P012 = 02) -1073741823 to 0 (at P012 = 03)	-268435455	Yes	—	4-137
	P074 Teaching selection	00: X00 (Multi-step position command 0 (P060)) 01: X01 (Multi-step position command 1 (P061)) 02: X02 (Multi-step position command 2 (P062)) 03: X03 (Multi-step position command 3 (P063)) 04: X04 (Multi-step position command 4 (P064)) 05: X05 (Multi-step position command 5 (P065)) 06: X06 (Multi-step position command 6 (P066)) 07: X07 (Multi-step position command 7 (P067))	00	Yes	—	
P100 to P131	Drive Program parameter U(00) to U(31)	0 to 65535	0	Yes	—	—
P160 to P169	Option I/F cmd W register 1 to 10	0000 to FFFF	0000	Yes	—	—
P170 to P179	Option I/F cmd R register 1 to 10	0000 to FFFF	0000	Yes	—	—
P180	Profibus node address	0 to 125	0	No	—	—
P181	Profibus clear mode	00: Clear 01: Last value	00	No	—	—
P182	Profibus Map selection	00: PPO 01: Conventional 02: Flexible mode	00	No	—	—
P185	CANOpen Node address	0 to 127	0	No	—	—
P186	CANOpen communication speed	00: Auto 01: 10Kbps 02: 20Kbps 03: 50Kbps 04: 125Kbps 05: 250Kbps 06: 500Kbps 07: 800Kbps 08: 1Mbps	06	No	—	—
P190	CompoNet node address	0 to 63	0	No	—	—
P192	DeviceNet node address	0 to 63	63	No	—	—
P195	ML2 frame length	00: 32 bytes 01: 17 bytes	00	No	—	—
P196	ML2 node address	21 to 3E	21	No	—	—

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
User parameter	U001	User 1 selection	no/d001 to P196	Yes	—	4-53
	U002	User 2 selection	no/d001 to P196			
	U003	User 3 selection	no/d001 to P196			
	U004	User 4 selection	no/d001 to P196			
	U005	User 5 selection	no/d001 to P196			
	U006	User 6 selection	no/d001 to P196			
	U007	User 7 selection	no/d001 to P196			
	U008	User 8 selection	no/d001 to P196			
	U009	User 9 selection	no/d001 to P196			
	U010	User 10 selection	no/d001 to P196			
	U011	User 11 selection	no/d001 to P196			
	U012	User 12 selection	no/d001 to P196			

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Chapter 4

Functions

4-1	Monitor Mode.....	4-1
4-2	Function Mode.....	4-8
4-3	Functions When PG Option Board (3G3AX-PG01) Is Used	4-123
4-4	Communication Function.....	4-145

4-1 Monitor Mode

Output Frequency Monitor [d001]

Displays the set point of output frequency of the Inverter affected by acceleration and deceleration ramps but without compensations. During stop, "0.00" is displayed.

(Display)

0.00 to 400.00 : Displays in increments of 0.01 Hz.

Note: When the frequency reference is set using the Digital Operator, the output frequency can be changed with the Increment/Decrement key during operation only.

The frequency setting changed with this monitor will be reflected in frequency reference F001.

Pressing the Enter key overwrites the currently selected frequency reference.

Note: This will correspond with the theoretical motor speed but not with the real output frequency of the inverter.

Output Current Monitor [d002]

Displays the output current value of the Inverter. During stop, "0.00" is displayed.

(Display)

0.0 to 9999.0: Displays in increments of 0.1 A.

Rotation Direction Monitor [d003]

Displays the RUN direction of the Inverter.

The RUN LED indicator lights up during forward/reverse rotation.

(Display)

FWD: Forward

STOP: Stop

REV: Reverse

PID Feedback Value Monitor [d004]

When "Enabled" (01) or "Reverse output enabled" (02) is selected in PID selection A071, the PID feedback value can be monitored.

Gain conversion is enabled with PID scale A075.

"d004 display" = "PID feedback value (%)" × "PID scale (A075)"

(A075): 0.01 to 99.99 (Can be set in increments of 0.01.)


(Display)

0.00 to 999000.00: Displays in increments of 0.01.

Multi-function Input Monitor [d005]

- This monitor indicates the input status of the multi-function input terminals.
- The item that the built-in CPU recognizes to be "significant" is indicated as being ON.
This does not depend on the NO/NC contact setting.


(Example)
FW, Multi-function input terminals 7, 2, 1: ON
Multi-function input terminals 8, 6, 5, 4, 3: OFF



Multi-function Output Monitor [d006]

- This monitor indicates the output status of the multi-function output terminals.
- This monitor displays the output status of the built-in CPU, not the control circuit terminal status.

(Example)
Multi-function output terminals 12, 11: ON
Relay output terminal AL2, Multi-function output terminals 15, 14, 13: OFF



Output Frequency Monitor (After Conversion) [d007]

Displays a gain conversion value based on the coefficient set in frequency conversion coefficient b086. This monitor is used to change the unit of displayed data (e.g. motor rpm).

"d007 display" = "Output frequency (d001)" × "Frequency conversion coefficient (b086)"
(b086) 0.1 to 99.9 (Can be set in increments of 0.1.)

(Example)
To display 4-pole motor rpm:
Motor rpm N (min⁻¹) = (120 × f (Hz)) / P (pole)
= f (Hz) × 30
As such, when b086 = 30.0, a motor rpm of 1800 (60 × 30.0) is displayed.

(Display)
0.00 to 39960.00: Displays in increments of 0.01.

Note: When the frequency reference is set using the Digital Operator, the output frequency can be changed with the Increment/Decrement key during operation only.
 The frequency setting changed with this monitor will be reflected in frequency reference F001.
 Pressing the Enter key overwrites the currently selected frequency reference. (The data storage accuracy depends on each frequency reference.)

Real Frequency Monitor [d008]

When a motor with an encoder is connected to a load, and the PG board (3G3AX-PG01) is used, this monitor displays the real frequency of the motor (regardless of the control method).

(Display)

In forward rotation: 0.00 to 400.00 : Displays in increments of 0.01 Hz.

In reverse rotation: 0.00 to -400.00 : Displays in increments of 0.01 Hz.

Note 1: To use this monitor, set the number of encoder pulses (P011) and the motor pole number selection (H004 or H204) correctly.

Note 2: The monitored value does not depend on V/f characteristics selection A044.

Torque Reference Monitor [d009]

When torque control is selected for sensor vector control, this monitor displays the currently entered torque reference value.

(Display)

-200 to 200: Displays in increments of 1%.

Torque Bias Monitor [d010]

When sensor vector control is selected, this monitor displays the torque bias amount currently set in display code d010.

(Display)

-200 to 200: Displays in increments of 1%.

Output Torque Monitor [d012]

Displays an estimated value of the Inverter's output torque.

(Display)

-200 to 200: Displays in increments of 1%.

Note: This monitor is enabled only when "sensorless vector control", "0-Hz sensorless vector control", or "sensor vector control" is selected as the control mode.

Output Voltage Monitor [d013]

Displays the output voltage of the Inverter.

(Display)

0.0 to 600.0: Displays in increments of 0.1 V.

Input Power Monitor [d014]

Displays the input power (instantaneous value) of the Inverter.

(Display)

0.0 to 999.9: Displays in increments of 0.1 W.

Power ON Time Monitor [d015]

- Displays the integrated power (integrated value of input power) of the Inverter.
The gain conversion of displayed data is performed with integrated power display gain b079.

"d015 display" = "Input power calculation value (kWh)" / "Integrated power display gain (b079)"
(b079) 1. to 1000. (Can be set in increments of 1.)

- When integrated power clear b078 is set to "01", pressing the Enter key clears the integrated power value.
- The integrated power value can also be cleared via terminal input, if "53" (KHC: Integrated power clear) is allocated to any of the multi-function input terminals.
- When b079 is set to "1000", up to "999000" (kWh) can be displayed.

(Display)

0 to 999999.9 : Displays in increments of 1 kWh/(b079) set value.

Total RUN Time [d016]

Displays the total RUN time of the Inverter.

(Display)

0 to 999999 : Displays in increments of 1 hour.

Power ON Time Monitor [d017]

Displays the total power ON time of the Inverter.

(Display)

0 to 999999 : Displays in increments of 1 hour.

Fin Temperature Monitor [d018]

Displays the temperature of the fin inside the Inverter.

(Display)

-020. to 200.0: Displays in increments of 0.1°C.

Motor Temperature Monitor [d019]

- Displays the temperature of the thermistor connected between the control circuit terminals TH and CM1.
- Set thermistor selection b098 to "02" (NTC enabled).

(Display)

-020. to 200.0: Displays in increments of 0.1°C.

Note: When b098 = "01" (PTC enabled), the motor temperature monitor is disabled.


4

Life Assessment Monitor [d022]

- This monitor indicates a life assessment result.

The following two items can be monitored:

- 1: Main circuit board capacitor service life
- 2: Cooling fan rpm reduction



Note 1: The capacitor service life is calculated every 10 minutes. If the Inverter is turned on/off frequently within this interval, the capacitor service life cannot be correctly diagnosed.

Note 2: While the cooling fan is stopped with b092 set to "01", the cooling fan rpm is judged as being normal.

Program Counter [d023]

Refer to Drive Programming Manual.

Display: 0 to 1024

Program Number [d024]

Refer to Drive Programming Manual.

Display: 0 to 9999

Drive Programming Monitor (UM0 to UM2) [d025 to d027]

Refer to Drive Programming Manual.

Display: -2147483647 to 2147483647

Pulse Counter Monitor [d028]

You can monitor a total pulse count of multi-function input function pulse counter 74 (PCNT).

Display: 0 to 2147483647

Position Command Monitor (Absolute Position Control Mode) [d029]

You can monitor a position command in absolute position control mode.

Note: This monitor is enabled only when V2 control mode selection P012 is set to "02" or "03" in sensor vector control mode.

Display: -1073741823 to 1073741823 when HAPR is selected
-268435456 to 268435456 when APR2 is selected

Current Position Monitor (Absolute Position Control Mode) [d030]

You can monitor the current position in absolute position control mode.

Note: This monitor is enabled only when V2 control mode selection P012 is set to "02" or "03" in sensor vector control mode.

Display: -1073741823 to 1073741823 when HAPR is selected
-268435456 to 268435456 when APR2 is selected

Clock [d031]

Setting Date and Time for the LCD digital operator.

(Display)
2000/1/1 to 2099/12/31: Displays in increments of 1 day.
00:00 to 23:59: Displays in increments of 1 minute.

Inverter Mode [d060]

Dual rating. Refer to b049 parameter.

(Display)
00 : Constant torque.
01 : Variable torque.

Fault Frequency Monitor [d080]

Displays the number of times the Inverter has tripped.

(Display)
0 to 65535 : Displays in increments of 1 time.

Fault Monitors 1 to 6 [d081] to [d086]

Refer to **7. Trip Mode** in *Chapter 3.4 Operation*.

Warning Monitor [d090]

- If the set data is inconsistent with other data, a warning code is displayed.
- While this warning remains in effect, the Warning LED indicator stays lit until forced to rewrite or correct the data.
- For details on the Warning display, refer to "5-2 Warning Function".

Display: 0 to 385

DC Voltage Monitor [d102]

- Displays the DC voltage (between P and N) of the Inverter.
- During operation, the monitor value changes depending on the actual DC voltage of the Inverter.

(Display)

0.0 to 999.9: Displays in increments of 0.1 V.

Regenerative Braking Load Rate Monitor [d103]

Displays a regenerative braking load rate. When the monitor value comes close to exceeding the value set in usage rate of the regenerative braking function b090, "E06 (Braking resistor overload protection)" works to trip the Inverter.

(Display)

0.0 to 100.0: Displays in increments of 0.1%.

Electronic Thermal Monitor [d104]

Displays an electronic thermal load rate. When the monitor value comes close to exceeding 100%, "E05 (Overload protection)" works to trip the Inverter.

(Display)

0.0 to 100.0: Displays in increments of 0.1%.

4-2 Function Mode

<Group F: Basic Function Parameters>

Output Frequency Setting/Monitor

- Set the Inverter output frequency.
- With frequency reference selection A001 set to 02, you can set the output frequency with F001. For other methods, refer to the [A001] section in "Frequency Reference Selection" (page 4-10). (If A001 is set other than to "02", F001 functions as the frequency reference monitor.)
- If a frequency is set in F001, the same value is automatically set in multi-step speed reference 0 (A020). To set the 2nd/3rd control, use the 2nd multi-step speed reference 0 (A220)/3rd multi-step speed reference 0 (A320) or use F001 with the SET/SET3 terminal turned on. To set using the SET/SET3 terminal, allocate 08 (SET)/17 (SET3) to the desired multi-function input.
- When this monitor is used to display a target value of the PID function, the monitor value is displayed as a percentage (%). (100% = Max. frequency)

Parameter No.	Function name	Data	Default setting	Unit
F001	Output frequency setting/monitor	0.0/Starting frequency to 1st/2nd/3rd max. frequency	0.00	Hz
A020	Multi-step speed reference 0		6.00	
A220	*2nd multi-step speed reference 0			
A320	*3rd multi-step speed reference 0			
Related functions		A001, A020, A220, A320, C001 to C008		

* To switch to the 2nd/3rd control, allocate 08 (SET)/17 (SET3) to the desired multi-function input and then turn it on.


Acceleration/Deceleration Time

- Set an acceleration/deceleration time for the motor. For a slow transition, set to a large value, and for a fast transition, set to a small one.

Parameter No.	Function name	Data	Default setting	Unit
F002	Acceleration time 1	0.01 to 3600.00	10.00	s
F202	*2nd acceleration time 1			
F302	*3rd acceleration time 1			
F003	Deceleration time 1			
F203	*2nd deceleration time 1			
F303	*3rd deceleration time 1			
P031	Acceleration/deceleration time input type	00: OPE (Digital Operator) 01: Option 1 02: Option 2 03: EzSQ (Drive Programming)	00	—
Related functions		A004, A204, A304, P031, C001 to C008		

* To switch to 2nd/3rd acceleration time 1 or 2nd/3rd deceleration time 1, allocate 08 (SET)/17 (SET3) to the desired multi-function input and then turn it on.

- The set time here indicates the acceleration/deceleration time from 0 Hz to the maximum frequency.



- When the LAD cancel (LAC) function is selected in the multi-function input selection and the signal is turned on, the acceleration/deceleration time is ignored, and the output frequency instantaneously follows the reference frequency.
- To switch between the 1st/2nd/3rd acceleration times or between the 1st/2nd/3rd deceleration times, allocate 08 (SET)/17 (SET3) to the desired multi-function input (refer to "Multi-function Input Selection" (page 4-79)), and use the SET/SET3.
- You can set the acceleration/deceleration time via (1) the Digital Operator, (2) optional board 1, or (3) optional board 2.
- Even if a short acceleration/deceleration time is set, the actual time cannot be shorter than the minimum acceleration/deceleration time that is determined by the mechanical inertia moment and the motor torque. If you set a time shorter than the minimum time, an overcurrent/overvoltage trip may occur.

Acceleration Time T_s

$$T_s = \frac{(J_L + J_M) \times N_M}{9.55 \times (T_s - T_L)}$$

Deceleration Time T_B

$$T_B = \frac{(J_L + J_M) \times N_M}{9.55 \times (T_B + T_L)}$$

J_L : Inertia moment of the load converted to the motor shaft [kg·m²]

J_M : Inertia moment of the motor [kg·m²]

N_M : Motor rotation speed [r/min]

T_s : Max. acceleration torque with the Inverter driving [N·m]

T_B : Max. deceleration torque with the Inverter driving [N·m]

T_L : Required driving torque [N·m]

For short-time deceleration, use a braking unit (optional).

Operator Rotation Direction Selection

- Select the rotation direction applied to the RUN command via the Digital Operator.
- This is disabled at terminals.

Parameter No.	Function name	Data	Default setting	Unit
F004	Operator rotation direction selection	00: FWD (Forward) 01: REV (Reverse)	00	—

<Group A: Standard Function Parameters>**Frequency Reference Selection**

Select the method for using the frequency reference.

Parameter No.	Function name	Data	Default setting	Unit
A001	Frequency reference selection	00: VR (Digital Operator (FREQ adjuster)) 01: Terminal 02: Digital Operator (F001) 03: RS485 (ModBus communication) 04: Option 1 05: Option 2 06: Pulse train frequency 07: EzSQ (Drive Programming) 10: (Math) Operation function result	01	—
Related functions		A005, A141 to A143, A145, A146		

Data	Frequency reference source
00	Set a frequency with the FREQ adjuster on the Digital Operator. (Enabled when 3G3AX-OP01 is used.)
01	Set a frequency via terminals. (O-L, OI-L, O2-L)
02	Set a frequency via the Digital Operator (F001).
03	Set a frequency through the ModBus communication.
04	Set a frequency via the PCB mounted to option port 1.
05	Set a frequency via the PCB mounted to option port 2.
06	Set a frequency as a pulse train by using 3G3AX-PG01.
07	Drive Programming
10	The operation result of the frequency operation function is defined as a frequency reference.

RUN Command Selection

Select the method for using the RUN/STOP command.

Parameter No.	Function name	Data	Default setting	Unit
A002	RUN command selection	01: Terminal 02: Digital Operator (F001) 03: RS485 (ModBus communication) 04: Option 1 05: Option 2	01	—
Related functions		F004, C001 to C008, C019		

Data	RUN command source
01	Turn on/off the FW or RV allocated to terminals. The STOP command is activated if both Forward/Reverse commands are input simultaneously.
02	Use the STOP/RESET key on the Digital Operator.
03	Use the ModBus communication.
04	Use option board 1.
05	Use option board 2.


Base Frequency

- Match the Inverter output (frequency/voltage) to the motor rating. Be careful, especially if you set a base frequency below 50 Hz. Otherwise, the motor may burn out.

Parameter No.	Function name	Data	Default setting	Unit
A003	Base frequency	30 to Max. frequency [A004]	50	Hz
A203	*2nd base frequency	30 to 2nd max. frequency [A204]		
A303	*3rd base frequency	30 to 3rd max. frequency [A304]		
Related functions		A004, A204, A304, A081, A082		

* To switch to the 2nd/3rd control, allocate 08 (SET)/17 (SET3) to the desired multi-function input and then turn it on.


- For the base frequency and motor voltage selections, match the Inverter output (frequency/voltage) to the motor rating.



- If you apply a base frequency of over 60 Hz, a special motor is required. This may require the Inverter to increase its capacity to accommodate a different applicable motor.
- Set the motor voltage selection according to the motor specifications. If the voltage exceeds the specified level, the motor may burn out.

Maximum Frequency

- Set the maximum value of the output frequency.
- The value set here is the maximum value (e.g., 10 V in the range from 0 to 10 V) of the external analog input (frequency reference).
- The maximum Inverter output voltage from base to maximum frequencies is the voltage set in AVR voltage selection A082.
- The Inverter cannot output voltage beyond that of the incoming voltage.



Parameter No.	Function name	Data	Default setting	Unit
A004	Maximum frequency	30 to 400	50	Hz
A204	*2nd maximum frequency			
A304	*3rd maximum frequency			
Related functions		A003, A203, A303, A081, A082		

* To switch to the 2nd/3rd control, allocate 08 (SET)/17 (SET3) to the desired multi-function input and then turn it on.

Analog Input (O, O2, OI)

- The Inverter has three types of external analog input terminals.

O-L terminal: 0 to 10 V (voltage input)

OI-L terminal: 4 to 20 mA (current input)

O2-L terminal: -10 to 10 V (voltage input)


- Below are the settings for this function.

Parameter No.	Function name	Data	Default setting	Unit
A005	O/OI selection	00: [O]/[O2] Switches between O/OI terminal AT 01: [O]/[O2] Switches between O/O2 terminal AT 02: [O]/VR Switches between O/FREQ adjuster via terminal AT (Enabled only when 3G3AX-OP01 is used.) 03: [OI]/VR Switches between OI/FREQ adjuster via terminal AT (Enabled only when 3G3AX-OP01 is used.) 04: [O2]/VR Switches between O2/FREQ adjuster via terminal AT (Enabled only when 3G3AX-OP01 is used.)	00	—
A006	O2 selection	00: [O2] only 01: [O/OI-P] Auxiliary frequency reference (not reversible) 02: [O/OI-PM] Auxiliary frequency reference (reversible) 03: [OFF] O2 disabled	03	—
Related functions		A005, A006, C001 to C008		


- The frequency reference and reversibility depend on whether "16" (AT) is allocated to a multi-function input, and depend on the combination of A005 and A006, as shown below.
If the frequency reference is "reversible", the motor runs in the reverse direction when "main frequency reference + auxiliary frequency reference" is less than zero, even if the FW (Forward) terminal is ON. Also, note that the motor may run in the reverse direction, resulting in prolonged acceleration time or other phenomena, if the voltage fluctuates around 0 V even with the O2 terminal not connected.

	A006	A005	AT terminal	Main frequency reference	Auxiliary frequency reference (O2-L terminal)	Reversibility
With AT allocated to a multi-function input	00, 03	00	OFF	O-L terminal	Disabled	Not reversible
			ON	OI-L terminal	Disabled	
		01	OFF	O-L terminal	Disabled	Reversible
			ON	O2-L terminal	Disabled	
	01	00 (Example 1)	OFF	O-L terminal	Enabled	Not reversible
			ON	OI-L terminal	Enabled	
		01	OFF	O-L terminal	Enabled	Reversible
			ON	O2-L terminal	Disabled	
	02	00 (Example 2)	OFF	O-L terminal	Enabled	Reversible
			ON	OI-L terminal	Enabled	
		01	OFF	O-L terminal	Enabled	
			ON	O2-L terminal	Disabled	
With AT NOT allocated to a multi-function input	00	—	—	O2-L terminal	Disabled	Reversible
	01	—	—	Addition of the O-L and OI-L terminals	Enabled	Not reversible
	02	—	—	Addition of the O-L and OI-L terminals	Enabled	Reversible
	03	—	—	Addition of the O-L and OI-L terminals	Disabled	Not reversible

(Example 1) Not reversible



(Example 2) Reversible



External Frequency (Voltage/Current) Adjustment

- External analog input (frequency reference)
 - O-L terminal: 0 to 10 V (voltage input)
 - OI-L terminal: 4 to 20 mA (current input)
 - O2-L terminal: -10 to 10 V (voltage input)


Also set an output frequency for the FREQ adjuster on the Digital Operator.

■ Adjusting the O2-L and OI-L Terminals


Parameter No.	Function name	Data	Default setting	Unit
A011 A101	O/OI start frequency	0.00 to 400.0 (Set a start/end frequency.)	0.00	Hz
A012 A102	O/OI end frequency			
A013 A103	O/OI start ratio	0 to 100 (Set a start/end ratio relative to an external frequency reference of 0 to 10 V and 4 to 20 mA.)	0	%
A014 A104	O/OI end ratio		20	
A015 A105	O/OI start selection		100	
A015 A105	O/OI start selection	00: External start frequency (A011 set value) 01: 0 Hz	01	—
A015 A105	O/OI start selection		00	
Related functions		A003, A203, A303, A081, A082		

- To input voltage ranging from 0 to 5 V on the OI-L terminal, set A014 to 50%.

(Example 1) A015/A105: 00



(Example 2) A015/A105: 01



■ Adjusting the O2-L Terminal


Parameter No.	Function name	Data	Default setting	Unit
A111	O2 start frequency	-400.00 to 400.00 (Set a start frequency.)	0.00	Hz
A112	O2 end frequency	-400.00 to 400.00 (Set an end frequency.)	0.00	
A113	O2 start ratio	-100 to O2 end ratio: (Set a start ratio relative to an external frequency reference of -10 to 10 V. *)	-100	%
A114	O2 end ratio	O2 start ratio to 100: (Set an end ratio relative to an external frequency reference of -10 to 10 V. *)	100	
Related functions		A003, A203, A303, A081, A082		

* Below is the ratio from -10 to 10 V.

-10 to 0 V: -100% to 0%

0 to 10 V: 0% to 100%

- For example, to input voltage ranging from -5 to 5 V on the O2-L terminal, set A113 to -50%, and A114 to 50%.



O, O2, OI Sampling

- You can set the built-in filter applied to frequency setting signals of the external voltage/current input.

Parameter No.	Function name	Data	Default setting	Unit
A016	O, O2, OI sampling	1 to 30 31 (with 500 ms filter +/- 0.1 Hz hysteresis)	31	—
Related functions		A011 to A016, C001 to C008		

- Helps remove noise in the frequency setting circuit.
- Set a larger data value if stable operation cannot be secured because of noise.
Note that the larger the data value is, the slower the response time. This parameter specifies a filter time constant for a set value of 1 to 30 ($\times 2$ ms).
- When "31." is selected, a filter time constant of 500 ms and a hysteresis of ± 0.1 Hz are set. (Factory default)

Multi-step Speed Operation Function

- You can set RUN speeds using codes and switch between the set speeds via the terminal.
- For multi-step speed operation, you can select either 4-terminal binary operation (with 16 steps max.) or 7-terminal bit operation (with 8 steps max.).

Parameter No.	Function name	Data	Default setting	Unit
A019	Multi-step speed selection	00: Binary: 16-step selection with 4 terminals 01: Bit: 8-step selection with 7 terminals	00	—
A020	Multi-step speed reference 0	0.0/Starting frequency to Max. frequency	6.00	Hz
A220	*2nd multi-step speed reference 0			
A320	*3rd multi-step speed reference 0			
A021	Multi-step speed reference 1		0.00	
A022	Multi-step speed reference 2			
A023	Multi-step speed reference 3			
A024	Multi-step speed reference 4			
A025	Multi-step speed reference 5			
A026	Multi-step speed reference 6			
A027	Multi-step speed reference 7			
A028 to A035	Multi-step speed references 8 to 15			


* To switch to the 2nd/3rd control, allocate 08 (SET)/17 (SET3) to the desired multi-function input and then turn it on.

- During multi-step speed operation, if frequency reference selection A001 is set to the terminal (01), and the external analog input (O, O2, OI) setting mode based on a combination of O/OI selection A005, O2 selection A006, and the AT terminal is set to "reversible", the RUN command is inverted when "main frequency reference + auxiliary frequency reference" is less than zero.


Binary Operation

- By allocating 02 to 05 (CF1 to CF4) to any of multi-function inputs 1 to 8 (C001 to C008), you can select from multi-step speeds 0 to 15.
- Use A021 to A035 (multi-step speeds 1 to 15) to set frequencies for speeds 1 to 15.
- When the Digital Operator is selected as the frequency reference, speed 0 is set with A020/A220/A320 or F001 (refer to page 4-8). When the control circuit terminal block is selected, speed 0 is set with terminals O, O2, and OI.

Multi-step speeds	CF4	CF3	CF2	CF1
0th	OFF	OFF	OFF	OFF
1st			ON	ON
2nd		ON	OFF	OFF
3rd			ON	ON
4th		OFF	OFF	OFF
5th			ON	ON
6th	ON	OFF	OFF	OFF
7th			ON	ON
8th		ON	OFF	OFF
9th			ON	ON
10th		OFF	OFF	OFF
11th			ON	ON
12th		ON	OFF	OFF
13th			ON	ON
14th		OFF	OFF	OFF
15th			ON	ON



- For multi-step speed binary operation, you can set the wait time until which the terminal input is determined in multi-step speed/position determination time C169. This prevents the transition status before the input determination from being applied.
- If no input is made after the time set in C169, the data is determined.
(Note that the longer the determination time, the slower the input response.)




Bit Operation

- By allocating 32 to 38 (SF1 to SF7) to any of multi-function inputs selection 1 to 8 (C001 to C008), you can select from multi-step speeds 0 to 7.
- For SF1 to SF7 frequency settings, set multi-step speeds 1 to 7 (A021 to A027).

Multi-step speeds	SF7	SF6	SF5	SF4	SF3	SF2	SF1
0th	OFF	OFF	OFF	OFF	OFF	OFF	OFF
1st	x	x	x	x	x	x	ON
2nd	x	x	x	x	x	ON	OFF
3rd	x	x	x	x	ON	OFF	OFF
4th	x	x	x	ON	OFF	OFF	OFF
5th	x	x	ON	OFF	OFF	OFF	OFF
6th	x	ON	OFF	OFF	OFF	OFF	OFF
7th	ON	OFF	OFF	OFF	OFF	OFF	OFF

- When several terminals are simultaneously turned on, priority is given to the terminal with the smallest number.
The x mark in the above table indicates that speed is selected regardless of ON/OFF status.



Jogging Operation Function


- The motor rotates while this function is turned on.

Parameter No.	Function name	Data	Default setting	Unit
A038	Jogging frequency	0.00/Starting frequency to 9.99	6.00	Hz
A039	Jogging stop selection	00: FRS (Free running on jogging stop/ Disabled in operation) 01: DEC (Deceleration stop on jogging stop/ Disabled in operation) 02: DB (DC injection braking on jogging stop/ Disabled in operation*) 03: FRS (RUN) (Free running on jogging stop/Enabled in operation) 04: DEC (RUN) (Deceleration stop on jogging stop/Enabled in operation) 05: DB (RUN) (DC injection braking on jogging stop/Enabled in operation*)	04	—

* When jogging stop selection A039 is set to "02" or "05", the DC injection braking settings are required. (Refer to page 4-24.)

- Allocate 06 (JG) to the desired multi-function input.

Jogging Frequency




- Setting a high jogging frequency causes the Inverter to easily trip. Adjust the set value of jogging frequency A038 to prevent the Inverter from tripping.


■ Jogging Stop Selection

Note: To perform the jogging operation, turn on the JG terminal before the FW or RV terminal.
(Do the same if the RUN command source is set to the Digital Operator.)

(Example 1)



(Example 2)



With jogging stop selection A039 set to "00", "01", or "02", jogging does not function if the FW signal is turned on first.

With A039 set to "03", "04", or "05", jogging functions even if the FW signal is turned on first. However, if the JG signal is turned off before the FW signal, the motor coasts to a free running stop.

Torque Boost


- Compensates for the voltage drop caused by the primary resistance of the motor, or by wiring to suppress torque reduction at a low speed range.
- To select the automatic torque boost for A041/A241, set motor capacity selection H003/H203 and motor pole number selection H004/H204 according to your motor.

Parameter No.	Function name	Data	Default setting	Unit
A041	Torque boost selection	00: Manual torque boost 01: Automatic torque boost	00	—
A241	*2nd torque boost selection			
A042	Manual torque boost voltage	0.0 to 20.0 (Ratio to the value of AVR voltage selection A082)	1.0	%
A242	*2nd manual torque boost voltage			
A342	*3rd manual torque boost voltage			
A043	Manual torque boost frequency	0.0 to 50.0 (Ratio to base frequency)	5.0	%
A243	*2nd manual torque boost frequency			
A343	*3rd manual torque boost frequency			
H003	Motor capacity selection	0.20 to 160.0 (Ratio to base frequency)	Factory default	kW
H203	*2nd motor capacity selection			
H004	Motor pole number selection	2/4/6/8/10	4	Pole
H204	*2nd motor pole number selection			

* To switch to the 2nd/3rd control, allocate 08 (SET)/17 (SET3) to the desired multi-function input and then turn it on.

Manual Torque Boost

- Outputs the voltage set in A042/A242/A342 or A043/A243/A343.
- In A042/A242/A342, set a ratio based on the voltage set in the motor voltage selection as 100%.



- If you raise the set value of the manual torque boost, be careful about motor overexcitation. Otherwise, the motor may burn out.
- In manual torque boost frequency A043/A243/A343, set a ratio based on the base frequency as 100%.

Automatic Torque Boost

- If the automatic torque boost is selected in the torque boost selection (A041/A241: 01), it operates to adjust the output frequency and voltage automatically, depending on the load level. (In actual control, the automatic torque boost is used along with the manual torque boost.)
- To select the automatic torque boost, set motor capacity selection H003/H203 and motor pole number selection H004/H204 correctly according to your motor.
- To avoid a possible overcurrent trip during deceleration, set the AVR selection to "Always ON" (A081: 00).
- If the automatic torque boost cannot provide the desired characteristics, adjust each item, as shown in the following table.

Phenomenon	Adjusting method	Adjustment item
Insufficient torque at low speed (Motor does not run at low speed.)	Gradually increase the voltage setting of the manual torque boost.	A042/A242
	Gradually increase the slip compensation gain of the automatic torque boost.	A047/A247
	Gradually increase the voltage compensation gain of the automatic torque boost.	A046/A246
	Reduce the set value of the carrier frequency.	b083
Rotation speed lowers when load is applied.	Gradually increase the slip compensation gain of the automatic torque boost.	A047/A247
Rotation speed increases when load is applied.	Gradually reduce the slip compensation gain of the automatic torque boost.	A047/A247
Overcurrent trip occurs when load is applied.	Gradually reduce the voltage compensation gain of the automatic torque boost.	A046/A246
	Gradually reduce the slip compensation gain of the automatic torque boost.	A047/A247
	Gradually reduce the voltage setting of the manual torque boost.	A042/A242

Control Method (V/f Characteristics)

You can set V/f characteristics (output voltage/output frequency).

Parameter No.	Function name	Data	Default setting	Unit
A044	V/f characteristics selection	Heavy duty 00: VC (Constant torque characteristics) 01: VP (Special reduced torque characteristics) 02: Free V/f (characteristics) (Only A044/A244 can be set.) 03: SLV (Sensorless vector control) (Only A044/A244 can be set.*1) 04: 0SLV (0-Hz sensorless vector control) (Only A044/A244 can be set.*2) 05: V2 (Sensor vector control) (Only A044/A244 can be set.) Normal duty 00: VC (Constant torque characteristics) 01: VP (Special reduced torque characteristics) 02: Free V/f (characteristics) 03: SLV (Sensorless vector control)	00	—
A244	*2nd V/f characteristics selection			
A344	*3rd V/f characteristics selection			
Related functions		A046, A246, A047, A247, A082, H003, H203, H004, H204		

* To switch to the 2nd/3rd control, allocate 08 (SET)/17 (SET3) to the desired multi-function input and then turn it on.


*1. Refer to "Sensorless Vector Control" (page 4-116).

*2. Refer to "0-Hz Sensorless Vector Control" (page 4-117).

■ Constant Torque Characteristics (VC)


Output voltage is proportional to output frequency.

While proportional from 0 Hz to base frequency, the output voltage is constant from base to maximum frequencies.



■Special Reduced Torque Characteristics (Special VP)

Suitable for a fan or pump that requires torque in a low speed range. These have VC characteristics only for low deceleration in reduced torque characteristics.



Period a: Provides constant torque characteristics within a range from 0 Hz to 10% of the base frequency.

(Example) If the base frequency is 50 Hz, the Inverter provides constant torque characteristics within a range from 0 to 5 Hz.

Period b: Provides reduced torque characteristics within a range from 10% to 100% of the base frequency.


The Inverter outputs voltage based on a curve of the 1.7th power of the frequency.

Period c: Provides constant voltage characteristics within a range from the base frequency to the maximum frequency.


■Free V/f Setting

- You can set desired V/f characteristics by setting 7 points of voltage and frequency. (b100 to b113)
- The free V/f frequencies should always be $1 \leq 2 \leq 3 \leq 4 \leq 5 \leq 6 \leq 7$.
All the default settings are 0 Hz. You must set Free V/f setting 7 first. (Operation is disabled by factory default.)
- If the free V/f setting is enabled, the functions of torque boost A041/A241, base frequency A003/A203/A303, and maximum frequency A004/A204/A304 are disabled. (Free V/f frequency 7 is regarded as the maximum frequency.)

Parameter No.	Function name	Data	Description	Default setting	Unit
b100	Free V/f frequency 1	0 to Free V/f frequency 2	Set frequencies for each break point.	0	Hz
b102	Free V/f frequency 2	0 to Free V/f frequency 3			
b104	Free V/f frequency 3	0 to Free V/f frequency 4			
b106	Free V/f frequency 4	0 to Free V/f frequency 5			
b108	Free V/f frequency 5	0 to Free V/f frequency 6			
b110	Free V/f frequency 6	0 to Free V/f frequency 7			
b112	Free V/f frequency 7	0 to 400			
b101	Free V/f voltage 1	0.0 to 800.0	Set output voltages for each break point. *	0.0	V
b103	Free V/f voltage 2				
b105	Free V/f voltage 3				
b107	Free V/f voltage 4				
b109	Free V/f voltage 5				
b111	Free V/f voltage 6				
b113	Free V/f voltage 7				
Related functions		A044, A244, A344			




* Even if free V/f voltages 1 to 7 are set to 800 V, the Inverter cannot output voltage higher than the input voltage or the value of the motor voltage selection.
Use thorough caution to verify that the output characteristic setting is proper. An improper setting causes overcurrent during acceleration or deceleration, or vibration of the motor and/or machine.



Output Voltage Gain

- Changes the Inverter output voltage, based on the voltage selected in AVR voltage selection A082 as 100%.
- You can avoid motor hunting by reducing the output voltage gain.

Parameter No.	Function name	Data	Default setting	Unit
A045	Output voltage gain	20 to 100	100	%
Related functions		A082		




DC Injection Braking

- DC injection braking is applied to the motor depending on the motor load.
 - Two methods are available for DC injection braking: One is the external method via the multi-function input terminal; the other is the internal method performed automatically to start/stop the motor.
- Even if DC injection braking is used, however, the motor may not stop depending on the moment of inertia of the motor load.

Parameter No.	Function name	Data	Default setting	Unit
A051	DC injection braking selection	00: OFF (Disabled) 01: ON (Enabled) 02: ON (FQ) (Frequency control [A052 set value])	00	—
A052	DC injection braking frequency	0.00 to 400.00	0.50	Hz
A053	DC injection braking delay time	0.0 to 5.0	0.0	s
A054	DC injection braking power	0 to 100 (0.4 to 55 kW)	50	%
		0 to 80 (75 to 132 kW)	40	
A055	DC injection braking time	0.0 to 60.0	0.5	s
A056	DC injection braking method selection	00: Edge operation 01: Level operation	01	—
A057	Startup DC injection braking power	0 to 100 (0.4 to 55 kW)	0	%
		0 to 80 (75 to 132 kW)	0	
A058	Startup DC injection braking time	0.0 to 60.0	0.0	s
A059	DC injection braking carrier frequency	0.5 to 15.0 (0.4 to 55 kW)	5.0	Hz
		0.5 to 10.0 (75 to 132 kW)	3.0	
Related functions		C001 to C008		

■DC Injection Braking Carrier Frequency


You can set a DC injection braking carrier frequency in A059. Note that setting a 5 kHz or higher frequency automatically reduces the braking power. Refer to the following figure (DC injection braking power limit).




DC Injection Braking Power Limit

■External DC Injection Braking

- Allocate 07 (DB) to any of multi-function inputs C001 to C008.
- DC injection braking can be applied by turning on/off the DB terminal, regardless of DC injection braking selection A051.
- Set a braking power level in DC injection braking power A054.
- If DC injection braking delay time A053 is set, the Inverter output is shut off during the set time period and the motor goes into free-run status. After the set time elapses, DC injection braking starts.
- Set DC injection braking time A055 via the Digital Operator or the DB terminal while taking into account motor heat generation.
- Perform each setting according to your system after setting DC injection braking method selection A056.







■Internal DC Injection Braking (A051: 01)

- DC injection braking is applied without terminal operation at start/stop of the Inverter. To use internal DC injection braking, set DC injection braking selection A051 to 01.
- Set the startup DC injection braking power in A057. In A058, set the startup DC injection braking time, regardless of the edge or level operation. (Example 4-a), (Example 4-b)
- Set DC injection braking power A054 to define the braking power other than at startup.
- Set the DC injection braking starting frequency in DC injection braking frequency A052.
- Once DC injection braking delay time A053 is set, the Inverter stops output when the frequency reaches the A052 value after the RUN command (FW) has been turned off. During the set time in A053, the motor remains in free-run status. After the set time in A053, DC injection braking starts.
- Edge and Level operations for internal DC injection braking work differently when the RUN command switches from STOP to RUN.

Edge operation: Giving priority to DC injection braking time A055, performs DC injection braking for the set time in A055. DC injection braking operates for the set time in A055 when the output frequency reaches the set value in A052 after the RUN command (FW) is turned off. Even if the RUN command is turned on during DC injection braking, the latter is effective during the set time in A055. (Example 5-a), (Example 6-a)


Level operation: Giving priority to the RUN command, shifts to normal operation, ignoring DC injection braking time A055. When the RUN command is turned on during DC injection braking, returns to normal operation, ignoring the set time in A055. (Example 5-b), (Example 6-b)






■ Internal DC Injection Braking (Operates Only at the Set Frequency) (A051: 02)

- DC injection braking can be applied when the output frequency becomes lower than the DC injection braking frequency (A052).
- Neither (2) external nor (3) internal DC injection braking is available while this function is selected.
- Operates only when the RUN command is turned on.
- DC injection braking starts when both the reference and current frequencies become lower than A052. (Example 7-a)
- When the reference frequency exceeds the A052 set value by 2 Hz or more, DC injection braking is released and the output returns to normal. (Example 7-a)
- If the reference frequency is "0" when the operation starts with analog input, the initial operation is DC injection braking because both the reference and current frequencies are "0". (Example 7-b)
- If the RUN command is turned on with the frequency reference established (or a value larger than the A052 setting is input), the initial operation is set to normal output.



- The operation to return to normal varies depending on the setting of DC injection braking power A054.



Frequency Limit


- You can set both the upper/lower limits to the output frequency.

Parameter No.	Function name	Data	Default setting	Unit
A061	Frequency upper limit	0.0/Frequency lower limit [A062] to Max. frequency [A004]	0.00	Hz
A261	*2nd frequency upper limit	0.0/2nd frequency lower limit [A262] to 2nd max. frequency [A204]	0.00	
A062	Frequency lower limit	0.0/Starting frequency to Frequency upper limit [A061]	0.00	
A262	*2nd frequency lower limit	0.0/Starting frequency to 2nd frequency upper limit [A261]	0.00	
Related functions		C001 to C008		

* To switch to the 2nd/3rd control, allocate 08 (SET)/17 (SET3) to the desired multi-function input and then turn it on.


- Does not accept any frequency reference beyond the upper/lower limits.
- Set the upper limit first. Make sure that the upper limit (A061/A261) is larger than the lower limit (A062/A262).
- Make sure that the upper and lower limiter settings do not exceed the maximum frequency (A004/A204/A304).
- Make sure that the output frequency (F001) and multi-step speeds 1 to 15 (A021 to A035) are not lower than the lower limit setting and not higher than the upper limit setting.
- Neither limit works if set to 0 Hz.
- Disabled when the 3rd control is selected.

■ When Using O-L and OI-L



- Once the lower limit is set, the Inverter outputs the frequency (A062) set for the lower limit, if 0 V (4 mA) is input to the frequency reference.

■ When Using O2-L



- When the lower limit is used for the O2 input, the rotation at 0 V is fixed to A062 for either forward or reverse rotation, as described below.

(a) When the RUN command is set to the terminal (A002: 01)

Terminal	Rotation when O2 = 0 V
FW (ON)	A062 for forward rotation
RV (ON)	A062 for reverse rotation

(a) When the RUN command is set to the Digital Operator (A002: 02)


F004	Rotation when O2 = 0 V
00	A062 for forward rotation
01	A062 for reverse rotation

Frequency Jump Function

- The frequency jump function helps avoid resonant points of loaded machines.

Parameter No.	Function name	Data	Default setting	Unit
A063 A065 A067	Jump frequency 1 Jump frequency 2 Jump frequency 3	0.00 to 400.00	0.00	Hz
A064 A066 A068	Jump frequency width 1 Jump frequency width 2 Jump frequency width 3	0.00 to 10.00	0.50	
Related functions		C001 to C008		


- You cannot set output frequencies within a jump frequency setting range, where the frequency jump function avoids steady operation.
- The output frequency fluctuates continuously according to the acceleration/deceleration time during both actions.
You can set up to three points for the jump frequency.



Acceleration Stop Function

- When the moment of inertia of a machine load is large, this function delays acceleration until the motor starting slip is reduced.
Use this function, if an overcurrent trip occurs during startup.
- Does not depend on acceleration pattern selection A097, and works with all acceleration patterns.

Parameter No.	Function name	Data	Default setting	Unit
A069	Acceleration stop frequency	0.00 to 400.00	0.00	Hz
A070	Acceleration stop time	0.0 to 60.0	0.0	s




PID Function

- This function enables process control of such elements as flow rate, air volume, and pressure.

Parameter No.	Function name	Data	Default setting	Unit
A071	PID selection	00: OFF (Disabled) 01: ON (+) (Enabled) 02: ON (+/-) (Reverse output enabled)	00	—
A072	PID P gain	0.2 to 5.0	1.0	—
A073	PID I gain	0.0 to 3600.0	1.0	s
A074	PID D gain	0.00 to 100.00	0.00	s
A075	PID scale	0.01 to 99.99	1.00	Time
A076	PID feedback selection	00: OI 01: O 02: Modbus (RS485 communication) 03: Pulse (Pulse train frequency) 10: Math (Operation function output)	00	—
A077	Reverse PID function	00: OFF (Deviation = Target value - Feedback value) 01: ON (Deviation = Feedback value - Target value)	00	—
A078	PID output limit function	0.0 to 100.0	0.0	%
A079	PID feedforward selection	00: Disabled 01: O 02: OI 03: O2	00	—
C044	PID deviation excessive level	0.0 to 100.0	3.0	%
C052	PID FB upper limit	0.0 to 100.0	100.0	%
C053	PID FB lower limit		0.0	%
Related functions		d004, A001, A005, A006, C001 to C008, C021 to C025		

- To use this function, set A071 to "01" or "02".
- You can disable the PID operation in progress using an external signal.
To use this function, allocate "23" (PID: PID disabled) to any of the multi-function inputs. While the PID terminal is turned on, the Inverter disables the PID function and outputs normally.
- You can limit the PID output under various conditions.


Basic Structure of PID Control (Example)



■PID Operation


P Operation

- Operation where the control volume is proportional to the target value




I Operation

- Operation where the control volume increases linearly according to time



D Operation

- Operation where the control volume is proportional to the variation ratio of the target value



- PI operation is the combination of the above P and I operations; PD is P and D operations; PID is P, I and D operations.

■Feedback Selection

- Select a terminal used for feedback signals in PID feedback selection A076.
- The target value depends on the terminal selected in frequency reference selection A001 other than that in A076.
When A001 is set to "01" (terminal), the setting of O/OI selection A005 is disabled.
- When analog input is selected for PID feedback and A001 is set to "01" (terminal), the PID target value is selected depending on the A006 set value, as shown in the following table.

PID feedback selection (A076)		PID target value			
		A006 = 00	A006 = 01	A006 = 02	A006 = 03
00 (OI-L)		O + O2 (Not reversible)		O + O2 (Reversible)	O
01 (O-L)		OI + O2 (Not reversible)		OI + O2 (Reversible)	OI
10 (operation result)	OI included in operands	O + O2 (Not reversible)		O + O2 (Reversible)	O
	O included in operands	OI + O2 (Not reversible)		OI + O2 (Reversible)	OI
	OI and O are the operands	O2 (Reversible)			

- To select RS485 for PID feedback, transfer data as described below.

<ASCII (C078 = 00)>

Transfer data using "command 01". To transfer feedback data, set the most significant byte of frequency data to "1".

(Example) To send 5 Hz:

Transmission data is "set value × 100" and expressed in 6 bytes → "000500"
Set the most significant byte to "1". → "100500"
ASCII conversion → "31 30 30 35 30 30"

Note: With ASCII data, the set value is frequency (Hz).

<ModBus-RTU (C078 = 01)>

Write data in holding register address 0006h. (100% = 10000)

Register No.	Function name	Function code	R/W	Monitor data and setting parameters	Data resolution
0006h	PID feedback	—	R/W	0 to 10000	0.01 [%]

Note: You can read and write data. However, you can read data only when ModBus-RTU is selected for the PID feedback. Data cannot be read under other settings.

- If "03" (pulse train input) is set for PID feedback A076, the Inverter obtains a percent conversion result (100% at max. frequency) as a feedback value, relative to the input pulse train frequency value (Hz).

■ Feedforward Selection

- Select a terminal used for feedforward signals in PID feedforward selection A079.
- The A079 setting is enabled even if the terminal selected in A079 is duplicated with the terminal selected for target value or feedback value input.
- If A079 is set to "disabled", feedforward control is disabled.


■ Reverse PID Function

Depending on the sensor characteristics, the polarity of deviation between the target and feedback values may not match the Inverter's command. In this case, you can invert the deviation polarity by setting A077 to "01".

(Example) To control a refrigerator compressor:


If the specified temperature range of a temperature sensor is -20°C to 100°C at 0 to 10 (V), the target value is 0°C, and the current temperature is 10°C, the Inverter reduces the frequency under normal PID control since the feedback value is higher than the target value.

→ Set A077 to "01" so that the Inverter increases the frequency.



■PID Output Limit Function

- This function limits PID output within a variable range relative to the target value.
- To use this function, set PID output limit function A078. The output frequency will be limited within a range of "target value \pm (A078)", with the maximum frequency defined as 100%.
- With A078 set to 0.0, this function is disabled.



■PID Reverse Output

- When a PID operation result is a negative value under normal PID control, the frequency reference to the Inverter is limited at 0 Hz. However, if PID selection A071 is set to "02" (reverse output enabled), reverse output can be provided for the Inverter when the PID operation result is a negative value.
- When A071 = 02, the above-mentioned PID variable range limit function and the PID output stop function are disabled.

■PID Gain Adjustment

- If a stable response cannot be obtained in PID function operation, adjust each gain as follows according to the situation.


• Feedback value variation is slow when the target value is changed.	→ Raise P gain A072.
• The feedback value changes fast but isn't stable.	→ Lower P gain A072.
• The target and feedback values wouldn't match smoothly.	→ Lower I gain A073.
• The feedback value fluctuates unstably.	→ Raise I gain A073.
• Response is slow even with P gain raised.	→ Raise D gain A074.
• With P gain raised, the feedback value vibrates and isn't stable.	→ Lower D gain A074.

■Excessive Deviation/Output

- You can set PID deviation excessive level C044 during PID control. With this function allocated, the multi-function output terminal is turned on when the PID deviation ε reaches the set level in C044.
- C044 can be set from 0 to 100. The setting corresponds to the range of 0 to the maximum target value.
- Allocate 04 (OD) to any of multi-function output terminals C021 to C025 or relay output terminal C026.

■Feedback Comparison Signal

- If a PID feedback value is out of the specified range, it can be output to a multi-function output terminal.
- Allocate 31 (FBV) to any of multi-function output terminals C021 to C025 or relay output terminal C026.



■PID Feedback Value Monitor

- You can monitor the PID feedback value.
- The monitor value is displayed as the product of the feedback value and PID scale A075.
"Monitor display" = "Feedback value (%)" × "A075 setting"

■PID Integral Reset

- Clears the integral value of PID operation.
- Allocate 24 (PIDC) to any of multi-function inputs C001 to C008.
- Clears the integral value every time the PIDC terminal is turned on.
Do not turn on the PIDC terminal during PID operation to avoid a possible overcurrent trip.
Turn on the PIDC terminal after turning off PID operation.

AVR Function

- This function outputs voltage to the motor correctly even if the incoming voltage to the Inverter fluctuates. With this function, output voltage to the motor is based on the voltage set in the motor voltage selection.

Parameter No.	Function name	Data	Default setting	Unit
A081	AVR selection	00: Always ON 01: Always OFF 02: OFF during deceleration	02	—
A082	AVR voltage selection	200-V class: 200/215/220/230/240 400-V class: 380/400/415/440/460/480	200/400	—
Related functions		d004, A001, A005		

- With A081 (AVR selection), set whether to enable or disable this function.
- Note that the Inverter cannot output voltage beyond that of the incoming voltage.
- To avoid a possible overcurrent trip during deceleration, set the AVR selection to "Always ON" (A081: 00).

Parameter No.	Data	Description	Note
A081	00	Always ON	Enabled during acceleration, constant speed , and deceleration.
	01	Always OFF	Disabled during acceleration, constant speed, and deceleration.
	02	OFF during deceleration	Disabled only during deceleration in order to reduce the energy regenerated to the Inverter by increasing the motor loss. This will avoid a possible trip due to regeneration during deceleration.

Automatic Energy-saving Operation Function

- This function automatically minimizes the Inverter output power during constant speed operation, and is suitable for load with reduced torque characteristics (e.g. fan, pump).

Parameter No.	Function name	Data	Default setting	Unit
A085	RUN mode selection	00: Normal operation 01: Energy-saving operation 02: Automatic operation	00	—
A086	Energy-saving response/ accuracy adjustment	0.0 to 100.0	50.0	%

- To operate with this function, set RUN mode selection A085 to "01".
You can adjust the response and accuracy with energy-saving response/accuracy adjustment A086.
- Controls the output power at a comparatively slow rate. Should rapid load fluctuation like impact load occur, the motor may stall, resulting in an overcurrent trip.

Parameter No.	Function name	Data	Response	Accuracy
A086	Energy-saving response/ accuracy adjustment	0.0 ↕ 100.0	Slow ↕ Fast	High ↕ Low

Automatic Optimum Acceleration/Deceleration

- The automatic acceleration/deceleration function eliminates the need for acceleration/deceleration settings during Inverter operation.

Parameter No.	Function name	Data	Default setting	Unit
A085	RUN mode selection	00: Normal operation 01: Energy-saving operation 02: Automatic operation	00	—
Related functions		A044, A244, A344, b021, b024, b022, b025		

- Conventionally, the user had to set an Inverter acceleration/deceleration time depending on the actual load conditions. However, this function can automatically set an acceleration/deceleration time, making full use of the Inverter's capacity.
The acceleration time is a time during which acceleration is performed within a current value set in the overload limit parameter (when the overload limit function is enabled), or within approx. 150% of the rated current (when the overload limit function is disabled). The deceleration time is a time during which deceleration is performed within approx. 150% of the rated current value, or within a DC voltage in the Inverter circuit of approx. 370 V (200V-class) or approx. 740 V (400 V-class). Thus, the Inverter enables real-time response to a change in applied load and inertia, and sets acceleration/deceleration time automatically.

- Note the following before use:

- Note 1: This function is not suitable for a machine that needs a fixed acceleration/deceleration time. Acceleration/deceleration time varies depending on applied load and inertia.
- Note 2: If the machine inertia exceeds approx. 20 times that of the motor shaft, the Inverter may trip. In this case, reduce the carrier frequency.
- Note 3: Acceleration/deceleration time varies depending on fluctuations in current value, even with the same motor.
- Note 4: The automatic optimum acceleration/deceleration setting is enabled only during V/f control. When sensorless vector control is selected, the Inverter performs normal operation.

Note 5: If the jogging operation is performed when the automatic operation is selected, the Inverter performs automatic acceleration, which is different from normal jogging operation.

Note 6: When the applied load is larger than the rating, deceleration time may be prolonged.

Note 7: If acceleration and deceleration are frequently repeated, the Inverter may trip.

Note 8: When the internal braking circuit is used, or when the regenerative braking unit is externally installed, the motor cannot stop within the specified deceleration time because of braking resistance. In this case, do not use the automatic optimum acceleration/deceleration function.

Note 9: When using a lower rank motor size than specified for the Inverter, enable the overload limit function (b021), and set the overload limit level (b022) to 1.5 times the rated current of the motor.

4

2-step Acceleration/Deceleration Function


•By setting this function, you can change the acceleration/deceleration time during acceleration/deceleration.

Parameter No.	Function name	Data	Default setting	Unit
A092	Acceleration time 2	0.01 to 3600.00	10.00	s
A292	*2nd acceleration time 2			s
A392	*3rd acceleration time 2			s
A093	Deceleration time 2	0.01 to 3600.00	10.00	s
A293	*2nd deceleration time 2			s
A393	*3rd deceleration time 2			s
A094	2-step acceleration/ deceleration selection	00: 2CH-Terminal (Switched via multi- function input 09 (example 1) 01: Preset FQ (Switched by setting) (example 2) 02: FWD-REV (Enabled only when switching forward/reverse (example 3)	00	—
A294	*2nd 2-step acceleration/ deceleration selection			
A095	2-step acceleration frequency	0.00 to 400.00	0.00	Hz
A295	*2nd 2-step acceleration frequency			
A096	2-step deceleration frequency	0.00 to 400.00	0.00	Hz
A296	*2nd 2-step deceleration frequency			
Related functions		F002, F202, F302, F003, F203, F303, C001 to C008		


* To switch to the 2nd/3rd control, allocate 08 (SET)/17 (SET3) to the desired multi-function input and then turn it on.

- Select an acceleration/deceleration time switching method from the following three:
 - Switching via a multi-function input
 - Automatic switching at a specified frequency
 - Automatic switching only when switching between forward/reverse
 If the 3rd control function is selected, however, switching by the 2-step acceleration/deceleration frequency is disabled.
- To switch via a multi-function input, allocate 09 (2CH) to any of C001 to C008.


(Example 1) When A094/A294 is set to 00



(Example 2) When A094/A294 is set to 01



(Example 3) When A094/A294 is set to 02



Acceleration/Deceleration Pattern

- Acceleration/deceleration pattern can be set for each system.











Parameter No.	Function name	Data	Default setting	Unit
A097	Acceleration pattern selection	00: Line 01: S-curve 02: U-curve 03: inv. U curve 04: EL-S curve	01	—
A098	Deceleration pattern selection			
A131	Acceleration curve parameter		02	—
A132	Deceleration curve parameter			

Parameter No.	Function name	Data	Default setting	Unit
A150	EL-S-curve ratio 1 during acceleration	0 to 50	10	%
A151	EL-S-curve ratio 2 during acceleration			
A152	EL-S-curve ratio 1 during deceleration	0 to 50	10	%
A153	EL-S-curve ratio 2 during deceleration			

- To select an acceleration or deceleration pattern, use A097 or A098, respectively.
- You can set acceleration and deceleration patterns individually.
- If any item other than "Line" (A097/A098 = 00) is selected for the acceleration/deceleration pattern, the acceleration/deceleration time is prolonged when this function is used with analog input (A001 = 01).


■ Pattern Selection

Select an acceleration/deceleration pattern with reference to the following table.

Parameter No.	Set values				
	00	01	02	03	04
	Line	S shape	U shape	Inverted U shape	EL-S shape
A097 (Acceleration)					
A098 (Deceleration)					
Description	Accelerates/ Decelerates linearly before reaching the set output frequency value.	Helps prevent the collapse of cargo on the elevating machine or conveyor.	Helps with tension control and roll break prevention (for a winding machine, etc.).		Provides shockless start/stop as with the S pattern, but the intermediate section is linear.

■Pattern Curve Parameter (Curve Factor)

- Determine a curve factor with reference to the figures below.




- The S pattern has an intermediate section where acceleration/deceleration time is shortened.
- If LAD cancel (LAC) is selected for a multi-function input and that input is turned on, the acceleration/deceleration pattern is ignored, and the output frequency instantaneously follows the reference frequency.

■EL-S Curve Ratio

If the EL-S pattern is used, you can set a curve ratio (A151 to A153) individually for acceleration and deceleration.

If all settings are "50 (%)", the Inverter operates in the same manner as with the S curve.



Operation Frequency Function

- Two systems of frequency reference operation results are available for the frequency reference and PID feedback value.

Parameter No.	Function name	Data	Default setting	Unit
A141	Operation frequency input A setting	00: Operator (Digital Operator (F001)) (A020/A220/A320) 01: VR (Digital Operator (FREQ adjuster)) (Enabled when 3G3AX-OP01 is used.)	02	—
A142	Operation frequency input B setting	02: O (Input O) 03: OI (Input OI) 04: Modbus (RS485 communication) 05: Option 1 06: Option 2 07: Pulse (Pulse train frequency)	03	—
A143	Operator selection	00: ADD (Addition (A + B)) 01: SUB (Subtraction (A - B)) 02: MUL (Multiplication (A × B))	00	—
Related functions		A001 = 10, A076 = 10		

Note 1: When this function is enabled, the Up/Down function cannot be used. In addition, frequency cannot be changed through key operations from output frequency monitor d001, frequency conversion monitor d007, or output frequency setting F001.

Note 2: The same setting is available in A141 and A142.

- To use this function as a frequency reference, set frequency reference selection A001 to "10".
- To use this function as a PID feedback, set PID feedback selection A076 to "10".

Frequency Addition Function

- The value set in frequency addition amount A145 can be added to or subtracted from the selected frequency reference value.
- To use this function, allocate 50 (ADD) to any of the multi-function inputs.
The A145 value is added or subtracted with the ADD terminal turned on.

Parameter No.	Function name	Data	Default setting	Unit
A145	Frequency addition amount	0.00 to 400.00	0.00	Hz
A146	Frequency addition direction	00: ADD (Add A145 value to output frequency) 01: SUB (Subtract A145 value from output frequency)	00	—
Related functions		C001 to C008, ADD input		

Note 1: If the sign of the frequency reference is changed ((-) → (+), or (+) → (-)) as a result of operation, the rotation direction will be inverted.

Note 2: When the PID function is used, the frequency addition function is enabled for a PID target value.
(Note that A145 is displayed in % (in increments of 0.01%).)

<Group B: Detailed Function Parameters>

Momentary Power Interruption/Trip Retry (Restart)

■ Restart During Momentary Power Interruption

- You can set whether the Inverter trips or retries (restarts) when a momentary power interruption or undervoltage occurs.
- If the retry function is selected in retry selection b001, the Inverter retries for the number of times set in b005 (for momentary power interruption) or b009 (for undervoltage), and trips on the next time.
(Under the limitless retry setting, the Inverter doesn't trip.)
- You can use b004 to select whether the Inverter trips or not when a momentary power interruption or undervoltage occurs during stop.
- When selecting the retry function, set retry condition b008 according to your system.
- If undervoltage is retained for 40 seconds even during retry operation, it results in E09 (undervoltage trip).

Parameter No.	Function name	Data	Default setting	Unit
b001	Retry selection ^{*4 *6}	00: TRIP (Alarm) 01: 0 Hz start 02: f-match (Frequency matching start) (example 1) ^{*3} 03: f-match Trip (Trip after frequency matching deceleration stop) ^{*1 *3} 04: Actv. f-match (Active Frequency Matching restart (example 1) ^{*3}	00	—
b002	Allowable momentary power interruption time	0.3 to 25.0: If the momentary power interruption is within the set time, the Inverter follows the setting in b001.	1.0	s
b003	Retry wait time	0.3 to 100.0 Time before restart	1.0	s
b004	Momentary power interruption/undervoltage trip during stop selection ^{*2 *4}	00: OFF (Disabled) 01: ON (Enabled) 02: Decel-OFF (Disabled during stop and deceleration stop)	00	—
b005	Momentary power interruption retry time selection	00: 16 times 01: No limit	00	—
b007	Frequency matching lower limit frequency setting	0.00 to 400.00 When the motor free-running frequency falls below this lower limit frequency, the Inverter restarts at 0 Hz (examples 3 and 4)	0.00	Hz
b008	Trip retry selection ^{*7}	00: TRIP (Alarm) 01: 0 Hz start 02: f-match (Frequency matching start) 03: f-match Trip (Trip after frequency matching deceleration stop) 04: Actv. f-match (Active Frequency Matching restart)	00	—
b009	Undervoltage retry time selection	00: 16 times 01: No limit	00	—
b010	Overvoltage/overcurrent retry time selection	1 to 3 Select the number of retry times in the event of overvoltage/overcurrent ^{*5}	3	Time
b011	Trip retry wait time	0.3 to 100.0 Time before restart	1.0	s

Parameter No.	Function name	Data	Default setting	Unit
b028	Active Frequency Matching restart level	0.20 × Rated current to 2.00 × Rated current (0.4 to 55 kW) 0.20 × Rated current to 1.80 × Rated current (75 to 132 kW) Current limit level at Active Frequency Matching restart	Rated current	A
b029	Active Frequency Matching restart parameter	0.10 to 30.00 Frequency reduction time at Active Frequency Matching restart	0.50	s
b030	Starting frequency at Active Frequency Matching restart	00: Off FQ (Frequency at interruption) 01: Max.FQ (Max. Frequency) 02: Set FQ (Set Frequency)	00	—
Related functions		C021 to C025, C026		

- *1. If an overvoltage/overcurrent trip occurs during deceleration, momentary power interruption error E16 appears, and the motor goes into free-run status. In this case, increase the deceleration time.
- *2. When direct current (P-N) is supplied to control power supply terminal Ro-To, the Inverter may detect undervoltage at power interruption and then trip. If there is any problem with your system, set "00" or "02".
- *3. The Inverter may start at 0 Hz if:
 - The output frequency is equal to or lower than 1/2 of the base frequency
 - The motor induction voltage quickly attenuates
- *4. Even if retry selection b001 is set to "Retry" (01 to 03) and selection of momentary power interruption/undervoltage trip during stop b004 is set to "Disabled" (00 or 02), the Inverter trips when the actual momentary power interruption time exceeds the allowable momentary power interruption time. (Example 2)
- *5. Even if the trip retry operation is selected, the Inverter trips if the cause of the trip is not remedied after the retry wait time (b003) elapses. In this case, increase the retry wait time.
- *6. Even if the retry operation is selected, the Inverter trips when undervoltage remains for 40 seconds or longer.
- *7. If frequency matching start or Active Frequency Matching restart is selected for retry operation, the Inverter abruptly restarts at power-on, by alarm reset or retry start.

- Below is the timing chart for frequency matching start (retry selection b001 = 02).

Note that the Inverter switches, regardless of settings, to the initial state when the power supply is turned on in the case of a complete power discharge.

t0: Momentary power interruption time


t1: Allowable momentary power interruption time (b002)

t2: Retry wait time (b003)

(Example 1)

Duration of momentary power interruption


< Allowable duration of momentary power interruption (b002)




(Example 2)

Duration of momentary power interruption


> Allowable duration of momentary power interruption (b002)



(Example 3) Motor frequency (rpm) > b007





(Example 4) Motor frequency (rpm) < b007



■Alarm Output for Momentary Power Interruption/Undervoltage During Stop

- Use b004 to select whether to enable an alarm output in case of momentary power interruption or undervoltage.
 - An alarm output continues while Inverter control power supply remains.
- Alarm output for momentary power interruption/undervoltage during stop
Standard (examples 5 to 7)
Operation where DC (P-N) is supplied to control power supply terminal Ro-To (examples 8 to10)





Note 1: You can allocate the momentary power interruption signal (IP: 08) and the undervoltage signal (UV: 09) to any of multi-function output terminals 11 to 15 selection (C021 to C025) or the relay output terminal (C026).

Note 2: If power interruption is retained for 1 second or longer, refer to the reset description ("Reset" (page 4-87)).

Restarting Procedure


•Frequency matching restart

This method restarts the Inverter by detecting frequency and rotation direction based on the motor's residual voltage.

•Active Frequency Matching restart

The Inverter starts output at the frequency set in starting frequency selection b030, and searches for a point where frequency and voltage are balanced to restart the Inverter, while holding current at the Active Frequency Matching restart level (b028).

If the Inverter trips with this method, reduce the b028 set value.



Input Power Supply Phase Loss Protection Function Selection

- This function outputs an alarm when the Inverter's input power supply has phase loss.

Parameter No.	Function name	Data	Default setting	Unit
b006	Input phase loss protection selection	00: OFF (Disabled) 01: ON (Enabled)	01	—

Phase loss may cause the Inverter to fail, as follows:

- The main capacitor ripple current increases, resulting in remarkable reduction in the capacitor's service life.
- When load is applied, the Inverter's internal converter or thyristor may be damaged.

Electronic Thermal Function

- Causes a trip to protect the motor from overheating. Set this according to the motor rated current.
- Provides the most appropriate protection characteristics, taking into account the decline of the motor cooling capability at a low speed.
- Outputs an alarm signal before an electronic thermal trip.
- Rated values will be affected by the HD, ND selection.

Parameter No.	Function name	Data	Default setting	Unit
b012	Electronic thermal level	0.20 × Rated current to 1.00 × Rated current	Rated current	A
b212	*2nd electronic thermal level			
b312	*3rd electronic thermal level			
b013	Electronic thermal characteristics selection	00: Reduced TRQ (Reduced torque characteristics) 01: Const TRQ (Constant torque characteristics) 02: Free set (Free setting)	00	—
b213	*2nd electronic thermal characteristics selection			
b313	*3rd electronic thermal characteristics selection			
b015	Free setting, electronic thermal frequency 1	0.00 to 400.00	0.00	Hz
b017	Free setting, electronic thermal frequency 2			
b019	Free setting, electronic thermal frequency 3			
b016	Free setting, electronic thermal current 1	0.0 to Rated current	0.0	A
b018	Free setting, electronic thermal current 2			
b020	Free setting, electronic thermal current 3			
C061	Thermal warning level	0 to 100 ^{*1}	80	%
Related functions		C021 to C025, C026		

* To switch to the 2nd/3rd control, allocate 08 (SET)/17 (SET3) to the desired multi-function input and then turn it on.

*1. Set a percentage relative to the electronic thermal multiplication value. When the value reaches 100%, an overload trip (E05) occurs.


Electronic Thermal Level (Motor Protection Level)

(Example) 3G3RX-A2150

Rated current: 64 A

Setting range: 12.8 A (20%) to 64.0 A (100%)

- The graph on the right shows the time limit characteristics with the electronic thermal level (b012) set to 64 A.





Electronic Thermal Characteristics

- The frequency characteristics are integrated with the above b012/b212/b312 set values.
- A general-purpose motor requires reduced load (current) because the lower the output frequency is, the lower the cooling capability of its self-cooling fan.
- The reduced torque characteristics are designed to fit the heat radiation of a general-purpose motor.

Reduced Torque Characteristics

Multiplied by the time limit characteristics set in b012/b212/b312 for each frequency.



(Example) 3G3RX-A2150 (Rated current: 64 A), b012 = 64 (A), Base frequency = 60 Hz, Output frequency = 20 Hz



Constant Torque Characteristics



Do not skip this setting when using a constant torque motor.

(Example) 3G3RX-A2150 (Rated current: 64 A), b012 = 64 (A), Output frequency = 2.5 Hz




Free Setting

To protect the motor according to load, you can freely set the electronic thermal characteristics. Below is the setting range.



(Example) Output frequency = b017



(x): (b018/Rated current) × 109%
(y): (b018/Rated current) × 150%
(z): (b018/Rated current) × 200%

Thermal Warning

- This function outputs an alarm signal before electronic thermal overhear protection is activated. The warning level can be set in C061.
- Allocate 13 (THM) to any of multi-function output terminals 11 to 15 (C021 to C025) or the relay output terminal (C026).

Overload Limit/Overload Warning


This function helps prevent an overcurrent trip due to rapid load fluctuation in acceleration or constant speed operation.

Parameter No.	Function name	Data	Default setting	Unit
b021	Overload limit selection	00: OFF (Disabled)	01	—
b024	Overload limit selection 2	01: ON-Acc/Cnst (Enabled in acceleration/ constant speed operation) 02: ON-Cnst (Enabled in constant speed operation) 03: ON-A/C(R) (Enabled in acceleration/ constant speed operation (accelerates during regeneration))	01	—
b022	Overload limit level	0.20 × Rated current to 2.00 × Rated current (0.4 to 55 kW)	1.50 × Rated current	A
b025	Overload limit level 2	0.20 × Rated current to 1.80 × Rated current (75 to 132 kW)	1.50 × Rated current	A
b023	Overload limit parameter	0.10 to 30.00	1.00	s
b026	Overload limit parameter 2		1.00	s
C040	Overload warning signal output mode	00: ACC/DEC/CST (Enabled during acceleration/deceleration/constant speed) 01: Const (Enabled only during constant speed)	01	—
C041	Overload warning level	0.0: Does not operate.	Rated current	A
C111	Overload warning level 2	0.1 × Rated current to 2.00 × Rated current (0.4 to 55 kW) 0.1 × Rated current to 1.80 × Rated current (75 to 132 kW) (Outputs OL and OL2 signals when reaching the overload warning level.)	Rated current	
Related functions		C001 to C008, C021 to C025, C026		

■ Overload Limit


- The Inverter monitors the motor current during acceleration or constant speed operation in order to lower output frequency automatically according to the overload limit parameter once the motor current reaches the overload limit.
- This function prevents an overcurrent trip caused by excessive moment of inertia during acceleration, or caused by rapid load fluctuations during constant speed operation.
- You can set two types of overload limit functions in b021/b022/b023 and b024/b025/b026.
- To switch between b021/b022/b023 and b024/b025/b026, allocate 39 (OLR) to a multi-function input and then turn it on/off.
- The overload limit level sets a current value for this function to work.
- The overload limit parameter sets a time of deceleration from the maximum frequency to 0 Hz.
- When this function operates, the acceleration time becomes longer than the set time.
- If "sensorless vector control", "0-Hz sensorless vector control", or "sensor vector control" is selected as the control method (V/f characteristics) (refer to "Control Method (V/f Characteristics)" (page 4-21)), and "03" is selected for b021/b024, the frequency increases when a current exceeding the overload limit level flows during regenerative operation.
- If overload limit parameter b023/b026 is set too short, an overvoltage trip may occur because of regenerative energy from the motor caused by automatic deceleration of this function even during acceleration.
- Make the following adjustments if this function operates before the frequency reaches the target value during acceleration.
 - Increase the acceleration time. (Refer to "Acceleration/Deceleration Time" (page 4-8).)
 - Increase the torque boost. (Refer to "Torque Boost" (page 4-19).)

Increase the overload limit level (b022/b025).



■ Overload Warning

- If the applied load is large, the Inverter can output an overload warning signal before an overload trip occurs. This helps prevent mechanical damage due to an overload in the carrier machine, or an operation line stop due to overload protection of the Inverter.
- Allocate "03" (OL) or "26" (OL2) to any of multi-function output terminals 11 to 15 (C021 to C025) or the relay output terminal (C026). (Two types of overload warning signals are available for output.)




Overcurrent Suppression Function

- This function suppresses overcurrent caused by a steep current rise in rapid acceleration.
- You can set whether to enable or disable this function with b027.

Parameter No.	Function name	Data	Default setting	Unit
b027	Overcurrent suppression function	00: OFF (Disabled) 01: ON (Enabled)	00	—

Note: If you use the Inverter with an elevating machine, disable this function. Otherwise, the machine may slide down.



Soft Lock Function

- You can set whether to enable or disable the writing of various code data. This helps prevent data rewriting due to erroneous operation.

Parameter No.	Function name	Data	Default setting	Unit
b031	Soft lock selection	00: Lock (SFT) (Data other than b031 cannot be changed when terminal SFT is ON) 01: Only FQ (SET) (Data other than b031 and specified frequency parameter cannot be changed when terminal SFT is ON) 02: Lock (Data other than b031 cannot be changed) 03: Only FQ (Data other than b031 and specified frequency parameter cannot be changed) 10: RUN chg mode (Data other than parameters changeable during operation cannot be changed)	01	—
Related functions		C001 to C008, SFT input		

- Select the soft lock setting and performing method from the above table.
- To use a multi-function input terminal, allocate 15 (SFT) to any of multi-function inputs 1 to 8 (C001 to C008).

RUN Time/Power ON Time Exceeded

- If the total RUN time of the Inverter exceeds the time set in ON time setting b034, a RUN/Power ON 'time exceeded' (RNT/ONT) signal is output.

Parameter No.	Function name	Data	Default setting	Unit
b034	RUN time/Power ON time setting	0 to 65535	0	—
Related functions		C021 to C025, C026, d016, d017		

■ RUN Time Exceeded (RNT)

- Allocate 11 (RNT) to any of multi-function output terminals 11 to 15 (C021 to C025) or the relay output terminal (C026).
- Set a time in RUN time/Power ON time setting b034.

■ Power ON Time Exceeded (ONT)

- Allocate 12 (ONT) to any of multi-function output terminals 11 to 15 (C021 to C025) or the relay output terminal (C026).
- Set a time in RUN time/Power ON time setting b034.

Rotation Direction Limit Selection


- Limits motor rotation directions.
- Enabled in either "control circuit terminal block" or "Digital Operator" control mode.

Parameter No.	Function name	Data	Default setting	Unit
b035	Rotation direction limit selection	00: FREE (Forward and Reverse are enabled) 01: FWD (Only Forward is enabled) 02: REV (Only Reverse is enabled)	00	—

Reduced Voltage Startup Selection

- Slowly increases voltage during motor startup.
- To increase torque during startup, reduce the set value of reduced voltage startup selection b036.
Note that if the value is too small, the motor starts in full-voltage starting mode, possibly resulting in an overcurrent trip.

Parameter No.	Function name	Data	Default setting	Unit
b036	Reduced voltage startup selection	00: Reduced voltage startup disabled 01 to 255: 01: Short (approx. 6 ms) ↕ ↕ 255: Long (approx. 1.53 s)	6	—
Related functions		b082		



Display Selection

- You can change the items to be displayed on the Digital Operator.

Parameter No.	Function name	Data	Default setting	Unit
b037	Display selection	00: All (Complete display) 01: Utilized (Individual display of functions) 02: User (User setting) 03: Only FQ (Data comparison display) 04: Basic (Basic display)	00	—
U001 to U012	User selection	__no: No allocation d001 to P196: Select the code you want to display. (Among all codes)	no	—

■ Individual Display of Functions

- If a specific function is not selected, its relevant parameter is not displayed.
- For details on the display requirements, refer to the following table.

No.	Display requirements	Parameters displayed when the requirements are met
1	A001 = 01	A005, A006, A011 to A016, A101, A102 A111 to A114, C081 to C083, C121 to C123
2	A001 = 10	A141 to A143
3	A002 = 01, 03, 04, 05	b087
4	A017 = 01	d025 to d027, P100 to P131 (Note that P100 to P131 cannot be used.)
5	A041 = 01	A046, A047
6	A044 = 00, 01	A041, A042, A043
7	A044 = 03, 04, 05	H002, H005, H050
8	A044 = 04	H060, H061
9	A044 = 03, 04, 05, and H002 = 00	H020 to H024
10	A044 = 03, 04, 05, and H002 = 01, 02	H030 to H034
11	Either of A044 or A244 = 03, 04, 05	d008 to d010, d012, b040 to b046, H001, H070 to H073
12	Either of A044 or A244 = 02	b100 to b113
13	A051 = 01, 02	A052, A056 to A058
14	A051 = 01, 02	A053 to A055, A059
15	A071 = 01, 02	d004, A005, A006, A011 to A016, A072 to A078 A101, A102, A111 to A114, C044, C052, C053, C081 to C083, C121 to C123
16	A076 = 10	A141 to A143
17	A094 = 01, 02	A095, A096
18	A097 = 01, 02, 03, 04	A131
19	A097 = 01, 02, 03, 04	A132
20	Any of b012, b212, and b312 = 02	b015 to b020
21	b021 = 01, 02, 03	b022, b023
22	b024 = 01, 02, 03	b025, b026
23	b050 = 01	b051 to b054
24	b095 = 01, 02	b090, b096
25	b098 = 01, 02	b099, C085
26	b120 = 01	b121 to b127
27	Any of C001 to C008 = 05, and A019 = 00	A028 to A035
28	Any of C001 to C008 = 06	A038, A039
29	Any of C001 to C008 = 07	A053 to A055, A059
30	Any of C001 to C008 = 08	F202, F203, A203, A204, A220, A244, A246, A247, A261, A262, A292, A293, A294, b212, b213, H203, H204, H206
31	Any of C001 to C008 = 08, and A041 = 01	A246, A247
32	Any of C001 to C008 = 08, and A244 = 00, 01	A241, A242, A243

No.	Display requirements	Parameters displayed when the requirements are met
33	Any of C001 to C008 = 08, and A244 = 03, 04	H202, H205, H250, H251, H252
34	Any of C001 to C008 = 08, and A244 = 04	H260, H261
35	Any of C001 to C008 = 08, A244 = 03, 04, and H202 = 00	H220 to H224
36	Any of C001 to C008 = 08, A244 = 03, 04, and H202 = 01, 02	H230 to H234
37	Any of C001 to C008 = 08, and A094 = 01, 02	A295, A296
38	Any of C001 to C008 = 11	b088
39	Any of C001 to C008 = 17	F302, F303, A303, A304, A320, A342, A343, A392, A393, b312, b313, H306
40	Any of C001 to C008 = 18	C102
41	Any of C001 to C008 = 27, 28, 29	C101
42	Any of C021 to C026 = 03	C040, C041
43	Any of C021 to C026 = 26	C040, C111
44	Any of C021 to C026 = 02, 06	C042, C043
45	Any of C021 to C026 = 07	C055 to C058
46	Any of C021 to C026 = 21	C063
47	Any of C021 to C026 = 24, 25	C045, C046
48	Any of C021 to C026 = 33	C142 to C144
49	Any of C021 to C026 = 34	C145 to C147
50	Any of C021 to C026 = 35	C148 to C150
51	Any of C021 to C026 = 36	C151 to C153
52	Any of C021 to C026 = 37	C154 to C156
53	Any of C021 to C026 = 38	C157 to C159
54	Any of C021 to C026 = 42	C064

■ User Setting

- Displays only the parameters optionally set in U001 to U012.
- In addition to U001 to U012, d001, F001 and b037 are displayed.

■ Data Comparison Display

- Displays only the parameters changed from the factory default.
Note that analog input adjustments C081, C082, C083, C121, C122, and C123, and thermistor adjustment C085 are not displayed.
- All monitors (d***) and F001 are displayed.

■Basic Display

- Displays basic parameters.
- Below are the parameters displayed when this function is enabled.

No.	Data	Function name	No.	Data	Function name
1	d001 to d104	Monitor display	16	A045	Output voltage gain
2	F001	Output frequency setting/monitor	17	A085	RUN mode selection
3	F002	Acceleration time 1	18	b001	Retry selection
4	F003	Deceleration time 1	19	b002	Allowable momentary power interruption time
5	F004	Operator rotation direction selection	20	b008	Trip retry selection
6	A001	Frequency reference selection	21	b011	Trip retry wait time
7	A002	RUN command selection	22	b037	Display selection
8	A003	Base frequency	23	b083	Carrier frequency
9	A004	Maximum frequency	24	b084	Initialization selection
10	A005	O/OI selection	25	b130	Overvoltage protection function selection during deceleration
11	A020	Multi-step speed reference 0	26	b131	Overvoltage protection level during deceleration
12	A021	Multi-step speed reference 1	27	C021	Multi-function output terminal 11 selection
13	A022	Multi-step speed reference 2	28	C022	Multi-function output terminal 12 selection
14	A023	Multi-step speed reference 3	29	C036	Relay output (AL2, AL1) contact
15	A044	V/f characteristics selection			
Related functions			U001 to U012		

Initial Screen Selection (Initial Screen at Power-ON)

You can select the Digital Operator screen to be displayed at power-on among the following items.
(By factory default, "01" (d001) is selected.)

Parameter No.	Function name	Data	Default setting	Unit
b038	Initial screen selection	000 to 202	001	—

Note: With "00" (screen on which the Enter key was last pressed) selected, if the last screen is other than d*** or F***, the entrance (*---) of each group is displayed.

(Example) When the power is turned off and then on after a change in the A020 setting, "A---" is displayed.

User Parameter Automatic Setting Function

- When user parameter automatic setting function b039 is set to "01" (enabled), the parameters subjected to a data change are automatically stored in sequence (from U001 to U012). This data can be used as changed data.
- The screen information is stored when the Enter key is pressed. The monitor screens (d***) are also stored in the same manner.
- U001 is the most recent parameter, and U012 is the oldest.
- The same parameter cannot be stored. If the number of parameters stored exceeds 12, the oldest data (U012) is erased.


Parameter No.	Function name	Data	Default setting	Unit
b039	User parameter automatic setting function selection	00: OFF (Disabled) 01: ON (Enabled)	00	—
Related functions		U001 to U012		

Torque Limit Function


- This function limits motor output torque when "03" (sensorless vector control), "04" (0-Hz sensorless vector control), or "05" (sensor vector control) is selected in control method A044/A244.

Parameter No.	Function name	Data	Default setting	Unit
A044/A244	V/f characteristics selection	03: SLV (Sensorless vector control) 04: 0SLV (0-Hz sensorless vector control) 05: V2 (Sensor vector control)	00	—
b040	Torque limit selection	00: 4-quadrant (Four-quadrant separate setting) 01: TRQ input (Terminal switch) 02: [O] input (Analog input) 03: Option 1 04: Option 2	00	—
b041	Torque limit 1 (Four-quadrant mode forward power running)	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) no (Torque limit disabled) Forward power running under four-quadrant separate setting	150	%
b042	Torque limit 2 (Four-quadrant mode reverse regeneration)	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) no (Torque limit disabled) Reverse regeneration under four-quadrant separate setting	150	%
b043	Torque limit 3 (Four-quadrant mode reverse power running)	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) no (Torque limit disabled) Reverse power running under four-quadrant separate setting	150	%
b044	Torque limit 4 (Four-quadrant mode forward regeneration)	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) no (Torque limit disabled) Forward regeneration under four-quadrant separate setting	150	%
C001 to C008	Multi-function inputs 1 to 8 selection	40: TL (Torque limit enabled) 41: TRQ1 (Torque limit switching 1) 42: TRQ2 (Torque limit switching 2)	—	—
C021 to C025	Multi-function output terminal 11 to 15 selection	10: TRQ (Torque limit)	—	—
Related functions		A044, A244, C001 to C008		

- You can select any of the following four torque limit functions from torque limit selection b040.
 - <Four-quadrant separate setting mode>
Sets torque limits 1 to 4 (b041 to b044) for four quadrants (forward power running, regeneration, reverse power running, and regeneration).
 - <Terminal switching mode>
Switches over torque limits 1 to 4 (b041 to b044), depending on combinations of torque limit switchings 1 and 2 (TRQ1 and TRQ2) allocated to multi-function inputs. Selected torque limit values are enabled for all operation modes.
 - <Analog input mode>
Sets a torque limit value depending on the voltage applied to terminal O2 on the control terminal block. 0 to 10 V correspond to torque limit values of 0% to 200%. Selected torque limit values are enabled for all operation modes.
 - <Option (option 1, option 2) mode>
Enabled when an optional 3G3AX-DI01 board is used. For details, refer to the optional board instruction manual.
- If the torque limit enable function (TL) is set for a multi-function input, the torque limit function set in b040 is enabled only when TL is turned on. When TL is off, the torque limit setting is disabled, and the maximum value is defined as the torque limit value. Unless the torque limit enable function (TL) is set for a multi-function input, the torque limit function set in torque limit selection b040 is always enabled.
- With this function, the torque limit value is set with the Inverter's maximum output current as 200%. This means output torque varies depending on the combination of motors. Note that the torque limit value is not the absolute one.
- When the torque limit signal is selected in the multi-function output selection, the torque limit signal is turned on when the above torque limit function is activated.
- The following figure shows torque limits 1 to 4 with "00" (four-quadrant separate setting) selected in torque limit selection b040.



- The following figure shows torque limits 1 to 4 with "01" (terminal switching) selected in torque limit selection b040. They can be switched with torque limit switchings 1 and 2 allocated to multi-function inputs.
(Example) When torque limit switching 1 (41) and torque limit switching 2 (42) are allocated to multi-function input terminals 7 and 8, respectively



- To use the torque limit function in a low speed range, also use the overload limit function.

Reverse Rotation Prevention Function

- This function is enabled when "03" (sensorless vector control), "04" (0-Hz sensorless vector control), or "05" (sensor vector control) is selected in control method A044/A244.
- Because of the Inverter's control characteristics, the Inverter may output a rotation signal in the direction opposite to that of the RUN command (e.g. in a low-speed range). If the motor's reverse rotation may cause a problem (e.g. damage to the machine driven by the motor), set reverse rotation prevention selection b046 to "enabled".

Parameter No.	Function name	Data	Default setting	Unit
A044/A244	V/f characteristics selection	03: SLV (Sensorless vector control) 04: 0SLV (0-Hz sensorless vector control) 05: V2 (Sensor vector control)	00	—
b046	Reverse rotation prevention selection	00: OFF (Disabled) 01: ON (Enabled)	00	—

Torque LADSTOP Function

- If "03" (sensorless vector control), "04" (0-Hz sensorless vector control), or "05" (sensor vector control) is selected in control method A004/A244, this function temporarily stops the frequency deceleration function (LAD) when the torque limit function is activated.

Parameter No.	Function name	Data	Default setting	Unit
A044/A244	V/f characteristics selection	03: SLV (Sensorless vector control) 04: 0SLV (0-Hz sensorless vector control) 05: V2 (Sensor vector control)	00	—
b040	Torque limit selection	00: 4-quadrant (Four-quadrant separate setting) 01: TRQ input (Terminal switch) 02: [O] input (Analog input) 03: Option 1 04: Option 2	00	—
b041	Torque limit 1 (Four-quadrant mode forward power running)	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) no (Torque limit disabled) Forward power running under four-quadrant separate setting	150	%
b042	Torque limit 2 (Four-quadrant mode reverse regeneration)	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) no (Torque limit disabled) Reverse regeneration under four-quadrant separate setting		
b043	Torque limit 3 (Four-quadrant mode reverse power running)	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) no (Torque limit disabled) Reverse power running under four-quadrant separate setting		
b044	Torque limit 4 (Four-quadrant mode forward regeneration)	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) no (Torque limit disabled) Forward regeneration under four-quadrant separate setting		
b045	Torque LADSTOP selection	00: OFF (Disabled) 01: ON (Enabled)	00	—
C001 to C008	Multi-function inputs 1 to 8 selection	40: TL (Torque limit enabled) 41: TRQ1 (Torque limit switching 1) 42: TRQ2 (Torque limit switching 2)	—	—

Dual Rating Selection

- Ratings of the inverter are switched to Heavy Duty (CT) and Normal Duty (VT) and it enables it. The ratings current value changes by switching Heavy Duty (CT) and Normal Duty (VT).
- The method of switching a Heavy Duty and a Normal Duty is done by Heavy Duty/Normal Duty selection (b049) in the operator.

Parameter No.	Function name	Data	Default setting	Unit
b049	Dual Rate Selection	00: CT (Constant torque) 01: VT (Variable torque)	00	—

- In the Normal Duty (VT), there is the item which is not displayed in the parameter of the operator.

Parameter No.	Function name	Function code	Function name
d008	Real frequency monitor	P024	Position bias amount
d009	Torque reference monitor	P025	Secondary resistance compensation enable/disable selection
d010	Torque bias monitor	P026	Overspeed error detection level
d029	Positioning command monitor	P027	Speed deviation error detection level
d030	Current position monitor	P028	Motor gear ratio numerator
b120	Brake control enable	P029	Motor gear ratio denominator
b121	Brake wait time for release	P032	Orientation stop position input type
b122	Brake wait time for acceleration	P033	Torque reference input selection
b123	Brake wait time fot stopping	P034	Torque reference setting
b124	Brake wait time for confirmation	P035	Polarity selection at torque reference via O2
b125	Brake release frequency	P036	Torque bias mode
b126	Brake release current	P037	Torque bias value
b127	Brake input frequency	P038	Torque bias polarity selection
H060	Limit at 0 Hz	P039	Speed limit value in torque control (forward)
H260	*2nd limit at 0 Hz	P040	Speed limit value in torque control (reverse)
H061	Boost amount at SLV startup, 0 Hz	P060	Multi-step position command 0
H261	*2nd boost amount at SLV startup, 0 Hz	P061	Multi-step position command 1
P011	Encoder pulses	P062	Multi-step position command 2
P012	V2 control mode selection	P063	Multi-step position command 3
P013	Pulse train mode selection	P064	Multi-step position command 4
P014	Orientation stop position	P065	Multi-step position command 5
P015	Orientation speed setting	P066	Multi-step position command 6
P016	Orientation direction setting	P067	Multi-step position command 7
P017	Position ready range setting	P068	Zero return mode
P018	Position ready delay time setting	P069	Zero return direction selection
P019	Electronic gear setting position selection	P070	Low-speed return frequency
P020	Electronic gear ratio numerator	P071	High-speed zero return frequency
P021	Electronic gear ratio denominator	P072	Position range specification (forward)
P022	Position control feedforward gain	P073	Position range specification (reverse)
P023	Position loop gain	P074	Teaching selection

- In the Normal Duty (VT), there is an item limited in the parameter of the operator by the setting range.

Function code	Function name
A044/A244	1st/2nd V/f characteristics selection
A054	DC injection braking power
A057	Startup DC injection braking power
A059	DC injection braking carrier frequency
A085	RUN mode selection
b022	Overload limit level
b025	Overload limit level 2
b028	Active Frequency Matching restart level
b041	Torque limit 1 (Four-quadrant mode forward power running)
b042	Torque limit 2 (Four-quadrant mode reverse regeneration)
b043	Torque limit 3 (Four-quadrant mode reverse power running)
b044	Torque limit 4 (Four-quadrant mode forward regeneration)
b083	Carrier frequency
C030	Digital current monitor reference value
C039	Light load detection level
C041	Overload warning level
C055	Overtorque level (Forward power running)
C056	Overtorque level (Reverse regeneration)
C057	Overtorque level (Reverse power running)
C058	Overtorque level (Forward regeneration)
C111	Overload warning level 2

- In the Normal Duty (VT), these terminals are not available.
- Intelligent input terminal that cannot set Normal Duty.

Code	Intelligent input terminal name
44: BOK	Brake confirmation
45: ORT	Orientation
47: PCLR	Position deviation error
48: STAT	Pulse train position command input permission
52: ATR	Torque command input permission
54: SON	Servo ON
55: FOC	Preliminary excitation
66: CP1	Position command selection 1
67: CP2	Position command selection 2
68: CP3	Position command selection 3
69: ORL	Zero return limit signal
70: ORG	Zero return startup signal
71: FOT	Forward driving stop
72: ROT	Reverse driving stop
73: SPD	Speed/Position switching

- Intelligent output terminal that cannot set Normal Duty.

Code	Intelligent output terminal name
19: BRK	Brake release
20: BER	Brake error
22: DSE	Excessive speed deviation
23: POK	Position ready

- When the parameter becomes outside a set range when changing to Heavy Duty -> Normal Duty, it changes to an initial value.
- An initial value of the following parameters is different in Heavy Duty ratings and Normal Duty ratings. When Heavy Duty/Normal Duty is changed with b049, items other than H003/H203 are changed to an initial value.

Name	Func. code	HD		ND	
		Range	Initial data	Range	Initial data
V/f characteristics selection	A044 A244 A344*	00: VC (Const. torque) 01: VP (Reduced torque) 02: Free V/F 03: SLV (sensorless vector) 04: 0SLV (0-Hz sensorless) 05: V2 (Sensor vector)	00: Const. torque	00: VC (Const. torque) 01: VP (Reduced torque) 02: Free V/F	00: Const. torque
DC injection braking power	A054	0 to 100 (%) 0.4 to 55kW 0 to 80 (%) 75 to 132kW	50% 0.4-55kW 40% 75-132kW	0 to 70 (%) 0.4 to 55kW 0 to 50 (%) 75 to 132kW	50% 0.4-55kW 40% 75-132kW
Startup DC injection braking power	A057	0 to 100 (%) 0.4 to 55kW 0 to 80 (%) 75 to 132kW	0 (%)	0 to 70 (%) 0.4 to 55kW 0 to 50 (%) 75 to 132kW	0 (%)
DC injection braking carrier frequency	A059	0.5 to 15.0 (kHz) 0.4-55kW 0.5 to 10.0 (kHz) 75-132kW	5.0 (kHz) 0.4-55kW	0.5 to 12.0 (kHz) 0.4-55kW 0.5 to 8.0 (kHz) 75-132kW	3.0 (kHz)
Electronic thermal level	b012	(0.20 to 1.00) x Rated current	Rated current (A)	(0.20 to 1.00) x Rated current	Rated current (A)
Overload limit level	b022/ b222	(0.20 to 2.00) x Rated current (A) 0.4-55kW (0.20 to 1.80) x Rated current (A) 75-132kW	1.50 x Rated current (A)	(0.20 to 1.50) x Rated current (A)	1.20 x Rated current (A)
Overload limit level 2	b025				
Carrier frequency	b083	0.5 to 15.0 (kHz) 0.4-55kW 0.5 to 10.0 (kHz) 75-132kW	5.0 (kHz) 0.4-55 kW	0.5 to 10.0 (kHz) 0.4-55kW 0.5 to 8.0 (kHz) 75-132kW	3.0 (kHz)
Motor capacity selection	H003/ H203	0.2 to 160 (kW)	Depends on type	0.4 to 160 (kW)	One size up than HD

* For the A344 parameter there are only two options available: 00 (VC) and 01 (VP).

Momentary Power Interruption Non-stop Function


- After the power is shut off during operation, this function decelerates the Inverter to a stop while keeping the voltage below the overvoltage level.
- You can select from three modes in momentary power interruption non-stop selection b050.

Parameter No.	Function name	Data	Default setting	Unit
b050	Selection of non-stop function at momentary power interruption	00: OFF (Disabled) 01: V-Cnst (STOP) (Enabled (deceleration stop)) 02: NS1 (Enabled (without recovery))* ⁵ 03: NS2 (Enabled (with recovery))* ⁵	00	—
b051	Starting voltage of non-stop function at momentary power interruption * ⁴	0.0 to 1000.0	220/440	V
b052	Stop deceleration level of non-stop function at momentary power interruption * ¹ * ⁴	0.0 to 1000.0	360/720	V
b053	Deceleration time of non-stop function at momentary power interruption * ³	0.01 to 3600.00	1.00	s
b054	Deceleration starting width of non-stop function at momentary power interruption * ³	0.00 to 10.00	0.00	Hz
b055	Proportional gain setting of non-stop function at momentary power interruption	0.00 to 2.55: Proportional gain for DC voltage constant control (b050 = 02, 03 only)	0.20	—
b056	Integral time setting of non-stop function at momentary power interruption	0.000 to 65.535: Integral time for DC voltage constant control (b050 = 02, 03 only)	0.100	s

■ Momentary Power Interruption Non-stop Deceleration Stop (b050 = 01)

- After the power is shut off during operation, this function decelerates the Inverter to a stop while keeping the voltage below the momentary power interruption non-stop deceleration level (b052).
- To use this function, remove the J51 connector cable connected between terminals Ro and To, and connect the cable from main terminal P to Ro, and from N to To. The cable size should be 0.75 mm² or larger.
- If the power is shut off during operation and the voltage falls below the momentary power interruption non-stop function starting voltage (b051), the frequency deceleration width decreases at the momentary power interruption non-stop deceleration starting width (b054), and then the Inverter decelerates for the momentary power interruption non-stop deceleration time (b053).
- If an overvoltage condition (momentary power interruption non-stop deceleration level b052 or higher) occurs because of regeneration during deceleration, the Inverter is kept in the LAD STOP status until the overvoltage condition is reset.

- *1. When the momentary power interruption non-stop deceleration level (b052) < the momentary power interruption non-stop function starting voltage (b051), the Inverter performs this function by increasing the momentary power interruption non-stop deceleration level (b052) to the momentary power interruption non-stop function starting voltage (b051). (The set value will not be changed.)
- If b052 is lower than the incoming voltage or equivalent (DC voltage or equivalent after rectification [$\text{incoming voltage} \times \sqrt{2}$]), the Inverter is brought into the LAD STOP status at power recovery during execution of this function, disabling deceleration. (The Inverter will accept neither a STOP command nor frequency reference change until operation is complete.) Make sure that the b052 setting is higher than the normal incoming voltage or equivalent.
- *2. This function is not reset before the operation is complete and stopped. To run the Inverter after power recovery during this function, input the RUN command following the STOP command (RUN command OFF) after a stop condition.
- *3. If the momentary power interruption non-stop deceleration starting width (b054) is too large, an overcurrent trip occurs because of rapid deceleration. If b054 is too small, or if the momentary power interruption non-stop deceleration time (b053) is too long, an undervoltage trip occurs because of insufficient regeneration power.




■ Momentary Power Interruption Non-stop DC Voltage Constant Control (b050 = 02: without recovery, b050 = 03: with recovery)

- If a momentary power interruption or main circuit DC voltage drop occurs during operation, the Inverter decelerates while keeping the main circuit DC voltage at the value set in momentary power interruption non-stop target voltage (OV-LADSTOP level) b052.
- This function is started when the following conditions are all satisfied:
 - b050 = "02" or "03"
 - The Inverter is running. (This function is disabled during trip/undervoltage/stop.)
 - The control power supply is momentarily interrupted, or the main circuit DC voltage falls below the momentary power interruption non-stop function starting voltage (b051)
- This function is enabled when the above starting conditions are satisfied, even if the J51 connector cable is disconnected from terminals Ro and To and is connected from main terminal P to Ro and from N and To, or even if the control power supply is separated from the main circuit power supply.
- If the time of momentary power interruption is short, the Inverter can continue to run without shutting off the output. However, if undervoltage occurs because of momentary power interruption, the Inverter immediately shuts off the output, and stops operating this function. The subsequent power recovery depends on the setting of retry selection b001.
- With b050 = 03, the Inverter can be restored to normal operation, if a momentary power interruption occurs and incoming voltage recovers before the output is shut off. Note that the Inverter may decelerate to a stop, depending on the b051 setting. Below are the details.

b050	b051	Operation
02 (without recovery)	b052 > Main circuit DC voltage at power recovery	Deceleration stop (DC voltage constant control) (example 1)
	b052 < Main circuit DC voltage at power recovery	Deceleration stop (normal operation) (example 2)
03 (with recovery)	b052 > Main circuit DC voltage at power recovery	Deceleration stop (DC voltage constant control) (example 1)
	b052 < Main circuit DC voltage at power recovery	Operation (normal operation) (example 2)

- If operation of this function results in deceleration stop, the Inverter is forced to stop, even if the FW command is ON. To restart the Inverter, make sure that the incoming voltage has recovered, and input the FW command again.

- *4. Make sure that the b051/b052 set values are larger than the undervoltage level (200-V class: 210 V, 400-V class: 410 V). If undervoltage occurs, this function is disabled. Make sure that b051 is smaller than b052. If the proportional gain setting (b055) is excessively increased when the difference between b051 and b052 is large, the Inverter may accelerate immediately after this function starts, resulting in overcurrent.
- *5. When b050 = 02, 03, PI control works to keep the internal DC voltage constant.
 - Though quicker response is expected with a larger proportional gain (b055), control tends to be divergent and may easily lead to a trip.
 - Response also becomes quicker with a shorter integral time (b056), but if too short, the same situation may occur.
 - If the proportional gain (b055) is too small, the voltage drops immediately after this function starts, resulting in an undervoltage trip.



Note: The main circuit DC voltage level, while the function is running, may fall below the b052 set value depending on the proportional gain and integral time settings.


Window Comparator (Disconnection Detection ODC/OIDc/O2Dc)

- The Inverter activates the window comparator output when the O/OI/O2 analog input value is within the upper and lower limit levels of the window comparator. This function allows you to monitor analog input based on the desired level (e.g. to detect a disconnection).

Parameter No.	Function name	Data	Default setting	Unit
C021 to C025	Multi-function output terminals 11 to 15 selection	27: ODC (analog O disconnection detection) 28: OIDc (analog OI disconnection detection) 29: O2Dc (analog O2 disconnection detection)	—	—
C026	Relay output (AL2, AL1) function selection	54: WCO (window comparator O) 55: WCOI (window comparator OI) 56: WCO2 (window comparator O2)	05	
b060 (O)	Window comparator O/OI/O2 upper limit level	Set an upper limit level. Setting range: 0 to 100 Lower limit: Lower limit level + Hysteresis width × 2	100	%
b063 (OI)				
b066 (O2)		Set an upper limit level. Setting range: -100 to 100 Lower limit: Lower limit level + Hysteresis width × 2		
b061 (O)	Window comparator O/OI/O2 lower limit level	Set a lower limit level. Setting range: 0 to 100 Upper limit: Upper limit level - Hysteresis width × 2	0	%
b064 (OI)				
b067 (O2)		Set a lower limit level. Setting range: -100 to 100 Upper limit: Upper limit level - Hysteresis width × 2		

Parameter No.	Function name	Data	Default setting	Unit
b062 (O)	Window comparator O/OI/O2 hysteresis width	Set a hysteresis width for the upper and lower limit levels. Setting range: 0 to 10 Upper limit: (Upper limit level - Lower limit level) × 2	0	%
b065 (OI)				
b068 (O2)				
b070 (O)	Analog operation level at O/OI/O2 disconnection	0 to 100/no (ignored): Set an analog input application value used for WCO/WCOI/ WCO2 (ODc/OIDc/O2Dc) output.	no	—
b071 (OI)		-100 to 100/no (ignored): Set an analog input application value used for WCO/WCOI/ WCO2 (ODc/OIDc/O2Dc) output.		
b072 (O2)				

- You can set hysteresis widths for the window comparator upper and lower limit levels.
- You can set limit levels and a hysteresis width individually for O, OI, and O2 inputs.
- For the WCO/WCOI/WCO2 output, you can fix the analog input application value to the desired value. Set values in O/OI/O2 disconnection operation levels b070/b071/b072. If "no" is set, the analog input value is directly reflected.
- ODc/OIDc/O2Dc outputs are the same as WCO/WCOI/WCO2, respectively.




Starting Frequency

- Set the frequency for starting Inverter output when the RUN signal is turned on.

Parameter No.	Function name	Data	Default setting	Unit
b082	Starting frequency	0.10 to 9.99	0.50	Hz

- Use mainly to adjust the starting torque.
- With starting frequency b082 set high, the starting current increases, possibly causing the current to exceed the overload limit and overcurrent protection to work to trip the Inverter.
- If "04" (OSLV: 0-Hz sensorless vector control) or "05" (V2: sensor vector control) is selected in control method selection A044, this function is disabled.



Carrier Frequency

- You can change the PWM waveform carrier frequency output from the Inverter.

Parameter No.	Function name	Data (HD)	Data (ND)	Default setting	Unit
b083	Carrier frequency	0.5 to 15.0 (0.4 to 55 kW)	0.5 to 12.0 (0.4 to 55 kW)	5.0	kHz
		0.5 to 10.0 (75 to 132 kW)	0.5 to 8.0 (75 to 132 kW)	3.0	


- With the carrier frequency set high, you can reduce metallic noise from the motor. However, this increases noise or leakage current from the Inverter.
- Helps avoid mechanical or motor resonance.
- The maximum carrier frequency varies depending on the capacity.
To raise the carrier frequency (fc), derate the output current as shown in the following table.
- Set a derating output current value as electronic thermal level.
(If the existing electronic thermal value is lower than the derating value, the above setting is not required.)
- To raise the carrier frequency, reduce the output current (or derate the rated current) as shown in the graph below.

Voltage	200-V class			400-V class		
Capacity	Max. fc (kHz)	Derating at fc = 12 kHz (ND)	Derating at fc = 15 kHz (HD)	Max. fc (kHz)	Derating at fc = 12 kHz (8kHz for 75 to 132 kW) (ND)	Derating at fc = 15 kHz (10 kHz for 75 to 132 kW) (HD)
0.4 kW	15	100%	100%	15	100%	100%
0.75 kW	15	100%	100%	15	100%	100%
1.5 kW	15	100%	100%	15	100%	100%
2.2 kW	15	100%	100%	15	100%	100%
3.7 kW	15	90%	100%	15	90%	100%
5.5 kW	15	100%	100%	15	100%	100%


Voltage	200-V class			400-V class		
Capacity	Max. fc (kHz)	Derating at fc = 12 kHz (ND)	Derating at fc = 15 kHz (HD)	Max. fc (kHz)	Derating at fc = 12 kHz (8kHz for 75 to 132 kW) (ND)	Derating at fc = 15 kHz (10 kHz for 75 to 132 kW) (HD)
7.5 kW	15	100%	100%	15	100%	100%
11 kW	12	90%	90%	15	100%	100%
15 kW	12	90%	95%	14	100%	95%
18.5 kW	10	90%	90%	10	95%	90%
22 kW	7	90%	70%	6	90%	75%
30 kW	5	80%	80%	10	80%	75%
37 kW	10	75%	75%	8	90%	80%
45 kW	5	90%	70%	9	80%	75%
55 kW	5	90%	70%	6	75%	60%
75 kW	—	—	—	6	90%	85%
90 kW	—	—	—	4	80%	75%
110 kW	—	—	—	6	80%	70%
132 kW	—	—	—	3	70%	60%

Normal duty

200-V class




400-V class




Heavy duty

200-V class



400-V class



- If the above maximum rated carrier frequency and the derating value at 15 kHz are exceeded, the Inverter may be damaged and/or the service life may be shortened.

Parameter Initialization

- You can initialize the rewritten set values and reset to the factory default.
- You can clear trip data.
- You cannot clear the P100 to P131 set values, RUN time, or power ON time.

Parameter No.	Function name	Data	Default setting	Unit
b084	Initialization selection	00: no (Clears the trip monitor) 01: Trip data (Initializes data) 02: Parameters (Clears the trip monitor and initializes data) 03: Trip+Param (Clears the trip monitor and parameters) 04: Trp+Prm+EzSQ (Clears the trip monitor, parameters and Drive program)	00	—
b085	Initialization parameter selection	01 *Do not change.	01	—
b180	Initialize trigger	00: No action 01: Initialize	00	—

STOP Key Selection

- When "control circuit terminal block" is selected for the RUN command, you can set whether the STOP/RESET key on the Digital Operator is used to activate the STOP command and trip reset operation.
- This setting is enabled when any item other than "02" (Digital Operator) is selected in RUN command selection A002. (Refer to "RUN Command Selection" (page 4-11).)
If "02" (Digital Operator) is selected in A002, the STOP command and trip reset operation are enabled regardless of this setting.

Parameter No.	Function name	Data	Default setting	Unit
b087	STOP key selection	00: ON (Enabled) 01: OFF (Disabled) 02: Only RESET (Disabled only during stop)	00	—

Data	STOP command via the STOP/RESET key on the Digital Operator	Trip reset operation via the STOP/RESET key on the Digital Operator
00	Enabled	Enabled
01	Disabled	Disabled
02	Disabled	Enabled

Stop Selection

- You can set whether the Inverter decelerates to a stop for the set deceleration time or goes into free-run status, when the STOP command is input from the Digital Operator or the control circuit terminal block.

- If the RUN command is input again during free running, the Inverter restarts according to free-run stop selection b088. (Refer to "Free-run Stop Selection" (page 4-71).)

Parameter No.	Function name	Data	Default setting	Unit
b091	Stop selection	00: Decel-Stop (Deceleration → Stop) 01: Free-RUN (Free-run stop)	00	—
b088	Free-run stop selection	00: 0-Hz start 01: f-match (Frequency matching start) 02: Actv. f-match (Active Frequency Matching restart)	00	—
b003	Retry wait time	0.3 to 100.0	1.0	s
b007	Frequency matching lower limit frequency setting	0.00 to 400.00	0.00	Hz
Related functions		F003, F203, F303		

Free-run Stop Selection


- Activating the free-run stop (FRS) function shuts off the Inverter output, letting the motor go into free-run status.

Parameter No.	Function name	Data	Default setting	Unit
b088	Free-run stop selection	00: 0-Hz start 01: f-match (Frequency matching start) 02: Actv. f-match (Active Frequency Matching restart)	00	—
b003	Retry wait time	0.3 to 100.0: Time before restart	1.0	s
b007	Frequency matching lower limit frequency setting	0.00 to 400.00: Set a frequency matching level.	0.00	Hz
b028	Active Frequency Matching restart level	0.20 × Rated current to 2.00 × Rated current (0.4 to 55 kW) 0.20 × Rated current to 1.80 × Rated current (75 to 132 kW)	Rated current	A
b029	Active Frequency Matching restart parameter	0.10 to 30.00	0.50	s
b030	Starting frequency at Active Frequency Matching restart	00: Off FQ (Frequency at interruption) 01: Max.FQ (Max. frequency) 02: Set FQ (Set frequency)	00	—


- Helps stop the motor using a mechanical brake such as an electromagnetic one.
Note that an overcurrent trip may occur if the mechanical brake forces the motor to stop during Inverter output.
- Allocate 11 (FRS) to any of multi-function inputs 1 to 8 (C001 to C008).
- Performs a free-run stop (FRS) while the FRS terminal is turned on.
When the FRS terminal is turned off, the motor restarts after the retry wait time (b003) elapses. However, if RUN command selection A002 is set to "02" (Digital Operator), the Inverter does not restart.
To restart the Inverter, input the RUN command.
- You can select as the Inverter output mode for restart a 0-Hz start, frequency matching start or Active Frequency Matching restart at free-run stop selection b088. (Examples 1, 2, 3)
- If you set frequency matching lower limit frequency setting b007, the Inverter restarts at 0 Hz, when the Inverter detects a frequency equal to or lower than this setting during frequency matching start.

- The setting of this function is applied to the FRS terminal, and also to the status when the Inverter is reset from free running.

(Example 1) 0-Hz start




(Example 2): Frequency matching start



- The Inverter starts running at 0 Hz regardless of the motor rpm. The retry wait time is ignored at 0-Hz start.
- If the Inverter starts running at 0 Hz with the motor rpm high, an overcurrent trip may occur.
- When the FRS terminal is turned off and the retry wait time elapses, the motor frequency is matched and a Active Frequency Matching starts without stopping the motor. If an overcurrent trip occurs at frequency matching start, extend the retry wait time.
- Even if "frequency matching start" is selected, the Inverter may start at 0 Hz when:
 - The output frequency is equal to or lower than 1/2 of the base frequency
 - The motor induction voltage quickly attenuates
 - The Inverter detects a frequency equal to or lower than the frequency matching lower limit frequency setting (b007)

(Example 3) Active Frequency Matching restart



- After the retry wait time (b003) elapses, the Inverter starts output from the b030 set value. The Inverter then decelerates according to b029, while keeping the output current at the b028 set value.
- When the frequency matches the voltage, the Inverter accelerates again, and then output frequency is restored to the original level.
- If an overcurrent trip occurs under this method, reduce the b028 set value.


Automatic Carrier Frequency Reduction Function

- This function automatically reduces carrier frequency according to an increase in output current.
- This function is enabled when automatic carrier frequency reduction selection b089 is set to "01".

Parameter No.	Function name	Data	Default setting	Unit
b089	Automatic carrier reduction	00: OFF (Disabled) 01: ON (Enabled)	00	—

- When output current exceeds 60%, 72%, 84% and 96% of the rated current, the carrier frequency is reduced to 12, 9, 6, and 3 kHz, respectively.
- When the output current falls below -5% of each level, this function will be reset.


Carrier frequency reduction starting level (Recovery level)	Reduced carrier frequency (kHz)
Less than 60% of the rated current	15.0
60% (55%) of the rated current	12.0
72% (67%) of the rated current	9.0
84% (79%) of the rated current	6.0
96% (91%) of the rated current	3.0



- The carrier frequency reduction rate is 2 kHz per second.
 - The upper limit of carrier frequency variable with this function conforms to the set value of carrier frequency b083, and the lower limit is 3 kHz.
- Note: When b083 is 3 kHz or lower, this function is disabled regardless of the b089 setting.

Regenerative Braking Function

- This function applies to the Inverter models with a built-in regenerative braking circuit (3G3RX-A2220/A4220 or lower models).
- With the built-in regenerative braking circuit, this function allows an external braking resistor to consume the motor's regeneration energy as heat.
This function is useful for a system in which the motor works as a generator when it is rapidly decelerated.
- To use this function, configure the following settings.

Parameter No.	Function name	Data	Default setting	Unit
b090	Usage rate of regenerative braking function	<p>0.0: Does not operate. 0.0 to 100.0: A regenerative braking usage rate for 100 seconds can be set, in increments of 0.1%. If the set usage rate is exceeded, a braking resistor overload trip (E06) occurs.</p>  $\text{Usage rate (\%)} = \frac{(t1 + t2 + t3)}{100 \text{ s}} \times 100$	0.0	%
b095	Regenerative braking function operation selection	<p>00: OFF (Disabled) 01: RUN-ON (Enabled (Disabled during stop)) 02: Alws-ON (Enabled (Enabled during stop))</p>	00	—
b096	Regenerative braking function ON level	<p>200-V class: 330 to 380 * 400-V class: 660 to 760 * (Inverter DC voltage)</p>	<p>200-V class: 360 V 400-V class: 720 V</p>	V

* The regenerative braking function ON level conforms to the voltage setting for the Inverter's internal converter (DC unit).

Cooling Fan Control

- You can set whether to operate the Inverter's cooling fan constantly or only during Inverter operation.

Parameter No.	Function name	Data	Default setting	Unit
b092	Cooling fan control	<p>00: Alws-ON (Always ON) 01: ON in RUN (ON during RUN) Regardless of the settings, the cooling fan operates for 5 minutes after power-on, and for 5 minutes after the Inverter stops.</p>	01	—

Note: If a momentary power interruption occurs or the power is shut off while the cooling fan is in operation, the cooling fan stops temporarily and restarts automatically after power recovery.

External Thermistor (TH)

- This function enables thermal protection of the external equipment (e.g. motor) if its internal thermistor is connected to the Inverter.

Parameter No.	Function name	Data	Default setting	Unit
b098	Thermistor selection	00: Disabled 01: PTC enabled 02: NTC enabled	00	—
b099	Thermistor error level	0 to 9999: Set a temperature resistance value to trip the Inverter, according to the specifications of your thermistor.	3000	Ω
C085	Thermistor adjustment	0.0 to 1000.0: Used for gain adjustment.	Factory default	—


Note: If thermistor selection b098 is set to "01" without connecting an external thermistor, the Inverter trips.

- Connect an external thermistor between control terminals TH and CM1.
- Set the following functions according to the specifications of your thermistor.
- When this function is used, keep the cable length between the motor and Inverter within 20 m. Since the current flowing through the thermistor is weak, you must take measures to prevent noise due to motor current. (For example, place the thermistor cable away from the motor cable.)

Brake Control Function

- This function allows the Inverter to control the external brake of equipment, including an elevating system. When brake control selection b120 is set to "01" (enabled), the Inverter operates as follows:

- (1) At RUN command input, the Inverter starts output, and accelerates to the release frequency.
- (2) After the release frequency is reached, the Inverter outputs the brake release signal (BRK) after the brake release establishment wait time (b121) elapses. However, if the Inverter's output current is less than the current value set in release current b126, the Inverter does not output the brake release signal. In this case, the Inverter trips, and outputs the brake error signal (BER).
- (3) If the brake confirmation signal (BOK) is allocated to a multi-function input (when "44" is set in any of C001 to C008), the Inverter waits for the brake confirmation signal for the period set in brake confirmation wait time b124 without accelerating, after the brake release signal is output. If the brake confirmation signal does not turn on within the period set in b124, the Inverter outputs the brake error signal (BER), resulting in trip. If the brake confirmation signal is not allocated to a multi-function input, brake confirmation wait time b124 is disabled, and the Inverter performs processing (4) after the brake release signal is output.
- (4) After the brake confirmation signal is input (or after the brake release signal is output if BOK is not selected), the Inverter restarts acceleration up to a set frequency after the period set in acceleration wait time b122 elapses.
- (5) After the RUN command is turned off, the Inverter decelerates to the brake release frequency (b125), and turns off the brake release signal (BRK).
- (6) If the brake confirmation signal (BOK) is allocated to a multi-function input (when "44" is set in any of C001 to C008), the Inverter waits for the brake confirmation signal to be turned off for the period set in brake confirmation wait time b124 without decelerating, after the brake release signal is turned off. If the brake confirmation signal is not turned off within the period set in b124, the Inverter outputs the brake error signal (BER), resulting in trip. If the brake confirmation signal is not allocated to a multi-function input, brake confirmation wait time b124 is disabled, and the Inverter performs processing (7) after the brake release signal is turned off.
- (7) After the brake confirmation signal is turned off (or after the brake release signal is turned off if BOK is not selected), the Inverter restarts deceleration down to 0 Hz after the period set in stop wait time b123 elapses.



Note: The above operation chart applies to a case where the brake confirmation signal (44: BOK) is selected for any of multi-function inputs 1 to 8 (C001 to C008). If BOK is not selected, the acceleration wait time (b122) starts at the brake release signal ON timing. The stop wait time (b123) starts at the brake release signal OFF timing.

- To use the brake control function, allocate the following functions to multi-function I/O terminals, as required.
 - To input a brake release signal from an external brake to the Inverter, allocate the brake confirmation signal (44: BOK) to any of multi-function inputs 1 to 8 (C001 to C008).

- Allocate the brake release signal (19: BRK) to any of multi-function output terminals 11 to 15 (C021 to C025). Also, to use a brake error output signal, allocate the brake error signal (20: BER).

- To use the brake control function, you are recommended to select "sensorless vector control" (A044 = 03), "0-Hz sensorless vector control" (A044 = 04), or "sensor vector control" (A044 = 05) so that the Inverter outputs high torque during startup. (Refer to page 4-21.)

Parameters Required for Brake Control Function

Parameter No.	Function name	Data	Default setting	Unit
b120	Brake control selection	00: OFF (Disabled) 01: ON (Enabled)	00	—
b121	Brake wait time for release	0.00 to 5.00: Set a time required for the output current to reach the rate of the release current after reaching the release frequency.	0.00	s
b122	Brake wait time for acceleration	0.00 to 5.00: Set a mechanical delay time from when the release signal is output until the brake is released.	0.00	s
b123	Brake wait time for stopping	0.00 to 5.00: Set a mechanical delay time from when the release signal is turned off until the brake is closed.	0.00	s
b124	Brake wait time for confirmation	0.00 to 5.00: Set a wait time longer than the time from when the release signal is released until the brake outputs the release completion signal to the Inverter.	0.00	s
b125	Brake release frequency	0.00 to 400.00: Set a frequency to output the brake release signal. *1	0.00	Hz
b126	Brake release current	0.0 to 2.00 x Rated current (0.4 to 55 kW) 0.0 to 1.80 x Rated current (75 to 132 kW)	Rated current	—
b127	Brake input frequency	0.00 to 400.00: Set a frequency to close the brake during stop. *1	0.00	Hz
Related functions		C001 to C008, C021 to C025		

*1. Set a brake release frequency higher than the starting frequency (b082).

*2. If the set current is too low, sufficient torque may not be provided when the brake is released.

In any of the following cases, the Inverter trips and outputs the brake error signal (BER). (Brake error: E36)


- The output current is lower than the release current after the brake release establishment wait time (b121) elapses.
- When the brake confirmation (BOK) signal is used, the brake confirmation signal does not turn on within the brake confirmation wait time (b124) during acceleration, or does not turn off within the brake confirmation wait time (b124) during deceleration; or the brake confirmation signal turns off, although the brake release signal is output.

Overvoltage Protection Function During Deceleration


- This function helps avoid an overvoltage trip due to regenerative energy from the motor during deceleration.
- You can set whether to enable or disable this function with overvoltage protection function selection during deceleration b130.
- If overvoltage protection function selection b130 is set to "01" (enabled: DC voltage constant control), the Inverter automatically decelerates while keeping the main circuit DC voltage rise due to deceleration start at the overvoltage protection function level setting (b131).
- If overvoltage protection function selection b130 is set to "02" (enabled: with acceleration), the main circuit DC voltage increases because of deceleration start. When the main circuit DC voltage exceeds the overvoltage protection function level setting (b131), the Inverter starts acceleration according to the setting of overvoltage protection parameter b132. After that, when the main circuit DC voltage falls below the b131 level, the Inverter starts deceleration again.

Parameter No.	Function name	Data	Default setting	Unit
b130	Overvoltage protection function selection during deceleration	00: OFF (Disabled) 01: V-const (DC voltage kept constant) (example 1) *2 02: Accel (Acceleration enabled) (example 2)	01	—
b131	Overvoltage protection level during deceleration *1	200-V class: 330 to 390 400-V class: 660 to 780	380/760	V
b132	Overvoltage protection parameter	0.10 to 30.00: Set the acceleration rate applied when this function is enabled.	1.00	s
b133	Overvoltage protection proportional gain setting	0.00 to 2.55: Proportional gain for DC voltage constant control (b130 = 01 only)	0.50	—
b134	Overvoltage protection integral time setting	0.000 to 65.535: Integral time for DC voltage constant control (b130 = 01 only)	0.060	s

(Example 1) When b130 = 01



(Example 2) When b130 = 02



Note 1: With this function enabled, the actual deceleration time may be longer than the set value.

Particularly with b130 = 02, if b131 is set too low, the Inverter may not decelerate.

Note 2: Even if this function is enabled, an overvoltage trip may occur depending on the deceleration rate and load condition.

Note 3: When using this function, the Inverter may reduce frequency depending on the moment of inertia of motor load, and takes a long time to stop.

- *1. If the b131 set value is lower than the incoming voltage or equivalent, the motor may not be stopped.
- *2. When b130 = 01, PI control works to keep the internal DC voltage constant.
 - Though quicker response is expected with a larger proportional gain (b133), control tends to be divergent and may easily lead to a trip.
 - Response also becomes quicker with a shorter integral time (b134), but if too short, the same situation may occur.

<Group C: Multi-function Terminal Function>

The RX has eight input terminals [1], [2], [3], [4], [5], [6], [7], and [8]; five open collector output terminals [11], [12], [13], [14], and [15]; one relay output terminal [AL2] and [AL1] (SPDT contact); two analog output terminals [AM] and [AMI]; as well as one digital output terminal [FM].

Multi-function Input Selection

- You can use the following functions by allocating them to any of multi-function inputs 1 to 8. To allocate the functions, set the following data in C001 to C008. For example, C001 corresponds to input terminal 1.
- The same two functions cannot be allocated to the multi-function input terminals. If you attempt to allocate the same two functions to the terminals by mistake, the terminal where you allocated the function last takes precedence. The previous data is set to "no (no allocation)", and the terminal function is disabled.
- After allocating functions to terminals 1 to 8, make sure that the function settings have been stored.

Parameter No.	Data	Function name	Reference item	Page
C001 to C008	01	RV : Reverse	RUN command	—
	02	CF1 : Multi-step speed setting binary 1	Multi-step speed operation function	4-16
	03	CF2 : Multi-step speed setting binary 2		
	04	CF3 : Multi-step speed setting binary 3		
	05	CF4 : Multi-step speed setting binary 4	Multi-step speed operation function	4-16
	06	JG : Jogging	Jogging operation	4-18
	07	DB : External DC injection braking	DC injection braking (external DC injection braking)	4-24
	08	SET : 2nd control	2nd/3rd control function	4-82
	09	2CH : 2-step acceleration/deceleration	2-step acceleration/deceleration function	4-37
	11	FRS : Free-run stop	Free-run stop	4-71
	12	EXT : External trip	External trip	4-84
	13	USP : USP function	Power recovery restart prevention function	4-84
	14	CS : Commercial switch	Commercial switch	4-85

Parameter No.	Data	Function name	Reference item	Page
C001 to C008	15	SFT : Soft lock	Soft lock	4-51
	16	AT : Analog input switching	External analog input	4-12
	17	SET3 : 3rd control	2nd/3rd control function	4-82
	18	RS : Reset	Reset	4-87
	20	STA : 3-wire start	3-wire input function	4-88
	21	STP : 3-wire stop		
	22	F/R : 3-wire forward/reverse		
	23	PID : PID enabled/disabled	PID function	4-31
	24	PIDC : PID integral reset		
	26	CAS : Control gain switching	Control gain switching	4-89
	27	UP : UP/DWN function accelerated	UP/DOWN function	4-90
	28	DWN : UP/DWN function decelerated		
	29	UDC : UP/DWN function data clear		
	31	OPE : Forced operator	Forced operator function	4-91
	32	SF1 : Multi-step speed setting bit 1	Multi-step speed operation function	4-16
	33	SF2 : Multi-step speed setting bit 2		
	34	SF3 : Multi-step speed setting bit 3		
	35	SF4 : Multi-step speed setting bit 4		
	36	SF5 : Multi-step speed setting bit 5		
	37	SF6 : Multi-step speed setting bit 6		
	38	SF7 : Multi-step speed setting bit 7		
	39	OLR : Overload limit switching	Overload limit	4-49
	40	TL : Torque limit enabled	Torque limit function	4-57
	41	TRQ1 : Torque limit switching 1		
	42	TRQ2 : Torque limit switching 2		
	43	PPI : P/PI switching	P/PI switching function	4-92
	44	BOK : Brake confirmation	Brake control function	4-76
	45	ORT : Orientation	Orientation function	4-134
	46	LAC : LAD cancel	LAD cancel function	4-9
	47	PCLR : Position deviation clear	V2 control mode selection	4-124
	48	STAT : Pulse train position command input permission		
	50	ADD : Frequency addition	Set frequency addition function	4-41
	51	F-TM : Forced terminal block	Forced terminal function	4-93
	52	ATR : Torque command input permission	Torque control	4-126
	53	KHC : Integrated power clear	Integrated power	4-4
	54	SON : Servo ON	Servo ON function	4-143

Parameter No.	Data	Function name	Reference item	Page
C001 to C008	55	FOC : Preliminary excitation	Preliminary excitation function	4-119
	56	MI1 : Drive Programming input 1	Drive Programming input 1 to 8	—
	57	MI2 : Drive Programming input 2		
	58	MI3 : Drive Programming input 3		
	59	MI4 : Drive Programming input 4		
	60	MI5 : Drive Programming input 5		
	61	MI6 : Drive Programming input 6		
	62	MI7 : Drive Programming input 7		
	63	MI8 : Drive Programming input 8		
	65	AHD : Analog command held	Analog command held	4-93
	66	CP1 : Position command selection 1	Absolute position control mode	4-139
	67	CP2 : Position command selection 2		
	68	CP3 : Position command selection 3		
	69	ORL : Zero return limit signal		—
	70	ORG : Zero return startup signal		4-142
	71	FOT : Forward driving stop		
	72	ROT : Reverse driving stop		4-140
	73	SPD : Speed/Position switching		
	74	PCNT : Pulse counter	Multi-function pulse counter	4-94
	75	PCC : Pulse counter clear		
	82	PRG : Drive program start	Drive program start	—
	no	NO : No allocation	—	—

• You can select NO- or NC-contact input for each multi-function input terminal.

Parameter No.	Function name	Data	Default setting	Unit
C011 to C018	Multi-function input 1 to 8 operation selection	00: NO 01: NC • You can set NO- and NC-contact inputs individually for multi-function input terminals 1 to 8 and the FW terminal.	00	—
C019	FW terminal operation selection	• NO contact: "ON" with the contact closed, "OFF" with the contact open. • NC contact: "ON" with the contact open. "OFF" with the contact closed. • A terminal with reset (RS) setting function only can be set as NO contact.	00	—
Related functions		C001 to C008		

2nd/3rd Control Function


- You can switch between three motors to control the Inverter by allocating 08 (SET)/17 (SET3) to any of multi-function inputs 1 to 8 (C001 to C008) and then turning on/off the SET/SET3 terminal.

Parameter No.	Function name	Data	Default setting	Unit
C001	Multi-function input 1 selection *1	01: RV (reverse) 02: CF1 (multi-step speed setting binary 1) 03: CF2 (multi-step speed setting binary 2) 04: CF3 (multi-step speed setting binary 3) 05: CF4 (multi-step speed setting binary 4) 06: JG (jogging) 07: DB (external DC injection braking) 08: SET (2nd control)	01	—
C002	Multi-function input 2 selection	09: 2CH (2-step acceleration/deceleration) 11: FRS (free-run stop) 12: EXT (external trip) 13: USP (USP function) 14: CS (commercial switch) 15: SFT (soft lock) 16: AT (analog input switching) 17: SET3 (3rd control) 18: RS (reset)	12	
C003	Multi-function input 3 selection *1	20: STA (3-wire start) 21: STP (3-wire stop) 22: F/R (3-wire forward/reverse) 23: PID (PID enabled/disabled) 24: PIDC (PID integral reset) 26: CAS (control gain switching) 27: UP (UP/DWN function accelerated) 28: DWN (UP/DWN function decelerated) 29: UDC (UP/DWN function data clear) 31: OPE (forced operator)	18	
C004	Multi-function input 4 selection	32: SF1 (multi-step speed setting bit 1) 33: SF2 (multi-step speed setting bit 2) 34: SF3 (multi-step speed setting bit 3) 35: SF4 (multi-step speed setting bit 4) 36: SF5 (multi-step speed setting bit 5) 37: SF6 (multi-step speed setting bit 6) 38: SF7 (multi-step speed setting bit 7) 39: OLR (overload limit switching)	02	
C005	Multi-function input 5 selection	40: TL (torque limit enabled) 41: TRQ1 (torque limit switching 1) 42: TRQ2 (torque limit switching 2) 43: PPI (P/PI switching) 44: BOK (brake confirmation) 45: ORT (orientation) 46: LAC (LAD cancel) 47: PCLR (position deviation clear) 48: STAT (pulse train position command input permission)	03	
C006	Multi-function input 6 selection	50: ADD (frequency addition) 51: F-TM (forced terminal) 52: ATR (torque command input permission) 53: KHC (integrated power clear) 54: SON (servo ON) 55: FOC (preliminary excitation)	06	
C007	Multi-function input 7 selection	56: MI1 (drive programming input 1) 57: MI2 (drive programming input 2) 58: MI3 (drive programming input 3) 59: MI4 (drive programming input 4) 60: MI5 (drive programming input 5) 61: MI6 (drive programming input 6) 62: MI7 (drive programming input 7) 63: MI8 (drive programming input 8) 65: AHD (analog command held) 66: CP1 (position command selection 1) 67: CP2 (position command selection 2) 68: CP3 (position command selection 3)	08	
C008	Multi-function input 8 selection	69: ORL (zero return limit signal) 70: ORG (zero return startup signal) 71: FOT (forward driving stop) 72: ROT (reverse driving stop) 73: SPD (speed/position switching) 74: PCNT (pulse counter) 75: PCC (pulse counter clear) 82: PRG (drive program start) no: NO (no allocation)	no	

*1. When the emergency shutoff function is enabled (SW1 = ON), C001 and C003 are forced to change to "18" (RS) and "64" (EMR), respectively. (You cannot intentionally set "64".)
If SW1 is turned on and then off, C003 is set to "no" (no allocation).

The functions switchable via the SET/SET3 terminal are:

F002/F202/F302 *	: 1st/2nd/3rd	acceleration time
F003/F203/F303 *	: 1st/2nd/3rd	deceleration time
A003/A203/A303	: 1st/2nd/3rd	base frequency
A004/A204/A304	: 1st/2nd/3rd	maximum frequency
A020/A220/A320 *	: 1st/2nd/3rd	multi-step speed reference 0
A041/A241	: 1st/2nd	torque boost selection
A042/A242/A342 *	: 1st/2nd/3rd	manual torque boost voltage
A043/A243/A343 *	: 1st/2nd/3rd	manual torque boost frequency
A044/A244/A344	: 1st/2nd/3rd	V/f characteristics selection
A046/A246 *	: 1st/2nd	automatic torque boost
		voltage compensation gain
A047/A247 *	: 1st/2nd	automatic torque boost slip
		compensation gain
A061/A261 *	: 1st/2nd	frequency upper limit
A062/A262 *	: 1st/2nd	frequency lower limit
A092/A292/A392 *	: 1st/2nd/3rd	acceleration time 2
A093/A293/A393 *	: 1st/2nd/3rd	deceleration time 2
A094/A294	: 1st/2nd	2-step acceleration/deceleration
		selection
A095/A295	: 1st/2nd	2-step acceleration frequency
A096/A296	: 1st/2nd	2-step deceleration frequency
b012/b212/b312 *	: 1st/2nd/3rd	electronic thermal level
b013/b213/b313 *	: 1st/2nd/3rd	electronic thermal characteristics
		selection
H002/H202	: 1st/2nd	motor parameter selection
H003/H203	: 1st/2nd	motor capacity selection
H004/H204	: 1st/2nd	motor pole number selection
H005/H205 *	: 1st/2nd	speed response
H006/H206/H306 *	: 1st/2nd/3rd	stabilization parameter
H020/H220	: 1st/2nd	motor parameter R1
H021/H221	: 1st/2nd	motor parameter R2
H022/H222	: 1st/2nd	motor parameter L
H023/H223	: 1st/2nd	motor parameter I0
H024/H224	: 1st/2nd	motor parameter J
H030/H230	: 1st/2nd	motor parameter R1 (auto-tuning)
H031/H231	: 1st/2nd	motor parameter R2 (auto-tuning)
H032/H232	: 1st/2nd	motor parameter L (auto-tuning)
H033/H233	: 1st/2nd	motor parameter I0 (auto-tuning)
H034/H234	: 1st/2nd	motor parameter J (auto-tuning)
H050/H250 *	: 1st/2nd	PI proportional gain
H051/H251 *	: 1st/2nd	PI integral gain
H052/H252 *	: 1st/2nd	P proportional gain
H060/H260 *	: 1st/2nd	Limit at 0 Hz



*: Parameters changeable during operation.

- The 1st/2nd/3rd control functions are displayed identically. You'll see which one is enabled by checking whether the terminal is turned on/off.
- When both SET and SET3 terminals are turned on, priority is given to SET, and the 2nd control function is enabled.
- During operation, you cannot switch between the 1st, 2nd, and 3rd control functions. You can switch them only during stop.

External Trip


- This function trips the Inverter via an error (trip) signal from a peripheral system. To use this function, allocate "12" (EXT) to any of multi-function inputs 1 to 8 (C001 to C008).

Data	Symbol	Function name	Status	Description
12	EXT	External trip	ON	Sets the motor to free-run status by shutting off output.
			OFF	The motor is in normal operation.
Available input terminals		C001 to C008		

Note: Do not turn on the EXT terminal after shutting off the power. Otherwise, the Inverter may not store data correctly.

- When the EXT terminal is turned on, E12 is displayed and the Inverter trips to stop output.
- When the Inverter has tripped, indicating E12, the trip is not reset even if the error signal from external equipment is reset (EXT terminal is turned off).
To reset the trip, perform the reset operation or turn the power off and on again.

Power Recovery Restart Prevention Function




- This function trips the Inverter, displaying "E13", if the power is turned on with the RUN command to the Inverter turned on.

Data	Symbol	Function name	Status	Description
13	USP	USP function	ON	Does not start the Inverter with the power turned on while the RUN command is input.
			OFF	Starts the Inverter with the power turned on while the RUN command is input.
Available input terminals		C001 to C008		

- To reset a trip, perform the reset operation, or turn off the RUN command. (Example 1)
- If a trip is reset with the RUN command input turned on, the Inverter restarts operation immediately after the trip is reset. (Example 2)
- If the RUN command is turned on after the power is turned on, the Inverter operates normally. (Example 3)
- Allocate 13 (USP) to any of multi-function inputs 1 to 8 (C001 to C008).


•The following shows how the power recovery restart prevention function works.





Commercial Switching

- You can use this function to drive a system with large moment of inertia during acceleration and deceleration by using the Inverter, and during constant speed by using a commercial power supply.
- Allocate "14" (CS) to any of multi-function inputs 1 to 8 (C001 to C008).
- When the CS terminal is turned on and then off with the RUN command turned on, the Inverter starts acceleration in synchronization with the motor rpm during free running, after the retry wait time (b003) elapses (frequency matching start). Note that the Inverter may start at 0 Hz if:
 - The motor rpm is equal to or lower than 1/2 of the base rpm
 - The motor induction voltage quickly attenuates
- If frequency matching lower limit frequency setting b007 is set, the Inverter starts at 0 Hz when the motor rpm lowers to the frequency set in b007. (Refer to page 4-38)
- Ensure that MC3 and MC2 are mechanically interlocked.
- If the earth leakage breaker (ELB) has tripped because of ground fault, the commercial power supply circuit does not work, either. If you need backup, supply power from a commercial power supply circuit (ELBC).
- For FWY, RVY, and CSY, use low current relays. Refer to the following sequence for timing.
- If an overcurrent trip occurs at frequency matching, extend the retry wait time (b003).
- For commercial switching operation, refer to the following examples of connections and timing of commercial switching operation.
- At power-on, the Inverter can automatically perform retry operation. This does not require the following CS terminal. For details, refer to "Reset" (page 4-87).

Examples of connections and timing of commercial switching operation





Reset


- This function resets an Inverter trip.

Parameter No.	Function name	Data	Default setting	Unit
b003	Retry wait time	0.3 to 100.0: (Refer to "Momentary Power Interruption/ Trip Retry (Restart)" (page 4-42).) Time from reset to restart	1.0	s
b007	Frequency matching lower limit frequency setting	0.00 to 400.00: (Refer to "Momentary Power Interruption/ Trip Retry (Restart)" (page 4-42).)	0.00	Hz
C102	Reset selection	00: ON-RESET (Trip reset at power-on) (example 1) Normal: Output shut off Abnormal: Trip reset	00	—
		01: OFF-RESET (Trip reset when the power is OFF (example 2) Normal: Output shut off Abnormal: Trip reset		
		02: On in Trip (Enabled only during trip (Reset when the power is OFF)) (example 1) Normal: Disabled Abnormal: Trip reset		
		03: Trip RESET (Trip reset only) (example 1) The Inverter does not initialize internal data at trip reset. Normal: Disabled Abnormal: Trip reset		
C103	Reset frequency matching selection	00: 0 Hz start 01: f-match (Frequency matching start) (example 3) 02: Actv. f-match (Active Frequency Matching restart)	00	—


- To reset an Inverter trip, press the STOP/RESET key on the Digital Operator, or switch the RS terminal from ON to OFF.
- To reset via the control circuit terminal block, allocate 18 (RS) to the desired multi-function input.
- With reset frequency matching selection C103, you can select how to restart the Inverter after reset, a frequency matching or 0-Hz start. If an overcurrent trip occurs at frequency matching start, increase the retry wait time (b003).
- You can select an alarm reset timing in reset selection C102. In addition, you can enable the reset signal only for alarm resetting during error.
- For the RS terminal, only NO contact is available.

Note: Do not use the reset terminal to shut off the Inverter output. Reset operation clears the internal data (e.g. electronic thermal BRD counter), causing damage to the Inverter.

(Example 1)




(Example 2)




(Example 3) If "01" (frequency matching start) is selected in reset frequency matching selection C103, frequency matching start is also enabled when the power is turned on again. When C103 = 00 (0-Hz start), the retry wait time (b003) is ignored. Even if "frequency matching start" is selected, however, the Inverter may start at 0 Hz if:

- The output frequency is equal to or lower than 1/2 of the base frequency
- The motor induction voltage quickly attenuates



Note: The counters used for the Inverter's internal protection are cleared during reset.
To shut off the Inverter's output via a multi-function input terminal, use the free-run stop terminal (FRS).

(Example 4) Active Frequency Matching restart



- After the retry wait time (b003) elapses, the Inverter starts output from the b030 set value. The Inverter then decelerates according to the b029 setting, while keeping the output current at the b028 set value.
- When the frequency matches the voltage, the Inverter accelerates again, and the frequency is restored to the original level.
- If an overcurrent trip occurs under this method, reduce the b028 setting.

Note: If a reset signal is input during the retry wait time, the value of "frequency at interruption" stored in the Inverter is cleared, resulting in a 0-Hz start.


3-wire Input Function

•This function helps start and stop the Inverter using an auto-recovery contact (e.g. pushbutton switch).

Data	Symbol	Function name	Status	Description
20	STA	3-wire start	ON	Starts with auto recovery contacts.
			OFF	Irrelevant to the motor operation.
21	STP	3-wire stop	ON	Stops with auto recovery contacts.
			OFF	Irrelevant to the motor operation.
22	F/R	3-wire forward/reverse	ON	Reverse
			OFF:	Forward
Available input terminals		C001 to C008		
Required settings		A002 = 01		

•Set RUN command selection A002 to 01 (control circuit terminal block).

- The following operations become possible when 20 (STA), 21 (STP), and 22 (F/R) are allocated to any of multi-function inputs 1 to 8 (C001 to C008). Allocating the STP terminal disables the FW and RV terminals.
- Below are the outputs via terminal operation.



Control Gain Switching Function

- This function provides two types of gain and time constant settings for the speed control system (proportional/integral compensation). You can switch over these settings when "sensorless vector control", "0-Hz sensorless vector control", or "sensor vector control" is selected as the control method.

Parameter No.	Function name	Data	Default setting	Unit
A044/A244	V/f characteristics selection	03: SLV (Sensorless vector control) 04: 0SLV (0-Hz sensorless vector control) 05: V2 (Sensor vector control)	00	—
C001 to C008	Multi-function inputs 1 to 8 selection	26: CAS (control gain switching)	—	—
H005/H205	Speed response	0.001 to 80.000	1.590	—
H050/H250	PI proportional gain	0.0 to 1000.0	100.0	%
H051/H251	PI integral gain	0.0 to 1000.0	100.0	%
H052/H252	P proportional gain	0.01 to 10.00	1.00	—
H070	For PI proportional gain switching	0.0 to 1000.0	100.0	%
H071	For PI integral gain switching	0.0 to 1000.0	100.0	%
H072	For P proportional gain switching	0.00 to 10.00	1.00	—
H073	Gain switching time	0 to 9999 (ms): Taper time during gain switching	100	ms

- If control gain switching is selected in the multi-function input selection, turning off the signal selects the gain setting of H050, H250, H051, H251, H052, or H252. Turning on the signal selects the gain setting of H070, H071, or H072.
- If control gain switching is not selected in multi-function inputs 1 to 8 (C001 to C008), the gain setting conforms to the status in which the signal is turned off.

UP/DOWN Function

- This function allows you to change the Inverter output frequency using the UP and DWN terminals of the multi-function inputs.

Data	Symbol	Function name	Status	Description
27	UP	UP/DWN function accelerated	ON	Increases the current speed during the signal input period.
			OFF	Keeps the current speed.
28	DWN	UP/DWN function decelerated	ON	Decreases the current speed during the signal input period.
			OFF	Keeps the current speed.
29	UDC	UP/DWN function data clear	ON	Clears the stored UP/DWN speed.
			OFF	Keeps the stored UP/DWN speed.
Available input terminals		C001 to C008		


Note: Do not turn on/off the UP/DWN terminal after shutting off the power. Otherwise, the Inverter may not store data correctly.

- Allocate "27" (UP) and "28" (DWN) to any of multi-function inputs 1 to 8 (C001 to C008).
- This function is enabled only when frequency reference selection A001 is set to "01" or "02". If "01" (terminal) is selected, however, this function is enabled for multi-step speed operation only.
- When you use an external analog input as frequency reference input, or when you set the jogging operation frequency, this function is disabled.
- While the UP/DWN terminal is turned on, the acceleration/deceleration time depends on F002, F003/F202, F203/F302, and F303. To switch between the 1st/2nd/3rd controls, allocate 08 (SET)/17 (SET3) to the desired multi-function input and then turn on/off the SET terminal.
- You can store a frequency set value after UP/DWN adjustment. Choose whether to store the value with C101.

Also, you can clear the stored frequency set value.

By allocating "29" (UDC) to a multi-function input and turning on/off the UDC terminal, you can clear or store the frequency reference setting adjusted at UP/DOWN.

Parameter No.	Data	Description
C101	00	Does not store the frequency reference adjusted at UP/DWN. After restoring the power, returns to the value set before UP/DWN adjustment.
	01	Stores the frequency reference adjusted at UP/DWN. After restoring the power, maintains the set value after UP/DWN adjustment.



Forced Operator Function

- This function forcibly enables operation via the Digital Operator by turning on/off the multi-function terminal if the frequency reference/RUN command sources are not set to the Digital Operator.

Data	Symbol	Function name	Status	Description
31	OPE	Forced operator	ON	Prioritizes the command from the Digital Operator (A020, A220 set values) over the A001 and A002 settings.
			OFF	Operates according to the A001 and A002 settings.
Available input terminals		C001 to C008		
Related codes		A001, A002		

- If the Forced Operator function is selected in the multi-function input selection, the Inverter is operated with the signal from the frequency reference source and RUN command source selected in A001 and A002, when the input signal is OFF. When the signal is ON, the Inverter is forced to operate with the frequency reference or RUN command from the Digital Operator.
- If you switch on/off this function during operation, the RUN command is reset to stop the Inverter output. Before resuming operation, turn off the RUN command from each command source to avoid possible danger and then input it again.

P/PI Switching Function

- This function allows you to switch the control (compensation) method for the speed control system between proportional integral compensation and proportional compensation, when "sensorless vector control", "0-Hz sensorless vector control", or "sensor vector control" is selected as the control method.

Parameter No.	Function name	Data	Default setting	Unit
A044/A244/A344	V/f characteristics selection	03: SLV (Sensorless vector control) (A344 is blank.) 04: 0SLV (0 Hz sensorless vector control) (A344 is blank.) 05: V2 (Sensor vector control)	00	—
C001 to C008	Multi-function inputs 1 to 8 selection	43: PPI (P/PI switching)	—	—
H005/H205	Speed response	0.001 to 80.000	1.590	—
H050/H250	PI proportional gain	0.0 to 1000.0	100.0	%
H051/H251	PI integral gain	0.0 to 1000.0	100.0	%
H052/H252	P proportional gain	0.01 to 10.00	1.00	—

- If P/PI switching is selected in the multi-function input selection, proportional integral compensation is enabled while the signal is off; proportional compensation is enabled while the signal is on. If P/PI switching is not selected in multi-function inputs 1 to 8 (C001 to C008), proportional integral compensation is enabled.


Normally, the Inverter performs proportional integral compensation (PI control) for speed control so that the difference between frequency reference and actual rpm becomes zero. If one load is operated by several motors, however, proportional control (P control) may be required. To enable proportional control (P control), allocate the P/PI switching function to any of multi-function input terminals 1 to 8 (set "43" in any of C001 to C008) via the Digital Operator, and turn on the terminal. If you choose to enable proportional control, set a "KPP" value in H052 (P proportional gain).

The relationship between the KPP value and speed change ratio is expressed broadly in the following formula:

$$(\text{Speed change ratio}) = \frac{10}{(\text{KPP set value})} \%$$

The relationship between speed change ratio and speed error is expressed broadly in the following formula:

$$(\text{Speed change ratio}) = \frac{\text{Speed error at rated torque (A)}}{\text{Synchronous rpm at base frequency}} \times 100\%$$



Forced Terminal Block Function (F-TM)

- This function forcibly enables operation via the control terminal block by turning on/off the multi-function terminal if the frequency reference/RUN command sources are not set to the control terminal block.

Data	Symbol	Function name	Description
51	F-TM	Multi-function input selection	Forced terminal
Available input terminals		C001 to C008	
Related codes		A001, A002	


- If the Forced Terminal Block function is selected in the multi-function input selection, the Inverter is operated with the signal from the frequency reference source and RUN command source selected in A001 and A002, when the input signal is OFF. When the signal is ON, the Inverter is forced to operate with the frequency reference or RUN command from the control circuit terminal block.
- If you switch on/off this function during operation, the RUN command is reset to stop the Inverter output. Before resuming operation, turn off the RUN command from each command source to avoid possible danger and then input it again.

Analog Command Hold Function

- While the AHD terminal is turned on, the Inverter keeps external analog input results on hold.

Parameter No.	Function name	Data	Default setting	Unit
C001 to C008	Multi-function inputs 1 to 8 selection	65: AHD (analog command held)	—	—

- While the AHD terminal is turned on, you can use the UP/DWN function based on the reference value of the analog signal kept on hold by this function.
- If UP/DWN selection C101 is set to "01", the Inverter can store an UP/DWN result.
- If the power is turned on with the AHD terminal turned on, or if the RS terminal is turned on and then off, the Inverter employs the data kept on hold immediately before.



Note1: If the control function is switched via the SET/SET3 terminal with the AHD terminal turned on, the set frequency is retained. To change the control function, turn off the AHD terminal once, and keep the analog signal on hold again.

Note 2: If this function is frequently used, the internal storage element service life may be shortened.


Multi-function Pulse Counter (PCNT, PCC)

- The Inverter can input pulse trains via a multi-function input.
- With pulse counter monitor d028, you can monitor the total count of input pulses.

Parameter No.	Function name	Data	Default setting	Unit
C001 to C008	Multi-function inputs 1 to 8 selection	74: PCNT (pulse counter) 75: PCC (pulse counter clear)	—	—
Related functions		d028		

- The total pulse count value cannot be stored. After the power is turned on or after reset, the counter is reset to zero.
- Turning on PCC (pulse counter clear) clears the total count value.
- The input pulse frequency resolution can be obtained with the following formula. (This applies to pulse input with a 50% duty ratio.) The Inverter cannot input frequency higher than the specified frequency resolution. It is recommended that you use input frequencies up to 100 Hz. For details on input terminal response, refer to "Input Terminal Response Time" (page 4-108).

Frequency resolution (Hz) = 250/(Input terminal response time set values C160 to C168 + 1)
Example: When the input terminal response time = 1, the frequency resolution = 125 Hz.



Multi-function Output Terminal Selection

- You can allocate the following functions to any of multi-function output terminals 11 to 15 (C021 to C025) or the alarm relay output terminal (C026).
- Multi-function output terminals 11 to 15 provide open-collector output. The alarm relay output terminal provides relay output.
- You can select NO- or NC-contact output for each output terminal with C031 to C035, or C036.
- If alarm code output is selected in C062 (refer to page 4-101), alarm code output (AC0 to AC3) is provided via output terminals 11 to 13 (for 3-bit code), or via output terminals 11 to 14 (for 4-bit code). The C021 to C025 settings are disabled.

Data	Description	Reference item	Page
00	RUN: Signal during RUN	Signal during RUN	4-98
01	FA1: Constant speed arrival signal	Frequency arrival signal	4-98
02	FA2: Over set frequency arrival signal		
03	OL: Overload warning	Overload limit/Overload warning	4-49
04	OD: Excessive PID deviation	PID function	4-31
05	AL: Alarm output	—	—
06	FA3: Set-frequency-only arrival signal	Frequency arrival signal	4-98
07	OTQ: Overtorque	Overtorque	4-100
08	IP: Signal during momentary power interruption	Momentary power interruption/Undervoltage	4-44
09	UV: Signal during undervoltage		
10	TRQ: Torque limit	Torque limit function	4-57
11	RNT: RUN time over	RUN time over	4-52
12	ONT: Power ON time over	Power ON time over	4-52
13	THM: Thermal warning	Electronic thermal function	4-46
19	BRK: Brake release	Brake control function	4-76
20	BER: Brake error		
21	ZS: 0-Hz signal	0-Hz detection signal	4-101
22	DSE: Excessive speed deviation	V2 control mode selection	4-124
23	POK: Position ready	Orientation function	4-134
24	FA4: Set frequency exceeded 2	Frequency arrival signal	4-98
25	FA5: Set frequency only 2		
26	OL2: Overload warning 2	Overload limit/Overload warning	4-49
27	ODc: Analog O disconnection detection	Window comparator function	4-66
28	OIDc: Analog OI disconnection detection		
29	O2Dc: Analog O2 disconnection detection		
31	FBV: PID FB status output	PID function	4-31
32	NDc: Network error	Network error	4-104

Data	Description	Reference item	Page
33	LOG1: Logic operation output 1	Logic operation function	4-102
34	LOG2: Logic operation output 2		
35	LOG3: Logic operation output 3		
36	LOG4: Logic operation output 4		
37	LOG5: Logic operation output 5		
38	LOG6: Logic operation output 6		
39	WAC: Capacitor life warning signal	Capacitor life warning signal	4-103
40	WAF: Cooling fan life warning signal	Cooling fan speed drop signal	4-104
41	FR: Starting contact signal	Starting contact signal	4-105
42	OHF: Fin overheat warning	Fin overheat warning	4-105
43	LOC: Light load detection signal	Light load detection signal	4-106
44	MO1 (Drive programming output 1)	Drive programming outputs	—
45	MO2 (Drive programming output 2)		
46	MO3 (Drive programming output 3)		
47	MO4 (Drive programming output 4)		
48	MO5 (Drive programming output 5)		
49	MO6 (Drive programming output 6)		
50	IRDY: Operation ready signal	Operation ready signal	4-106
51	FWR: Forward run signal	Forward run signal	4-107
52	RVR: Reverse run signal	Reverse run signal	4-107
53	MJA: Fatal fault signal	Fatal fault signal	4-107
54	WCO: Window comparator O	Window comparator function	4-66
55	WCO1: Window comparator O1		
56	WCO2: Window comparator O2		
63	OPO: Option board output	Output controlled from option board	—
Related functions		C021 to C025, C026	


Multi-function Output Terminal Contact Selection

- You can set NO- or NC-contact output individually for multi-function output terminals 11 to 15 as well as the relay output terminal.
- Multi-function output terminals 11 to 15 provide open-collector output.

Parameter No.	Function name	Data	Default setting	Unit
C031 to C035	Multi-function output terminal 11 to 15 contact selection	00: NO 01: NC	00	—
C036	Relay output (AL2, AL1) contact selection	00: NO contact between AL2, NC contact at AL1 01: NC contact between AL2, NO contact at AL1	01	—

■ Specifications of Multi-function Output Terminals 11 to 15


- Below are the specifications of multi-function output terminals 11 to 15.



C031 to C035 set values	Power supply	Output status	Electrical characteristics
00 (NO contact)	ON	ON	Between each terminal and CM2 Voltage drop 4 V max. at power-on Max. allowable voltage: 27 V DC Max. allowable current: 50 mA
	OFF	—	
01 (NC contact)	ON	ON	
	OFF	—	

■ Specifications of the Relay Output Terminals

- The relay output terminals have an SPDT contact configuration. Below is its operation.




(Example) When the relay output terminals are used for alarm

C036 set values	Power	Inverter status	Output terminal status		Resistance load		Inductive load
			AL2-AL0	AL1-AL0	AL2-AL0	AL1-AL0	
00	ON	Abnormal	Closed	Open	Max. contact capacity	250 V AC, 2 A 30 V DC, 8 A	250 V AC, 0.2 A 30 V DC, 0.6 A
		Normal	Open	Closed	Min. contact capacity	100 V AC, 10 mA 5 V DC, 100 mA	
	OFF	—	Open	Closed	Max. contact capacity	250 V AC, 1 A 30 V DC, 1 A	250 V AC, 0.2 A 30 V DC, 0.2 A
01 (Default)	ON	Abnormal	Open	Closed	Min. contact capacity	100 V AC, 10 mA 5 V DC, 100 mA	
		Normal	Closed	Open			
	OFF	—	Open	Closed			

Signal During RUN

- While the Inverter is running, this signal is output via multi-function output terminals 11 to 15 or the relay output terminal.
- Allocate "00" (RUN) to any of multi-function output terminals 11 to 15 (C021 to C025) or the relay output terminal (C026).
- This signal is also output during DC injection braking.

Below is the time chart.



Frequency Arrival Signal


- When the output frequency reaches the set level, a frequency arrival signal is output.

Parameter No.	Function name	Data	Default setting	Unit
C042	Arrival frequency during acceleration	0.00: Does not output arrival signal during acceleration. 0.01 to 400.00: Outputs arrival signal during acceleration.	0.00	Hz
C045	Arrival frequency during acceleration 2			
C043	Arrival frequency during deceleration	0.00: Does not output arrival signal during deceleration. 0.01 to 400.00: Outputs arrival signal during deceleration.	0.00	Hz
C046	Arrival frequency during deceleration 2			

- For elevating machines, use this signal for applying the brake. To release the brake, use the overtorque signal.
- Allocate "01" (FA1: Constant speed arrival signal), "02" (FA2: Set frequency exceeded), "06" (FA3: Set frequency only), "24" (FA4: Set frequency exceeded 2), or "25" (FA5: Set frequency only 2) to any of multi-function output terminals 11 to 15 (C021 to C025) or the relay output terminal (C026).
- Below is the hysteresis of the frequency arrival signal:
 - ON: (Set frequency - 1% of the maximum frequency) (Hz)
 - OFF: (Set frequency - 2% of the maximum frequency) (Hz)
- If "06" (FA3) or "25" (FA5) is set, however, operation during acceleration is:
 - ON: (Set frequency - 1% of the maximum frequency) (Hz)
 - OFF: (Set frequency + 2% of the maximum frequency) (Hz)
- and operation during deceleration is:
 - ON: (Set frequency + 1% of the maximum frequency) (Hz)
 - OFF: (Set frequency - 2% of the maximum frequency) (Hz)


■ Constant Speed Arrival Output (01: FA1)

A signal is output when the output frequency has reached the level set in the frequency setting (F001, A020, A220, and A320) or multi-step speed (A021 to A035).




■ Set-frequency-exceeded Output (02: FA2, 24: FA4)

A signal is output when the output frequency has exceeded the arrival frequencies during acceleration/deceleration set in [C042, C043 (FA2)] and [C045, C046 (FA4)].



■ Set-frequency-only Output (06: FA3, 25: FA5)

A signal is output when the output frequency equals the arrival frequencies during acceleration/deceleration set in [C042, C043 (FA3)] and [C045, C046 (FA5)].



Overtorque (OTQ)

- This function outputs a signal when detecting a motor output torque estimated value exceeding a specified level.

Parameter No.	Function name	Data	Default setting	Unit
C021 to C025	Multi-function output terminal 11 to 15 selection	07: OTQ (Overtorque)	-	—
C026	Relay output (AL2, AL1) function selection		05	
C055	Overtorque level (Forward power running)	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) OTQ signal output level for forward power running	200 (Under 55 kW) 180 (Over 75 kW)	%
C056	Overtorque level (Reverse regeneration)	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) OTQ signal output level for reverse regeneration	200 (Under 55 kW) 180 (Over 75 kW)	%
C057	Overtorque level (Reverse power running)	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) OTQ signal output level for reverse power running	200 (Under 55 kW) 180 (Over 75 kW)	%
C058	Overtorque level (Forward regeneration)	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) OTQ signal output level for forward regeneration	200 (Under 55 kW) 180 (Over 75 kW)	%
Related functions		A044, A244, A344, C063		

- Enabled when "overtorque signal" is selected in the multi-function output selection. You can use this function only when "sensorless vector control", "0-Hz sensorless vector control", or "sensor vector control" is selected in V/f characteristics selection A044/A244. With other settings, the output is unstable.
- For elevating machines, use this signal for releasing the brake. To close the brake, use the frequency arrival signal.

0-Hz Detection Signal

- This function outputs a detection signal when the Inverter's output frequency falls below the 0-Hz detection value set in 0-Hz detection level C063.

Parameter No.	Function name	Data	Default setting	Unit
C021 to C025	Multi-function output terminal 11 to 15 selection	21: ZS (0-Hz signal)	—	—
C026	Relay output (AL2, AL1) function selection		05	
C063	0-Hz detection level	0.00 to 100.00: Set a frequency to be detected as 0 Hz.	0.00	Hz
Related functions		A044, A244, A344		

- Enabled when "21" (ZS) is allocated to any of multi-function output terminals 11 to 15 (C021 to C025) or the relay output terminal (C026).
When "VC", "special VP", "free V/F", "sensorless vector control", or "0-Hz sensorless vector control" is selected as the control method, this function works for the Inverter's output frequency.
When the control method is "sensor vector control", this function works for the motor rotation frequency.

Alarm Code Output (AC0 to AC3)

- This function outputs a 3-bit or 4-bit code signal to indicate the cause of an Inverter trip.

Parameter No.	Function name	Data	Default setting	Unit
C062	Alarm code selection	00: OFF (Disabled)	00	—
		01: 3-bit		
		02: 4-bit		

- If "01" (3-bit) or "02" (4-bit) is selected in alarm code selection C062, multi-function output terminals 11 to 13, or 11 to 14, are forced to output an alarm code.
The following table shows the output alarm codes.

Multi-function output terminals				With 4-bit code selected		With 3-bit code selected	
14	13	12	11	Factor code	Trip cause	Factor code	Trip cause
AC3	AC2	AC1	AC0				
0	0	0	0	Normal	Normal	Normal	Normal
0	0	0	1	E01 to E03, E04	Overcurrent protection	E01 to E03, E04	Overcurrent protection
0	0	1	0	E05, E38	Overload protection Overload protection in a low speed range	E05	Overload protection
0	0	1	1	E07, E15	Overvoltage/Incoming overvoltage protection	E07, E15	Overvoltage/Incoming overvoltage protection
0	1	0	0	E09	Undervoltage protection	E09	Undervoltage protection
0	1	0	1	E16	Momentary power interruption protection	E16	Momentary power interruption protection
0	1	1	0	E30	IGBT error	E30	IGBT error
0	1	1	1	E06	Braking resistor overload protection	—	Other errors


Multi-function output terminals				With 4-bit code selected		With 3-bit code selected	
14	13	12	11	Factor code	Trip cause	Factor code	Trip cause
AC3	AC2	AC1	AC0				
1	0	0	0	E08, E11 E23, E25	EEPROM error, CPU error, GA communication error, Main circuit error	—	—
1	0	0	1	E10	CT error	—	—
1	0	1	0	E12, E13 E35, E36	External trip, USP error, Thermistor error, Brake error	—	—
1	1	0	0	E14	Grounding protection	—	—
1	1	0	1	E20	Abnormal temperature due to the cooling fin's speed drop		
1	1	0	1	E21	Abnormal temperature	—	—
1	1	1	0	E24	Input phase loss protection	—	—
1	1	1	1	E50 to E79	Network error, Options 1, 2 Errors 0 to 9	—	—

Output Signal Logic Operation

- This function performs output signal logic operations inside the Inverter.
- All output signals are operation targets.
However, the logic operation outputs (LOG1 to LOG6) are not subject to operations.

Parameter No.	Function name	Data	Default setting	Unit
C021 to C025	Multi-function output terminal 11 to 15 selection	33: LOG1 (Logic operation output [C142, C143, C144]) 34: LOG2 (Logic operation output 2 [C145, C146, C147]) 35: LOG3 (Logic operation output 3 [C148, C149, C150])	—	—
C026	Relay output (AL2, AL1) function selection	36: LOG4 (Logic operation output 4 [C151, C152, C153]) 37: LOG5 (Logic operation output 5 [C154, C155, C156]) 38: LOG6 (Logic operation output 6 [C157, C158, C159])	05	
C142/C145/C148/ C151/C154/C157	Logic output signal selection 1	Select 00 to 50 from the multi-function output data (other than LOG1 to LOG6): Select operand 1.	00	—
C143/C146/C149/ C152/C155/C158	Logic output signal selection 2	Select 00 to 50 from the multi-function output data (other than LOG1 to LOG6): Select operand 2.	00	—
C144/C147/C150/ C153/C156/C159	Logic output signal operator selection	00: AND 01: OR 02: XOR	00	—

- You can select from three types of operators (AND, OR, and XOR).



- The setting parameters vary depending on the logic operation output selected. Refer to the following table to set the necessary parameters.

Selected signal	Operand 1 selection	Operand 2 selection	Operator selection
33: Logic operation output 1 (LOG1)	C142	C143	C144
34: Logic operation output 2 (LOG2)	C145	C146	C147
35: Logic operation output 3 (LOG3)	C148	C149	C150
36: Logic operation output 4 (LOG4)	C151	C152	C153
37: Logic operation output 5 (LOG5)	C154	C155	C156
38: Logic operation output 6 (LOG6)	C157	C158	C159

(Example) To output a logic output 1 (LOG1) signal through AND operation of "RUN signal" (00: RUN) and "over set frequency arrival signal" (02: FA2) to multi-function output 2

- Multi-function input 2 selection (C002) : 33 (LOG1)
- Logic output signal 1 selection 1 (C142) : 00 (RUN)
- Logic output signal 1 selection 2 (C143) : 02 (FA2)
- Logic output signal 1 operator selection (C144): 00 (AND)

Capacitor Life Warning Signal


- This function determines estimated service life of the capacitor on the PCB, based on the Inverter's internal temperature and ON time.
- Life assessment monitor d022 shows the status of this signal.
- If this function is activated, it is recommended that the main circuit board and logic board be replaced.

Parameter No.	Function name	Data	Default setting	Unit
C021 to C025	Multi-function output terminal 11 to 15 selection	39: WAC (Capacitor life warning signal (on PCB))	—	—
C026	Relay output (AL2, AL1) function selection		05	

Network Error

- Enabled only when ModBus-RTU is selected for RS485 communication.
- If a reception timeout error occurs, this signal is output until reception of the next data.
- Set a time before reception timeout in communication error timeout C077.
- For details, refer to "4-4 Communication Function".

Parameter No.	Function name	Data	Default setting	Unit
C021 to C025	Multi-function output terminal 11 to 15 selection	32: NDc (network error)	—	—
C026	Relay output (AL2, AL1) function selection		05	
C077	Communication error timeout	0.00 to 99.99: Set a time before reception timeout.	0.00	s



Cooling Fan Speed Drop Signal


- This signal is output when detecting that the Inverter's built-in cooling fan rotation speed is reduced to 75% or less.
- If "01" is selected in cooling fan control b092, this signal is not output even while the fan is stopped.
- While this signal is output, check the cooling fan for clogging.
- Life assessment monitor d022 shows the status of this signal.

Parameter No.	Function name	Data	Default setting	Unit
C021 to C025	Multi-function output terminal 11 to 15 selection	40: WAF (cooling fan life warning signal)	—	—
C026	Relay output (AL2, AL1) function selection		05	
Related functions		b092, d022		

Starting Contact Signal

- While the Inverter is receiving the RUN command, a starting contact signal is output.
- The output is enabled regardless of the setting of RUN command source selection A002.
- If inputs FW and RV are simultaneously turned on, the Inverter stops.

Parameter No.	Function name	Data	Default setting	Unit
C021 to C025	Multi-function output terminal 11 to 15 selection	41: FR (starting contact signal)	—	—
C026	Relay output (AL2, AL1) function selection		05	



Fin Overheat Warning


- This function monitors the Inverter's internal fin temperature and outputs a signal when the temperature exceeds the fin overheat warning level (C064).

Parameter No.	Function name	Data	Default setting	Unit
C021 to C025	Multi-function output terminal 11 to 15 selection	42: OHF (fin overheat warning)	—	—
C026	Relay output (AL2, AL1) function selection		05	
C064	Fin overheat warning level	0 to 200: Set a temperature to output the overheat warning signal.	120	°C

Light Load Detection Signal

- This signal is output when output current falls below the light load detection level (C039).
- In light load signal output mode C038, you can set whether this output is enabled in any operation mode, or only in constant speed operation.

Parameter No.	Function name	Data	Default setting	Unit
C021 to C025	Multi-function output terminal 11 to 15 selection	43: LOC (light load detection signal)	—	—
C026	Relay output (AL2, AL1) function selection		05	
C038	Light load signal output mode	00: ACC/DEC/CST (Enabled during acceleration/deceleration/constant speed) 01: Const (Enabled only during constant speed)	01	—
C039	Light load detection level	0.0 to 2.00 × Rated current: (0.4 to 55 kW) 0.0 to 1.80 × Rated current (75 to 132 kW) Set an output level for low current signals.	Rated current	A



Operation Ready Signal

- This signal is output when the Inverter becomes ready for operation (ready to receive the RUN command).
- Even if the RUN command is input while this signal is not output, the Inverter does not recognize the RUN command.
- If this signal is not output, check if the input power supply voltage (R/L1, S/L2, T/L3) is within the specified range.

Parameter No.	Function name	Data	Default setting	Unit
C021 to C025	Multi-function output terminal 11 to 15 selection	50: IRDY (operation ready signal)	—	—
C026	Relay output (AL2, AL1) function selection		05	

Forward Run Signal

- This signal is output while the Inverter is running forward.
- While the Inverter is running in reverse, or when stopped, this signal is turned off.


Parameter No.	Function name	Data	Default setting	Unit
C021 to C025	Multi-function output terminal 11 to 15 selection	51: FWR (forward run signal)	—	—
C026	Relay output (AL2, AL1) function selection		05	

4

Reverse Run Signal

- This signal is output while the Inverter is running in reverse.
- While the Inverter is running forward, or when stopped, this signal is turned off.

Parameter No.	Function name	Data	Default setting	Unit
C021 to C025	Multi-function output terminal 11 to 15 selection	52: RVR (reverse run signal)	—	—
C026	Relay output (AL2, AL1) function selection		05	



Fatal Fault Signal

Parameter No.	Function name	Data	Default setting	Unit
C021 to C025	Multi-function output terminal 11 to 15 selection	53: MJA (fatal fault signal)	—	—
C026	Relay output (AL2, AL1) function selection		05	

- In addition to an alarm, this signal is output if any of the following trips occurs. (These trips are caused by hardware.)

No.	Error code	Description
1	E10.*	CT error
2	E11.*	CPU error
3	E14.*	Grounding protection
4	E20.*	Abnormal temperature due to cooling fan stop
5	E23.*	Gate array communications error
6	E25.*	Main circuit error

Multi-function Output Terminal ON Delay/OFF Delay

- You can set ON/OFF delay times for each output terminal.

Output terminal	ON delay time	OFF delay time
11	C130	C131
12	C132	C133
13	C134	C135
14	C136	C137
15	C138	C139
RY (AL*)	C140	C141

- All output signals immediately turn on/off when the specified conditions are satisfied. Depending on the selected signal, chattering may occur. In such a case, use this function to hold or delay the signal.
- Set the parameters for individual output terminals (multi-function output terminals 11 to 15 and the relay output terminal: six terminals in total). For the output terminals and the corresponding parameters, refer to the table below.

Function code	Item	Data	Default setting	Unit
C130/C132/C134/C136/ C138/C140	Output ON delay	0.0 to 100.0: Set an ON delay time.	0.0	s
C131/C133/C135/C137/ C139/C141	Output OFF delay	0.0 to 100.0: Set an OFF delay time.	0.0	s

Input Terminal Response Time

- You can set a sampling time individually for multi-function input terminals 1 to 8 as well as the FW terminal. This helps remove chattering or other noise.
- If the terminal input becomes unstable because of chattering, increase the set value. The larger the data value is, the slower the response time. A setting range of 0 to 200 is available, which corresponds to approx. 2 to 400 ms.

Parameter No.	Function name	Data	Default setting	Unit
C160 to C167	Input terminal response time 1 to 8	0 to 200 (× 2 ms): Can be set in increments of 1.	1	ms
C168	FW terminal response time			

Digital FM Terminal


- You can monitor the output frequency and current using the FM terminal on the control circuit terminal block.
- The FM terminal provides pulse output.

■ FM Selection

- Select a signal to output from the following table.
For "03" (digital output frequency), use the digital frequency counter.
For other output signals, use the analog meter.

Parameter No.	Data	Description	Full-scale value
C027	00	Output frequency (example 1)	0 to Max. frequency (Hz) ^{*3}
	01	Output current (example 1)	0% to 200%
	02	Output torque (example 1) ^{*1}	0% to 200%
	03	Digital output frequency (example 2)	0 to Max. frequency (Hz)
	04	Output voltage (example 1)	0% to 100%
	05	Power (example 1)	0% to 200%
	06	Thermal load rate (example 1)	0% to 100%
	07	LAD frequency (example 1)	0 to Max. frequency (Hz)
	08	Digital current monitor	^{*2}
	09	Motor temperature	0°C to 200°C (0°C output at 0°C or lower)
	10	Fin temperature	0°C to 200°C (0°C output at 0°C or lower)
	12	Drive programming output (YA0)	-
	19	Option board 1 (OP1)	-
	20	Option board 2 (OP2)	-

*1. This output is enabled only when "SLV", "0-Hz SLV", or "V2" is selected. (Refer to "Control Method (V/f Characteristics)" (page 4-21).)



*2. Digital current monitor

- When the monitor displays the value set in digital current monitor reference value C030, 1440 Hz is output.

Parameter No.	Function name	Data	Default setting	Unit
C030	Digital current monitor reference value	0.20 × Rated current to 2.00 × Rated current (Under 55 kW) 0.20 × Rated current to 1.50 × Rated current (Over 75 kW) Set a current value at 1440-Hz output.	Rated current	A

*3. In any other method the real output frequency of the inverter including compensations (different than d001 value) is displayed.

■FM Adjustment

- Adjust the Inverter output gain according to the meter connected to the FM terminal.

Parameter No.	Function name	Data	Default setting	Unit
C105	FM gain setting	50 to 200: Set a gain for the FM monitor.	100	%
Related functions		C027, b081		

Analog Output AM/AMI Terminals

You can monitor the output frequency and current using the AM and AMI terminals on the control circuit terminal block.

The AM terminal provides 0- to 10-V analog output.

The AMI terminal provides 4- to 20-mA analog output.


■AM/AMI Selection

- Select a signal to output from the following table.

Parameter No.	Function name	Data	Default setting	Unit
C028/C029	AM selection/ AMI selection	00: Output frequency (0 to Max. frequency (Hz) ^{*3})	00	—
		01: Output current (0% to 200%)		
		02: Output torque ^{*1} (0% to 200%)		
		04: Output voltage (0% to 100%)		
		05: Power (0% to 200%)		
		06: Thermal load rate (0% to 100%)		
		07: LAD frequency (0 to Max. frequency [Hz])		
		09: Motor temperature (0°C to 200°C) (0°C output at 0°C or lower)		
		10: Fin temperature (0°C to 200°C) (0°C output at 0°C or lower)		
		11: Output torque (signed) (AM output only. 0% to 200% ^{*1 *2})		
		13: Drive programming output (YA1) (AM selection only)		
		14: Drive programming output (YA2) (AMI selection only)		
		19: Option board 1 (OP1) (AM selection only)		
		20: Option board 2 (OP2) (AM selection only)		

*1. This output is enabled only when "SLV", "0-Hz SLV", or "V2" is selected. (Refer to "Control Method (V/f Characteristics)" (page 4-21).)

*2. Below are the specifications of the output torque (signed).



*3. In any other method the real output frequency of the inverter including compensations (different than d001 value) is displayed.

■AM/AMI Adjustment

•Adjust the Inverter output gain according to the meters connected to the AM and AMI terminals.

Parameter No.	Function name	Data	Default setting	Unit
C106	AM gain setting	50 to 200: Set a gain for the AM monitor.	100	%
C109	AM bias setting	0 to 100: Set an offset for the AM monitor.	0	
C107	AMI gain setting	50 to 200: Set a gain for the AMI monitor.	100	
C110	AMI bias setting	0 to 100: Set an offset for the AMI monitor.	20	

Note: The offset data is set in %.

(Example) If AMI provides 4 to 20 mA output, the offset value is 20% (= 4/20). (Default value)

Operation Selection During Option Error

If the built-in optional board causes an error, you can set whether the Inverter trips or continues to run regardless of the option error.

Parameter No.	Function name	Data	Default setting	Unit
P001/P002	Operation selection at option error	00: Trip 01: RUN (Continues operation)	00	—

<Group H: Motor Control Parameters>

Offline Auto-Tuning Function

- This function enables measurement and automatic setting of the motor parameters required for "sensorless vector control", "0-Hz sensorless vector control", and "sensor vector control".
- To perform "sensorless vector control", "0-Hz sensorless vector control", or "sensor vector control" for a motor with unknown motor parameters, perform offline auto-tuning to determine the motor parameters.
- To use the online auto-tuning function described later, be sure to perform offline auto-tuning in advance.
- This function is applicable to 1st/2nd control, not to 3rd control.
- For motor parameters, the Inverter inputs data on one phase of Y-connection at 50 Hz.

Parameter No.	Function name	Data	Default setting	Unit
H001	Auto-tuning selection	00: OFF (Disabled) 01: ON (STOP) 02: ON (Rotation)	00	—
H002/H202	Motor parameter selection	00: Standard motor parameter 01: Auto-tuning parameter 02: Auto-tuning parameter (Online auto-tuning enabled.)	00	—
H003/H203	Motor capacity selection	0.20 to 160.00	Factory default	kW
H004/H204	Motor pole number selection	2/4/6/8/10	4	Pole
H030/H230	Motor parameter R1 (auto-tuning data)	0.001 to 65.535	Depends on the motor capacity.	Ω
H031/H231	Motor parameter R2 (auto-tuning data)	0.001 to 65.535	Depends on the motor capacity.	Ω

Parameter No.	Function name	Data	Default setting	Unit
H032/H232	Motor parameter L (auto-tuning data)	0.01 to 655.35	Depends on the motor capacity.	mH
H033/H233	Motor parameter IO (auto-tuning data)	0.01 to 655.35	Depends on the motor capacity.	A
H034/H234	Motor parameter J (auto-tuning data)	0.001 to 9999.000	Depends on the motor capacity.	kgm ²
A003	Base frequency	30 to Max. frequency	50	Hz
A051	DC injection braking selection	00: OFF (Disabled) 01: ON (Enabled) 02: ON (FQ) (Frequency control [A052 set value])	00	—
A082	AVR voltage selection	200/215/220/230/240: Selectable for 200-V class 380/400/415/440/460/480: Selectable for 400-V class	200/400	—

•Note the following before use:


- Set base frequency A003 and AVR voltage selection A082 according to the specifications of the motor to be measured.
- The motor parameters can be determined for motors with the maximum applicable capacity or one rank lower motor size. For motors with other capacities, correct constant data may not be obtained. (In some cases, auto-tuning may not be completed. In this case, pressing the STOP/RESET key displays an error message.)
- If DC injection braking selection A051 is set to "01" (enabled), the data cannot be measured correctly. Be sure to set to "00" (disabled). (The default setting is "00" (disabled).)
- If "02" (auto-tuning with motor rotation) is selected in auto-tuning selection H001, note the following:
 - Make sure there is no problem even if the motor accelerates up to approx. 80% of the base frequency.
 - The motor is not driven by external equipment.
 - The brake is released.
 - During auto-tuning, the output torque is insufficient, which may cause an elevator system to slip and fall. To prevent this, remove the motor from the load machine, and perform the auto-tuning for the motor separately. (In this case, moment of inertia (J) is determined for the single motor. You should add a motor shaft conversion value of the load machine's moment of inertia to parameter J.)
 - With a machine (e.g. lift, ball screw) whose motor shaft rotation is limited, the machine may be damaged if the allowable rotation limit is exceeded. In this case, set H001 to "01" (auto-tuning without motor rotation).
 - With a motor whose no-load current is unknown, measure the current at 50 Hz in the "V/f setting" mode, and perform auto-tuning after setting the current value in H023/H223.
- Even if "01" (auto-tuning without motor rotation) is selected in H001, the motor may slightly rotate.
- To perform auto-tuning for one rank lower motor size, enable the overload limit function and set the overload limit level to 1.5 times the rated current of the motor.

Operating Procedure

(1) Set auto-tuning selection H001 to "01" or "02".

(2) Turn on the RUN command.

Turning on the RUN command starts automatic operation in the following sequence.



Note 1: When "auto-tuning without motor rotation" is selected (H001 = 01), steps (4) and (5) are not performed.

Note 2: The rotation frequency in step (5) is defined as follows ("T" is whichever larger value of acceleration time or deceleration time in step (4)):

When $T \leq 0 < 50$ s, $x = 40\%$

When $50 \text{ s} \leq T < 100$ s, $x = 20\%$

When $100 \text{ s} \leq T$, $x = 10\%$

Note 3: If a trip occurs during auto-tuning, the auto-tuning processing is forced to stop.

(No error message appears. Trip display is given higher priority.)

After removing the cause of a trip, perform the auto-tuning again.

Note 4: If the auto-tuning is interrupted by STOP command input (by pressing the STOP key or by turning off the RUN command), the parameters for auto-tuning may remain in the Inverter. To perform the auto-tuning again, initialize the parameters, and then set each parameter again. (This also applies when you restart ordinary operation.)

Note 5: If the offline auto-tuning is performed with "free V/f setting" selected as the control method, the Inverter displays an error message and stops processing.

Note 6: Even if auto-tuning is completed normally, the Inverter cannot be operated with the tuning data. To do so, be sure to set motor parameter selection H002 to "01".

Online Auto-Tuning Function

- Online auto-tuning compensates for changes in motor parameters resulting from a motor temperature rise or other factor, thus ensuring stable operation.
- This function is applicable to 1st/2nd control, not to 3rd control.

Parameter No.	Function name	Data	Default setting	Unit
H002/H202	Motor parameter selection	00: Standard motor parameter 01: Auto-tuning parameter 02: Auto-tuning parameter (Online auto-tuning data enabled.)	00	—

Note the following before use:

- Be sure to perform the offline auto-tuning before the online auto-tuning.
- This function calculates online auto-tuning data during offline auto-tuning. Even with a general-purpose motor, perform offline auto-tuning once.
- After the motor is stopped, online auto-tuning is performed for 5 seconds max. (For tuning R1 and R2, this function performs DC excitation once. The tuning result is not displayed.) If the RUN command is input during this period, priority is given to the RUN command, and the online auto-tuning is aborted. (The tuning result is not reflected.)

- With "DC injection braking during stop" selected, online auto-tuning starts after DC injection braking is completed.
- If FOC and SON are allocated to terminals, online auto-tuning is not performed.

Operating Procedure

- (1) Set motor parameter selection H002 to "02" (online auto-tuning enabled).
(Set auto-tuning selection H001 to "00" (disabled).)
- (2) Turn on the RUN command. (The Inverter automatically performs online auto-tuning during stop.)

Secondary Resistance Compensation Function (Temperature Compensation)

- This function compensates for speed fluctuations resulting from motor temperature changes, when "sensorless vector control", "0-Hz sensorless vector control", or "sensor vector control" is selected as the control method.

To use this function, set thermistor selection b098 to "02" (NTC).

(With other thermistors and settings, the motor temperature cannot be detected correctly.)

Parameter No.	Function name	Data	Default setting	Unit
P025	Secondary resistance compensation enable/disable selection	00: OFF (Disabled) 01: ON (Enabled)	00	—

Motor Parameter Selection

- Set this parameter according to your motor.
- To use several motors with a single Inverter in the "VC", "special VP", or "free V/F setting" control mode, calculate the total capacity of the motors and select the closest value in the motor capacity selection.
- When automatic torque boost is used, improper setting of this parameter may result in torque reduction or motor hunting.
- The motor parameters for "sensorless vector control", "0-Hz sensorless vector control", or "sensor vector control" can be selected from the following three types:
 - Motor parameter of a standard motor
 - Motor parameter measured by offline auto-tuning
 - Arbitrarily set motor parameter
- For 3rd control, motor parameters specified for 1st control are used.

Parameter No.	Function name	Data	Default setting	Unit
A044/A244/ A344	V/f characteristics selection	00: VC (Constant torque characteristics) 01: VP (Special reduced torque characteristics) 02: Free V/f (characteristics) *1 03: SLV (Sensorless vector control) *1 04: 0SLV (0-Hz sensorless vector control) *1 05: V2 (Sensor vector control) *1	00	—
H002/H202	Motor parameter selection	00: Standard motor parameter 01: Auto-tuning parameter 02: Online auto-tuning parameter	00	—
H003/H203	Motor capacity selection	0.2 to 160.0	Factory default	kW
H004/H204	Motor pole number selection	2/4/6/8/10	4	Pole
H020/H220	Motor parameter R1	0.001 to 65.535	Depends on the motor capacity.	Ω
H021/H221	Motor parameter R2	0.001 to 65.535	Depends on the motor capacity.	Ω
H022/H222	Motor parameter L	0.01 to 655.35	Depends on the motor capacity.	mH
H023/H223	Motor parameter IO	0.01 to 655.35	Depends on the motor capacity.	A
H024/H224	Motor parameter J	0.001 to 9999.000 *2	Depends on the motor capacity.	kgm ²
H030/H230	Motor parameter R1 (auto-tuning data)	0.001 to 65.535	Depends on the motor capacity.	Ω
H031/H231	Motor parameter R2 (auto-tuning data)	0.001 to 65.535	Depends on the motor capacity.	Ω
H032/H232	Motor parameter L (auto-tuning data)	0.01 to 655.35	Depends on the motor capacity.	mH
H033/H233	Motor parameter IO (auto-tuning data)	0.01 to 655.35	Depends on the motor capacity.	A
H034/H234	Motor parameter J (auto-tuning data)	0.001 to 9999.000 *2	Depends on the motor capacity.	kgm ²

*1. For 1st control A044, all items (00 to 05) are selectable. However, for 2nd control A244 and 3rd control A344, the selectable range is 00 to 04, and 00 to 01, respectively. For ND the selectable range is 00 to 02.

*2: Convert moment of inertia J into motor shaft data. The larger the J value, the faster the response, resulting in a steep torque rise; the smaller the J value, the slower the response, resulting in a gradual torque rise. After setting the J value, adjust the response speed in speed response H005/H205.

Arbitrary Motor Parameter

- For arbitrary settings of motor parameters, the function codes vary depending on the setting of 1st/2nd control and on the set value of the motor parameter selection.
 - When 1st/2nd control is enabled and the motor parameter selection is set to "00" → Directly enter H020 to H024.
 - When 1st/2nd control is enabled and the motor parameter selection is set to "01" or "02" → Directly enter H030 to H034.
- If offline auto-tuning has not been performed, the motor parameters in the same capacity rank as the Inverter (standard motor parameters) are set in H030/H230 to H034/H234.

Sensorless Vector Control

- This function estimates and controls motor rpm and output torque based on the Inverter's output voltage and current, as well as the motor parameter settings. This control method provides high starting torque in a low-frequency range (0.3 Hz), enabling high-precision operation.
- To use this function, set V/f characteristics selection A044/A244 to "03".
- To use this function, make sure that the motor parameter settings are suitable for your motor. (Refer to "Motor Parameter Selection" (page 4-115)).
- Note the following before use:
 - Sufficient characteristics may not be obtained if you select a motor size two or more ranks lower than the motor size specified.
 - If sensorless vector control cannot provide the desired characteristics, adjust the motor parameters depending on the phenomena, as shown in the table below.

Operation status	Phenomenon	Adjusting method	Adjustment item
Power running	Speed change ratio is a negative value.	Increase motor parameter R2 gradually (up to set parameter × 1.2).	H021/H221/H031
	Speed change ratio is a positive value.	Reduce motor parameter R2 gradually (down to set parameter × 0.8).	H021/H221/H031
Regeneration	Insufficient torque at low frequency (several Hz)	Increase motor parameter R1 gradually (up to set parameter × 1.2).	H020/H220/H030
		Increase motor parameter I _o gradually (up to set parameter × 1.2).	H023/H223/H033
During startup	Shock occurs during startup.	Reduce motor parameter J from the set parameter.	H024/H224/H034
During deceleration	Motor hunting	Reduce the speed response.	H005/H205
		Reduce motor parameter J from the set parameter.	H024/H224/H034
During torque limit	Insufficient torque at low frequency during torque limit	Set a overload limit level lower than that of the torque.	b021 b041 to b044
Low-frequency operation	Rotation is not constant.	Increase motor parameter J from the set parameter.	H024/H224/H034
Related functions		A001, A044/A244, F001, b040, b041 to b044, H002/H202, H003/H203, H004/H204, H005/H205, H020/H220, H021/H221, H022/H222, H023/H223, H024/H224, H050/H250, H051/H251, H052/H252	

Note 1: Make sure that the carrier frequency (b083) is not lower than 2.1 kHz. If the carrier frequency is lower than 2.1 kHz, the Inverter does not operate normally.

Note 2: To use lower rank motor size than the Inverter, set a torque limit value (b041 to b044), while keeping the value α , calculated with the following formula, at 200% or lower. Otherwise, the motor may burn out.

$$\alpha = \text{Torque limit set value} \times (\text{Inverter capacity}) / (\text{Motor capacity})$$

(Example) If the Inverter capacity is 0.75 kW and the motor capacity is 0.4 kW, the torque limit set value for $\alpha = 200\%$, calculated with the above formula, is as follows: Torque limit set value (b041 to b044) = $\alpha \times (\text{Motor capacity}) / (\text{Inverter capacity}) = 200\% \times (0.4 \text{ kW}) / (0.75 \text{ kW}) = 106\%$

0-Hz Sensorless Vector Control

- This function enables high-torque operation in the 0-Hz range (0- to 3-Hz frequency reference). This control method is particularly suitable for applications such as an elevating system, which requires sufficient torque in a low-frequency range at startup (e.g. crane, hoist).
- To use this function, set V/f characteristics selection A044/A244 to "04".
- To use this function, make sure that the motor parameter settings are suitable for your motor. (Refer to "Motor Parameter Selection" (page 4-115).)
- The parameters for 0-Hz SLV control are as follows:
 - In 0-Hz limit H060/H260, you can set a current value used for constant current control in the 0-Hz range (generally, 3.0 Hz or lower). This parameter is expressed as a ratio of the output current to the Inverter's rated current.
 - In 0-Hz SLV startup boost amount H061/H261, you can set a current boost amount at startup in the 0-Hz range. A current value expressed as a ratio to the Inverter's rated current is added to the current value set in H060/H260 at startup only.

Parameter No.	Function name	Data	Default setting	Unit
H060/H260	Limit at 0 Hz	0.0 to 100.0: Current limit in low frequency range	100.0	%
H061/H261	Boost amount at SLV startup, 0 Hz	0 to 50: Current boost amount at startup	50	%

- Note the following before use:
 - Select an Inverter with one rank higher in capacity than the motor's.
 - Sufficient characteristics may not be obtained if you select a motor size two or more ranks lower than the maximum applicable motor size.
 - In the 0-Hz sensorless control mode, the digital command board (3GAX-DI01) cannot be used.
 - If 0-Hz sensorless vector control cannot provide the desired characteristics, adjust the motor parameters depending on the phenomena, as shown in the table below.

Operation status	Phenomenon	Adjusting method	Adjustment item
Power running	Speed change ratio is a negative value.	Increase motor parameter R2 gradually (up to set parameter $\times 1.2$).	H021/H221/H031
	Speed change ratio is a positive value.	Reduce motor parameter R2 gradually (down to set parameter $\times 0.8$).	H021/H221/H031
Regeneration	Insufficient torque at low frequency (several Hz)	Increase motor parameter R1 gradually (up to set parameter $\times 1.2$).	H020/H220/H030
		Increase motor parameter I _o gradually (up to set parameter $\times 1.2$).	H023/H223/H033
During startup	Shock occurs during startup.	Reduce motor parameter J from the set parameter.	H024/H224/H034
During deceleration	Motor hunting	Reduce the speed response.	H005/H205
		Reduce motor parameter J from the set parameter.	H024/H224/H034
Immediately after deceleration	Overcurrent or overvoltage protection is activated.	Reduce motor parameter I _o gradually (down to set parameter $\times 0.8$).	H023/H223/H033
		Set AVR selection A081 to "00" (always ON) or "01" (always OFF).	A081
Low-frequency operation	Rotation is not constant.	Increase motor parameter J from the set parameter.	H024/H224/H034
Related functions		A001, A044/A244, F001, b040, b041 to b044, H002/H202, H003/H203, H004/H204, H005/H205, H020/H220, H021/H221, H022/H222, H023/H223, H024/H224, H050/H250, H051/H251, H052/H252, H060/H260, H061/H261	

Note 1: Make sure that the carrier frequency (b083) is not lower than 2.1 kHz. If the carrier frequency is at 2.1 kHz or lower, the Inverter does not operate normally.

Note 2: Set a torque limit value (b041 to b044), while keeping the value α , calculated with the following formula, at 200% or lower. Otherwise, the motor may burn out.

$$\alpha = \text{Torque limit set value} \times (\text{Inverter capacity}) / (\text{Motor capacity})$$

(Example) If the Inverter capacity is 0.75 kW and the motor capacity is 0.4 kW, the torque limit set value for $\alpha = 200\%$, calculated with the above formula, is as follows: Torque limit set value (b041 to b044) = $\alpha \times (\text{Motor capacity}) / (\text{Inverter capacity}) = 200\% \times (0.4 \text{ kW}) / (0.75 \text{ kW}) = 106\%$

Torque Monitor Function


- This function allows you to monitor an estimated motor output torque, when "sensorless vector control", "0-Hz sensorless vector control", or "sensor vector control" is selected as the control method.

Parameter No.	Function name	Data	Default setting	Unit
A044/A244	V/f characteristics selection	03: SLV (Sensorless vector control) 04: OSLV (0-Hz sensorless vector control) 05: V2 (Sensor vector control)	00	—
C027 C028 C029	FM selection AM selection AMI selection	02: Output TRQ (Output torque) 11: Out TRQ sign (Output torque (signed)) (C028 only)	00	—
H003/H203	Motor capacity selection	0.20 to 160.0	Factory default	kW
H004/H204	Motor pole number selection	2/4/6/8/10	4	Pole

- To use the monitor via the Digital Operator, select display code d012.
- To use the monitor with a signal from the control terminal block, refer to "Digital FM Terminal" (page 4-109) or "Analog Output AM/AMI Terminals" (page 4-110).
- If "VC", "special VP", or "free V/f setting" is selected in V/f characteristics selection A044/A244, this function is disabled, and the display or the output signal from the control terminal block is not defined.
- For a torque monitor value of this function, the output torque at the rated frequency equivalent to the motor's output rating during synchronous rotation is indicated as 100%.
- Since this function estimates output torque based on the motor current, the accuracy is approx. 20% when a motor with the same output capacity as the Inverter is used.

Preliminary Excitation Function (FOC)

- This function supplies excitation current from an input terminal to establish magnetic flux preliminarily, when "03" (sensorless vector control), "04" (0-Hz sensorless vector control), or "05" (sensor vector control) is selected in V/f characteristics selection A004/A244.
- Allocate 55 (FOC) to the desired multi-function input.
- The Inverter does not accept the RUN command unless the FOC terminal is turned on when FOC is allocated.
- If the FOC terminal is turned off during operation, the Inverter goes into free-run status. If the FOC terminal is turned on again, the Inverter restarts according to the setting of free-run stop selection b088.



Related functions	A044/A244, C001 to C008
-------------------	-------------------------

High-torque Multi-operation

- When "sensorless vector control" or "0-Hz sensorless vector control" is selected with a single Inverter, this function controls two motors of the same type to drive a single load.
- To use this function, you set the same parameters as when you select "Sensorless Vector Control" (page 4-116) or "0-Hz Sensorless Vector Control" (page 4-117). However, set the motor parameters as follows:
 - Set motor parameters R1, R2, and L to one half of the set value for one motor.
 - Set motor parameter Io to be twice the set value for one motor.
 - Set motor parameter J to one half of the total moment of inertia of two motors and loads connected to these motors.
 - Select the motor capacity value closest to the total capacity of two motors.
- When different loads are driven with two motors, a fluctuation in one load affects the operating condition of the other, which may hinder normal control.
To prevent this, be sure to operate a system in a way that the load driven by two motors is regarded as one load.

Related functions	A044/A244, F001, b040, b041 to b044, H002/H202, H003/H203, H004/H204, H005/H205, H020/H220, H021/H221, H022/H222, H023/H223, H024/H224, H050/H250, H051/H251, H052/H252
-------------------	---

Stabilization Parameter

- This function adjusts to reduce motor hunting.
- In case of motor hunting, check whether motor capacity H003/H203 and motor pole number selection H004/H204 match your motor. If they do not, match them. If the motor's primary resistance is smaller than that of the standard motor, increase the H006/H206/H306 set value gradually. To run a motor with a capacity larger than the Inverter's rated capacity, reduce the set value.
- Other than this function, the following methods are suggested to reduce hunting:
 Lower the carrier frequency (b083). (Refer to page 4-68.)
 Lower the output voltage gain (A045). (Refer to page 4-24.)

Parameter No.	Function name	Data	Default setting	Unit
H006/H206/H306	Stabilization parameter	0 to 255: If hunting occurs, adjust the set value.	100	—
A045	Output voltage gain	20 to 100: If hunting occurs, reduce the set value.	100	%
b083	Carrier frequency	0.5 to 15.0: If hunting occurs, reduce the set value.	5.0	kHz

Auto Return Initial Display

- Ten minutes after last key operation display returns to the initial parameter set by b038.

Parameter No.	Function name	Data	Default setting
b164	Auto return initial display	00: OFF (Disabled) 01: ON (Enabled)	00

Data Read/Write Selection

- Restrict the data read/write operation by 3G3AX-OP05.

Parameter No.	Function name	Data	Default setting
b166	Data read/write selection	00: R/W OK (Read/Write OK) 01: R/W Protected (Read/Write protected)	00

Option I/F cmd W Register 1 to 10

- When communication option board is used these parameters are used to define a user exchange area with the master unit. Refer to specific option board manual for details.

Parameter No.	Function name	Data	Default setting
P160 to P169	Option I/F cmd W register 1 to 10	0000 to FFFF	0000

Option I/F cmd R Register 1 to 10

- When communication option board is used these parameters are used to define a user exchange area with the master unit. Refer to specific option board manual for details.

Parameter No.	Function name	Data	Default setting
P170 to P179	Option I/F cmd R register 1 to 10	0000 to FFFF	0000

Profibus Communications

- Use these parameters to define the node address and communication type when 3G3AX-RX-PRT Profibus unit is used.

Parameter No.	Function name	Data	Default setting
P180	Profibus node address	0 to 125	-
P181	Profibus clear mode	00: Clear 01: Last value	00
P182	Profibus map selection	00: PPO 01: Conventional 02: Flexible mode	00

CompoNet Communications

- Use these parameters to configure CompoNet network when 3G3AX-RX-CRT CompoNet unit is used.

Parameter No.	Function name	Data	Default setting
P045	Operation setting at communications error	00: Trip 01: Decel-Trip (Trip after deceleration stop) 02: Ignore 03: Free run 04: Decel-Stop (Deceleration stop)	00
P046	Instance Number	0: Basic speed I/O 1: Extended speed I/O 2: Extended speed and Torque control 3: Special I/O 4: Extended control I/O 5: Extended control I/O and multifunction I/O monitor 6: Flexible format 7: Extended speed and Acceleration control 8-20: Not used	1
P048	Operation setting at idle mode detection	00: Trip 01: Decel-Trip (Trip after deceleration stop) 02: Ignore 03: Free RUN 04: Decel-Stop (Deceleration stop)	00
P190	CompoNet node address	0 to 63	0

DeviceNet Communications

•Use these parameters to configure DeviceNet network when 3G3AX-RX-DRT unit is used.

Parameter No.	Function name	Data	Default setting
P044	DeviceNet comm Watch dog timer	0.00 to 99.99	1.00
P045	Operation setting at communications error	00: Trip 01: Decel-Trip (Trip after deceleration stop) 02: Ignore 03: Free RUN 04: Decel-Stop (Deceleration stop)	00
P046	Instance Number	0: Basic speed I/O 1: Extended speed I/O 2: Extended speed and Torque control 3: Special I/O 4: Extended control I/O 5: Extended control I/O and multifunction I/O monitor 6: Flexible format 7: Extended speed and Acceleration control 8-20: Not used	1
P048	Operation setting at idle mode detection	00: Trip 01: Decel-Trip (Trip after deceleration stop) 02: Ignore 03: Free RUN 04: Decel-Stop (Deceleration stop)	00
P049	Polarity setting for rotation speed	0/2/4/6/8/10/12/14/16/18/20/22/24/26/28/ 30/32/34/36/38	0
P192	DeviceNet node address	0 to 63	63

MECHATROLINK-II Communications

•Use these parameters to configure the MECHATROLINK-II network when 3G3AX-RX-MRT unit is used.

Parameter No.	Function name	Data	Default setting
P195	ML2 frame length	00: 32 bytes 01: 17 bytes	00
P196	ML2 node address	21 to 3E	21

4-3 Functions When PG Option Board (3G3AX-PG01) Is Used

Functions That Need 3G3AX-PG01

- Generally, the Feedback Option Board (3G3AX-PG01) is required for the following two cases:
 - "05" (V2: sensor vector control) is selected in V/f characteristics selection A044.
 - "Pulse train frequency input" is selected in any of the following parameters:
- "06" (pulse train frequency) is selected in frequency reference selection A001.
- With "10" (operation function result) selected in frequency reference selection A001, "07" (pulse train frequency) is selected in operation frequency input A setting (A141) or operation frequency input B setting (A142).
- "03" (pulse train frequency) is selected in PID feedback selection A076.
- When running the Inverter with V/f characteristics selection A044 set to "00" (VC), you can check the rotation direction with real frequency monitor d008.
(If positive frequency is detected when the forward command is activated, or if negative frequency is detected when the reverse command is activated, the rotation direction is judged as being normal.)

Related functions	A044, A001, A076, A141, A142
-------------------	------------------------------

V2 Control Mode Selection

Select a control method in V2 control mode selection P012.

When "00" (ASR) is selected in P012, speed control mode is enabled. Select a frequency reference in frequency reference selection A001.

When "01" (APR) is selected in P012, the Inverter enables position control by generating frequency reference based on the position command pulse input from the pulse train position command input terminal, and on the position feedback detected by the encoder.

Select any of the three pulse train position command input modes in pulse train mode selection P013.

To perform pulse train position control, allocate "48" (STAT) to any of the multi-function input terminals. While the STAT terminal is tuned on, pulse train position command input is accepted.

Position deviation can be cleared through external input. Allocate "47" (PCLR) to any of the multi-function input terminals. Turning on and then off the PCLR terminal can clear position deviation data. Allocate "22" (DSE) to any of the multi-function output terminals to enable excessive speed deviation signal output.

Set a deviation level in speed deviation error detection level P027. When the deviation between real frequency and reference frequency exceeds the P027 set value, the DSE signal turns on.

When "02" (APR2) or "03" (HAPR) is selected in P012, the Inverter performs absolute position control with reference to the absolute position from its origin.

Parameter No.	Function name	Data	Default setting	Unit
P012	V2 control mode selection	00: ASR (speed control mode) 01: APR (pulse train position control mode) 02: APR2 (absolute position control mode) 03: HAPR (high-resolution absolute position control mode)	00	—
P011	Encoder pulses	128 to 65535: Number of encoder pulses	1024	Pulse
P023	Position loop gain	0.00 to 100.00: Position loop gain	0.50	rad/s
P027	Speed deviation error detection level	0.00 to 120.00: DSE signal output level	7.50	Hz
H004	Motor pole number selection	2/4/6/8/10: Select the number of motor poles.	4	Pole
C001 to C008	Multi-function inputs 1 to 8 selection	47: PCLR (position deviation clear) 48: STAT (pulse train position command input permission)	—	—
C021 to C025	Multi-function output terminals 11 to 15 selection	22: DSE (excessive speed deviation)	—	—
C026	Relay output (AL2, AL1) function selection		05	
Related functions		A001, P013		

Sensor Vector Control (Speed Control)

To use this function, set V/f characteristics selection A044 to "05" (V2), and V2 control mode selection P012 to "00" (speed control).

("Sensor vector control" can be selected for 1st control only.)

To use this function, make sure that the motor parameter settings are suitable for your motor. Refer to Inverter model RX user's manual "Chapter 4 Functions, 4-2 Function Mode, Motor Parameter Selection".

Also, be sure to set the number of your encoder pulses.

With V2 control mode selection P012, you can select four types of control modes: Speed control, Pulse train position control, Absolute position control, and High-resolution absolute position control. Note the following before use:

- Sufficient characteristics may not be obtained if you select a motor size two or more ranks lower than the maximum applicable motor size.
- If the Inverter does not normally accelerate, or if overload protection is activated, check the phase order of the encoder signal.

(If phase A is advanced by 90° from phase B during forward run, it is judged as being normal.)

When running the Inverter with V/f characteristics selection A044 set to "00" (VC), you can check the rotation direction with real frequency monitor d008.

(If positive frequency is detected when the forward command is activated, or if negative frequency is detected when the reverse command is activated, the rotation direction is judged as being normal.)

If sensor vector control cannot provide the desired characteristics, adjust the motor parameters depending on the phenomena, as shown in the table below.

Operation status	Phenomenon	Adjusting method	Adjustment item
During startup	Shock occurs during startup.	Reduce motor parameter J from the set parameter.	H024/H034
During deceleration	Motor hunting	Reduce the speed response.	H005
		Reduce motor parameter J from the set parameter.	H024/H034
During torque limit	Insufficient torque at low frequency during torque limit	Set a overload limit level lower than that of the torque.	b021 b041 to b044
Low-frequency operation	Rotation is not constant.	Increase motor parameter J from the set parameter.	H024/H034
Related functions		A001, A044, F001, b040, H002, H003, H004, H020, H021, H022, H023, H050, H051, H052, P011, P012	

Note 1: Make sure that the carrier frequency (b083) is not lower than 2.1 kHz. If the carrier frequency is at 2.1 kHz or lower, the Inverter does not operate normally.

Note 2: To use a lower rank motor size than the Inverter, set a torque limit value (b041 to b044), while keeping the value α , calculated with the following formula, at 200% or lower. Otherwise, the motor may burn out.
 $\alpha = \text{Torque limit set value} \times (\text{Inverter capacity}) / (\text{Motor capacity})$

(Example) If the Inverter capacity is 0.75 kW and the motor capacity is 0.4 kW, the torque limit set value for $\alpha = 200\%$, calculated with the above formula, is as follows:

$$\begin{aligned} \text{Torque limit set value (b041 to b044)} &= \alpha \times (\text{Motor capacity}) / (\text{Inverter capacity}) \\ &= 200\% \times (0.4 \text{ kW}) / (0.75 \text{ kW}) = 106\% \end{aligned}$$

Torque Bias Function

This function applies bias to the torque reference generated by speed control, and is useful for elevating applications (e.g. elevator).

Parameter No.	Function name	Data	Default setting	Unit
P036	Torque bias mode	00: OFF (Disabled) 01: OPE (Digital Operator) 02: O2 (Terminal O2) * ¹ 05: Option 1 06: Option 2	00	—
P037	Torque bias value	-200 to 200 (0.4 to 55 kW) -180 to 180 (75 to 132 kW) Enabled when P036 = 01	0	%
P038	Torque bias polarity selection * ²	00: Sign (Signed) 01: Direction (Depends on the RUN direction)	00	—
Related functions	d010			

*1. When torque bias is set to the O2 terminal, -10 to +10 (V) is recognized as -200 to +200 (%).

*2. • When "00" (As per sign) is selected:

When the polarity of a torque bias signal is (+), the torque increases for forward rotation, and when it is (-), the torque increases for reverse rotation, regardless of the RUN direction.

• When "01" (Depends on the RUN direction) is selected:

The torque bias signal polarity and torque bias direction vary depending on the RUN command direction.

Forward command: Applies torque in the same direction as the torque bias.

Reverse command: Applies torque in the opposite direction of the torque bias.

Torque Control

Under this function, the Inverter can be used in torque control, as well as in the speed and pulse train position controls.

Torque control can be applied to winders, and more.

To run the Inverter in torque control mode, allocate "52" (ATR) to any of the multi-function inputs. While the ATR terminal is turned on, the torque reference input is enabled.

In torque reference input selection P033, you can select one of the three analog inputs or the input via the Digital Operator.

The torque control speed depends on the balance between torque and load. To prevent the Inverter from running out of control, set a speed limit value in P039 (forward) or P040 (reverse).

Parameter No.	Function name	Data	Default setting	Unit
P033	Torque reference input selection	00: O (Terminal O) 01: OI (Terminal OI) 02: O2 (Terminal O2) 03: OPE (Digital Operator) 06: Option 1 07: Option 2	00	—
P034	Torque reference setting	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) Torque reference when P033 = 03	0	%
P035	Polarity selection at torque reference via O2	00: Sign (Signed) 01: Direction (Depends on the RUN direction)	00	-


4-3 Functions When PG Option Board (3G3AX-PG01) Is Used

4

Functions

Parameter No.	Function name	Data	Default setting	Unit
P039	Speed limit value in torque control (forward)	0.00 to Maximum frequency	0.00	Hz
P040	Speed limit value in torque control (reverse)	0.00 to Maximum frequency	0.00	Hz
P036	Torque bias mode	00: OFF (None) 01: OPE (Digital Operator) 02: O2 (Terminal O2) 05: Option 1 06: Option 2	00	—
P037	Torque bias value	-200 to +200 (0.4 to 55 kW) -180 to +180 (75 to 132 kW) Enabled when P036 = 01	0	%
P038	Torque bias polarity selection	00: Sign (Signed) 01: Direction (Depends on the RUN direction)	00	—
C001 to C008	Multi-function inputs 1 to 8 selection	52: ATR (torque command input permission)	—	—
Related functions	d009, d010, d012			

Control Block Diagram



Pulse Train Position Control Mode

To use this function, set V/f characteristics selection A044 to "05" (V2), and V2 control mode selection P012 to "01" (pulse train position control).

("Sensor vector control" can be selected for 1st control only.)

Select a pulse train position command input mode in pulse train mode selection P013.

Parameter No.	Function name	Data	Default setting	Unit
P012	V2 control mode selection	01: APR (pulse train position control mode)	00	—
P013	Pulse train mode selection	00: Mode 1 (pulse train with 90° phase difference) 01: Mode 2 (forward/reverse command + pulse train) 02: Mode 3 (forward pulse train + reverse pulse train)		

Parameter No.	Function name	Data	Default setting	Unit
P017	Position ready range setting	0 to 10000: Set a value equivalent to encoder ×4 multiplication.	5	—
P018	Position ready delay time setting	0.00 to 9.99	0.00	s
P019	Electronic gear setting position selection	00: FB (Position feedback side) 01: REF (Position command side)	00	—
P020	Electronic gear ratio numerator	1 to 9999	1	—
P021	Electronic gear ratio denominator	1 to 9999	1	—
P022	Position control feedforward gain	0.00 to 655.35	0.00	—
P023	Position loop gain	0.00 to 100.00	0.50	rad/s
P024	Position bias amount	-2048 to 2048	0	rad/s
C001 to C008	Multi-function inputs 1 to 8 selection	47: PCLR (position deviation clear) 48: STAT (pulse train position command input permission)	—	—

Frequency reference for the pulse train position control mode is calculated with the following formula:

$$\text{Frequency reference (Hz)} = \frac{6.4 \times P \times K_v}{\text{ENC}} \times \frac{\Delta P}{255}$$


P : Number of motor poles
K_v : Position loop gain
ENC : Number of encoder pulses
ΔP : Position deviation

In the position control mode, the acceleration/deceleration time settings are disabled. (The Inverter is automatically brought into LAD cancel status.)


The higher the position loop-back gain, the shorter the acceleration/deceleration time.

For details on the pulse train input mode, refer to the following.


•Mode 0: Pulse train with 90° phase difference



•Mode 1: Forward/Reverse command + Pulse train



•Mode 2: Forward pulse train + Reverse pulse train




Electronic Gear Function

This function allows you to set a gain relative to position command or position feedback and to change the main/sub motor rotation ratio, particularly for synchronous operation.


Parameter No.	Function name	Data	Default setting	Unit
P019	Electronic gear setting position selection	00: FB (Position feedback side) 01: REF (Position command side)	00	—
P020	Electronic gear ratio numerator *3	1 to 9999	1	—
P021	Electronic gear ratio denominator *3	1 to 9999	1	—
P022	Position control feedforward gain *1	0.00 to 655.35	0.00	—
P023	Position loop gain *2	0.00 to 100.00	0.50	rad/s

Note: Below are the block diagrams of the electronic gear function.



- *1. It is recommended that position control feedforward gain adjustment should be started with P022 = 2.00. To reduce the position deviation between the main and sub motors, increase the feedforward gain. If motor hunting occurs, reduce the feedforward gain.
- *2. It is recommended that position loop gain adjustment should be started with P023 = 2.00. To increase positioning accuracy and holding power, increase the position loop gain. If an increased position loop gain causes hunting, reduce the position loop gain.
- *3. Make sure that the N/D setting is within the range of $1/50 \leq N/D \leq 20$.
(N: Electronic gear ratio numerator [P020], D: Electronic gear ratio denominator [P021])

Example: Synchronous Operation



For the Inverter (master Inverter) on the main motor side, you can select either the speed control or pulse train position control mode.
For the Inverter (slave Inverter) on the sub motor side, you need to select the pulse train position control mode.

Configuration Example

- Main motor : Number of encoder pulses = 1024
- Sub motor : Number of encoder pulses = 3000
- Main motor rpm:Sub motor rpm = 2:1

For operation under the above conditions, set the following data in the slave Inverter.

Pulse train mode selection (P013) : 00 (pulse with 90° phase difference)
Electronic gear setting position selection (P019) : 01 (REF)
Electronic gear ratio numerator (P020) : 3000
Electronic gear ratio denominator (P021) : $1024 \times 2 = 2048$

The following shows an example of the ratio of slave rpm to master rpm depending on the P019 to P021 settings.

(Note that the same number of encoder pulses (1024 pulses) should be set on both Inverters.)


Electronic gear setting position selection (P019)	REF (Position command side)	REF (Position command side)	FB (Position feedback side)	FB (Position feedback side)
Electronic gear ratio numerator (P020)	1024	2048	1024	2048
Electronic gear ratio denominator (P021)	2048	1024	2048	1024
Slave rpm/Master rpm	1/2	2	2	1/2

Configuration Example


- Main motor : Number of encoder pulses = 1024
- Sub motor : Number of encoder pulses = 3000
- Main motor rpm:Sub motor rpm = 2:1

For operation under the above conditions, set the following data in the slave Inverter.

Electronic gear setting position selection (P019) : 01 (REF)
Electronic gear ratio numerator (P020) : 3000
Electronic gear ratio denominator (P021) : $1024 \times 2 = 2048$



Electronic gear setting position = 00(FB) selected



Electronic gear setting position =01(REF) selected

Motor Gear Ratio Setting Function

This function is useful for a system with an optional encoder installed on the machine side.

Set the number of actual encoder pulses in encoder pulses P011.

Set a motor-to-encoder rpm ratio in motor gear ratio numerator/denominator P028/P029.

With the above settings, the number of encoder pulses converted into motor shaft data is set in the Inverter.


This function performs speed/position detection based on the number of encoder pulses converted into motor shaft data and calculates the orientation stop position based on the number of encoder pulses (P011).

Parameter No.	Function name	Data	Default setting	Unit
P028	Motor gear ratio numerator	1 to 9999 Set a motor-to-encoder rpm ratio.	1	—
P029	Motor gear ratio denominator			
P011	Encoder pulses	128 to 65535 Set the number of actual encoder pulses.	1024	Pulse

Note: Make sure that the N/D setting is within the range of $1/50 \leq N/D \leq 20$.

(N: Motor gear ratio numerator, D: Motor gear ratio denominator)

<Example>



•When the motor-to-encoder rpm ratio is 1:10, set the following data:

Number of encoder pulses (P011) : 1024

Motor gear ratio numerator (P028) : 10

Motor gear ratio denominator (P029) : 100

In this case, the orientation stop position is defined as 4096 divisions of the encoder's one rotation.

Note that the concept of the stop position is inverted from the description in "Orientation stop position conceptual drawing" (page 4-135).

Position Bias Function

Set this function to apply position command bias in the pulse train position control mode.

The set number of pulses is added to a change value at 2-ms intervals. This is used for adjusting the phase of synchronization points during synchronous operation.

Set an addition value in position bias amount P024. A positive value adds the value in the forward direction.


Related functions	P024
-------------------	------

Speed Bias Function

This function applies speed command bias in the pulse train position control mode.

Set a bias value in frequency addition amount A145, and select a sign in frequency addition direction A146.

Allocate 50 (ADD) to any of the multi-function inputs. While the ADD terminal is turned on, the bias value is added to the speed command.




Related functions	A145, A146
-------------------	------------

Orientation Function

This function determines a motor position at a single desired point during one rotation of the motor, and can be used to exchange tools for the machine tool main spindle or others.

During positioning, the Z-pulse (one rotation position signal) is used as the reference signal. Input Z-pulse between EZP and EZN.


Parameter No.	Function name	Data	Default setting	Unit
P011	Encoder pulses	128 to 65535 (10000 to 65530)	1024	Pulse
P014	Orientation stop position	0 to 4095	0	—
P015	Orientation speed setting	Setting frequency to Max. frequency (upper limit: 120.0)	5.00	Hz
P016	Orientation direction setting	00: FWD (Forward side)	00	
		01: REV (Reverse side)		
P017	Position ready range setting	0 to 10000	5	Pulse
P018	Position ready delay time setting	0.00 to 9.99	0.00	s
P023	Position loop gain	0.00 to 100.00	0.50	rad/s
C001 to C008	Multi-function inputs 1 to 8 selection	45: ORT (orientation)	—	—
C021 to C025	Multi-function output terminal 11 to 15 selection	23: POK (position ready)	—	
C026	Relay output (AL2, AL1) function selection		05	



- (1) When the RUN command is turned on with the ORT terminal turned on, the Inverter accelerates to the orientation speed (P015), and then performs constant speed operation.
(If the RUN command is turned on during operation, the operation speed changes to the orientation speed when the ORT terminal is turned on.)
- (2) After the orientation speed is reached, the Inverter shifts to the position control mode when the first Z-pulse is detected.
- (3) During forward run, position control is performed with a target value of "Orientation stop position (P014) + one rotation"; During reverse run, with a target value of "Orientation stop position (P014) + two rotations".
In this step, the higher the position loop gain (P023), the shorter the deceleration time (regardless of the deceleration time setting).
- (4) After the remaining number of pulses reaches the position ready range setting (P017), the Inverter outputs the POK signal after the position ready delay time setting (P018) elapses. (The POK output remains until the ORT signal is turned off.)
After positioning is completed, the servo lock status remains until the RUN command is turned off.

Note 1: Do not set a high frequency for the orientation speed, because positioning must be completed within two rotations during deceleration. Otherwise, overvoltage protection may cause a trip.

Note 2: Orientation stop position is defined as 4096 (0 to 4095) divisions of one forward rotation from the reference point. (The number of divisions is fixed to 4096, regardless of the encoder's number of pulses.) The reference point is defined as the point where the pulse is input between EZP and EZN. Below is the layout of the stop target position. (Positive-phase connection)



Absolute Position Control Mode


- To use this function, set V/f characteristics selection A044 to "05" (V2), and V2 control mode selection P012 to "02" (APR2: Absolute position control).
- When "03" (high-resolution absolute position control) is selected in V2 control mode selection P012, control is based on $\times 4$ the number of pulses used for internal operations.
(Set the multi-step position command and position range setting for $\times 4$ multiplication control.)
- The position command can be changed up to 8 steps, depending on combinations of multi-function input terminals.
- Zero return speed can be selected from one low speed and two high speeds.
(The orientation function, described in the previous section, is not available.)
- By using the teaching function, you can set the position command while running the machine.
- By allocating "73" (SPD) to a multi-function input, you can switch between the speed and position controls.
- For data with many digits (e.g. position command), only the higher 4 digits are displayed.

Parameter No.	Function name	Data	Default setting	Unit
P012	V2 control mode selection	02: APR2 (absolute position control mode) 03: HAPR (high-resolution absolute position control mode)	00	—
P023	Position loop gain	0.00 to 100.00	0.50	rad/s
P060	Multi-step position command 0	Position range setting (reverse side) to Position range setting (forward side) -268435455 to 268435455	0	—
P061	Multi-step position command 1	Position range setting (reverse side) to Position range setting (forward side) -268435455 to 268435455	0	—
P062	Multi-step position command 2	Position range setting (reverse side) to Position range setting (forward side) -268435455 to 268435455	0	—
P063	Multi-step position command 3	Position range setting (reverse side) to Position range setting (forward side) -268435455 to 268435455	0	—
P064	Multi-step position command 4	Position range setting (reverse side) to Position range setting (forward side) -268435455 to 268435455	0	—
P065	Multi-step position command 5	Position range setting (reverse side) to Position range setting (forward side) -268435455 to 268435455	0	—
P066	Multi-step position command 6	Position range setting (reverse side) to Position range setting (forward side) -268435455 to 268435455	0	—
P067	Multi-step position command 7	Position range setting (reverse side) to Position range setting (forward side) -268435455 to 268435455	0	—
P068	Zero return mode	00: Low speed 01: High speed 1 02: High speed 2	00	—
P069	Zero return direction selection	00: FWD (Forward side) 01: REV (Reverse side)	00	—
P070	Low-speed zero return frequency	0.00 to 10.00	0.00	Hz
P071	High-speed zero return frequency	0.00 to Maximum frequency	0.00	Hz

4-3 Functions When PG Option Board (3G3AX-PG01) Is Used

Parameter No.	Function name	Data	Default setting	Unit
P072	Position range specification (forward)	0 to 268435455: When APR2 is selected 0 to 1073741823: When HAPR is selected	268435455	—
P073	Position range specification (reverse)	–268435455 to 0: When APR2 is selected –1073741823 to 0: When HAPR is selected	–268435455	—
P074	Teaching selection	00: X00 (Multi-step position command 0 (P060)) 01: X01 (Multi-step position command 1 (P061)) 02: X02 (Multi-step position command 2 (P062)) 03: X03 (Multi-step position command 3 (P063)) 04: X04 (Multi-step position command 4 (P064)) 05: X05 (Multi-step position command 5 (P065)) 06: X06 (Multi-step position command 6 (P066)) 07: X07 (Multi-step position command 7 (P067))	00	—
C169	Multi-step speed/position determination time	0 to 200: × 10 ms	0	ms
d029	Position command monitor	–1073741823 to 1073741823 when HAPR is selected –268435456 to 268435456 when APR2 is selected	—	—
d030	Current position monitor	–1073741823 to 1073741823 when HAPR is selected –268435456 to 268435456 when APR2 is selected	—	—
C001 to C008	Multi-function inputs 1 to 8 selection	45: ORT (orientation) 54: SON (servo ON) 66: CP1 (position command selection 1) 67: CP2 (position command selection 2) 68: CP3 (position command selection 3) 69: ORL (zero return limit signal) 70: ORG (zero return startup signal) 71: FOT (forward driving stop) 72: ROT (reverse driving stop) 73: SPD (speed/position switching)	—	—
C102	Reset selection	03: Trip RESET (Trip reset only)	00	—

Absolute Position Control Operation



In the absolute position control mode, the Inverter moves to the target position according to the following parameter settings, and is then set in the position servo lock status.

- Position command
- Speed command (frequency reference)
- Acceleration/Deceleration time

(The servo lock status is retained until the RUN command is turned off.)

The frequency reference and acceleration/deceleration command for absolute position control conform to the items selected when the RUN command is turned on.

If the position command is set to a low value, the Inverter may stop deceleration and perform positioning before the speed command value is reached.

In the absolute position control mode, the direction of RUN command (FW or RV) does not refer to the rotating direction. The FW or RV signal starts or stops the Inverter. The Inverter runs forward when "Target position - Current position" is a positive value, or runs in reverse when it is a negative value.

If you do not perform zero return operation, (to be described later), the position at power-on is regarded as the origin (position = 0).

When position command is set to "0", positioning is performed when the RUN command is turned on.

In reset selection C102, select "03" (trip reset only).

* If reset selection C102 is not set to "03", turning on the Inverter's reset terminal (or RESET key) clears the current position counter. To operate the Inverter by using the current position count value after resetting a trip by turning on the reset terminal (or RESET key), be sure to set reset selection C102 to "03".

If PCLR is allocated, turning on the PCLR terminal clears the current position counter.

(The internal position deviation counter is simultaneously cleared.)

The absolute position control mode disables the ATR terminal. (Torque control is disabled.)

The absolute position control mode disables the STAT terminal. (Pulse train position control is disabled.)

The absolute position control mode disables the orientation function.

(However, the ORT terminal is used for teaching, as described later.)

Multi-step Position Switching Function (CP1/CP2/CP3)

By allocating "66" to "68" (CP1 to CP3) to any of multi-function inputs 1 to 8 (C001 to C008), you can select multi-step positions 0 to 7.


Set position commands in multi-step position commands 0 to 7 (P060 to P067).

If no position command is allocated to the terminals, multi-step position command 0 (P060) is defined as the position command.

Position command	CP3	CP2	CP1
Multi-step position 0	0	0	0
Multi-step position 1	0	0	1
Multi-step position 2	0	1	0
Multi-step position 3	0	1	1
Multi-step position 4	1	0	0
Multi-step position 5	1	0	1
Multi-step position 6	1	1	0
Multi-step position 7	1	1	1

When you input a multi-step position command, you can set the wait time until the terminal input is determined. This prevents the transition status from being applied before it is determined.

You can adjust the determination time in multi-step speed/position determination time C169. If no input is made during the time set in C169, the data is determined after the set time elapses. (Note that the longer the determination time, the slower the input response.)



Speed/Position Switching Function (SPD)

Allocate 73 (SPD) to one of the multi-function inputs.


While the SPD terminal is turned on, the current position counter is retained at "0". Therefore, if the SPD terminal is turned off during operation, the Inverter shifts to the position control mode. (Speed/Position switching)

At this time, if the position command is "0", the Inverter immediately stops.

(Hunting may occur, depending on the position loop gain setting.)

While the SPD terminal is turned on, the Inverter runs in the direction based on the RUN command.

When shifting from speed control to position control, be careful about the polarity sign of the RUN command.




Zero Return Function

This function performs three types of zero return operations depending on the setting of zero return mode P068. When zero return is complete, the current position is cleared to zero.

You can select the zero return direction in zero return direction selection P069.


If zero return is not performed, the Inverter performs position control with the position at power-on defined as the origin.

<Low-speed zero return (P068 = 00)>




- (1) The Inverter accelerates to the low-speed zero return frequency according to the acceleration time setting.
- (2) The Inverter runs at the low-speed zero return speed.
- (3) The Inverter performs positioning when the ORL signal is input.

<High-speed zero return 1 (P068 = 01)>



- (1) The Inverter accelerates to the high-speed zero return frequency according to the acceleration time setting.
- (2) The Inverter runs at the high-speed zero return frequency.
- (3) The Inverter starts deceleration when the ORL signal is turned on.
- (4) The Inverter runs in reverse at the low-speed zero return frequency.
- (5) The Inverter performs positioning when the ORL signal is turned off.

<High-speed zero return 2 (P068 = 02)>



- (1) The Inverter accelerates to the high-speed zero return frequency according to the acceleration time setting.
- (2) The Inverter runs at the high-speed zero return frequency.
- (3) The Inverter starts deceleration when the ORL signal is turned on.
- (4) The Inverter runs in reverse at the low-speed zero return frequency.
- (5) The Inverter starts deceleration when the ORL signal is turned off.
- (6) The Inverter runs forward at the low-speed zero return frequency.
- (7) The Inverter performs positioning at the first Z-pulse position after the ORL signal is turned on.

Forward/Reverse Run Stop Function (FOT/ROT)

With a signal from the control range limit switch, this function prevents the Inverter from running outside the specified operation range.

The torque limit is set to 10% on the forward side when the FOT terminal is turned on, and on the reverse side when the ROT terminal is turned on.

This function can be used as the limit switch at the machine end. To do so, allocate "71" (FOT) and "72" (ROT) to any of multi-function inputs 1 to 8 (C001 to C008).

Position Range Setting Function

Set a forward/reverse position control range in position range setting (forward) P072 and position range setting (reverse) P073. If the current position counter exceeds the setting range, a position control range trip (E63.* or E73.*) occurs, and the Inverter goes into free-run status.

The upper limit setting of multi-step position commands 0 to 7 (P060 to P067) is limited by this control range setting.

(You cannot set a position command beyond the position range.)

Teaching Function

This function starts or stops the motor at a desired position and stores the current position as a position command in a desired position command area.

Allocate "45" (ORT) to any of multi-function inputs 1 to 8 (C001 to C008).

When V2 control mode selection P012 is set to "02" (absolute position control) or "03" (high-resolution absolute position control), the relevant terminal serves as a teaching terminal.


Related functions	C001 to C008, P012, P074
-------------------	--------------------------

<Teaching Procedure>

(1) In teaching selection P074, select the position command you want to set.

(2) Move the workpiece.

- Input the RUN command with the ORT terminal turned on. At this time, the speed command and acceleration/deceleration time conform to the currently selected parameters.



* If the Inverter control circuit (Ro, To) is turned on, teaching is enabled.

The current position counter operates even if the workpiece is moved by an external device.

Teaching is therefore enabled even while the Inverter is stopped.

Note: Make sure that the power supplies (R/L1, S/L2, T/L3) for the Inverter power circuit are shut off or that the Inverter's outputs (U/T1, V/T2, W/T3) are disconnected from the motor. Not doing so may result in injury and/or damage to the equipment.

(3) When the target position is reached, press the Enter key on the Digital Operator. Press the key on the data display screen (the PRG LED indicator is lit).

- (4) The current position is set to the area corresponding to the position command source set in teaching selection P074.
(However, the P074 setting is not stored. After the power is shut off or after reset, this parameter is indicated as "00" (x00).)

P074 set values	Position commands to be set
00	P060: Multi-step position command 0
01	P061: Multi-step position command 1
02	P062: Multi-step position command 2
03	P063: Multi-step position command 3
04	P064: Multi-step position command 4
05	P065: Multi-step position command 5
06	P066: Multi-step position command 6
07	P067: Multi-step position command 7

Servo ON Function


This function brings the Inverter into speed servo lock status via an input terminal when "05" (sensor vector control) is selected in V/f characteristics selection A044.

Allocate 54 (SON) to the desired multi-function input.

The Inverter does not accept the RUN command unless the SON terminal is turned on when SON is allocated.

If the SON terminal is turned off during operation, the Inverter goes into free-run status. When the SON terminal is turned on again, the Inverter restarts according to the setting of free-run stop selection b088.

This function cannot be simultaneously used with the preliminary excitation function (55: FOC). If FOC and SON are both allocated to multi-function input terminals, priority is given to FOC, and SON is disabled.



Related functions

A044, C001 to C008

Pulse Train Frequency Input

This function allows you to use a pulse train input to the SAP-SAN terminals as frequency reference or PID feedback value in each control mode.


(This function can be used in all control modes.)

Set the input frequency at the maximum frequency in pulse train frequency scale P055.

The analog input start/end function cannot be used. To limit the input frequency, use pulse train frequency bias amount P057 and pulse train frequency limit P058.

Parameter No.	Function name	Data	Default setting	Unit
P055	Pulse train frequency scale	1.0 to 50.0: Set the input frequency at the maximum frequency.	25.0	kHz
P056	Pulse train frequency filter time constant	0.01 to 2.00: Set a filter time constant for pulse train input.	0.10	s
P057	Pulse train frequency bias amount	-100 to 100	0	%
P058	Pulse train frequency limit	0 to 100	100	%
A001	Frequency reference selection	06: Pulse train frequency	01	—
A076	PID feedback selection	03: Pulse (Pulse train frequency)	00	
A141	Operation frequency input A setting	07: Pulse (Pulse train frequency)	02	
A142	Operation frequency input B setting	07: Pulse (Pulse train frequency)	03	

Pulse train frequency processing block



Note: The SWENC switch on PG Board is available for "OFF: encoder disconnection detection disabled".

4-4 Communication Function


- This function allows the Inverter to communicate with an external controller via the RS485 interface from the TM2 terminal on the Inverter's control terminal block board.

■ Communication Specifications

Item	ASCII method	ModBus-RTU method	Note
Transmission speed	2400/4800/9600/19200 bps		Select using the Digital Operator.
Communication method	Half-duplex communication		
Synchronous system	Start-stop synchronous system	Asynchronous system	
Transmission code	ASCII code	Binary	
Transmission mode	LSB first		
Compatible interface	RS-485		
Data bit length	7 or 8 bits	8 bits	Select using the Digital Operator.
Parity	No parity/Even/Odd		Select using the Digital Operator.
Stop bit length	1 or 2 bits		Select using the Digital Operator.
Starting method	One-side start using host command		
Wait time	10 to 1000 [ms]	0 to 1000 [ms]	Set using the Digital Operator.
Connection	1:N (N = 32 max.)		Use the Digital Operator to select a station No.
Error check	Overrun/Framing BCC/Vertical/Horizontal parity	Overrun/Framing CRC-16/Horizontal parity	

<RS485 Port Specifications and Connections>

For the RS485 communication function, use the TM2 terminal on the control terminal block board.



Terminal abbreviations	Description
SP	Transmission/Reception (+)
SN	Transmission/Reception (-)
RP	Termination resistor enabling terminal
SN	Termination resistor enabling terminal


The following wires are recommended for TM2:

Single wire	0.14 to 1.5 mm ² (If two equal-sized wires are connected to one pole: 0.14 to 0.5 mm ²)
Stranded wire	0.14 to 1.0 mm ² (If two equal-sized wires are connected to one pole: 0.14 to 0.2 mm ²)
Stranded wire with solderless terminal	0.25 to 0.5 mm ²
Wire strip length	5 mm
Tightening torque	0.22 to 0.25 N•m (screw size: M2)

•Connection

Connect the Inverters parallel to each other, as shown below. For the termination Inverter, short-circuit the RP and SN terminals. (Also, if the RS485 communication function is used with a single Inverter, the RP and SN terminals must be short-circuited.)

Short-circuiting the RP and SN terminals activates the termination resistor inside the control terminal block board, suppressing signal reflection.



Setting

RS485 communication requires the following settings.

Parameter No.	Function name	Data	Default setting	Unit
C071	Communication speed selection (Baud rate selection)	02: Loop-back test 03: 2400 bps 04: 4800 bps 05: 9600 bps 06: 19200 bps	05	—
C072	Communication station No. selection	1 to 247	1	—
C073	Communication bit length selection	7: 7-bit 8: 8-bit	8	—
C074	Communication parity selection	00: No parity 01: Even 02: Odd	00	—
C075	Communication stop bit selection	1: 1-bit 2: 2-bit	1	—
C076	Communication error selection	00: Trip 01: Decel-Trip (Trip after deceleration stop) 02: Ignore 03: Free-RUN (Free-run stop) 04: Decel-Stop (Deceleration stop)	02	—
C077	Communication error timeout	0.00 to 99.99: Communication disconnection judgment time	0.00	s

Parameter No.	Function name	Data	Default setting	Unit
C078	Communication wait time	0 to 1000: Time to wait for response from the Inverter	0	ms
C079	Communication method selection	00: ASCII 01: ModBus-RTU	01	—
Related functions		A001, A002		

■ Communication Test Mode

- The communication test mode allows you to check the RS485 communication line (hardware).


(Communication Test Mode Procedure)

- (1) Before conducting a loop-back test, disconnect the cable from TM2 on the control terminal block board.
- (2) Set the following parameter via the Digital Operator.
 - Set C071 (communication speed selection) to "02" (loop-back test).
- (3) Turn off the Inverter, and turn it on again. The check will start.
- (4) After the check is complete, the Digital Operator displays the following code:
 - OK: LoopBack OK
 - NG: LoopBack NG
- (5) Press the RESET button on the Digital Operator or on the copy unit to show the basic setting screen. Reset the parameter that you changed in step (2) to a desired setting.

ASCII Method

■Communication Procedure

•The following shows the communication procedure between the Inverter and external controller.



- (1): Indicates a frame sent from the external controller to the Inverter.
- (2): Indicates a frame sent back from the Inverter to the external controller.

Frame (2) is response output from the Inverter after reception of frame (1). It is not an active output. Below is each frame format (command).

Command List

Command	Description	Communication with all stations	Note
00	Inputs forward/reverse/stop command.	Available	Enabled only when b084 is set to "01" or "02". (Clears trip data.)
01	Sets frequency reference.	Available	
02	Sets multi-function input terminal status.	Available	
03	Reads all monitor data.	Not available	
04	Reads the Inverter status.	Not available	
05	Reads trip data.	Not available	
06	Reads a parameter.	Not available	
07	Sets a parameter.	Available	
08	Initializes each set value.	Available	
09	Checks if a set value can be stored in EEPROM.	Not available	
0A	Stores a set value in EEPROM.	Available	
0B	Re-calculates internal parameters.	Available	

The following describes each command.

<Command 00>

Inputs the forward/reverse/stop command. (To use this command, set A002 to "03" (RS485).)

•Transmission frame

Frame format

STX	Station No.	Command	Data	BCC	CR
-----	-------------	---------	------	-----	----

	Description	Data size	Setting
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32, and FF (Communication with all stations)
Command	Transmission command	2 bytes	00
Data	Transmission data	1 byte	*
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

*

Data	Description	Note
0	Stop command	
1	Forward command	
2	Reverse command	

(Example) To send a forward command to station 01

(STX)01|00|1|(BCC)|(CR) ASCII conversion 02|30 31|30 30|31|33 30|0D

←—————→

•Response frame

Normal response: Refer to page 4-161.

Error response: Refer to page 4-161.

<Command 01>

Sets frequency reference. (To use this command, set A001 to "03" (RS485).)

•Transmission frame

Frame format

STX	Station No.	Command	Data	BCC	CR
-----	-------------	---------	------	-----	----

	Description	Data size	Setting
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32, and FF (Communication with all stations)
Command	Transmission command	2 bytes	01
Data	Transmission data (Decimal ASCII code)	6 bytes	*
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

* To set "5 Hz" for station 01

(STX)01|01|000500|(BCC)|(CR)

ASCII conversion 02|30 31|30 31|30 30 35 30 30|30 35|0D

—————→

Note 1: Data is a value obtained by multiplying the set value by 100.

(Example) 5 (Hz) \rightarrow 500 \rightarrow 000500 ASCII conversion 30 30 30 35 30 30

Note 2: To use the data as PID control feedback data, set "1" in the MSB of the data.

(Example) 5 (%) \rightarrow 500 \rightarrow 100500 ASCII conversion 31 30 30 35 30 30

- Response frame

Normal response: Refer to page 4-161.

Error response: Refer to page 4-161.

<Command 02>

Sets multi-function input terminal status.

- Transmission frame

Frame format

STX	Station No.	Command	Data	BCC	CR
-----	-------------	---------	------	-----	----

	Description	Data size	Setting
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32, and FF (Communication with all stations)
Command	Transmission command	2 bytes	02
Data	Transmission data	16 bytes	*
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

* Data (hexadecimal) and description of multi-function terminals (For details, refer to "Multi-function Input Selection" (page 4-79).)

Data (hex)	Description	Data (hex)	Description
0000000000000001	FWD : Forward	0000001000000000	SF1 : Multi-step speed setting bit 1
0000000000000002	RV : Reverse	0000002000000000	SF2 : Multi-step speed setting bit 2
0000000000000004	CF1 : Multi-step speed setting binary 1	0000004000000000	SF3 : Multi-step speed setting bit 3
0000000000000008	CF2 : Multi-step speed setting binary 2	0000008000000000	SF4 : Multi-step speed setting bit 4
0000000000000010	CF3 : Multi-step speed setting binary 3	0000001000000000	SF5 : Multi-step speed setting bit 5
0000000000000020	CF4 : Multi-step speed setting binary 4	0000002000000000	SF6 : Multi-step speed setting bit 6
0000000000000040	JG : Jogging	0000004000000000	SF7 : Multi-step speed setting bit 7
0000000000000080	DB : External DC injection braking	0000008000000000	OLR : Overload limit switching
0000000000000100	SET : 2nd control	0000010000000000	TL : Torque limit enabled
0000000000000200	2CH : 2-step acceleration/deceleration	0000020000000000	TRQ1 : Torque limit switching 1
0000000000000400	—	0000040000000000	TRQ2 : Torque limit switching 2
0000000000000800	FRS : Free-run stop	0000080000000000	PPI : P/PI switching
0000000000001000	EXT : External trip	0000100000000000	BOK : Brake confirmation
0000000000002000	USP : USP function	0000200000000000	ORT : Orientation
0000000000004000	CS : Commercial switching	0000400000000000	LAC : LAD cancel
0000000000008000	SFT : Soft lock	0000800000000000	PCLR : Position deviation clear
0000000000010000	AT : Analog input switching	0001000000000000	STAT : Pulse train position command permission
0000000000020000	SET3 : 3rd control	0002000000000000	—
0000000000040000	RS : Reset	0004000000000000	ADD : Frequency addition
0000000000080000	—	0008000000000000	F-TM : Forced terminal block
0000000000100000	STA : 3-wire start	0010000000000000	ATR : Torque command input permission
0000000000200000	STP : 3-wire stop	0020000000000000	KHC : Integrated power clear
0000000000400000	F/R : 3-wire forward/reverse	0040000000000000	SON : Servo ON
0000000000800000	PID : PID enabled/disabled	0080000000000000	FOC : Preliminary excitation
0000000001000000	PIDC : PID integral reset	0100000000000000	MI1 : Drive Programming input 1
0000000002000000	—	0200000000000000	MI2 : Drive Programming input 2
0000000004000000	CAS : Control gain switching	0400000000000000	MI3 : Drive Programming input 3
0000000008000000	UP : UP/DWN function accelerated	0800000000000000	MI4 : Drive Programming input 4
0000000010000000	DWN : UP/DWN function decelerated	1000000000000000	MI5 : Drive Programming input 5
0000000020000000	UDC : UP/DWN function data clear	2000000000000000	MI6 : Drive Programming input 6
0000000040000000	—	4000000000000000	MI7 : Drive Programming input 7
0000000080000000	OPE : Forced operator	8000000000000000	MI8 : Drive Programming input 8

* Data (hexadecimal) and description of multi-function terminals corresponding to 12 commands (For details, refer to "Multi-function Input Terminal Function".)

Data (hex)	Description	Data (hex)	Description
0000000000000001	—	0000000100000000	—
0000000000000002	AHD: Analog command held	0000000200000000	—
0000000000000004	CP1: Position command selection 1	0000000400000000	—
0000000000000008	CP2: Position command selection 2	0000000800000000	—
0000000000000010	CP3: Position command selection 3	0000001000000000	—
0000000000000020	ORL: Zero return limit signal	0000002000000000	—
0000000000000040	ORG: Zero return startup signal	0000004000000000	—
0000000000000080	FOT: Forward driving stop	0000008000000000	—
0000000000000100	ROT: Reverse driving stop	0000010000000000	—
0000000000000200	SPD: Speed/Position switching	0000020000000000	—
0000000000000400	PCNT: Pulse counter	0000040000000000	—
0000000000000800	PCC: Pulse counter clear	0000080000000000	—
0000000000001000	—	0000100000000000	—
0000000000002000	—	0000200000000000	—
0000000000004000	—	0000400000000000	—
0000000000008000	—	0000800000000000	—
0000000000010000	—	0001000000000000	—
0000000000020000	—	0002000000000000	—
0000000000040000	—	0004000000000000	—
0000000000080000	—	0008000000000000	—
0000000000100000	—	0010000000000000	—
0000000000200000	—	0020000000000000	—
0000000000400000	—	0040000000000000	—
0000000000800000	—	0080000000000000	—
0000000001000000	—	0100000000000000	—
0000000002000000	—	0200000000000000	—
0000000004000000	—	0400000000000000	—
0000000008000000	—	0800000000000000	—
0000000010000000	—	1000000000000000	—
0000000020000000	—	2000000000000000	—
0000000040000000	—	4000000000000000	—
0000000080000000	—	8000000000000000	—

(Example) To enable "Forward", "Multi-step speed 1", and "Multi-step speed 2" for the Inverter with station No. 01
 $0x0000000000000001 + 0x0000000000000004 + 0x0000000000000008$
 $= 0x000000000000000D$
 The transmission frame is therefore:
 (STX)|01|02|000000000000000D|(BCC)|(CR)

- Response frame

Positive response: Refer to page 4-161.

Negative response: Refer to page 4-161.

<Command 03>

Reads all monitor data.

- Transmission frame

Frame format

STX	Station No.	Command	BCC	CR
-----	-------------	---------	-----	----

	Description	Data size	Setting
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32
Command	Transmission command	2 bytes	03
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

- Response frame

Frame format

STX	Station No.	Data	BCC	CR
-----	-------------	------	-----	----

	Description	Data size	Setting
STX	Control code (Start of Text)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32
Data	Data	104 bytes	*
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

* Each monitor value

Monitor item	Unit	Magnification	Data size	Description	
Output frequency	Hz	× 100	8 bytes	Decimal ASCII code	
Output current	A	× 10	8 bytes	Decimal ASCII code	
Rotation direction	—	—	8 bytes	0: Stop, 1: Forward, 2: Reverse	
PID feedback monitor	%	× 100	8 bytes	Decimal ASCII code	
Multi-function input monitor	—	—	8 bytes	See *1.	
Multi-function output monitor	—	—	8 bytes	See *2.	→ MSB
Frequency conversion monitor	—	× 100	8 bytes	Decimal ASCII code	LSB ←
Output torque	%	× 1	8 bytes	Decimal ASCII code	
Output voltage monitor	V	× 10	8 bytes	Decimal ASCII code	
Power monitor	kW	× 10	8 bytes	Decimal ASCII code	
—	—	—	8 bytes	"00000000" is stored. (Preliminary data storage area)	
RUN time monitor	h	× 1	8 bytes	Decimal ASCII code	
ON time monitor	h	× 1	8 bytes	Decimal ASCII code	

*1. Multi-function input terminal monitor

Item	Data
1 terminal	00000001
2 terminal	00000002
3 terminal	00000004
4 terminal	00000008
5 terminal	00000010
6 terminal	00000020
7 terminal	00000040
8 terminal	00000080
FW terminal	00000100

*2. Multi-function output terminal monitor

Item	Data
11 terminal	00000001
12 terminal	00000002
13 terminal	00000004
14 terminal	00000008
15 terminal	00000010
Relay terminal	00000020

<Command 04>

Reads the Inverter status.

•Transmission frame

Frame format

STX	Station No.	Command	BCC	CR
-----	-------------	---------	-----	----

	Description	Data size	Setting
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32
Command	Transmission command	2 bytes	04
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

•Response frame

Frame format

STX	Station No.	Data	BCC	CR
-----	-------------	------	-----	----

	Description	Data size	Setting
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32
Data	Data	8 bytes	*
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

* Inverter status data includes the following three elements (A, B, and C).

Data

Status A	Status B	Status C	00 (Reserved)
----------	----------	----------	---------------

Inverter status A

Code	Status
00	Initial status
01	-
02	During stop
03	During RUN
04	During FRS
05	During JG
06	During DB
07	During retry
08	During trip
09	During UV

Inverter status B

Code	Status
00	During stop
01	During RUN
02	During trip

Inverter status C

Code	Status
00	-
01	Stop
02	Deceleration
03	Constant speed
04	Acceleration
05	Forward
06	Reverse
07	Forward to reverse
08	Reverse to forward
09	Forward run start
10	Reverse run start

<Command 05>
Reads trip data.

- Transmission frame
Frame format

STX	Station No.	Command	BCC	CR
	Description	Data size	Setting	
STX	Control code (Start of TeXt)	1 byte	STX (0x02)	
Station No.	Station No. of the target Inverter	2 bytes	01 to 32	
Command	Transmission command	2 bytes	05	
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)	
CR	Control code (Carriage Return)	1 byte	CR (0x0D)	

•Response frame

Frame format

STX	Station No.	Data	BCC	CR
-----	-------------	------	-----	----

	Description	Data size	Setting
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32
Data	Each monitor's data at the time of tripping	440 bytes	*
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

* Each trip monitor stores the past six trips, together with total trip count (8 bytes).

Total count	Trip data 1	Trip data 6
-------------	-------------	-------	-------------

Monitor item	Unit	Magnification	Data size	Note	
Trip factor	—	—	8 bytes	Code display	
Inverter status A	—	—	8 bytes		
Inverter status B	—	—	8 bytes	See "Command 04".	
Inverter status C	—	—	8 bytes		→ MSB
Output frequency	Hz	× 10	8 bytes	Decimal ASCII code	
Total RUN time	h	× 1	8 bytes	Decimal ASCII code	LSB ←
Output current	A	× 10	8 bytes	Decimal ASCII code	
DC voltage	V	× 10	8 bytes	Decimal ASCII code	
Power ON time	h	× 1	8 bytes	Decimal ASCII code	

<Command 06>

Reads a setting item.

•Transmission frame

Frame format

STX	Station No.	Command	Parameter	BCC	CR
-----	-------------	---------	-----------	-----	----

	Description	Data size	Setting
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32
Command	Transmission command	2 bytes	06
Parameter	Parameter No. for data	4 bytes	*
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

* All parameters except F001 and U001 to U012 are retrieved.

- Response frame
Positive response

Frame format

STX	Station No.	ACK	Data	BCC	CR
-----	-------------	-----	------	-----	----

	Description	Data size	Setting
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32
ACK	Control code (ACKnowledge)	1 byte	ACK (0x06)
Data	Data (Decimal ASCII code)	8 bytes	*
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

* If the data is a selected item, the corresponding code data is received/transmitted.
Data on H003 and H203 (motor capacity selection) are the following code data.

Code data	00	01	02	03	04	05	06	07	08	09	10
Domestic/USA mode (b085 = 00 or 02)	0.2 kW	—	0.4	—	0.75	—	1.5	2.2	—	3.7	—
EU mode (b085 = 01)	0.2 kW	0.37	—	0.55	0.75	1.1	1.5	2.2	3.0	—	4.0
Code data	11	12	13	14	15	16	17	18	19	20	21
Domestic/USA mode (b085 = 00 or 02)	5.5 kW	7.5	11	15	18.5	22	30	37	45	55	75
EU mode (b085 = 01)	5.5 kW	7.5	11	15	18.5	22	30	37	45	55	75
Code data	22	23	24	25	26						
Domestic/USA mode (b085 = 00 or 02)	90 kW	110	132	150	160						
EU mode (b085 = 01)	90 kW	110	132	150	160						

- If the data is a numeric value, refer to the function code list.
(Example) When acceleration time F002 is set to 30.00 sec, the data is "3000".
Negative response: Refer to page 4-161.

<Command 07>

Writes data to a specified setting item.

•Transmission frame

Frame format

STX	Station No.	Command	Parameter	Data	BCC	CR
-----	-------------	---------	-----------	------	-----	----

	Description	Data size	Setting
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32, and FF (Communication with all stations)
Command	Transmission command	2 bytes	07
Parameter	Parameter No. for data	4 bytes	*1
Data	Parameter data (Decimal ASCII code)	8 bytes	*2
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

*1 Allowable parameter ranges are shown below.

From F002, A001, b001, C001, H001, and P001 (For F001, use command 01.)

*2 Refer to command 06.

•Response frame

Positive response: Refer to page 4-161.

Negative response: Refer to page 4-161.

<Command 08>

Initializes each set value.

Initialization conforms to the setting of initialization selection b084. If b084 is "00", the trip data is cleared.

•Transmission frame

Frame format

STX	Station No.	Command	BCC	CR
-----	-------------	---------	-----	----

	Description	Data size	Setting
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32, and FF (Communication with all stations)
Command	Transmission command	2 bytes	08
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

•Response frame

Positive response: Refer to page 4-161.

Negative response: Refer to page 4-161.

<Command 09>

Checks if a set value can be stored in EEPROM.

•Transmission frame

Frame format

STX	Station No.	Command	BCC	CR
-----	-------------	---------	-----	----

	Description	Data size	Setting
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32
Command	Transmission command	2 bytes	09
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

•Response frame

Frame format

STX	Station No.	ACK	Data	BCC	CR
-----	-------------	-----	------	-----	----

	Description	Data size	Setting
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32
ACK	Control code (ACKnowledge)	1 byte	ACK (0x06)
Data	Data	2 bytes	01: Enabled
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

Negative response: Refer to page 4-161.

<Command 0A>

Stores a set value in EEPROM.

•Transmission frame

Frame format

STX	Station No.	Command	BCC	CR
-----	-------------	---------	-----	----

	Description	Data size	Setting
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32
Command	Transmission command	2 bytes	0A
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

•Response frame

Positive response: Refer to page 4-161.

Negative response: Refer to page 4-161.

<Command 0B>

Re-calculates internal parameters.

Recalculation is required when the base frequency and H*** parameters are changed via RS485 communication.

•Transmission frame

Frame format

STX	Station No.	Command	BCC	CR
-----	-------------	---------	-----	----

	Description	Data size	Setting
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32
Command	Transmission command	2 bytes	0B
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

•Response frame

Positive response: Refer to page 4-161.

Negative response: Refer to page 4-161.

■Positive/Negative Responses

<Positive Response>

•Response frame

Frame format

STX	Station No.	ACK	BCC	CR
-----	-------------	-----	-----	----

	Description	Data size	Setting
STX	Control code (Start of TeXt)	1 byte	STX (0x02)
Station No.	Station No. of the target Inverter	2 bytes	01 to 32
ACK	Control code (ACKnowledge)	1 byte	ACK (0x06)
BCC	Block check code	2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)
CR	Control code (Carriage Return)	1 byte	CR (0x0D)

<Negative Response>

•Response frame

Frame format

STX	Station No.	NAK	Error code	BCC	CR
	Description		Data size	Setting	
STX	Control code (Start of TeXt)		1 byte	STX (0x02)	
Station No.	Station No. of the target Inverter		2 bytes	01 to 32	
NAK	Control code (Negative AcKnowledge)		1 byte	NAK (0x15)	
Error code	Communication error status		2 bytes	*	
BCC	Block check code		2 bytes	Exclusive OR from station No. to data. (Refer to page 4-163.)	
CR	Control code (Carriage Return)		1 byte	CR (0x0D)	


* Error Code List

Error code	Description
01H	Parity error
02H	Checksum error
03H	Framing error
04H	Overflow error
05H	Protocol error
06H	ASCII code error
07H	Receiving buffer overrun error
08H	Receiving timeout error
—	—
—	—
11H	Command invalid error
12H	—
13H	Execution disabled error
14H	—
15H	—
16H	Parameter invalid error
17H	—

During communication with all stations, the Inverter sends no response.


4

(Example) To set "5 Hz" using command 01 (frequency reference setting) (When the target station No. is "01")



To determine BCC, the Inverter performs ASCII conversion from the station No. to data, and calculates a result of the exclusive OR (Xor) per byte.

For the above transmission frame, BCC is calculated as follows:




(Appendix) ASCII Code Conversion Table

Text data	ASCII code
STX	2
ACK	6
CR	0D
NAK	15
0	30
1	31
2	32
3	33
4	34
5	35
6	36
7	37
8	38
9	39

Text data	ASCII code
A	41
B	42
C	43
D	44
E	45
F	46
H	48
P	50
b	62

ModBus-RTU Method

Follow the procedures below in regards to communication between the external controller and the Inverter.



(1) : Frame to be sent from the external control device to the Inverter (Query)

(2) : Frame to be returned from the Inverter to the external controller (Response)

(3) : Unless the Inverter completes reception of a query from the host within the time set in C077 after the Inverter completes a response (response transmission), the Inverter becomes ready to receive the first data again. In this case, the Inverter sends no response.

Also, the Inverter's operation conforms to the setting of communication error selection C076. For details, refer to the following table.

The receiving timeout monitor starts after the first transmission/reception is performed after power-on or reset. Receiving timeout is inactive until reception or transmission is performed.

Parameter No.	Function name	Data	Default setting	Unit
C076	Communication error selection	00: Trip (Trip after receiving timeout [E41]) 01: Decel-Trip (Deceleration stop after receiving timeout. Trip after stop [E41]) 02: Ignore (No trip and no alarm output) 03: Free-RUN (Free-run stop after receiving timeout. No trip and no alarm output) 04: Decel-Stop (Deceleration stop after receiving timeout. No trip and no alarm output)	02	—
C077	Communication error timeout	0.00 to 99.99: Time before receiving timeout	0.00	—
C078	Communication wait time	0 to 1000: Wait time until response starts after reception is completed (excluding silent interval)	0	—

Response from the Inverter (Frame 2) is output as return after the Inverter receives the query (Frame 1), not output independently.

Below is each frame format (command).

Message Configuration: Query

Header (Silent interval)
Slave address
Function code
Data
Error check
Trailer (Silent interval)

<Slave Address>

- Pre-set numbers ranging from 1 to 247 in each Inverter (slave). (Only the Inverter having the same slave address as the query takes in the corresponding query.)
- Broadcasting can be performed by setting the slave address to "0".
- Data call or loop-back cannot be performed while broadcasting.

<Data>

- Sends the function command.
- The RX corresponds with the following data formats used in the ModBus.

Data name	Description
Coil	2-value data (1-bit long) that can be referred to or changed
Holding register	16-bit long data that can be referred to or changed

<Function Code>

- Specifies the function for the Inverter to perform.
- Below are the function codes supported by the RX.


Function Code

Function code	Function	Maximum number of data bytes in 1 message	Maximum data number in 1 message
01h	Reading coil status	4	32 coils (in bits)
03h	Reading holding register content	8	4 registers (in bytes)
05h	Writing into the coil	2	1 coil (in bits)
06h	Writing into the holding register	2	1 register (in bytes)
08h	Loop-back test	—	
0Fh	Writing into multiple coils	4	32 coils (in bits)
10h	Writing into multiple registers	8	4 registers (in bytes)

<Error Check>

- CRC (Cyclic Redundancy Check) is used for the ModBus-RTU error check.
- The CRC code is a 16-bit data generated for the block of random length data in the 8-bit unit.
- To prepare the CRC code, use a generation polynomial of CRC-16 ($X^{16} + X^{15} + X^2 + 1$).

CRC-16 Calculation Example



<Header and Trailer (Silent Interval)>

- Wait time from receiving the query from the master to the response by the Inverter.
- Be sure to provide 3.5 characters (24 bits) as the wait time. If the length does not reach 3.5 characters, the Inverter does not respond.
- The actual communication wait time is the total of the silent interval (3.5-character length) and C078 (communication wait time) setting.

Message Configuration: Response

<Total Communication Time>

- The time from receiving query to the response by the Inverter is the total of the silent interval (3.5-character length) and C078 (communication wait time) setting.
- If sending another query to the Inverter after receiving the response, be sure to provide the silent interval length (3.5 characters) at the minimum.

<Normal Response>

- If the query is the loop-back function code (08h), the Inverter sends back a response of the same content as the query.
- If the query is the function code to be written into the holding register or coil (05h, 06h, 0Fh, 10h), the Inverter sends back the query as it is in response.
- If the query is the function code to be read from the holding register or coil (01h, 03h), the Inverter makes the slave address and function code the same as the query and attaches the read data to the query.

<Abnormal Response>
Field Configuration

Slave address
Function code
Exception code
CRC-16

- If an error (aside from a communication error) is found in the query content, the Inverter returns exception responses without performing any operation.
- To determine the cause of an error, check the function code of the response. The function code of the exception response is the value of the query function code to which 80h is added.
- Check the details of the error with the exception code.

Exception code

Code	Description
01h	An unsupported function has been specified.
02h	Specified address does not exist.
03h	Specified data has an unacceptable format.
21h	Data is out of the Inverter's range for writing into the holding register.
22h	<p>The Inverter does not allow this function.</p> <ul style="list-style-type: none"> • Has attempted to change the register that cannot be changed during operation. • Has issued the enter command during operation (UV). • Has written into the register during trip (UV). • Has written into the read-only register (coil)

<No Response>

The Inverter ignores the query and does not respond if:

- The broadcast is received.
- A communication error is detected in receiving a query.
- The query slave address does not correspond with the slave address set for the Inverter.
- The time interval between 2 pieces of data that configure the message is less than a 3.5-character length.
- Query data length is inappropriate.

Note: If the timer is set in the master to monitor response, but no response is returned within the set time period, send the same query again.

■Explanation of Each Function Code

<Reading Coil Status [01h]>

Reads out the coil status (ON/OFF).

(Example)

Read multi-function input terminals 1 to 6 on the Inverter with slave address 8.

Refer to the following table for the multi-function input terminal status.

Multi-function input terminals	1	2	3	4	5	6
Coil No.	7	8	9	10	11	12
Terminal status	ON	ON	ON	OFF	ON	OFF

Coils 13 and 14 are OFF.

Query

No.	Field name	Example (HEX)
1	Slave address ^{*1}	08
2	Function code	01
3	Coil start number (MSB) ^{*2}	00
4	Coil start number (LSB) ^{*2}	06
5	Number of coils (MSB) ^{*3}	00
6	Number of coils (LSB) ^{*3}	06
7	CRC-16 (MSB)	5C
8	CRC-16 (LSB)	90

Response

No.	Field name	Example (HEX)
1	Slave address	08
2	Function code	01
3	Number of data bytes	01
4	Coil data ^{*4}	17
5	CRC-16 (MSB)	12
6	CRC-16 (LSB)	1A

^{*4}. Transfers data by the number of data bytes.

- ^{*1}. Broadcasting cannot be performed.
^{*2}. Note that the start number is reduced by 1.
^{*3}. When specifying the value of 0 or over 32 for the number of reading coils, the error code "3h" is replied.

The data received as the response shows the status of coils 7 to 14. The data received here, "17h = 00010111b", should be read with coil 7 as LSB, as follows:

Coil No.	14	13	12	11	10	9	8	7
Coil status	OFF	OFF	OFF	ON	OFF	ON	ON	ON

If the read coil exceeds the defined coil range in the final coil data, such coil data is regarded as "0" and sent.

If the coil status reading command has not been performed normally, refer to the "Exception Response" section.

<Reading Holding Register Content [03h]>

Reads consecutively the specified number of holding register contents from the specified holding register address.

(Example)

Read past trip data from the Inverter with slave address 5.

Below is the data on past three trips:

RX command	d081 (Previous factor)	d081 (Previous Inverter status)
Holding register No.	0012h	0013h
Trip factor (high-order)	Overvoltage (E07)	During deceleration (02)

Query

No.	Field name	Example (HEX)
1	Slave address ^{*1}	05
2	Function code	03
3	Register start number (MSB) ^{*2}	00
4	Register start number (LSB) ^{*2}	11
5	Number of holding registers (MSB)	00
6	Number of holding registers (LSB)	02
7	CRC-16 (MSB)	95
8	CRC-16 (LSB)	8A

*1. Broadcasting cannot be performed.

*2. Note that the start number is reduced by 1.

Response

No.	Field name	Example (HEX)
1	Slave address	05
2	Function code	03
3	Number of data bytes ^{*3}	04
4	Register start number (MSB)	00
5	Register start number (LSB)	07
6	Register start number +1 (MSB)	00
7	Register start number +1 (LSB)	02
8	CRC-16 (MSB)	36
9	CRC-16 (LSB)	37

*3. Transfers data by the number of data bytes. In this example, the Inverter sends response data on two holding registers (4 bytes).

Read the data received in response, as follows:

Response buffer	4	5	6	7
Holding register start number	+0 (MSB)	+0 (LSB)	+1 (MSB)	+1 (LSB)
Response data	00h	07h	00h	02h
Trip cause	Overvoltage trip		During deceleration	

If the holding register content has not been read out normally, refer to the "Exception Response" section.

<Writing Into the Coil [05h]>

Writes into one coil.
The following table shows the coil status change.

	Coil status	
	OFF → ON	ON → OFF
Change data (MSB)	FFh	00h
Change data (LSB)	00h	00h

(Example)
Issue the RUN command to the Inverter with slave address 10.
To run the Inverter, set "03" in A002. The coil number of the RUN command is "1".

Query

No.	Field name	Example (HEX)
1	Slave address ^{*1}	0A
2	Function code	05
3	Coil start number (MSB) ^{*2}	00
4	Coil start number (LSB) ^{*2}	00
5	Change data (MSB)	FF
6	Change data (LSB)	00
7	CRC-16 (MSB)	8D
8	CRC-16 (LSB)	41

Response

No.	Field name	Example (HEX)
1	Slave address	0A
2	Function code	05
3	Coil start number (MSB)	00
4	Coil start number (LSB)	00
5	Change data (MSB)	FF
6	Change data (LSB)	00
7	CRC-16 (MSB)	8D
8	CRC-16 (LSB)	41

*1. There is no response for broadcasting.
*2. Note that the start number is reduced by 1.

If writing into the coil cannot be performed normally, refer to the "Exception Response" section.

4-4 Communication Function

<Writing Into the Holding Register [06h]>

Writes data into the specified holding register.

(Example)

Write 50 Hz into the Inverter with slave address 5 as the base frequency (A003).

The data resolution of the holding register "1203h" of the base frequency (A003) is 1 Hz. To set 50 Hz, set the change data to "50 (0032h)".

Query

No.	Field name	Example (HEX)
1	Slave address * ¹	05
2	Function code	06
3	Register start number (MSB) * ²	12
4	Register start number (LSB) * ²	02
5	Change data (MSB)	00
6	Change data (LSB)	32
7	CRC-16 (MSB)	AD
8	CRC-16 (LSB)	23

*1. There is no response for broadcasting.

*2. Note that the start number is reduced by 1.

Response

No.	Field name	Example (HEX)
1	Slave address	05
2	Function code	06
3	Register start number (MSB)	12
4	Register start number (LSB)	02
5	Change data (MSB)	00
6	Change data (LSB)	32
7	CRC-16 (MSB)	AD
8	CRC-16 (LSB)	23

If writing into the holding register cannot be performed normally, refer to the "Exception Response" section.

<Loop-back Test [08h]>

Used to check the communications between master and slave. A random value can be used for test data.

(Example)

Loop-back test to the Inverter with slave address 1

Query

No.	Field name	Example (HEX)
1	Slave address *	01
2	Function code	08
3	Diagnostic sub code (MSB)	00
4	Diagnostic sub code (LSB)	00
5	Data (MSB)	Random
6	Data (LSB)	Random
7	CRC-16 (MSB)	CRC
8	CRC-16 (LSB)	CRC

* Broadcasting cannot be performed.

Response

No.	Field name	Example (HEX)
1	Slave address	01
2	Function code	08
3	Diagnostic sub code (MSB)	00
4	Diagnostic sub code (LSB)	00
5	Data (MSB)	Random
6	Data (LSB)	Random
7	CRC-16 (MSB)	CRC
8	CRC-16 (LSB)	CRC

The diagnostic sub code corresponds only with the query data echo (00h, 00h), not any other commands.

<Writing Into Multiple Coils [0Fh]>

Rewrites consecutive multiple coils.

(Example)

Change the status of multi-function input terminals 1 to 6 on the Inverter with slave address 5.

Set the multi-function input terminals as shown in the following table.

Multi-function input terminals	1	2	3	4	5	6
Coil No.	7	8	9	10	11	12
Terminal status	ON	ON	ON	OFF	ON	OFF

Query

No.	Field name	Example (HEX)
1	Slave address ^{*1}	05
2	Function code	0F
3	Coil start number (MSB) ^{*2}	00
4	Coil start number (LSB) ^{*2}	06
5	Number of coils (MSB)	00
6	Number of coils (LSB)	06
7	Number of bytes ^{*3}	02
8	Change data (MSB) ^{*3}	17
9	Change data (LSB) ^{*3}	00
10	CRC-16 (MSB)	DB
11	CRC-16 (LSB)	3E

Response

No.	Field name	Example (HEX)
1	Slave address	05
2	Function code	0F
3	Coil start number (MSB)	00
4	Coil start number (LSB)	06
5	Number of coils (MSB)	00
6	Number of coils (LSB)	06
7	CRC-16 (MSB)	34
8	CRC-16 (LSB)	4C

*1. There is no response for broadcasting.

*2. Note that the start number is reduced by 1.

*3. Since the change data comprises of both MSB and LSB as a set, make the byte to be an even number by adding 1, even if the byte that actually needs to be changed is an odd number.

If writing into multiple coils cannot be performed normally, refer to the "Exception Response" section.

<Writing Into Multiple Holding Register [10h]>

Writes into consecutive multiple holding registers.

(Example)

Set acceleration time 1 (F002) to "3000 sec." for the Inverter with slave address 1.

The data resolution of the holding register "1103h, 1104h" of acceleration time 1 (F002) is 0.01 seconds. To set to 3000 seconds, set data to "300000 (493E0h)".

Query

No.	Field name	Example (HEX)
1	Slave address ^{*1}	01
2	Function code	10
3	Start address (MSB) ^{*2}	11
4	Start address (LSB) ^{*2}	02
5	Number of holding registers (MSB)	00
6	Number of holding registers (LSB)	02
7	Number of bytes ^{*3}	04
8	Change data 1 (MSB)	00
9	Change data 1 (LSB)	04
10	Change data 2 (MSB)	93
11	Change data 2 (LSB)	E0
12	CRC-16 (MSB)	9E
13	CRC-16 (LSB)	9F

Response

No.	Field name	Example (HEX)
1	Slave address	01
2	Function code	10
3	Start address (MSB)	11
4	Start address (LSB)	02
5	Number of holding registers (MSB)	00
6	Number of holding registers (LSB)	02
7	CRC-16 (MSB)	E5
8	CRC-16 (LSB)	34

*1. There is no response for broadcasting.

*2. Note that the start address is reduced by 1.

*3. Specifies the number of actual bytes to change, not the number of holding registers.

If writing into multiple holding registers cannot be performed normally, refer to the "Exception Response" section.

<Exception Response>

The master requires the response for a query except for broadcast. Though the Inverter should return a response corresponding with the query, it returns an exception response if the query has an error.

The exception response has the field configuration shown in the following table.

Field Configuration
Slave address
Function code
Exception code
CRC-16

The detailed field configuration is shown below. The function code of the exception response is the value of the query function code to which 80h is added. The exception code shows the cause of exception response.

Function code

Query	Exception response
01h	81h
03h	83h
05h	85h
06h	86h
0Fh	8Fh
10h	90h

Exception code

Code	Description
01h	An unsupported function has been specified.
02h	Specified address does not exist.
03h	Specified data has an unacceptable format.
21h	Data is out of the Inverter's range for writing into the holding register.
22h	The Inverter does not allow this function. <ul style="list-style-type: none"> • Has attempted to change the register that cannot be changed during operation. • Has issued the enter command during operation (UV). • Has written into the register during trip (UV). • Has written into the read-only register (coil).

■ Saving the Change to the Holding Register (Enter Command)

Even if using the command to write into the holding register (06h) or into the consecutive holding registers (10h), no change can be saved in the Inverter's memory element. If the Inverter power shuts off without saving any changes, the holding register returns to the status before the changes were made. To save the holding register changes in the Inverter's memory element, the "Enter Command" must be issued according to the following procedure.

When the control parameters are changed, the motor parameters must be re-calculated. In this case, perform re-calculation with this register.

To issue the Enter command

Write all memory data into the holding register with the write command (06h), and write re-calculated motor parameters into holding register 0900h. Below are the values to be written into the holding register.

Set value	Description
0000	Motor parameter re-calculation
0001	Set value storage
Other than the above	Motor parameter re-calculation and set value storage


Note

- The Enter command needs considerable time. Monitor the data writing signal (coil number 0049h) to check whether the data is being written.
- Since the Inverter's memory element has a limit on the number of rewrites (approx. 100,000 times), the Inverter life may be shortened if enter commands are frequently used.

EEPROM Write Mode

- If the holding register write command (06h), etc. is used to write "1" into the holding register for EEPROM write mode (0902h), the EEPROM write mode will become active.
- If data is changed using the holding register write command (06h) after switching to the EEPROM write mode, the new data is written into both the volatile memory for operation (RAM) and nonvolatile memory for storage (EEPROM). At the same time, the EEPROM write mode is cancelled.
- If any command other than the holding register write command (06h) is received after switching to the EEPROM write mode, the EEPROM write mode is cancelled.

Difference between Enter Command and EEPROM Write Mode



■Register Number List

R/W in the list shows whether the coil or holding register accepts reading and/or writing.

R: Read only R/W: Read and write enabled

<Coil Number List>

Coil No.	Item	R/W	Description
0000h	Not used	—	
0001h	RUN command	R/W	1: Run 0: Stop (Enabled when A002 = 03)
0002h	Rotation direction command	R/W	1: Reverse 0: Forward (Enabled when A002 = 03)
0003h	External trip (EXT)	R/W	1: Trip
0004h	Trip reset (RS)	R/W	1: Reset
0005h	Not used	—	
0006h	Not used	—	
0007h	Multi-function input terminal 1	R/W	1: ON 0: OFF *1
0008h	Multi-function input terminal 2	R/W	1: ON 0: OFF *1
0009h	Multi-function input terminal 3	R/W	1: ON 0: OFF *1
000Ah	Multi-function input terminal 4	R/W	1: ON 0: OFF *1
000Bh	Multi-function input terminal 5	R/W	1: ON 0: OFF *1
000Ch	Multi-function input terminal 6	R/W	1: ON 0: OFF *1
000Dh	Multi-function input terminal 7	R/W	1: ON 0: OFF *1
000Eh	Multi-function input terminal 8	R/W	1: ON 0: OFF *1
000Fh	Operation status	R	1: Run 0: Stop (Interlocked with d003)
0010h	Rotation direction	R	1: Reverse 0: Forward (Interlocked with d003)
0011h	Inverter ready	R	1: Ready 0: Not ready
0012h	Not used	—	
0013h	RUN (during RUN)	R	1: During trip 0: Normal
0014h	FA1 (constant speed arrival signal)	R	1: ON 0: OFF
0015h	FA2 (over set frequency arrival signal)	R	1: ON 0: OFF

*1. When either the control circuit terminal block or the coil is turned on, these settings are ON.

The control circuit terminal block has the priority for the multi-function input terminals.

If the master cannot reset the coil ON status because of communication disconnection, turn the control circuit terminal block from ON to OFF to turn off the coil.

*2. The communications error is retained until a fault reset is input. (Can be reset during operation.)

4-4 Communication Function

4

Functions

Coil No.	Item	R/W	Description
0016h	OL (overload warning)	R	1: ON 0: OFF
0017h	OD (excessive PID deviation)	R	1: ON 0: OFF
0018h	AL (alarm output)	R	1: ON 0: OFF
0019h	FA3 (set-frequency-only arrival signal)	R	1: ON 0: OFF
001Ah	OTQ (overtorque)	R	1: ON 0: OFF
001Bh	IP (signal during momentary power interruption)	R	1: ON 0: OFF
001Ch	UV (signal during undervoltage)	R	1: ON 0: OFF
001Dh	TRQ (torque limit)	R	1: ON 0: OFF
001Eh	RNT (RUN time over)	R	1: ON 0: OFF
001Fh	ONT (Power ON time over)	R	1: ON 0: OFF
0020h	THM (thermal warning)	R	1: ON 0: OFF
0021h	Not used	—	
0022h	Not used	—	
0023h	Not used	—	
0024h	Not used	—	
0025h	Not used	—	
0026h	BRK (brake release)	R	1: ON 0: OFF
0027h	BER (brake error)	R	1: ON 0: OFF
0028h	ZS (0 Hz signal)	R	1: ON 0: OFF
0029h	DSE (excessive speed deviation)	R	1: ON 0: OFF
002Ah	POK (position ready)	R	1: ON 0: OFF
002Bh	FA4 (set frequency exceeded 2)	R	1: ON 0: OFF
002Ch	FA5 (set frequency only 2)	R	1: ON 0: OFF
002Dh	OL2 (overload warning 2)	R	1: ON 0: OFF

*1. When either the control circuit terminal block or the coil is turned on, these settings are ON.

The control circuit terminal block has the priority for the multi-function input terminals.

If the master cannot reset the coil ON status because of communication disconnection, turn the control circuit terminal block from ON to OFF to turn off the coil.

*2. The communications error is retained until a fault reset is input. (Can be reset during operation.)

Coil No.	Item	R/W	Description
002Eh	ODc (analog O disconnection detection)	R	1: ON 0: OFF
002Fh	OIDc (analog OI disconnection detection)	R	1: ON 0: OFF
0030h	O2Dc (analog O2 disconnection detection)	R	1: ON 0: OFF
0031h	Not used	—	
0032h	FBV (PID FB status output)	R	1: ON 0: OFF
0033h	NDc (network error)	R	1: ON 0: OFF
0034h	LOG1 (logic operation output 1)	R	1: ON 0: OFF
0035h	LOG2 (logic operation output 2)	R	1: ON 0: OFF
0036h	LOG3 (logic operation output 3)	R	1: ON 0: OFF
0037h	LOG4 (logic operation output 4)	R	1: ON 0: OFF
0038h	LOG5 (logic operation output 5)	R	1: ON 0: OFF
0039h	LOG6 (logic operation output 6)	R	1: ON 0: OFF
003Ah	WAC (capacitor life warning signal)	R	1: ON 0: OFF
003Bh	WAF (cooling fan life warning signal)	R	1: ON 0: OFF
003Ch	FR (starting contact signal)	R	1: ON 0: OFF
003Dh	OHF (fin overheat warning)	R	1: ON 0: OFF
003Eh	LOC (light load detection signal)	R	1: ON 0: OFF
003Fh	MO1 (Drive Programming output 1)	R/W	1: ON 0: OFF
0040h	MO2 (Drive Programming output 2)	R/W	1: ON 0: OFF
0041h	MO3 (Drive Programming output 3)	R/W	1: ON 0: OFF
0042h	MO4 (Drive Programming output 4)	R/W	1: ON 0: OFF
0043h	MO5 (Drive Programming output 5)	R/W	1: ON 0: OFF

*1. When either the control circuit terminal block or the coil is turned on, these settings are ON.

The control circuit terminal block has the priority for the multi-function input terminals.

If the master cannot reset the coil ON status because of communication disconnection, turn the control circuit terminal block from ON to OFF to turn off the coil.

*2. The communications error is retained until a fault reset is input. (Can be reset during operation.)

Coil No.	Item	R/W	Description
0044h	MO6 (Drive Programming output 6)	R/W	1: ON 0: OFF
0045h	IRDY (operation ready signal)	R	1: ON 0: OFF
0046h	FWR (forward run signal)	R	1: ON 0: OFF
0047h	RVR (reverse run signal)	R	1: ON 0: OFF
0048h	MJA (fatal fault signal)	R	1: ON 0: OFF
0049h	During data write	R	1: Writing 0: Normal
004Ah	CRC error	R	1: Error 0: No error *2
004Bh	Overrun error	R	1: Error 0: No error *2
004Ch	Framing error	R	1: Error 0: No error *2
004Dh	Parity error	R	1: Error 0: No error *2
004Eh	Checksum error	R	1: Error 0: No error *2
004Fh	Not used	—	
0050h	WCO (window comparator O)	R	1: ON 0: OFF
0050h	WCOI (window comparator OI)	R	1: ON 0: OFF
0052h	WCO2 (window comparator O2)	R	1: ON 0: OFF

*1. When either the control circuit terminal block or the coil is turned on, these settings are ON.

The control circuit terminal block has the priority for the multi-function input terminals.

If the master cannot reset the coil ON status because of communication disconnection, turn the control circuit terminal block from ON to OFF to turn off the coil.

*2. The communications error is retained until a fault reset is input. (Can be reset during operation.)

<Holding Register Number List (Frequency Reference and Trip Monitor)>

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
0001h	Output frequency setting/monitor	F001 (HIGH)	R/W	0.00 to 400.00 (Enabled when A001 = 03)	0.01 [Hz]
0002h		F001 (LOW)	R/W		
0003h	Inverter status A	—	R	0: Initial status 1: — 2: Stop 3: RUN 4: Free-run stop 5: Jogging 6: DC injection braking 7: Retry 8: Trip 9: During UV	—
0004h	Inverter status B	—	R	0: During stop 1: During RUN 2: During trip	—
0005h	Inverter status C	—	R	0: — 1: Stop 2: Deceleration 3: Constant speed 4: Acceleration 5: Forward 6: Reverse 7: Forward to reverse 8: Reverse to forward 9: Forward run start 10: Reverse run start	—
0006h	PID feedback	—	R/W	0 to 10000	0.01 [%]
0007h to 0010h	Not used	—	—		—
0011h	Fault frequency monitor	d080	R	0 to 65535	1 [time]
0012h	Fault monitor 1 factor	d081	R	See "Inverter Trip Factor List" (page 4-183).	—
0013h	Fault monitor 1 Inverter status			See "Inverter Trip Factor List" (page 4-183).	—
0014h	Fault monitor 1 frequency (HIGH)			0.00 to 400.00	0.01 [Hz]
0015h	Fault monitor 1 frequency (LOW)				
0016h	Fault monitor 1 current			Output current value at the time of tripping	0.1 [A]
0017h	Fault monitor 1 voltage			DC input voltage at the time of tripping	1 [V]
0018h	Fault monitor 1 RUN time (HIGH)			Total RUN time before the trip	1 [h]
0019h	Fault monitor 1 RUN time (LOW)				
001Ah	Fault monitor 1 ON time (HIGH)			Total power ON time before the trip	1 [h]
001Bh	Fault monitor 1 ON time (LOW)				

Note 1: The Inverter's rated current is "1000".

Note 2: If the set value is "10000" (100.0 sec) or more, the value in the second decimal place is ignored.

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
001Ch	Fault monitor 2 factor	d082	R	See "Inverter Trip Factor List" (page 4-183).	—
001Dh	Fault monitor 2 Inverter status			See "Inverter Trip Factor List" (page 4-183).	—
001Eh	Fault monitor 2 frequency (HIGH)			0.00 to 400.00	0.01 [Hz]
001Fh	Fault monitor 2 frequency (LOW)				
0020h	Fault monitor 2 current			Output current value at the time of tripping	0.1 [A]
0021h	Fault monitor 2 voltage			DC input voltage at the time of tripping	1 [V]
0022h	Fault monitor 2 RUN time (HIGH)			Total RUN time before the trip	1 [h]
0023h	Fault monitor 2 RUN time (LOW)				
0024h	Fault monitor 2 ON time (HIGH)			Total power ON time before the trip	1 [h]
0025h	Fault monitor 2 ON time (LOW)				
0026h	Fault monitor 3 factor	d083	R	See "Inverter Trip Factor List" (page 4-183).	—
0027h	Fault monitor 3 Inverter status			See "Inverter Trip Factor List" (page 4-183).	—
0028h	Fault monitor 3 frequency (HIGH)			0.00 to 400.00	0.01 [Hz]
0029h	Fault monitor 3 frequency (LOW)				
002Ah	Fault monitor 3 current			Output current value at the time of tripping	0.1 [A]
002Bh	Fault monitor 3 voltage			DC input voltage at the time of tripping	1 [V]
002Ch	Fault monitor 3 RUN time (HIGH)			Total RUN time before the trip	1 [h]
002Dh	Fault monitor 3 RUN time (LOW)				
002Eh	Fault monitor 3 ON time (HIGH)			Total power ON time before the trip	1 [h]
002Fh	Fault monitor 3 ON time (LOW)				
0030h	Fault monitor 4 factor	d084	R	See "Inverter Trip Factor List" (page 4-183).	—
0031h	Fault monitor 4 Inverter status			See "Inverter Trip Factor List" (page 4-183).	—
0032h	Fault monitor 4 frequency (HIGH)			0.00 to 400.00	0.01 [Hz]
0033h	Fault monitor 4 frequency (LOW)				
0034h	Fault monitor 4 current			Output current value at the time of tripping	0.1 [A]
0035h	Fault monitor 4 voltage			DC input voltage at the time of tripping	1 [V]
0036h	Fault monitor 4 RUN time (HIGH)			Total RUN time before the trip	1 [h]
0037h	Fault monitor 4 RUN time (LOW)				
0038h	Fault monitor 4 ON time (HIGH)			Total power ON time before the trip	1 [h]
0039h	Fault monitor 4 ON time (LOW)				

Note 1: The Inverter's rated current is "1000".

Note 2: If the set value is "10000" (100.0 sec) or more, the value in the second decimal place is ignored.

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
003Ah	Fault monitor 5 factor	d085	R	See "Inverter Trip Factor List" (page 4-183).	—
003Bh	Fault monitor 5 Inverter status			See "Inverter Trip Factor List" (page 4-183).	—
003Ch	Fault monitor 5 frequency (HIGH)			0.00 to 400.00	0.01 [Hz]
003Dh	Fault monitor 5 frequency (LOW)				
003Eh	Fault monitor 5 current			Output current value at the time of tripping	0.1 [A]
003Fh	Fault monitor 5 voltage			DC input voltage at the time of tripping	1 [V]
0040h	Fault monitor 5 RUN time (HIGH)			Total RUN time before the trip	1 [h]
0041h	Fault monitor 5 RUN time (LOW)				
0042h	Fault monitor 5 ON time (HIGH)			Total power ON time before the trip	1 [h]
0043h	Fault monitor 5 ON time (LOW)				
0044h	Fault monitor 6 factor	d086	R	See "Inverter Trip Factor List" (page 4-183).	—
0045h	Fault monitor 6 Inverter status			See "Inverter Trip Factor List" (page 4-183).	—
0046h	Fault monitor 6 frequency (HIGH)			0.00 to 400.00	0.01 [Hz]
0047h	Fault monitor 6 frequency (LOW)				
0048h	Fault monitor 6 current			Output current value at the time of tripping	0.1 [A]
0049h	Fault monitor 6 voltage			DC input voltage at the time of tripping	1 [V]
004Ah	Fault monitor 6 RUN time (HIGH)			Total RUN time before the trip	1 [h]
004Bh	Fault monitor 6 RUN time (LOW)				
004Ch	Fault monitor 6 ON time (HIGH)			Total power ON time before the trip	1 [h]
004Dh	Fault monitor 6 ON time (LOW)				
004Eh	Warning monitor	d090	R	Warning code 0 to 385	—
004Fh to 08FFh	Not used	—	—		—
0900h	EEPROM write	—	W	0000: Motor parameter recalculation 0001: Set value storage in EEPROM Other: Motor parameter recalculation and set value storage in EEPROM	—
0901h to 1000h	Not used	—	—		—
1F01h	Coil control word	—	R/W	Register coil 0001h to 000Fh	—
1E01h	Coil status word	—	R	Register coil 0010h to 001Fh	—

Note 1: The Inverter's rated current is "1000".

Note 2: If the set value is "10000" (100.0 sec) or more, the value in the second decimal place is ignored.

4-4 Communication Function

Inverter Trip Factor List

Trip factor high-order (factor)		Trip factor low-order (Inverter status)	
Name	Code	Name	Code
No trip factor	0	During reset	0
Overcurrent protection during constant speed	1	During stop	1
Overvoltage protection during deceleration	2	During deceleration	2
Overcurrent protection during acceleration	3	During constant speed	3
Overcurrent protection during stop	4	During acceleration	4
Overload protection	5	Operates at frequency = 0	5
Braking resistor overload protection	6	During startup	6
Overvoltage protection	7	During DB	7
EEPROM error	8	During overload limit	8
Undervoltage protection	9	During SON/FOC	9
CT error	10		
CPU error	11		
External trip	12		
USP error	13		
Grounding protection	14		
Incoming overvoltage protection	15		
Momentary power interruption protection	16		
Power module abnormal temperature (during FAN stop)	20		
Power module abnormal temperature	21		
Gate array communications error	23		
Input phase loss protection	24		
Main circuit error	25		
IGBT error	30		
Thermistor error	35		
Brake error addition	36		
Emergency shutoff error	37		
Low-speed-range electronic thermal	38		
Option 1 errors 0 to 9	60 to 69		
Option 2 errors 0 to 9	70 to 79		

<Holding Register Number List (Monitor)>

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1001h	Output frequency monitor	d001 (HIGH)	R	0.00 to 400.00	0.01 [Hz]
1002h		d001 (LOW)			
1003h	Output current monitor	d002	R	0.0 to 9999.0	0.1 [A]
1004h	Rotation direction monitor	d003	R	FWD: Forward STOP: Stop REV: Reverse	—
1005h	PID feedback value monitor	d004 (HIGH)	R	0.00 to 999000.00	—
1006h		d004 (LOW)			
1007h	Multi-function input monitor	d005	R	2 [^] 0: Terminal 1 to 2 [^] 7: Terminal 8 2 [^] 8: Terminal FW	—
1008h	Multi-function output monitor	d006	R	2 [^] 0: Terminal 11 to 2 [^] 4: Terminal 15 2 [^] 6: Relay terminal	—
1009h	Output frequency monitor (after conversion)	d007 (HIGH)	R	0.00 to 39960.00	0.01
100Ah		d007 (LOW)			
100Bh	Real frequency monitor	d008 (HIGH)	R	-400.00 to 400.00	0.01 [Hz]
100Ch		d008 (LOW)	R		
100Dh	Torque reference monitor	d009	R	-200 to 200	1 [%]
100Eh	Torque bias monitor	d010	R	-200 to 200	1 [%]
100Fh	Not used	—	—		—
1010h	Output torque monitor	d012	R	-200 to 200	1 [%]
1011h	Output voltage monitor	d013	R	0.0 to 600.0	0.1 [V]
1012h	Input power monitor	d014	R	0.0 to 999.9	[kW]
1013h	Integrated power monitor	d015 (HIGH)	R	0.0 to 999999.9	0.1 [h]
1014h		d015 (LOW)			
1015h	Total RUN time	d016 (HIGH)	R	0 to 999999	1 [h]
1016h		d016 (LOW)			
1017h	Power ON time monitor	d017 (HIGH)	R	0 to 999999	1 [h]
1018h		d017 (LOW)			
1019h	Fin temperature monitor	d018	R	-020. to 200.0	0.1 [°C]
101Ah	Motor temperature monitor	d019	R	-020. to 200.0	0.1 [°C]
101Bh	Not used	—	—		—
101Ch					
101Dh	Life assessment monitor	d022	R	2 [^] 0: Capacitor on the main circuit board 2 [^] 1: Cooling fan rotation speed reduced	—

4-4 Communication Function

4

Functions

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
101Eh to 1025h	Not used	—	—		—
1026h	DC voltage monitor	d102	R	0.0 to 999.9	0.1 [V]
1027h	Regenerative braking load rate monitor	d103	R	0.0 to 100.0	0.1 [%]
1028h	Electronic thermal monitor	d104	R	0.0 to 100.0	0.1 [%]
1029h to 102Dh	Not used	—	—		—
102Eh	User monitor 0	d025 (HIGH)	R	-2147483647 to 2147483647	1
102Fh		d025 (LOW)			
1030h	User monitor 1	d026 (HIGH)	R	-2147483647 to 2147483647	1
1031h		d026 (LOW)			
1032h	User monitor 2	d027 (HIGH)	R	-2147483647 to 2147483647	1
1033h		d027 (LOW)			
1034h	Pulse counter monitor	d028 (HIGH)	R	0 to 2147483647	1
1035h		d028 (LOW)	R		
1036h	Position command monitor	d029 (HIGH)	R	-1073741823 to 1073741823 when HAPR is selected	1
1037h		d029 (LOW)	R	-268435456 to 268435456 when APR2 is selected	
1038h	Current position monitor	d030 (HIGH)	R	-1073741823 to 1073741823 when HAPR is selected	1
1039h		d030 (LOW)	R	-268435456 to 268435456 when APR2 is selected	
103Ah to 1102h	Not used	—	—	—	—
1057h	Inverter mode	d060	R/W	00 to 01	—

<Holding Register Number List>

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1103h	Acceleration time 1	F002 (HIGH)	R/W	0.01 to 3600.00	0.01 [s]
1104h		F002 (LOW)			
1105h	Deceleration time 1	F003 (HIGH)	R/W	0.01 to 3600.00	0.01 [s]
1106h		F003 (LOW)			

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1107h	Operator rotation direction selection	F004	R/W	00: FWD (Forward) 01: REV (Reverse)	—
1108h to 1200h	Not used	—	—		—

<Holding Register Number List (Function Mode)>

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1201h	Frequency reference selection	A001	R/W	00: VR (Digital Operator (FREQ adjuster)) 01: Terminal 02: Digital Operator (F001) 03: RS485 (ModBus communication) 04: Option 1 05: Option 2 06: Pulse train frequency 07: EzSQ (Drive Programming) 10: (Math) Operation function result	—
1202h	RUN command selection	A002	R/W	01: Terminal 02: Digital Operator (F001) 03: RS485 (ModBus communication) 04: Option 1 05: Option 2	—
1203h	Base frequency	A003	R/W	30 to Max. frequency	1 [Hz]
1204h	Maximum frequency	A004	R/W	30 to 400	1 [Hz]
1205h	O/OI selection	A005	R/W	00: [O]/[O2] Switches between O/OI terminal 01: [O]/[O2] Switches between O/O2 terminal AT 02: [O]/VR Switches between O/FREQ adjuster via terminal AT 03: [OI]/VR Switches between OI/FREQ adjuster via terminal AT 04: [O2]/VR Switches between O2/FREQ adjuster via terminal AT	—
1206h	O2 selection	A006	R/W	0: [O2] only 1: [O/OI-P] auxiliary frequency reference (not reversible) 2: [O/OI-PM] auxiliary frequency reference (reversible) 3: [OFF] O2 disabled	—
1207h to 120Ah	Not used	—	—		—
120Bh	O start frequency	A011 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
120Ch		A011 (LOW)			
120Dh	O end frequency	A012 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
120Eh		A012 (LOW)			
120Fh	O start ratio	A013	R/W	0 to 100	1 [%]

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1210h	O end ratio	A014	R/W	0 to 100	1 [%]
1211h	O start selection	A015	R/W	00: External start frequency (A011 set value) 01: 0 Hz	—
1212h	O, O2, OI sampling	A016	R/W	1 to 30 31: 500-ms filter with a hysteresis of ± 0.1 Hz	1
1213h	Drive Programming (EzSQ) Selection	A017	R/W	00: Disable 01: [PRG] start 02: Always ON	—
1213h	Not used	—	—		—
1214h	Not used	—	—		—
1215h	Multi-step speed selection	A019	R/W	00: Binary: 16-step selection with 4 terminals 01: Bit: 8-step selection with 7 terminals	—
1216h	Multi-step speed reference 0	A020 (HIGH)	R/W	0/Starting frequency to Max. frequency	0.01 [Hz]
1217h		A020 (LOW)	R/W		
1218h	Multi-step speed reference 1	A021 (HIGH)	R/W	0/Starting frequency to Max. frequency	0.01 [Hz]
1219h		A021 (LOW)	R/W		
121Ah	Multi-step speed reference 2	A022 (HIGH)	R/W	0/Starting frequency to Max. frequency	0.01 [Hz]
121Bh		A022 (LOW)	R/W		
121Ch	Multi-step speed reference 3	A023 (HIGH)	R/W	0/Starting frequency to Max. frequency	0.01 [Hz]
121Dh		A023 (LOW)	R/W		
121Eh	Multi-step speed reference 4	A024 (HIGH)	R/W	0/Starting frequency to Max. frequency	0.01 [Hz]
121Fh		A024 (LOW)	R/W		
1220h	Multi-step speed reference 5	A025 (HIGH)	R/W	0/Starting frequency to Max. frequency	0.01 [Hz]
1221h		A025 (LOW)	R/W		
1222h	Multi-step speed reference 6	A026 (HIGH)	R/W	0/Starting frequency to Max. frequency	0.01 [Hz]
1223h		A026 (LOW)	R/W		
1224h	Multi-step speed reference 7	A027 (HIGH)	R/W	0/Starting frequency to Max. frequency	0.01 [Hz]
1225h		A027 (LOW)	R/W		

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1226h	Multi-step speed reference 8	A028 (HIGH)	R/W	0/Starting frequency to Max. frequency	0.01 [Hz]
1227h		A028 (LOW)	R/W		
1228h	Multi-step speed reference 9	A029 (HIGH)	R/W	0/Starting frequency to Max. frequency	0.01 [Hz]
1229h		A029 (LOW)	R/W		
122Ah	Multi-step speed reference 10	A030 (HIGH)	R/W	0/Starting frequency to Max. frequency	0.01 [Hz]
122Bh		A030 (LOW)	R/W		
122Ch	Multi-step speed reference 11	A031 (HIGH)	R/W	0/Starting frequency to Max. frequency	0.01 [Hz]
122Dh		A031 (LOW)	R/W		
122Eh	Multi-step speed reference 12	A032 (HIGH)	R/W	0/Starting frequency to Max. frequency	0.01 [Hz]
122Fh		A032 (LOW)	R/W		
1230h	Multi-step speed reference 13	A033 (HIGH)	R/W	0/Starting frequency to Max. frequency	0.01 [Hz]
1231h		A033 (LOW)	R/W		
1232h	Multi-step speed reference 14	A034 (HIGH)	R/W	0/Starting frequency to Max. frequency	0.01 [Hz]
1233h		A034 (LOW)	R/W		
1234h	Multi-step speed reference 15	A035 (HIGH)	R/W	0/Starting frequency to Max. frequency	0.01 [Hz]
1235h		A035 (LOW)	R/W		
1236h	Not used	—	—		—
1237h	Not used	—	—		—
1238h	Jogging frequency	A038	R/W	Starting frequency to 999	0.01 [Hz]
1239h	Jogging stop selection	A039	R/W	00: FRS (Free-running on jogging stop/ Disabled in operation) 01: DEC (Deceleration stop on jogging stop/Disabled in operation) 02: DB (DC injection braking on jogging stop/Disabled in operation) 03: FRS (RUN) (Free running on jogging stop/Enabled in operation) 04: DEC (RUN) (Deceleration stop on jogging stop/Enabled in operation) 05: DB (RUN) (DC injection braking on jogging stop/Enabled in operation)	—
123Ah	Not used	—	—		—

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
123Bh	Torque boost selection	A041	R/W	00: Manual torque boost 01: Automatic torque boost	—
123Ch	Manual torque boost voltage	A042	R/W	0.0 to 20.0	0.1 [%]
123Dh	Manual torque boost frequency	A043	R/W	0.0 to 50.0	0.1 [%]
123Eh	V/f characteristics selection	A044	R/W	00: VC (Constant torque characteristics) 01: VP (Special reduced torque characteristics) 02: Free V/f (characteristics) 03: SLV (Sensorless vector control) 04: 0SLV (0-Hz sensorless vector control) 05: V2 (Sensor vector control)	—
123Fh	Output voltage gain	A045	R/W	20 to 100	1 [%]
1240h	Automatic torque boost voltage compensation gain	A046	R/W	0 to 255	1 [%]
1241h	Automatic torque boost slip compensation gain	A047	R/W	0 to 255	1 [%]
1242h to 1244h	Not used	—	—		—
1245h	DC injection braking selection	A051	R/W	00: OFF (Disabled) 01: ON (Enabled) 02: ON (FQ) (Frequency control [A052 set value])	—
1246h	DC injection braking frequency	A052	R/W	0.00 to 400.00	0.01 [Hz]
1247h	DC injection braking delay time	A053	R/W	0.0 to 5.0	0.1 [s]
1248h	DC injection braking power	A054	R/W	0 to 100 (0.4 to 55 kW) 0 to 80 (75 to 132 kW)	1 [%]
1249h	DC injection braking time	A055	R/W	0.0 to 60.0	0.1 [s]
124Ah	DC injection braking method selection	A056	R/W	00: Edge operation 01: Level operation	—
124Bh	Startup DC injection braking power	A057	R/W	0 to 100 (0.4 to 55 kW) 0 to 80 (75 to 132 kW)	1 [%]
124Ch	Startup DC injection braking time	A058	R/W	0.0 to 60.0	0.1 [s]
124Dh	DC injection braking carrier frequency	A059	R/W	0.5 to 15.0 (0.4 to 55 kW) 0.5 to 10.0 (75 to 132 kW)	0.1 [kHz]
124Eh	Not used	—	—		—
124Fh	Frequency upper limit	A061 (HIGH)	R/W	0.00/Frequency lower limit to Max. frequency	0.01 [Hz]
1250h		A061 (LOW)	R/W		
1251h	Frequency lower limit	A062 (HIGH)	R/W	0.00/Starting frequency to Frequency upper limit	0.01 [Hz]
1252h		A062 (LOW)	R/W		

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1253h	Jump frequency 1	A063 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
1254h		A063 (LOW)	R/W		
1255h	Jump frequency width 1	A064	R/W	0.00 to 10.00	0.01 [Hz]
1256h	Jump frequency 2	A065 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
1257h		A065 (LOW)	R/W		
1258h	Jump frequency width 2	A066	R/W	0.00 to 10.00	0.01 [Hz]
1259h	Jump frequency 3	A067 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
125Ah		A067 (LOW)	R/W		
125Bh	Jump frequency width 3	A068	R/W	0.00 to 10.00	0.01 [Hz]
125Ch	Acceleration stop frequency	A069 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
125Dh		A069 (LOW)	R/W		
125Eh	Acceleration stop time	A070	R/W	0.0 to 60.0	0.1 [s]
125Fh	PID selection	A071	R/W	00: OFF (Disabled) 01: ON (+) (Enabled) 02: ON (+/-) (Reverse output enabled)	—
1260h	PID P gain	A072	R/W	0.2 to 5.0	0.1
1261h	PID I gain	A073	R/W	0.0 to 3600.0	0.1 [s]
1262h	PID D gain	A074	R/W	0.00 to 100.00	0.01 [s]
1263h	PID scale	A075	R/W	0.01 to 99.99	0.01
1264h	PID feedback selection	A076	R/W	00: OI 01: O 02: Modbus (RS485 communication) 03: Pulse (Pulse train frequency) 10: Math (Operation function output)	—
1265h	Reverse PID function	A077	R/W	00: OFF (Deviation = Target value - Feedback value) 01: ON (Deviation = Feedback value - Target value)	—
1266h	PID output limit function	A078	R/W	0.0 to 100.0	0.1 [s]
1267h	PID feedforward selection	A079	R/W	00: Disabled 01: O 02: OI 03: O2	—
1268h	Not used	—	—		—
1269h	AVR selection	A081	R/W	00: Always ON 01: Always OFF 02: OFF during deceleration	—

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
126Ah	AVR voltage selection	A082	R/W	200-V class: 0 (200) 1 (215) 2 (220) 3 (230) 4 (240) 400-V class: 5 (380) 6 (400) 7 (415) 8 (440) 9 (460) 10 (480)	—
126Bh	Not used	—	—		—
126Ch	Not used	—	—		—
126Dh	RUN mode selection	A085	R/W	00: Normal operation 01: Energy-saving operation 02: Automatic operation	—
126Eh	Energy-saving response/ accuracy adjustment	A086	R/W	0.0 to 100.0	0.1 [%]
126Fh to 1273h	Not used	—	—		—
1274h	Acceleration time 2	A092 (HIGH)	R/W	0.01 to 3600.00	0.01 [s]
1275h		A092 (LOW)	R/W		
1276h	Deceleration time 2	A093 (HIGH)	R/W	0.01 to 3600.00	0.01 [s]
1277h		A093 (LOW)	R/W		
1278h	2-step acceleration/ deceleration selection	A094	R/W	00: 2CH-Terminal (Switched via multifunction input 09) 01: Preset FQ (Switched by setting) 02: FWD-REV (Enabled only when switching forward/reverse)	—
1279h	2-step acceleration frequency	A095 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
127Ah		A095 (LOW)	R/W		
127Bh	2-step deceleration frequency	A096 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
127Ch		A096 (LOW)	R/W		
127Dh	Acceleration pattern selection	A097	R/W	00: Line 01: S-curve 02: U-curve 03: inv.U curve 04: EL-S curve	—
127Eh	Deceleration pattern selection	A098	R/W	00: Line 01: S-curve 02: U-curve 03: inv.U curve 04: EL-S curve	—

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
127Fh	Not used	—	—		—
1280h	Not used	—	—		—
1281h	OI start frequency	A101 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
1282h		A101 (LOW)	R/W		
1283h	OI end frequency	A102 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
1284h		A102 (LOW)	R/W		
1285h	OI start ratio	A103	R/W	0 to OI end ratio	1 [%]
1286h	OI end ratio	A104	R/W	OI start ratio to 100	1 [%]
1287h	OI start selection	A105	R/W	00: Start FQ (Use OI start frequency [A101]) 01: 0 Hz	—
1288h to 128Ch	Not used	—	—		—
128Dh	O2 start frequency	A111 (HIGH)	R/W	-400.00 to 400.00	0.01 [Hz]
128Eh		A111 (LOW)	R/W		
128Fh	O2 end frequency	A112 (HIGH)	R/W	-400.00 to 400.00	0.01 [Hz]
1290h		A112 (LOW)	R/W		
1291h	O2 start ratio	A113	R/W	-100 to O2 end ratio	1 [%]
1292h	O2 end ratio	A114	R/W	O2 start ratio to 100	1 [%]
1293h to 12A4h	Not used	—	—		—
12A5h	Acceleration curve parameter	A131	R/W	01: Small curve to 10: Large curve	—
12A6h	Deceleration curve parameter	A132	R/W	01: Small curve to 10: Large curve	—
12A7h to 12AEh	Not used	—	—		—
12AFh	Operation frequency input A setting	A141	R/W	00: Operator (Digital Operator (F001)) 01: VR (Digital Operator (FREQ adjuster)) 02: O (Input O) 03: OI (Input OI) 04: Modbus (RS485 communication) 05: Option 1 06: Option 2 07: Pulse (Pulse train frequency)	—

4-4 Communication Function

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
12B0h	Operation frequency input B setting	A142	R/W	00: Operator (Digital Operator (F001)) 01: VR (Digital Operator (FREQ adjuster)) 02: O (Input O) 03: OI (Input OI) 04: Modbus (RS485 communication) 05: Option 1 06: Option 2 07: Pulse (Pulse train frequency)	—
12B1h	Operator selection	A143	R/W	00: ADD (Addition (A + B)) 01: SUB (Subtraction (A - B)) 02: MUL (Multiplication (A × B))	—
12B2h	Not used	—	—		—
12B3h	Frequency addition amount	A145 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
12B4h		A145 (LOW)	R/W		
12B5h	Frequency addition direction	A146	R/W	00: ADD (Frequency reference + A145) 01: SUB (Frequency reference - A145)	—
12B6h to 12B8h	Not used	—	—		—
12B9h	EL-S-curve ratio 1 during acceleration	A150	R/W	0 to 50	1 [%]
12BAh	EL-S-curve ratio 2 during acceleration	A151	R/W	0 to 50	1 [%]
12BBh	EL-S-curve ratio 1 during deceleration	A152	R/W	0 to 50	1 [%]
12BCh	EL-S-curve ratio 2 during deceleration	A153	R/W	0 to 50	1 [%]
12BDh to 1300h	Not used	—	—		—
1301h	Retry selection	b001	R/W	00: TRIP (Alarm) 01: 0-Hz start 02: f-match (Frequency matching start) 03: f-match Trip (Trip after frequency matching deceleration stop) 04: Actv. f-match (Active Frequency Matching restart)	—
1302h	Allowable momentary power interruption time	b002	R/W	0.3 to 25.0	0.1 [s]
1303h	Retry wait time	b003	R/W	0.3 to 100.0	0.1 [s]
1304h	Momentary power interruption/undervoltage trip during stop selection	b004	R/W	00: OFF (Disabled) 01: ON (Enabled) 02: Decel-OFF (Disabled during stop and deceleration stop)	—
1305h	Momentary power interruption retry time selection	b005	R/W	00: 16 times 01: No limit	—
1306h	Input phase loss protection selection	b006	R/W	00: OFF (Disabled) 01: ON (Enabled)	—

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1307h	Frequency matching lower limit frequency setting	b007 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
1308h		b007 (LOW)	R/W		
1309h	Trip retry selection	b008	R/W	00: TRIP (Alarm) 01: 0-Hz start 02: f-match (Frequency matching start) 03: f-match Trip (Trip after frequency matching deceleration stop) 04: Actv. f-match (Active Frequency Matching restart)	—
130Ah	Undervoltage retry time selection	b009	R/W	00: 16 times 01: No limit	—
130Bh	Overvoltage/overcurrent retry time selection	b010	R/W	1 to 3	—
130Ch	Trip retry wait time	b011	R/W	0.3 to 100.0	0.1 [s]
130Dh	Electronic thermal level	b012	R/W	0.20 x Rated current to 1.00 x Rated current	0.1 [A]
130Eh	Electronic thermal characteristics selection	b013	R/W	00: Reduced TRQ (Reduced torque characteristics) 01: Const TRQ (Constant torque characteristics) 02: Free set (Free setting)	—
130Fh	Not used	—	—		—
1310h	Free setting, electronic thermal frequency 1	b015	R/W	0 to 400	1 [Hz]
1311h	Free setting, electronic thermal current 1	b016	R/W	0.0 to Rated current	0.1 [A]
1312h	Free setting, electronic thermal frequency 2	b017	R/W	0 to 400	1 [Hz]
1313h	Free setting, electronic thermal current 2	b018	R/W	0.0 to Rated current	0.1 [A]
1314h	Free setting, electronic thermal frequency 3	b019	R/W	0 to 400	1 [Hz]
1315h	Free setting, electronic thermal current 3	b020	R/W	0.0 to Rated current	0.1 [A]
1316h	Overload limit selection	b021	R/W	00: OFF (Disabled) 01: ON-Acc/Cnst (Enabled in acceleration/constant speed operation) 02: ON-Cnst (Enabled during constant speed operation) 03: ON-A/C (R) (Enabled in acceleration/constant speed operation (accelerates during regeneration))	—
1317h	Overload limit level	b022	R/W	0.20 x Rated current to 2.00 x Rated current (0.4 to 55 kW) 0.20 x Rated current to 1.80 x Rated current (75 to 132 kW)	0.1 [A]
1318h	Overload limit parameter	b023	R/W	0.10 to 30.00	0.01 [s]

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1319h	Overload limit selection 2	b024	R/W	00: OFF (Disabled) 01: ON-Acc/Cnst (Enabled in acceleration/constant speed operation) 02: ON-Cnst (Enabled during constant speed operation) 03: ON-A/C (R) (Enabled in acceleration/constant speed operation (accelerates during regeneration))	—
131Ah	Overload limit level 2	b025	R/W	0.20 x Rated current to 2.00 x Rated current (0.4 to 55 kW) 0.20 x Rated current to 1.80 x Rated current (75 to 132 kW)	0.1 [A]
131Bh	Overload limit parameter 2	b026	R/W	0.10 to 30.00	0.01 [s]
131Ch	Overcurrent suppression function	b027	R/W	00: OFF (Disabled) 01: ON (Enabled)	—
131Dh	Active Frequency Matching restart level	b028	R/W	0.20 x Rated current to 2.00 x Rated current (0.4 to 55 kW) 0.20 x Rated current to 1.80 x Rated current (75 to 132 kW)	0.1 [A]
131Eh	Active Frequency Matching restart parameter	b029	R/W	0.10 to 30.00	0.01 [s]
131Fh	Starting frequency at Active Frequency Matching restart	b030	R/W	00: Off FQ (Frequency at interruption) 01: Max.FQ (Max. frequency) 02: Set FQ (Set frequency)	—
1320h	Soft lock selection	b031	R/W	00: Lock (SFT) (Data other than b031 cannot be changed when terminal SFT is ON) 01: Only FQ (SFT) (Data other than b031 and the specified frequency parameter cannot be changed when terminal SFT is ON) 02: Lock (Data other than b031 cannot be changed) 03: Only FQ (Data other than b031 and the specified frequency parameter cannot be changed) 10: RUN chg mode (Data other than parameters changeable during operation cannot be changed)	—
1321h	Not used	—	—		—
1322h	Not used	—	—		—
1323h	RUN time/Power ON time setting	b034 (HIGH)	R/W	0 to 65535	1 [h]
1324h		b034 (LOW)	R/W		
1325h	Rotation direction limit selection	b035	R/W	00: FREE (Forward and Reverse are enabled) 01: FWD (Only Forward is enabled) 02: REV (Only Reverse is enabled)	—
1326h	Reduced voltage startup selection	b036	R/W	0: (Reduced voltage startup time: Short) to 255: (Reduced voltage startup time: Long)	—

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1327h	Display selection	b037	R/W	00: All (Complete display) 01: Utilized (Individual display of functions) 02: User (User setting) 03: Compare (Data comparison display) 04: Basic (Basic display)	—
1328h	Initial screen selection	b038	R/W	000 to 202	—
1329h	User parameter automatic setting function selection	b039	R/W	00: OFF (Disabled) 01: ON (Enabled)	—
132Ah	Torque limit selection	b040	R/W	00: 4-quadrant (Four-quadrant separate setting) 01: TRQ input (Terminal switch) 02: [O] input (Analog Input) 03: Option 1 04: Option 2	—
132Bh	Torque limit 1 (Four-quadrant mode forward power running)	b041	R/W	0 to 200 (0.4 to 55 kW)/ 0 to 180 (75 to 132 kW) no (Torque limit disabled)	1 [%]
132Ch	Torque limit 2 (Four-quadrant mode reversed regeneration)	b042	R/W	0 to 200 (0.4 to 55 kW)/ 0 to 180 (75 to 132 kW) no (Torque limit disabled)	1 [%]
132Dh	Torque limit 3 (Four-quadrant mode reversed power running)	b043	R/W	0 to 200 (0.4 to 55 kW)/ 0 to 180 (75 to 132 kW) no (Torque limit disabled)	1 [%]
132Eh	Torque limit 4 (Four-quadrant mode forward regeneration)	b044	R/W	0 to 200 (0.4 to 55 kW)/ 0 to 180 (75 to 132 kW) no (Torque limit disabled)	1 [%]
132Fh	Torque LADSTOP selection	b045	R/W	00: OFF (Disabled) 01: ON (Enabled)	—
1330h	Reverse rotation prevention selection	b046	R/W	00: OFF (Disabled) 01: ON (Enabled)	—
1331h to 1332h	Not used	—	—		—
1333h	Dual rate selection	b049	R/W	00: CT (Constant torque) 01: VT (Variable torque)	—
1334h	Selection of non-stop function at momentary power interruption	b050	R/W	00: OFF (Disabled) 01: V-Cnst (STOP) (Enabled (Deceleration stop)) 02: NS1 (Enabled (without recovery)) 03: NS2 (Enabled (with recovery))	—
1335h	Starting voltage of non-stop function at momentary power interruption	b051	R/W	0.0 to 1000.0	0.1 [V]
1336h	Starting deceleration level of non-stop function at momentary power interruption	b052	R/W	0.0 to 1000.0	0.1 [V]
1337h	Deceleration time of non-stop function at momentary power interruption	b053 (HIGH)	R/W	0.01 to 3600.00	0.01 [s]
1338h		b053 (LOW)	R/W		

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1339h	Deceleration starting width of non-stop function at momentary power interruption	b054	R/W	0.00 to 10.00	0.01 [Hz]
133Ah	Proportional gain setting of non-stop function at momentary power interruption	b055	R/W	0.00 to 2.55	0.01
133Bh	Integral time setting of non-stop function at momentary power interruption	b056	R/W	0.000 to 65.535	0.001 [s]
133Ch to 133Eh	Not used	—	—		—
133Fh	Window comparator O upper limit level	b060	R/W	Set an upper limit level. Setting range: 0 to 100 Lower limit: Lower limit level + Hysteresis width × 2	1 [%]
1340h	Window comparator O lower limit level	b061	R/W	Set a lower limit level. Setting range: 0 to 100 Upper limit: Upper limit level - Hysteresis width × 2	1 [%]
1341h	Window comparator O hysteresis width	b062	R/W	Set a hysteresis width for the upper and lower limit levels. Setting range: 0 to 10 Upper limit: (Upper limit level - Lower limit level) × 2	1 [%]
1342h	Window comparator OI upper limit level	b063	R/W	Set an upper limit level. Setting range: 0 to 100 Lower limit: Lower limit level + Hysteresis width × 2	1 [%]
1343h	Window comparator OI lower limit level	b064	R/W	Set a lower limit level. Setting range: 0 to 100 Upper limit: Upper limit level - Hysteresis width × 2	1 [%]
1344h	Window comparator OI hysteresis width	b065	R/W	Set a hysteresis width for the upper and lower limit levels. Setting range: 0 to 10 Upper limit: (Upper limit level - Lower limit level) × 2	1 [%]
1345h	Window comparator O2 upper limit level	b066	R/W	Set an upper limit level. Setting range: -100 to 100 Lower limit: Lower limit level + Hysteresis width × 2	1 [%]
1346h	Window comparator O2 lower limit level	b067	R/W	Set a lower limit level. Setting range: -100 to 100 Upper limit: Upper limit level - Hysteresis width × 2	1 [%]
1347h	Window comparator O2 hysteresis width	b068	R/W	Set a hysteresis width for the upper and lower limit levels. Setting range: 0 to 10 Upper limit: (Upper limit level - Lower limit level) × 2	1 [%]

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1348h	Not used	—	—		—
1349h	Analog operation level at O disconnection	b070	R/W	0 to 100/no (ignored)	1 [%]
134Ah	Analog operation level at OI disconnection	b071	R/W	0 to 100/no (ignored)	1 [%]
134Bh	Analog operation level at O2 disconnection	b072	R/W	-100 to 100/no (ignored)	1 [%]
134Ch to 1350	Not used	—	—		—
1351h	Integrated power clear	b078	R/W	Cleared with the Enter key after changing to 01	—
1352h	Integrated power display gain	b079	R/W	1 to 1000	1
1353h	Not used	—	—		—
1354h	Not used	—	—		—
1355h	Starting frequency	b082	R/W	0.10 to 9.99	0.01 [Hz]
1356h	Carrier frequency	b083	R/W	0.5 to 15.0 (0.4 to 55 kW) 0.5 to 10.0 (75 to 132 kW)	0.1 [kHz]
1357h	Initialization selection	b084	R/W	00: no (Clears the trip monitor) 01: Trip data (Initializes data) 02: Parameters (Clears the trip monitor and initializes data) 03: Trip+Param (Clears the trip monitor and parameters) 04: Trp+Prm+EzSQ (Clears the trip monitor, parameters and Drive Program)	—
1358h	Initialization parameter selection	b085	R/W	01 *Do not change.	—
1359h	Frequency conversion coefficient	b086	R/W	0.1 to 99.9	0.1
135Ah	STOP key selection	b087	R/W	00: ON (Enabled) 01: OFF (Disabled) 02: Only RESET (Disabled only during stop)	—
135Bh	Free-run stop selection	b088	R/W	00: 0-Hz start 01: f-match (Frequency matching start) 02: Actv. f-match (Active Frequency Matching restart)	—
135Ch	Automatic carrier reduction	b089	R/W	00: OFF (Disabled) 01: ON (Enabled)	—
135Dh	Usage rate of regenerative braking function	b090	R/W	0.0 to 100.0	0.1 [%]
135Eh	Stop selection	b091	R/W	00: Decel-Stop (Deceleration → Stop) 01: Free-RUN (Free-run stop)	—
135Fh	Cooling fan control	b092	R/W	00: Alws-ON (Always ON) 01: ON in RUN (ON during RUN)	—
1360h	Not used	—	—		—
1361h	Not used	—	—		—

4-4 Communication Function

4

Functions

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1362h	Regenerative braking function operation selection	b095	R/W	00: OFF (Disabled) 01: RUN-ON (Enabled (Disabled during stop)) 02: Alws-ON (Enabled (Enabled during stop))	—
1363h	Regenerative braking function ON level	b096	R/W	330 to 380 660 to 760	1 [V]
1364h	Not used	—	—		—
1365h	Thermistor selection	b098	R/W	00: Disabled 01: PTC enabled 02: NTC enabled	—
1366h	Thermistor error level	b099	R/W	0 to 9999	1 [Ω]
1367h	Free V/f frequency 1	b100	R/W	0 to Free V/f frequency 2	1 [Hz]
1368h	Free V/f voltage 1	b101	R/W	0.0 to 800.0	0.1 [V]
1369h	Free V/f frequency 2	b102	R/W	0 to Free V/f frequency 3	1 [Hz]
136Ah	Free V/f voltage 2	b103	R/W	0.0 to 800.0	0.1 [V]
136Bh	Free V/f frequency 3	b104	R/W	0 to Free V/f frequency 4	1 [Hz]
136Ch	Free V/f voltage 3	b105	R/W	0.0 to 800.0	0.1 [V]
136Dh	Free V/f frequency 4	b106	R/W	0 to Free V/f frequency 5	1 [Hz]
136Eh	Free V/f voltage 4	b107	R/W	0.0 to 800.0	0.1 [V]
136Fh	Free V/f frequency 5	b108	R/W	0 to Free V/f frequency 6	1 [Hz]
1370h	Free V/f voltage 5	b109	R/W	0.0 to 800.0	0.1 [V]
1371h	Free V/f frequency 6	b110	R/W	0 to Free V/f frequency 7	1 [Hz]
1372h	Free V/f voltage 6	b111	R/W	0.0 to 800.0	0.1 [V]
1373h	Free V/f frequency 7	b112	R/W	0 to 400	1 [Hz]
1374h	Free V/f voltage 7	b113	R/W	0.0 to 800.0	0.1 [V]
1375h to 137Ah	Not used	—	—		—
137Bh	Brake control selection	b120	R/W	00: OFF (Disabled) 01: ON (Enabled)	—
137Ch	Brake wait time for release	b121	R/W	0.00 to 5.00	0.01 [s]
137Dh	Brake wait time for acceleration	b122	R/W	0.00 to 5.00	0.01 [s]
137Eh	Brake wait time for stopping	b123	R/W	0.00 to 5.00	0.01 [s]
137Fh	Brake wait time for confirmation	b124	R/W	0.00 to 5.00	0.01 [s]
1380h	Brake release frequency	b125	R/W	0.00 to 400.00	0.01 [Hz]
1381h	Brake release current	b126	R/W	0.0 to 2.00 x Rated current (0.4 to 55 kW) 0.0 to 1.80 x Rated current (75 to 132 kW)	0.1 [A]
1382h	Brake input frequency	b127	R/W	0.00 to 400.00	0.01 [Hz]
1383h	Not used	—	—		—
1384h	Not used	—	—		—

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1385h	Overvoltage protection function selection during deceleration	b130	R/W	00: OFF (Disabled) 01: V-const (DC voltage kept constant) 02: Accel (Acceleration enabled)	—
1386h	Overvoltage protection level during deceleration	b131	R/W	200-V class: 330 to 390 (V) 400-V class: 660 to 780 (V)	1 [V]
1387h	Overvoltage protection parameter	b132	R/W	0.10 to 30.00	0.01 [s]
1388h	Overvoltage protection proportional gain setting	b133	R/W	0.00 to 2.55	0.01
1389h	Overvoltage protection integral time setting	b134	R/W	0.000 to 65.535	0.001 [s]
1390h to 1400h	Not used	—	—		—

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1401h	Multi-function input 1 selection	C001	R/W	01: RV (reverse) 02: CF1 (multi-step speed setting binary 1) 03: CF2 (multi-step speed setting binary 2) 04: CF3 (multi-step speed setting binary 3) 05: CF4 (multi-step speed setting binary 4) 06: JG (jogging) 07: DB (external DC injection braking) 08: SET (2nd control) 09: 2CH (2-step acceleration/deceleration) 11: FRS (free-run stop) 12: EXT (external trip) 13: USP (USP function) 14: CS (commercial switch) 15: SFT (soft lock) 16: AT (analog input switching) 17: SET3 (3rd control) 18: RS (reset) 20: STA (3-wire start) 21: STP (3-wire stop) 22: F/R (3-wire forward/reverse) 23: PID (PID enabled/disabled) 24: PIDC (PID integral reset) 26: CAS (control gain switching) 27: UP (UP/DWN function accelerated) 28: DWN (UP/DWN function decelerated) 29: UDC (UP/DWN function data clear) 31: OPE (forced operator) 32: SF1 (multi-step speed setting bit 1) 33: SF2 (multi-step speed setting bit 2) 34: SF3 (multi-step speed setting bit 3) 35: SF4 (multi-step speed setting bit 4) 36: SF5 (multi-step speed setting bit 5) 37: SF6 (multi-step speed setting bit 6) 38: SF7 (multi-step speed setting bit 7) 39: OLR (overload limit switching) 40: TL (torque limit enabled) 41: TRQ1 (torque limit switching 1) 42: TRQ2 (torque limit switching 2) 43: PPI (P/PI switching) 44: BOK (Brake confirmation) 45: ORT (orientation) 46: LAC (LAD cancel) 47: PCLR (position deviation clear) 48: STAT (pulse train position command input permission)	—
1402h	Multi-function input 2 selection	C002	R/W	50: ADD (frequency addition) 51: F-TM (forced terminal block) 52: ATR (torque command input permission) 53: KHC (integrated power clear) 54: SON (servo ON) 55: FOC (preliminary excitation) 56: MI1 (Drive Programming input 1) 57: MI2 (Drive Programming input 2) 58: MI3 (Drive Programming input 3) 59: MI4 (Drive Programming input 4) 60: MI5 (Drive Programming input 5) 61: MI6 (Drive Programming input 6) 62: MI7 (Drive Programming input 7) 63: MI8 (Drive Programming input 8) 65: AHD (analog command held) 66: CP1 (position command selection 1) 67: CP2 (position command selection 2) 68: CP3 (position command selection 3) 69: ORL (zero return limit signal) 70: ORG (zero return startup signal) 71: FOT (forward driving stop) 72: ROT (reverse driving stop) 73: SPD (speed/position switching) 74: PCNT (pulse counter) 75: PCC (pulse counter clear) 82: PRG (Drive program start) no: NO (no allocation)	—
1403h	Multi-function input 3 selection	C003	R/W		—
1404h	Multi-function input 4 selection	C004	R/W		—
1405h	Multi-function input 5 selection	C005	R/W		—
1406h	Multi-function input 6 selection	C006	R/W		—
1407h	Multi-function input 7 selection	C007	R/W		—
1408h	Multi-function input 8 selection	C008	R/W		—
1409h	Not used	—	—		—
140Ah	Not used	—	—		—

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
140Bh	Multi-function input 1 operation selection	C011	R/W	00: NO 01: NC	—
140Ch	Multi-function input 2 operation selection	C012	R/W		—
140Dh	Multi-function input 3 operation selection	C013	R/W		—
140Eh	Multi-function input 4 operation selection	C014	R/W		—
140Fh	Multi-function input 5 operation selection	C015	R/W		—
1410h	Multi-function input 6 operation selection	C016	R/W		—
1411h	Multi-function input 7 operation selection	C017	R/W		—
1412h	Multi-function input 8 operation selection	C018	R/W		—
1413h	FW terminal operation selection	C019	R/W		—
1414h	Not used	—	—		—

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1415h	Multi-function output terminal 11 selection	C021	R/W	00: RUN (signal during RUN) 01: FA1 (constant speed arrival signal) 02: FA2 (over set frequency arrival signal) 03: OL (overload warning) 04: OD (excessive PID deviation) 05: AL (alarm output) 06: FA3 (set-frequency-only arrival signal) 07: OTQ (overtorque) 08: IP (signal during momentary power interruption)	—
1416h	Multi-function output terminal 12 selection	C022	R/W	09: UV (signal during undervoltage) 10: TRQ (torque limit) 11: RNT (RUN time over) 12: ONT (Power ON time over) 13: THM (thermal warning) 19: BRK (brake release) 20: BER (brake error) 21: ZS (0 Hz signal) 22: DSE (excessive speed deviation) 23: POK (position ready)	—
1417h	Multi-function output terminal 13 selection	C023	R/W	24: FA4 (set frequency exceeded 2) 25: FA5 (set frequency only 2) 26: OL2 (overload warning 2) 27: ODc (analog O disconnection detection) 28: OIdc (analog OI disconnection detection) 29: O2Dc (analog O2 disconnection detection) 31: FBV (PID FB status output) 32: NDc (network error)	—
1418h	Multi-function output terminal 14 selection	C024	R/W	33: LOG1 (logic operation output 1) 34: LOG2 (logic operation output 2) 35: LOG3 (logic operation output 3) 36: LOG4 (logic operation output 4) 37: LOG5 (logic operation output 5) 38: LOG6 (logic operation output 6) 39: WAC (capacitor life warning signal) 40: WAF (cooling fan life warning signal) 41: FR (starting contact signal) 42: OHF (fin overheat warning)	—
1419h	Multi-function output terminal 15 selection	C025	R/W	43: LOC (light load detection signal) 44: MO1 (Drive Programming output 1) 45: MO2 (Drive Programming output 2) 46: MO3 (Drive Programming output 3) 47: MO4 (Drive Programming output 4) 48: MO5 (Drive Programming output 5) 49: MO6 (Drive Programming output 6) 50: IRDY (operation ready signal) 51: FWR (forward run signal) 52: RVR (reverse run signal)	—
141Ah	Relay output (AL2, AL1) function selection	C026	R/W	53: MJA (fatal fault signal) 54: WCO (window comparator O) 55: WCOI (window comparator OI) 56: WCO2 (window comparator O2) 63: OPO (option board output) no: Not used (When alarm code output is selected in C062, AC0 to AC2, or AC0 to AC3 (ACn: alarm code output) are forced to be allocated to multi-function output terminals 11 to 13, or 11 to 14.)	—

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
141Bh	FM selection	C027	R/W	00: Output FQ (Output frequency) 01: Output I (Output current) 02: Output TRQ (Output torque) 03: Pulse FQ (Digital output frequency) 04: Output V (Output voltage) 05: Power 06: Thermal (Thermal load rate) 07: LAD-FQ (LAD frequency) 08: Pulse I (Digital current monitor) 09: Motor tmp (Motor temperature) 10: Heatsink tmp (Fin temperature) 12: YA0 (Drive Programming) 19: OP1 (Option board 1) 20: OP2 (Option board 2)	—
141Ch	AM selection	C028	R/W	00: Output FQ (Output frequency) 01: Output I (Output current) 02: Output TRQ (Output torque) 04: Output V (Output voltage) 05: Power 06: Thermal (Thermal load rate) 07: LAD-FQ (LAD frequency) 08: Pulse I (Digital current monitor) 09: Motor tmp (Motor temperature) 10: Heatsink tmp (Fin temperature) 11: Out TRQ sign (Output torque (signed)) 13: YA1 (Drive Programming) 19: OP1 (Option board 1) 20: OP2 (Option board 2)	—
141Dh	AMI selection	C029	R/W	00: Output FQ (Output frequency) 01: Output I (Output current) 02: Output TRQ (Output torque) 04: Output V (Output voltage) 05: Power 06: Thermal (Thermal load rate) 07: LAD-FQ (LAD frequency) 09: Motor tmp (Motor temperature) 10: Heatsink tmp (Fin temperature) 14: YA2 (Drive Programming)	—
141Eh	Digital current monitor reference value	C030	R/W	0.20 × Rated current to 2.00 × Rated current (Under 55 kW) 0.20 × Rated current to 1.50 × Rated current (Over 75 kW) (Current value at the digital current monitor output 1440 Hz)	0.1 [A]

4-4 Communication Function

4

Functions

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
141Fh	Multi-function output terminal 11 contact selection	C031	R/W	00: NO 01: NC	—
1420h	Multi-function output terminal 12 contact selection	C032	R/W		—
1421h	Multi-function output terminal 13 contact selection	C033	R/W		—
1422h	Multi-function output terminal 14 contact selection	C034	R/W		—
1423h	Multi-function output terminal 15 contact selection	C035	R/W		—
1424h	Relay output (AL2, AL1) contact selection	C036	R/W	00: NO contact at AL2, NC contact at AL1 01: NC contact at AL2, NO contact at AL1	—
1425h	Not used	—	—		—
1426h	Light load signal output mode	C038	R/W	00: ACC/DEC/CST (Enabled during acceleration/deceleration/constant speed) 01: Const (Enabled only during constant speed)	—
1427h	Light load detection level	C039	R/W	0.0 to 2.00 x Rated current (0.4 to 55 kW) 0.0 to 1.80 x Rated current (75 to 132 kW)	0.1 [A]
1428h	Overload warning signal output mode	C040	R/W	00: ACC/DEC/CST (Enabled during acceleration/deceleration/constant speed) 01: Const (Enabled only during constant speed)	—
1429h	Overload warning level	C041	R/W	0.0: Does not operate. 0.1 x Rated current to 2.00 x Rated current (0.4 to 55 kW) 0.1 x Rated current to 1.80 x Rated current (75 to 132 kW)	0.1 [A]
142Ah	Arrival frequency during acceleration	C042 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
142Bh		C042 (LOW)	R/W		
142Ch	Arrival frequency during deceleration	C043 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
142Dh		C043 (LOW)	R/W		
142Eh	PID deviation excessive level	C044	R/W	0.0 to 100.0	0.1 [%]
142Fh	Arrival frequency during acceleration 2	C045 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
1430h		C045 (LOW)	R/W		

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1431h	Arrival frequency during deceleration 2	C046 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
1432h		C046 (LOW)	R/W		
1433h to 1437h	Not used	—	—		—
1438h	PID FB upper limit	C052	R/W	0.0 to 100.0	0.1 [%]
1439h	PID FB lower limit	C053	R/W	0.0 to 100.0	0.1 [%]
143Ah	Not used	—	—		—
143Bh	Overtorque level (Forward power running)	C055	R/W	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW)	1 [%]
143Ch	Overtorque level (Reverse regeneration)	C056	R/W	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW)	1 [%]
143Dh	Overtorque level (Reverse power running)	C057	R/W	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW)	1 [%]
143Eh	Overtorque level (Forward regeneration)	C058	R/W	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW)	1 [%]
143Fh	Not used	—	—		—
1440h	Not used	—	—		—
1441h	Thermal warning level	C061	R/W	0 to 100	1 [%]
1442h	Alarm code selection	C062	R/W	00: OFF (Disabled) 01: 3-bit 02: 4-bit	—
1443h	0-Hz detection level	C063	R/W	0.00 to 100.00	0.01 [Hz]
1444h	Fin overheat warning level	C064	R/W	0 to 200	1 [°C]
1445h to 144Ah	Not used	—	—		—
144Bh	Communication speed selection (Baud rate selection)	C071	R/W	02: Loop-back test 03: 2400 bps 04: 4800 bps 05: 9600 bps 06: 19200 bps	—
144Ch	Communication station No. selection	C072	R/W	1 to 247	—
144Dh	Communication bit length selection	C073	R/W	7: 7-bit 8: 8-bit	—
144Eh	Communication parity selection	C074	R/W	00: No parity 01: Even 02: Odd	—
144Fh	Communication stop bit selection	C075	R/W	1: 1-bit 2: 2-bit	—

4-4 Communication Function

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1450h	Communication error selection	C076	R/W	00: Trip 01: Decel-Trip (Trip after deceleration stop) 02: Ignore 03: Free-RUN (Free-run stop) 04: Decel-Stop (Deceleration stop)	—
1451h	Communication error timeout	C077	R/W	0.00 to 99.99	0.01 [s]
1452h	Communication wait time	C078	R/W	0 to 1000	1 [ms]
1453h	Communication method selection	C079	R/W	00: ASCII 01: ModBus-RTU	—
1454h	Not used	—	—		—
1455h	O adjustment	C081	R/W	0 to 65535	1
1456h	OI adjustment	C082	R/W	0 to 65535	1
1457h	O2 adjustment	C083	R/W	0 to 65535	1
1458h	Not used	—	—		—
1459h	Thermistor adjustment	C085	R/W	0.0 to 1000.0	0.1
145Ah to 145Eh	Not used	—	—		—
145Fh	Debug mode selection	C091	R/W	00 *Do not change	—
1460h to 1468h	Not used	—	—		—
1469h	UP/DWN selection	C101	R/W	00: Not save (Do not store the frequency data) 01: Save (Store the frequency data)	—
146Ah	Reset selection	C102	R/W	00: ON-RESET (Trip reset at power-on) 01: OFF-RESET (Trip reset at power-off) 02: On in Trip (Enabled only during trip (Reset at power-on)) 03: Trip RESET (Trip reset only)	—
146Bh	Reset frequency matching selection	C103	R/W	00: 0-Hz start 01: f-match (Frequency matching start) 02: Actv. f-match (Active Frequency Matching restart)	—
146Ch	Not used	—	—		—
146Dh	FM gain setting	C105	R/W	50 to 200	1 [%]
146Eh	AM gain setting	C106	R/W	50 to 200	1 [%]
146Fh	AMI gain setting	C107	R/W	50 to 200	1 [%]
1470h	Not used	—	—		—
1471h	AM bias setting	C109	R/W	0 to 100	1 [%]
1472h	AMI bias setting	C110	R/W	0 to 100	1 [%]
1473h	Overload warning level 2	C111	R/W	0.0 to 2.00 x Rated current (0.4 to 55 kW) 0.0 to 1.80 x Rated current (75 to 132 kW)	0.1 [A]

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1474h to 147Ch	Not used	—	—		—
147Dh	O zero adjustment	C121	R/W	0 to 65535	1
147Eh	OI zero adjustment	C122	R/W	0 to 65535	1
147Fh	O2 zero adjustment	C123	R/W	0 to 65535	1
1480h to 1485h	Not used	—	—		—
1486h	Output 11 ON delay	C130	R/W	0.0 to 100.0	0.1 [s]
1487h	Output 11 OFF delay	C131	R/W		0.1 [s]
1488h	Output 12 ON delay	C132	R/W		0.1 [s]
1489h	Output 12 OFF delay	C133	R/W		0.1 [s]
148Ah	Output 13 ON delay	C134	R/W		0.1 [s]
148Bh	Output 13 OFF delay	C135	R/W		0.1 [s]
148Ch	Output 14 ON delay	C136	R/W		0.1 [s]
148Dh	Output 14 OFF delay	C137	R/W		0.1 [s]
148Eh	Output 15 ON delay	C138	R/W		0.1 [s]
148Fh	Output 15 OFF delay	C139	R/W		0.1 [s]
1490h	Relay output ON delay	C140	R/W		0.1 [s]
1491h	Relay output OFF delay	C141	R/W		0.1 [s]
1492h	Logic output signal 1 selection 1	C142	R/W	Same as C021 to C026 (except LOG1 to LOG6)	—
1493h	Logic output signal 1 selection 2	C143	R/W	Same as C021 to C026 (except LOG1 to LOG6)	—
1494h	Logic output signal 1 operator selection	C144	R/W	00: AND 01: OR 02: XOR	—
1495h	Logic output signal 2 selection 1	C145	R/W	Same as C021 to C026 (except LOG1 to LOG6)	—
1496h	Logic output signal 2 selection 2	C146	R/W	Same as C021 to C026 (except LOG1 to LOG6)	—
1497h	Logic output signal 2 operator selection	C147	R/W	00: AND 01: OR 02: XOR	—
1498h	Logic output signal 3 selection 1	C148	R/W	Same as C021 to C026 (except LOG1 to LOG6)	—
1499h	Logic output signal 3 selection 2	C149	R/W	Same as C021 to C026 (except LOG1 to LOG6)	—
149Ah	Logic output signal 3 operator selection	C150	R/W	00: AND 01: OR 02: XOR	—
149Bh	Logic output signal 4 selection 1	C151	R/W	Same as C021 to C026 (except LOG1 to LOG6)	—
149Ch	Logic output signal 4 selection 2	C152	R/W	Same as C021 to C026 (except LOG1 to LOG6)	—

4-4 Communication Function

4

Functions

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
149Dh	Logic output signal 4 operator selection	C153	R/W	00: AND 01: OR 02: XOR	—
149Eh	Logic output signal 5 selection 1	C154	R/W	Same as C021 to C026 (except LOG1 to LOG6)	—
149Fh	Logic output signal 5 selection 2	C155	R/W	Same as C021 to C026 (except LOG1 to LOG6)	—
14A0h	Logic output signal 5 operator selection	C156	R/W	00: AND 01: OR 02: XOR	—
14A1h	Logic output signal 6 selection 1	C157	R/W	Same as C021 to C026 (except LOG1 to LOG6)	—
14A2h	Logic output signal 6 selection 2	C158	R/W	Same as C021 to C026 (except LOG1 to LOG6)	—
14A3h	Logic output signal 6 operator selection	C159	R/W	00: AND 01: OR 02: XOR	—
14A4h	Input terminal response time 1	C160	R/W	0 to 200 (× 2 ms)	1
14A5h	Input terminal response time 2	C161	R/W	0 to 200 (× 2 ms)	1
14A6h	Input terminal response time 3	C162	R/W	0 to 200 (× 2 ms)	1
14A7h	Input terminal response time 4	C163	R/W	0 to 200 (× 2 ms)	1
14A8h	Input terminal response time 5	C164	R/W	0 to 200 (× 2 ms)	1
14A9h	Input terminal response time 6	C165	R/W	0 to 200 (× 2 ms)	1
14AAh	Input terminal response time 7	C166	R/W	0 to 200 (× 2 ms)	1
14ABh	Input terminal response time 8	C167	R/W	0 to 200 (× 2 ms)	1
14ACh	FW terminal response time	C168	R/W	0 to 200 (× 2 ms)	1
14ADh	Multi-step speed/position determination time	C169	R/W	0 to 200 (× 2 ms)	1
14AEh to 1500h	Not used	—	—		—
1501h	Auto-tuning selection	H001	R/W	00: OFF (Disabled) 01: ON (STOP) 02: ON (Rotation)	—
1502h	Motor parameter selection	H002	R/W	00: Standard motor parameter 01: Auto-tuning parameter 02: Auto-tuning parameter (online auto-tuning enabled)	—
1503h	Motor capacity selection	H003	R/W	0.20 to 160.0	0.1 [kW]
1504h	Motor pole number selection	H004	R/W	2/4/6/8/10	Pole

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1505h	Speed response	H005 (HIGH)	R/W	0.001 to 80.000	0.001
1506h		H005 (LOW)	R/W		
1507h	Stabilization parameter	H006	R/W	0 to 255	1
1508h to 1514h	Not used	—	—		—
1515h	Motor parameter R1	H020 (HIGH)	R/W	0.001 to 65.535	0.001 [Ω]
1516h		H020 (LOW)	R/W		
1517h	Motor parameter R2	H021 (HIGH)	R/W	0.001 to 65.535	0.001 [Ω]
1518h		H021 (LOW)	R/W		
1519h	Motor parameter L	H022 (HIGH)	R/W	0.01 to 655.35	0.01 [mH]
151Ah		H022 (LOW)	R/W		
151Bh	Motor parameter IO	H023 (HIGH)	R/W	0.01 to 655.35	0.01 [A]
151Ch		H023 (LOW)	R/W		
151Dh	Motor parameter J	H024 (HIGH)	R/W	0.001 to 9999.000	0.001 [kgm ²]
151Eh		H024 (LOW)	R/W		
151Fh to 1523h	Not used	—	—		—
1524h	Motor parameter R1 (auto-tuning data)	H030 (HIGH)	R/W	0.001 to 65.535	0.001 [Ω]
1525h		H030 (LOW)	R/W		
1526h	Motor parameter R2 (auto-tuning data)	H031 (HIGH)	R/W	0.001 to 65.535	0.001 [Ω]
1527h		H031 (LOW)	R/W		
1528h	Motor parameter L (auto-tuning data)	H032 (HIGH)	R/W	0.01 to 655.35	0.01 [mH]
1529h		H032 (LOW)	R/W		
152Ah	Motor parameter IO (auto-tuning data)	H033 (HIGH)	R/W	0.01 to 655.35	0.01 [A]
152Bh		H033 (LOW)	R/W		

4-4 Communication Function

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
152Ch	Motor parameter J (auto-tuning data)	H034 (HIGH)	R/W	0.001 to 9999.000	0.001 [kgm ²]
152Dh		H034 (LOW)	R/W		
152Eh to 153Ch	Not used	—	—		—
153Dh	PI proportional gain	H050	R/W	0.0 to 1000.0	0.1 [%]
153Eh	PI integral gain	H051	R/W	0.0 to 1000.0	0.1 [%]
153Fh	P proportional gain	H052	R/W	0.01 to 10.00	0.01
1540h to 1546h	Not used	—	—		—
1547h	Limit at 0 Hz	H060	R/W	0.0 to 100.0	0.1 [%]
1548h	Boost amount at SLV startup, 0 Hz	H061	R/W	0 to 50	1 [%]
1549h to 1550h	Not used	—	—		—
1551h	For PI proportional gain switching	H070	R/W	0.0 to 1000.0	0.1 [%]
1552h	For PI integral gain switching	H071	R/W	0.0 to 1000.0	0.1 [%]
1553h	For P proportional gain switching	H072	R/W	0.00 to 10.00	0.01
1554h	Gain switching time	H073	R/W	0 to 9999	1 [ms]
1555h to 1600h	Not used	—	—		—
1601h	Operation selection at option 1 error	P001	R/W	00: Trip 01: RUN (Continues operation)	—
1602h	Operation selection at option 2 error	P002	R/W	00: Trip 01: RUN (Continues operation)	—
1603h to 160Ah	Not used	—	—		—
160Bh	Encoder pulses	P011	R/W	128 to 65535	1
160Ch	V2 control mode selection	P012	R/W	00: ASR (speed control mode) 01: APR (pulse train position control mode) 02: APR2 (absolute position control mode) 03: HAPR (High resolution absolute position control mode)	—
160Dh	Pulse train mode selection	P013	R/W	00: Mode 1 01: Mode 2 02: Mode 3	—
160Eh	Orientation stop position	P014	R/W	0 to 4095	1

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
160Fh	Orientation speed setting	P015	R/W	Starting frequency to Max. frequency (upper limit: 120.0)	0.01 [Hz]
1610h	Orientation direction setting	P016	R/W	00: FWD (Forward side) 01: REV (Reverse side)	—
1611h	Position ready range setting	P017	R/W	0 to 10000	1
1612h	Position ready delay time setting	P018	R/W	0.00 to 9.99	0.01 [s]
1613h	Electronic gear setting position selection	P019	R/W	00: FB (Position feedback side) 01: REF (Position command side)	—
1614h	Electronic gear ratio numerator	P020	R/W	1 to 9999	—
1615h	Electronic gear ratio denominator	P021	R/W	1 to 9999	—
1616h	Position control feedforward gain	P022	R/W	0.00 to 655.35	0.01
1617h	Position loop gain	P023	R/W	0.00 to 100.00	0.01
1618h	Position bias amount	P024	R/W	-2048 to 2048	—
1619h	Secondary resistance compensation enable/disable selection	P025	R/W	00: OFF (Disabled) 01: ON (Enabled)	—
161Ah	Overspeed error detection level	P026	R/W	0.0 to 150.0	0.1 [%]
161Bh	Speed deviation error detection level	P027	R/W	0.00 to 120.00	0.01 [Hz]
161Ch	Motor gear ratio numerator	P028	R/W	1 to 9999	1
161Dh	Motor gear ratio denominator	P029	R/W	1 to 9999	1
161Eh	Not used	—	—		—
161Fh	Acceleration/deceleration time input type	P031	R/W	00: OPE (Digital Operator) 01: Option 1 02: Option 2 03: EzSQ (Drive Programming)	—
1620h	Orientation stop position input type	P032	R/W	00: OPE (Digital Operator) 01: Option 1 02: Option 2	—
1621h	Torque reference input selection	P033	R/W	00: O (Terminal O) 01: OI (Terminal OI) 02: O2 (Terminal O2) 03: OPE (Digital Operator) 06: Option 1 07: Option 2	—
1622h	Torque reference setting	P034	R/W	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW)	1 [%]
1623h	Polarity selection at torque reference via O2	P035	R/W	00: Sign (Signed) 01: Direction (Depends on the RUN direction)	—

4-4 Communication Function

4

Functions

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1624h	Torque bias mode	P036	R/W	00: OFF (None) 01: OPE (Digital Operator) 02: O2 (Terminal O2) 05: Option 1 06: Option 2	—
1625h	Torque bias value	P037	R/W	-200 to 200 (0.4 to 55 kW) -180 to 180 (75 to 132 kW)	1 [%]
1626h	Torque bias polarity selection	P038	R/W	00: Sign (Signed) 01: Direction (Depends on the RUN direction)	—
1627h	Speed limit value in torque control (forward)	P039 (HIGH)	R/W	0.00 to Maximum frequency	0.01 [Hz]
1628h		P039 (LOW)	R/W		
1629h	Speed limit value in torque control (reverse)	P040 (HIGH)	R/W	0.00 to 1st Max. frequency	0.01 [Hz]
162Ah		P040 (LOW)	R/W		
162Bh	Not used	—	—		—
162Ch	Not used	—	—		—
162Dh	Not used	—	—		—
162Eh	DeviceNet comm Watch dog timer	P044	R/W	0.00 to 99.99	[s]
162Fh	Operation setting at communications error	P045	R/W	00: Trip 01: Decel-Trip (Trip after deceleration stop) 02: Ignore 03: Free RUN 04: Decel-Stop (Deceleration stop)	—
1630h	Instance Number	P046	R/W	0: Basic speed I/O 1: Extended speed I/O 2: Extended speed and Torque control 3: Special I/O 4: Extended control I/O 5: Extended control I/O and multifunction I/O monitor 6: Flexible format 7: Extended speed and Acceleration control 8-20: Not used	—
1632h	Operation setting at idle mode detection	P048	R/W	00: Trip 01: Decel-Trip (Trip after deceleration stop) 02: Ignore 03: Free RUN 04: Decel-Stop (Deceleration stop)	—
1633h	Polarity setting for rotation speed	P049	R/W	0/2/4/6/8/10/12/14/16/18/20/22/24/26/28/30/32/34/36/38	—
1634h to 1638h	Not used	—	—		—
1639h	Pulse train frequency scale	P055	R/W	1.0 to 50.0 * Input frequency at maximum frequency	0.1 [kHz]

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
163Ah	Pulse train frequency filter time constant	P056	R/W	0.01 to 2.00	0.01 [s]
163Bh	Pulse train frequency bias amount	P057	R/W	-100 to 100	1 [%]
163Ch	Pulse train frequency limit	P058	R/W	0 to 100	1 [%]
163Dh	Not used	—	—		—
163Eh	Multi-step position command 0	P060 (HIGH)	R/W	Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	1
163Fh		P060 (LOW)	R/W		
1640h	Multi-step position command 1	P061 (HIGH)	R/W	Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	1
1641h		P061 (LOW)	R/W		
1642h	Multi-step position command 2	P062 (HIGH)	R/W	Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	1
1643h		P062 (LOW)	R/W		
1644h	Multi-step position command 3	P063 (HIGH)	R/W	Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	1
1645h		P063 (LOW)	R/W		
1646h	Multi-step position command 4	P064 (HIGH)	R/W	Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	1
1647h		P064 (LOW)	R/W		
1648h	Multi-step position command 5	P065 (HIGH)	R/W	Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	1
1649h		P065 (LOW)	R/W		
164Ah	Multi-step position command 6	P066 (HIGH)	R/W	Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	1
164Bh		P066 (LOW)	R/W		
164Ch	Multi-step position command 7	P067 (HIGH)	R/W	Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	1
164Dh		P067 (LOW)	R/W		
164Eh	Zero return mode	P068	R/W	00: Low speed 01: High speed 1 02: High speed 2	—
164Fh	Zero return direction selection	P069	R/W	00: FWD (Forward side) 01: REV (Reverse side)	—
1650h	Low-speed zero return frequency	P070	R/W	0.00 to 10.00	0.01 [Hz]
1651h	High-speed zero return frequency	P071	R/W	0.00 to Maximum frequency	0.01 [Hz]

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
1652h	Position range specification (forward)	P072 (HIGH)	R/W	0 to 268435455 (at P012 = 02)/ 0 to 1073741823 (at P012 = 03)	1
1653h		P072 (LOW)	R/W		
1654h	Position range specification (reverse)	P073 (HIGH)	R/W	-268435455 to 0 (at P012 = 02)/ -1073741823 to 0 (at P012 = 03)	1
1655h		P073 (LOW)	R/W		
1656h	Teaching selection	P074	R/W	00: X00 (Multi-step position command 0 (P060)) 01: X01 (Multi-step position command 0 (P061)) 02: X02 (Multi-step position command 0 (P062)) 03: X03 (Multi-step position command 0 (P063)) 04: X04 (Multi-step position command 0 (P064)) 05: X05 (Multi-step position command 0 (P065)) 06: X06 (Multi-step position command 0 (P066)) 07: X07 (Multi-step position command 0 (P067))	—
1656h to 1665h	Not used	—	—		—
1666h to 1685h	Drive Program parameter U(00) to U(31)	P100 to P131	R/W	0 to 65535	1
1686h to 16A1h	Not used	—	—		—
16A2h to 16ABh	Option I/F cmd W register 1 to 10	P160 to P169	R/W	0000 to FFFF	—
16ACh to 16B5h	Option I/F cmd R register 1 to 10	P170 to P179	R/W	0000 to FFFF	—
16B6h	Profibus node address	P180	R/W	0 to 125	—
16B7h	Profibus clear mode	P181	R/W	00: Clear 01: Last value	—
16B8h	Profibus Map selection	P182	R/W	00: PPO 01: Conventional 02: Flexible mode	—
16BBh	CANOpen Node address	P185	R/W	0 to 127	—

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
16BCh	CANOpen communication speed	P186	R/W	00: Auto 01: 10Kbps 02: 20Kbps 03: 50Kbps 04: 125Kbps 05: 250Kbps 06: 500Kbps 07: 800Kbps 08: 1Mbps	—
16C0h	CompoNet node address	P190	R/W	0 to 63	—
16C2h	DeviceNet node address	P192	R/W	0 to 63	—
16C5h	ML2 frame length	P195	R/W	00: 32 bytes 01: 17 bytes	—
16C6h	ML2 node address	P196	R/W	21 to 3E	—

* Data on H003 (Motor capacity selection) is the following code data.

Code data	00	01	02	03	04	05	06	07	08	09	10
Motor capacity (kW)	0.2	—	0.4	—	0.75	—	1.5	2.2	—	3.7	—
Code data	11	12	13	14	15	16	17	18	19	20	21
Motor capacity (kW)	5.5	7.5	11	15	18.5	22	30	37	45	55	75
Code data	22	23	24	25	26						
Motor capacity (kW)	90	110	132	150	160						

<Holding Register Number List (2nd Setting)>

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
2103h	2nd acceleration time 1	F202 (HIGH)	R/W	0.01 to 3600.00	0.01 [s]
2104h		F202 (LOW)	R/W		
2105h	2nd deceleration time 1	F203 (HIGH)	R/W	0.01 to 3600.00	0.01 [s]
2106h		F203 (LOW)	R/W		
2107h to 2202h	Not used	—	—		—

<Holding Register Number List (Function Mode 2nd Setting)>

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
2203h	2nd set base frequency	A203	R/W	30 to 2nd Max. frequency	1 [Hz]
2204h	2nd maximum frequency	A204	R/W	30 to 400	1 [Hz]
2205h to 2215h	Not used	—	—		—

4-4 Communication Function

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
2216h	2nd multi-step speed reference 0	A220 (HIGH)	R/W	0.00 to 2nd Max. frequency	0.01 [Hz]
2217h		A220 (LOW)	R/W		
2218h to 223Ah	Not used	—	—		—
223Bh	2nd torque boost selection	A241	R/W	00: Manual torque boost 01: Automatic torque boost	—
223Ch	2nd manual torque boost voltage	A242	R/W	0.0 to 20.0	0.1 [%]
223Dh	2nd manual torque boost frequency	A243	R/W	0.0 to 50.0	0.1 [%]
223Eh	2nd V/f characteristics selection	A244	R/W	00: VC (Constant torque characteristics) 01: VP (Special reduced torque characteristics) 02: Free V/f (characteristics) 03: SLV (Sensorless vector control) 04: OSLV (0-Hz sensorless vector control) 05: V2 (Sensor vector control)	—
223Fh	Not used	—	—		—
2240h	2nd automatic torque boost voltage compensation gain	A246	R/W	0 to 255	1
2241h	*2nd automatic torque boost slip compensation gain	A247	R/W	0 to 255	1
2242h to 224Eh	Not used	—	—		—
224Fh	2nd frequency upper limit	A261 (HIGH)	R/W	0.00/2nd frequency lower limit to 2nd Max. frequency	0.01 [Hz]
2250h		A261 (LOW)	R/W		
2251h	2nd frequency lower limit	A262 (HIGH)	R/W	0.00/Starting frequency to 2nd frequency upper limit	0.01 [Hz]
2252h		A262 (LOW)	R/W		
2253h to 226Eh	Not used	—	—		—
226Fh	2nd acceleration time 2	A292 (HIGH)	R/W	0.01 to 3600.00	0.01 [s]
2270h		A292 (LOW)	R/W		
2271h	2nd deceleration time 2	A293 (HIGH)	R/W	0.01 to 3600.00	0.01 [s]
2272h		A293 (LOW)	R/W		

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
2273h	2nd 2-step acceleration/ deceleration selection	A294	R/W	00: 2CH-Terminal (Switched via multifunction input 09) 01: Preset FQ (Switched by setting) 02: FWD-REV (Enabled only when switching forward/reverse)	—
2274h	2nd 2-step acceleration frequency	A295 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
2275h		A295 (LOW)	R/W		
2276h	2nd 2-step deceleration frequency	A296 (HIGH)	R/W	0.00 to 400.00	0.01 [Hz]
2277h		A296 (LOW)	R/W		
2278h to 230Bh	Not used	—	—		—
230Ch	2nd electronic thermal level	b212	R/W	0.20 x Rated current to 1.00 x Rated current	0.1 [A]
230Dh	2nd electronic thermal characteristics selection	b213	R/W	00: Reduced TRQ (Reduced torque characteristics) 01: Const TRQ (Constant torque characteristics) 02: Free set (Free setting)	—
230Eh to 2501h	Not used	—	—		—
2502h	2nd motor parameter selection	H202	R/W	00: Standard motor parameter 01: Auto-tuning parameter 02: Auto-tuning parameter (online auto-tuning enabled)	—
2503h	2nd motor capacity selection	H203	R/W	0.20 to 160.0	0.01 [kW]
2504h	2nd motor pole number selection	H204	R/W	2/4/6/8/10	Pole
2505h	2nd speed response	H205 (HIGH)	R/W	0.001 to 80.000	0.001
2506h		H205 (LOW)	R/W		
2507h	2nd stabilization parameter	H206	R/W	0 to 255	1
2508h to 2514h	Not used	—	—		—
2515h	2nd motor parameter R1	H220 (HIGH)	R/W	0.001 to 65.535	0.001 [Ω]
2516h		H220 (LOW)	R/W		
2517h	2nd motor parameter R2	H221 (HIGH)	R/W	0.001 to 65.535	0.001 [Ω]
2518h		H221 (LOW)	R/W		

4-4 Communication Function

4

Functions

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
2519h	2nd motor parameter L	H222 (HIGH)	R/W	0.01 to 655.35	0.01 [mH]
251Ah		H222 (LOW)	R/W		
251Bh	2nd motor parameter IO	H223 (HIGH)	R/W	0.01 to 655.35	0.01 [A]
251Ch		H223 (LOW)	R/W		
251Dh	2nd motor parameter J	H224 (HIGH)	R/W	0.001 to 9999.000	0.001 [kgm ²]
251Eh		H224 (LOW)	R/W		
251Fh to 2523h	Not used	—	—		—
2524h	2nd motor parameter R1 (auto-tuning data)	H230 (HIGH)	R/W	0.001 to 65.535	0.001 [Ω]
2525h		H230 (LOW)	R/W		
2526h	2nd motor parameter R2 (auto-tuning data)	H231 (HIGH)	R/W	0.001 to 65.535	0.001 [Ω]
2527h		H231 (LOW)	R/W		
2528h	2nd motor parameter L (auto-tuning data)	H232 (HIGH)	R/W	0.01 to 655.35	0.01 [mH]
2529h		H232 (LOW)	R/W		
252Ah	2nd motor parameter IO (auto-tuning data)	H233 (HIGH)	R/W	0.01 to 655.35	0.01 [A]
252Bh		H233 (LOW)	R/W		
252Ch	2nd motor parameter J (auto-tuning data)	H234 (HIGH)	R/W	0.001 to 9999.000	0.001 [kgm ²]
252Dh		H234 (LOW)	R/W		
252Eh to 253Ch	Not used	—	—		—
253Dh	2nd PI proportional gain	H250	R/W	0.0 to 1000.0	0.1 [%]
253Eh	2nd PI integral gain	H251	R/W	0.0 to 1000.0	0.1 [%]
253Fh	2nd P proportional gain	H252	R/W	0.01 to 10.00	0.01
2540h to 2546h	Not used	—	—		—
2547h	2nd limit at 0 Hz	H260	R/W	0.0 to 100.0	0.1 [%]
2548h	2nd boost amount at SLV startup, 0 Hz	H261	R/W	0 to 50	1 [%]

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
2549h to 3102h	Not used	—	—		—

* Data on H203 (2nd motor capacity selection) is the following code data.

Code data	00	01	02	03	04	05	06	07	08	09	10
Motor capacity (kW)	0.2	—	0.4	—	0.75	—	1.5	2.2	—	3.7	—
Code data	11	12	13	14	15	16	17	18	19	20	21
Motor capacity (kW)	5.5	7.5	11	15	18.5	22	30	37	45	55	75
Code data	22	23	24	25	26						
Motor capacity (kW)	90	110	132	150	160						

<Holding Register Number List (3rd Setting)>

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
3103h	3rd acceleration time 1	F302 (HIGH)	R/W	0.01 to 3600.00	0.01 [s]
3104h		F302 (LOW)	R/W		
3105h	3rd deceleration time 1	F303 (HIGH)	R/W	0.01 to 3600.00	0.01 [s]
3106h		F303 (LOW)	R/W		
3107h to 3202h	Not used	—	—		—

<Holding Register Number List (Function Mode 3rd Setting)>

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
3203h	3rd set base frequency	A303	R/W	30 to 3rd Max. frequency	1 [Hz]
3204h	3rd maximum frequency	A304	R/W	30 to 400	1 [Hz]
3205h to 3215h	Not used	—	—		—
3216h	3rd multi-step speed reference 0	A320 (HIGH)	R/W	0.00 to 3rd Max. frequency	0.01 [Hz]
3217h		A320 (LOW)	R/W		
3218h to 323Bh	Not used	—	—		—
323Ch	3rd manual torque boost voltage	A342	R/W	0.0 to 20.0	0.1 [%]
323Dh	3rd manual torque boost frequency	A343	R/W	0.0 to 50.0	0.1 [%]
323Eh	3rd V/f characteristics selection	A344	R/W	00: VC (Constant torque characteristics) 01: VP (Special reduced torque characteristics)	—

4-4 Communication Function

Register No.	Function name	Function code	R/W	Monitor and setting parameters	Resolution
323Fh to 326Ch	Not used	—	—		—
326Dh	3rd acceleration time 2	A392 (HIGH)	R/W	0.01 to 3600.00	0.01 [s]
326Eh		A392 (LOW)	R/W		
326Fh	3rd deceleration time 2	A393 (HIGH)	R/W	0.01 to 3600.00	0.01 [s]
3270h		A393 (LOW)	R/W		
3271h to 330B	Not used	—	—		—
330Ch	3rd electronic thermal level	b312	R/W	0.20 x Rated current to 1.00 x Rated current	0.1 [A]
330Dh	3rd electronic thermal characteristics selection	b313	R/W	00: Reduced TRQ (Reduced torque characteristics) 01: Const TRQ (Constant torque characteristics) 02: Free set (Free setting)	—
330Eh to 3506h	Not used	—	—		—
3507h	3rd stabilization parameter	H306	R/W	0 to 255	1
From 3508h	Not used	—	—		—

Chapter 5

Maintenance Operations

5-1	Protective Functions and Troubleshooting...	5-1
5-2	Warning Function.....	5-10

5-1 Protective Functions and Troubleshooting

Error Code List

Name	Description	Error Code	Points to check and remedy	Reference page
Overcurrent trip	If the motor is restrained or rapidly accelerated or decelerated, a large current flows through the Inverter, which results in a malfunction. The current exceeding the specified level shuts off the output and an error appears. This protection function detects an overcurrent through the AC CT (current detector). The protection circuit is activated at approximately 220% of the Inverter rated output current and a trip occurs.	Constant speed	E01.0 Is there any rapid load fluctuation? (Eliminate load fluctuation.) Is there any output short-circuit? (Check the output wires.) Is there any ground fault? (Check the output wires and motor.)	—
		Deceleration	E02.0 Is there any rapid deceleration? (Increase the deceleration time.)	4-8 4-37
		Acceleration	E03.0 Is there any rapid acceleration? (Increase the acceleration time.) Has the motor shaft been locked? (Check the motor and wires.) Is the torque boost too high? (Lower the torque boost.)	4-8 4-37
		Others	E04.0 Is the DC injection braking too high? (Lower the injection braking.) Is there any error on CT? (Replace or repair the CT.)	4-24
Overload trip *1	Monitors the Inverter output current and shuts off the output, displaying an error if the built-in electronic thermal function detects overload against the motor. Trips depending on the electronic thermal function settings.	E05.0	Is the load too large? (Reduce the loading factor.) Is the thermal level correct? (Adjust the thermal level to an appropriate level.) Note: The electronic thermal function is set to work easily at 5 Hz or lower. If a large load inertial moment is applied, the overload protect function works when the motor starts accelerating, and the load prevents it from accelerating. In this case, increase the torque boost or take other measures for adjustment.	4-46
Braking resistor overload trip	Shuts off the output and displays an error if the usage rate of regenerative braking circuit exceeds the b090 set value.	E06.0	Is there any rapid deceleration? (Increase the deceleration time.) Is the operation cycle frequent? (Decrease the number of operation cycles.) Is the usage rate setting of the regenerative braking function low? (Set to an appropriate level.) Note: Pay attention to the allowable power of the resistor.	4-8 4-74

Name	Description	Error Code	Points to check and remedy	Reference page
Overvoltage trip	Extremely high DC voltage between P/+ and N/- may result in failure. This function therefore shuts off the output and displays an error if the DC voltage between P/+ and N/- exceeds the specified level because of regenerative energy from the motor or increase of the incoming voltage during operation. Trips when the DC voltage between P/+ and N/- reaches approximately 400 V DC for 200-V class, and 800 V DC for 400-V class.	E07.0	Is there any rapid deceleration? (Increase the deceleration time.) Is there any ground fault? (Check the output wires and motor.) Has the motor been rotated/driven from the load side? (Reduce regenerative energy.)	—
EEPROM error *2 *3	Shuts off the output and displays an error if an error occurs in the built-in EEPROM because of external noise or abnormal temperature rise. Note: This may be a CPU error depending on the case.	E08.0	Is there any large electrical noise source around? (Countermeasures against electrical noise) Has the cooling efficiency been reduced? (Check that there is no clogging in the cooling fan and fin, if so clean it.) (Replace the cooling fan if faulty.)	—

*1. The reset command is not accepted until approximately 10 seconds after the trip occurs (protection function works).

*2. The reset command is not accepted if the EEPROM error E08.0 occurs. Turn off the power once. If you find E08 when turning on the power again, it is possible that the internal memory element of the drive has been damaged or the parameters have not been memorized correctly. Perform the user initialization to set the parameters again.

*3. The reset command through the RS terminal or STOP/RESET key is not accepted. Turn off the power.

Name	Description	Error Code	Check point and remedy	Reference page
Undervoltage trip	Shuts off the output if the incoming supply voltage drops below the specified level. This is because the control circuit stops working properly when the incoming supply voltage to the Inverter drops. Trips when the DC voltage between P/+ and N/- drops to approximately 175 V DC for 200-V class, and 345 V DC for 400-V class.	E09.0	Has the power supply voltage decreased? (Check the incoming power supply.) Is the power supply capacity sufficient? (Check the power supply.) Has the drives internal charge circuit thyristor been damaged? (Check the thyristor.)	4-28
CT error	Shuts off the output if an error occurs in the CT (current detector) built into the Inverter. Trips if the CT output is approximately 0.6 V or more when the power is turned on.	E10.0	The Inverter has a fault. (Repair/Replace)	—
CPU error *1	Shuts off the output and displays an error if the internal CPU has worked erroneously or abnormally. Note: If an abnormal value is read from EEPROM, it may become a CPU error depending on the case.	E11.0	Is there any large electrical noise source around? (Countermeasures against noise) The Inverter has a fault. (Repair/Replace)	—

*1. The reset command through the RS terminal or STOP/RESET key is not accepted. Turn off the power.

*2. The reset operation via the Digital Operator is not accepted. Be sure to reset via the RS terminal.

Name	Description	Error Code	Check point and remedy	Reference page
External trip	If an error occurs in the external equipment or devices, the Inverter receives an input signal, then the drives output is shut off. (Available with the external trip function selected)	E12.0	Has any error occurred in the external devices when the external trip function is selected? (Correct the external device error.)	4-84
USP trip	Appears when the power is turned on with the RUN signal input into the Inverter. (Available with the USP function selected)	E13.0	When the USP function was selected, did you turn on the power with the RUN signal input into the Inverter? (Cancel the RUN command and turn on the power.)	4-84
Ground fault trip *1	Protects the Inverter if a ground fault between the Inverter output unit and the motor is detected when turning on the power. (This function does not work when there is residual voltage in the motor.)	E14.0	Is there any ground fault? (Check the output wires and motor.) Is there any error in the Inverter itself? (Disconnect the output wires to check.) Is there any error in the main circuit? (Check the main circuit. Refer to Chapter 6.) (Repair/Replace)	—
Incoming overvoltage trip	Appears if the incoming voltage continues to be higher than the specification value for 100 seconds while the Inverter is stopped. Trips when the main circuit DC voltage reaches approximately 390 V DC for 200-V class, and 780 V DC for 400-V class.	E15.0	Is the incoming supply voltage too high while the Inverter is stopped? (Lower the incoming voltage, correct the power supply fluctuation. Fit an AC reactor to power supply input if needed.)	—
Momentary power interruption trip	Shuts off the output when a momentary power interruption occurs for 15 ms or more. If the shutoff time is long, it is normally recognized as a power shutoff. Note that, when restart is selected, the Inverter restarts at power-on as long as the RUN command remains.	E16.0	Has the incoming power supply voltage dropped? (Power recovery) Is there a contact failure for MCCB and/or Mg? (Replace MCCB, Mg.)	4-60
Temperature error when the rotation speed of the cooling fan decreases	Appears if a decrease of the cooling fan rotation speed has been detected when a temperature error occurs.	E20.0	Has the cooling efficiency been reduced? (Replace the cooling fan.) Is there any clogging in the heatsink fin? (Clean the fin.)	—
Temperature error	Shuts off the output if the temperature has risen in the main circuit because of the high ambient temperature.	E21.0	Have you installed the Inverter vertically? (Installation check) Is the ambient temperature high? (Decrease the ambient temperature.)	—
Gate array communications error	Trips when a fault is detected in communication behavior between the built-in CPU and the gate array.	E23.0	Is there any large electrical noise source around? (Countermeasures against electrical noise) Has any internal cable been disconnected? (Check the connector.)	—

*1. The reset command through the RS terminal or STOP/RESET key is not accepted. Turn off the power.

*2. The reset operation via the Digital Operator is not accepted. Be sure to reset via the RS terminal.

Name	Description	Error Code	Check point and remedy	Reference page
Input open phase trip	Prevents Inverter damage due to input phase loss when the input phase loss protection selection is enabled (b006=01), and trips. Trips when the phase loss time is approximately 1 s or more.	E24.0	Is there any input power supply phase loss? (Check the input wiring.) Is there a contact failure for MCCB and/or Mg? (Replace MCCB, Mg.)	—
Main circuit error *1	Trips when the gate array cannot confirm IGBT ON/OFF because of a main element failure, a load short circuit, or an erroneous operation resulting from radiated electrical noise.	E25.0	Is there any large electrical noise source around? (Countermeasures against electrical noise) Has the main element/IGBT been damaged? Is there any output short-circuit? (Check the IGBT.) The Inverter has a failure. (Repair/ Replace)	—
IGBT error	Shuts off the Inverter output to protect the main element when a momentary overcurrent, temperature error in the main element, or drop of the main element driving power supply occurs. (Retry operation cannot be performed for this trip.)	E30.0	Is there any output short-circuit? (Check the output wires.) Is there any ground fault? (Check the output wires and motor.) Has the main element been damaged? (Check the IGBT.) Is there any clogging in the fin? (Clean the fin.)	—
Thermistor error	Shuts off the Inverter output when detecting the thermistor resistance value inside the motor has changed which is connected to the TH terminal, resulting motor temperature rise.	E35.0	Is the motor temperature too high? (Check the motor temperature.) Is there any damage to the thermistor inside the motor? (Check the thermistor.) Is there any electrical noise being introduced in the thermistor signal? (Separate the wiring.)	2-9 4-75
Brake error	When 01 is selected in b120 (brake control selection), this error appears if the brake ON/OFF cannot be confirmed within the b124 set time (brake confirmation wait time) after the Inverter outputs the brake release signal.	E36.0	Is the brake ON/OFF function working? (Brake check) Is the set time for b124 too short? (Increase b124.) Has the brake confirmation signal been input? (Wiring check)	4-76
Emergency shutoff *2	Shuts off the hardware output and displays an error when the EMR terminal (S3) is turned on with SW1 on the logic board ON.	E37.0	Did any error occur in the external devices when the emergency shutoff function was selected? (Correct the external device error.)	2-9
Overload trip in low speed range	If an overload is detected in the lowest speed range of 0.2 Hz max., an electronic thermal trip inside the Inverter works to shut off the Inverter output. (2nd electronic thermal) (However, a higher frequency could remain in the error history.)	E38.0	Is the load too large? (Reduce the loading factor.)	—
ModBus communications error	Appears when the timeout occurs because of disconnection during Modbus-RTU communication. (Trip by the C076 setting)	E41.0	Is the communication speed correct? Is the wiring distance appropriate? (Connection check)	4-147

*1. The reset command through the RS terminal or STOP/RESET key is not accepted. Turn off the power.

*2. The reset operation via the Digital Operator is not accepted. Be sure to reset via the RS terminal.

Name	Description	Error Code	Check point and remedy	Reference page
Option 1 error	Detects an error on the board mounted on option port 1.	E60.0 to E69.0	Has the option board been securely mounted? (Check that the mounting is correct.)	—
Option 2 error	Detects an error on the board mounted on option port 2.	E70.0 to E79.0	Has the option board been securely mounted? (Check that the mounting is correct.)	—
Undervoltage standby	Shows the waiting status after the incoming Inverter voltage decreases and shuts off. This error also appears during momentary power interruption.	UV Wait	Has the incoming power supply voltage dropped? (Power recovery) Is there a contact failure for MCCB and/or Mg? (Replace MCCB, Mg.) Is the voltage between P/+ and N/- normal? (Check the voltage between P/+ and N/-.)	—
Communications error	Appears if an error occurs between the Digital Operator and the Inverter.	COM ERROR	Has the remote cable plug been inserted properly? (Check the remote cable inserted correctly.) Has the Digital Operator been inserted properly? (Check the Digital Operator contact.)	—
Retry standby	Appears in the restart standby status when the momentary power interruption/trip retry functions are enabled.	Restart Wait	In case of zero-start.	—
		F-adj Wait	In case of frequency matching.	
Power shutoff	Appears when the power is shut off.	Power OFF	—	—
RUN command is limited	Appears if the limited RUN command is received while the rotation direction is limited to one direction with b035.	RUN CMD. Disable	—	—

*1. The reset command through the RS terminal or STOP/RESET key is not accepted. Turn off the power.

*2. The reset operation via the Digital Operator is not accepted. Be sure to reset via the RS terminal.

LCD Digital Operator Error Message

Display	Cause	Check item	Action	Resetting method
COM ERROR	-No signal is received from the inverter within 4 sec.	-Reset the inverter. -Check inverter type. -Check the connector for looseness/disconnection. -Check the cable for break.	-Avoid issuing the RESET signal continuously for more than 5 sec. -Change the correct inverter type. -Replace the cable and the connector.	Press STOP/RESET key
INV in RUN mode	-The WRITE key is pressed while the inverter is running. -Soft-lock is turned ON.	-Check if the WRITE key is pressed while the inverter is running. -Check if the WRITE key is pressed while soft-lock is ON.	-The WRITE key should be pressed only while the inverter stops. -Release the Soft-Lock (of the inverter).	
INV in TRIP mode	-WRITE key is pressed while inverter trips.	-Check if the inverter trips.	-Reset the inverter from trip status.	
INV Type Un-match	-An attempt was made writing parameters between different inverter type.	-	-Writing is possible only between the same type inverters,	
Read lock enabled	-In case of display "READ LOCK".	-	-Release the Read Lock.	
Data Check Sum Error	-EEPROM of LCD digital operator is overloaded. It reaches the EEPROM's Write Limitation.	-	-If the same error appears after the power is supplied several times, the operator is defective.	Supply the power again
INV Check Sum Error	-The parameters in LCD digital operator and the parameters written into the inverter are unmatched.	-	-If the same error appears several times, the inverter is defective. (Note)	

Note: It will happen sometimes when you try to write data into an inverter with different voltage class and capacity. (Please refer to each inverter instruction manual).

Option Board Protection Function List

E6*.□(OP1-*) appears when the option board is mounted on option port 1 (Digital Operator connector side) , and E7*.□(OP2-*) appears when it is mounted on option port 2 (control circuit terminal block side).

•Protection function list when the PG board (3G3AX-PG01) is mounted

Name	Description	Error Code	
Encoder disconnection	Shuts off the output and displays an error when the encoder wiring disconnection or connection failure is detected, the encoder is damaged, or an encoder except for line driver output is used.	E60.0	E70.0
Excess speed	Shuts off the output and displays an error when the motor rotation exceeds the maximum frequency (A004) × the overspeed error detection level (P026).	E61.0	E71.0
Positioning error	Shuts off the output and displays an error when the current position deviation against the position reference value exceeds 1,000,000 pulses during position control.	E62.0	E72.0
Position control range trip	Shuts off the output and displays an error when the current position exceeds the setting values of the position limit range specification for Forward (P072) and Reverse (P073) during absolute position control.	E63.0	E73.0
3G3AX-PG01 connection error	Shuts off the output and displays an error if a connection (mounting) failure of the PG board is detected.	E69.0	E79.0

Note: Check the DIP switch settings on the PG board for any abnormal operation.

Function List of the DIP Switches on the PG Board (3G3AX-PG01)

DIP switch	Switch No.	Description	
SWENC	1	ON	Disconnection detection enabled when the encoder A/B-phase is not connected
		OFF	Disconnection detection disabled when the encoder A/B-phase is not connected
	2	ON	Disconnection detection enabled when the encoder Z-phase is not connected
		OFF	Disconnection detection disabled when the encoder Z-phase is not connected
SWR	1	ON	With the termination resistor between SAP and SAN (150 Ω)
		OFF	Without the termination resistor between SAP and SAN
	2	ON	With the termination resistor between SBP and SBN (150 Ω)
		OFF	Without the termination resistor between SBP and SBN

•Protection function display when the digital command board (3G3AX-DI01) is mounted

Name	Description	Error Code	
3G3AX-DI01 error	Shuts off the output and displays an error if a timeout occurs in communication between the Inverter and digital command board.	E60.0	E70.0

Note: Input mode is determined by the combination of DIP and rotary switches. Check the settings of the DIP and rotary switches on the digital command board for any abnormal operation.

Function List of the DIP and Rotary Switches on the digital command board (3G3AX-DI01)

DIP switch (TYPE)		Rotary switch (CODE)	Resolution setting									
			Set frequency				Acceleration/Deceleration time setting			Torque limit setting	Posi- tion setting	
Switch No.		Setting code	0.01 Hz	0.1 Hz	1 Hz	Rate	0.01 sec	0.1 sec	1 sec	1%	1 pulse	
1	2		0	○								
ON: BCD input (BCD) OFF: Binary input (BIN)	OFF: Batch input mode (PAC)	1		○								
		2			○							
		3				○						
		4								○		
		5	For factory adjustment (Do not set)									
		6									○	
		7 to F	For factory adjustment (Do not set)									
		ON: Dividing input mode (DIV)	0	○					○			○
	1								○			
	2									○		
	3			○				○				
	4							○				
	5								○			
	6				○		○					
	7						○					
	8								○			
	9					○	○					
	A							○				
	B								○			
	C to F		For factory adjustment (Do not set)									

How to Read the Input Mode List

Example 1. Switch setting when setting the frequency with a resolution of 1 Hz, via binary input (BIN) in the batch input mode (PAC)

TYPE		CODE
1	2	2
OFF: BIN	OFF: PAC	

Example 2. Switch setting when setting the frequency with a resolution of 0.1 Hz, via BCD input, and setting the acceleration/deceleration time with a resolution of 0.1 sec, via BCD input in the dividing input mode (DIV)

TYPE		CODE
1	2	4
ON: BCD	ON: DIV	

For the communication option boards, refer to the specific user manual of each option.

Trip Monitor Display


TRIP	M1-STOP	ALL
E12.1		
Ext. Trip		
111006	11:05	Stop



TRIP	M1-STOP	ALL
ERR1 P1		
Ext. Trip		
111006	11:05	Stop
Output FQ	50.00Hz	
Output current	4.00A	



TRIP	M1-STOP	ALL
ERR1 P2		
Ext. Trip		
DC Voltage	400.2Vdc	
RUN time	15hr	
ON time	8hr	



5-2 Warning Function

•The following table shows the details of warning display and parameter correction.

Target code	Condition	Base code
Frequency upper limit A061/A261	>	Maximum frequency A004/A204/A304
Frequency lower limit A062/A262	>	
Base frequency A003/A203/A303 ^{*1}	>	
Output frequency F001, Multi-step speed reference 0 A020/A220/A320 ^{*2}	>	
Multi-step speeds 1 to 15 A021 to A035	>	
Orientation speed setting P015	>	
Frequency lower limit A062/A262	>	Frequency upper limit A061/A261
Output frequency F001, Multi-step speed reference 0 A020/A220 ^{*2}	>	
Multi-step speeds 1 to 15 A021 to A035	>	
Frequency upper limit A061/A261	<	Orientation speed P015
	<	Frequency lower limit A062/A262
Output frequency F001, Multi-step speed reference 0 A020/A220/A320 ^{*2}	<	Starting frequency b082
Frequency upper limit A061/A261	<	
Frequency lower limit A062/A262	<	
Output frequency F001, Multi-step speed reference 0 A020/A220/A320 ^{*2}	<	
Multi-step speeds 1 to 15 A021 to A035	<	
Jogging frequency A038	<	Jump frequency 1/2/3 ± Jump width A063 ± A064 A065 ± A066 A067 ± A068 ^{*3}
Output frequency F001, Multi-step speed reference 0 A020/A220/A320 ^{*2}	< >	
Multi-step speeds 1 to 15 A021 to A035	< >	
Frequency upper limit A061/A261	>	Free V/f frequency 7 b112
Frequency lower limit A062/A262	>	
Output frequency F001, Multi-step speed reference 0 A020/A220 ^{*2}	>	
Multi-step speed reference 1 to 15 A021 to A035	>	
Free V/f frequencies 1 to 6 b100, b102, b104, b106, b108, b110	>	
Free V/f frequencies 2 to 6 b102, b104, b106, b108, b110	<	Free V/f frequency 1 b100
Free V/f frequency 1 b100	>	Free V/f frequency 2 b102
Free V/f frequencies 3 to 6 b104, b106, b108, b110	<	
Free V/f frequencies 1, 2 b100, b102	>	Free V/f frequency 3 b104
Free V/f frequencies 4 to 6 b106, b108, b110	<	

5-2 Warning Function

Target code	Condition	Base code
Free V/f frequencies 1 to 3 b100, b102, b104	>	Free V/f frequency 4 b106
Free V/f frequencies 5, 6 b108, b110	<	
Free V/f frequencies 1 to 4 b100, b102, b104, b106	>	Free V/f frequency 5 b108
Free V/f frequency 6 b110	<	
Free V/f frequencies 1 to 5 b100, b102, b104, b106, b108	>	Free V/f frequency 6 b110
Free electric thermal frequencies 2, 3 b017, b019	<	Free electric thermal frequency 1 b015
Free electric thermal frequency 1 b015	>	Free electric thermal frequency 2 b017
Free electric thermal frequency 3 b019	<	
Free electric thermal frequencies 1 2 b015, b017	>	Free electric thermal frequency 3 b019

- *1. In this case, the base frequency is rewritten when corresponding parameters. Change the data to a correct value is a warning occurs. Otherwise, the motor may burn out depending on the value.
- *2. Checks even if the frequency reference selection (A001) is set other than to the Digital Operator (02).
- *3. The jump frequency is rewritten into the value of the subtraction of the jump width (lower limit) from the jump frequency.
- Warning appears when a target code set data meets the condition shown above in relation to the base code data.
- Parameters are rewritten into the data of the base code. (rewritten at start-up)



Chapter 6

Inspection and Maintenance



6-1	Inspection and Maintenance	6-1
-----	----------------------------------	-----

6-1 Inspection and Maintenance

DANGER

	Do not change wiring and slide switches (SW1), put on or take off Digital Operator and optional devices, replace cooling fans while the input power is being supplied. Doing so may result in a serious injury due to an electric shock.
	Do not remove the terminal block cover during the power supply and 10 minutes after the power shutoff. Doing so may result in a serious injury due to an electric shock.

CAUTION

	Do not touch the Inverter fins, braking resistors and the motor, which become too hot during the power supply and for some time after the power shutoff. Doing so may result in a burn.
	Do not dismantle, repair or modify this product. Doing so may result in an injury.

Safety Information

■Maintenance and Inspection

- Be sure to confirm safety before conducting maintenance, inspection or parts replacement.

Precautions for Use

■Operation Stop Command

- Provide a separate emergency stop switch because the STOP key on the Digital Operator is valid only when function settings are performed.
- When checking a signal during the power supply and the voltage is erroneously applied to the control input terminals, the motor may start abruptly. Be sure to confirm safety before checking a signal.

■Product Disposal

- Comply with the local ordinance and regulations when disposing of the product.

Daily Inspection

- Basically, check the following during operation.
 - The motor operates according to the settings.
 - There are no errors in the installation environment.
 - There are no errors in the cooling system.
 - There are no abnormal vibrations or sounds.
 - There are no abnormal overheat or discoloration.
 - There are no abnormal odors.
- Check the input voltage of the Inverter during operation using a tester or other equipment.
 - There is no frequent power supply voltage fluctuation.
 - The voltage level between the wires is balanced.

Cleaning

- Always keep the Inverter clean for operation.
- Lightly remove any dirt with a soft cloth moistened with a neutral detergent.

Note:

Do not use such solutions as acetone, benzene, toluene, or alcohol for cleaning. Doing so may cause the Inverter surface to dissolve or its coating to come off.

Do not use any detergent or alcohol to clean the Digital Operator display.

Periodic Inspection

- Check the parts that cannot be checked without stopping operation, as well as those that require periodic inspection.
- Contact OMRON Corporation for periodic inspections.
 - Check that there are no errors in the cooling system.
 - Clean the air filter.
 - Check that all parts that need tightening are secure.
 - Screws and bolts may become loose because of vibration or temperature change.
 - Check that there is no corrosion or damage to the conductors and/or insulators.
 - Measurement of insulation resistance.
 - Check and replace the cooling fan, smoothing capacitor, and relay.

■ Daily Inspection and Periodic Inspection

Inspection part	Inspection item	Inspection point	Inspection period			Inspection method	Criteria	Meter
			Daily	Periodic				
				1 year	2 years			
General	Ambient environment	Check ambient temperature, as well as humidity and dust levels.	○			Refer to "2-1 Installation".	Ambient temperature 10°C to 50°C, no freezing. Ambient humidity 90% max., no condensation.	Thermometer -er Hygrometer Recorder
	Entire device	Check that there are no abnormal vibrations or sounds.	○			Visual or acoustic inspection	No faults	
	Power supply voltage	Check that the main circuit voltage is normal.	○			Measure the voltage between Inverter main circuit terminals R/L1, S/L2, and T/L3.	Must be within allowable fluctuation of AC voltage.	Tester, digital multimeter
Main circuit	General	Megger check (between main circuit terminal and ground terminal)		○		Disconnect the I/O wirings of the Inverter main circuit terminal block, detach the control terminal block board, and remove the short-circuit bar used for switching the Inverter built-in filter function. Then, use a megger to measure the resistance between the ground terminal and the short-circuited parts of terminals R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, P/+, PD/+1, N/-, RB, Ro, and To.	5 MΩ min.	500 V DC megger

*1. The life of the smoothing capacitor depends on ambient temperature.

Refer to "Appendix-2 Product Life Curve" for the replacement reference.

*2. The life of the cooling fan varies depending on the environmental conditions, such as ambient temperature and/or dust. Check the operation through daily inspections.

*3. The replacement reference (year/cycle) or "Appendix-2 Product Life Curve" is based on the expected design life, which is not guaranteed.

Inspection part	Inspection item	Inspection point	Inspection period			Inspection method	Criteria	Meter
			Daily	Periodic				
				1 year	2 years			
Main circuit	General	Check that any parts which may need tightening are secure.		○		Tighten securely.	No faults	
		Check that no part has indications of overheating.		○		Visual inspection	No faults	
	Connection conductor and wire	Check that there is no distortion with the conductor.		○		Visual inspection	No faults	
		Check that there is no damage to the wire Insulation.		○				
	Terminal block	Check that there is no damage.		○		Visual inspection	No faults	
	Inverter unit Converter unit (including the resistor)	Check the resistance between the terminals.			○	Disconnect the wiring of the Inverter main circuit terminal block and measure the resistance levels between terminals R/L1, S/L2, T/L3 and P/+, N/-, and between U/T1, V/T2, W/T3 and P/+, N/- in the range of tester x 1 Ω.	Refer to "Checking the Inverter and Converter". Inverter unit replacement reference Start/Stop: Cycle 10 ⁶ *3	Analog tester
	Smoothing capacitor	Check that there is no liquid leakage.	○			Visual inspection	No faults Reference of the replacement period: 10 years *2 *3	Capacity meter
		Check that the safety valve has not come out and that there are no bulges.	○					
	Relay	Check that there is no abnormal sound during operation.		○		Acoustic inspection	No faults	
		Check that there is no rough surface on the contact.		○		Visual inspection	No faults	

*1. The life of the smoothing capacitor depends on ambient temperature.

Refer to "Appendix-2 Product Life Curve" for the replacement reference.

*2. The life of the cooling fan varies depending on the environmental conditions, such as ambient temperature and/or dust. Check the operation through daily inspections.

*3. The replacement reference (year/cycle) or "Appendix-2 Product Life Curve" is based on the expected design life, which is not guaranteed.

Inspection part	Inspection item	Inspection point	Inspection period			Inspection method	Criteria	Meter
			Daily	Periodic				
				1 year	2 years			
Control circuit Protection circuit	Operation check	Check the balance of output voltage levels between phases in single Inverter run.		○		Measure the voltage between Inverter main circuit terminals U/T1, V/T2, and W/T3.	Phase-to-phase voltage balance 200-V class: 4 V max. 400-V class: 8 V max.	Digital multimeter Rectifier Voltmeter
		Check that there are no errors in protection and display circuits through sequence protection operation.		○		Short-circuit or open the Inverter protection circuit output under simulated conditions.	Error is found in the sequence.	
Cooling system	Cooling fan	Check that there are no abnormal vibration or sounds.	○			Rotate manually when the power is off.	Rotates smoothly. No faults Reference of the replacement period: 10 years *2 *3	
		Check that the connection parts are secure.		○		Visual inspection		
	Fin	Check that there is no clogging.		○		Visual inspection	No clogging.	
Display	Display	Check that the LED indicators are lit properly.	○			Visual inspection	Check that the LED indicators are lit properly.	Voltmeter, ammeter
		Cleaning		○		Clean with a soft cloth.		
	Meter	Check that the indicated value is normal.	○			Check the indicated values on the panel meters.	The specified or control values must be satisfied.	

*1. The life of the smoothing capacitor depends on ambient temperature.

Refer to "Appendix-2 Product Life Curve" for the replacement reference.

*2. The life of the cooling fan varies depending on the environmental conditions, such as ambient temperature and/or dust. Check the operation through daily inspections.

*3. The replacement reference (year/cycle) or "Appendix-2 Product Life Curve" is based on the expected design life, which is not guaranteed.

Inspection part	Inspection item	Inspection point	Inspection period			Inspection method	Criteria	Meter
			Daily	Periodic				
				1 year	2 years			
Motor	General	Check that there are no abnormal vibrations or sounds.	○			Acoustic, feeling, and/or visual inspection	No faults	
		Check that there are no abnormal odors.	○			Check that there is no abnormal odor caused by damage or overheating.	No faults	
	Insulation resistance	Megger check (Between the collective motor terminals and ground terminal)			○	Disconnect Inverter main circuit terminals U/T1, V/T2, and W/T3, and short-circuit the 3-phase motor wires. Then, use a megger to measure the resistance between the motor wire and ground terminal.	5 MΩ min.	500 V DC megger

*1. The life of the smoothing capacitor depends on ambient temperature.

Refer to "Appendix-2 Product Life Curve" for the replacement reference.


*2. The life of the cooling fan varies depending on the environmental conditions, such as ambient temperature and/or dust. Check the operation through daily inspections.

*3. The replacement reference (year/cycle) or "Appendix-2 Product Life Curve" is based on the expected design life, which is not guaranteed.

Megger test

- For a megger test of the external circuit, be sure to disconnect all the terminals of the Inverter so as not to apply the test voltage to the Inverter.
- Use a high resistance tester for a power distribution test of the control circuit. Do not use a megger or buzzer.
- Conduct an Inverter megger test only to the main circuit, not to the control circuit.
- Use a 500 V DC megger for a megger test.
- For a megger test of the Inverter main circuit, remove the short-circuit bar used for switching the Inverter built-in filter function and then short-circuit terminals R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, PD/+1, P/+, N/-, RB, Ro, and To with the wires, as shown below.
After the megger test, remove the short-circuit wires from terminals R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, P/+, PD/+1, N/-, RB, Ro, and To, and reconnect the short-circuit bar for switching the Inverter built-in filter function.

Note that the RB terminal is provided only for the Inverters with 22 kW or lower capacity.



Withstand Voltage Test

Do not conduct a withstand voltage test on any part of the Inverter.

Doing the test is dangerous and may cause damage or deterioration to the parts inside the Inverter.

Checking the Inverter and Converter

- The quality of the Inverter and converter can be checked using a tester.

(Preparation)

Disconnect the externally connected power supply wires (R/L1, S/L2, T/L3), the motor connection wires (U/T1, V/T2, W/T3), and the regenerative braking resistance (P/+, RB).

Prepare a tester. (Usable range is 1 Ω measurement resistance.)

(Checking method)

- The quality can be judged by measuring the conduction state of Inverter main circuit terminal blocks R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, RB, P/+, and N/- while alternating the tester polarity.

Note 1: Before checking, measure the voltage between P/+ and N/- at DC voltage range in advance, and confirm that the smoothing capacitor is sufficiently discharged.

Note 2: A nearly infinite value is shown in a no-conduction state.


However, the value may not be infinite if the momentary conduction occurs through the influence of the smoothing capacitor

The value shown ranges from a few to a few dozen Ω in a conduction state.

The Inverter or converter is in good shape if the values from various parameters are nearly equal, though they are not consistent depending on the types of elements or testers.


Note 3: The regenerative braking circuit is provided for Inverters with a capacity of 22 kW or lower.

		Tester polarity		Measurement value
		+ (red)	- (black)	
Converter unit	D1	R/L1	PD/+1	No conduction
		PD/+1	R/L1	Conduction
	D2	S/L2	PD/+1	No conduction
		PD/+1	S/L2	Conduction
	D3	T/L3	PD/+1	No conduction
		PD/+1	T/L3	Conduction
	D4	R/L1	N/-	Conduction
		N/-	R/L1	No conduction
	D5	S/L2	N/-	Conduction
		N/-	S/L2	No conduction
	D6	T/L3	N/-	Conduction
		N/-	T/L3	No conduction
Inverter unit	TR1	U/T1	P/+	No conduction
		P/+	U/T1	Conduction
	TR2	V/T2	P/+	No conduction
		P/+	V/T2	Conduction
	TR3	W/T3	P/+	No conduction
		P/+	W/T3	Conduction
	TR4	U/T1	N/-	Conduction
		N/-	U/T1	No conduction
	TR5	V/T2	N/-	Conduction
		N/-	V/T2	No conduction
	TR6	W/T3	N/-	Conduction
		N/-	W/T3	No conduction
Regenerative braking circuit	TR7	RB	P/+	No conduction
		P/+	RB	Conduction
		RB	N/-	No conduction
		N/-	RB	No conduction



■ Measurement Methods of I/O Voltage, Current, and Electric Power

Below is a general measurement device for input/output voltages, current, and electric power.




Measurement item	Measurement point	Measurement device	Note	Measurement value reference
Power supply voltage E_{IN}	Between R-S, S-T, and T-R (E_R), (E_S), (E_T)	Moving-iron voltmeter or Rectifier voltmeter	All effective values	200-V class: 200 to 240 V, 50/60 Hz 400-V class: 380 to 480 V, 50/60 Hz
Power supply current I_{IN}	Current R, S, T (I_R), (I_S), (I_T)	Moving iron ammeter	All effective values	When the input current is not balanced $I_{IN} = (I_R + I_S + I_T)/3$
Input electric power W_{IN}	Between R-S, S-T, and T-R (W_{11}) + (W_{12}) + (W_{13})	Electrodynamic wattmeter	All effective values	Three-wattmeter method
Input power factor P_{fin}	Calculated from the measured values of power supply voltage E_{IN} , power supply current I_{IN} , and input electric power W_{IN} . $P_{fin} = \frac{W_{IN}}{\sqrt{3} \cdot E_{IN} \cdot I_{IN}} \times 100(\%)$			
Output voltage E_{OUT}	Between U-V, V-W, W-U (E_U), (E_V), (E_W)	See the figure below or Rectifier voltmeter	Effective value of fundamental wave	
Output current I_{OUT}	Current U, V, W (I_U), (I_V), (I_W)	Moving iron ammeter	All effective values	
Output power W_{OUT}	Between U-V, V-W (W_{01}) + (W_{02})	Electrodynamic wattmeter	All effective values	Two-wattmeter method (or three-wattmeter method)
Output power factor P_{fout}	Calculated from the measured values of output voltage E_{OUT} , output current I_{OUT} , and output power W_{OUT} . $P_{fout} = \frac{W_{OUT}}{\sqrt{3} \cdot E_{OUT} \cdot I_{OUT}} \times 100(\%)$			

Note 1: For output voltage, use a measurement device that displays effective values of fundamental wave. For current and electric power, use a measurement device that displays all effective values.

Note 2: The Inverter output waveform, under PWM control, has a margin of error, especially at a low frequency.

Note 3: General-purpose testers are not applicable because of noise in many cases.



Chapter 7

Specifications

7-1	Standard Specification List.....	7-1
7-2	Dimensional Drawing.....	7-7
7-3	Options.....	7-15

7-1 Standard Specification List

■Three-phase 200-V Class

Class			3-phase 200 V									
Model name (3G3RX-)			A2004	A2007	A2015	A2022	A2037	A2055	A2075	A2110	A2150	A2185
Max. applicable motor 4P	kW	at CT	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5
		at VT	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22
Rated output capacity (kVA)	200 V	at CT	1.0	1.7	2.5	3.6	5.7	8.3	11.0	15.9	22.1	26.3
		at VT	1.3	2.1	3.2	4.1	6.7	10.4	15.2	20.0	26.3	29.4
	240 V	at CT	1.2	2.0	3.1	4.3	6.8	9.9	13.3	19.1	26.6	31.5
		at VT	1.5	2.6	3.9	5.0	8.1	12.4	18.2	24.1	31.5	35.3
Rated input voltage			3-phase (3-wire) 200 V -15% to 240 V +10%, 50/60 Hz ±5%									
Rated output voltage			3-phase: 200 to 240 V (Cannot exceed that of incoming voltage.)									
Rated output current (A)	at CT	3.0	5.0	7.5	10.5	16.5	24	32	46	64	76	
	at VT	3.7	6.3	9.4	12	19.6	30	44	58	73	85	
Radio noise filter			Built-in									
Weight (kg)			3.5	3.5	3.5	3.5	3.5	6	6	6	14	14
Braking	Regenerative braking		Built-in braking resistor circuit (discharge resistor separately mounted)									
	Minimum connection resistance (Ω)		50	50	35	35	35	16	10	10	7.5	7.5



Class			3-phase 200 V				
Model name (3G3RX-)			A2220	A2300	A2370	A2450	A2550
Max. applicable motor 4P	kW	at CT	22	30	37	45	55
		at VT	30	37	45	55	75
Rated output capacity (kVA)	200 V	at CT	32.9	41.9	50.2	63.0	76.2
		at VT	39.1	49.5	59.2	72.7	93.5
	240 V	at CT	39.4	50.2	60.2	75.6	91.4
		at VT	46.9	59.4	71.0	87.2	112.2
Rated input voltage			3-phase (3-wire) 200 V -15% to 240 V +10%, 50/60 Hz ±5%				
Rated output voltage			3-phase: 200 to 240 V (Cannot exceed that of incoming voltage.)				
Rated output current (A)		at CT	95	121	145	182	220
		at VT	113	140	169	210	270
Radio noise filter			Built-in				
Weight (kg)			14	22	30	30	43
Braking	Regenerative braking		Built-in braking resistor circuit	Regenerative braking unit separately mounted			
	Minimum connection resistance (Ω)		5	—			

■Three-phase 400-V Class

Class			3-phase 400 V									
Model name (3G3RX-)			A4004	A4007	A4015	A4022	A4040	A4055	A4075	A4110	A4150	A4185
Max. applicable motor 4P	kW	at CT	0.4	0.75	1.5	2.2	4.0	5.5	7.5	11	15	18.5
		at VT	0.75	1.5	2.2	4.0	5.5	7.5	11	15	18.5	22
Rated output capacity (kVA)	400 V	at CT	1.0	1.7	2.5	3.6	6.2	9.7	13.1	17.3	22.1	26.3
		at VT	1.3	2.1	3.3	4.6	7.7	11.0	15.2	20.9	25.6	30.4
	480 V	at CT	1.2	2.0	3.1	4.3	7.4	11.6	15.8	20.7	26.6	31.5
		at VT	1.5	2.5	4.0	5.5	9.2	13.3	18.2	24.1	30.7	36.5
Rated input voltage			3-phase (3-wire) 380 V -15% to 480 V +10%, 50/60 Hz ±5%									
Rated output voltage			3-phase: 380 to 480 V (Cannot exceed that of incoming voltage.)									
Rated output current (A)	at CT		1.5	2.5	3.8	5.3	9.0	14	19	25	32	38
	at VT		1.9	3.1	4.8	6.7	11.1	16	22	29	37	43
Radio noise filter			Built-in									
Weight (kg)			3.5	3.5	3.5	3.5	3.5	6	6	6	14	14
Braking	Regenerative braking		Built-in braking resistor circuit (discharge resistor)									
	Minimum connection resistance (Ω)		100	100	100	100	70	70	35	35	24	24

Class			3-phase 400 V								
Model name (3G3RX-)			A4220	A4300	A4370	A4450	A4550	B4750	B4900	B411K	B413K
Max. applicable motor 4P	kW	at CT	22	30	37	45	55	75	90	110	132
		at VT	30	37	45	55	75	90	110	132	160
Rated output capacity (kVA)	400 V	at CT	33.2	40.1	51.9	63.0	77.6	103.2	121.9	150.3	180.1
		at VT	39.4	48.4	58.8	72.7	93.5	110.8	135	159.3	200.9
	480 V	at CT	39.9	48.2	62.3	75.6	93.1	128.3	146.3	180.4	216.1
		at VT	47.3	58.1	70.6	87.2	112.2	133	162.1	191.2	241.1
Rated input voltage			3-phase (3-wire) 380 V -15% to 480 V +10%, 50/60 Hz ±5%								
Rated output voltage			3-phase: 380 to 480 V (Cannot exceed that of incoming voltage.)								
Rated output current (A)	at CT		48	58	75	91	112	149	176	217	260
	at VT		57	70	85	105	135	160	195	230	290
Radio noise filter			Built-in								
Weight (kg)			14	22	30	30	30	60	60	80	80
Braking	Regenerative braking		Built-in braking resistor circuit	Regenerative braking unit separately mounted							
	Minimum connection resistance (Ω)		20	—							

Common Specifications

Item		Specifications
Enclosure rating		IP20 up to 55 kW, IP00 from 75 to 132 kW
Cooling method		Forced air cooling
Control method		Phase-to-phase sinusoidal modulation PWM
Output frequency range		0.1 to 400 Hz
Frequency precision		Digital command: $\pm 0.01\%$ of the max. frequency Analog command: $\pm 0.2\%$ of the max. frequency ($25^{\circ}\text{C} \pm 10^{\circ}\text{C}$)
Frequency resolution		Digital setting: 0.01 Hz Analog setting: Max. frequency/4000 (Terminal O: 12 bits/0 to +10 V), (Terminal O2: 12 bits/-10 to +10 V), (Terminal OI: 12 bits/0 to +20 mA)
Voltage/Frequency characteristics		V/f optionally changeable at base frequencies of 30 to 400 Hz, V/f braking constant torque, reduction torque, sensor-less vector control, sensor-less vector control at 0 Hz
Speed fluctuation		$\pm 0.5\%$ (under sensor-less vector control or sensor-less vector control at 0 Hz)
Overload current rating		150%/60s, 200%/3s for CT and 120%/60s for VT
Acceleration/Deceleration time		0.01 to 3600.0 s (line/curve selection)
Starting torque		200%/0.3 Hz (under sensor-less vector control or sensor-less vector control at 0 Hz)
		150%/Torque at 0 Hz (under sensor-less vector control at 0 Hz, when a motor size one rank lower than specified is connected)
DC injection braking		Operates when the starting frequency is lower than that in deceleration via the STOP command, when the frequency reference is lower than the operation frequency, or via an external input (braking power, time, and frequency are variable)
Input	Frequency settings	Standard Digital Operator Setting via   keys
		External signal 0 to +10 V DC, -10 to +10 V DC (Input impedance: 10 k Ω) 4 to 20 mA (Input impedance: 100 Ω)
		External port Setting through RS485 communication
	Forward or reverse operation/Stop	Standard Digital Operator RUN/STOP (Forward/reverse switched via the parameter settings)
		External signal Forward/Stop (Reverse/Stop available at the time of multi-functional input terminal allocation) 3-wire input available (at the time of control circuit terminal block allocation)
		External port Setting through RS485 communication

Item		Specifications
Input	Multi-function input	<p>8 terminals, NO/NC switchable, sink/source logic switchable</p> <p>[Terminal function] 8 functions can be selected from among 61.</p> <p>Reverse (RV), Multi-step speed setting binary 1 (CF1), Multi-step speed setting binary 2 (CF2), Multi-step speed setting binary 3 (CF3), Multi-step speed setting binary 4 (CF4), Jogging (JG), DC injection braking (DB), 2nd control (SET), 2-step acceleration/deceleration (2CH), Free-run stop (FRS), External trip (EXT), USP function (USP), Commercial switching (CS), Soft lock (SFT), Analog input switching (AT), 3rd control (SET3), Reset (RS), 3-wire start (STA), 3-wire stop (STP), 3-wire forward/reverse (F/R), PID enabled/disabled (PID), PID integral reset (PIDC), Control gain switching (CAS), UP/DWN function accelerated (UP), UP/DWN function decelerated (DWN), UP/DWN function data clear (UDC), Forced operator (OPE), Multi-step speed setting bit 1 (SF1), Multi-step speed setting bit 2 (SF2), Multi-step speed setting bit 3 (SF3), Multi-step speed setting bit 4 (SF4), Multi-step speed setting bit 5 (SF5), Multi-step speed setting bit 6 (SF6), Multi-step speed setting bit 7 (SF7), Overload limit switching (OLR), Torque limit enabled (TL), Torque limit switching 1 (TRQ1), Torque limit switching 2 (TRQ2), P/PI switching (PPI), Brake confirmation (BOK), Orientation (ORT), LAD cancel (LAC), Position deviation clear (PCLR), Pulse train position command input permission (STAT), Frequency addition function (ADD), Forced terminal block (F-TM), Torque reference input permission (ATR), Integrated power clear (KHC), Servo ON (SON), Preliminary excitation (FOC), Analog command on hold (AHD), Position command selection 1 (CP1), Position command selection 2 (CP2), Position command selection 3 (CP3), Zero return limit signal (ORL), Zero return startup signal (ORG), Forward driving stop (FOT), Reverse driving stop (ROT), Speed/Position switching (SPD), Pulse counter (PCNT), Pulse counter clear (PCC), No allocation (no)</p>
	Thermistor input terminal	1 terminal (Positive/Negative temperature coefficient of resistance element switchable)
Output	Multi-function output	<p>5 open collector output terminals: NO/NC switchable, sink/source logic switchable</p> <p>1 relay (SPDT contact) output terminal: NO/NC switchable</p> <p>[Terminal function] 6 functions can be selected from among 45.</p> <p>Signal during RUN (RUN), Constant speed arrival signal (FA1), Over set frequency arrival signal (FA2), Overload warning (OL), Excessive PID deviation (OD), Alarm signal (AL), Set-frequency-only arrival signal (FA3), Overtorque (OTQ), Signal during momentary power interruption (IP), Signal during undervoltage (UV), Torque limit (TRQ), RUN time exceeded (RNT), Power ON time exceeded (ONT), Thermal warning (THM), Brake release (BRK), Brake error (BER), 0-Hz signal (ZS), Excessive speed deviation (DSE), Position ready (POK), Set frequency exceeded 2 (FA4), Set frequency only 2 (FA5), Overload warning 2 (OL2), Analog FV disconnection detection (FVDc), Analog FI disconnection detection (FIDc), Analog FE disconnection detection (FEDc), PID FB status output (FBV), Network error (NDc), Logic operation output 1 (LOG1), Logic operation output 2 (LOG2), Logic operation output 3 (LOG3), Logic operation output 4 (LOG4), Logic operation output 5 (LOG5), Logic operation output 6 (LOG6), Capacitor life warning (WAC), Cooling fan life warning (WAF), Starting contact signal (FR), Fan overheat warning (OHF), Light load detection signal (LOC), Operation ready (IRDY), Forward run (FWR), Reverse run (RVR), Fatal fault (MJA), Window comparator FV (WCFV), Window comparator FI (WCFI), Window comparator FE (WCFE), Alarm codes 0 to 3 (AC0 to AC3)</p>
	Multi-function monitor output terminal	Analog voltage output, Analog current output, Pulse train output (A-F, D-F {multiplied by "n", pulse output only}, A, T, V, P, etc.)
Display monitor		Output frequency, Output current, Output torque, Frequency conversion value, Trip record, I/O terminal status, Electric power, etc.
Other functions		V/f free setting (7), Upper/lower frequency limit, Frequency jump, Curve acceleration/deceleration, Manual torque boost level/break, Energy-saving operation, Analog meter adjustment, Starting frequency, Carrier frequency adjustment, Electronic thermal function, (free setting available), External start/end (frequency/rate), Analog input selection, Trip retry, Restart during momentary power interruption, Various signal outputs, Reduced voltage startup, Overload limit, Initialization value setting, Automatic deceleration at power-off, AVR function, Automatic acceleration/deceleration, Auto tuning (Online/Offline), High-torque multi-motor operation control (sensor-less vector control of two monitors with one Inverter)




Item		Specifications
Carrier frequency modification range		0.5 to 15 kHz for CT, 0.5 to 12 kHz for VT
Protective functions		Overcurrent protection, Overvoltage protection, Undervoltage protection, Electronic thermal protection, Temperature error protection, Momentary power interruption/Power interruption protection, Input phase loss protection, Braking resistor overload protection, Ground-fault current detection at power-on, USP error, External trip, Emergency shutoff trip, CT error, Communication error, Option error, etc.
Operating environment	Ambient/Storage temperature/ Humidity	-10°C to 50°C/-20°C to 65°C/20% to 90% RH (with no condensation)
	Vibration *	3G3RX-A□004 to A□220 5.9 m/s ² (0.6G), 10 to 55 Hz 3G3RX-A□300 to A□550, B4750 to B413K 2.94 m/s ² (0.3G), 10 to 55 Hz
	Location	At a maximum altitude of 1,000 m; indoors (without corrosive gases or dust)
Options	Feedback option	Sensor vector control
	Digital input option	4-digit BCD, 16-bit binary
Other options		Braking resistor, AC reactor, DC reactor, Digital Operator cables, Noise filter, Braking unit, etc.

* Complies with the test method specified in JIS C0040 (1999).

Note: Insulation distance complies with UL/CE standards.




7-2 Dimensional Drawing

■ 3G3RX-A2004/A2007/A2015/A2022/A2037
A4004/A4007/A4015/A4022/A4040






Specifications


■3G3RX-A2055/A2075/A2110
A4055/A4075/A4110




■3G3RX-A2150/A2185/A2220
A4150/A4185/A4220




■3G3RX-A2300/A4300






■3G3RX-A2370/A2450
A4370/A4450/A4550




■3G3RX-A2550



3G3RX-B4750/B4900




■3G3RX-B411K/B413K



7-3 Options

Braking Unit (AX-BCR□□□□□□□-TE)

■Dimensional Drawing



Reference	Dimensions					
	B	B1	H	H1	T	S
AX-BCR4015045-TE	82.5	40.5	150	138	220	6
AX-BCR4017068-TE						
AX-BCR2035090-TE	130	64.5	205	193	208	6
AX-BCR2070130-TE						
AX-BCR4035090-TE						
AX-BCR4070130-TE						
AX-BCR4090240-TE	131	64.5	298	280	300	9


■Specifications

Voltage	Reference	Specifications					
		Permanent		Peak (5s max)		Minimum connectable resistor (Ohms)	Superfast fuse F2 (A)
		Current (A)	Brake power (KVA)	Current (A)	Brake power (KVA)		
200V	AX-BCR2035090-TE	35	13	90	32	4	100
	AX-BCR2070130-TE	70	25	130	47	2.8	125
400V	AX-BCR4015045-TE	15	11	45	33	16	50
	AX-BCR4017068-TE	17	13	68	51	11	63
	AX-BCR4035090-TE	35	26	90	67	8.5	100
	AX-BCR4070130-TE	70	52	130	97	5.5	125
	AX-BCR4090240-TE	90	67	240	180	3.2	250


Braking Resistor (AX-REM□□K□□□□-IE)

■ Dimensional Drawing

AX-REM00K1200/400-IE



AX-REM00K2/4/5/6□□□-IE




7

Specifications

Type	Specifications		Dimensions					Weight
	Resistance (Ω)	Power (W)	L	H	M	I	T	KG
AX-REM00K2070-IE	70	200	105	27	36	94	-	0.2
AX-REM00K2120-IE	120	200						
AX-REM00K2200-IE	200	200						
AX-REM00K4075-IE	75	400	200	27	36	189	-	0.425
AX-REM00K4035-IE	35	400						
AX-REM00K4030-IE	30	400						
AX-REM00K5120-IE	120	500	260	27	36	249	-	0.58
AX-REM00K6100-IE	100	600	320	27	36	309	-	0.73
AX-REM00K6035-IE	35	600						


AX-REM00K9□□□-IE



Type	Specifications		Dimensions							Weight
	Resistance (Ω)	Power (W)	L	H	M	I	T	G	N	KG
AX-REM00K9070-IE	70	900	200	61	100	74	211	40	230	1.41
AX-REM00K9020-IE	20	900								
AX-REM00K9017-IE	17	900								

7


AX-REM01K9□□□-IE



Type	Specifications		Dimensions					Weight
	Resistance (Ω)	Power (W)	L	H	M	I	T	KG
AX-REM01K9070-IE	70	1900	365	73	105	350	70	4
AX-REM01K9017-IE	17	1900						


Specifications

AX-REM02/03K□□□□-IE



Type	Specifications		Dimensions					Weight
	Resistance (Ω)	Power (W)	L	H	M	I	T	KG
AX-REM02K1070-IE	70	2100	310	100	240	295	210	7
AX-REM02K1017-IE	17	2100						
AX-REM03K5035-IE	35	3500	365	100	240	350	210	8
AX-REM03K5010-IE	10	3500						

AX-REM19/38K□□□□-IE



Type	Specifications		Dimensions					Weight
	Resistance (Ω)	Power (W)	L	H	M	I	T	KG
AX-REM19K0030-IE	30	19000	206	350	140	190	50	8.1
AX-REM19K0020-IE	20	19000						
AX-REM19K0008-IE	8	19000						
AX-REM19K0006-IE	6	19000						
AX-REM38K0012-IE	12	38000	306	350	140	290	50	14.5

■ Simplified Selection Table for Braking Unit and Braking Resistor

Inverter				Braking resistor unit						
Max. motor kW		RX□	Braking Unit AX-BCR□	min. resistance Ω	Inverter mounted type (3 %ED, 10 sec max)		Braking torque %	External resistor 10%ED 10 sec max for built-in 5 sec max for Braking Unit		Braking torque %
		3-pha			Type AX-	Resist Ω		Type AX-	Resist Ω	
200 V (single-/three-phase)	0.55	2004	Built-in	50	REM00K1200-IE	200	180	REM00K1200-IE	200	180
	1.1	2007					100	REM00K2070-IE	70	200
	1.5	2015		35	REM00K2070-IE	70	140	REM00K4075-IE	75	130
	2.2	2022					90	REM00K4035-IE	35	180
	4.0	2037			REM00K4075-IE	75	50	REM00K6035-IE	35	100
	5.5	2055		16	REM00K4035-IE	35	75	REM00K9017-IE	17	150
	7.5	2075		10			55	REM01K9017-IE	17	110
	11.0	2110		REM00K6035-IE	35	40	REM02K1017-IE	17	75	
	15.0	2150		7.5	REM00K9017-IE	17	55	REM03K5010-IE	10	95
	18.5	2185			REM03K5010-IE	10	75	REM19K0008-IE	8	95
	22.0	2220		5		65	80			
	30.0	2300	2035090-TE	4				REM19K0006-IE	6	80
	37.0	2370							6	60
	45.0	2450	2070130-TE	2.8				2 x REM19K0006-IE	3	105
	55.0	2550							3	85
400 V (three-phase)	0.55	4004	Built-in	100	REM00K1400-IE	400	200	REM00K1400-IE	400	200
	1.1	4007					200			200
	1.5	4015			REM00K1200-IE	200	190	REM00K2200-IE	200	190
	2.2	4022			REM00K2200-IE	200	130	REM00K5120-IE	120	200
	4.0	4040		70	REM00K2120-IE	120	120	REM00K6100-IE	100	140
	5.5	4055			REM00K4075-IE	75	140	REM00K9070-IE	70	150
	7.5	4075		35			100	REM01K9070-IE	70	110
	11.0	4110		REM00K6100-IE	100	50	REM02K1070-IE	70	75	
	15.0	4150		24	REM00K9070-IE	70	55	REM03K5035-IE	35	110
	18.5	4185			REM03K5035-IE	35	90	REM19K0030-IE	30	100
	22.0	4220		20			75			85
	30.0	4300	4015045-TE	16				REM19K0020-IE	20	95
	37.0	4370	4017068-TE	11				REM38K0012-IE	12	125
	45.0	4450								100
	55.0	4550	4035090-TE	8.5				2 x REM19K0020-IE	10	100
	75.0	4750						3 x REM19K0030-IE	10	75
	90.0	4900	4070130-TE	5.5				2 x REM38K0012-IE	6	105
	110.0	411K	4090240-TE	3.2				3 x REM38K0012-IE	4	125
	132.0	413K								105

(1) Inverter specifications (choose voltage, capacity, and model)

The content noted in the table assumes the case of combining one Inverter and one motor of the same capacity.

(2) Select the %ED. Use the %ED that is equivalent to or lower than the value shown.

(3) Table above just contain typical recommended values that could work correctly in a wide range of applications. But special precaution and selection should be done when very large braking torque or continuous regeneration is required (for example cranes).


(5) The specified conditions contain restrictions. Make sure there are not any issues

* Calculated based on using a standard 4-pole motor.

* The simplified selection table above cannot be used in cases where a 10% ED is exceeded

DC Reactor (AX-RC□□□□□□□□-DE)

■Dimensional Drawing




Voltage	Reference AX-RC	Fig	Dimensions								Kg					
			A	B	C	D	E	F	G	H						
200V	10700032-DE	1	84	113	96	101	66	5	7.5	2	1.22					
	06750061-DE				105						1.60					
	03510093-DE				116						1.95					
	02510138-DE		108	135	124	120	82	6.5	9.5	9.5	3.20					
	01600223-DE				136						135	94	7	9.5	-	5.20
	01110309-DE				146											6.00
	00840437-DE		150	177	160	160	115	2	-	11.4						
	00590614-DE				182.6					14.3						
	00440859-DE															
	00301275-DE	2	195	161	162.5	185	88	10	-	-	17.0					
	00231662-DE			196			123				25.5					
	00192015-DE		240	188	200	228	109	12			34.0					
	00162500-DE			198			119				38.0					
	00133057-DE			228			149				42.0					
	400V	43000020-DE	1	84	113	96	101	66	5	7.5	2	1.22				
		27000030-DE				105						1.60				
14000047-DE		116				1.95										
10100069-DE		108		135	133	120	82	6.5	9.5	9.5	3.70					
06400116-DE					136						135	94	7	9.5	-	5.20
04410167-DE					146											6.00
03350219-DE		150		177	160	160	115	7	2	-	-	11.4				
02330307-DE					182.6							14.3				
01750430-DE																
01200644-DE		2	195	161	162.5	185	88	10	-	-	17.0					
00920797-DE				196			123				25.5					
00741042-DE			240	188	200	228	109	12			34.0					
00611236-DE				198			119				38.0					
00501529-DE				228			149				42.0					
00372094-DE																48.8
00312446-DE			300	216	250	288	133				67.0					
00252981-DE											67.0					
00213613-DE	236						153					79.0				

■ Specifications

Voltage	Inverter Type RX-	Max. applicable motor output kW	Reference	Current value (A)	Inductance (mH)
200V	A2004	0.4	AX-RC10700032-DE	3.2	10.70
	A2007	0.7	AX-RC06750061-DE	6.1	6.75
	A2015	1.5	AX-RC03510093-DE	9.3	3.51
	A2022	2.2	AX-RC02510138-DE	13.8	2.51
	A2037	3.7	AX-RC01600223-DE	22.3	1.60
	A2055	5.5	AX-RC01110309-DE	30.9	1.11
	A2075	7.5	AX-RC00840437-DE	43.7	0.84
	A2110	11.0	AX-RC00590614-DE	61.4	0.59
	A2150	15.0	AX-RC00440859-DE	85.9	0.44
	A2185 / A2220	18.5 to 22	AX-RC00301275-DE	127.5	0.30
	A2300	30	AX-RC00231662-DE	166.2	0.23
	A2370	37	AX-RC00192015-DE	201.5	0.19
	A2450	45	AX-RC00162500-DE	250.0	0.16
	A2550	55	AX-RC00133057-DE	305.7	0.13
400V	A4004	0.4	AX-RC43000020-DE	2.0	43.00
	A4007	0.7	AX-RC27000030-DE	3.0	27.00
	A4015	1.5	AX-RC14000047-DE	4.7	14.00
	A4022	2.2	AX-RC10100069-DE	6.9	10.10
	A4040	4.0	AX-RC06400116-DE	11.6	6.40
	A4055	5.5	AX-RC04410167-DE	16.7	4.41
	A4075	7.5	AX-RC03350219-DE	21.9	3.35
	A4110	11.0	AX-RC02330307-DE	30.7	2.33
	A4150	15.0	AX-RC01750430-DE	43.0	1.75
	A4185 / A4220	18.5 to 22	AX-RC01200644-DE	64.4	1.20
	A4300	30	AX-RC00920797-DE	79.7	0.92
	A4370	37	AX-RC00741042-DE	104.2	0.74
	A4450	45	AX-RC00611236-DE	123.6	0.61
	A4550	55	AX-RC00501529-DE	152.9	0.50
	B4750	75	AX-RC00372094-DE	209.4	0.37
	B4900	90	AX-RC00312446-DE	244.6	0.31
	B411K	110	AX-RC00252981-DE	298.1	0.25
	B413K	132	AX-RC00213613-DE	361.3	0.21

External EMC Filter (AX-FIR□□□□-RE)


■Dimensional Drawing



Voltage	Inverter model	Model	Dimensions						Filter type	Weight KG								
			L	W	H	X	Y	M										
3x200 V	3G3RX-A2004	AX-FIR2018-RE	305	125	45	290	110	M5	Footprint	2.0								
	3G3RX-A2007																	
	3G3RX-A2015																	
	3G3RX-A2022																	
	3G3RX-A2037																	
	3G3RX-A2055	AX-FIR2053-RE	312	212	56	296	110	M6	Footprint	2.5								
	3G3RX-A2075																	
	3G3RX-A2110																	
	3G3RX-A2150	AX-FIR2110-RE	455	110	240	414	80	Book type	8.0									
	3G3RX-A2185																	
	3G3RX-A2220																	
	3G3RX-A2300	AX-FIR2145-RE								8.6								
	3G3RX-A2370	AX-FIR3250-RE								13								
	3G3RX-A2450	AX-FIR3320-RE								13.2								
3G3RX-A2550	AX-FIR3320-RE								13.2									
3x400 V	3G3RX-A4004	AX-FIR3010-RE	305	125	45	290	110	M5	Footprint	1.9								
	3G3RX-A4007																	
	3G3RX-A4015																	
	3G3RX-A4022																	
	3G3RX-A4040																	
	3G3RX-A4055	AX-FIR3030-RE	312	212	50	296	189	M6	Footprint	2.2								
	3G3RX-A4075																	
	3G3RX-A4110																	
	3G3RX-A4150	AX-FIR3053-RE	451	252	60	435	229	M6	Footprint	4.5								
	3G3RX-A4185																	
	3G3RX-A4220																	
	3G3RX-A4300	AX-FIR3064-RE	598	310	70	578	265	M8	Book type	7.0								
	3G3RX-A4370	AX-FIR3100-RE	455	110	240	414	80	-		8.0								
	3G3RX-A4450	AX-FIR3130-RE								8.6								
	3G3RX-A4550	AX-FIR3130-RE								8.6								
	3G3RX-B4750	AX-FIR3250-RE	386	260	135	240	235	-		Book type	13.0							
	3G3RX-B4900																	
	3G3RX-B411K	AX-FIR3320-RE							AX-FIR3320-RE								13.2	
	3G3RX-B413K																	

Output AC Reactor (AX-RAO□□□□□□□□-DE)

■Dimensional Drawing



Reference	Dimensions						Weight Kg
	A	B2	C2	D	E	F	
AX-RAO11500026-DE	120	70	120	80	52	5.5	1.78
AX-RAO07600042-DE	120	70	120	80	52	5.5	1.78
AX-RAO04100075-DE	120	80	120	80	62	5.5	2.35
AX-RAO03000105-DE	120	80	120	80	62	5.5	2.35
AX-RAO01830160-DE	180	85	190	140	55	6	5.5
AX-RAO01150220-DE	180	85	190	140	55	6	5.5
AX-RAO00950320-DE	180	85	205	140	55	6	6.5
AX-RAO00630430-DE	180	95	205	140	65	6	9.1
AX-RAO00490640-DE	180	95	205	140	65	6	9.1
AX-RAO00390800-DE	240	110	275	200	75	6	16.0
AX-RAO00330950-DE	240	110	275	200	75	6	16.0
AX-RAO00251210-DE	240	110	275	200	75	6	16.0
AX-RAO00191450-DE	240	120	275	200	85	6	18.6
AX-RAO00161820-DE	240	150	275	200	110	6	27.0
AX-RAO00132200-DE	240	-	-	200	110	6	27.0
AX-RAO16300038-DE	120	70	120	80	52	5.5	1.78
AX-RAO11800053-DE	120	80	120	80	52	5.5	2.35
AX-RAO07300080-DE	120	80	120	80	62	5.5	2.35
AX-RAO04600110-DE	180	85	190	140	55	6	5.5
AX-RAO03600160-DE	180	85	205	140	55	6	6.5
AX-RAO02500220-DE	180	95	205	140	55	6	9.1
AX-RAO02000320-DE	180	105	205	140	85	6	11.7
AX-RAO01650400-DE	240	110	275	200	75	6	16.0
AX-RAO01300480-DE	240	120	275	200	85	6	18.6
AX-RAO01030580-DE	240	120	275	200	85	6	18.6
AX-RAO00800750-DE	240	120	275	200	110	6	27.0
AX-RAO00680900-DE	240	150	275	200	110	6	27.0


Reference	Dimensions						Weight Kg
	A	B2	C2	D	E	F	
AX-RAO00531100-DE	240	150	275	200	110	6	27.0
AX-RAO00401490-DE	300	165	320	200	125	6	44.0
AX-RAO00331760-DE	300	165	320	200	125	6	44.0
AX-RAO00262170-DE	360	-	-	300	145	8	70.0
AX-RAO00212600-DE	360	-	-	300	145	8	70.0

■ Specifications

Voltage	Max. applicable motor output kW	Reference	Current value (A)	Inductance (mH)
200 V class	0.4	AX-RAO11500026-DE	2.6	11.50
	0.75	AX-RAO07600042-DE	4.2	7.60
	1.5	AX-RAO04100075-DE	7.5	4.10
	2.2	AX-RAO03000105-DE	10.5	3.00
	3.7	AX-RAO01830160-DE	16.0	1.83
	5.5	AX-RAO01150220-DE	22.0	1.15
	7.5	AX-RAO00950320-DE	32.0	0.95
	11	AX-RAO00630430-DE	43.0	0.63
	15	AX-RAO00490640-DE	64.0	0.49
	18.5	AX-RAO00390800-DE	80.0	0.39
	22	AX-RAO00330950-DE	95.0	0.33
	30	AX-RAO00251210-DE	121.0	0.25
	37	AX-RAO00191450-DE	145.0	0.19
	45	AX-RAO00161820-DE	182.0	0.16
	55	AX-RAO00132200-DE	220.0	0.13
400 V class	0.4 to 1.5	AX-RAO16300038-DE	3.8	16.30
	2.2	AX-RAO11800053-DE	5.3	11.80
	4.0	AX-RAO07300080-DE	8.0	7.30
	5.5	AX-RAO04600110-DE	11.0	4.60
	7.5	AX-RAO03600160-DE	16.0	3.60
	11	AX-RAO02500220-DE	22.0	2.50
	15.0	AX-RAO02000320-DE	32.0	2.00
	18.5	AX-RAO01650400-DE	40.0	1.65
	22	AX-RAO01300480-DE	48.0	1.30
	30	AX-RAO01030580-DE	58.0	1.03
	37	AX-RAO00800750-DE	75.0	0.80
	45	AX-RAO00680900-DE	90.0	0.68
	55	AX-RAO00531100-DE	110.0	0.53
	75	AX-RAO00401490-DE	149.0	0.40
	90	AX-RAO00331760-DE	176.0	0.33
	110	AX-RAO00262170-DE	217.0	0.26
	132	AX-RAO00212600-DE	260.0	0.21

Input AC Reactor (AX-RAI□□□□□□□□-DE)

■ Dimensional Drawing




Voltage	Reference	Dimensions								Weight Kg		
		A	B1	B2	C1	C2	D	E	F			
200V	AX-RAI02800100-DE	120	-	80	-	120	80	62	5.5	2.35		
	AX-RAI00880200-DE											
	AX-RAI00350335-DE	180		85	-	190	140	55	6	5.5		
	AX-RAI00180670-DE											
	AX-RAI00091000-DE					205						
	AX-RAI00071550-DE					205	85					
	AX-RAI00042300-DE	240		130	-	210	-	200	75		16.0	
400V	AX-RAI07700050-DE	120	-	70	-			52	5.5	1.78		
	AX-RAI03500100-DE			80		120	80	62		2.35		
	AX-RAI01300170-DE									2.5		
	AX-RAI00740335-DE	180		85	-	190	140	55	6	5.5		
	AX-RAI00360500-DE											6.5
	AX-RAI00290780-DE					205				85	11.7	
	AX-RAI00191150-DE									16.0		
	AX-RAI00111850-DE	240		110	275	200	75	16.0				
	AX-RAI00072700-DE							165		-	210	-

■ Specifications

Voltage	Max. applicable motor output kW	Reference	Current value A	Inductance mH
3 phase 200V	0.4 to 1.5	AX-RAI02800100-DE	10.0	2.8
	2.2 to 3.7	AX-RAI00880200-DE	20.0	0.88
	5.5 to 7.5	AX-RAI00350335-DE	33.5	0.35
	11.0 to 15.0	AX-RAI00180670-DE	67.0	0.18
	18.5 to 22.0	AX-RAI00091000-DE	100.0	0.09
	30.0 to 37.0	AX-RAI00071550-DE	155.0	0.07
	45.0 to 55.0	AX-RAI00042300-DE	230.0	0.04
3 phase 400V	0.4 to 1.5	AX-RAI07700050-DE	5.0	7.7
	2.2 to 4.0	AX-RAI03500100-DE	10.0	3.5
	5.5 to 7.5	AX-RAI01300170-DE	17.0	1.3
	11.0 to 15.0	AX-RAI00740335-DE	33.5	0.74
	18.5 to 22.0	AX-RAI00360500-DE	50.0	0.36
	30.0 to 37.0	AX-RAI00290780-DE	78.0	0.29
	45.0 to 55.0	AX-RAI00191150-DE	115.0	0.19
	75.0 to 90.0	AX-RAI00111850-DE	185.0	0.11
	110.0 to 132.0	AX-RAI00072700-DE	270.0	0.07


Chokes (AX-FER□□□□-RE)

■ Dimensional Drawing





Reference	D diameter	Motor kW	Dimensions						Weight Kg
			L	W	H	X	Y	m	
AX-FER2102-RE	21	< 2.2	85	22	46	70	-	5	0.1
AX-FER2515-RE	25	< 15	105	25	62	90	-	5	0.2
AX-FER5045-RE	50	< 45	150	50	110	125	30	5	0.7
AX-FER6055-RE	60	< 55	200	65	170	180	45	6	1.7

■ 3G3AX-OP05



Digital Operator (3G3AX-OP)

■3G3AX-OP01



Panel cut dimensions

External dimensions	Height (55 mm) × Width (70 mm) × Depth (10 mm)
---------------------	--



Appendix


Appendix-1	Parameter List.....	App-1
Appendix-2	Product Life Curve.....	App-47
Appendix-3	Life Alarm Output	App-48
Appendix-4	EC Declaration of Conformity.....	App-49

Appendix-1 Parameter List

Monitor Mode (d□□□□)

- The default setting displays "d001" at power-on. To select the optional display, change the setting in "b038".

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
d001	Output frequency monitor [Output FQ]	0.00 to 400.00	—	Yes	Hz	4-1
d002	Output current monitor [Output current]	0.0 to 9999.0	—	—	A	4-1
d003	Rotation direction monitor [Rotation]	FWD: Forward STOP: Stop REV: Reverse	—	—	—	4-1
d004	PID feedback value monitor [PID-FB]	0.00 to 999000.00 (Enabled when the PID function is selected)	—	—	—	4-1
d005	Multi-function input monitor [Input]	 <p>Example FW, Multi-function input terminals 7, 2, 1: ON Multi-function input terminals 8, 6, 5, 4, 3: OFF</p>	—	—	—	4-2
d006	Multi-function output monitor [Output]	 <p>Example Multi-function output terminals 12, 11: ON Relay output terminal AL2, Multi-function output terminals 15, 14, 13: OFF</p>	—	—	—	4-2
d007	Output frequency monitor (after conversion) [Scaled FQ]	0.00 to 39960.00 (Output frequency x Conversion factor of b086)	—	Yes	—	4-2
d008	Real frequency monitor [Actual FQ]	-400.00 to 400.00	—	—	Hz	4-3
d009	Torque reference monitor [Torque command]	-200 to 200	—	—	%	4-3
d010	Torque bias monitor [Torque bias]	-200 to 200	—	—	%	4-3
d012	Output torque monitor [Output Torque]	-200 to 200	—	—	%	4-3
d013	Output voltage monitor [Output Voltage]	0.0 to 600.0	—	—	V	4-3

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
d014	Input power monitor [Input Power]	0.0 to 999.9	—	—	W	4-4
d015	Power ON time monitor [Watt-hour]	0.0 to 999999.9	—	—	—	4-4
d016	Total RUN time [RUN time]	0 to 999999	—	—	h	4-4
d017	Power ON time monitor [ON time]	0 to 999999	—	—	h	4-4
d018	Fin temperature monitor [Heatsink Tmp.]	-020. to 200.0	—	—	°C	4-4
d019	Motor temperature monitor [Motor tmp.]	-020. to 200.0	—	—	°C	4-5
d022	Life assessment monitor [Life (C/F)]	 <p>1: Main circuit board capacitor service life 2: Cooling fan rpm reduction</p>	—	—	—	4-5
d023	Program counter [Program Counter]	0 to 1024	—	—	—	—
d024	Program number [Program No.]	0 to 9999	—	—	—	—
d025	Drive programming monitor (UM0) [UM0]	-2147483647 to 2147483647	—	—	—	—
d026	Drive programming monitor (UM1) [UM1]	-2147483647 to 2147483647	—	—	—	—
d027	Drive programming monitor (UM2) [UM2]	-2147483647 to 2147483647	—	—	—	—
d028	Pulse counter monitor [Pls. Cnt.]	0 to 2147483647	—	—	—	4-6
d029	Position command monitor [Set pos]	-1073741823 to 1073741823 when HAPR is selected -268435456 to 268435456 when APR2 is selected	—	—	—	4-6
d030	Current position monitor [Curnt pos]	-1073741823 to 1073741823 when HAPR is selected -268435456 to 268435456 when APR2 is selected	—	—	—	4-6 4-137
d031	Clock [Clock]	Setting Data and Time for the LCD digital operator	—	—	—	—

Appendix-1 Parameter List

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
d060	Inverter mode [Inverter mode]	00 to 01	—	—	—	—
d080	Fault frequency monitor [Trip Counter]	0 to 65535	—	—	Time	4-6
d081	Fault monitor 1 (Latest) [ERR1]	Error code (condition of occurrence) →Output frequency [Hz] → Output current [A] →Internal DC voltage [V] →RUN time [h] →ON time [h]	—	—	—	4-7
d082	Fault monitor 2 [ERR2]					4-7
d083	Fault monitor 3 [ERR3]					4-7
d084	Fault monitor 4 [ERR4]					4-7
d085	Fault monitor 5 [ERR5]					4-7
d086	Fault monitor 6 [ERR6]					4-7
d090	Warning monitor [WARN]	Warning code 0 to 385	—	—	—	4-7
d102	DC voltage monitor [DC Voltage]	0.0 to 999.9	—	—	V	4-7
d103	Regenerative braking load rate monitor [BRD load]	0.0 to 100.0	—	—	%	4-7
d104	Electronic thermal monitor [E.Thermal]	0.0 to 100.0	—	—	%	4-7

Basic Function Mode (F□□□)

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
F001	Output frequency setting/monitor [SetFrequency (TM)]	0.0/Starting frequency to 1st/2nd/3rd max. frequency 0.00 to 400.00	0.00	Yes	Hz	4-8
F002	Acceleration time 1 [Accel.time1]	0.01 to 3600.00	10.00	Yes	s	4-8
F202	* 2nd acceleration time 1 [Accel.time1-M2]	0.01 to 3600.00	10.00	Yes	s	4-8
F302	* 3rd acceleration time 1 [Accel.time1-M3]	0.01 to 3600.00	10.00	Yes	s	4-8
F003	Deceleration time 1 [Decel.time1]	0.01 to 3600.00	10.00	Yes	s	4-8
F203	* 2nd deceleration time 1 [Decel.time1-M2]	0.01 to 3600.00	10.00	Yes	s	4-8
F303	* 3rd deceleration time 1 [Decel.time1-M3]	0.01 to 3600.00	10.00	Yes	s	4-8
F004	Operator rotation direction selection [Run key direction]	00: FWD (Forward) 01: REV (Reverse)	00	No	—	4-9

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Extended Function Mode

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Basic setting	A001	Frequency reference selection [Frequency source] 00: VR (Digital Operator (FREQ adjuster)) (Enabled when 3G3AX-OP01 is used.) 01: Terminal 02: Digital Operator (F001) 03: RS485 (ModBus communication) 04: Option 1 05: Option 2 06: Pulse train frequency 07: EzSQ (Drive programming) 10: (Math) Operation function result	01	No	—	4-10 4-144
	A002	RUN command selection [RUN cmd source] 01: Terminal 02: Digital Operator (F001) 03: RS485 (ModBus communication) 04: Option 1 05: Option 2	01	No	—	4-11
	A003	Base frequency [Base Frequency] 30 to Maximum frequency [A004]	50	No	Hz	4-11 4-112
	A203	* 2nd set base frequency [Base Frequency-M2] 30 to 2nd maximum frequency [A204]	50			4-11
	A303	* 3rd set base frequency [Base Frequency-M3] 30 to 3rd maximum frequency [A304]	50			
	A004	Maximum frequency [Max.Frequency] A003 to 400	50	No	Hz	4-12
	A204	* 2nd maximum frequency [Max.Frequency-M2] A203 to 400	50			
	A304	* 3rd maximum frequency [Max.Frequency-M3] A303 to 400	50			
Analog input, Others	A005	O/OI selection [AT Select] 00: [O]/[O2] Switches between O/OI terminal AT 01: [O]/[O2] Switches between O/O2 terminal AT 02: [O]/VR Switches between O/FREQ adjuster via terminal AT (Enabled only when 3G3AX-OP01 is used) 03: [OI]/VR Switches between OI/FREQ adjuster via terminal AT (Enabled only when 3G3AX-OP01 is used) 04: [O2]/VR Switches between O2/FREQ adjuster via terminal AT (Enabled only when 3G3AX-OP01 is used)	00	No	—	4-12

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Analog input, Others	A006	O2 selection [O2 Select] 00: [O2] only 01: [O/OI-P] auxiliary frequency reference (not reversible) 02: [O/OI-PM] auxiliary frequency reference (reversible) 03: [OFF] O2 disabled	03	No	—	4-12
	A011	O start frequency [[O] start FQ]	0.00	No	Hz	4-14
	A012	O end frequency [[O] end FQ]	0.00	No	Hz	
	A013	O start ratio [[O] start %]	0	No	%	
	A014	O end ratio [[O] end %]	100	No	%	
	A015	O start selection [[O] start FQ select] 00: External start frequency (A011 set value) 01: 0 Hz	01	No	—	
	A016	O, O2, OI sampling [Analog-in filter] 1 to 30 31 (with 500 ms filter ± 0.1 Hz hysteresis)	31	No	—	4-15
	A017	Drive Programming (EzSQ) Selection [EzSQ select] 0: Disable 1: [PRG] start 2: Always ON	00	No	—	—
Multi-step speed, Jogging	A019	Multi-step speed selection [Multispeed select] 00: Binary: 16-step selection with 4 terminals 01: Bit: 8-step selection with 7 terminals	00	No	—	4-16
	A020	Multi-step speed reference 0 [Multispeed 0]	6.00	Yes	Hz	4-8 4-16
	A220	* 2nd multi-step speed reference 0 [Multispeed 0-M2]	6.00	Yes	Hz	
	A320	* 3rd multi-step speed reference 0 [Multispeed 0-M3]	6.00	Yes	Hz	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Multi-step speed, Jogging	A021 Multi-step speed reference 1 [Multispeed 1]	0.0/Starting frequency to Max. frequency	0.00	Yes	Hz	4-16
	A022 Multi-step speed reference 2 [Multispeed 2]		0.00			
	A023 Multi-step speed reference 3 [Multispeed 3]		0.00			
	A024 Multi-step speed reference 4 [Multispeed 4]		0.00			
	A025 Multi-step speed reference 5 [Multispeed 5]		0.00			
	A026 Multi-step speed reference 6 [Multispeed 6]		0.00			
	A027 Multi-step speed reference 7 [Multispeed 7]		0.00			
	A028 Multi-step speed reference 8 [Multispeed 8]		0.00			
	A029 Multi-step speed reference 9 [Multispeed 9]		0.00			
	A030 Multi-step speed reference 10 [Multispeed 10]		0.00			
	A031 Multi-step speed reference 11 [Multispeed 11]		0.00			
	A032 Multi-step speed reference 12 [Multispeed 12]		0.00			
	A033 Multi-step speed reference 13 [Multispeed 13]		0.00			
	A034 Multi-step speed reference 14 [Multispeed 14]		0.00			
	A035 Multi-step speed reference 15 [Multispeed 15]		0.00			

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page	
Multi-step speed, Jogging	A038	Jogging frequency [Jog frequency]	0.00/Starting frequency to 9.99	6.00	Yes	Hz	4-18
	A039	Jogging stop selection [Jog stop mode]	00: FRS (Free running on jogging stop/ Disabled in operation) 01: DEC (Deceleration stop on jogging stop/ Disabled in operation) 02: DB (DC injection braking on jogging stop/ Disabled in operation) 03: FRS (RUN) (Free running on jogging stop/Enabled in operation) 04: DEC (RUN) (Deceleration stop on jogging stop/Enabled in operation) 05: DB (RUN) (DC injection braking on jogging stop/Enabled in operation)	04	No	—	
V/f characteristics	A041	Torque boost selection [TRQ boost sel]	00: Manual torque boost 01: Automatic torque boost	00	No	—	4-19
	A241	* 2nd torque boost selection [TRQ boost sel-M2]		00			
	A042	Manual torque boost voltage [TRQ boost V%]	0.0 to 20.0	1.0	Yes	%	
	A242	* 2nd manual torque boost voltage [TRQ boost V%-M2]		1.0			
	A342	* 3rd manual torque boost voltage [TRQ boost V%-M3]		1.0			
	A043	Manual torque boost frequency [TRQ boost FQ%]	0.0 to 50.0	5.0	Yes	%	
	A243	* 2nd manual torque boost frequency [TRQ boost FQ%-M2]		5.0			
	A343	* 3rd manual torque boost frequency [TRQ boost FQ%-M3]]		5.0			

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
V/f characteristics	A044	V/f characteristics selection [V/F select]	00: VC (Constant torque characteristics) 01: VP (Special reduced torque characteristics) 02: Free V/f (characteristics) 03: SLV (Sensorless vector control) 04: 0SLV (0-Hz sensorless vector control) 05: V2 (Sensor vector control)	00	No	—	4-21
	A244	* 2nd V/f characteristics selection [V/F select-M2]	00: VC (Constant torque characteristics) 01: VP (Special reduced torque characteristics) 02: Free V/f (characteristics) 03: SLV (Sensorless vector control) 04: 0SLV (0-Hz sensorless vector control) 05: V2 (Sensor vector control)	00			
	A344	* 3rd V/f characteristics selection [V/F select-M3]	00: VC (Constant torque characteristics) 01: VP (Special reduced torque characteristics)	00			
	A045	Output voltage gain [V/F gain]	20 to 100	100	Yes	%	4-24
	A046	Automatic torque boost voltage compensation gain [A.TQ-BST V gain]	0 to 255	100	Yes	—	4-20
	A246	* 2nd automatic torque boost voltage compensation gain [A.TQ-BST V gain-M2]	0 to 255	100			
	A047	Automatic torque boost slip compensation gain [A.TQ-BST SL gain]	0 to 255	100	Yes	—	
	A247	* 2nd automatic torque boost slip compensation gain [A.TQ-BST SL gain-M2]	0 to 255	100			

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page	
DC injection braking	A051	DC injection braking selection [DB enable]	00: OFF (Disabled) 01: ON (Enabled) 02: ON (FQ) (Frequency control [A052 set value])	00	No	—	4-24 4-112
	A052	DC injection braking frequency [DB Frequency]	0.00 to 400.00	0.50	No	Hz	4-24
	A053	DC injection braking delay time [DB wait time]	0.0 to 5.0	0.0	No	s	4-24
	A054	DC injection braking power [DB force]	0 to 100 (0.4 to 55 kW)	50	No	%	
			0 to 80 (75 to 132 kW)	40	No	%	
	A055	DC injection braking time [DB decel time]	0.0 to 60.0	0.5	No	s	
	A056	DC injection braking method selection [DB input select]	00: Edge operation 01: Level operation	01	No	—	
	A057	Startup DC injection braking power [DB force start]	0 to 100 (0.4 to 55 kW) 0 to 80 (75 to 132 kW)	0	No	%	
	A058	Startup DC injection braking time [DB time start]	0.0 to 60.0	0.0	No	s	
A059	DC injection braking carrier frequency [DB carrier FQ]	0.5 to 15.0 (0.4 to 55 kW)	5.0	No	kHz		
		0.5 to 10.0 (75 to 132 kW)	3.0	No	kHz		
Upper/Lower limiter, Jump	A061	Frequency upper limit [FQ upper limit]	0.00/Frequency lower limit to Max. Frequency	0.00	No	Hz	4-28
	A261	* 2nd frequency upper limit [FQ upper limit-M2]	0.00/2nd frequency lower limit to 2nd Max. Frequency	0.00			
	A062	Frequency lower limit [FQ lower limit]	0.00/Starting frequency to Frequency upper limit	0.00	No	Hz	
	A262	* 2nd frequency lower limit [FQ lower limit-M2]	0.00/Starting frequency to 2nd frequency upper limit	0.00			

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Upper/Lower limit, Jump	A063	Jump frequency 1 [Jump FQ1 Center]	0.00	No	Hz	4-30
	A064	Jump frequency width 1 [Jump FQ1 Width]	0.50			
	A065	Jump frequency 2 [Jump FQ2 Center]	0.00			
	A066	Jump frequency width 2 [Jump FQ2 Width]	0.50			
	A067	Jump frequency 3 [Jump FQ3 Center]	0.00			
	A068	Jump frequency width 3 [Jump FQ3 Width]	0.50			
	A069	Acceleration stop frequency [Accel hold FQ]	0.00 to 400.00	No	Hz	
	A070	Acceleration stop time [Accel hold time]	0.0 to 60.0	No	s	
PID control	A071	PID selection [PID enable]	00: OFF (Disabled) 01: ON (+) (Enabled) 02: ON (+/-) (Reverse output enabled)	No	—	4-31
	A072	PID P gain [PID P gain]	0.2 to 5.0	Yes	—	
	A073	PID I gain [PID I gain]	0.0 to 3600.0	Yes	s	
	A074	PID D gain [PID D gain]	0.00 to 100.00	Yes	s	
	A075	PID scale [PID scale convert]	0.01 to 99.99	No	Time	
	A076	PID feedback selection [PV source select]	00: OI 01: O 02: Modbus (RS485 communication) 03: Pulse (Pulse train frequency) 10: Math (Operation function output)	No	—	
	A077	Reverse PID function [Reverse PID action]	00: OFF (Deviation = Target value - Feedback value) 01: ON (Deviation = Feedback value - Target value)	No	—	
	A078	PID output limit function [PID limit]	0.0 to 100.0	No	%	
	A079	PID feedforward selection [PID F-Fwd select]	00: Disabled 01: O 02: OI 03: O2	No	—	4-31

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
AVR	A081	AVR selection [AVR select] 00: Always ON 01: Always OFF 02: OFF during deceleration	02	No	—	4-35
	A082	AVR voltage selection [AVR voltage sel] 200-V class: 200/215/220/230/240 400-V class: 380/400/415/440/460/480	200/ 400	No	V	
RUN mode, Acceleration/Deceleration functions	A085	RUN mode selection [Operation mode] 00: Normal operation 01: Energy-saving operation 02: Automatic operation	00	No	—	4-36
	A086	Energy-saving response/accuracy adjustment [Energy-saving tune] 0.0 to 100.0	50.0	Yes	—	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page	
RUN mode, Acceleration/Deceleration functions	A092	Acceleration time 2 [Accel.time2]	0.01 to 3600.00	10.00	Yes	s	4-37	
	A292	* 2nd acceleration time 2 [Accel.time2-M2]		10.00				
	A392	* 3rd acceleration time 2 [Accel.time2-M3]		10.00				
	A093	Deceleration time 2 [Decel.time2]		10.00				
	A293	* 2nd deceleration time 2 [Decel.time2-M2]		10.00				
	A393	* 3rd deceleration time 2 [Decel.time2-M3]		10.00				
	A094	2-step acceleration/ deceleration selection [Acc2/Dec2 sel]	00: 2CH-Terminal (Switched via multi-function input 09) 01: Preset FQ (Switched by setting) 02: FWD-REV (Enabled only when switching forward/reverse)	00	No	—		
	A294	* 2nd 2-step acceleration/ deceleration selection [Acc2/Dec2 sel-M2]		00				
	A095	2-step acceleration frequency [Acc.1-2 FQ]	0.00 to 400.00	0.00	No	Hz		
	A295	* 2nd 2-step acceleration frequency [Acc.1-2 FQ-M2]		0.00				
	A096	2-step deceleration frequency [Dec.1-2 FQ]		0.00	No	Hz		
	A296	* 2nd 2-step deceleration frequency [Dec. 1-2 FQ-M2]		0.00				
	A097	Acceleration pattern selection [Accel.curve select]	00: Line 01: S-curve 02: U-curve 03: inv.U curve 04: EL-S curve	01	No	—		4-38
	A098	Deceleration pattern selection [Decel. curve select]		01	No	—		

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
External frequency adjustment	A101	OI start frequency [[OI] start FQ]	0.00	No	Hz	4-14
	A102	OI end frequency [[OI] end FQ]	0.00	No	Hz	
	A103	OI start ratio [[OI] start %]	20	No	%	
	A104	OI end ratio [[OI] end %]	100	No	%	
	A105	OI start selection [[OI] start FQ select]	00: Start FQ (Use OI start frequency [A101]) 01: 0 Hz	No	—	
Ext freq adjustment	A111	O2 start frequency [[O2] start FQ]	0.00	No	Hz	4-15
	A112	O2 end frequency [[O2] end FQ]	0.00	No	Hz	
	A113	O2 start ratio [[O2] start %]	-100	No	%	
	A114	O2 end ratio [[O2] end %]	100	No	%	
Accel/Decel	A131	Acceleration curve parameter [Accel.curve const]	02	No	—	4-38
	A132	Deceleration curve parameter [Decel.curve const]	02	No	—	
Operation frequency	A141	Operation frequency input A setting [A-input calc. FQ]	00: Operator (Digital Operator (F001)) 01: VR (Digital Operator (FREQ adjuster)) (Enabled when 3G3AX-OP01 is used.) 02: O (Input O) 03: OI (Input OI)	No	—	4-41
	A142	Operation frequency input B setting [B-input calc. FQ]	04: Modbus (RS485 communication) 05: Option 1 06: Option 2 07: Pulse (Pulse train frequency)	No	—	
	A143	Operator selection [Calculation symbol]	00: ADD (Addition (A + B)) 01: SUB (Subtraction (A - B)) 02: MUL (Multiplication (A × B))	No	—	
	A145	Frequency addition amount [Add frequency]	0.00 to 99.99 100.0 to 400.0	No	Hz	4-41
	A146	Frequency addition direction [Add direction]	00: ADD (Add A145 value to output frequency) 01: SUB (Subtract A145 value from output frequency)	No	—	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Acceleration/Deceleration	A150	EL-S-curve ratio 1 during acceleration [EL-S start accel]	10	No	%	4-39
	A151	EL-S-curve ratio 2 during acceleration [EL-S end accel]	10	No	%	
	A152	EL-S-curve ratio 1 during deceleration [EL-S start decel]	10	No	%	
	A153	EL-S-curve ratio 2 during deceleration [EL-S end decel]	10	No	%	
Momentary power interruption/Trip restart	b001	Retry selection [Restart mode UV] 00: TRIP (Alarm) 01: 0 Hz start 02: f-match (Frequency matching start) 03: f-match Trip (Trip after frequency matching deceleration stop) 04: Actv. f-match (Active Frequency Matching restart)	00	No	—	4-42
	b002	Allowable momentary power interruption time [Allowable UV time] 0.3 to 25.0	1.0	No	s	
	b003	Retry wait time [Retry wait time UV] 0.3 to 100.0	1.0	No	s	4-87
	b004	Momentary power interruption/ undervoltage trip during stop selection [UV trip on stop] 00: OFF (Disabled) 01: ON (Enabled) 02: Decel-OFF (Disabled during stop and deceleration stop)	00	No	—	4-42
	b005	Momentary power interruption retry time selection [No. Of restart UV] 00: 16 times 01: No limit	00	No	—	
	b006	Input phase loss protection selection [Phase loss detection] 00: OFF (Disabled) 01: ON (Enabled)	01	No	—	4-46
	b007	Frequency matching lower limit frequency setting [Restart min. FQ] 0.00 to 400.00	0.00	No	Hz	4-42 4-71 4-87
	b008	Trip retry selection [Restart mode OV/ OC] 00: TRIP (Alarm) 01: 0 Hz start 02: f-match (Frequency matching start) 03: f-match Trip (Trip after frequency matching deceleration stop) 04: Actv. f-match (Active Frequency Matching restart)	00	No	—	4-42

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Momentary power interruption/Trip restart	b009	Undervoltage retry time selection [Under voltage retry]	00: 16 times 01: No limit	00	No	—	4-42
	b010	Overvoltage/ overcurrent retry time selection [No. Of restart OV/ OC]	1 to 3	3	No	Time	
	b011	Trip retry wait time [Retry wait time OV/ OC]	0.3 to 100.0	1.0	No	s	
Electronic Thermal	b012	Electronic thermal level [E. Thermal Level]	0.20 × Rated current to 1.00 × Rated current	Rated current	No	A	4-46
	b212	* 2nd electronic thermal level [E. Thermal Level-M2]					
	b312	* 3rd electronic thermal level [E. Thermal Level-M3]					
	b013	Electronic thermal characteristics selection [E. Thermal Character]	00 01: Const TRQ (Constant torque characteristics) 02: Free set (Free setting)	No	—		
	b213	* 2nd electronic thermal characteristics selection [E. Thermal Character-M2]					
	b313	* 3rd electronic thermal characteristics selection [E. Thermal Character-M3]					

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Electronic Thermal	b015	Free setting, electronic thermal frequency 1 [Free E.Thermal FQ-1]	0 to 400	0	No	Hz	4-46
	b017	Free setting, electronic thermal frequency 2 [Free E.Thermal FQ-2]					
	b019	Free setting, electronic thermal frequency 3 [Free E.Thermal FQ-3]					
	b016	Free setting, electronic thermal current 1 [Free E.Thermal I-1]	0.0 to Rated current	0.0	No	A	
	b018	Free setting, electronic thermal current 2 [Free E.Thermal I-2]					
	b020	Free setting, electronic thermal current 3 [Free E.Thermal I-3]					

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Overload limit, Overcurrent Protection	b021	Overload limit selection [OL restrict mode] 00: OFF (Disabled) 01: ON-Acc/Cnst (Enabled in acceleration/ constant speed operation) 02: ON-Cnst (Enabled in constant speed operation) 03: ON-A/C(R) (Enabled in acceleration/ constant speed operation (Accelerates during regeneration))	01	No	—	4-49
	b022	Overload limit level [OL restrict level] 0.20 × Rated current to 2.00 × Rated current (0.4 to 55 kW) 0.20 × Rated current to 1.80 × Rated current (75 to 132 kW)	1.50 × Rated current	No	A	
	b023	Overload limit parameter [Decel.rate OL restrict] 0.10 to 30.00	1.00	No	s	
	b024	Overload limit selection 2 [OL restrict 2 mode] 00: OFF (Disabled) 01: ON-Acc/Cnst (Enabled in acceleration/ constant speed operation) 02: ON-Cnst (Enabled in constant speed operation) 03: ON-A/C(R) (Enabled in acceleration/ constant speed operation (Accelerates during regeneration))	01	No	—	
	b025	Overload limit level 2 [OL restrict 2 level] 0.20 × Rated current to 2.00 × Rated current (0.4 to 55 kW) 0.20 × Rated current to 1.80 × Rated current (75 to 132 kW)	1.50 × Rated current	No	A	
	b026	Overload limit parameter 2 [Decel.rate OL2 rstr] 0.10 to 30.00	1.00	No	s	
	b027	Overcurrent suppression function [OC suppress select] 00: OFF (Disabled) 01: ON (Enabled)	00	No	—	4-51
	b028	Active Frequency Matching restart level [Curnt Active F- match] 0.20 × Rated current to 2.00 × Rated current (0.4 to 55 kW) 0.20 × Rated current to 1.80 × Rated current (75 to 132 kW)	Rated current	No	A	4-43 4-71
	b029	Active Frequency Matching restart parameter [Decel.rate act.F- match] 0.10 to 30.00	0.50	No	s	
	b030	Starting frequency at Active Frequency Matching restart [Start FQ act.F- match] 00: Off FQ (Frequency at interruption) 01: Max.FQ (Max. Frequency) 02: Set FQ (Set Frequency)	00	No	—	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Lock	b031	Soft lock selection [Softlock select]	00: Lock (SFT) (Data other than b031 cannot be changed when terminal SFT is ON) 01: Only FQ (SFT) (Data other than b031 and the specified frequency parameter cannot be changed when terminal SFT is ON) 02: Lock (Data other than b031 cannot be changed) 03: Only FQ (Data other than b031 and the specified frequency parameter cannot be changed) 10: RUN chg mode (Data other than parameters changeable during operation cannot be changed)	01	No	—	4-51
Others	b034	RUN time/Power ON time setting [RNT/ONT time]	0 to 65535	0	No	h	4-52
	b035	Rotation direction limit selection [Rotation restriction]	00: FREE (Forward and Reverse are enabled) 01: FWD (Only Forward is enabled) 02: REV (Only Reverse is enabled)	00	No	—	4-52
	b036	Reduced voltage startup selection [Reduced V start]	0 (Reduced voltage startup time: small) to 255 (Reduced voltage startup time: large)	6	No	—	4-53
	b037	Display selection [Display restriction]	00: All (Complete display) 01: Utilized (Individual display of functions) 02: User (User setting) 03: Compare (Data comparison display) 04: Basic (Basic display)	00	No	—	4-53
	b038	Initial screen selection [Initial display]	000 to 202	001	No	—	4-56
	b039	User parameter automatic setting function selection [Auto U param. regist]	00: OFF (Disabled) 01: ON (Enabled)	00	No	—	4-57
Torque limit	b040	Torque limit selection [TRQ limit select]	00: 4-quadrant (Four-quadrant separate setting) 01: TRQ input (Terminal switch) 02: [O] input (Analog input) 03: Option 1 04: Option 2	00	No	—	4-57 4-59
	b041	Torque limit 1 (Four-quadrant mode forward power running) [TRQ limit FW/POW]	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) no (Torque limit disabled)	150	No	%	4-57 4-59

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page	
Torque limit	b042	Torque limit 2 (Four-quadrant mode reverse regeneration) [TRQ limit RV/REG]	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) no (Torque limit disabled)	150	No	%	4-57 4-59
	b043	Torque limit 3 (Four-quadrant mode reverse power running) [TRQ limit RV/POW]	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) no (Torque limit disabled)	150	No	%	
	b044	Torque limit 4 (Four-quadrant mode forward regeneration) [TRQ limit FW/REG]	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW) no (Torque limit disabled)	150	No	%	
	b045	Torque LADSTOP selection [TRQ limit LADSTOP]	00: OFF (Disabled) 01: ON (Enabled)	00	No	—	4-59
Others	b046	Reverse rotation prevention selection [Rev RUN protect]	00: OFF (Disabled) 01: ON (Enabled)	00	No	—	4-59
	b049	Dual rate selection [Dual rate select]	00: CT (Constant torque) 01: VT (Variable torque)	00	No	—	—

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Others	b050	Selection of non-stop function at momentary power interruption [Ctrl'd decel. select] 00: OFF (Disabled) 01: V-Cnst (STOP) (Enabled (deceleration stop)) 02: NS1 (Enabled (without recovery)) 03: NS2 (Enabled (with recovery))	00	No	—	4-60
	b051	Starting voltage of non-stop function at momentary power interruption [DC Volt ctrl'd. decel]	220/ 440	No	V	
	b052	Stop deceleration level of non-stop function at momentary power interruption [OV lvl ctrl'd. decel]	360/ 720	No	V	
	b053	Deceleration time of non-stop function at momentary power interruption [Decel time ctrl'd. dec]	1.00	No	s	
	b054	Deceleration starting width of non-stop function at momentary power interruption [FQ drop ctrl'd. decel]	0.00	No	Hz	
	b055	Proportional gain setting of non-stop function at momentary power interruption [P gain ctrl'd. decel]	0.20	Yes	—	
	b056	Integral time setting of non-stop function at momentary power interruption [I gain ctrl'd. decel]	0.100	Yes	s	4-63

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Others	b060	Window comparator O upper limit level [Windw comp [O] max] Set an upper limit level. Setting range: 0 to 100 Lower limit: Lower limit level + Hysteresis width × 2	100	Yes	%	4-66
	b061	Window comparator O lower limit level [Windw comp [O] min] Set a lower limit level. Setting range: 0 to 100 Upper limit: Upper limit level - Hysteresis width × 2	0	Yes	%	
	b062	Window comparator O hysteresis width [Windw comp [O] hys] Set a hysteresis width for the upper and lower limit levels. Setting range: 0 to 10 Upper limit: (Upper limit level - Lower limit level) × 2	0	Yes	%	
	b063	Window comparator OI upper limit level [Windw comp [OI] max] Set an upper limit level. Setting range: 0 to 100 Lower limit: Lower limit level + Hysteresis width × 2	100	Yes	%	
	b064	Window comparator OI lower limit level [Windw comp [OI] min] Set a lower limit level. Setting range: 0 to 100 Upper limit: Upper limit level - Hysteresis width × 2	0	Yes	%	
	b065	Window comparator OI hysteresis width [Windw comp [OI] hys] Set a hysteresis width for the upper and lower limit levels. Setting range: 0 to 10 Upper limit: (Upper limit level - Lower limit level) × 2	0	Yes	%	
	b066	Window comparator O2 upper limit level [Windw comp [O2] max] Set an upper limit level. Setting range: -100 to 100 Lower limit: Lower limit level + Hysteresis width × 2	100	Yes	%	4-66
	b067	Window comparator O2 lower limit level [Windw comp [O2] min] Set a lower limit level. Setting range: -100 to 100 Upper limit: Upper limit level - Hysteresis width × 2	-100	Yes	%	
	b068	Window comparator O2 hysteresis width [Windw comp [O2] hys] Set a hysteresis width for the upper and lower limit levels. Setting range: 0 to 10 Upper limit: (Upper limit level - Lower limit level) × 2	0	Yes	%	
	b070	Analog operation level at O disconnection [Discon Level [O]] 0 to 100/no (ignored)	no	No	—	
	b071	Analog operation level at OI disconnection [Discon Level [OI]] 0 to 100/no (ignored)	no	No	—	
	b072	Analog operation level at O2 disconnection [Discon Level [O2]] -100 to 100/no (ignored)	no	No	—	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
b078	Integrated power clear [Clear kWh data]	Cleared with the Enter key after changing to 01	00	Yes	—	4-4
b079	Integrated power display gain [kWh display gain]	1 to 1000	1	No	—	
b082	Starting frequency [Start Frequency]	0.10 to 9.99	0.50	No	Hz	4-68
b083	Carrier frequency [Carrier frequency]	0.5 to 15.0 (0.4 to 55 kW) *Derating enabled	5.0	No	kHz	4-68 4-120
		0.5 to 10.0 (75 to 132 kW) *Derating enabled	3.0	No	kHz	
b084	Initialization selection [Initialize Mode]	00: no (Clears the trip monitor) 01: Trip data (Initializes data) 02: Parameters)Clears the trip monitor and initializes data) 03: Trip+Param (Clears the trip monitor and parameters) 04: Trp+Prm+EzSQ (Clears trip monitor, parameters and Drive program)	00	No	—	4-70
b085	Initialization parameter selection [Initial data select]	01 *Do not change.	01	No	—	
b086	Frequency conversion coefficient [FQ scale factor]	0.1 to 99.9	1.0	Yes	—	4-2
b087	STOP key selection [STOP key enable]	00: ON (Enabled) 01: OFF (Disabled) 02: Only RESET (Disabled only during stop)	00	No	—	4-70
b088	Free-run stop selection [Restart after FRS]	00: 0 Hz start 01: f-match (Frequency matching start) 02: Actv. f-match (Active Frequency Matching restart)	00	No	—	4-71
b089	Automatic carrier reduction [Auto.Carrier reduce]	00: OFF (Disabled) 01: ON (Enabled)	00	No	—	4-73
b090	Usage rate of regenerative braking function [BRD use ratio]	0.0 to 100.0	0.0	No	%	4-74
b091	Stop selection [Stop mode select]	00: Decel-Stop (Deceleration → Stop) 01: Free-RUN (Free-run stop)	00	No	—	4-70
b092	Cooling fan control [Cooling fan ctrl]	00: Alws-ON (Always ON) 01: ON in RUN (ON during RUN)	01	No	—	4-74
b095	Regenerative braking function operation selection [BRD ctrl select]	00: OFF (Disabled) 01: RUN-ON (Enabled (Disabled during stop)) 02: Alws-ON (Enabled (Enabled during stop))	00	No	—	
b096	Regenerative braking function ON level [BRD activation]	330 to 380 660 to 760	360/ 720	No	V	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Others	b098	Thermistor selection [Thermistor select]	00: Disabled 01: PTC enabled 02: NTC enabled	00	No	—	4-75
	b099	Thermistor error level [Thermistor level]	0 to 9999	3000	No	Ω	
Vf free setting	b100	Free V/f frequency 1 [Free V/F-F1]	0 to Free V/f frequency 2	0	No	Hz	4-22
	b101	Free V/f voltage 1 [Free V/F-V1]	0.0 to 800.0	0.0	No	V	
	b102	Free V/f frequency 2 [Free V/F-F2]	0 to Free V/f frequency 3	0	No	Hz	
	b103	Free V/f voltage 2 [Free V/F-V2]	0.0 to 800.0	0.0	No	V	
	b104	Free V/f frequency 3 [Free V/F-F3]	0 to Free V/f frequency 4	0	No	Hz	
	b105	Free V/f voltage 3 [Free V/F-V3]	0.0 to 800.0	0.0	No	V	
	b106	Free V/f frequency 4 [Free V/F-F4]	0 to Free V/f frequency 5	0	No	Hz	
	b107	Free V/f voltage 4 [Free V/F-V4]	0.0 to 800.0	0.0	No	V	
	b108	Free V/f frequency 5 [Free V/F-F5]	0 to Free V/f frequency 6	0	No	Hz	
	b109	Free V/f voltage 5 [Free V/F-V5]	0.0 to 800.0	0.0	No	V	
	b110	Free V/f frequency 6 [Free V/F-F6]	0. to Free V/f frequency 7	0	No	Hz	
	b111	Free V/f voltage 6 [Free V/F-V6]	0.0 to 800.0	0.0	No	V	
	b112	Free V/f frequency 7 [Free V/F-F7]	0. to 400	0	No	Hz	
	b113	Free V/f voltage 7 [Free V/F-V7]	0.0 to 800.0	0.0	No	V	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
b120	Brake control selection [Brake control sel]	00: OFF (Disabled) 01: ON (Enabled)	00	No	—	4-77
b121	Brake wait time for release [Brake w.time Rels]	0.00 to 5.00	0.00	No	s	
b122	Brake wait time for acceleration [Brake w.time Accel]	0.00 to 5.00	0.00	No	s	
b123	Brake wait time for stopping [Brake w.time Stop]	0.00 to 5.00	0.00	No	s	
b124	Brake wait time for confirmation [Brake w.time Confirm]	0.00 to 5.00	0.00	No	s	
b125	Brake release frequency [Brake Release FQ]	0.00 to 400.00	0.00	No	Hz	
b126	Brake release current [Brake Release I]	0.0 to 2.00 × Rated current (0.4 to 55 kW) 0.0 to 1.80 × Rated current (75 to 132 kW)	Rated current	No	—	
b127	Brake input frequency [Braking Frequency]	0.00 to 400.00	0.00	No	Hz	4-78
b130	Overvoltage protection function selection during deceleration [Over-V supp.select]	00: OFF (Disabled) 01: V-const (DC voltage kept constant) 02: Accel (Acceleration enabled)	01	No	—	
b131	Overvoltage protection level during deceleration [Over-V supp. level]	200-V class: 330 to 390 400-V class: 660 to 780	380/ 760	No	V	
b132	Overvoltage protection parameter [Over-V supp. constant]	0.10 to 30.00	1.00	No	s	
b133	Overvoltage protection proportional gain setting [Over-V supp.P-gain]	0.00 to 2.55	0.50	Yes	—	
b134	Overvoltage protection integral time setting [Over-V supp.I-gain]	0.000 to 65.535	0.060	Yes	s	
b164	Auto return initial display [Auto return init.disp]	00: OFF 01: ON	00	No	—	—
b166	Data Read/Write selection [Data R/W select]	00: R/W OK (Read/Write Ok) 01: R/W Protected (Read/Write Protected)	00	No	—	—

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Others	b180	Initialize trigger [Initialize trigger]	00: No action 01: Initialize	00	No	—
Multi-function input terminals	C001	Multi-function input 1 selection *1 [Input [1] Function]	01 *1	No	—	4-79
	C002	Multi-function input 2 selection [Input [2] Function]	12			
	C003	Multi-function input 3 selection *1 [Input [3] Function]	18			
	C004	Multi-function input 4 selection [Input [4] Function]	02			
	C005	Multi-function input 5 selection [Input [5] Function]	03			
	C006	Multi-function input 6 selection [Input [6] Function]	06			
	C007	Multi-function input 7 selection [Input [7] Function]	08			
	C008	Multi-function input 8 selection [Input [8] Function]	no			

*1. C001 and C003 are forcibly rewritten into 18 (RS) and 64 (EMR), respectively, when the emergency shutoff function is enabled (SW1 = ON). (64 cannot be set optionally.)
When SW1 is turned ON once and then OFF, C003 has no allocations ("no").

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Multi-function input terminals	C011	Multi-function input 1 operation selection [Input [1] actv. State]	00	No	—	4-81
	C012	Multi-function input 2 operation selection [Input [2] actv. State]	00			
	C013	Multi-function input 3 operation selection [Input [3] actv. State]	00			
	C014	Multi-function input 4 operation selection [Input [4] actv. State]	00			
	C015	Multi-function input 5 operation selection [Input [5] actv. State]	00			
	C016	Multi-function input 6 operation selection [Input [6] actv. State]	00			
	C017	Multi-function input 7 operation selection [Input [7] actv. State]	00			
	C018	Multi-function input 8 operation selection [Input [8] actv. State]	00			
	C019	FW terminal operation selection [Input [FW] actv. State]	00			
		00: NO 01: NC				

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Multi-function output terminal	C021	Multi-function output terminal 11 selection [Output [11] function] 00: RUN (signal during RUN) 01: FA1 (constant speed arrival signal) 02: FA2 (over set frequency arrival signal) 03: OL (overload warning) 04: OD (excessive PID deviation) 05: AL (alarm output) 06: FA3 (set-frequency-only arrival signal) 07: OTQ (overtorque) 08: IP (signal during momentary power interruption)	00	No	—	4-95
	C022	Multi-function output terminal 12 selection [Output [12] function] 09: UV (signal during undervoltage) 10: TRQ (torque limit) 11: RNT (RUN time over) 12: ONT (Power ON time over) 13: THM (thermal warning) 19: BRK (brake release) 20: BER (brake error) 21: ZS (0 Hz signal) 22: DSE (excessive speed deviation)	21			
	C023	Multi-function output terminal 13 selection [Output [13] function] 23: POK (position ready) 24: FA4 (set frequency exceeded 2) 25: FA5 (set frequency only 2) 26: OL2 (overload warning 2) 27: ODc (analog O disconnection detection) 28: OIdc (analog OI disconnection detection) 29: O2Dc (analog O2 disconnection detection) 31: FBV (PID FB status output) 32: NDc (network error)	03			
	C024	Multi-function output terminal 14 selection [Output [14] function] 33: LOG1 (logic operation output 1) 34: LOG2 (logic operation output 2) 35: LOG3 (logic operation output 3) 36: LOG4 (logic operation output 4) 37: LOG5 (logic operation output 5) 38: LOG6 (logic operation output 6) 39: WAC (capacitor life warning signal) 40: WAF (cooling fan life warning signal) 41: FR (starting contact signal) 42: OHF (fin overheat warning)	07			
	C025	Multi-function output terminal 15 selection [Output [15] function] 43: LOC (light load detection signal) 44: MO1 (Drive programming output 1) 45: MO2 (Drive programming output 2) 46: MO3 (Drive programming output 3) 47: MO4 (Drive programming output 4) 48: MO5 (Drive programming output 5) 49: MO6 (Drive programming output 6) 50: IRDY (operation ready signal) 51: FWR (forward run signal)	01			
	C026	Relay output (AL2, AL1) function selection [Alarm relay function] 52: RVR (reverse run signal) 53: MJA (fatal fault signal) 54: WCO (window comparator O) 55: WCOI (window comparator OI) 56: WCO2 (window comparator O2) 63: OPO (Option board output) no: Not used (When C062 is used to select the alarm code output, the multi-function output terminals 11 to 13, or 11 to 14 are forcibly changed to AC0 to AC2 or AC0 to AC3 [Acn 'Alarm code output'], respectively.)	05			

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Analog monitor	C027	FM selection [[FM] Function] When inverter is in sensor vector control (A044=05) the real motor speed from the motor encoder (d008 monitor) is used instead of the output frequency. 00: Output FQ (Output frequency) 01: Output I (Output current) 02: Output TRQ (Output torque) 03: Pulse FQ (Digital output frequency) 04: Output V (Output voltage) 05: Power 06: Thermal (Thermal load rate) 07: LAD-FQ (LAD frequency) 08: Pulse I (Digital current monitor) 09: Motor tmp (Motor temperature) 10: Heatsink tmp (Fin temperature) 12: YA0 (Drive programming) 19: OP1 (Option board 1) 20: OP2 (Option board 2)	00	No	—	4-109 4-118
	C028	AM selection [[AM] Function] When inverter is in sensor vector control (A044=05) the real motor speed from the motor encoder (d008 monitor) is used instead of the output frequency. 00: Output FQ (Output frequency) 01: Output I (Output current) 02: Output TRQ (Output torque) 04: Output V (Output voltage) 05: Power 06: Thermal (Thermal load rate) 07: LAD-FQ (LAD frequency) 08: Pulse I (Digital current monitor) 09: Motor tmp (Motor temperature) 10: Heatsink tmp (Fin temperature) 11: Out TRQ sign (Output torque <signed>) 13: YA1 (Drive programming) 19: OP1 (Option board 1) 20: OP2 (Option board 2)	00	No	—	4-110 4-118
	C029	AMI selection [[AMI] Function] When inverter is in sensor vector control (A044=05) the real motor speed from the motor encoder (d008 monitor) is used instead of the output frequency. 00: Output FQ (Output frequency) 01: Output I (Output current) 02: Output TRQ (Output torque) 04: Output V (Output voltage) 05: Power 06: Thermal (Thermal load rate) 07: LAD-FQ (LAD frequency) 09: Motor tmp (Motor temperature) 10: Heatsink tmp (Fin temperature) 14: YA2 (Drive programming)	00	No	—	
	C030	Digital current monitor reference value [Digital I Ref.] 0.20 × Rated current to 2.00 × Rated current (Under 55 kW) 0.20 × Rated current to 1.50 × Rated current (Over 75 kW) (Current value at the digital current monitor output 1440 Hz)	Rated current	Yes	A	4-109

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Multi-function output terminal	C031	Multi-function output terminal 11 contact selection [Output [11] actv. state]	00	No	—	4-96
	C032	Multi-function output terminal 12 contact selection [Output [12] actv. state]				
	C033	Multi-function output terminal 13 contact selection [Output [13] actv. state]				
	C034	Multi-function output terminal 14 contact selection [Output [14] actv. state]				
	C035	Multi-function output terminal 15 contact selection [Output [15] actv. state]				
	C036	Relay output (AL2, AL1) contact selection [Alarm RLY active state]	01			
Level and output terminal status	C038	Light load signal output mode [LOC out mode select]	01	No	—	4-106
	C039	Light load detection level [LOC out level]	Rated current	No	A	
	C040	Overload warning signal output mode [Overload warn mode]	01	No	—	4-49
	C041	Overload warning level [Overload warn level]	Rated current	No	A	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Level and output terminal status							
Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page	
C042	Arrival frequency during acceleration [FQ arrive accel.1]	0.00 to 400.00	0.00	No	Hz	4-98	
C043	Arrival frequency during deceleration [FQ arrive decel.1]	0.00 to 400.00	0.00	No	Hz		
C044	PID deviation excessive level [PID deviation]	0.0 to 100.0	3.0	No	%	4-31	
C045	Arrival frequency during acceleration 2 [FQ arrive accel.2]	0.00 to 400.00	0.00	No	Hz	4-98	
C046	Arrival frequency during deceleration 2 [FQ arrive decel.2]	0.00 to 400.00	0.00	No	Hz		
C052	PID FB upper limit [PID FBV high limit]	0.0 to 100.0	100.0	No	%	4-31	
C053	PID FB lower limit [PID FBV low limit]	0.0 to 100.0	0.0	No	%		
C055	Overtorque level (Forward power running) [OV-TRQ FW/POW]	0 to 200 (0.4 to 55 kW)	200	No	%	4-100	
		0 to 180 (75 to 132 kW)	180				
C056	Overtorque level (Reverse regeneration) [OV-TRQ RV/REG]	0 to 200 (0.4 to 55 kW)	200	No	%		
		0 to 180 (75 to 132 kW)	180				
C057	Overtorque level (Reverse power running) [OV-TRQ RVPOW]	0 to 200 (0.4 to 55 kW)	200	No	%		
		0 to 180 (75 to 132 kW)	180				
C058	Overtorque level (Forward regeneration) [OV-TRQ FW/REG]	0 to 200 (0.4 to 55 kW)	200	No	%		
		0 to 180 (75 to 132 kW)	180				
C061	Thermal warning level [E-Thermal warning]	0 to 100	80	No	%	4-46	
C062	Alarm code selection [Alarm code output]	00: OFF (Disabled) 01: 3-bit 02: 4-bit	00	No	—	4-101	
C063	0 Hz detection level [0Hz detection level]	0.00 to 100.00	0.00	No	Hz	4-101	
C064	Fin overheat warning level [Heatsink warning]	0 to 200	120	No	℃	4-105	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Communication function	C071	Communication speed selection (Baud rate selection) [Comm. baud rate] 02: Loop-back test 03: 2400 bps 04: 4800 bps 05: 9600 bps 06: 19200 bps	05	No	—	4-146
	C072	Communication station No. selection [Modbus address] 1 to 247	1	No	—	
	C073	Communication bit length selection [Comm. Data length] 7: 7-bit 8: 8-bit	8	No	—	
	C074	Communication parity selection [Parity] 00: No parity 01: Even 02: Odd	00	No	—	
	C075	Communication stop bit selection [Stop bit] 1: 1-bit 2: 2-bit	1	No	—	
	C076	Communication error selection [Comm.error mode] 00: Trip 01: Decel-Trip (Trip after deceleration stop) 02: Ignore 03: Free-RUN (Free-run stop) 04: Decel-Stop (Deceleration stop)	02	No	—	4-104 4-146
	C077	Communication error timeout [Comm. Timeout] 0.00 to 99.99	0.00	No	s	
	C078	Communication wait time [Comm.wait time] 0 to 1000	0	No	ms	
	C079	Communication method selection [Comm.mode] 00: ASCII 01: ModBus-RTU	01	No	—	4-146
Adjustment	C081	O adjustment [[O] span calibration] 0 to 65535	Factory default	Yes	—	—
	C082	OI adjustment [[OI] span calibration] 0 to 65535	Factory default	Yes	—	—
	C083	O2 adjustment [[O2] span calibration] 0 to 65535	Factory default	Yes	—	—
	C085	Thermistor adjustment [PTC span calibration] 0.0 to 1000.0	Factory default	Yes	—	4-75
	C091	Debug mode selection [Debug mode select] Use "00". * Do not change.	00	No	—	—

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Others	C101	UP/DWN selection [UP/DWN memory mode] 00: Not save (Do not store the frequency data) 01: Save (Store the frequency data)	00	No	—	4-90
	C102	Reset selection [Reset mode select] 00: ON-RESET (Trip reset at power-on) 01: OFF-RESET (Trip reset when the power is OFF) 02: On in Trip (Enabled only during trip (Reset when the power is ON)) 03: Trip RESET (Trip reset only)	00	Yes	—	4-87 4-137
	C103	Reset frequency matching selection [Restart after reset] 00: 0 Hz start 01: f-match (Frequency matching start) 02: Actv.f-match (Active Frequency Matching restart)	00	No	—	4-87
Meter adjustment	C105	FM gain setting [FM gain adjust] 50 to 200	100	Yes	%	4-110
	C106	AM gain setting [AM gain adjust] 50 to 200	100	Yes	%	4-111
	C107	AMI gain setting [AMI gain adjust] 50 to 200	100	Yes	%	
	C109	AM bias setting [AM bias adjust] 0 to 100	0	Yes	%	
	C110	AMI bias setting [AMI bias adjust] 0 to 100	20	Yes	%	
Terminal	C111	Overload warning level 2 [Overload warn lvl 2] 0.0 to 2.00 × Rated current (0.4 to 55 kW) 0.0 to 1.80 × Rated current (75 to 132 kW)	Rated current	No	A	4-49
Adjustment	C121	O zero adjustment [[O] 0 calibration] 0 to 65535	Factory default	Yes	—	—
	C122	OI zero adjustment [[OI] 0 calibration] 0 to 65535	Factory default	Yes	—	
	C123	O2 zero adjustment [[O2] 0 calibration] 0 to 65535	Factory default	Yes	—	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page	
Output terminal operation function	C130	Output 11 ON delay [Output [11] ON delay]	0.0 to 100.0	0.0	No	s	4-108
	C131	Output 11 OFF delay [Output [11] OFF delay]	0.0 to 100.0	0.0			
	C132	Output 12 ON delay [Output [12] ON delay]	0.0 to 100.0	0.0			
	C133	Output 12 OFF delay [Output [12] OFF delay]	0.0 to 100.0	0.0			
	C134	Output 13 ON delay [Output [13] ON delay]	0.0 to 100.0	0.0			
	C135	Output 13 OFF delay [Output [13] OFF delay]	0.0 to 100.0	0.0			
	C136	Output 14 ON delay [Output [14] ON delay]	0.0 to 100.0	0.0			
	C137	Output 14 OFF delay [Output [14] OFF delay]	0.0 to 100.0	0.0			
	C138	Output 15 ON delay [Output [15] ON delay]	0.0 to 100.0	0.0			
	C139	Output 15 OFF delay [Output [15] OFF delay]	0.0 to 100.0	0.0			
	C140	Relay output ON delay [Alarm-RLY ON delay]	0.0 to 100.0	0.0			
	C141	Relay output OFF delay [Alarm-RLY OFF delay]	0.0 to 100.0	0.0			
C142	Logic output signal 1 selection 1 [Log.out 1 operand A]	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00				
C143	Logic output signal 1 selection 2 [Log.out 2 operand B]	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00				

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
C144	Logic output signal 1 operator selection [Log.out 1 operator]	00: AND 01: OR 02: XOR	00	No	—	4-102
C145	Logic output signal 2 selection 1 [Log.out 2 operand A]	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00			
C146	Logic output signal 2 selection 2 [Log.out 2 operand B]	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00			
C147	Logic output signal 2 operator selection [Log.out 2 operator]	00: AND 01: OR 02: XOR	00			
C148	Logic output signal 3 selection 1 [Log.out 3 operand A]	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00			
C149	Logic output signal 3 selection 2 [Log.out 3 operand B]	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00			
C150	Logic output signal 3 operator selection [Log.out 3 operator]	00: AND 01: OR 02: XOR	00			
C151	Logic output signal 4 selection 1 [Log.out 4 operand A]	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00	No	—	4-102
C152	Logic output signal 4 selection 2 [Log.out 4 operand B]	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00			
C153	Logic output signal 4 operator selection [Log.out 4 operator]	00: AND 01: OR 02: XOR	00			
C154	Logic output signal 5 selection 1 [Log.out 5 operand A]	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00			
C155	Logic output signal 5 selection 2 [Log.out 5 operand B]	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00			
C156	Logic output signal 5 operator selection [Log.out 5 operator]	00: AND 01: OR 02: XOR	00			
C157	Logic output signal 6 selection 1 [Log.out 6 operand A]	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00			
C158	Logic output signal 6 selection 2 [Log.out 6 operand B]	Same as options for C021 to C026 (excluding LOG1 to LOG6)	00			
C159	Logic output signal 6 operator selection [Log.out 6 operator]	00: AND 01: OR 02: XOR	00			

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Input terminal response	C160	Input terminal response time 1 [Input [1] resp.time]	1	No	ms	4-108
	C161	Input terminal response time 2 [Input [2] resp.time]	1			
	C162	Input terminal response time 3 [Input [3] resp.time]	1			
	C163	Input terminal response time 4 [Input [4] resp.time]	1			
	C164	Input terminal response time 5 [Input [5] resp.time]	1			
	C165	Input terminal response time 6 [Input [6] resp.time]	1			
	C166	Input terminal response time 7 [Input [7] resp.time]	1			
	C167	Input terminal response time 8 [Input [8] resp.time]	1			
	C168	FW terminal response time [Input [FW] resp.time]	1			
Others	C169	Multi-step speed/position determination time [Multi-spdpd determ.time]	0	No	ms	4-16 4-137

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Control parameter	H001	Auto-tuning selection [Auto-tuning select]	00: OFF (Disabled) 01: ON (STOP) 02: ON (Rotation)	00	No	—	4-111
	H002	Motor parameter selection [Motor data select]	00: Standard motor parameter 01: Auto-tuning parameter 02: Auto-tuning parameter (online auto-tuning enabled)	00	No	—	4-111 4-113 4-115
	H202	* 2nd motor parameter selection [Motor data select-M2]		00			
	H003	Motor capacity selection [Motor capacity]	0.20 to 160.0	Factory default	No	kW	4-19 4-111 4-115 4-118
	H203	* 2nd motor capacity selection [Motor capacity-M2]		Factory default			
	H004	Motor pole number selection [Motor poles]	2/4/6/8/10	4	No	Pole	
	H204	* 2nd motor pole number selection [Motor poles-M2]		4			
	H005	Speed response [M.speed const]	0.001 to 80.000	1.590	Yes	—	4-89 4-92
	H205	* 2nd speed response [M.speed const-M2]		1.590			
	H006	Stabilization parameter [M.stabil.const]	0 to 255	100	Yes	—	4-120
	H206	* 2nd stabilization parameter [M.stabil.const-M2]		100			
	H306	* 3rd stabilization parameter [M.stabil.const-M3]		100			

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page	
Control parameter	H020	Motor parameter R1 [M.const R1]	0.001 to 65.535	Depends on the motor capacity.	No	Ω	4-115
	H220	* 2nd motor parameter R1 [M.const R1-M2]		Depends on the motor capacity.			
	H021	Motor parameter R2 [M.const R2]	0.001 to 65.535	Depends on the motor capacity.	No	Ω	
	H221	* 2nd motor parameter R2 [M.const R2-M2]		Depends on the motor capacity.			
	H022	Motor parameter L [M.const L]	0.01 to 655.35	Depends on the motor capacity.	No	mH	
	H222	* 2nd motor parameter L [M.const L-M2]		Depends on the motor capacity.			
	H023	Motor parameter IO [M.const IO]	0.01 to 655.35	Depends on the motor capacity.	No	A	4-115
	H223	* 2nd motor parameter IO [M.const IO-M2]		Depends on the motor capacity.			
	H024	Motor parameter J [M.const J]	0.001 to 9999.000	Depends on the motor capacity.	No	kgm ²	
	H224	* 2nd motor parameter J [M.const J-M2]		Depends on the motor capacity.			

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Control parameter	H030	Motor parameter R1 (auto-tuning data) [M.const R1 (A.Tune)]	0.001 to 65.535	Depends on the motor capacity.	No	Ω	4-111 4-115
	H230	* 2nd motor parameter R1 (auto-tuning data) [M.const R1-M2 (A.Tune)]		Depends on the motor capacity.			
	H031	Motor parameter R2 (auto-tuning data) [M.const R2 (A.Tune)]	0.001 to 65.535	Depends on the motor capacity.	No	Ω	
	H231	* 2nd motor parameter R2 (auto-tuning data) [M.const R2-M2 (A.Tune)]		Depends on the motor capacity.			
	H032	Motor parameter L (auto-tuning data) [M.const L (A.Tune)]	0.01 to 655.35	Depends on the motor capacity.	No	mH	
	H232	* 2nd motor parameter L (auto-tuning data) [M.const L-M2 (A.Tune)]		Depends on the motor capacity.			
	H033	Motor parameter Io (auto-tuning data) [M.const IO (A.Tune)]	0.01 to 655.35	Depends on the motor capacity.	No	A	
	H233	* 2nd motor parameter Io (auto-tuning data) [M.const IO-M2 (A.Tune)]		Depends on the motor capacity.			
H034	Motor parameter J (auto-tuning data) [M.const J (A.Tune)]	0.001 to 9999.000	Depends on the motor capacity.	No	kgm ²		
H234	* 2nd motor parameter J (auto-tuning data) [M.const J-M2 (A.Tune)]		Depends on the motor capacity.				

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Control parameter	H050	PI proportional gain [PI P gain]	0.0 to 1000.0	100.0	Yes	—	4-89 4-92
	H250	* 2nd PI proportional gain [PI P gain-M2]		100.0			
	H051	PI integral gain [PI I gain]	0.0 to 1000.0	100.0	Yes	—	
	H251	*2nd PI integral gain [PI I gain-M2]		100.0			
	H052	P proportional gain [P gain]	0.01 to 10.00	1.00	Yes	—	
	H252	*2nd P proportional gain [P gain-M2]		1.00			
	H060	Limit at 0 Hz [0Hz Speed limit]	0.0 to 100.0	100.0	Yes	%	4-117
	H260	* 2nd limit at 0 Hz [0Hz Speed limit-M2]		100.0			
	H061	Boost amount at SLV startup, 0 Hz [Bst HiTQ start SLV]	0 to 50	50	Yes	%	
	H261	* 2nd boost amount at SLV startup, 0 Hz [Bst HiTQ start SLV-M2]		50			
	H070	For PI proportional gain switching [PI P gain term.]	0.0 to 1000.0	100.0	Yes	—	4-89
	H071	For PI integral gain switching [PI I gain term.]	0.0 to 1000.0	100.0	Yes	—	
	H072	For P proportional gain switching [P gain term.]	0.00 to 10.00	1.00	Yes	—	
	H073	Gain switching time [Gain switching time]	0 to 9999	100	Yes	ms	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Options	P001	Operation selection at option 1 error [Error mode OP1 card] 00: Trip 01: RUN (Continues operation)	00	No	—	4-111
	P002	Operation selection at option 2 error [Error mode OP2 card] 00: Trip 01: RUN (Continues operation)	00	No	—	
	P011	Encoder pulses [FB Encoder PPR] 128 to 65535	1024	No	Pulse	4-124 4-133 4-134
	P012	V2 control mode selection [Control pulse setting] 00: ASR (speed control mode) 01: APR (pulse train position control mode) 02: APR2 (absolute position control mode) 03: HAPR (High resolution absolute position control mode)	00	No	—	4-124 4-136
	P013	Pulse train mode selection [Pulse train mode] 00: Mode 1 01: Mode 2 02: Mode 3	00	No	—	4-127
	P014	Orientation stop position [Home search stop] 0 to 4095	0	No	—	4-134
	P015	Orientation speed setting [Home search speed] Starting frequency to Max. frequency (upper limit: 120.0)	5.00	No	Hz	
	P016	Orientation direction setting [Home search direction] 00: FWD (Forward side) 01: REV (Reverse side)	00	No	—	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.		Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Options	P017	Position ready range setting [Home search range]	0 to 10000	5	No	Pulse	4-127 4-134
	P018	Position ready delay time setting [Home search delay]	0.00 to 9.99	0.00	No	s	4-127 4-134
	P019	Electronic gear setting position selection [E.gear position]	00: FB (Position feedback side) 01: REF (Position command side)	00	Yes	—	4-128 4-129
	P020	Electronic gear ratio numerator [E.gear ratio-Num.]	1 to 9999	1	Yes	—	
	P021	Electronic gear ratio denominator [E.gear ratio-Den.]	1 to 9999	1	Yes	—	
	P022	Position control feedforward gain [Feed-FW gain]	0.00 to 655.35	0.00	Yes	—	
	P023	Position loop gain [Position loop gain]	0.00 to 100.00	0.50	Yes	rad/s	4-124 4-128 4-129 4-134 4-136
	P024	Position bias amount [Position bias]	-2048 to 2048	0	Yes	rad/s	4-128
	P025	Secondary resistance compensation enable/disable selection [Temp.comp. Therm]	00: OFF (Disabled) 01: ON (Enabled)	00	No	—	4-114
	P026	Overspeed error detection level [OverSpeed err level]	0.0 to 150.0	135.0	No	%	5-7
	P027	Speed deviation error detection level [SpeedDev. Err level]	0.00 to 120.00	7.50	No	Hz	4-124
	P028	Motor gear ratio numerator [M.gear ratio-num]	1 to 9999	1	No	—	4-133
	P029	Motor gear ratio denominator [M.gear ratio-den]	1 to 9999	1	No	—	
	P031	Acceleration/ deceleration time input type [Acc/Dec time source]	00: OPE (Digital Operator) 01: Option 1 02: Option 2 03: EzSQ (Drive Programming)	00	No	—	4-8
	P032	Orientation stop position input type [Positioning cmd src.]	00: OPE (Digital Operator) 01: Option 1 02: Option 2	00	No	—	—

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
P033	Torque reference input selection [TRQ cmd source]	00: O (Terminal O) 01: OI (Terminal OI) 02: O2 (Terminal O2) 03: OPE (Digital Operator) 06: Option 1 07: Option 2	00	No	—	4-126
P034	Torque reference setting [TRQ cmd setting]	0 to 200 (0.4 to 55 kW) 0 to 180 (75 to 132 kW)	0	Yes	%	
P035	Polarity selection at torque reference via O2 [O2 TRQ polarity]	00: Sign (Signed) 01: Direction (Depends on the RUN direction)	00	No	—	
P036	Torque bias mode [TRQ bias mode]	00: OFF (None) 01: OPE (Digital Operator) 02: O2 (Terminal O2) 05: Option 1 06: Option 2	00	No	—	4-126 4-127
P037	Torque bias value [TRQ bias value]	-200 to 200 (0.4 to 55 kW) -180 to 180 (75 to 132 kW)	0	Yes	%	
P038	Torque bias polarity selection [TRQ bias polarity]	00: Sign (Signed) 01: Direction (Depends on the RUN direction)	00	No	—	
P039	Speed limit value in torque control (forward) [TRQ SpeedLmt (FW)]	0.00 to Maximum frequency	0.00	Yes	Hz	4-126
P040	Speed limit value in torque control (reverse) [TRQ SpeedLmt (RV)]	0.00 to Maximum frequency	0.00	Yes	Hz	
P044	DeviceNet comm Watch dog timer [DeviceNet comm WDT]	0.00 to 99.99	1.00	No	s	—
P045	Operation setting at communications error [Act. Network com loss]	00: Trip 01: Decel-Trip (Trip after deceleration stop) 02: Ignore 03: Free RUN 04: Decel-Stop (Deceleration stop)	00	No	—	—
P046	Instance Number [Instance No.]	0: Basic speed I/O 1: Extended speed I/O 2: Extended speed and Torque control 3: Special I/O 4: Extended control I/O 5: Extended control I/O and multifunction I/O monitor 6: Flexible format 7: Extended speed and Acceleration control 8-20: Not used	1	No	—	—

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
Options	P048	Operation setting at idle mode detection [Act. Network idle] 00: Trip 01: Decel-Trip (Trip after deceleration stop) 02: Ignore 03: Free RUN 04: Decel-Stop (Deceleration stop)	00	No	—	—
	P049	Polarity setting for rotation speed [Poles of RPM] 0/2/4/6/8/10/12/14/16/18/20/22/24/26/28/30/32/34/36/38	0	No	—	—
	P055	Pulse train frequency scale [Pulse FQ scale] 1.0 to 50.0	25.0	No	kHz	4-144
	P056	Pulse train frequency filter time constant [Pulse FQ filter] 0.01 to 2.00	0.10	No	s	
	P057	Pulse train frequency bias amount [Pulse FQ bias] -100 to 100	0	No	%	
	P058	Pulse train frequency limit [Pulse FQ limit] 0 to 100	100	No	%	
Absolute position control	P060	Multi-step position command 0 [Position set 0] Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	0	Yes	—	4-136
	P061	Multi-step position command 1 [Position set 1] Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	0			
	P062	Multi-step position command 2 [Position set 2] Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	0			
	P063	Multi-step position command 3 [Position set 3] Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	0			
	P064	Multi-step position command 4 [Position set 4] Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	0			
	P065	Multi-step position command 5 [Position set 5] Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	0			
	P066	Multi-step position command 6 [Position set 6] Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	0			
	P067	Multi-step position command 7 [Position set 7] Position range specification (reverse side) to Position range specification (forward side) -268435455 to 268435455	0			
	P068	Zero return mode [Homing mode select] 00: Low speed 01: High speed 1 02: High speed 2	00	Yes	—	
	P069	Zero return direction selection [Homing direction] 00: FWD (Forward side) 01: REV (Reverse side)	00	Yes	—	

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-1 Parameter List


Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
P070	Low-speed zero return frequency [LowSpeed homing FQ]	0.00 to 10.00	0.00	Yes	Hz	4-136
P071	High-speed zero return frequency [HiSpeed homing FQ]	0.00 to Maximum frequency	0.00	Yes	Hz	
P072	Position range specification (forward) [Position range FWD]	0 to 268435455 (at P012 = 02) 0 to 1073741823 (at P012 = 03)	268435455	Yes	—	
P073	Position range specification (reverse) [Position range REV]	-268435455 to 0 (at P012 = 02) -1073741823 to 0 (at P012 = 03)	-268435455	Yes	—	4-137
P074	Teaching selection [Teaching select]	00: X00 (Multi-step position command 0 (P060)) 01: X01 (Multi-step position command 1 (P061)) 02: X02 (Multi-step position command 2 (P062)) 03: X03 (Multi-step position command 3 (P063)) 04: X04 (Multi-step position command 4 (P064)) 05: X05 (Multi-step position command 5 (P065)) 06: X06 (Multi-step position command 6 (P066)) 07: X07 (Multi-step position command 7 (P067))	00	Yes	—	
P100 to P131	Drive Program parameter U(00) to U(31) [EzSQ parameter U(00)] to [EzSQ parameter U(31)]	0 to 65535	0	Yes	—	—
P160 to P169	Option I/F cmd W register 1 to 10 [Op I/F cmd W reg.1] to [Op I/F cmd W reg.10]	0000 to FFFF	0000	Yes	—	—
P170 to P179	Option I/F cmd R register 1 to 10 [Op I/F cmd R reg.1] to [Op I/F cmd R reg.10]	0000 to FFFF	0000	Yes	—	—
P180	Profibus node address [Profibus Node adrs]	0 to 125	0	No	—	—
P181	Profibus clear mode [Profibus CLR mode]	00: Clear 01: Last value	00	No	—	—

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Parameter No.	Function name	Monitor or data range	Default setting	Changes during operation	Unit	Page
P182	Profibus Map selection [Profibus Map selection]	00: PPO 01: Conventional 02: Flexible Mode	00	No	—	—
P185	CANOpen Node address [CANOpen Node adrs]	0 to 127	0	No	—	—
P186	CANOpen communication speed [CANOpen com speed]	00: Auto 01: 10Kbps 02: 20Kbps 03: 50Kbps 04: 125Kbps 05: 250Kbps 06: 500Kbps 07: 800Kbps 08: 1Mbps	06	No	—	—
P190	CompoNet node address [CompoNet Node address]	0 to 63	0	No	—	—
P192	DeviceNet node address [DeviceNet MAC ID]	0 to 63	63	No	—	—
P195	ML2 frame length [ML2 frame length]	00: 32 bytes 01: 17 bytes	00	No	—	—
P196	ML2 node address [ML2 node address]	21 to 3E	21	No	—	—
User parameter	U001	User 1 selection	no/d001 to P196	Yes	—	4-53
	U002	User 2 selection	no/d001 to P196			
	U003	User 3 selection	no/d001 to P196			
	U004	User 4 selection	no/d001 to P196			
	U005	User 5 selection	no/d001 to P196			
	U006	User 6 selection	no/d001 to P196			
	U007	User 7 selection	no/d001 to P196			
	U008	User 8 selection	no/d001 to P196			
	U009	User 9 selection	no/d001 to P196			
	U010	User 10 selection	no/d001 to P196			
	U011	User 11 selection	no/d001 to P196			
	U012	User 12 selection	no/d001 to P196			

* 2nd/3rd control is displayed when "SET(08)/SET3(17)" is allocated to one of multi-function inputs from C001 to C008.

Appendix-2 Product Life Curve



- Note 1: Ambient temperature refers to the temperature measured at the location approximately 5 cm from the bottom center of the Inverter. (atmospheric temperature)
It refers to the temperature inside if the Inverter is stored in an enclosure.
- Note 2: The smoothing capacitor, which will deteriorate because of the chemical reaction caused by the temperatures of the parts, should normally be replaced once every 10 years (which is the expected design life, and not guaranteed).
However, if the ambient temperature is high, or the Inverter is used with a current exceeding the rated current, for example, under overload conditions, its life will be significantly shortened.

Appendix-3 Life Alarm Output

- When the product life becomes close to the end for the parts including the on-board smoothing capacitor or cooling fan, but excluding the main circuit smoothing capacitor, an alarm can be output through the self-diagnostic function. Use it as a reference of the parts replacement period. For details, refer to "Life Assessment Monitor [d022]" (page 4-5), "Multi-function Pulse Counter (PCNT, PCC)" (page 4-94), or "Multi-function Output Terminal Contact Selection" (page 4-96). This alarm is output through the self-diagnosis based on the expected design life (not a guaranteed value). Therefore, it has a margin of error depending on your environment or operation conditions.

Appendix-4 EC Declaration of Conformity

No. EMEC035C (1/3)

OMRON

EC Declaration of Conformity

We hereby declare that the following products are in conformity with the requirements of the following EC Directive:

Product: Inverter
Type: 3G3RX series (Refer to appending types list)
Title and No. of Directive: EMC Directive 2004/108/EC
Low Voltage Directive 2006/95/EC

These products are designed and manufactured in accordance with the following standards.
EMI (Electromagnetic Interference): EN61800-3:2004

Test methods:

Conducted/Radiated: EN61800-3:2004

EMS (Electromagnetic Susceptibility): EN61800-3:2004

Test methods:

ESD: EN61800-3:2004/IEC61000-4-2:2001

RF EM Field: EN61800-3:2004/IEC61000-4-3:2002

Conducted RF common mode: EN61800-3:2004/IEC61000-4-6:2004

Fast Transient: EN61800-3:2004/IEC61000-4-4:2004

Surge Power ports: EN61800-3:2004/IEC61000-4-5:2001

Voltage Dips and short Interruptions: EN61800-3:2004/IEC61000-2-1:1990

The examination was performed by Category C3.

LVD (Low Voltage Directive): EN61800-5-1:2003

The year in which the CE marking was affixed : 2007

Manufacturer:

Name: OMRON Corporation, Industrial Automation Company,
Control Device Division H.Q.
Address: 2-2-1, Nishikusatsu, Kusatsu-city Shiga-pref., 525-0035 Japan
Date: Nov 27th 08

Signed:

E. Ikeno
General Manager

Representative in EU:

Name: OMRON Europe B.V.
Address: Zilverenberg 2, 5234 GM, 's-Hertogenbosch,
THE NETHERLANDS
Date: 3.12.2008
Signed:

H. Sintnicolaas
European Manufacturing Manager

No. EMEC035C (2/3)

OMRON

<i>Model Type</i>	<i>Rated Input</i>	<i>Capacity</i>	<i>Remarks</i>	<i>Rev.</i>
3G3RX-A2055	3-phase AC200-240V 50/60Hz	5.5kW	Standard	<A>
3G3RX-A2075	3-phase AC200-240V 50/60Hz	7.5kW	Standard	<A>
3G3RX-A2110	3-phase AC200-240V 50/60Hz	11.0kW	Standard	<A>
3G3RX-A2150	3-phase AC200-240V 50/60Hz	15.0kW	Standard	<A>
3G3RX-A2185	3-phase AC200-240V 50/60Hz	18.5kW	Standard	<A>
3G3RX-A2220	3-phase AC200-240V 50/60Hz	22.0kW	Standard	<A>
3G3RX-A2300	3-phase AC200-240V 50/60Hz	30.0kW	Standard	<A>
3G3RX-A2370	3-phase AC200-240V 50/60Hz	37.0kW	Standard	<A>
3G3RX-A2450	3-phase AC200-240V 50/60Hz	45.0kW	Standard	<A>
3G3RX-A2550	3-phase AC200-240V 50/60Hz	55.0kW	Standard	<A>
3G3RX-A4055	3-phase AC380-480V 50/60Hz	5.5kW	Standard	<A>
3G3RX-A4075	3-phase AC380-480V 50/60Hz	7.5kW	Standard	<A>
3G3RX-A4110	3-phase AC380-480V 50/60Hz	11.0kW	Standard	<A>
3G3RX-A4150	3-phase AC380-480V 50/60Hz	15.0kW	Standard	<A>
3G3RX-A4185	3-phase AC380-480V 50/60Hz	18.5kW	Standard	<A>
3G3RX-A4220	3-phase AC380-480V 50/60Hz	22.0kW	Standard	<A>
3G3RX-A4300	3-phase AC380-480V 50/60Hz	30.0kW	Standard	<A>
3G3RX-A4370	3-phase AC380-480V 50/60Hz	37.0kW	Standard	<A>
3G3RX-A4450	3-phase AC380-480V 50/60Hz	45.0kW	Standard	<A>
3G3RX-A4550	3-phase AC380-480V 50/60Hz	55.0kW	Standard	<A>
3G3RX-A2004	3-phase AC200-240V 50/60Hz	0.4kW	Standard	
3G3RX-A2007	3-phase AC200-240V 50/60Hz	0.75kW	Standard	
3G3RX-A2015	3-phase AC200-240V 50/60Hz	1.5kW	Standard	
3G3RX-A2022	3-phase AC200-240V 50/60Hz	2.2kW	Standard	
3G3RX-A2037	3-phase AC200-240V 50/60Hz	3.7kW	Standard	
3G3RX-A4004	3-phase AC380-480V 50/60Hz	0.4kW	Standard	
3G3RX-A4007	3-phase AC380-480V 50/60Hz	0.75kW	Standard	
3G3RX-A4015	3-phase AC380-480V 50/60Hz	1.5kW	Standard	
3G3RX-A4022	3-phase AC380-480V 50/60Hz	2.2kW	Standard	
3G3RX-A4037	3-phase AC380-480V 50/60Hz	3.7kW	Standard	
3G3RX-A4750	3-phase AC380-480V 50/60Hz	75kW	Standard	<C>
3G3RX-A4900	3-phase AC380-480V 50/60Hz	90kW	Standard	<C>
3G3RX-A411K	3-phase AC380-480V 50/60Hz	110kW	Standard	<C>
3G3RX-A413K	3-phase AC380-480V 50/60Hz	132kW	Standard	<C>

Index

Index

Numerics

0-Hz sensorless vector control	4-117
2-step acceleration/deceleration.....	4-37
3-wire input function	4-88

A

acceleration stop	4-30
acceleration time 2	4-37
acceleration/deceleration pattern	4-38
acceleration/deceleration time.....	4-8
ADD	4-41
AHD	4-93
AL	4-95
alarm code output.....	4-101
allowable momentary power interruption time	4-42
AM	2-7, 4-110
AMI	2-7, 4-110
analog command hold function.....	4-93
automatic energy-saving operation function.....	4-36
automatic optimum acceleration/deceleration	4-36
automatic torque boost	4-20

B

base frequency	4-11
basic display	4-56
BER	4-76
binary operation.....	4-17
bit operation.....	4-18
BOK.....	4-76
brake control.....	4-76
BRK	4-76

C

capacitor life warning.....	4-103
carrier frequency.....	4-68
CAS	4-89
commercial switching	4-85
communication function.....	4-145
constant torque characteristics (VC)	4-21
control circuit terminal.....	2-6
control gain switching	4-89
control method.....	4-21
cooling fan control	4-74
cooling fan speed drop signal.....	4-104
current position monitor.....	4-6

D

data comparison display.....	4-53, 4-55
DC injection braking	4-24
DC voltage monitor.....	4-7
deceleration time 2	4-37
derating.....	4-68
digital operator.....	2-22, 3-3
display selection	3-18, 4-53
DWN	4-90

E

electronic gear	4-129
electronic thermal monitor	4-7
EMC.....	2-14, 2-15, 2-16
emergency shutoff	2-8, 2-9
end frequency.....	4-14
end ratio.....	4-14
excess speed.....	5-7
EXT.....	4-84
extended function mode	3-20
external analog input	4-12
external DC injection braking.....	4-25
external thermistor.....	4-75
external trip (EXT)	4-84

F

F/R.....	4-88
fatal fault signal.....	4-107
fault monitor.....	4-7
FBV.....	4-34
FC.....	2-20
FE	2-6, 2-20
feedback	4-32
feedback option	4-123
FI	2-20
fin overheat warning	4-105
fin temperature monitor	4-4
FOC.....	4-119
forced operator	4-91
forced terminal.....	4-93
forward run signal	4-107
FR.....	4-105
free-run stop	4-71
free-run stop selection and stop selection	4-70
frequency addition function.....	4-41
frequency arrival signal.....	4-98
frequency conversion coefficient	4-2
frequency jump	4-30
frequency limit	4-28
lower limit.....	4-28
upper limit	4-28

frequency matching	4-71
frequency pull-in restart	4-43, 4-45
frequency reference selection	4-10
FRS	4-71
F-TM	4-93
function mode	4-8
FV	2-20
FW	2-8
FWR	4-107

H

high-torque multi-operation	4-119
-----------------------------------	-------

I

initial screen	4-56
initialization	4-70
input power monitor	4-4
internal DC injection braking	4-26, 4-28
IP	4-44, 4-45

J

JG	4-18
jogging operation	4-18

K

KHC	4-4
-----------	-----

L

LAC	4-9, 4-40
LAD	4-9, 4-80
life assessment monitor	4-5, 4-103
light load detection signal	4-106
LOC	4-106
LOG1 to LOG6	4-102

M

main circuit terminal	2-6, 2-14
manual torque boost	4-20
maximum frequency	4-12
MJA	4-107
momentary power interruption non-stop	4-60
momentary power interruption/undervoltage trip during stop selection	4-42, 4-44
MP	4-109
multi-function input monitor	4-2
multi-function input terminal selection	4-79
multi-function output monitor	4-2
multi-function output terminal	4-95

N

NDc	4-104
no	4-79

O

OD	4-34
offline auto-tuning	4-111
OHF	4-105
OL, OL2	4-50
OLR	4-49
online auto-tuning	4-113
ONT	4-52
OPE	4-91
operation frequency function	4-41
operation method	3-3
operation ready signal	4-106
operation selection during option error	4-111
orientation function	4-134
OTQ	4-100
output current monitor	4-1
output frequency monitor	4-1, 4-2
output frequency setting/monitor	4-8
output signal delay/hold	4-108
output signal logic operation	4-102
output torque monitor	4-3
output voltage gain	4-24
output voltage monitor	4-3
overcurrent suppression	4-51
overload limit	4-49
overload warning	4-49
overtorque	4-100
overvoltage protection function during deceleration	4-78

P

P/PI switching	4-92
P24	2-7
phase loss protection	4-46
PID	4-31
PID feedback value monitor	4-1
PIDC	4-35
power ON time	4-4
power recovery restart prevention	4-84
PPI	4-92
preliminary excitation	4-119
pulse train frequency input	4-144

Index

R

real frequency monitor.....	4-3
reduced voltage startup.....	4-53
relay output terminals.....	4-97
reset.....	4-87
retry selection.....	4-42
reverse rotation prevention.....	4-59
reverse run signal.....	4-107
RNT.....	4-52
rotation direction limit selection.....	4-52
rotation direction selection.....	4-9
RS.....	2-9
RUN.....	4-98
RUN command selection.....	4-11
RUN direction monitor.....	4-1
RUN direction selection.....	4-9
RV.....	2-11, 4-79
RVR.....	4-107

S

SC.....	2-20
secondary resistance compensation.....	4-114
sensor vector control.....	4-125
sensorless vector control.....	4-116
servo ON.....	4-143
SF1 to SF7.....	4-18
signal during RUN.....	4-98
sink logic.....	2-21
slide switch.....	2-10
soft lock.....	4-51
SON.....	4-143
source logic.....	2-21
special reduced torque characteristics.....	4-22
STA.....	4-88
stabilization parameter.....	4-120
start frequency.....	4-14
start ratio.....	4-14
start selection.....	4-14
starting contact signal.....	4-105
starting frequency.....	4-68
stop key selection.....	4-70
stop selection.....	4-70, 4-71
STP.....	4-88
synchronous operation.....	4-130

T

test run.....	3-4
thermistor.....	4-75
THM.....	4-48
TL.....	4-58
torque bias monitor.....	4-3
torque boost.....	4-19
torque LADSTOP function.....	4-59
torque limit.....	4-57
torque reference monitor.....	4-3
total RUN time.....	4-4
trip monitor display.....	5-9
trip retry.....	4-42
TRQ.....	4-95
TRQ1, TRQ2.....	4-58

U

UDC.....	4-90
UP.....	4-90
UP/DOWN function.....	4-90
user parameter.....	4-57
user selection.....	4-53
USP.....	4-84
UV.....	4-45, 4-95

V

V2.....	4-124
---------	-------

W

WAF.....	4-104
wiring control circuit terminals.....	2-20
wiring the main circuit terminals.....	2-11

Z

ZS.....	4-101
---------	-------

OMRON EUROPE B.V. Wegalaan 67-69, NL-2132 JD, Hoofddorp, The Netherlands.
Tel: +31 (0) 23 568 13 00 Fax: +31 (0) 23 568 13 88 industrial.omron.eu

Austria

Tel: +43 (0) 2236 377 800
industrial.omron.at

Belgium

Tel: +32 (0) 2 466 24 80
industrial.omron.be

Czech Republic

Tel: +420 234 602 602
industrial.omron.cz

Denmark

Tel: +45 43 44 00 11
industrial.omron.dk

Finland

Tel: +358 (0) 207 464 200
industrial.omron.fi

France

Tel: +33 (0) 1 56 63 70 00
industrial.omron.fr

Germany

Tel: +49 (0) 2173 6800 0
industrial.omron.de

Hungary

Tel: +36 (0) 1 399 30 50
industrial.omron.hu

Italy

Tel: +39 02 32 681
industrial.omron.it

South Africa

Tel: +27 (0) 11 579 2600
industrial.omron.eu

Netherlands

Tel: +31 (0) 23 568 11 00
industrial.omron.nl

Norway

Tel: +47 (0) 22 65 75 00
industrial.omron.no

Poland

Tel: +48 22 458 66 66
industrial.omron.pl

Portugal

Tel: +351 21 942 94 00
industrial.omron.pt

Russia

Tel: +7 495 648 94 50
industrial.omron.ru

Spain

Tel: +34 902 100 221
industrial.omron.es

Sweden

Tel: +46 (0) 8 632 35 00
industrial.omron.se

Switzerland

Tel: +41 (0) 41 748 13 13
industrial.omron.ch

Turkey

Tel: +90 212 467 30 00
industrial.omron.com.tr

United Kingdom

Tel: +44 (0) 870 752 08 61
industrial.omron.co.uk

Note: Specifications subject to change without notice.
Cat. No. I560-E2-05A

OMRON