

Washdown Delta Robot R6Y3 Series

Delta Robot IP67 Mini Delta Robot IP67

MAINTENANCE MANUAL

OMRON

Safety Instructions

1. Safety Information	S-1
2. Signal words used in this manual	S-2
3. Warning labels	S-3
3.1 Warning labels	S-3
3.1.1 Contents of warning label messages	S-3
3.1.2 Supplied warning label	S-4
3.2 Warning symbols	S-4
4. Major precautions for each stage of use	S-5
4.1 Precautions for using robots	S-5
4.2 Design	S-5
4.3 Moving and installation	S-6
4.4 Safety measures	S-8
4.4.1 Safety measures	S-8
4.4.2 Installing a safety enclosure	S-9
4.5 Operation	S-10
4.5.1 Trial operation	S-10
4.5.2 Automatic operation	S-10
4.5.3 Precautions during operation	S-10
4.6 Inspection and maintenance	S-11
4.6.1 Before inspection and maintenance work	S-11
4.6.2 Precautions during service work	S-12
4.7 Disposal	S-12
5. Emergency action when a person is caught by robot	S-13
6. Using the robot safely	S-14
6.1 Robot protective functions	S-14
6.2 Residual risk	S-14
6.3 Special training for industrial robot operation	S-14

Warranty

Chapter 1 Overview

1. Overview	1-1
-------------	-----

Chapter 2 Attaching, detaching and replacing the cover

1. Detaching or attaching the α , β and γ -axes covers	2-1
1.1 R6Y3[]110	2-1
1.1.1 α , β and γ -axes cover removal procedure	2-2
1.1.2 α , β and γ -axes cover attachment procedure	2-7
1.2 R6Y3[]065	2-13
1.2.1 α , β and γ -axes cover removal procedure	2-14
1.2.2 α , β and γ -axes cover attachment procedure	2-17
2. Detaching or attaching the θ -axis cover	2-22
2.1 θ -axis motor cover removal	2-23
2.2 θ -axis motor cover attachment	2-25

Chapter 3 Periodic inspection

1. Overview	3-1
2. Daily inspection	3-2
3. Monthly inspection	3-3
4. Six-month inspection	3-4

Chapter 4 Adjusting the origin

1. Adjusting the origin	4-1
1.1 Adjusting the α , β and γ -axes origin position	4-2
1.1.1 R6Y3[]110	4-2
1.1.2 R6Y3[]065	4-5
1.2 Adjusting the θ -axis origin position (4-axes specification only)	4-8

Chapter 5 Shaft, movable base and spring cover replacement

1. Shaft, movable base and spring cover replacement procedure	5-1
1.1 Detaching the shafts, movable base and spring cover	5-3
1.2 Attaching the shafts, movable base and spring covers	5-5
1.2.1 R6Y30110S03067NJ5, R6Y30065S02067NJ5 (3-axes specification)	5-5
1.2.2 R6Y31110L03067NJ5, R6Y31110H03067NJ5, R6Y31065L02067NJ5, R6Y31065H02067NJ5 (4-axes specification)	5-7
1.2.3 Attaching the spring cover (Reinforced Spring Cover common to 3-axes and 4-axes)	5-10
2. Movable base link ball replacement	5-12

Chapter 6 Spring mechanism replacement

1. Spring mechanism replacement procedure	6-1
1.1 Spring mechanism removal	6-2
1.2 Spring mechanism attachment	6-3

Chapter 7 Plastic bearing replacement

1. Plastic bearing replacement procedure	7-1
1.1 Removing the plastic bearing from the link ball sliding part	7-1
1.2 Attaching the plastic bearing to the link ball sliding part	7-2
1.3 Spring mechanism plate plastic bearing removal	7-3
1.4 Spring mechanism plate plastic bearing attachment	7-3
2. Plastic bearing inspection	7-4

Chapter 8 θ -axis seal, O-ring replacement

1. θ-axis seal, O-ring replacement procedure	8-1
1.1 θ -axis seal, O-ring removal	8-1
1.2 θ -axis seal, O-ring attachment	8-3

Chapter 9 Motor replacement

1. α, β and γ-axes motor replacement	9-1
1.1 R6Y3[]110	9-1
1.1.1 α , β and γ -axes motor removal	9-1
1.1.2 α , β and γ -axes motor attachment	9-4
1.2 R6Y3[]065	9-5
1.2.1 α , β and γ -axes motor removal	9-5
1.2.2 α , β and γ -axes motor attachment	9-8
2. θ-axis motor replacement	9-9
2.1 θ -axis motor removal	9-9

Chapter 10 Speed reduction gear, arm replacement

1. Speed reduction gear replacement precautions	10-1
2. Speed reduction gear and arm replacement procedure	10-2
2.1 R6Y3[]110	10-2
2.1.1 α , β and γ -axes arm replacement	10-2
2.1.1.1 Work required after replacing arm link balls	10-4
2.1.1.2 Arm harness replacement	10-4
2.1.2 α , β and γ -axes speed reduction gear replacement	10-6
2.2 R6Y3[]065	10-8
2.2.1 α , β and γ -axes arm replacement	10-8
2.2.1.1 Work required after replacing arm link balls	10-10
2.2.1.2 Arm harness replacement	10-10
2.2.2 α , β and γ -axes speed reduction gear replacement	10-12
2.3 θ -axis speed reduction gear replacement	10-15

Chapter 11 Option parts replacement

1. Shaft replacement procedure	11-1
1.1 Shaft removal	11-1
1.2 Shaft attachment	11-3
2. Harness replacement procedure	11-6
2.1 R6Y3[]110	11-6
2.2 R6Y3[]065	11-8
3. Detection connector replacement procedure	11-10

Chapter 12 Maintenance parts

1. Consumable parts	12-1
2. Basic specification	12-2
2.1 R6Y3[]110	12-2
2.2 R6Y3[]065	12-3
3. Maintenance parts	12-4
3.1 R6Y3[]110	12-4
3.1.1 R6Y30110S03067NJ5 BASE	12-4
3.1.2 R6Y31110[]03067NJ5 BASE	12-5
3.1.3 R6Y30110S03067NJ5 AXIS	12-6
3.1.4 R6Y31110[]03067NJ5 AXIS	12-7
3.1.5 R6Y30110S03067NJ5 ARM	12-8
3.1.6 R6Y31110[]03067NJ5 ARM	12-9
3.1.7 R6Y30110S03067NJ5 SHAFT	12-10
3.1.8 R6Y31110[]03067NJ5 SHAFT	12-11
3.1.9 R6Y31110[]03067NJ5 OPTION	12-12
3.2 R6Y3[]065	12-13
3.2.1 R6Y30065S02067NJ5 BASE	12-13
3.2.2 R6Y31065[]02067NJ5 BASE	12-14
3.2.3 R6Y30065S02067NJ5 AXIS	12-15
3.2.4 R6Y31065[]02067NJ5 AXIS	12-16
3.2.5 R6Y30065S02067NJ5 ARM	12-17
3.2.6 R6Y31065[]02067NJ5 ARM	12-18
3.2.7 R6Y30065S02067NJ5 SHAFT	12-19
3.2.8 R6Y31065[]02067NJ5 SHAFT	12-20
3.2.9 R6Y31065[]02067NJ5 OPTION	12-21
3.3 R6Y3[]110, R6Y3[]065 θ -axis	12-22
3.3.1 R6Y30110S03067NJ5, R6Y30065S02067NJ5 θ	12-22
3.3.2 R6Y31110L03067NJ5, R6Y31065L02067NJ5 θ	12-23
3.3.3 R6Y31110H03067NJ5, R6Y31065H02067NJ5 θ	12-25

Safety Instructions

Contents

1. Safety Information	S-1
2. Signal words used in this manual	S-2
3. Warning labels	S-3
3.1 Warning labels	S-3
3.1.1 Contents of warning label messages	S-3
3.1.2 Supplied warning label	S-4
3.2 Warning symbols	S-4
4. Major precautions for each stage of use	S-5
4.1 Precautions for using robots	S-5
4.2 Design	S-5
4.3 Moving and installation	S-6
4.4 Safety measures	S-8
4.4.1 Safety measures	S-8
4.4.2 Installing a safety enclosure	S-9
4.5 Operation	S-10
4.5.1 Trial operation	S-10
4.5.2 Automatic operation	S-10
4.5.3 Precautions during operation	S-10
4.6 Inspection and maintenance	S-11
4.6.1 Before inspection and maintenance work	S-11
4.6.2 Precautions during service work	S-12
4.7 Disposal	S-12
5. Emergency action when a person is caught by robot	S-13
6. Using the robot safely	S-14
6.1 Robot protective functions	S-14
6.2 Residual risk	S-14
6.3 Special training for industrial robot operation	S-14

1. Safety Information

Industrial robots are highly programmable, mechanical devices that provide a large degree of freedom when performing various manipulative tasks. To operate the robot in safer and correct manner, strictly observe the safety instructions and precautions stated in this "Safety Instructions" guide. Failure to take necessary safety measures or incorrect handling may result in trouble or damage to the robot, and also may cause personal injury (to installation personnel, robot operator or service personnel) including fatal accidents.

The safety instructions and precautions described in the "Safety Instructions" cover only the robot (mechanical sections). For details about operation of the controller and safety precautions associated with the controller operation, refer to the Controller Manual.

Before using this product, read this manual and related manuals and take safety precautions to ensure correct handling. The precautions listed in this manual relate to this product. To ensure the safety of the user's final system that includes robots, the user must take appropriate safety considerations.

To use robots safely and correctly, be sure to strictly observe the safety rules and instructions.

- For specific safety information and standards, refer to the applicable local regulations and comply with the instructions.
- Warning labels attached to the robots are written in English, Japanese, Chinese and Korean. This manual is available in English or Japanese (or some parts in Chinese). Unless the robot operators or service personnel understand these languages, do not permit them to handle the robot.
- Cautions regarding the official language of EU countries. For equipment that will be installed in EU countries, the language used for the manuals, warning labels, operation screen characters, and CE declarations is English only. Warning labels only have pictograms or else include warning messages in English. In the latter case, messages in Japanese or other languages might be added.

It is not possible to list all safety items in detail within the limited space of this manual. So please note that it is essential that the user have a full knowledge of safety and also make correct judgments on safety procedures.

2. Signal words used in this manual

This manual uses the following safety alert symbols and signal words to provide safety instructions that must be observed and to describe handling precautions, prohibited actions, and compulsory actions. Make sure you understand the meaning of each symbol and signal word and then read this manual.



DANGER

THIS INDICATES AN IMMEDIATELY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, WILL RESULT IN DEATH OR SERIOUS INJURY.



WARNING

THIS INDICATES A POTENTIALLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN DEATH OR SERIOUS INJURY.



CAUTION

This indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury, or damage to the equipment.



NOTE

Explains the key point in the operation in a simple and clear manner.

3. Warning labels

Warning labels are attached to the robot body. To ensure correct use, read the warning labels and comply with the instructions.

3.1 Warning labels



WARNING

IF WARNING LABELS ARE REMOVED OR DIFFICULT TO SEE, THEN THE NECESSARY PRECAUTIONS MAY NOT BE TAKEN, RESULTING IN AN ACCIDENT.

- DO NOT REMOVE, ALTER OR STAIN THE WARNING LABELS ON THE ROBOT BODY.
- DO NOT ALLOW WARNING LABELS TO BE HIDDEN BY DEVICES INSTALLED ON THE ROBOT BY THE USER.
- PROVIDE PROPER LIGHTING SO THAT THE SYMBOLS AND INSTRUCTIONS ON THE WARNING LABELS CAN BE CLEARLY SEEN FROM OUTSIDE THE SAFETY ENCLOSURE.

3.1.1 Contents of warning label messages

Word messages on the danger, warning and caution labels are concise and brief instructions. For more specific instructions, read and follow the "Instructions on this label" described on the right of each label shown below.


1. Warning label 1



DANGER

SERIOUS INJURY MAY RESULT FROM CONTACT WITH A MOVING ROBOT.

- KEEP OUTSIDE OF THE ROBOT SAFETY ENCLOSURE DURING OPERATION.
- PRESS THE EMERGENCY STOP BUTTON BEFORE ENTERING THE SAFETY ENCLOSURE.

Instructions on this label	
	
Potential hazard to human body	Serious injury may result from contact with a moving robot.
To avoid hazard	<ul style="list-style-type: none"> • Keep outside of the robot safety enclosure during operation. • Press the emergency stop button before entering the safety enclosure.


2. Warning label 2



WARNING

MOVING PARTS CAN PINCH OR CRUSH HANDS.

KEEP HANDS AWAY FROM THE MOVABLE PARTS OF THE ROBOT.

Instructions on this label	
	
Potential hazard to human body	Moving parts can pinch or crush hands.
To avoid hazard	Keep hands away from the movable parts of the robot.



3. Warning label 3



WARNING

IMPROPER INSTALLATION OR OPERATION MAY CAUSE SERIOUS INJURY.

BEFORE INSTALLING OR OPERATING THE ROBOT, READ THE MANUAL AND INSTRUCTIONS ON THE WARNING LABELS AND UNDERSTAND THE CONTENTS.

Instructions on this label	
<div><div>WARNING 경고 경고</div><div><div><p>Read and understand manuals before operation.</p><p>操作前, 務必仔细阅读操作手册并充分理解其内容。</p><p>조작전에 매뉴얼을 숙지 할 것.</p><p>操作する前にマニュアルを読んで理解すること。</p></div></div><div>90K41-001290</div></div> <div><ul style="list-style-type: none">• Be sure to read the warning label and this manual carefully to make you completely understand the contents before attempting installation and operation of the robot.• Before starting the robot operation, even after you have read through this manual, read again the corresponding procedures and "Safety instructions" in this manual.• Never install, adjust, inspect or service the robot in any manner that does not comply with the instructions in this manual.</div>	
Potential hazard to human body	Improper installation or operation may cause serious injury.
To avoid hazard	Before installing or operating the robot, read the manual and instructions on the warning labels and understand the contents.

3.1.2 Supplied warning label



CAUTION

Attach the warning label that has been included in the robot at shipment to a legible location close to the robot, such as entrance of the safety enclosure.

3.2 Warning symbols


Warning symbols shown below are attached to the robot body to alert the operator to potential hazards. To use the OMRON robot safely and correctly always follow the instructions and cautions indicated by the symbols.

1. Electrical shock hazard symbol



WARNING

TOUCHING THE TERMINAL BLOCK OR CONNECTOR MAY CAUSE ELECTRICAL SHOCK, SO USE CAUTION.


Instructions by this symbol
 <p>This indicates a high voltage is present. Touching the terminal block or connector may cause electrical shock.</p>

2. High temperature hazard symbol



WARNING

MOTORS, HEATSINKS, AND REGENERATIVE UNITS BECOME HOT, SO DO NOT TOUCH THEM.

Instructions by this symbol
 <p>This indicates the area around this symbol may become very hot. Motors, heatsinks, and regenerative units become hot during and shortly after operation. To avoid burns be careful not to touch those sections.</p>

4. Major precautions for each stage of use

This section describes major precautions that must be observed when using robots. Be sure to carefully read and comply with all of these precautions even if there is no alert symbol shown.

4.1 Precautions for using robots

General precautions for using robots are described below.

1. Applications where robots cannot be used

OMRON robots are designed as general-purpose industrial equipment and cannot be used for the applications listed below.



DANGER

ROBOTS ARE DESIGNED AS GENERAL-PURPOSE INDUSTRIAL EQUIPMENT AND CANNOT BE USED FOR THE FOLLOWING APPLICATIONS.

- IN MEDICAL EQUIPMENT SYSTEMS WHICH ARE CRITICAL TO HUMAN LIFE
- IN SYSTEMS THAT SIGNIFICANTLY AFFECT SOCIETY AND THE GENERAL PUBLIC
- IN EQUIPMENT INTENDED TO CARRY OR TRANSPORT PEOPLE
- IN ENVIRONMENTS WHICH ARE SUBJECT TO VIBRATION SUCH AS ONBOARD SHIPS AND VEHICLES.

2. Qualification of operators/workers

Operators or persons who handle the robot such as for teaching, programming, movement check, inspection, adjustment, and repair must receive appropriate training and also have the skills needed to perform the job correctly and safely. They must read the manual carefully to understand its contents before attempting the robot operation or maintenance.

Tasks related to industrial robots (teaching, programming, movement check, inspection, adjustment, repair, etc.) must be performed by qualified persons who meet requirements established by local regulations and standards for industrial robots.



WARNING

- THE ROBOT MUST BE OPERATED ONLY BY PERSONS WHO HAVE RECEIVED SAFETY AND OPERATION TRAINING. OPERATION BY AN UNTRAINED PERSON IS EXTREMELY HAZARDOUS.
- ADJUSTMENT AND MAINTENANCE BY REMOVING A COVER REQUIRE SPECIALIZED TECHNICAL KNOWLEDGE AND SKILLS, AND MAY ALSO INVOLVE HAZARDS IF ATTEMPTED BY AN UNSKILLED PERSON. THESE TASKS MUST BE PERFORMED ONLY BY PERSONS WHO HAVE ENOUGH ABILITY AND QUALIFICATIONS IN ACCORDANCE WITH LOCAL LAWS AND REGULATIONS. FOR DETAILED INFORMATION, PLEASE CONTACT YOUR DISTRIBUTOR WHERE YOU PURCHASED THE PRODUCT.

4.2 Design

1. Restricting the movement range



WARNING

SOFT LIMIT FUNCTION IS NOT A SAFETY-RELATED FUNCTION INTENDED TO PROTECT THE HUMAN BODY. ENSURE SAFETY BY INSTALLING A SAFETY ENCLOSURE AND SO ON.

2. Provide safety measures for end effector (gripper, etc.)



WARNING

- END EFFECTORS MUST BE DESIGNED AND MANUFACTURED SO THAT THEY CAUSE NO HAZARDS (SUCH AS A LOOSE WORKPIECE OR LOAD) EVEN IF POWER (ELECTRICITY, AIR PRESSURE, ETC.) IS SHUT OFF OR POWER FLUCTUATIONS OCCUR.
- IF THE OBJECT GRIPPED BY THE END EFFECTOR MIGHT POSSIBLY FLY OFF OR DROP, THEN PROVIDE APPROPRIATE SAFETY PROTECTION TAKING INTO ACCOUNT THE OBJECT SIZE, WEIGHT, TEMPERATURE, AND CHEMICAL PROPERTIES.

3. Provide adequate lighting

Provide enough lighting to ensure safety during work.

4. Install an operation status light



WARNING

INSTALL A SIGNAL LIGHT (SIGNAL TOWER) AT AN EASY-TO-SEE POSITION SO THAT THE OPERATOR WILL BE AWARE OF THE ROBOT STOP STATUS (TEMPORARILY STOPPED, EMERGENCY STOP, ERROR STOP, ETC.).

4.3 Moving and installation

■ Installation environment

1. Do not use in strong magnetic fields



WARNING

DO NOT USE THE ROBOT NEAR EQUIPMENT OR IN LOCATIONS THAT GENERATE STRONG MAGNETIC FIELDS. THE ROBOT MAY BREAK DOWN OR MALFUNCTION IF USED IN SUCH LOCATIONS.

2. Do not use in locations subject to possible electromagnetic interference, etc.



WARNING

DO NOT USE THE ROBOT IN LOCATIONS SUBJECT TO ELECTROMAGNETIC INTERFERENCE, ELECTROSTATIC DISCHARGE OR RADIO FREQUENCY INTERFERENCE. THE ROBOT MAY MALFUNCTION IF USED IN SUCH LOCATIONS CREATING HAZARDOUS SITUATIONS.

3. Do not use in locations exposed to flammable gases



WARNING

- OMRON ROBOTS ARE NOT DESIGNED TO BE EXPLOSION-PROOF.
- DO NOT USE THE ROBOTS IN LOCATIONS EXPOSED TO EXPLOSIVE OR INFLAMMABLE GASES, DUST PARTICLES OR LIQUID. FAILURE TO FOLLOW THIS INSTRUCTION MAY CAUSE SERIOUS ACCIDENTS INVOLVING INJURY OR DEATH, OR LEAD TO FIRE.

■ Moving

1. Use caution to prevent pinching or crushing of hands or fingers



WARNING

KEEP YOUR HAND AWAY FROM THE ROBOT INSTALLATION SURFACE DURING MOVING. OTHERWISE, YOUR HAND IS ENTANGLED, CAUSING SERIOUS PERSONAL INJURY.

As instructed in Warning label 2, use caution to prevent hands or fingers from being pinched or crushed by movable parts when transporting or moving the robot. For details on warning labels, see "3. Warning labels" in "Safety instructions."

2. Take safety measures when moving the robot

To ensure safety when moving the DELTA robot, use the eyebolts that come with the robot. Refer to the "2.3 Moving the robot" in Chapter 2 of the Installation Manual for details.

3. Take measures to prevent the robot from falling

When moving the robot by lifting it with equipment such as a hoist or crane, wear personal protective gear and be careful not to move the robot at higher than the required height.

Make sure that there are no persons on paths used for moving the robot.



WARNING

A ROBOT FALLING FROM A HIGH PLACE AND STRIKING A WORKER MAY CAUSE DEATH OR SERIOUS INJURY. WHEN MOVING THE ROBOT, WEAR PERSONAL PROTECTIVE GEAR SUCH AS HELMETS AND MAKE SURE THAT NO ONE IS WITHIN THE SURROUNDING AREA.

■ Installation

1. Protect electrical wiring and hydraulic/pneumatic hoses

Install a cover or similar item to protect the electrical wiring and hydraulic/pneumatic hoses from possible damage.

2. Cautions on arm

In the installation work or in case of an emergency, do not hold the arm by your hand. It may cause malfunction.

■ Adjustment

1. Adjustment that requires removing a cover



WARNING

ADJUSTMENT BY REMOVING A COVER REQUIRE SPECIALIZED TECHNICAL KNOWLEDGE AND SKILLS, AND MAY ALSO INVOLVE HAZARDS IF ATTEMPTED BY AN UNSKILLED PERSON. THESE TASKS MUST BE PERFORMED ONLY BY PERSONS WHO HAVE ENOUGH ABILITY AND QUALIFICATIONS IN ACORDANCE WITH LOCAL LAWS AND REGULATIONS. FOR DETAILED INFORMATION, PLEASE CONTACT YOUR DISTRIBUTOR WHERE YOU PURCHASED THE PRODUCT.

■ Wiring

1. Robot cable

After checking the specified combinations of the robot and controller, connect the robot and controller.

2. Wiring safety points



WARNING

ALWAYS SHUT OFF ALL PHASES OF THE POWER SUPPLY EXTERNALLY BEFORE STARTING INSTALLATION OR WIRING WORK. FAILURE TO DO THIS MAY CAUSE ELECTRICAL SHOCK OR PRODUCT DAMAGE.



CAUTION

- Do not apply excessive impacts or loads to the connectors when making cable connections. This might bend the connector pins or damage the internal PC board.
- When disconnecting the cable from the robot, do not hold the cable and pull it out by hand. Loosen the screws on the connector (if fastened with the screws), and then disconnect the cable. Trying to detach by pulling on the cable itself may damage the connector or cables, and poor cable contact will cause the controller or robot to malfunction.

3. Precautions for cable routing and installation



CAUTION

- Be sure to store the cables connected to the robot in the duct or clamp them securely in place. If the cables are not stored in a conduit or properly clamped, excessive play or movement or mistakenly pulling on the cable may damage the connector or cables, and poor cable contact will cause the controller or robot to malfunction.
- Do not modify the cables and do not place any heavy objects on them. Handle them carefully to avoid damage. Damaged cables may cause malfunction or electrical shock.
- If the cables connected to the controller may possibly become damaged, protect them with an appropriate cover, etc.
- Check that the control lines and communication cables are routed at a gap sufficiently away from main power supply circuits and power lines, etc. Bundling them together with power lines or close to power lines may cause faulty operation due to noise.

4. Protective measures against electrical shock



WARNING

ALWAYS GROUND THE ROBOT BODY EARTH TERMINAL. FAILURE TO DO SO MAY RESULT IN ELECTRIC SHOCK.

4.4 Safety measures

4.4.1 Safety measures

1. Referring to warning labels and manual



WARNING

- BEFORE STARTING INSTALLATION OR OPERATION OF THE ROBOT, BE SURE TO READ THE WARNING LABELS AND THIS MANUAL, AND COMPLY WITH THE INSTRUCTIONS.
- NEVER ATTEMPT ANY REPAIR, PARTS REPLACEMENT AND MODIFICATION UNLESS DESCRIBED IN THIS MANUAL. THESE TASKS REQUIRE SPECIALIZED TECHNICAL KNOWLEDGE AND SKILLS AND MAY ALSO INVOLVE HAZARDS. PLEASE CONTACT YOUR DISTRIBUTOR FOR ADVICE.



NOTE

For details on warning labels, see "3. Warning labels" in "Safety instructions."

2. Draw up "work instructions" and make the operators/workers understand them



WARNING

DECIDE ON "WORK INSTRUCTIONS" IN CASES WHERE PERSONNEL MUST WORK WITHIN THE ROBOT SAFETY ENCLOSURE TO PERFORM STARTUP OR MAINTENANCE WORK. MAKE SURE THE WORKERS COMPLETELY UNDERSTAND THESE "WORK INSTRUCTIONS".

Decide on "work instructions" for the following items in cases where personnel must work within the robot safety enclosure to perform teaching, maintenance or inspection tasks. Make sure the workers completely understand these "work instructions".

1. Robot operating procedures needed for tasks such as startup procedures and handling switches
2. Robot speeds used during tasks such as teaching
3. Methods for workers to signal each other when two or more workers perform tasks
4. Steps that the worker should take when a problem or emergency occurs
5. Steps to take after the robot has come to a stop when the emergency stop device was triggered, including checks for cancelling the problem or error state and safety checks in order to restart the robot.
6. In cases other than above, the following actions should be taken as needed to prevent hazardous situations due to sudden or unexpected robot operation or faulty robot operation as listed below.
 - Place a display sign on the operator panel
 - Ensure the safety of workers performing tasks within the robot safety enclosure
 - Clearly specify position and posture during work
 - Specify a position and posture where worker can constantly check robot movements and immediately move to avoid trouble if an error/problem occurs
 - Take noise prevention measures
 - Use methods for signaling operators of related equipment
 - Use methods to decide that an error has occurred and identify the type of error

Implement the "work instructions" according to the type of robot, installation location, and type of work task.

When drawing up the "work instructions", make an effort to include opinions from the workers involved, equipment manufacturer technicians, and workplace safety consultants, etc.

3. Take safety measures



DANGER

- NEVER ENTER THE ROBOT MOVEMENT RANGE WHILE THE ROBOT IS OPERATING OR THE MAIN POWER IS TURNED ON. FAILURE TO FOLLOW THIS WARNING MAY CAUSE SERIOUS ACCIDENTS INVOLVING INJURY OR DEATH. INSTALL A SAFETY ENCLOSURE OR A GATE INTERLOCK WITH AN AREA SENSOR TO KEEP ALL PERSONS AWAY FROM THE ROBOT MOVEMENT RANGE.
- WHEN IT IS NECESSARY TO OPERATE THE ROBOT WHILE YOU ARE WITHIN THE ROBOT MOVEMENT RANGE SUCH AS FOR TEACHING OR MAINTENANCE/INSPECTION TASKS, BE SURE TO INSTALL AN ENABLE DEVICE IN THE EXTERNAL SAFETY CIRCUIT SO THAT YOU CAN IMMEDIATELY STOP THE ROBOT OPERATION IN CASE OF AN ABNORMAL OR HAZARDOUS CONDITION. ADDITIONALLY, SET THE ROBOT MOVING SPEED SO THAT IT COMPLIES WITH THE ROBOT SAFETY STANDARDS.

**WARNING**

- DURING STARTUP OR MAINTENANCE TASKS, DISPLAY A SIGN STATING "WORK IN PROGRESS " ON THE OPERATION PANEL OR LOCK THE COVER OF THE OPERATION PANEL IN ORDER TO PREVENT ANYONE OTHER THAN THE PERSON FOR THAT TASK FROM MISTAKENLY OPERATING THE START OR SELECTOR SWITCH.
- ALWAYS CONNECT THE ROBOT AND ROBOT CONTROLLER IN THE CORRECT COMBINATION. USING THEM IN AN INCORRECT COMBINATION MAY CAUSE FIRE OR BREAKDOWN.

4. Install brake release circuit

The DELTA robot is equipped with a brake release switch for the manual teaching or maintenance inspection. To use this brake release switch, it is also necessary to install a brake release circuit on the user side. For details, see "4.2 Wiring the brake release cable connector" in Chapter 2 of the Installation Manual.

**WARNING**

WHEN PERFORMING THE TEACHING OR MAINTENANCE INSPECTION MANUALLY, INSTALL THE BRAKE RELEASE CIRCUIT TO ENSURE THE SAFETY.

5. Install system

When configuring an automated system using a robot, hazardous situations are more likely to occur from the automated system than the robot itself. So the system manufacturer should install the necessary safety measures required for the individual system. The system manufacturer should provide a proper manual for safe, correct operation and servicing of the system.

**WARNING**

TO CHECK THE ROBOT CONTROLLER OPERATING STATUS, REFER TO THE RELATED MANUALS. DESIGN AND INSTALL THE SYSTEM INCLUDING THE ROBOT CONTROLLER SO THAT IT WILL ALWAYS WORK SAFELY.

6. Do not modify**WARNING**

NEVER ATTEMPT TO MODIFY THE ROBOT. DO NOT OPEN ANY COVER. DOING SO MAY CAUSE ELECTRICAL SHOCK, BREAKDOWN, MALFUNCTION, INJURY, OR FIRE.

4.4.2 Installing a safety enclosure

Be sure to install a safety enclosure to keep anyone from entering within the movement range of the robot. The safety enclosure will prevent the operator and other persons from coming in contact with moving parts of the robot and suffering injury.

**DANGER**

- SERIOUS INJURY MAY RESULT FROM CONTACT WITH A MOVING ROBOT.
- KEEP OUTSIDE OF THE ROBOT SAFETY ENCLOSURE DURING OPERATION.
 - PRESS THE EMERGENCY STOP BUTTON BEFORE ENTERING THE SAFETY ENCLOSURE.

**WARNING**

- INSTALL AN INTERLOCK THAT TRIGGERS EMERGENCY STOP WHEN THE DOOR OR GATE OF THE SAFETY ENCLOSURE IS OPENED.
- THE SAFETY ENCLOSURE SHOULD BE DESIGNED SO THAT NO ONE CAN ENTER INSIDE EXCEPT FROM THE DOOR OR GATE EQUIPPED WITH AN INTERLOCK DEVICE.
- WARNING LABEL 1 (SEE "3. WARNING LABELS" IN "SAFETY INSTRUCTIONS") THAT COMES SUPPLIED WITH A ROBOT SHOULD BE AFFIXED TO AN EASY-TO-SEE LOCATION ON THE DOOR OR GATE OF THE SAFETY ENCLOSURE.

4.5 Operation

When operating a robot, ignoring safety measures and checks may lead to serious accidents. Always take the following safety measures and checks to ensure safe operation.



DANGER

CHECK THE FOLLOWING POINTS BEFORE STARTING ROBOT OPERATION.

- NO ONE IS WITHIN THE ROBOT SAFETY ENCLOSURE.
- THE ROBOT AND PERIPHERAL EQUIPMENT ARE IN GOOD CONDITION.

4.5.1 Trial operation

Refer to the controller manual after carrying out robot installation, adjustments, inspection, maintenance, or repair.

4.5.2 Automatic operation

To perform the automatic operation, follow the instructions stated in the controller manual.

4.5.3 Precautions during operation

1. When the robot is damaged or an abnormal condition occurs



WARNING

- IF UNUSUAL ODORS, NOISE OR SMOKE OCCUR DURING OPERATION, IMMEDIATELY TURN OFF POWER TO PREVENT POSSIBLE ELECTRICAL SHOCK, FIRE OR BREAKDOWN. STOP USING THE ROBOT AND CONTACT YOUR DISTRIBUTOR.
- IF ANY OF THE FOLLOWING DAMAGE OR ABNORMAL CONDITIONS OCCURS THE ROBOT, THEN CONTINUING TO OPERATE THE ROBOT IS DANGEROUS. IMMEDIATELY STOP USING THE ROBOT AND CONTACT YOUR DISTRIBUTOR.

Damage or abnormal condition	Type of danger
Damage to machine harness or robot cable	Electrical shock, robot malfunction
Damage to robot exterior	Damaged parts fly off during robot operation
Abnormal robot operation (position deviation, vibration, etc.)	Robot malfunction
α -axis, β -axis or γ -axis brake malfunction	Shaft or movable base falling or related part fly off

2. High temperature hazard



WARNING

- DO NOT TOUCH THE ROBOT DURING OPERATION. THE ROBOT BODY IS VERY HOT DURING OPERATION, SO BURNS MAY OCCUR IF YOU TOUCH THESE SECTIONS.
- THE MOTOR AND SPEED REDUCTION GEAR CASING ARE VERY HOT SHORTLY AFTER OPERATION, SO BURNS MAY OCCUR IF THESE ARE TOUCHED. BEFORE TOUCHING THOSE PARTS FOR INSPECTIONS OR SERVICING, TURN OFF THE CONTROLLER, WAIT FOR A WHILE AND CHECK THAT THEIR TEMPERATURE HAS FALLEN.

3. Use caution when releasing the α -axis, β -axis or γ -axis brake

To release the brake, it is necessary to install a brake release circuit on the user side.



WARNING

- THE α -AXIS, β -AXIS OR γ -AXIS WILL SLIDE DOWNWARD WHEN THE BRAKE IS RELEASED, CAUSING A HAZARDOUS SITUATION. TAKE ADEQUATE SAFETY MEASURES BY TAKING THE WEIGHT AND SHAPE INTO ACCOUNT.
- BEFORE RELEASING THE BRAKE AFTER PRESSING THE EMERGENCY STOP BUTTON, PLACE A SUPPORT UNDER THE α -AXIS, β -AXIS OR γ -AXIS SO THAT IT WILL NOT SLIDE DOWN.
- WHEN PERFORMING TASKS (DIRECT TEACHING, ETC.) WITH THE BRAKE RELEASED, RELEASE THE BRAKE OF ONLY NECESSARY AXIS AND BE CAREFUL NOT TO LET YOUR BODY GET CAUGHT BETWEEN THE MOVABLE BASE AND THE INSTALLATION BASE.

4. If the α -axis, β -axis, γ -axis or θ -axis rotation angle is small



CAUTION

If the α -axis, β -axis, γ -axis or θ -axis rotation angle is set smaller than 5 degrees, then it will always move within the same position, making it difficult for a proper oil film to form on the speed reduction gear, possibly shortening its service life. To prevent this, add a range of motion so that each axis moves through a range of 120 degrees or more about 5 times a day.

4.6 Inspection and maintenance

Always perform daily and periodic inspections and make a pre-operation check to ensure there are no problems with the robot and related equipment. If a problem or abnormality is found, then promptly repair it or take other measures as necessary.

Keep a record of periodic inspections or repairs and store this record for at least 3 years.

4.6.1 Before inspection and maintenance work

1. Do not attempt any work or operation unless described in this manual.

Never attempt any work or operation unless described in this manual.



WARNING

NEVER ATTEMPT INSPECTION, MAINTENANCE, REPAIR, AND PART REPLACEMENT UNLESS DESCRIBED IN THIS MANUAL. THESE TASKS REQUIRE SPECIALIZED TECHNICAL KNOWLEDGE AND SKILLS AND MAY ALSO INVOLVE HAZARDS. PLEASE BE SURE TO CONTACT YOUR DISTRIBUTOR FOR ADVICE.

2. Precautions during repair and parts replacement



WARNING

IF IT IS ABSOLUTELY REQUIRED TO REPAIR OR REPLACE ANY PART OF THE ROBOT, PLEASE BE SURE TO CONTACT YOUR DISTRIBUTOR AND FOLLOW THE INSTRUCTIONS THEY PROVIDE. INSPECTION AND MAINTENANCE OF THE ROBOT BY AN UNSKILLED OR UNTRAINED PERSON IS EXTREMELY HAZARDOUS.

Adjustment, maintenance and parts replacement require specialized technical knowledge and skills, and also may involve hazards. These tasks must be performed only by persons who have enough ability and qualifications required by local laws and regulations.



WARNING

ADJUSTMENT AND MAINTENANCE BY REMOVING A COVER REQUIRE SPECIALIZED TECHNICAL KNOWLEDGE AND SKILLS, AND MAY ALSO INVOLVE HAZARDS IF ATTEMPTED BY AN UNSKILLED PERSON. FOR DETAILED INFORMATION, PLEASE CONTACT YOUR DISTRIBUTOR WHERE YOU PURCHASED THE PRODUCT.

3. Shut off all phases of power supply



WARNING

ALWAYS SHUT OFF ALL PHASES OF THE POWER SUPPLY EXTERNALLY BEFORE CLEANING THE ROBOT AND CONTROLLER OR SECURELY TIGHTENING THE TERMINAL SCREWS ETC. FAILURE TO DO THIS MAY CAUSE ELECTRICAL SHOCK OR PRODUCT DAMAGE OR MALFUNCTION.

4. Allow a waiting time after power is shut off (Allow time for temperature and voltage to drop)



WARNING

THE MOTOR AND SPEED REDUCTION GEAR CASING ARE VERY HOT SHORTLY AFTER OPERATION, SO BURNS MAY OCCUR IF THEY ARE TOUCHED. BEFORE TOUCHING THOSE PARTS FOR INSPECTIONS OR SERVICING, TURN OFF THE CONTROLLER, WAIT FOR A WHILE AND CHECK THAT THE TEMPERATURE HAS FALLEN.

4.6.2 Precautions during service work

1. Precautions when removing a motor



WARNING

THE α -AXIS, β -AXIS OR γ -AXIS WILL SLIDE DOWNWARD WHEN THE MOTOR IS REMOVED, CAUSING A HAZARDOUS SITUATION .

- TURN OFF THE CONTROLLER AND PLACE A SUPPORT UNDER THE α -AXIS, β -AXIS OR γ -AXIS BEFORE REMOVING THE MOTOR.
- BE CAREFUL NOT TO LET YOUR BODY GET CAUGHT BETWEEN THE MOVABLE BASE AND THE INSTALLATION BASE.

4.7 Disposal

When disposing of robots and related items, handle them carefully as industrial wastes. Use the correct disposal method in compliance with your local regulations, or entrust disposal to a licensed industrial waste disposal company.


1. Disposal of packing boxes and materials

When disposing of packing boxes and materials, use the correct disposal method in compliance with your local regulations. We do not collect and dispose of the used packing boxes and materials.

5. Emergency action when a person is caught by robot

If a person is caught in between the robot and mechanical section, such as installation base, use the brake release switch on the robot main unit to release the axis.

Brake release switch



As the robot is put in the emergency stop state, the robot drive power is shut down. However, the axis cannot be moved since the brake is activated. So, release the brake, and then push the axis by hand to move it.



WARNING

THE α -AXIS, β -AXIS OR γ -AXIS WILL SLIDE DOWNWARD WHEN THE BRAKE IS RELEASED, CAUSING A HAZARDOUS SITUATION.

- BEFORE RELEASING THE BRAKE, BE SURE TO PLACE A SUPPORT UNDER THE α -AXIS, β -AXIS OR γ -AXIS SO THAT IT WILL NOT SLIDE DOWN.
- WHEN RELEASING THE BRAKE, BE CAREFUL NOT TO LET YOUR BODY GET CAUGHT BETWEEN THE MOVABLE BASE AND THE INSTALLATION BASE.



CAUTION

Release the brake axis-by-axis.



NOTE

For details about the brake release cable connector, see “4.2 Wiring the brake release cable connector” in Chapter 2 of the Installation Manual.

6. Using the robot safely

6.1 Robot protective functions

1. Soft limits

Soft limits can be set on each axis to limit the working envelope in manual (jog) operation and automatic operation after return-to-origin. The working envelope is the area limited by soft limits.



WARNING

SOFT LIMIT FUNCTION IS NOT A SAFETY-RELATED FUNCTION INTENDED TO PROTECT THE HUMAN BODY. ENSURE SAFETY BY INSTALLING A SAFETY ENCLOSURE AND SO ON.

2. α -axis, β -axis or γ -axis brakes

An electromagnetic brake is installed on the α -axis, β -axis and γ -axis to prevent them from sliding downward when the servo is OFF.



WARNING

THE α -AXIS, β -AXIS OR γ -AXIS WILL SLIDE DOWNWARD WHEN THE BRAKE IS RELEASED, CAUSING A HAZARDOUS SITUATION. TAKE ADEQUATE SAFETY MEASURES BY TAKING THE WEIGHT AND SHAPE INTO ACCOUNT.

- BEFORE RELEASING THE BRAKE AFTER PRESSING THE EMERGENCY STOP BUTTON, PLACE A SUPPORT UNDER THE α -AXIS, β -AXIS OR γ -AXIS SO THAT IT WILL NOT SLIDE DOWN.
- WHEN PERFORMING TASKS (DIRECT TEACHING, ETC.) WITH THE BRAKE RELEASED, BE CAREFUL NOT TO LET YOUR BODY GET CAUGHT BETWEEN THE MOVABLE BASE AND THE INSTALLATION BASE.

6.2 Residual risk

To ensure safe and correct use of OMRON robots, System integrators and/or end users implement the machinery safety design that conforms to ISO12100.

Residual risks for OMRON robots are described in the DANGER or WARNING instructions provided in each chapter and section. So, read them carefully.

6.3 Special training for industrial robot operation

Operators or persons who handle the robot for tasks such as for teaching, programming, movement checks, inspections, adjustments, and repairs must receive appropriate training and also have the skills needed to perform the job correctly and safely. They must also read the manual carefully to understand its contents before attempting the robot operation or maintenance.

Tasks related to industrial robots (teaching, programming, movement check, inspection, adjustment, repair, etc.) must be performed by qualified persons who meet requirements established by local regulations and safety standards for industrial robots.

Comparison of terms used in this manual with ISO

This manual	ISO 10218-1	Note
Maximum movement range	maximum space	Area limited by mechanical stoppers.
Movement range	restricted space	Area limited by movable mechanical stoppers.
Working envelope	operational space	Area limited by software limits.
Within safety enclosure	safeguarded space	

Warranty

For information on the warranty period and terms, please contact our distributor where you purchased the product.

■ This warranty does not cover any failure caused by:

1. Installation, wiring, connection to other control devices, operating methods, inspection or maintenance that does not comply with industry standards or instructions specified in the OMRON manual;
2. Usage that exceeded the specifications or standard performance shown in the OMRON manual;
3. Product usage other than intended by OMRON;
4. Storage, operating conditions and utilities that are outside the range specified in the manual;
5. Damage due to improper shipping or shipping methods;
6. Accident or collision damage;
7. Installation of other than genuine OMRON parts and/or accessories;
8. Modification to original parts or modifications not conforming to standard specifications designated by OMRON, including customizing performed by OMRON in compliance with distributor or customer requests;
9. Pollution, salt damage, condensation;
10. Fires or natural disasters such as earthquakes, tsunamis, lightning strikes, wind and flood damage, etc;
11. Breakdown due to causes other than the above that are not the fault or responsibility of OMRON;
12. Electrical shock when the user installs the actuator, etc. on the movable base or end effector in the 3-axis specifications.

■ The following cases are not covered under the warranty:

1. Products whose serial number or production date (month & year) cannot be verified.
2. Changes in software or internal data such as programs or points that were created or changed by the customer.
3. Products whose trouble cannot be reproduced or identified by OMRON.
4. Products utilized, for example, in radiological equipment, biological test equipment applications or for other purposes whose warranty repairs are judged as hazardous by OMRON.

WARRANTY

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year after the date of manufacturing as shown on the product serial number plate.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NONINFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

LIMITATIONS OF LIABILITY

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR COMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

In no event shall the responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.

IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE OR INAPPROPRIATE MODIFICATION OR REPAIR.

Chapter 1 Overview

Contents

1. Overview	1-1
-------------	-----

1. Overview



WARNING

- ADJUSTMENT, MAINTENANCE AND REMOVAL OF ARMS, SHAFTS, OR THE θ -AXIS ASSEMBLY REQUIRE SPECIALIZED TECHNICAL KNOWLEDGE AND SKILLS, AND ALSO MAY INVOLVE HAZARDS. THIS WORK MUST BE CARRIED OUT BY REFERENCING THIS MANUAL BY SUFFICIENTLY SKILLED AND QUALIFIED PERSONNEL IN ACCORDANCE WITH THE LAWS AND REGULATIONS OF EACH COUNTRY.
- PLACE A CONSPICUOUS SIGN INDICATING THE ROBOT IS BEING ADJUSTED, TO PREVENT OTHERS FROM TOUCHING THE CONTROLLER SWITCH OR OPERATION PANEL.
- IF A SAFETY ENCLOSURE HAS NOT YET BEEN PROVIDED RIGHT AFTER INSTALLATION OF THE ROBOT, ROPE OFF OR CHAIN OFF THE MOVEMENT RANGE AROUND THE MANIPULATOR IN PLACE OF A SAFETY ENCLOSURE, AND OBSERVE THE FOLLOWING POINTS.
 1. USE STABLE POSTS WHICH WILL NOT FALL OVER EASILY.
 2. THE ROPE OR CHAIN SHOULD BE EASILY VISIBLE BY EVERYONE AROUND THE ROBOT.
 3. PLACE A CONSPICUOUS SIGN PROHIBITING THE OPERATOR OR OTHER PERSONNEL FROM ENTERING THE MOVEMENT RANGE OF THE MANIPULATOR.
- IF CHECKING OPERATION FOLLOWING ADJUSTMENT, REFER TO THE CONTROLLER MANUAL.



CAUTION

Use only the lubricants specified by your distributors.

Chapter 2

Attaching, detaching and replacing the cover

Contents

1. Detaching or attaching the α, β and γ-axes covers	2-1
1.1 R6Y3 110	2-1
1.1.1 α , β and γ -axes cover removal procedure	2-2
1.1.2 α , β and γ -axes cover attachment procedure	2-7
1.2 R6Y3 065	2-13
1.2.1 α , β and γ -axes cover removal procedure	2-14
1.2.2 α , β and γ -axes cover attachment procedure	2-17
2. Detaching or attaching the θ-axis cover	2-22
2.1 θ-axis motor cover removal	2-23
2.2 θ-axis motor cover attachment	2-25

1. Detaching or attaching the α , β and γ -axes covers


1.1 R6Y3[]110



WARNING

- IF THE COVERS ARE REMOVED FOR MAINTENANCE WORK, BE SURE TO RETURN THEM TO THEIR ORIGINAL POSITIONS USING THE BOLTS USED TO SECURE THEM.
- IF ANY OF THE BOLTS BECOME LOST, USE THE SPECIFIED BOLTS AND QUANTITIES TO SECURE THE COVERS WHILE REFERRING TO THE BELOW PICTURE.
- IF THE COVERS ARE NOT SECURED FIRMLY, NOISE MAY OCCUR, THE COVERS MAY DROP AND FLY OUT, HANDS MAY BECOME ENTANGLED IN THE DRIVE UNIT DURING TEACHING, OR COME INTO CONTACT WITH THE HOT DRIVE UNIT, CAUSING BURNS. OBSERVE THESE CAUTIONS STRICTLY TO PREVENT SUCH TROUBLES.

R6Y3[]110



1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty	Remarks
1	Motor cover	KDL-M2163-00x		2	β , γ -axes, affixed with electric shock caution label
2		KDL-M2163-10x		1	α -axis, warning label
3	Seal	KDL-M2138-00x		1	Motor cover attachment part (*1)
4	Cover securing bolt	97080-05008	M5, length 8	2	(*1)
5	Brake release switch	KDL-M4851-00x		1	(*1)
6	Bracket	KDL-M1172-00x		1	Motor cover upper attachment (*1)
		KDL-M1173-00x		1	Motor cover lower attachment (*1)
7	Bracket securing bolt	91312-04020	M4, length 20	4	(*1)
8	Cap	KDL-M2165-00x		1	(*1)
9	Boot	KDL-M212A-00x		1	(*1)
10	Grommet	KDL-M212F-00x		1	Encoder integrated cable (*1)
		KDL-M212F-10x		1	(*1)

*1 : Quantity per cover

2. Tools to be prepared

Name	Part. No.	Manufacturer	Remarks
Cleaning wipe			
Hex wrench set			
Spanner	No. 7		

1.1.1 α , β and γ -axes cover removal procedure



WARNING

WHEN HANDLING MOTORS, TAKE CARE TO AVOID ELECTRIC SHOCK OR BURNS OWING TO THE HEAT GENERATED BY THE MOTORS.

1

Remove the duct, and then remove the boot and cap.



Step 1

Duct, boot and cap removal



NOTE


The boot and cap are merely inserted when the robot is shipped.

2

Disconnect the robot cable connector.




Cap removal



Boot removal

3 **Remove the M5 hex bolt from the top of the motor cover.**

► Step 3 Bolt removal




4 **Remove the cover a little.**
 Grasp the rear of the cover and pull it out while shaking it up and down to remove the cover a little. About 10mm of the rubber will come out (within 5mm when attached).



NOTE

The inside of the cover will catch and so will not come off completely.

► Step 4 Temporarily removed cover



Cover bottom temporarily removed



Cover top temporarily removed

5

Pull the cover out further.

Make a gap between the cover and base by pulling the cover out further.



NOTE

The cover will catch at this point and so will not come off completely.



Step 5

Temporarily removed cover



Cover bottom temporarily removed



Cover top temporarily removed

2

Attaching, detaching and replacing the cover

Pull out the cover.

Grasp the sides of the cover and push both sides so that the bottom deforms a little to pull out the cover. The clips on the inside near the switch will come free, making it easier to pull out the cover without it catching.


The motor connector will catch on the hole on the side of the cover, and so the cover should be shifted to avoid the connector. The switch on the inside will catch on the motor connector, and so the cover should be pulled out while trying to avoid the connector.

▶ **Step 6****Pull out the cover.**


■ Clip structure

The cover clips will catch on the step of the bracket under the reduction gear. There are two steps, and the clips catch on the second step.


Clip construction



Clip construction on inside



Inside of removed cover



1.1.2 α , β and γ -axes cover attachment procedure

Attach the cover using the opposite of the procedure used for removal.



WARNING

THE SAME TYPE OF MOTOR CABLE AND ENCODER CABLE IS USED FOR THE α , β , AND γ -AXES. CONNECT THE CABLES SO THAT THEY MATCH THE RESPECTIVE AXES AT THE CONTROLLER (DRIVER). IF THE CABLES ARE CONNECTED INCORRECTLY, THE ROBOT WILL NOT OPERATE CORRECTLY TO RESULT IN POSSIBLE DANGER.

1

Insert the motor cable from smaller hole on the boot with small hole.

The motor cable connector should still be inserted first even if using L-shaped connectors.

2

Insert the encoder cable and brake release cable (prepared by user) from smaller hole on the boot.



CAUTION

The encoder cable must pass through the inside of the cover and therefore a sufficient length of cable should be inserted.

3

Pull the cover internal cables from the hole with the boot.

On the outside of the cover is the cap, and the motor connector part should be the boot.

4


Connect the cover internal switch connector and brake release connector.

Store the joint inside the cover.

The cable leading from the brake release connector should be prepared by the user.


Step 1

Insert the motor cable.



Step 2

Insert the encoder cable and brake release cable (prepared by user).



Step 4


Switch connector and brake release connector connection



5

Route the encoder cable.



Insert the encoder cable only through the hole for the motor connector, and pull it out from the adjacent cap hole.

**Step 5****Encoder cable routing**

Temporarily insert the motor cover.

Insert the motor cover so that the internal switch does not interfere with the motor connector. Pull the brake release cable and encoder cable out from the gap next to the motor connector.

▶ Step 6

Temporary motor cover insertion

Cables removed when temporarily inserting cover

7 ***Insert the cover so that the rubber on the bottom fits in.***

There will be a gap when the cover catches on the first clip.

8 ***Insert the cover so that the rubber on the top fits in.***



CAUTION

Insert the rubber a little at a time, and avoid trying to force it in. If forced in, the rubber will end up deformed, making it difficult to attach the motor cover.

9 ***Push in the motor cover from the rear.***

The rubber at the bottom of the switch should protrude approximately 5mm, and the rubber at the top of the switch should protrude approximately 1mm.

► Step 7 **Gap**



Gap at top of cover




Gap at bottom of cover

► Step 8 **Insert the rubber.**



► Step 9 **Push in the motor cover.**



10 *Adjust the motor cover position and then secure with the M5 hex bolt(s).*

Adjust the motor cover position and then screw in two M5 hex bolts to secure.

Ensure that the motor cover has been securely attached.

It will not be possible to insert the bolts if the motor cover position and tapping positions for the M5 hex bolts are not aligned.

At this time, do not use any thread sealer.

11 *Attach the robot cable connector.*



WARNING

CONNECT THE α , β AND γ -AXES ROBOT CABLES SO THAT THEY MATCH THE RESPECTIVE AXES AT THE CONTROLLER (DRIVER). IF THE CABLES ARE CONNECTED INCORRECTLY, THE ROBOT WILL NOT OPERATE CORRECTLY TO RESULT IN POSSIBLE DANGER.


12 *Attach the boot and cap to the motor cover.*

13 *Attach the duct to the robot cable.*


Insert the robot cable into the notch on the duct.

The cable can be inserted easily by inserting a thick rod such as a flat screwdriver.

Step 10 Motor cover attachment



Step 12 Boot, cap attachment




Step 13 Duct attachment



- 14 *Attach the grommet to the robot cable.*
- 15 *Insert the grommet in the boot.*
- 16 *Insert the boot in the duct.*

► Step 14 **Grommet attachment**



► Step 15 **Grommet insertion**



► Step 16 **Boot insertion**



1.2 R6Y3[]065



WARNING


- IF THE COVERS ARE REMOVED FOR MAINTENANCE WORK, BE SURE TO RETURN THEM TO THEIR ORIGINAL POSITIONS USING THE BOLTS USED TO SECURE THEM.
- IF ANY OF THE BOLTS BECOME LOST, USE THE SPECIFIED BOLTS AND QUANTITIES TO SECURE THE COVERS WHILE REFERRING TO THE BELOW PICTURE.
- IF THE COVERS ARE NOT SECURED FIRMLY, NOISE MAY OCCUR, THE COVERS MAY DROP AND FLY OUT, HANDS MAY BECOME ENTANGLED IN THE DRIVE UNIT DURING TEACHING, OR COME INTO CONTACT WITH THE HOT DRIVE UNIT, CAUSING BURNS. OBSERVE THESE CAUTIONS STRICTLY TO PREVENT SUCH TROUBLES.



CAUTION

The α , β , and γ -axis motor cover construction does not comply with IP67, and therefore the inside of the cover should be cleaned periodically. The motor and speed reduction gear inside the cover do comply with IP67.

R6Y3[]065



1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty	Remarks
1	Motor cover	KDL-M2163-40x		2	β , γ -axes, affixed with electric shock caution label
2		KDL-M2163-50x		1	α -axis, warning label
3	Seal	KDL-M2138-10x		1	Motor cover attachment part (*1)
4	Cover securing bolt	97080-05008	M5, length 8	2	(*1)
5	Brake release switch	KDL-M4851-00x		1	(*1)
6	Bracket	KDL-M1172-00x		1	Motor cover upper attachment (*1)
		KDL-M1193-00x		1	Motor cover lower attachment (*1)
7	Bracket securing bolt	91312-04010	M4, length 10	2	(*1)
		91312-04020	M4, length 20	2	(*1)
8	Cap	KDL-M212A-10x		1	(*1)
9	Grommet	KDL-M212F-20x		1	(*1)

*1 : Quantity per cover

2. Tools to be prepared

Name	Part. No.	Manufacturer	Remarks
Cleaning wipe			
Hex wrench set			
Spanner	No. 7		

1.2.1 α , β and γ -axes cover removal procedure



WARNING

WHEN HANDLING MOTORS, TAKE CARE TO AVOID ELECTRIC SHOCK OR BURNS OWING TO THE HEAT GENERATED BY THE MOTORS.

1

Remove the duct and cap.



Step 1 Duct and cap removal



NOTE

The cap is shipped in the state that it is only fit.


2

Remove the M5 hex bolt from the top of the motor cover.



NOTE

The M5 hex bolt can be removed easily by pushing in the motor cover deeply.



Step 2 Bolt removal



3 *Pull out the cover.*

**NOTE**


Gradually pull out the cover so that the brake release switch is not caught in the motor connector.

4 *Disconnect the robot cable connector.*

**CAUTION**

Be careful not to drop any mounting screw as it is small.

▶ Step 3 *Cover pull-out*



▶ Step 4 *Connector disconnection*



- 5 **Remove four power cable connector mounting screws from the connector.**

**CAUTION**

Be careful not to drop any screw you have removed as it is small.


- 6 **Pull out the brake release cable, brake cable and encoder cable from the cap in order.**

- 7 **Finally, pull out the power cable, from which the screws have been removed. Gradually disconnect the power cable in the orientation shown in the picture.**

**NOTE**

As the inlet is narrow, pull out the cable by deforming the inlet.


- Step 5 **Mounting screw removal**



- Step 6 **Cable pull-out from the cap**



- Step 7 **Power cable pull-out**



1.2.2 α , β and γ -axes cover attachment procedure

Attach the cover using the opposite of the procedure used for removal.



WARNING

THE SAME TYPE OF MOTOR CABLE AND ENCODER CABLE IS USED FOR THE α , β , AND γ -AXES. CONNECT THE CABLES SO THAT THEY MATCH THE RESPECTIVE AXES AT THE CONTROLLER (DRIVER). IF THE CABLES ARE CONNECTED INCORRECTLY, THE ROBOT WILL NOT OPERATE CORRECTLY TO RESULT IN POSSIBLE DANGER.

1

Remove four power cable connector mounting screws from the connector.



CAUTION

Be careful not to drop any screw you have removed as it is small.

2

Insert the power cable, from which the screws have been removed, through the hole at the upper portion of the cap. Gradually insert the power cable in the orientation shown in the picture.



NOTE


As the inlet is narrow, pull out the cable by deforming the inlet.

3

Insert the encoder cable, brake cable and brake release cable (prepared by the user) in order.


Step 1

Mounting screw removal



Step 2

Power cable insertion



Step 3

Each cable insertion



- 4 *Pass the cables through the hole outside the motor cover.*



NOTE

Make sure that the rubber seal is attached to the cover.

- 5 *Connect the brake release switch connector.*


- 6 *Connect the cable connector to the motor connector.*



WARNING

CONNECT THE α , β AND γ -AXES ROBOT CABLES SO THAT THEY MATCH THE RESPECTIVE AXES AT THE CONTROLLER (DRIVER). IF THE CABLES ARE CONNECTED INCORRECTLY, THE ROBOT WILL NOT OPERATE CORRECTLY TO RESULT IN POSSIBLE DANGER.

- Step 4 **Cables passing through the motor cover**



- Step 5 **Brake release connector connection**



- Step 6 **Connector connection**



7 *Attach the motor cover.*




CAUTION


Attach the motor cover so that the brake release switch on the motor cover does not interfere with the motor connector.

8 *Insert the motor cover until the stepped portion of the rubber seal.*

► Step 7 Motor cover attachment



► Step 8 Motor cover insertion



9

Adjust the motor cover position and then secure with the M5 hex bolt(s).

Adjust the motor cover position and then screw in two M5 hex bolts to secure.

Ensure that the motor cover has been securely attached.

It will not be possible to insert the bolts if the motor cover position and tapping positions for the M5 hex bolts are not aligned.



► Step 9

Hex bolt attachment



10 *Attach the cap to the motor cover.***NOTE**

Attaching the cap from the rear will ensure good workability.

11 *Attach the grommet to the robot cables.***12** *Attach the duct to the robot cables.*
Insert the robot cables through the slit in the duct.**13** *Attach the duct to the cap.*▶ **Step 10** **Cap attachment**▶ **Step 11** **Grommet attachment**▶ **Step 12** **Duct attachment**▶ **Step 13** **Cap attachment**

2. Detaching or attaching the θ -axis cover


To detach the covers, remove the bolts and screws shown in the below picture.



WARNING

- IF THE COVERS ARE REMOVED FOR MAINTENANCE WORK, BE SURE TO RETURN THEM TO THEIR ORIGINAL POSITIONS USING THE BOLTS USED TO SECURE THEM.
- IF ANY OF THE BOLTS BECOME LOST, USE THE SPECIFIED BOLTS AND QUANTITIES TO SECURE THE COVERS WHILE REFERRING TO THE BELOW PICTURE.
- IF THE COVERS ARE NOT SECURED FIRMLY, NOISE MAY OCCUR, THE COVERS MAY DROP AND FLY OUT, HANDS MAY BECOME ENTANGLED IN THE DRIVE UNIT DURING TEACHING, OR COME INTO CONTACT WITH THE HOT DRIVE UNIT, CAUSING BURNS. OBSERVE THESE CAUTIONS STRICTLY TO PREVENT SUCH TROUBLE.

θ -axis



1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty	Remarks
1	θ -axis motor cover	KDL-M182E-00x		1	
2	θ -axis motor cover attachment bolt	90780-04010	M4, length 10	6	
3	O-ring	KN5-M2144-00x		1	
4	Washer	KDL-M1861-00x		6	
5	θ -axis harness (cover side)	KDL-M4813-00x		1	Motor cable
6		KDL-M4814-00x		1	Encoder cable
7	θ -axis harness securing bolt	91380-03006	M3, length 6	8	Secured to motor cover
8	θ -axis harness (motor side)	KDL-M4811-00x		1	Motor cable
9		KDL-M4812-00x		1	Encoder cable
10	Earth bolt	97980-04308		2	

2. Tools to be prepared

Name	Part. No.	Manufacturer	Remarks
Cleaning wipe			
Phillips screwdriver			
Hex wrench set			
Spanner	No. 7		
Thread sealer	Loctite 241	Henkel	Medium strength type (blue)

2.1 θ -axis motor cover removal



CAUTION



When removing the θ -axis motor cover, first disconnect the harness from the outside of the motor cover and then remove the movable base from the α , β and γ -axis shafts before proceeding. There is a risk of bodily injury if the harness is damaged or a robot malfunction occurs inside the robot movement range. Take care not to cover the washers attached to the θ -axis motor cover.

- 1 **Remove the M4 hex bolts securing the θ -axis motor cover and movable base.**
Loosen with a spanner and then remove.
- 2 **Lift the θ -axis motor cover from the movable base.**
- 3 **Disconnect the cable connectors inside the cover.**
Disconnect the motor cable connector and encoder cable connector.
- 4 **Remove the two earth bolts.**
- 5 **Remove the θ -axis motor cover.**

Step 1 M4 hex bolt removal



Step 2-4 Inside the motor cover



Remove the harness from the inside of the θ -axis motor cover (when replacing the harness inside the motor cover).



The motor cable and encoder cable will both be removed.

Remove the four length 6 M3 hex socket head bolts from the connector connection on the outside of the θ -axis motor cover, and pull the harness toward the outside of the cover.

If replacing the harness inside the cover, also replace both of the connector O-rings.


► Step 6

Harness removal (motor cable side)



► Step 6

Harness removal (encoder cable side)




7

Disconnect the motor cable and encoder cable from the θ -axis motor (when replacing the motor, speed reduction gear).

▶ Step 7

Motor side motor cable, encoder cable removal



2.2 θ -axis motor cover attachment

Attach the cover using the opposite of the procedure used for removal.



CAUTION

When attaching the θ -axis motor cover, first disconnect the harness from the outside of the motor cover and then remove the movable base from the α , β and γ -axis shafts before proceeding. There is a risk of bodily injury if the harness is damaged or a robot malfunction occurs inside the robot movement range.

1

Connect the motor cable and encoder cable to the θ -axis motor (when replacing the motor, speed reduction gear).

When attaching the θ -axis motor cover, secure the harness with cable ties to prevent them from moving.

2

Connect the harness (motor side) on the inside of the θ -axis motor cover.

Attach the connector side of the harness so that it is facing the outside of the cover.

Ensure that the mark on the connector is facing upward.

If replacing the harness on the inside of the cover, fit an O-ring to the connector.

Secure the connector connection on the outside of the θ -axis motor cover with the four length 6 M3 hex socket head bolts.

- Tightening torque: 2Nm




CAUTION

If replacing harness on the inside of the cover, it will not be possible to guarantee waterproofing properties if the connector O-rings are not fitted, and therefore caution is advised.



▶ Step 1

Motor side motor cable, encoder cable connection



▶ Step 2

Harness connection (motor cable side)



3

Connect the cable at the encoder side in the same manner as that described in Step 2.

Attach the cable connector so that the mark (groove) is facing upward.





CAUTION

If replacing cables on the inside of the cover, it will not be possible to guarantee waterproofing properties if the connector O-rings are not fitted, and therefore caution is advised.

- Tightening torque: 2Nm

Step 3

Harness connection (encoder cable side)



4 **Connect the cable connectors to the inside of the cover.**

Connect both the motor cable connector and encoder cable connector.

5 **Attach the two earth bolts.**

At this time, do not use any thread sealer.



WARNING

FAILURE TO ATTACH THE EARTH BOLTS MAY RESULT IN ELECTRIC SHOCK.

6 **Replace the θ -axis motor cover.**






CAUTION

- Route the cables on the inside of the θ -axis motor cover so that they do not contact the O-rings. Prolonged contact with the O-rings may cause them to shift, leading to a possible loss of waterproofing properties.
- Do not bend the harness excessively, or apply excessive force when replacing the θ -axis motor cover. Failure to observe this may result in harness damage.

7 **Secure the θ -axis motor cover to the movable base.**

Attach the washers to the θ -axis motor cover, fit the M4 hex bolts to the washers, and then tighten with a spanner.

Step 4-6 **Harness routing inside motor cover**



Step 7 **Washer attachment**



Chapter 3 Periodic inspection

Contents

1. Overview	3-1
2. Daily inspection	3-2
3. Monthly inspection	3-3
4. Six-month inspection	3-4

1. Overview

Daily and periodic inspection of the OMRON robot is essential in order to ensure safe and efficient operation. This chapter describes the periodic inspection items and procedures for the R6Y3 Series robots.

Periodic inspection includes:

- Daily inspection
- Monthly inspection
- 6-month inspection

Make sure that you thoroughly understand details of the inspection and follow the procedures and precautions explained in this chapter.



WARNING

SPECIALIZED TECHNICAL KNOWLEDGE AND SKILLS ARE REQUIRED WHEN ARMS, SHAFTS AND THE θ -AXIS ASSEMBLY ARE DETACHED TO ADJUST OR MAINTAIN. OPERATIONS PERFORMED BY WORKERS WHO DO NOT POSSESS THESE SPECIAL KNOWLEDGE AND SKILLS MAY LEAD TO DANGER. THIS WORK MUST BE CARRIED OUT BY REFERENCING THIS MANUAL BY SUFFICIENTLY SKILLED AND QUALIFIED PERSONNEL IN ACCORDANCE WITH THE LAWS AND REGULATIONS OF EACH COUNTRY.



WARNING

- WHEN INSPECTION IS REQUIRED INSIDE THE SAFETY ENCLOSURE, ALWAYS TURN OFF THE CONTROLLER AND ALSO THE EXTERNAL SWITCH BOARD.
- IF THE INSPECTION OR MAINTENANCE PROCEDURE CALLS FOR OPERATION OF THE ROBOT, STAY OUTSIDE THE SAFETY ENCLOSURE.
- PLACE A SIGN INDICATING THE ROBOT IS BEING INSPECTED, TO KEEP OTHERS FROM OPERATING THE CONTROLLER SWITCH OR OPERATION PANEL.
- IF CHECKING OPERATION FOLLOWING INSPECTION, REFER TO THE CONTROLLER MANUAL.



CAUTION

Use only the lubricants specified by your distributors.

2. Daily inspection

The following is an inspection list that must be performed every day before and after operating the robot.

■ Inspection to be performed with the controller turned off

Be sure to inspect with controller power off.

- 1 ***Place a sign indicating the robot is being adjusted.***
Place a sign indicating the robot is being inspected, to keep others from operating the controller switch.
- 2 ***Perform the daily inspection.***
Enter the safety enclosure and check the following points.

Checkpoint	Procedure
Robot cable User cable and wiring	Check for scratches, dents and excessive bend and kinks. (If the robot cable is damaged, contact your distributor.)
Regulator, joints, air tube, solenoid valve, air cylinder	<ul style="list-style-type: none">• Check air pressure.• Check for air leaks.• Check drain.• Check air filter for clogging or damage.
Robot exterior	Check for damage. (If a damage is found, contact your distributor.)
Plastic bearing (link ball sliding surface)	<ul style="list-style-type: none">• Check for deformation, dents.• Check that wear amount is 0.5mm or less.
Plastic bearing (spring mechanism plate sliding surface)	<ul style="list-style-type: none">• Check for deformation, breakage. (Check for cracks.)• Check that wear amount is 0.5mm or less.
Shaft	Check for deformation.
Spring cover	Check for damage. (Check for guide clip breakage.)
Inside spring cover (spring, plate, etc.)	<ul style="list-style-type: none">• Check for deformation.• Check the spring to see if it is overstretched. (Normal length: 32.5±1mm)• Check for M3 screw looseness.
θ-axis assembly seal	Check for any grease leaking from the coupling.

■ Adjustment and parts replacement



CAUTION

- If adjustment or replacement is deemed necessary following inspection, turn off the controller power before entering the safety enclosure to carry out work. If checking operation after work is complete, do so in accordance with “■ Inspection to be performed with the controller turned off” described above.
- If robot repair or part replacement is deemed necessary, contact your distributor. Such repair and part replacement requires specialized technical knowledge, and must not be carried out by the user.

3. Monthly inspection

This inspection is carried out once a month.

Pay attention to the following if applying grease to the θ -axis assembly.



WARNING

PRECAUTIONS WHEN HANDLING GREASE:

- INFLAMMATION MAY OCCUR IF THIS GETS IN THE EYES. BEFORE HANDLING THE GREASE, WEAR YOUR SAFETY GOGGLES TO ENSURE THE GREASE WILL NOT COME IN CONTACT WITH THE EYES.
- USE FOOD GREASE (CASSIDA GREASE, EPS2) WHEN USING THE ROBOT AT FOOD PLANTS.
- INFLAMMATION MAY OCCUR IF THE GREASE COMES INTO CONTACT WITH SKIN. BE SURE TO WEAR PROTECTIVE GLOVES TO PREVENT CONTACT WITH SKIN.
- DO NOT TAKE ORALLY OR EAT. (EATING WILL CAUSE DIARRHEA AND VOMITING.)
- KEEP OUT OF THE REACH OF CHILDREN.
- DO NOT HEAT THE GREASE OR PLACE NEAR AN OPEN FLAME SINCE THIS COULD LEAD TO SPARKS AND FIRES.

EMERGENCY TREATMENT:

- IF THIS GREASE GETS IN THE EYES, WASH LIBERALLY WITH PURE WATER FOR ABOUT 15 MINUTES AND CONSULT A PHYSICIAN FOR TREATMENT.
- IF THIS GREASE COMES IN CONTACT WITH THE SKIN, WASH AWAY COMPLETELY WITH SOAP AND WATER.
- IF TAKEN INTERNALLY, DO NOT INDUCE VOMITING BUT PROMPTLY CONSULT A PHYSICIAN FOR TREATMENT.

DISPOSING OF GREASE AND THE CONTAINER:

- PROPER DISPOSAL IS COMPULSORY UNDER FEDERAL, STATE AND LOCAL REGULATIONS. TAKE APPROPRIATE MEASURES IN COMPLIANCE WITH LEGAL REGULATIONS.

■ Inspection to be performed with the controller turned off

Be sure to perform the inspection with controller power off.

1

Place a sign indicating the robot is being adjusted.

Place a sign showing that the robot is being inspected, to keep others from operating the controller switch.

2

Perform the inspection.

Enter the safety enclosure and check the following points.

Checkpoint	Procedure
θ -axis assembly seals (large) (small)	<ul style="list-style-type: none">• Check for deformation, damage or grease run-out. If the grease runs out, apply the grease.• Check if the component may not be picked up (pickup force lowers). If the component is not picked up, replace the seal with a new one. The leak amount for 30 sec. is 0.05MPa or less in the 0.6MPa-sealed state.• For details about how to replace the seal, refer to Chapter 8 "0-axis seal, O-ring replacement".
Plastic bearing (link ball sliding part) (plate installation part)	Measure the worn-out amount. For details about how to measure the worn-out amount, see "2. Plastic bearing inspection" in Chapter 7. Replace the plastic bearing based on 1500 operation hours or 10.8 million operation cycles. (Plate installation part is 3 times longer than this reference value.)
Spring cover	Check for looseness.



CAUTION

When performing the inspection, replace necessary parts with new ones according to the inspection contents and inspection references. If the robot is operated continuously without part replacement, this may cause the robot to malfunction.

4. Six-month inspection

Take the following precautions when performing 6-month inspection.

■ Inspection to be performed with the controller turned off

Be sure to perform the inspection with controller power off.

- 1 ***Place a sign indicating the robot is being adjusted.***
Place a sign showing that the robot is being inspected, to keep others from operating the controller switch.
- 2 ***Perform the inspection.***
Enter the safety enclosure and check the following points.

Checkpoint	Procedure
Arm	Check for deformation, damage.
Link ball	Check for damage.
Major robot body bolts and screws (Those exposed on outside)	Check for looseness and tighten if necessary. (See the below table)
Speed reduction gear	Check the speed reduction gear for large noise or rattle during operation. If large noise or rattle is found, replace the speed reduction gear while referring to "2. Speed reduction gear and arm replacement procedure" in Chapter 10.

Bolt tightening torque

Bolt size	Tightening torque (kgfcm)	Tightening torque (Nm)
M3 set screw	20	2
M3	20	2
M4	46	4.5
M4 4-axis specification α -axis arm harness clamp	20	2
M6	156	15.3
M8	380	37
M8 motor mounting bolt	194	19
M10	540	53
M12	1310	128

■ Adjustment and parts replacement



CAUTION

- If adjustment or replacement is deemed necessary following inspection, turn off the controller power before entering the safety enclosure to carry out work. If checking operation after work is complete, do so in accordance with "■ Inspection to be performed with the controller turned off" described above.
- If robot repair or part replacement is deemed necessary, contact your distributor. Such repair and part replacement requires specialized technical knowledge, and must not be carried out by the user.

Chapter 4

Adjusting the origin

Contents

1. Adjusting the origin	4-1
1.1 Adjusting the α, β and γ-axes origin position	4-2
1.1.1 R6Y3[]110	4-2
1.1.2 R6Y3[]065	4-5
1.2 Adjusting the 0-axis origin position (4-axes specification only)	4-8

1. Adjusting the origin

The R6Y3 Series uses a calibration tool to mechanically adjust the origin position of the α , β , γ and θ -axes. Be sure to adjust the origin position in the following cases:

1. If the origin position is lost after disconnecting the robot cable connecting the controller with robot
2. If the origin position is lost after disconnecting the θ -axis harness from the θ -axis motor cover connectors and controller side robot cable connector
3. If the motor is replaced (same reason as above)
4. If any of the axis arms are removed



CAUTION

- If any of the above situations occur after purchasing the robot, it is necessary to adjust the origin position(s) using the calibration tool. (The robot origin positions are adjusted at the factory.)
- Always use the calibration tool to perform origin position adjustment. If adjusted without using the calibration tool, the position will shift, resulting in abnormal robot operation, leading to robot damage and possible bodily injury.

This manual describes the origin position adjustment method using the calibration tool.

1. Replacement parts

R6Y3[]110

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty	Remarks
1	Origin position jig	KDL-M1501-00x		1	For α , β and γ -axes
2		KDL-M1501-10x		1	For θ -axis

R6Y3[]065


	Part Name	OMRON Part No.	Part No. / Specs	Q'ty	Remarks
1	Origin position jig	KDL-M501-30x		1	For α , β and γ -axes
2		KDL-M501-10x		1	For θ -axis

2. Tools to be prepared

Name	Part No.	Manufacturer	Remarks
Cleaning wipe			
Hex wrench set	No. 10		

α , β and γ -axes origin positions





1 *Post a sign indicating that the robot is being adjusted.*

Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.

2 *Enter the safety enclosure.*

3 *Secure the calibration tool to the base.*

Secure the end of the calibration tool to the jig attachment holes on the base with the M12 hex socket head bolts provided.

The arm is moved at Step 5, and if it hits the calibration tool at that time, temporarily secure the tool, move the arm to a position above the tool at Step 5, apply the brake, secure the tool, and then perform Steps 4 and 5.

4 *Release the motor brake for α -axis.*




CAUTION

When performing origin position adjustment, release the brake one axis at a time. Never release the brake for all three axes at the same time.

Doing so will result in a drop in origin position accuracy, leading to malfunctions.


Step 3 **Securing the calibration tool**



- 5 *Move the arm slowly until the link ball on the end of the arm contacts the top of the calibration tool.*
- 6 *Apply the motor brake for α -axis .*
- 7 *Remove the calibration tool from the base.*

By loosening the M12 hex socket head bolt on the end of the calibration tool, the tool comes away from the arm link ball. Confirm this and then remove the calibration tool.
- 8 *Perform the procedure in Steps 3 to 7 for the γ and β -axes also.*


► Step 5 Position link ball against tool.



1.1.2 R6Y3[]065

The α , β and γ -axes origin positions are shown in the below picture.
Adjust each axis to its respective origin positions using the calibration jig.

α , β and γ -axes origin positions



Calibration tool (α , β and γ -axes)



- 1 ***Post a sign indicating that the robot is being adjusted.***
Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.

- 2 ***Enter the safety enclosure.***

- 3 ***Secure the calibration tool to the base.***
Secure the tip of the calibration tool to the jig mounting hole in the top surface of the base with the knob attached to the calibration tool.
The arm is moved at Step 5, and if it hits the calibration tool at that time, temporarily secure the tool, move the arm to a position above the tool at Step 5, apply the brake, secure the tool, and then perform Steps 4 and 5.

- 4 ***Release the motor brake for α -axis.***



CAUTION

When performing origin position adjustment, release the brake one axis at a time. Never release the brake for all three axes at the same time.

Doing so will result in a drop in origin position accuracy, leading to malfunctions.

Step 3 Securing the calibration tool



5 *Move the arm slowly until the link ball on the end of the arm contacts the top of the calibration tool.*


6 *Apply the motor brake for α -axis .*

7 *Remove the calibration tool from the base.*

By loosening the M12 hex socket head bolt on the end of the calibration tool, the tool comes away from the arm link ball. Confirm this and then remove the calibration tool.

8 *Perform the procedure in Steps 3 to 7 for the γ and β -axes also.*

► Step 5 Position link ball against tool.



1.2 Adjusting the θ -axis origin position (4-axes specification only)

The θ -axis origin position reference is the position in which the tool flange dowel hole is facing the α -axis. The axis is adjusted to the reference position when shipped from the factory, however, the position may shift slightly. When installing the robot for the first time, it is necessary to use the calibration tool to adjust the origin position.




CAUTION

The tool flange is fixed on 3-axes robots, and therefore it is only necessary to attach the movable base in the correct direction. Refer to "1.2 Attaching the shafts, movable base, and spring covers" in Chapter 5 for details on attaching the movable base. With the 4-axes robot, it is necessary to adjust the θ -axis origin position in addition to attaching the movable base in the correct direction. The θ -axis origin position should generally never be changed. If changed, the axis may no longer move in the right direction.

- 1 ***Post a sign indicating that the robot is being adjusted.***
Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.
- 2 ***Enter the safety enclosure.***
- 3 ***Secure the calibration tool.***
The θ -axis origin position is the position in which the tool flange dowel hole is facing the α -axis.

θ -axis origin position



- 4 ***Align the θ -axis calibration tool pin with the tool flange dowel hole.***

Securing the calibration tool

Secure at these two points.

θ -axis calibration tool



Dowel hole

Knock-pin

θ -axis calibration tool



Chapter 5

Shaft, movable base and spring cover replacement

Contents

1.	Shaft, movable base and spring cover replacement procedure	5-1
1.1	Detaching the shafts, movable base and spring cover	5-3
1.2	Attaching the shafts, movable base and spring covers	5-5
1.2.1	R6Y30110S03067NJ5, R6Y30065S02067NJ5 (3-axes specification)	5-5
1.2.2	R6Y31110L03067NJ5, R6Y31110H03067NJ5, R6Y31065L02067NJ5, R6Y31065H02067NJ5 (4-axes specification)	5-7
1.2.3	Attaching the spring cover (Reinforced Spring Cover common to 3-axes and 4-axes)	5-10
2.	Movable base link ball replacement	5-12

1. Shaft, movable base and spring cover replacement procedure

1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty	Remarks
1	Spring cover	KDL-M1542-00x		2	Upper side cover
1		S02D-MR129-00x		2	A cover (Reinforced Spring Cover)
2		KDL-M1543-00x		2	Lower side cover
2		S02D-MR131-00x		2	B cover (Reinforced Spring Cover)
3	Block	S02D-MR126-00x		2	The attachment part may vary depending on the upper and lower positions (Reinforced Spring Cover)
4	Hex socket head bolt	91380-03006		8	(Reinforced Spring Cover)
5	Plate	S02D-MR127-00x		2	Plate A (Reinforced Spring Cover)
5		S02D-MR128-00x		2	Plate B (Reinforced Spring Cover)
6	Shaft assembly	KDL-M150G-01x		1	R6Y3[]110: β , γ -axes (common), α -axis (3-axes specifications)
(1)	Shaft assembly 1	KDL-M150H-01x		2	
(2)	Cover assembly	KDL-M1540-00x		2	
(2)		S02D-MR132-00x		1	Reinforced Spring Cover upper portion
(2)		S02D-MR132-10x		1	Reinforced Spring Cover lower portion
6	Shaft assembly	KDL-M150G-21x		1	R6Y3[]065: β , γ -axes (common), α -axis (3-axes specifications)
(1)	Shaft assembly 1	KDL-M150H-31x		2	
(2)	Cover assembly	KDL-M1540-00x		2	
(2)		S02D-MR132-00x		1	Reinforced Spring Cover upper portion
(2)		S02D-MR132-10x		1	Reinforced Spring Cover lower portion
7	Shaft assembly	KDL-M150G-11x		1	R6Y3[]110: α -axis (4-axes specifications)
(1)	Shaft assembly 1	KDL-M150H-31x		2	
(2)	Shaft assembly 1	KDL-M150H-31x		2	
(3)	Cover assembly	KDL-M1540-00x		2	
(3)		S02D-MR132-00x		1	Reinforced Spring Cover upper portion
(3)		S02D-MR132-10x		1	Reinforced Spring Cover lower portion
7	Shaft assembly	KDL-M150G-31x		1	R6Y3[]065: α -axis (4-axes specifications)
(1)	Shaft assembly 1	KDL-M150H-31x		2	
(2)	Shaft assembly 1	KDL-M150H-31x		2	
(3)	Cover assembly	KDL-M1540-00x		2	
(3)		S02D-MR132-00x		1	Reinforced Spring Cover upper portion
(3)		S02D-MR132-10x		1	Reinforced Spring Cover lower portion

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty	Remarks
1	Shaft assembly 1	KDL-M150H-01x		1	R6Y3[]110: β , γ -axes (common) α -axis (3-axes specification)
(1)	Shaft A	KDL-M150A-01x		1	
(2)	Plastic bearing	KDL-M152J-01x		2	
1	Shaft assembly 1	KDL-M150H-31x		1	R6Y3[]065: β , γ -axes (common) α -axis (3-axes specification)
(1)	Shaft A	KDL-M150A-20x		1	
(2)	Plastic bearing	KDL-M152J-01x		2	
1	Shaft assembly 1	KDL-M150H-11x		1	R6Y3[]110: α -axis motor cable side (4-axes specification)
(1)	Shaft A	KDL-M150E-02x		1	
(2)	Plastic bearing	KDL-M152J-01x		2	
1	Shaft assembly 1	KDL-M150H-41x		1	R6Y3[]065: α -axis motor cable side (4-axes specification)
(1)	Shaft A	KDL-M150E-10x		1	
(2)	Plastic bearing	KDL-M152J-01x		2	
1	Shaft assembly 1	KDL-M150H-21x		1	R6Y3[]110: α -axis encoder cable side (4-axes specification)
(1)	Shaft A	KDL-M150F-02x		1	
(2)	Plastic bearing	KDL-M152J-01x		2	
1	Shaft assembly 1	KDL-M150H-51x		1	R6Y3[]065: α -axis encoder cable side (4-axes specification)
(1)	Shaft A	KDL-M150F-10x		1	
(2)	Plastic bearing	KDL-M152J-01x		2	

1.1 Detaching the shafts, movable base and spring cover

With the R6Y31110L03067NJ5, R6Y31110H03067NJ5, R6Y31065L02067NJ5 and R6Y31065H02067NJ5 (4-axes specification) robots, the harness protrudes from the α -axis shaft. Shaft, movable base, and spring cover detachment is the same as that for the 3-axes specification robot.



CAUTION

It is necessary to enter the safety enclosure in order to detach or attach the shafts, movable base, or spring covers, and therefore the controller power must be turned off beforehand.

1

Post a sign indicating that the robot is being adjusted.

Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.

2

Enter the safety enclosure.

3

Remove the spring covers.

There are a total of six spring covers: one at the arm, and one at the movable base for each of the three axes.

There is a top spring cover and bottom spring cover, with the top cover being wider.

The spring covers are held together with clips on the inside.

Pull the bottom cover down at the arm side and pull the top cover up at the movable base side to remove the spring cover.



CAUTION

The Reinforced Spring Cover is attached in a way different from the normal spring cover.

For detailed about how to attach or detach the Reinforced Spring Cover, see "1.2.3 Attaching the spring cover (Reinforced Spring Cover common to 3-axes and 4-axes)" in this chapter.



CAUTION

Use both hands when removing the spring covers. Use one hand for removal and the other to stop the bottom cover falling.

If the spring cover falls and is damaged, the robot may operate abnormally.

4

Remove the end effector.

Refer to "6. Attaching the end effector" in Chapter 2 of the installation manual for details.

5

Disconnect the air tube from the joint on the user tubing.





CAUTION

Do not carry out replacement work with the air tube still attached to the joint on the user tubing.


By doing so, the air tube may bend.

Step 3

Spring cover removal



Arm side



Base side

6

Disconnect the θ -axis connection connector of the α -axis arm.
(R6Y31110L03067NJ5,
R6Y31110H03067NJ5,
R6Y31065L02067NJ5 and
R6Y31065H02067NJ5 only)

Turn the connector 90° counterclockwise and pull it out.

7

Disconnect the harness at the movable base side from the motor cover. (R6Y31110L03067NJ5,
R6Y31110H03067NJ5,
R6Y31065L02067NJ5 and
R6Y31065H02067NJ5 only)

The harness is disconnected by rotating the connector as shown with the arrow on the cable connector and then disconnecting it from the motor cover.

8

Remove the shafts.

Remove the shafts from the arm and movable base link balls.

When doing so, the link balls can be stretched by hand at the end of the shaft as shown in the picture on the right.

When removing the shafts from the movable base, disconnect the θ -axis robot cable from the motor beforehand.



CAUTION

- Remove the spring covers before removing the shafts. The spring covers may be damaged if work is carried out without removing them.
- Take care not to pull the springs on the shafts too much. If stretched too far, the springs may not return to their original shape, possibly leading to abnormal robot movement.
- With the R6Y31110L03067NJ5, R6Y31110H03067NJ5, R6Y31065L02067NJ5 and R6Y31065H02067NJ5 the harness is attached to the α -axis shaft. If the α -axis shaft is removed from the movable base without disconnecting the θ -axis harness from the motor, the cable will be pulled and possibly damaged, leading to potential defects. Furthermore, care should be taken not to drop the movable base.

Step 6

Arm side harness



Step 7

Harness removal at movable base side



Step 8

Shaft removal



1.2 Attaching the shafts, movable base and spring covers



CAUTION

It is necessary to enter the safety enclosure in order to detach or attach the shafts, movable base, or spring covers, and therefore the controller power must be turned off beforehand.

1.2.1 R6Y30110S03067NJ5, R6Y30065S02067NJ5 (3-axes specification)

The replacement procedure for the shafts, movable base, and spring covers is the same as that for the α , β and γ -axes.

1

Post a sign indicating that the robot is being adjusted.

Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.

2

Enter the safety enclosure.

3

Attach the shafts.

Attach the shafts while ensuring to hook the shaft plastic bearings onto the arm and movable base link balls. The link balls can be stretched by hand at the end of the shaft as shown in the picture.

The depression on the shafts for spring cover attachment should face upward.

The movable base attachment direction is as shown in the picture. Refer to "1.2 Adjusting the θ -axis origin position" in Chapter 4 for details.




CAUTION

By attaching the shafts with hands placed anywhere other than the shaft end, the joint between the shaft and shaft end may deform, possibly leading to malfunction. Ensure to place hands on the end of the shaft as shown in the picture on the right.

Take care not to pull the springs on the shafts too much. If stretched too far, the springs may not return to their original shape, possibly leading to malfunction.


Step 3 Shaft attachment



Movable base side



Arm side



4

Attach the spring covers.

There are a total of six spring covers: one at the arm, and one at the movable base for each of the three axes.

The top and bottom positions of the spring covers are fixed.



If the shaft direction is correct at Step 3, the cover attached at the top will be wide as shown in the picture.

The spring covers come as a top and bottom set when shipped. Attach the covers so that they snap together at the guide clips.

**CAUTION**

The Reinforced Spring Cover is attached in a way different from the normal spring cover.

For detailed about how to attach or detach the Reinforced Spring Cover, see "1.2.3 Attaching the spring cover (Reinforced Spring Cover common to 3-axes and 4-axes)" in this chapter.

**Step 4****Spring cover attachment**

1.2.2 R6Y31110L03067NJ5, R6Y31110H03067NJ5, R6Y31065L02067NJ5, R6Y31065H02067NJ5 (4-axes specification)

With the R6Y31110L03067NJ5, R6Y31110H03067NJ5, R6Y31065L02067NJ5 and R6Y31065H02067NJ5 (4-axes specification) robots, the harness protrudes from the α -axis shaft.

Shaft, movable base, and spring cover attachment is the same as that for the 3-axes specification robot.

- 1 **Post a sign indicating that the robot is being adjusted.**
Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.
- 2 **Enter the safety enclosure.**
- 3 **Attach the shafts.**
Attach the shafts while ensuring to hook the shaft plastic bearings onto the arm and movable base link balls. The link balls can be stretched by hand at the end of the shaft as shown in the picture.
The depression on the shafts for spring cover attachment should face upward.
The movable base attachment direction is as shown in the picture. Refer to "1.2 Adjusting the θ -axis origin position" in Chapter 4 for details.




CAUTION


By attaching the shafts with hands placed anywhere other than the shaft end, the joint between the shaft and shaft end may deform, possibly leading to malfunction. Ensure to place hands on the end of the shaft as shown in the picture on the right.

Take care not to pull the springs on the shafts too much. If stretched too far, the springs may not return to their original shape, possibly leading to malfunction.


Step 3 Shaft attachment



Movable base side



Arm side



Attach the spring covers.

There are a total of six spring covers: one at the arm, and one at the movable base for each of the three axes.

The top and bottom positions of the spring covers are fixed.




If the shaft direction is correct at Step 3, the cover attached at the top will be wide as shown in the picture.

The spring covers come as a top and bottom set when shipped. Attach the covers so that they snap together at the guide clips.

**CAUTION**

The Reinforced Spring Cover is attached in a way different from the normal spring cover.

For detailed about how to attach or detach the Reinforced Spring Cover, see "1.2.3 Attaching the spring cover (Reinforced Spring Cover common to 3-axes and 4-axes)" in this chapter.

**Step 4****Spring cover attachment**

5

Connect the harness on the arm side.

The connector type of the motor cable is different from that of the encoder cable. Connect the cables so that they are not twisted forcibly.
Turn the connector clockwise to lock it after inserted.



**CAUTION**

When performing the operation without locking the connector, the cable may come off and have faulty wiring.

6

Attach the harness at the movable base side to the motor cover.

Ensure that the movable base and α -axis shaft attachment directions are correct.
Align the arrow on the cable connector with the connector mark on the motor cover and attach.
Attach both the motor cable and encoder cable to their respective connectors.


▶ **Step 5****Connecting the harness on the arm side**▶ **Step 6****Harness attachment at movable base side**

5

Shaft, movable base and spring cover replacement

1.2.3 Attaching the spring cover (Reinforced Spring Cover common to 3-axes and 4-axes)

The upper cover attaching (detaching) procedures may vary from the lower cover attaching (detaching) procedures.



- 1 **Press-fit the A cover of the upper cover into the spring part from the upper portion.**




CAUTION

If the shaft is installed upside down, the cover cannot be attached.

- 2 **Press-fit the B cover of the upper cover from the lower portion and secure it together with the plate B using the M3 hex socket head bolts.**
Tightening torque: 2Nm

Step 1 Upper cover press-fitting



Step 2 Upper cover securing



- 3 **Press-fit the A cover of the lower cover into the spring part from the upper portion.**



CAUTION

If the shaft is installed upside down, the cover cannot be attached.

- 4 **Press-fit the B cover of the lower cover from the lower portion and secure it together with the plate A using the M3 hex socket head bolts.**
Tightening torque: 2Nm



CAUTION

Detach the cover in the reverse order of attachment.

- Remove the M3 hex socket head bolts from the lower portion to detach the upper cover.
- Remove the M3 hex socket head bolts from the upper portion to detach the lower cover.




CAUTION

Hold the lower clamp bolts of the upper cover or the B cover of the lower cover by hand so that any part does not drop.

Step 3

Lower cover press-fitting



Step 4

Lower cover securing



2. Movable base link ball replacement

The link ball attachment method is described below.

Remove the link balls using the opposite of the method used for attachment.

1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty	Remarks
1	Link ball	KDL-M152A-00x		6	Movable base part

2. Tools to be prepared

Name	Part. No.	Manufacturer	Remarks
Cleaning wipe			
Spanner	No. 12		
Thread sealer	Loctite 241	Henkel	Medium strength type (blue)

1 *Apply the thread sealer to the screw part of the link ball thinly.*


Use Henkel Loctite 241 (blue).

2 *Attach a link ball at six locations on the movable base.*

3 *Tighten the link balls with a tool.*

• Tightening torque: 20Nm

► Step 2 Link ball attachment



► Step 3 Tightening



Chapter 6

Spring mechanism replacement

Contents

1. Spring mechanism replacement procedure	6-1
1.1 Spring mechanism removal	6-2
1.2 Spring mechanism attachment	6-3

1. Spring mechanism replacement procedure

1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty*1	Remarks
(1)	Spring	KDL-M152M-00x		2	
(2)	Plate	KDL-M1534-00x		4	
(3)	Plastic bearing	KDL-M152K-00x		4	
(4)	Plastic block	KDL-M153A-00x		2	
(5)	Screw	98980-03006	M3, length 6	4	

*1 : Quantity per axis

2. Tools to be prepared

Name	Part No.	Manufacturer	Remarks
Phillips screwdriver			

1.1 Spring mechanism removal

1 ***Remove the shaft from the arm and movable base.***

Refer to “Shaft, movable base, and spring cover replacement” in Chapter 5 for details.

2 ***Remove the M3 screws at four locations.***

By removing the screws, the springs, plate assembly, and plastic blocks come free of the shaft.

3 ***Remove the springs.***


Perform this procedure only when replacing springs.

4 ***Remove the press-fit plastic bearings.***


Perform this procedure only when replacing plastic bearings.

Refer to “Plastic bearing replacement” in Chapter 7 for details.

► Step 1 **Shaft removed from arm and movable base**



► Step 2 **Screw removal**



1.2 Spring mechanism attachment

- 1 **Press fit the plastic bearings into the plate.**
Refer to “Plastic bearing replacement” in Chapter 7 for details.



CAUTION

Pay attention to the attachment direction. It will not be possible to attach the shaft if the plate and plastic bearing directions are not as shown on the right.

- 2 **Attach the spring.**
Ensure that the plates are bilaterally symmetrical. For two shafts, two of the assemblies shown on the right are required at the arm side, and two assemblies are required at the movable base side.

- 3 **Secure the plastic blocks with M3 screws.**


As shown on the right, press the protruding part of the plastic block against the protruding part of the plate, and then secure with the screws. Attach the plate to the other plastic block attachment surface on the other side after attaching to the shaft. Tightening torque: 40cNm




CAUTION

Force is applied to the plastic when tightening, and therefore care should be taken to avoid over tightening.



Step 1 Plastic bearing, plate



Step 2 Spring attachment



Step 3 Securing the plastic blocks



4

Attach the plate and plastic block assembly to the shaft.

Insert the plastic bearing attached to the plate so that it catches on the shaft pin.



NOTE

The assembly is attached at both the arm side and movable base side; however, the plastic block direction should be the same for both.

5

Attach the other plate and spring assembly (assembly without plastic block) to the shaft.

6

Secure the plastic block with the M3 screws as described in Step 3.


Attach so that the plate and plastic block are level.

7

Attach the plate and plastic block assembly on the opposite of the side already attached using the same procedure described in Steps 3 to 6.


► **Step 4**

Assembly attachment locations



► **Step 5**

Plate and spring assembly attachment



Chapter 7 Plastic bearing replacement

Contents

1. Plastic bearing replacement procedure	7-1
1.1 Removing the plastic bearing from the link ball sliding part	7-1
1.2 Attaching the plastic bearing to the link ball sliding part	7-2
1.3 Spring mechanism plate plastic bearing removal	7-3
1.4 Spring mechanism plate plastic bearing attachment	7-3
2. Plastic bearing inspection	7-4

1. Plastic bearing replacement procedure



CAUTION

Plastic bearings are consumable parts and should therefore be replaced periodically.

1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty	Remarks
1	Plastic bearing 1	KDL-M152J-00x		12	Replace if the wear amount is 0.5mm or more
2	Plastic bearing 2	KDL-M152K-00x		24	Spring mechanism (Replace if the wear amount is 0.5mm or more)

2. Tools to be prepared

Name	Part. No.	Manufacturer	Remarks
Jig	KDL-M150I-21x		
Jig A	KDL-M1116-01x		
Jig B	KDL-M1117-00x		
Hex wrench	No. 3		
Pliers			

1.1 Removing the plastic bearing from the link ball sliding part


Plastic bearing replacement guideline: when amount of wear reaches 0.5mm

When replacing plastic bearings, be sure to check and take a note of the bearing depth, and periodically measure the amount of wear.

- 1 **Install an M4 hex socket head bolt (L20 or more) into the tapping hole in the plastic bearing.**
- 2 **Push up the plastic bearing while tightening the M4 hex socket head bolt with a hex wrench.**

Step 2

Bolt attachment



1.2 Attaching the plastic bearing to the link ball sliding part

1 *Fit the plastic bearing installation jig A into the plastic bearing.*

2 *Insert the plastic bearing and jig A into the shaft side.*

3 *Press-fit the plastic bearing using either procedure (1) or (2) shown below.*

(1) Push-in the plastic bearing using the tool that can pinch, such as the water pump pliers together with the jig B.


(2) Arrange the jig A on the horizontal surface and push it in from the opposite side by hand.

Step 2 Inserting the plastic bearing and jig A




Step 3 Pushing in the plastic bearing

(1) Using water pump pliers




(2) Pushing by hand



Check that the plastic bearing does not protrude.

► Step 4

Plastic bearing attachment condition



1.3 Spring mechanism plate plastic bearing removal


1

Push the plate down from above with the protruding part of the plastic bearing facing down.

The plastic bearing will pop up, allowing it to be removed. If it still cannot be removed even after popping up, use a flat screwdriver or similar tool to remove it.

► Step 1

Plastic bearing removal



CAUTION

The bearing is press fit when attached, and should therefore be removed using a tool.

1.4 Spring mechanism plate plastic bearing attachment

1

Pay attention to the plastic bearing attachment direction and attach by press fitting.

Attach with the plastic bearing and plate facing in the directions shown on the right.

► Step 1

Plastic bearing attachment



CAUTION

It will not be possible to attach the spring cover if the direction is incorrect, resulting in possible robot malfunction.

2. Plastic bearing inspection

Measure the width of the gap between the two shaft joints with calipers and so on.

This measurement includes the width of two plastic bearings of the link and four plastic bearings of the plate.



CAUTION

- When the total amount of wear reaches 1mm or more, replace the plastic bearings of the link.
- When the plastic bearings of the link are replaced at the third time, replace the plastic bearings of the plate.

(Example) If the initial measurement value is 149.50mm and this value has reached 148.50mm during periodic measurement, replace the plastic bearings.

When replacing plastic bearings, be sure to check and take a note of the measurement result, and periodically measure the amount of wear.

Measurement method



CAUTION

Plastic bearing wear debris precautions:

- Wear debris removal is necessary when cleaning in food-related industries.
- Wear debris removal in industrial applications should be carried out as required.

Chapter 8

θ -axis seal, O-ring replacement

Contents

1.	θ-axis seal, O-ring replacement procedure	8-1
1.1	θ-axis seal, O-ring removal	8-1
1.2	θ-axis seal, O-ring attachment	8-3

1. θ -axis seal, O-ring replacement procedure

1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty	Remarks
1	Seal (small)	KDL-M219K-00x		1	Inside θ -axis housing, small side
2	Seal (large)	KDL-M219K-10x		1	Inside θ -axis housing, large side
3	O-ring	KN5-M2144-00x		1	Housing side
4	O-ring	KN6-M1895-00x		1	θ -axis motor cover side
5	Housing	KDL-M1811-00x		1	
6	Housing securing bolt	91380-04020	M4, length 20	6	
7	Tool flange	KDL-M1843-00x		1	
		KDL-M1844-00x		1	
8	Tool flange securing bolt	91380-04012	M4, length 12	2	
9	Tool flange cover	KDL-M1816-00x		1	Rubber cover

2. Tools to be prepared

Name	Part. No.	Manufacturer	Remarks
Cleaning wipe			
Phillips screwdriver			
Hex wrench set			
Thread sealer	Loctite 241	Henkel	Medium strength type (blue)
Grease	EPS2 1g	CASSIDA grease	Food grade or its compatible

1.1 θ -axis seal, O-ring removal

The procedure described below is for the R6Y31110L03067NJ5, R6Y31110H03067NJ5, R6Y31065L02067NJ5 and R6Y31065H02067NJ5 (4-axes specification).

- 1 **Remove the θ -axis motor cover.**
When removing the θ -axis motor cover, first disconnect the θ -axis harness and then remove the movable base from the shafts before proceeding.

Refer to "1.2 Detaching or attaching the θ -axis cover" in chapter 2 for details.

- 2 **Remove the O-ring from the groove in the movable base at the motor cover side.**

► Step 2

O-ring removal



3

Remove the tool flange.

Remove the rubber cover, remove the M4 hex socket head bolts, and then remove the tool flange.

4

Remove the six length 20 M4 hex socket head bolts from the movable base.


These bolts secure the movable base and housing.

5


Remove the housing from the movable base.

The housing will still be attached to the movable base a little.

▶ Step 3

Tool flange removal

▶ Step 4

M4 hex socket head bolt removal

▶ Step 5

Housing removal

- 6 **Remove the O-ring from the groove on the movable base at the housing side.**


► Step 6 O-ring removal



- 7 **Remove the two seals from the housing.**

The seals can be easily removed by prizing them free with a precision flat screw driver as shown on the right.

► Step 7 Seal removal



1.2 θ-axis seal, O-ring attachment

Fit the seals using the opposite of the procedure used for removal.



CAUTION

When replacing θ-axis seal, wipe off the old grease sticking to the housing or θ-axis shaft before attaching the seal.

- Recommended grease: CASSIDA grease EPS 2 Total grease amount: 1g

- 1 **Fit the two seals to the housing.**

If unable to attach the seals properly as shown on the right, attach by pressing in a little, and ensure that the seals are not twisted.

► Step 1 Seal attachment



- 2 *Apply the recommended grease so that the grooves on the seals (large) and (small) are filled with it.*


CAUTION



If the grease application amount is small, the service life of the seal may become shorter.

- 3 *Apply a thin layer of the recommended grease to the sliding parts with the seals (large) and (small).*


CAUTION

If the grease application amount is small, the service life of the seal may become shorter.

- 4 *Attach the O-ring to the groove in the movable base at the housing side.*

Step 2
Grease application

Step 3
Grease application

Step 4
O-ring attachment


Attach the housing.


Push the housing until it is aligned with the underside of the movable base so that the air tube attachment port is on the β -axis side.

After pushing in, tighten the six length 20 M4 hex socket head bolts.

- Tightening torque: 2Nm

**CAUTION**

Attach the housing with the housing side O-ring attached to the movable base part. Furthermore, ensure that the housing is aligned with the underside of the movable base. Pickup will not be possible if the O-ring has not been attached, or the housing has not been attached sufficiently.

▶ **Step 5****Housing attachment**

6

Install the tool flange.

Remove grease from the θ -axis shaft (tool flange attachment part).

The tool flange is shaped so that it fits into the θ -axis shaft groove.

7




Attach the tool flange with the two M4 hex socket head bolts.

- Tightening torque: 4.5Nm

**CAUTION**

Tighten the two M4 hex socket head bolts evenly. Slippage may occur between the θ -axis shaft and seal flange if one bolt is tightened more than the other.

► Step 6-7 **Tool flange installation**



8 *Attach the rubber cover to the tool flange.*

9 *Attach the O-ring to the groove in the movable base at the motor side.*

10 *Attach the θ -axis motor cover.*

Refer to "1.2 Detaching or attaching the θ -axis cover" in chapter 2 for details.


► Step 8

Rubber cover attachment



► Step 9

O-ring attachment



Chapter 9

Motor replacement

Contents

1.	α, β and γ-axes motor replacement	9-1
1.1	R6Y3 110	9-1
1.1.1	α , β and γ -axes motor removal	9-1
1.1.2	α , β and γ -axes motor attachment	9-4
1.2	R6Y3 065	9-5
1.2.1	α , β and γ -axes motor removal	9-5
1.2.2	α , β and γ -axes motor attachment	9-8
2.	θ-axis motor replacement	9-9
2.1	θ-axis motor removal	9-9

1. α , β and γ -axes motor replacement

1.1 R6Y3[]110



WARNING

IF REPLACING A MOTOR WITH SHAFTS, MOVABLE BASE, AND ARM ATTACHED, PLACE A SUPPORT UNDER THE MOVABLE BASE TO PREVENT IT FALLING. AND IF REPLACING A MOTOR WITH ONLY THE ARM ATTACHED, PLACE A SUPPORT UNDER THE ARM OR STRAP IT UP WITH SOME STRING TO PREVENT IT FALLING.

1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty ^{*1}	Remarks
1	Motor	R88M-K1K030T-BS2 ^{*2}	1000W, 200 V, with brake	1	For α , β and γ -axes
2	Motor securing bolt	91312-08025	M8, length 25	4	
3	O-ring	90200-03J850		1	Attached to speed reduction gear groove

*1 : Quantity per axis

*2 : For installation, remove the key

2. Tools to be prepared

Name	Part. No.	Manufacturer	Remarks
Cleaning wipe			
Hex wrench set		kenko	Only No. 6 is 160 mm long
Thread sealer	Loctite 241	Henkel	Medium strength type (blue)
Seal tape	NITOFロン pipe seal No. 95S or its equivalent	NITTO DENKO	

1.1.1 α , β and γ -axes motor removal



NOTE

The same procedure is used to replace the α , β and γ -axes motors.

1 ***Post a sign indicating that the robot is being adjusted.***

Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.

2 ***Enter the safety enclosure.***

3 ***Remove the motor cover.***

Refer to "1. Detaching, attaching, and replacing the covers" in chapter 2 for details.

4 **Remove the speed reduction gear cap bolt.**

If the hex socket head bolt is not visible inside the hole when the cap bolt is removed, release the motor brake, move the arm to a position at which the hex socket head bolt becomes visible, and then adjust (if the arm has been removed, rotate the speed reduction gear to adjust the position.)



CAUTION

If removing the motor with the arm still attached, it will fall suddenly when the motor brake is released, and must therefore be supported. And if removing the motor with the shafts and movable base still attached, the movable base must be supported to prevent it dropping suddenly.

5 **Loosen the M6 hex socket head bolt connecting the speed reduction gear and motor shaft.**

Tighten the bolt with a torque of 15Nm.

6 **Remove the four M8 hex socket head bolts securing the motor to the speed reduction gear.**


Tighten the bolt with a torque of 19Nm.




CAUTION

Take care to prevent the motor falling when the bolts are removed.

Step 4 **Cap bolt removal**



Step 5 **Loosen the M6 hex socket head bolt**



Step 6 **Hex socket head bolt removal**




- 7 *Pull the motor from the speed reduction gear to remove.*

**CAUTION**

The motor is relatively heavy and should therefore be supported with both hands when removing.

- 8 *Attach the O-ring to the groove in the speed reduction gear (when replacing the O-ring).*

► Step 7 **Motor removal**



► Step 8 **O-ring removal**




1.1.2 α , β and γ -axes motor attachment


Attach the motors using the opposite of the procedure used for removal.
When doing so, the following additional procedures are necessary.

- Use a waste cloth to remove any grease from the motor shaft and speed reduction gear attachment surfaces.
- To make it easier to secure the motor shaft to the speed reduction gear, rotate the speed reduction gear beforehand so that the gear hex socket head bolt is visible from the cap attachment hole.
- When attaching the motor, fit an O-ring to the speed reduction gear.
- Attach the motor with the connector facing to the inside.
- Tighten the M8 bolt of the motor with a torque of 19Nm.
- Tighten the clamp between the motor and speed reduction gear with a torque of 15Nm (M6).
- Wind the seal tape on the cap bolt.

O-ring attachment



Motor attachment direction



Seal tape winding direction



1.2 R6Y3[]065



WARNING

IF REPLACING A MOTOR WITH SHAFTS, MOVABLE BASE, AND ARM ATTACHED, PLACE A SUPPORT UNDER THE MOVABLE BASE TO PREVENT IT FALLING. AND IF REPLACING A MOTOR WITH ONLY THE ARM ATTACHED, PLACE A SUPPORT UNDER THE ARM OR STRAP IT UP WITH SOME STRING TO PREVENT IT FALLING.

1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty ^{*1}	Remarks
1	Motor	R88M-K40030T-BS2 ^{*2}	400W, 200 V, with brake	1	For α , β and γ -axes
2	Motor securing bolt	91380-04014	M4, length 14	4	
3	O-ring	90200-01J530		1	Attached to speed reduction gear groove

*1 : Quantity per axis

*2 : For installation, remove the key

2. Tools to be prepared

Name	Part. No.	Manufacturer	Remarks
Cleaning wipe			
Hex wrench set		kenko	Only No. 4 is 160 mm long
Thread sealer	Loctite 241	Henkel	Medium strength type (blue)
Seal tape	NITOFロン pipe seal No. 95S or its equivalent	NITTO DENKO	

1.2.1 α , β and γ -axes motor removal



NOTE

The same procedure is used to replace the α , β and γ -axes motors.

- Post a sign indicating that the robot is being adjusted.**
Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.
- Enter the safety enclosure.**
- Remove the motor cover.**
Refer to “1. Detaching, attaching, and replacing the covers” in chapter 2 for details.

4 **Remove the speed reduction gear cap bolt.**

If the hex socket head bolt is not visible inside the hole when the cap bolt is removed, release the motor brake, move the arm to a position at which the hex socket head bolt becomes visible, and then adjust (if the arm has been removed, rotate the speed reduction gear to adjust the position.)



CAUTION

If removing the motor with the arm still attached, it will fall suddenly when the motor brake is released, and must therefore be supported. And if removing the motor with the shafts and movable base still attached, the movable base must be supported to prevent it dropping suddenly.

5 **Loosen the M4 hex socket head bolt connecting the speed reduction gear and motor shaft.**

Tighten the bolt with a torque of 4.3Nm.

6 **Remove the four M4 hex socket head bolts securing the motor to the speed reduction gear.**

Tighten the bolt with a torque of 2.3Nm.




CAUTION

Take care to prevent the motor falling when the bolts are removed.

Step 4 Cap bolt removal



Step 5 Loosen the M4 hex socket head bolt



Step 6 Hex socket head bolt removal



- 7 *Pull the motor from the speed reduction gear to remove.*

**CAUTION**

The motor is relatively heavy and should therefore be supported with both hands when removing.

- 8 *Attach the O-ring to the groove in the speed reduction gear (when replacing the O-ring).*

► Step 7 **Motor removal**



► Step 8 **O-ring removal**




1.2.2 α , β and γ -axes motor attachment

Attach the motors using the opposite of the procedure used for removal.
When doing so, the following additional procedures are necessary.

- Use a waste cloth to remove any grease from the motor shaft and speed reduction gear attachment surfaces.
- To make it easier to secure the motor shaft to the speed reduction gear, rotate the speed reduction gear beforehand so that the gear hex socket head bolt is visible from the cap attachment hole.
- When attaching the motor, fit an O-ring to the speed reduction gear.
- Attach the motor with the connector facing to the inside.
- Tighten the M4 bolt of the motor with a torque of 2.3Nm.
- Tighten the clamp between the motor and speed reduction gear with a torque of 4.3Nm (M4).
- Wind the seal tape on the cap bolt.

O-ring attachment



Motor attachment direction



Seal tape winding direction



2. θ -axis motor replacement

1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty	Remarks
1	Motor	R88M-K05030T-S2 ^{*1}	50W, 200 V, without brake	1	For R6Y31110L03067NJ5 and R6Y31065L02067NJ5
		R88M-K10030T-S2 ^{*1}	100W, 200V, without brake	1	For R6Y31110H03067NJ5 and R6Y31065H02067NJ5
2	Motor securing bolt	91380-04014	M4, length 14	2	Common to R6Y31110L03067NJ5, R6Y31110H03067NJ5, R6Y31065L02067NJ5 and R6Y31065H02067NJ5

*1 : For installation, remove the key

2.1 θ -axis motor removal

The procedure required to replace the θ -axis motor only is described below. Refer to "2.3 θ -axis speed reduction gear replacement" in chapter 10 if removing the speed reduction gear also.

1 **Remove the movable base from the shaft.**

Refer to the "1. Shaft, movable base, and spring cover replacement procedure" in chapter 5 for details.

2 **Remove the θ -axis motor cover.**

Refer to the "1. Shaft, movable base, and spring cover replacement procedure" in chapter 5 for details.

3 **Loosen the two speed reduction gear set screws.**

Remove the gasket and then loosen the set screws.




NOTE

If the set screw is not loosened securely, the speed reduction gear may be disassembled during motor removal. It is preferable to replace the motor and speed reduction gear at the same time.

Step 3

Set screw area



4 **Remove the two M4 hex socket head bolts securing the motor to the speed reduction gear.**

5 **Remove the motor from the speed reduction gear.**

Attach the motor using the opposite of the procedure used for removal.

Refer to "2.3 θ -axis speed reduction gear replacement" in chapter 10 for details.

Step 4

M4 hex socket head bolt removal



Chapter 10

Speed reduction gear, arm replacement

Contents

1.	Speed reduction gear replacement precautions	10-1
2.	Speed reduction gear and arm replacement procedure	10-2
2.1	R6Y3[]110	10-2
2.1.1	α , β and γ -axes arm replacement	10-2
2.1.2	α , β and γ -axes speed reduction gear replacement	10-6
2.2	R6Y3[]065	10-8
2.2.1	α , β and γ -axes arm replacement	10-8
2.2.2	α , β and γ -axes speed reduction gear replacement	10-12
2.3	θ-axis speed reduction gear replacement	10-15

1. Speed reduction gear replacement precautions

Speed reduction gear replacement precautions are described below. Always read the following replacement procedures and precautions before carrying out replacement work.

■ Speed reduction gear replacement precautions



WARNING

- THE MOTOR AND SPEED REDUCTION GEAR CASING WILL BECOME VERY HOT SHORTLY AFTER OPERATION, RESULTING IN BURNS IF TOUCHED. BEFORE TOUCHING THESE PARTS, TURN OFF THE CONTROLLER, WAIT FOR A WHILE, AND THEN CHECK THAT THE TEMPERATURE HAS SUFFICIENTLY FALLEN.

DEGREASING AND WASHING PRECAUTIONS:

- THE EYES MAY BECOME INFLAMED IF EXPOSED TO GREASE OR DETERGENT ON THE WASTE CLOTH USED FOR GREASE REMOVAL. BEFORE HANDLING THE GREASE, WEAR YOUR SAFETY GOGGLES TO ENSURE THE GREASE WILL NOT COME IN CONTACT WITH THE EYES.
- INFLAMMATION MAY OCCUR IF THE GREASE COMES INTO CONTACT WITH SKIN. BE SURE TO WEAR PROTECTIVE GLOVES TO PREVENT CONTACT WITH SKIN.
- DO NOT TAKE ORALLY OR EAT. (EATING WILL CAUSE DIARRHEA AND VOMITING.)
- KEEP OUT OF THE REACH OF CHILDREN.

EMERGENCY TREATMENT:

- IF GREASE OR DETERGENT SPLATTERS AND GETS INTO THE EYES, RINSE WITH CLEAN WATER FOR 15 MINUTES AND THEN CONSULT A PHYSICIAN.
- IF THIS GREASE COMES IN CONTACT WITH THE SKIN, WASH AWAY COMPLETELY WITH SOAP AND WATER.
- IF TAKEN INTERNALLY, DO NOT INDUCE VOMITING BUT PROMPTLY CONSULT A PHYSICIAN FOR TREATMENT.



CAUTION

About the speed reduction gear

- Do not apply strong force to any of the parts with a hammer and so on. Furthermore, be careful not to drop any of the parts, as this may result in scratches or dents, leading to likely speed reduction gear damage.
- If the speed reduction gear is used in a damaged condition, it will not function at its specified performance. Furthermore, using in this condition may lead to problems such as complete gear break-down.
- The speed reduction gear will shift when replaced, and therefore it is necessary to adjust the origin position following replacement.

2. Speed reduction gear and arm replacement procedure

The replacement procedure and precautions for speed reduction gears and arms are listed below.

Refer to the following table for bolt tightening torque values required when replacing speed reduction gears or arms. However, please follow the instructions given at each replacement procedure for the tightening torque applied to bolts used to secure reduction gears and arms. OMRON bolts should be used.

■ Bolt tightening torque

Bolt size	Tightening torque (kgfcm)	Tightening torque (Nm)
M3 set screw	20	2
M3	20	2
M4	46	4.5
M4 4-axes specification α -axis arm harness clamp	20	2
M4 harness clamp (R6Y3[]065)	20	2
M5 harness mounting bolt (R6Y3[]110)	63	6.2
M5 harness mounting bolt (R6Y3[]065)	20	2
M6	156	15.3
M8	380	37
M10	540	53
M12	1310	128

Recommended "Screw Lock": LOCTITE 241 (made by Henkel Corporation)

2.1 R6Y3[]110

2.1.1 α , β and γ -axes arm replacement



WARNING

CARRY OUT REPLACEMENT AFTER READING "ATTACHING, DETACHING AND REPLACING THE COVER" IN CHAPTER 2.



NOTE

The arm replacement procedure is the same for the α , β and γ -axes.

The requirements for α , β and γ -axes arm replacement are as follows.

1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty ^{*1}	Remarks
1	Arm assembly 1	KDL-M1520-01x		1	β , γ -axes (common), α -axis (3-axes)
(1)	Arm	KDL-M1521-01x		1	
(2)	Link ball	KDL-M152A-00x		2	
(3)	Cap	KDL-M1561-01x		1	
(4)	Bolt 1	97080-04006	M4, length 6	3	
(5)	Bolt 2	91312-08020	M8, length 20	6	
(6)	Bolt 3	97080-05008	M5, length 8	2	
(7)	Bolt 4	97080-06008	M6, length 8	1	

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty*1	Remarks
2	Arm assembly 2	KDL-M1520-11x		1	α -axis (4-axes)
(1)	Arm	KDL-M1521-01x		1	
(2)	Link ball	KDL-M152A-00x		2	
(3)	Cap	KDL-M1561-01x		1	
(4)	Lower clamp	KDL-M1573-00x		2	
(5)	Bolt 1	91312-04010	M4, length 10	2	
(6)	Bolt 2	97080-04006	M4, length 8	1	
(7)	Bolt 3	91312-08020	M8, length 20	6	
(8)	Harness	KDL-M4815-00x		1	θ -axis harness
(9)	Bolt 4	KDL-M152N-00x	M5, length 12	2	
(10)	Upper clamp	KDL-M1574-00x		2	
(11)	Cable tie	\$AB80		4	
(12)	Pin	99480-03008		2	
(13)	Bolt 5	97080-06008	M6, length 8	1	

*1 : Quantity per axis

2. Required tools

Name	Part. No.	Manufacturer	Remarks
Cleaning wipe			
Hex wrench set			
Hex wrench			Only No. 6 is 160 mm long
Spanner	No. 8		
Thread sealer	Loctite 241	Henkel	Medium strength type (blue)

The arm removal procedure is described below. Use the opposite procedure to perform arm attachment.

1 ***Post a sign indicating that the robot is being adjusted.***

Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.

2 ***Enter the safety enclosure.***

3 ***Remove the cap (white) from each axis arm.***

The hex socket head bolt attachment surface is exposed by removing the cap.

Step 3 ***When cap removed from arm***

4 ***Adjust the arm position (if replacing the speed reduction gear).***

5 ***Remove the length 20 M8 hex socket head bolt used to secure the arm for each axis to its respective speed reduction gear.***

Tighten the bolts with a tightening torque of 37Nm when attaching the arm.



6 ***Remove each axis arm.***

2.1.1.1 Work required after replacing arm link balls

The link ball attachment method is described here.

- 1 ***Apply the thread sealer to the screw part of the link ball thinly.***
Use Henkel Loctite 241 (blue).
- 2 ***Attach a link ball to two locations on each axis arm.***
Attach to a total of six locations on the α , β and γ -axes.
- 3 ***Tighten the link balls with a tool.***
 - Tightening torque: 20Nm

▶ Step 2 Link ball attachment




▶ Step 3 Tightening with tool



2.1.1.2 Arm harness replacement

- 1 ***Post a sign indicating that the robot is being adjusted.***
Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.
- 2 ***Enter the safety enclosure.***
- 3 ***Turn the θ -cable connector counterclockwise to remove it.***

▶ Step 3 Removing the θ -cable connector



- 4 ***Cut the cable ties that clamp the harness and remove the upper portion.***
- 5 ***Remove the M5 hex bolts from the harness block.***
- 6 ***Prepare new harness parts and secure them with the M5 hex bolts.***
 - Tightening torque: 6.2Nm
- 7 ***Install the upper clamp and secure it with two cable ties.***
- 8 ***Secure excess harness so that it does not interfere with the arm or cover.***

▶ Step 4

Cutting the cable ties and removing the upper portion

▶ Step 5

Removing the bolts

▶ Step 8

Securing the harness

2.1.2 α , β and γ -axes speed reduction gear replacement



NOTE

The same procedure is used to replace the α , β and γ -axes speed reduction gears.

The requirements for α , β and γ -axes speed reduction gear replacement are as follows.

1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty*	Remarks
1	Speed reduction gear	KDL-M211A-00x		1	For α , β and γ -axes
2	Speed reduction gear mounting bolt	90112-10J030	M10, length 30	4	

*1 : Quantity per axis

2. Required tools

Name	Part No.	Manufacturer	Remarks
Cleaning wipe			
Hex wrench set			
Screw thread locking agent	Loctite 241	Henkel	Medium-strength type (blue)

■ Removal

1 **Post a sign indicating that the robot is being adjusted.**

Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.

2 **Enter the safety enclosure.**



CAUTION

The robot body is extremely heavy, and therefore care should be taken when carrying out replacement work.

3 **Remove the relevant axis motor.**

Refer to "1.2.1 α , β and γ -axes motor removal" in chapter 9 for details on motor replacement.

4 **Loosen the bracket hex socket head bolts.**

Loosen the length 20 M4 hex socket head bolts on the bracket used to secure the motor cover attached above and below the speed reduction gear.


The speed reduction gear can be easily removed by loosening the bracket.

Remove the bracket if still difficult to remove the speed reduction gear even after loosening.


5 **Remove the M10 hex socket head bolts used to secure the speed reduction gear to the base.**

Tighten the bolts with a tightening torque of 53Nm when reattaching.

► Step 4 **Loosen the M4 hex socket head bolts**



► Step 5 **Speed reduction gear hex socket head bolt removal**



6


Remove the speed reduction gear.

Keep the angle of the speed reduction gear steady and remove slowly while supporting with both hands. If the angle is not kept steady and the speed reduction gear becomes stuck on the base, it will be difficult to remove.

If the brackets used to secure the motor cover attached above and below the speed reduction gear become caught, remove them.

**CAUTION**

Do not apply excessive force to remove the speed reduction gear. Doing so may result in gear malfunction.

▶ **Step 6****Speed reduction gear removal****■ Attachment**

Attach the speed reduction gear using the opposite of the procedure used for removal.

Attach the speed reduction gear so that the cap bolts are on the outside.

**CAUTION**

- The speed reduction gear is extremely heavy and should therefore be supported with both hands when attaching.
- Insert the speed reduction gear slowly while holding it perpendicular to the base at the same angle. It will be difficult to insert the reduction gear into the base if at angle.
- Try again if unable to insert the speed reduction gear properly. Using excessive force to insert the gear may damage it.

Speed reduction gear attachment condition

Arm side



The bottom is wider when viewed from the side.

Motor side



Check the left and right clearances.

2.2 R6Y3[]065

2.2.1 α , β and γ -axes arm replacement



WARNING

CARRY OUT REPLACEMENT AFTER READING “ATTACHING, DETACHING AND REPLACING THE COVER” IN CHAPTER 2.



NOTE

The arm replacement procedure is the same for the α , β and γ -axes.

The requirements for α , β and γ -axes arm replacement are as follows.

1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty ^{*1}	Remarks
1	Arm assembly 1	KDL-M1520-21x		1	β , γ -axes (common), α -axis (3-axes)
(1)	Arm	KDL-M1521-10x		1	
(2)	Shaft	KDL-M152F-00x		1	
(3)	Link ball	KDL-M152A-00x		2	
(4)	Cap	KDL-M1561-10x		1	
(5)	Bolt 1	97080-04006	M4, length 6	5	
(6)	Bolt 2	91380-06016	M8, length 16	6	
2	Arm assembly 2	KDL-M1520-31x		1	α -axis (4-axes)
(1)	Arm	KDL-M1521-10x		1	
(2)	Shaft	KDL-M152F-00x		1	
(3)	link ball	KDL-M152A-00x		2	
(4)	Cap	KDL-M1561-10x		1	
(5)	Bolt 1	91380-06016	M6, length 16	6	
(6)	block	KDL-M153E-00x		1	
(7)	Bolt 2	91380-04030	M4, length 30	3	
(8)	Harness	KDL-M4815-00x		1	θ -axis harness
(9)	Bolt 3	KDL-M152N-00x	M5, length 12	2	
(10)	Clamp	KDL-M1573-10x		2	
(11)	Bolt 4	97080-04020	M4, length 20	2	
(12)	Cable tie	\$AB80		1	

*1 : Quantity per axis



2. Required tools

Name	Part. No.	Manufacturer	Remarks
Cleaning wipe			
Hex wrench set			
Hex wrench			
Spanner	No. 6, 8		
Thread sealer	Loctite 241	Henkel	Medium strength type (blue)

The arm removal procedure is described below. Use the opposite procedure to perform arm attachment.

- 1 ***Post a sign indicating that the robot is being adjusted.***
Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.
- 2 ***Enter the safety enclosure.***
- 3 ***Remove the cap (white) from each axis arm.***
The hex socket head bolt attachment surface is exposed by removing the cap.
- 4 ***Adjust the arm position (if replacing the speed reduction gear).***
- 5 ***Remove the length 16 M6 hex socket head bolt used to secure the arm for each axis to its respective speed reduction gear.***
Tighten the bolts with a tightening torque of 15Nm when attaching the arm.
- 6 ***Remove each axis arm.***

► Step 3 When cap removed from arm



2.2.1.1 Work required after replacing arm link balls

The link ball attachment method is described here.

- 1 ***Apply the thread sealer to the screw part of the link ball thinly.***
Use Henkel Loctite 241 (blue).
- 2 ***Attach a link ball to two locations on each axis arm.***
Attach to a total of six locations on the α , β and γ -axes.
- 3 ***Tighten the link balls with a tool.***
 - Tightening torque: 20Nm


► Step 3 **Tightening with tool**



2.2.1.2 Arm harness replacement

- 1 ***Post a sign indicating that the robot is being adjusted.***
Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.
- 2 ***Enter the safety enclosure.***
- 3 ***Turn the θ -cable connector counterclockwise to remove it.***

► Step 3 **Removing the θ -cable connector**



4 *Cut the cable ties that clamp the harness and remove the M4 hex bolts from the clamp.*

5 *Remove the M5 hex bolts from the harness block.*

6 *Prepare new harness parts and secure them with the M5 hex bolts.*

- Tightening torque: 2Nm

7 *Secure the clamp with the M4 hex bolts and use the cable ties to secure the clamp at a position where is 150mm away from the clamp.*

- Tightening torque: 2Nm

▶ Step 4


Cutting the cable ties and removing the M4 bolts from the clamp



▶ Step 5

Removing the bolts





2.2.2 α , β and γ -axes speed reduction gear replacement



NOTE

The same procedure is used to replace the α , β and γ -axes speed reduction gears.

The requirements for α , β and γ -axes speed reduction gear replacement are as follows.

1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty*	Remarks
1	Speed reduction gear	KDL-M211A-10x		1	For α , β and γ -axes
2	Speed reduction gear mounting bolt	91380-08025	M8, length 25	4	

*1 : Quantity per axis

2. Required tools

Name	Part No.	Manufacturer	Remarks
Cleaning wipe			
Hex wrench set		Kenko	Only No.6 is 120mm long
Screw thread locking agent	Loctite 241	Henkel	Medium-strength type (blue)

■ Removal

- 1 ***Post a sign indicating that the robot is being adjusted.***
Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.
- 2 ***Enter the safety enclosure.***



CAUTION

The robot body is extremely heavy, and therefore care should be taken when carrying out replacement work.

- 3 ***Remove the relevant axis motor.***
Refer to “1.2.1 α , β and γ -axes motor removal” in chapter 9 for details on motor replacement.
- 4 ***Remove the M8 hex socket head bolts used to secure the speed reduction gear to the base.***
Tighten the bolts with a tightening torque of 26Nm when reattaching.
- 5 ***Remove the speed reduction gear.***
Keep the angle of the speed reduction gear steady and remove slowly while supporting with both hands. If the angle is not kept steady and the speed reduction gear becomes stuck on the base, it will be difficult to remove.



CAUTION

Do not apply excessive force to remove the speed reduction gear. Doing so may result in gear malfunction.

▶ Step 4

Speed reduction gear hex socket head bolt removal



▶ Step 5

Speed reduction gear removal



■ Attachment

Attach the speed reduction gear using the opposite of the procedure used for removal.
Attach the speed reduction gear so that the cap bolts are on the outside.




CAUTION


- The speed reduction gear is extremely heavy and should therefore be supported with both hands when attaching.
- Insert the speed reduction gear slowly while holding it perpendicular to the base at the same angle. It will be difficult to insert the reduction gear into the base if at angle.
- Try again if unable to insert the speed reduction gear properly. Using excessive force to insert the gear may damage it.

Speed reduction gear attachment condition


Protrusion condition on opposite side



Check the left and right clearances



Cap bolt



2.3 θ -axis speed reduction gear replacement

The requirements for θ -axis speed reduction gear replacement are as follows.

1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty [*]	Remarks
1	Speed reduction gear	KDL-M1822-00x		1	For R6Y31110L03067NJ5 and R6Y31065L02067NJ5
		KDL-M1822-10x		1	For R6Y31110H03067NJ5 and R6Y31065H02067NJ5
2	Speed reduction gear mounting bolt	91380-03010	M3, length 10	4	Common to R6Y31110L03067NJ5, R6Y31110H03067NJ5, R6Y31065L02067NJ5 and R6Y31065H02067NJ5
3	θ -axis shaft	KDL-M1870-00x		1	
4	Shaft securing bolt	91380-03008	M3, length 8	6	
5	Spacer	KDL-M1830-00x		1	
6	Spacer securing bolt	91380-04008	M4, length 8	3	

2. Required tools

Name	Part No.	Manufacturer	Remarks
Cleaning wipe			
Hex wrench set			
Screw thread locking agent	Loctite 241	Henkel	Medium-strength type (blue)
Spanner			
Grease	EPS2	CASSIDA	Food grade or its compatible
Jig			For installation of speed reduction gear

■ Removal

- 1 ***Post a sign indicating that the robot is being adjusted.***
Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.
- 2 ***Enter the safety enclosure.***
- 3 ***Remove the end effector.***
Refer to "6. Attaching the end effector" in chapter 2 of the installation manual for details.
- 4 ***Disconnect the air tube from the joint on the user tubing.***



CAUTION

Do not carry out replacement work with the air tube still attached to the joint on the user tubing. By doing so, the air tube may bend.

- 5 ***Disconnect the harness from the θ -axis motor cover.***
Refer to "1. Shaft, movable base, and spring cover replacement procedure" in chapter 5 for details.



CAUTION


Do not carry out replacement work with the harness still attached to the θ -axis motor. By doing so, the harness may be damaged.

- 6 ***Remove the movable base from the shafts.***
Refer to "1. Shaft, movable base, and spring cover replacement procedure" in chapter 5 for details.
- 7 ***Remove the θ -axis motor cover.***
Refer to "1. Detaching, attaching, and replacing the covers" in chapter 2 for details.
- 8 ***Remove the motor cover side O-ring.***
- 9 ***Remove the tool flange.***
Refer to "1.1 θ -axis seal, O-ring removal" in chapter 8 for details.
- 10 ***Remove the housing.***
- 11 ***Remove the O-ring at the housing side.***
- 12 ***Remove the shaft attached to the speed reduction gear.***
Insert a hex wrench through the shaft through hole to prevent the axis rotating, and then remove the six M3 hex socket head bolts.
- 13 ***Remove the spacer.***
Use a spanner to prevent the axis rotating, and then remove the three M4 hex socket head bolts.
- 14 ***Pull the motor and speed reduction gear assembly from the movable base.***
Remove the four M3 hex socket head bolts from the speed reduction gear brackets.
- 15 ***Remove the two M4 hex socket head bolts securing the motor to the speed reduction gear.***
- 16 ***Loosen the two speed reduction gear set screws.***
- 17 ***Remove the motor from the speed reduction gear.***

Step 12 Shaft removal



Step 13 Spacer removal



Step 15 M4 hex socket head bolt removal



Step 17 Speed reduction gear removal



■ Attachment

Attach the speed reduction gear using the opposite of the procedure used for removal.

- 1 ***Attach the motor to the speed reduction gear.***
- 2 ***Attach the two length 14 M4 hex socket head bolts used to secure the motor to the speed reduction gear.***
 - Tightening torque: 4.5Nm
- 3 ***Tighten the two speed reduction gear set screw.***
 - Tightening torque: 69cNm
- 4 ***Insert the motor and speed reduction gear assembly into the movable base.***

Ensure that the motor connector side is facing the movable base α -axis side.



WARNING

IF THE ATTACHMENT DIRECTION IS INCORRECT, IT WILL NOT BE POSSIBLE TO PROPERLY EARTH THE θ -AXIS MOTOR COVER WHEN ATTACHED, RESULTING IN POSSIBLE ELECTRIC SHOCK.

► Step 1 Speed reduction gear attachment



► Step 3 Bolt attachment



► Step 4 Assembly attachment



α -axis side



α -axis side
Identified by 2 punch holes
and earth bolt holes.

5 *Temporarily tighten the speed reduction gear to the movable base with the four length 10 M3 hex socket head bolts.*

6 *Center the rotational axis.*

Align the rotation centering jig with the center of the speed reduction gear axis.

Secure to the movable base at two of the six bolt locations with the M4 bolts, adjust to center the θ -axis, and then fully tighten the bolts temporarily tightened at Step 5.

- Tightening torque: 2Nm

After tightening, remove the two M4 bolts used to secure the movable base, and then remove the rotation centering jig.


▶ Step 5

Temporary tightening



▶ Step 6

Rotation centering jig attachment



7

Install the spacer.

Use a spanner to prevent the axis rotating, and then attach the three length 8 M4 hex socket head bolts.

- Tightening torque: 4.5Nm

8

Attach the shaft.

Insert a hex wrench through the shaft through hole to prevent the axis rotating, and then attach the six length 8 M3 hex socket head bolts.

- Tightening torque: 2Nm (Thread sealer is not applied)
- Recommended grease: CASSIDA grease EPS 2

9

Apply a thin layer of the recommended grease to the sliding parts with the seals (large) and (small).

- Recommended grease: CASSIDA grease EPS 2

Refer to “1.2 θ -axis seal, O-ring attachment” in chapter 8 for details.

10

Attach the O-ring at the housing side.


Refer to “1.2 θ -axis seal, O-ring attachment” in chapter 8 for details.

11

Attach the housing.

Refer to “1.2 θ -axis seal, O-ring attachment” in chapter 8 for details.


▶ Step 7

Spacer attachment

▶ Step 8

Shaft attachment

▶ Step 9

Grease application

Chapter 11

Option parts replacement

Contents

1. Shaft replacement procedure	11-1
1.1 Shaft removal	11-1
1.2 Shaft attachment	11-3
2. Harness replacement procedure	11-6
2.1 R6Y3[]110	11-6
2.2 R6Y3[]065	11-8
3. Detection connector replacement procedure	11-10

1. Shaft replacement procedure

1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty	Remarks
1	Shaft	S02D-MR116-00x		1	For detection (for R6Y3[]110)
1	Shaft	S02D-MR116-20x		1	For detection (for R6Y3[]065)

1.1 Shaft removal

The detection cable shaft is located on the left of each axis.

The work other than the detection part connector attachment and detachment is common to each axis.



CAUTION

It is necessary to enter the safety enclosure in order to detach or attach the shafts, movable base, or spring covers, and therefore the controller power must be turned off beforehand.

1

Post a sign indicating that the robot is being adjusted.

Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.

2

Enter the safety enclosure.

3

Remove the spring covers.

There are a total of six spring covers: one at the arm, and one at the movable base for each of the three axes.

There is a top spring cover and bottom spring cover, with the top cover being wider.

The spring covers are held together with clips on the inside.

Pull the bottom cover down at the arm side and pull the top cover up at the movable base side to remove the spring cover.



CAUTION

Use both hands when removing the spring covers. Use one hand for removal and the other to stop the bottom cover falling.

If the spring cover falls and is damaged, the robot may operate abnormally.

4

Remove the end effector.

Refer to "6. Attaching the end effector" in chapter 2 of the installation manual for details.

5

Disconnect the air tube from the joint on the user tubing.






CAUTION

Do not carry out replacement work with the air tube still attached to the joint on the user tubing.

By doing so, the air tube may bend.

Step 3

Spring cover removal



6

Disconnect the connector of each arm. (The detection cable connector is located on the left.)

Turn the connector 90° counterclockwise and pull it out.

7

Hold the wiring on the shaft side and pull it to disconnect the connector.

8

Remove the shafts.

Remove the shafts from the arm and movable base link balls.

When doing so, the link balls can be stretched by hand at the end of the shaft as shown in the picture on the right.

When removing the shafts from the movable base, disconnect the θ -axis robot cable from the motor beforehand.




CAUTION

- Remove the spring covers before removing the shafts. The spring covers may be damaged if work is carried out without removing them.
- Take care not to pull the springs on the shafts too much. If stretched too far, the springs may not return to their original shape, possibly leading to abnormal robot movement.
- With the R6Y31110L03067NJ5 and R6Y31110H03067NJ5, R6Y31065L02067NJ5 and R6Y31065H02067NJ5 the harness is attached to the α -axis shaft. If the α -axis shaft is removed from the movable base without disconnecting the θ -axis harness from the motor, the cable will be pulled and possibly damaged, leading to potential defects. Furthermore, care should be taken not to drop the movable base.

Step 6

Arm side harness



Step 7

Wiring on shaft side



Step 8

Shaft removal



1.2 Shaft attachment

For details about how to connect the θ -axis cable, refer to "R6Y31110L03067NJ5, R6Y31110H03067NJ5, R6Y31065L02067NJ5, R6Y31065H02067NJ5 (4-axes specification)" in chapter 5.

How to attach the shaft, movable base, and spring cover is the same as the standard specifications.



NOTE

The movable base detection cable connectors (3 locations) can be connected to any matching connectors.

As the length from the shaft is already determined, connect the connectors while referring to "Configuration of drop detection cable option" in the R6Y3 Series Installation Manual.

1

Post a sign indicating that the robot is being adjusted.

Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.

2

Enter the safety enclosure.

3

Attach the shafts.

Attach the shafts while ensuring to hook the shaft plastic bearings onto the arm and movable base link balls. The link balls can be stretched by hand at the end of the shaft as shown in the picture.

The depression on the shafts for spring cover attachment should face upward.

The movable base attachment direction is as shown in the picture. Refer to "1.2 Adjusting the θ -axis origin position" in chapter 4 for details.







CAUTION

By attaching the shafts with hands placed anywhere other than the shaft end, the joint between the shaft and shaft end may deform, possibly leading to malfunction. Ensure to place hands on the end of the shaft as shown in the picture on the right.

Take care not to pull the springs on the shafts too much. If stretched too far, the springs may not return to their original shape, possibly leading to malfunction.

Step 3

Shaft attachment



Attach the spring covers.



There are a total of six spring covers: one at the arm, and one at the movable base for each of the three axes.

The top and bottom positions of the spring covers are fixed.

If the shaft direction is correct at Step 3, the cover attached at the top will be wide as shown in the picture below.

The spring covers come as a top and bottom set when shipped. Attach the covers so that they snap together at the guide clips.

► **Step 4** **Spring cover attachment**



5

Connect the harness on the arm side.

The detection cable connector is located on the left of each arm.
 Connect the cables so that they are not twisted forcibly.
 Turn the connector clockwise to lock it after inserted.

**CAUTION**

When performing the operation without locking the connector, the cable may come off and have faulty wiring.


6

Connect the connector.

Insert the connector all the way inside securely and attach the rubber cover to it.

**CAUTION**

The encoder cable connector on the arm side and the detection cable connector have the same shape.
 So, the connector can be inserted, but the wirings are different from each other.
 If not operated correctly, check for incorrect connections.

▶ **Step 5****Connecting the harness on the arm side**▶ **Step 6****Connecting the connector**

2. Harness replacement procedure

2.1 R6Y3[]110



WARNING

CARRY OUT REPLACEMENT AFTER READING “ATTACHING, DETACHING AND REPLACING THE COVER” IN CHAPTER 2.



NOTE

The harness replacement work is common to each axis.

Parts and tools necessary for the replacement work are shown below.

1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty ^{*1}	Remarks
1	Harness	S02D-MR111-00x		1	For α -axis (encoder + detection)
2	Harness	S02D-MR112-00x		1	For β -axis (detection + \varnothing 6-air joint)
3	Harness	S02D-MR113-00x		1	For γ -axis (drive power + detection)
4	Hex bolt	S02D-MR123-00x	No.8	2	* Quantity per axis
5	Cable tie	SAB80		4	

*1 : Quantity per axis

2. Required tools

Name	Part No.	Manufacturer	Remarks
Cleaning wipe			
Thread sealer	Loctite 241	Henkel	Medium strength type (blue)
Spanner	No.8		


1 *Post a sign indicating that the robot is being adjusted.*

Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.

2 *Enter the safety enclosure.*

3 *Turn the detection cable connector counterclockwise to disconnect it.*

► Step 3 Disconnecting the detection connector



- 4 ***Cut the cable ties that clamp the harness and remove the upper portion.***
- 5 ***Remove the M5 hex bolts from the harness block.***
- 6 ***Prepare new harness parts and secure them with the M5 hex bolts.***
 - Tightening torque: 6.2Nm
- 7 ***Install the upper clamp and secure it with two cable ties.***
- 8 ***Secure excess harness so that it does not interfere with the arm or cover.***

► Step 4

Cutting the cable ties and removing the upper portion



► Step 5

Removing the bolts



► Step 8

Securing the harness



2.2 R6Y3[]065



WARNING

CARRY OUT REPLACEMENT AFTER READING “ATTACHING, DETACHING AND REPLACING THE COVER” IN CHAPTER 2.



NOTE

The harness replacement work is common to each axis.

Parts and tools necessary for the replacement work are shown below.

1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty ^{*1}	Remarks
1	Harness	S02D-MR111-00x		1	For α -axis (encoder + detection)
2	Harness	S02D-MR112-00x		1	For β -axis (detection + \emptyset 6-air joint)
3	Harness	S02D-MR113-00x		1	For γ -axis (drive power + detection)
4	Hex bolt	S02D-MR123-00x	No.8	2	* Quantity per axis
5	Cable tie	SAB80		1	

*1 : Quantity per axis

2. Required tools

Name	Part No.	Manufacturer	Remarks
Cleaning wipe			
Thread sealer	Loctite 241	Henkel	Medium strength type (blue)
Spanner	No.8		

1 **Post a sign indicating that the robot is being adjusted.**

Post a sign indicating that the robot is being adjusted to prevent others from turning on the controller power.

2 **Enter the safety enclosure.**

3 **Turn the detection cable connector counterclockwise to disconnect it.**


Step 3 **Disconnecting the detection connector**



- 4 ***Cut the cable ties that clamp the harness and remove the M4 hex bolts from the clamp.***
- 5 ***Remove the M5 hex bolts from the harness block.***
- 6 ***Prepare new harness parts and secure them with the M5 hex bolts.***
 - Tightening torque: 2Nm
- 7 ***Secure the clamp with the M4 hex bolts and use the cable ties to secure the clamp at a position where is 150mm away from the clamp.***
 - Tightening torque: 2Nm
- 8 ***Secure excess harness so that it does not interfere with the arm or cover.***

▶ Step 4

Cutting the cable ties and removing the M4 bolts from the clamp



▶ Step 5

Removing the bolts



▶ Step 8

Securing the harness



3. Detection connector replacement procedure



NOTE

The work other than the detection part connector attachment and detachment is common to each axis.
Pay special attention to the connector attachment orientation.


1. Replacement parts

	Part Name	OMRON Part No.	Part No. / Specs	Q'ty	Remarks
1	Detection connector	S02D-MR109-00x		1	
2	Hex bolt	97080-04006		1	

2. Required tools

Name	Part No.	Manufacturer	Remarks
Cleaning wipe			
Thread sealer	Loctite 241	Henkel	Medium strength type (blue)
Spanner	No.7		

Configuration diagram



1


Attach the connector so that it is located on the left when viewed from the front.

Tightening torque: 4.5Nm



Step 1

Detection connector



Chapter 12

Maintenance parts

Contents

1. Consumable parts	12-1
2. Basic specification	12-2
2.1 R6Y3[]110	12-2
2.2 R6Y3[]065	12-3
3. Maintenance parts	12-4
3.1 R6Y3[]110	12-4
3.1.1 R6Y30110S03067NJ5 BASE	12-4
3.1.2 R6Y31110[]03067NJ5 BASE	12-5
3.1.3 R6Y30110S03067NJ5 AXIS	12-6
3.1.4 R6Y31110[]03067NJ5 AXIS	12-7
3.1.5 R6Y30110S03067NJ5 ARM	12-8
3.1.6 R6Y31110[]03067NJ5 ARM	12-9
3.1.7 R6Y30110S03067NJ5 SHAFT	12-10
3.1.8 R6Y31110[]03067NJ5 SHAFT	12-11
3.1.9 R6Y31110[]03067NJ5 OPTION	12-12
3.2 R6Y3[]065	12-13
3.2.1 R6Y30065S02067NJ5 BASE	12-13
3.2.2 R6Y31065[]02067NJ5 BASE	12-14
3.2.3 R6Y30065S02067NJ5 AXIS	12-15
3.2.4 R6Y31065[]02067NJ5 AXIS	12-16
3.2.5 R6Y30065S02067NJ5 ARM	12-17
3.2.6 R6Y31065[]02067NJ5 ARM	12-18
3.2.7 R6Y30065S02067NJ5 SHAFT	12-19
3.2.8 R6Y31065[]02067NJ5 SHAFT	12-20
3.2.9 R6Y31065[]02067NJ5 OPTION	12-21
3.3 R6Y3[]110, R6Y3[]065 θ -axis	12-22
3.3.1 R6Y30110S03067NJ5, R6Y30065S02067NJ5 θ	12-22
3.3.2 R6Y31110L03067NJ5, R6Y31065L02067NJ5 θ	12-23
3.3.3 R6Y31110H03067NJ5, R6Y31065H02067NJ5 θ	12-25

1. Consumable parts

Consumable part	Q'ty	Remarks
KDL-M152J-01x	12	Plastic bearing 1
KDL-M152K-00x	24	Plastic bearing 2
KDL-M219K-00x	1	Seal (inside θ -axis housing, small side)
KDL-M219K-10x	1	Seal (inside θ -axis housing, large side)
KDL-M150E-02x	1	R6Y3[]110 shaft (α -axis motor cable side, 4-axes specification)
KDL-M150F-02x	1	R6Y3[]110 shaft (α -axis encoder cable side, 4-axes specification)
KDL-M150E-10x	1	R6Y3[]065 shaft (α -axis motor cable side, 4-axes specification)
KDL-M150F-10x	1	R6Y3[]065 shaft (α -axis encoder cable side, 4-axes specification)
KDL-M211A-00x	3	R6Y3[]110 speed reduction gear (α , β and γ -axes)
KDL-M211A-10x	3	R6Y3[]065 speed reduction gear (α , β and γ -axes)
KDL-M1822-00x	1	Speed reduction gear (θ -axis for low inertia models)
KDL-M1822-10x	1	Speed reduction gear (θ -axis for high inertia models)

- θ -axis seal recommended grease
CASSIDA grease EPS 2

2. Basic specification

2.1 R6Y3[]110

Robot model			R6Y30110S03067NJ5	R6Y31110L03067NJ5	R6Y31110H03067NJ5
Working volume	X, Y axis	Stroke	Ø1100mm		
	Z axis	Stroke	300mm (max. Ø1100mm)/450mm (center Ø580mm)		
	θ axis	Rotation range		±180° (default setting, it can be changed)	
Servo motor		Arm 1, 2, 3	1000W		
		Rotational axis 4		50W	100W
Repeatability*1		X, Y, Z axis	±0.2mm		
		θ axis		±0.1°	
Maximum payload			3kg		
Maximum through-put*2			150 CPM*4		
θ axis tolerable moment of inertia*3				0.01kgm²(50W)	0.035kgm²(100W)
User tubing (outer diameter)			Ø6x1 (movable tool)		
Travel limit			Soft limit		
Protection class			IP67		
Weight			75kg		

*1: This is the value at a constant ambient temperature.

*2: With 0.1kg payload. When reciprocating 305mm in horizontal and 25mm in vertical directions.

*3: There are limits to acceleration coefficient settings.

*4: CPM: Cycle per minutes. Check the note 2 for the cycle definition.

2.2 R6Y3[]065

Robot model			R6Y30065S02067NJ5	R6Y31065L02067NJ5	R6Y31065H02067NJ5
Working volume	X, Y axis	Stroke	Ø650mm		
	Z axis	Stroke	150mm (max. Ø650mm)/250mm (center Ø480mm)		
	θ axis	Rotation range		±180° (default setting, it can be changed)	
Servo motor		Arm 1, 2, 3	400W		
		Rotational axis 4		50W	100W
Repeatability*1		X, Y, Z axis	±0.1mm		
		θ axis		±0.1°	
Maximum payload			2kg		
Maximum through-put*2			200 CPM*4		
θ axis tolerable moment of inertia*3				0.01kgm²(50W)	0.035kgm²(100W)
User tubing (outer diameter)			Ø6x1 (movable tool)		
Travel limit			Soft limit		
Protection class			IP67		
Weight			32kg		

*1: This is the value at a constant ambient temperature.

*2: With 0.1kg payload. When reciprocating 305mm in horizontal and 25mm in vertical directions.

*3: There are limits to acceleration coefficient settings.

*4: CPM: Cycle per minutes. Check the note 2 for the cycle definition.

3. Maintenance parts




CAUTION

This manual describes the parts (part numbers) when the manual is published. The part number is subject to change without prior notice. So, be sure to check that the part number is the latest one when ordering it.


3.1 R6Y3[]110

3.1.1 R6Y30110S03067NJ5 BASE




No.	Part Number	Part Name	Qty	Remarks
A1	KDL-M1101-01	BASE,1	1	
A2	KDL-M1171-00	BRACKET,1	1	
A3	KDL-M2163-10	COVER ASSY	1	
A4	KDL-M2163-00	COVER ASSY	2	
A5	KDL-M1172-00	BRACKET,2	3	
A6	KDL-M1173-00	BRACKET,3	3	
A7	KDL-M111A-00	EYE BOLT	3	
A8	97080-04010	BOLT,HEXAGON	2	
A9	97080-05008	BOLT,HEXAGON	6	
A10	KK1-M5184-10	SEAL NAME	1	
A11	90172-00J040	WASHER,EXTL.TOOTHED	2	
A12	97602-04308	SCREW,PAN HEAD W/W	2	
A13	91380-05014	BOLT HEX.SOCKET HEAD	4	
A14	91312-04020	BOLT,HEX.SOCKET HEAD	12	
A15	KDL-M212F-10	COVER,CABLE3	3	
	KDL-M212F-00	COVER,CABLE3	3	For L type connector
A16	KDL-M211A-00	REDUCTION GEAR	3	
A17	90200-03J850	O-RING	3	
A18	R88M-K1K030T-BS2	SERVO MOTOR	3	
A19	KDL-M2138-00	SEAL	3	
A20	KDL-M4851-00	SW ASSY	3	
A21	KDL-M212A-00	COVER CABLE 1	3	
A22	KDL-M2165-00	COVER,2	3	
A23	90112-10J030	BOLT HEX.S.H.:M10X30	12	
A24	91312-08025	BOLT HEX.SOCKET HEAD	12	

3.1.2 R6Y31110[03067NJ5 BASE




No.	Part Number	Part Name	Qty	Remarks
A1	KDL-M1101-01	BASE,1	1	
A2	KDL-M1171-00	BRACKET,1	1	
A3	KDL-M2163-10	COVER ASSY	1	
A4	KDL-M2163-00	COVER ASSY	2	
A5	KDL-M1172-00	BRACKET,2	3	
A6	KDL-M1173-00	BRACKET,3	3	
A7	KDL-M111A-00	EYE BOLT	3	
A8	97080-04006	BOLT,HEXAGON	6	
A9	97080-05008	BOLT,HEXAGON	6	
A10	KK1-M5184-10	SEAL NAME	1	
A11	90172-00J040	WASHER,EXTL.TOOTHED	2	
A12	97602-04308	SCREW,PAN HEAD W/W	2	
A13	91380-05014	BOLT HEX.SOCKET HEAD	4	
A14	91312-04020	BOLT,HEX.SOCKET HEAD	12	
A15	KDL-M212F-10	COVER,CABLE3	3	For L type connector
	KDL-M212F-00	COVER,CABLE3	3	
A16	KDL-M211A-00	REDUCTION GEAR	3	
A17	90200-03J850	O-RING	3	
A18	R88M-K1K030T-BS2	SERVO MOTOR	3	
A19	KDL-M2138-00	SEAL	3	
A20	KDL-M4851-00	SW ASSY	3	
A21	KDL-M212A-00	COVER CABLE 1	3	
A22	KDL-M2165-00	COVER,2	3	
A23	90112-10J030	BOLT HEX.S.H.:M10X30	12	
A24	91312-08025	BOLT HEX.SOCKET HEAD	12	
A25	98980-04008	SCREW BINDING HEAD	1	
A26	SNK12N	NYLON CLIP	1	

3.1.3 R6Y30110S03067NJ5 AXIS




No.	Part Number	Part Name	Qty	Remarks
B1	KDL-M1520-01	ARM 1 ASSY	3	
B3	KDL-M150G-01	ARM,2 CARBON ASSY.	3	
B5	KDL-M1800-00	R-AXIS ASSY	1	
B6	KDL-M1501-00	BRACKET ASSY	1	α, β and γ-axes origin jig
B8	KDL-M1501-21	HOLDER SET	1	Plastic bearing replacement jig
B9	KDL-M4871-00	CONNECTOR,E/L 1	3	Brake release cable connector

3.1.4 R6Y31110[03067NJ5 AXIS




No.	Part Number	Part Name	Qty	Remarks
B1	KDL-M1520-01	ARM 1 ASSY	2	
B2	KDL-M1520-11	ARM 1 ASSY	1	
B3	KDL-M150G-01	ARM,2 CARBON ASSY.	2	
B4	KDL-M150G-11	ARM,2 CARBON ASSY.	1	
B5	KDL-M1800-10	R-AXIS ASSY	1	R6Y31110L03067NJ5
	KDL-M1800-20	R-AXIS ASSY	1	R6Y31110H03067NJ5
B6	KDL-M1501-00	BRACKET ASSY	1	α, β and γ-axes origin jig
B7	KDL-M1501-10	BRACKET SET	1	θ-axis origin jig
B8	KDL-M1501-21	HOLDER SET	1	Plastic bearing replacement jig
B9	KDL-M4871-00	CONNECTOR,E/L 1	3	Brake release cable connector

3.1.5 R6Y30110S03067NJ5 ARM




No.	Part Number	Part Name	Qty	Remarks
C1	KDL-M1521-01	ARM,X	3	
C2	KDL-M152A-00	JOINT,1	6	
C3	KDL-M1561-01	CAP,1	3	
C4	91312-08020	BOLT,HEX.SOCKET HEAD	18	
C5	97080-04006	BOLT,HEXAGON	9	
C11	KDL-M150H-01	ARM,CARBON ASSY.	6	
C12	KDL-M1540-00	COVER,ASSY.	6	
C15	97080-06008	BOLT,HEXAGON	3	
C16	97080-05008	BOLT,HEXAGON	6	

3.1.6 R6Y31110[03067NJ5 ARM




No.	Part Number	Part Name	Qty	Remarks
C1	KDL-M1521-01	ARM,X	3	
C2	KDL-M152A-00	JOINT,1	6	
C3	KDL-M1561-01	CAP,1	3	
C4	91312-08020	BOLT,HEX.SOCKET HEAD	18	
C5	97080-04006	BOLT,HEXAGON	7	
C6	KDL-M1573-00	CLAMP, 1	2	
C7	KDL-M1574-00	CLAMP, 2	2	
C8	\$AB80	TIE 80MM	4	
C9	99480-03008	PIN,PARALLEL	2	
C10	91312-04006	BOLT,HEX.SOCKET HEAD	2	
C11	KDL-M150H-01	ARM,CARBON ASSY.	4	
C12	KDL-M1540-00	COVER,ASSY.	6	
C13	KDL-M150H-11	ARM,CARBON ASSY.	1	
C14	KDL-M150H-21	ARM,CARBON ASSY.	1	
C15	97080-06008	BOLT,HEXAGON	3	
C16	97080-05008	BOLT,HEXAGON	4	
C17	KDL-M4815-00	CABLE,TERMINAL 5	1	
C18	KDL-M152N-00	BOLT	2	

3.1.7 R6Y30110S03067NJ5 SHAFT




No.	Part Number	Part Name	Qty	Remarks
D1	KDL-M150A-01	ARM 1 CARBON	6	
D2	KDL-M152J-01	BEARING,1	12	
D4	KDL-M152M-00	SPRING	12	
D5	KDL-M1534-00	PLATE,1	24	
D6	KDL-M152K-00	BEARING,2	24	
D7	KDL-M153A-00	BLOCK,1	12	
D8	KDL-M1542-00	COVER,2	6	
D9	KDL-M1543-00	COVER,3	6	
D10	98980-03006	SCREW,BINDING HEAD	24	

3.1.8 R6Y31110[03067NJ5 SHAFT



No.	Part Number	Part Name	Qty	Remarks
D1	KDL-M150A-01	ARM 1 CARBON	4	
D2	KDL-M152J-01	BEARING,1	12	
D4	KDL-M152M-00	SPRING	12	
D5	KDL-M1534-00	PLATE,1	24	
D6	KDL-M152K-00	BEARING,2	24	
D7	KDL-M153A-00	BLOCK,1	12	
D8	KDL-M1542-00	COVER,2	6	
D9	KDL-M1543-00	COVER,3	6	
D10	98980-03006	SCREW,BINDING HEAD	24	
D11	KDL-M150E-02	ARM 2 CARBON	1	
D12	KDL-M150F-02	ARM 3 CARBON	1	


3.1.9 R6Y31110[03067NJ5 OPTION



No.	Part Number	Part Name	Qty	Remarks
A25	98980-04008	SCREW BINDING HEAD	1	
A26	\$NKG12N	NYLON CLIP	1	
C5	97080-04006	BOLT,HEXAGON	3	
C6	KDL-M1573-00	CLAMP, 1	6	
C7	KDL-M1574-00	CLAMP, 2	6	
C8	\$AB80	TIE 80MM	12	
C9	99480-03008	PIN,PARALLEL	6	
C10	91312-04010	BOLT	6	
C17	S02D-MR111-00	CABLE,TERMINAL 6	1	
C18	S02D-MR112-00	CABLE,TERMINAL 7	1	
C19	S02D-MR113-00	CABLE,TERMINAL 8	1	
C20	KDL-M152N-00	BOLT	6	
D1	KDL-M150A-00	ARM 1 CARBON	1	
D11	KDL-M150E-02	ARM,2 CARBON	1	
D12	KDL-M150F-02	ARM,3 CARBON	1	
D13	S02D-MR116-00	ARM,4 CARBON	3	
E1	S02D-MR108-00	BASE, 2	1	
E32	S02D-MR109-00	CABLE,TERMINAL 9	3	
E33	97080-04006	BOLT,HEXAGON	6	


3.2 R6Y3[]065

3.2.1 R6Y30065S02067NJ5 BASE




No.	Part Number	Part Name	Qty	Remarks
A1	KDL-M1101-10	BASE,1	1	
A2	KDL-M2163-50	COVER ASSY	1	
A3	KDL-M2163-40	COVER ASSY	2	
A4	KDL-M1172-00	BRACKET,2	3	
A5	KDL-M1193-00	STAY,COVER	3	
A6	KDL-M111A-10	EYE BOLT	3	
A7	97080-05008	BOLT,HEXAGON	6	
A8	KK1-M5184-10	SEAL NAME	1	
A9	90172-00J040	WASHER,EXTL.TOOTHED	2	
A10	97602-04308	SCREW,PAN HEAD W/W	2	
A11	91312-04010	BOLT,HEX.SOCKET HEAD	6	
A12	91312-04020	BOLT,HEX.SOCKET HEAD	6	
A13	KDL-M212F-20	COVER,CABLE3	3	
A14	KDL-M211A-10	REDUCTION GEAR	3	
A15	90200-01J530	O-RING	3	
A16	R88M-K40030T-BS2	SERVO MOTOR	3	
A17	KDL-M2138-10	SEAL	3	
A18	KDL-M4851-00	SW ASSY	3	
A19	KDL-M212A-10	COVER,CABLE,1	3	
A20	91380-08025	BOLT,HEX.SOCKET HEAD	12	
A21	91380-04014	BOLT,HEX.SOCKET HEAD	12	

3.2.2 R6Y31065[|02067NJ5 BASE




No.	Part Number	Part Name	Qty	Remarks
A1	KDL-M1101-10	BASE,1	1	
A2	KDL-M2163-50	COVER ASSY	1	
A3	KDL-M2163-40	COVER ASSY	2	
A4	KDL-M1172-00	BRACKET,2	3	
A5	KDL-M1193-00	STAY,COVER	3	
A6	KDL-M111A-10	EYE BOLT	3	
A7	97080-05008	BOLT,HEXAGON	6	
A8	KK1-M5184-10	SEAL NAME	1	
A9	90172-00J040	WASHER,EXTL.TOOTHED	2	
A10	97602-04308	SCREW,PAN HEAD W/W	2	
A11	91312-04010	BOLT,HEX.SOCKET HEAD	6	
A12	91312-04020	BOLT,HEX.SOCKET HEAD	6	
A13	KDL-M212F-20	COVER,CABLE3	3	
A14	KDL-M211A-10	REDUCTION GEAR	3	
A15	90200-01J530	O-RING	3	
A16	R88M-K40030T-BS2	SERVO MOTOR	3	
A17	KDL-M2138-10	SEAL	3	
A18	KDL-M4851-00	SW ASSY	3	
A19	KDL-M212A-10	COVER,CABLE,1	3	
A20	91380-08025	BOLT,HEX.SOCKET HEAD	12	
A21	91380-04014	BOLT,HEX.SOCKET HEAD	12	
A22	KAU-M229N-00	CLAMP	1	
A23	98780-04008	SCREW,FLAT HEAD	1	
A24	\$AB80	TIE 80	1	

3.2.3 R6Y30065S02067NJ5 AXIS




No.	Part Number	Part Name	Qty	Remarks
B1	KDL-M1520-21	ARM 1 ASSY	3	
B2	KDL-M150G-21	ARM,2 CARBON ASSY.	3	
B3	KDL-M1800-00	R-AXIS ASSY	1	
B4	KDL-M1501-30	BRACKET ASSY	1	
B5	KDL-M1501-21	HOLDER SET	1	
B6	KDL-M4871-00	CONNECTOR,E/L 1	3	

3.2.4 R6Y31065[|02067NJ5 AXIS




No.	Part Number	Part Name	Qty	Remarks
B1	KDL-M1520-21	ARM 1 ASSY	2	
B2	KDL-M1520-31	ARM 1 ASSY	1	
B3	KDL-M150G-21	ARM,2 CARBON ASSY.	2	
B4	KDL-M150G-31	ARM,2 CARBON ASSY.	1	
B5	KDL-M1800-10	R-AXIS ASSY	1	R6Y31065L02067NJ5
	KDL-M1800-20	R-AXIS ASSY	1	R6Y31065H02067NJ5
B6	KDL-M1501-30	BRACKET ASSY	1	
B7	KDL-M1501-21	HOLDER SET	1	
B8	KDL-M4871-00	CONNECTOR,E/L 1	1	

3.2.5 R6Y30065S02067NJ5 ARM




No.	Part Number	Part Name	Qty	Remarks
C1	KDL-M1521-10	ARM,X	3	
C2	KDL-M152F-00	JOINT,3	3	
C3	KDL-M152A-00	JOINT,1	6	
C4	KDL-M1561-10	CAP,1	3	
C5	97080-04006	BOLT,HEXAGON	15	
C6	91380-06016	BOLT,HEX.SOCKET HEAD	18	
C7	KDL-M150H-31	ARM,CARBON ASSY.	6	
C8	KDL-M1540-00	COVER,ASSY.	6	

3.2.6 R6Y31065[]02067NJ5 ARM




No.	Part Number	Part Name	Qty	Remarks
C1	KDL-M1521-10	ARM,X	3	
C2	KDL-M152F-00	JOINT,3	3	
C3	KDL-M152A-00	JOINT,1	6	
C4	KDL-M1561-10	CAP,1	3	
C5	97080-04006	BOLT,HEXAGON	10	
C6	91380-06016	BOLT,HEX.SOCKET HEAD	18	
C7	KDL-M1573-10	CLAMP, 1	2	
C8	97080-04020	BOLT,HEXAGON	2	
C9	KDL-M153E-00	BLOCK,2	1	
C10	91380-04030	BOLT,HEX.SOCKET HEAD	3	
C11	KDL-M4815-00	CABLE,TERMINAL 5	1	
C12	KDL-M152N-00	BOLT	2	
C13	KDL-M150H-31	ARM,CARBON ASSY.	4	
C14	KDL-M150H-41	ARM,CARBON ASSY.	1	
C15	KDL-M150H-51	ARM,CARBON ASSY.	1	
C16	KDL-M1540-00	COVER,ASSY.	6	

3.2.7 R6Y30065S02067NJ5 SHAFT




No.	Part Number	Part Name	Qty	Remarks
D1	KDL-M150A-20	ARM 1 CARBON	6	
D2	KDL-M152J-01	BEARING,1	12	
D3	KDL-M152M-00	SPRING	12	
D4	KDL-M1534-00	PLATE,1	24	
D5	KDL-M152K-00	BEARING,2	24	
D6	KDL-M153A-00	BLOCK,1	12	
D7	KDL-M1542-00	COVER,2	6	
D8	KDL-M1543-00	COVER,3	6	
D9	98980-03006	SCREW,BINDING HEAD	24	

3.2.8 R6Y31065[|02067NJ5 SHAFT



No.	Part Number	Part Name	Qty	Remarks
D1	KDL-M150A-20	ARM 1 CARBON	4	
D2	KDL-M152J-01	BEARING,1	12	
D3	KDL-M152M-00	SPRING	12	
D4	KDL-M1534-00	PLATE,1	24	
D5	KDL-M152K-00	BEARING,2	24	
D6	KDL-M153A-00	BLOCK,1	12	
D7	KDL-M1542-00	COVER,2	6	
D8	KDL-M1543-00	COVER,3	6	
D9	98980-03006	SCREW,BINDING HEAD	24	
D10	KDL-M150E-10	ARM 2 CARBON	1	
D11	KDL-M150F-10	ARM 3 CARBON	1	


3.2.9 R6Y31065[]02067NJ5 OPTION




No.	Part Number	Part Name	Qty	Remarks
A22	KAU-M229N-00	CLAMP	3	
A23	98780-04008	SCREW,FLAT HEAD	3	
A24	\$AB80	TIE 80	3	
C7	KDL-M1573-10	CLAMP, 1	6	
C8	97080-04020	BOLT,HEXAGON	6	
C9	KDL-M153E-00	BLOCK,2	3	
C10	91380-04030	BOLT,HEX.SOCKET HEAD	9	
C17	S02D-MR111-00	CABLE,TERMINAL 6	1	
C18	S02D-MR112-00	CABLE,TERMINAL 7	1	
C19	S02D-MR113-00	CABLE,TERMINAL 8	1	
C20	KDL-M152N-00	BOLT	6	
D1	KDL-M150A-20	ARM,1 CARBON	1	
D10	KDL-M150E-10	ARM,2 CARBON	1	
D11	KDL-M150F-10	ARM,3 CARBON	1	
D12	S02D-MR116-00	ARM,4 CARBON	3	
E1	S02D-MR108-00	BASE,2	1	
E32	S02D-MR109-00	CABLE,TERMINAL	3	
E33	97080-04006	BOLT,HEXAGON	6	

3.3 R6Y3[]110, R6Y3[]065 0-axis


3.3.1 R6Y30110S03067NJ5, R6Y30065S02067NJ5 0



No.	Part Number	Part Name	Qty	Remarks
E1	KDL-M1102-01	BASE,2	1	
E2	KDL-M152A-00	JOINT,1	6	
E3	KDL-M181A-01	BRACKET,1	1	
E4	KDL-M1846-00	PLATE ,1	1	
E5	97080-04010	BOLT,HEXAGON	3	
E6	91380-04012	BOLT HEX.SOCKET HEAD	6	
E7	STL6-01	JOINT	1	



No.	Part Number	Part Name	Qty	Remarks
E1	KDL-M1102-01	BASE,2	1	
E2	KDL-M152A-00	JOINT,1	6	
E3	R88M-K05030T-S2	SERVO MOTOR	1	
E4	KDL-M1822-00	REDUCTION GEAR	1	
E5	KDL-M1811-00	HOUSING,1	1	
E6	KDL-M1830-00	SPACER	1	
E7	KDL-M1870-00	SHAFT	1	
E8	KDL-M1843-00	HOLDER,SHAFT 1	1	
E9	KDL-M1844-00	HOLDER,SHAFT 2	1	
E10	KDL-M182E-00	COVER R AXIS	1	
E11	KDL-M1861-00	WASHER	6	
E12	KDL-M4811-00	CABLE,TERMINAL 1	1	
E13	KDL-M4812-00	CABLE,TERMINAL 2	1	
E14	KDL-M4813-00	CABLE,TERMINAL 3	1	
E15	KDL-M4814-00	CABLE,TERMINAL 4	1	
E16	KDL-M212E-00	COVER,CABLE 2	2	
E17	KN5-M2144-00	O RING,,3	1	
E18	KN6-M1895-00	O RING,1	1	
E19	KDL-M219K-00	SEAL	1	
E20	KDL-M219K-10	SEAL	1	
E21	KDL-M1816-00	COVER,1	1	
E22	\$TL6-01	JOINT	1	
E23	97080-04010	BOLT,HEXAGON	6	
E24	91380-03006	BOLT HEX.SOCKET HEAD	8	
E25	91380-03008	BOLT HEX.SOCKET HEAD	6	
E26	91380-03010	BOLT HEX.SOCKET HEAD	4	
E27	91380-04008	BOLT HEX.SOCKET HEAD	3	
E28	91380-04014	BOLT HEX.SOCKET HEAD	2	
E29	91380-04012	BOLT HEX.SOCKET HEAD	2	
E30	91380-04020	BOLT HEX.SOCKET HEAD	6	
E31	97980-04308	SCREW P/H W/W (+-)	2	



No.	Part Number	Part Name	Qty	Remarks
E1	KDL-M1102-01	BASE,2	1	
E2	KDL-M152A-00	JOINT,1	6	
E3	R88M-K10030T-S2	SERVO MOTOR	1	
E4	KDL-M1822-10	REDUCTION GEAR	1	
E5	KDL-M1811-00	HOUSING,1	1	
E6	KDL-M1830-00	SPACER	1	
E7	KDL-M1870-00	SHAFT	1	
E8	KDL-M1843-00	HOLDER,SHAFT 1	1	
E9	KDL-M1844-00	HOLDER,SHAFT 2	1	
E10	KDL-M182E-00	COVER R AXIS	1	
E11	KDL-M1861-00	WASHER	6	
E12	KDL-M4811-00	CABLE,TERMINAL 1	1	
E13	KDL-M4812-00	CABLE,TERMINAL 2	1	
E14	KDL-M4813-00	CABLE,TERMINAL 3	1	
E15	KDL-M4814-00	CABLE,TERMINAL 4	1	
E16	KDL-M212E-00	COVER,CABLE 2	2	
E17	KN5-M2144-00	O RING,,3	1	
E18	KN6-M1895-00	O RING,1	1	
E19	KDL-M219K-00	SEAL	1	
E20	KDL-M219K-10	SEAL	1	
E21	KDL-M1816-00	COVER,1	1	
E22	\$TL6-01	JOINT	1	
E23	97080-04010	BOLT,HEXAGON	6	
E24	91380-03006	BOLT HEX.SOCKET HEAD	8	
E25	91380-03008	BOLT HEX.SOCKET HEAD	6	
E26	91380-03010	BOLT HEX.SOCKET HEAD	4	
E27	91380-04008	BOLT HEX.SOCKET HEAD	3	
E28	91380-04014	BOLT HEX.SOCKET HEAD	2	
E29	91380-04012	BOLT HEX.SOCKET HEAD	2	
E30	91380-04020	BOLT HEX.SOCKET HEAD	6	
E31	97980-04308	SCREW P/H W/W (+-)	2	

Revision history

A manual revision code appears as a suffix to the catalog number on the front cover manual.

Cat. No. I195E-EN-03



The following table outlines the changes made to the manual during each revision.

Revision code	Date	Description
01	June 2013	Original production
01A	September 2013	Delta robot model references have been modified
01B	April 2014	Illustrations were changed, text errors were corrected
01C	May 2014	Gear box bolt was modified
02	November 2014	In Chapter 7, the section "1. Plastic bearing replacement procedure" was updated In Chapter 10, new section "2.1.2 Arm harness replacement" was added New Chapter 11 "Option parts replacement" was added In Chapter 12, new section "3. Maintenance parts" was added Replacement parts and details of tools to be prepared were added and changed, small errors were corrected
03	August 2015	Mini Delta robot models (R6Y3[]065) were added. New subchapter "1.2.3 Attaching the spring cover (Reinforced Spring Cover common to 3-axes and 4-axes)" was added into Chapter 5



Authorized Distributor: