

## Portable Multi Logger ZR-RX40

## User's Manual



## Introduction

This manual provides information regarding functions, performance and operating methods that are required for using the ZR-RX40.

When using the ZR-RX40, be sure to observe the following:

- The ZR-RX40 must be operated by personnel knowledgeable in electrical engineering.
- To ensure correct use, please read this manual thoroughly to deepen your understanding of the product.
- Please keep this manual in a safe place so that it can be referred to whenever necessary.

## Registered Trademarks


- Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corp. in the United States and/or other countries.
- Other product and company names herein may be either registered trademarks or trademarks of their respective owners.

## Type of Manuals

The manuals of the ZR-RX40 series consist of the following.

Select the manual suitable for your purpose and read it before starting operation.

### Manual packaged in the product (brochure)



#### Start Up Guide

The basic information to use the ZR-RX40 series is described, such as the information for safe and correct use, confirmation of the package, procedure from connection to measurement, and the information of functions and specifications of the ZR-RX40 series.

### Manuals contained in the utility CD-ROM (pdf data)



#### Software Manual

- How to install PC software, "Smart Viewer RX40"
- Basic operation
- Explanation of screen and setting methods

#### Start Up Guide

Same contents as the above referenced "Start Up Guide" packaged in the product.

#### User's Manual (this manual)

- Information for safe and correct use
- Before use: connection and wiring in details, language change of display, etc.
- Procedure in details for setting and measurement
- Specifications of the ZR-RX40 series and accessories
- Other information which is required for the use of the ZR-RX40 series

# User's Manual

APPLICATION CONSIDERATIONS  
(Please Read)

BEFORE USE

1

SETTINGS AND MEASUREMENT

2

SPECIFICATIONS

3

## **READ AND UNDERSTAND THIS DOCUMENT**

Please read and understand this document before using the products. Please consult your OMRON representative if you have any questions or comments.

## **WARRANTY**

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year (or other period if specified) from date of sale by OMRON.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

## **LIMITATIONS OF LIABILITY**

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY.

In no event shall responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.

IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR, OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED, AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE, OR INAPPROPRIATE MODIFICATION OR REPAIR.

## **SUITABILITY FOR USE**

THE PRODUCTS CONTAINED IN THIS DOCUMENT ARE NOT SAFETY RATED. THEY ARE NOT DESIGNED OR RATED FOR ENSURING SAFETY OF PERSONS, AND SHOULD NOT BE RELIED UPON AS A SAFETY COMPONENT OR PROTECTIVE DEVICE FOR SUCH PURPOSES.

Please refer to separate catalogs for OMRON's safety rated products.

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of products in the customer's application or use of the product.

At the customer's request, OMRON will provide applicable third party certification documents identifying ratings and limitations of use that apply to the products. This information by itself is not sufficient for a complete determination of the suitability of the products in combination with the end product, machine, system, or other application or use.

The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of the products, nor is it intended to imply that the uses listed may be suitable for the products:

- Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this document.

- Nuclear energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations.
- Systems, machines, and equipment that could present a risk to life or property.

Please know and observe all prohibitions of use applicable to the products.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

## **PERFORMANCE DATA**

Performance data given in this document is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of OMRON's test conditions, and the users must correlate it to actual application requirements. Actual performance is subject to the OMRON Warranty and Limitations of Liability.

## **CHANGE IN SPECIFICATIONS**

Product specifications and accessories may be changed at any time based on improvements and other reasons.

It is our practice to change model numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the product may be changed without any notice. When in doubt, special model numbers may be assigned to fix or establish key specifications for your application on your request. Please consult with your OMRON representative at any time to confirm actual specifications of purchased products.

## **DIMENSIONS AND WEIGHTS**

Dimensions and weights are nominal and are not to be used for manufacturing purposes, even when tolerances are shown.

## **ERRORS AND OMISSIONS**

The information in this document has been carefully checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical, or proofreading errors, or omissions.

## **PROGRAMMABLE PRODUCTS**

OMRON shall not be responsible for the user's programming of a programmable product, or any consequence thereof.

## **COPYRIGHT AND COPY PERMISSION**

This document shall not be copied for sales or promotions without permission.

This document is protected by copyright and is intended solely for use in conjunction with the product. Please notify us before copying or reproducing this document in any manner, for any other purpose. If copying or transmitting this document to another, please copy or transmit it in its entirety.

## Meanings of Signal Words

The following signal words are used in this manual.



**WARNING**

Indicates a potentially hazardous situation which, if not avoided, will result in minor or moderate injury, or may result in serious injury or death. Additionally there may be significant property damage.



**CAUTION**

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or in property damage.

## Meanings of Alert Symbols

The following alert symbols are used in this manual.



Indicates the possibility of explosion under specific conditions.



Indicates the possibility of electric shock under specific conditions.



Indicates prohibition when there is a risk of minor injury from electrical shock or other source if the product is disassembled.



Indicates general prohibitions for which there is no specific symbol.

## Alert Statements in this Manual

The following alert statements apply to the products in this manual. Each alert statement also appears at the locations needed in this manual to attract your attention.



### WARNING

This product cannot be used for directly or indirectly detecting human bodies to ensure safety.

Do not use this product as a human body protection device.



Serious hazard may occur in rare occasions due to ignition, rupture or combustion of the lithium battery contained in this product.

Never disassemble, deform under pressure, heat or incinerate this product.



Serious hazard may occur in rare occasions due to ignition, rupture or combustion.

Never disassemble, deform under pressure, heat or incinerate the lithium ion battery pack ZR-XRB1 (GRAPHTEC: B-517).



### CAUTION

Injuries from electric shock may occur in rare occasions as the result of disassembly.

Never disassemble, deform under pressure or incinerate the main unit.



Hazard may occur from serious fire or electric shock.

Do not connect voltages exceeding the rated voltage to the signal input terminals.



Fire or hazard may occur in rare occasions from ignition, rupture or combustion.

Do not use battery packs other than ZR-XRB1.



## Precautions for Safe Use

Be sure to observe the following items as they are very important to ensure safety.

### 1. Installation environment

- Do not store or use in locations where the temperature exceeds the rated range.
- Do not use in locations where the relative humidity exceeds the 30 to 80 %RH range.
- Do not use in locations subject to steam.
- Do not use in flammable or explodable gas environment.

### 2. Power supply and wiring

- Do not connect voltages exceeding the rated voltage to signal cables.
- Be sure to check the polarity of the signals when connecting the signal cables.
- When using the battery pack, be sure to read the cautions on the battery pack carefully for correct usage.
- Be sure to use only the specified battery pack.
- Be sure to use only the AC cable and the AC adapter provided as standard accessories.
- Do not connect power supplies exceeding the rated voltage to the AC adapter.
- Be sure to turn off the power supply when connecting to the input terminals.
- Do not touch the input terminals during measurement.

### 3. Others

- Dispose of this product as industrial waste.
- If there are any troubles, stop usage immediately, turn off the power supply and contact OMRON branch or sales office.



## Precautions for Correct Use

Please observe the following precautions to prevent inoperability, misoperation of the product or negative effects on the performance and the device.

### 1. Installation Location

Do not install this product in the following locations.

- Locations where the temperature exceeds the rated range
- Locations where severe changes in temperature occur (where condensation occurs)
- Locations subject to corrosive or flammable gases
- Locations subject to dust, salt or iron powder
- Locations subject to direct shock or vibration
- Locations subject to direct sunlight or near heating devices
- Locations where water, oil or chemical products may be splashed
- Locations subject to strong magnetic fields or strong electric fields

### 2. Power supply, connecting and wiring

- The cables should be wired apart from high-tension or power lines.  
Malfunction or damage may occur due to induction.
- After wiring, check the adequacy of power supply voltage, miswiring such as overvoltage/load short-circuiting and adequacy of load current before turning on the power supply.  
Malfunction may occur due to miswiring and such.
- Always turn off the power supply when attaching or removing peripheral devices.  
Attaching or removing of peripheral devices with the power supply on can cause malfunction or data corruption.

### 3. Installation

- Do not cover the vent hole when using this product.  
Leave at least 30cm of installation space around this product.  
The generated heat may cause malfunction or damage.
- When measuring temperature, install the product so that the input terminals are not subject to severe changes in temperature by wind or sunlight.  
It may cause calculation errors.
- Do not install this product in a slanted or vertical position.
- Connect the GND terminal for safe measurement. This product must also be grounded when sharing a common ground level with other devices.

### 4. Warm up

- For stable measurement, wait at least 30 minutes after turning on the power supply before using.

### 5. Handling

- Be sure to take backups of captured data in your PC. The captured content may be altered or lost due to misuse or malfunctions during usage.
- Do not drop or apply strong impact or force to the product.  
It may cause malfunction of the monitor or the main unit.

### 6. Maintenance

- Do not use thinner, benzene, acetone or kerosene to clean this product.
- Calibration should be performed periodically to maintain measurement accuracy.

## Checking the Accessories

Item	Remarks	Quantity
Main unit	ZR-RX40	1
Start Up Guide		1
Utility disk	<ul style="list-style-type: none"><li>• Basic PC software “Smart Viewer RX40”</li><li>• Start Up Guide PDF files</li><li>• User's Manual PDF files</li><li>• “Smart Viewer RX40” Software Manual PDF files</li></ul>	1
AC cable/AC adapter	100 to 240 VAC, 50/60 Hz	1

## Editor's Note

### ■ Meaning of Symbols

Menu items that are displayed on the ZR-RX40's LCD screen, and windows, dialog boxes and other GUI elements displayed on the PC are indicated enclosed by brackets "[ ]".

### ■ Visual Aids

#### Important

Indicates points that are important to achieve the full product performance, such as operational precautions.

#### Note

Indicates application procedures.



Indicates pages where related information can be found.

# CONTENTS

## 1.BEFORE USE

<b>Features</b> .....	<b>16</b>
<b>Part Names and Functions</b> .....	<b>17</b>
<b>Connecting the Power Cable</b> .....	<b>18</b>
Connecting to an AC Power Supply. ....	18
Connecting to a DC Power Supply .....	19
<b>Connecting the Analog Input Terminal</b> .....	<b>21</b>
Terminal Configuration and Signal Types .....	21
Connection diagram .....	21
<b>Connecting the Logic Input Terminal</b> .....	<b>22</b>
Circuit Example of Relay Drive by Alarm Output .....	23
<b>Attaching USB Memory</b> .....	<b>24</b>
Inserting a USB Memory .....	24
<b>Connecting to a PC</b> .....	<b>25</b>
Connection Using a USB Cable .....	25
LAN Connection .....	26
<b>Using the Battery Pack</b> .....	<b>27</b>
Mounting the Battery Pack .....	27
Charging the Battery .....	28
<b>Connecting the Humidity Sensor</b> .....	<b>29</b>
<b>Mounting and Removing the Terminal Unit</b> .....	<b>30</b>
To Remove .....	30
To Mount .....	31
<b>Mounting the Extension Terminal Base Set</b> .....	<b>32</b>
Set Contents .....	32
To Mount .....	32
<b>Mounting the 20 Channel Extension Terminal Set</b> .....	<b>34</b>
Set Contents .....	34
To Mount .....	34
<b>Precautions to Observe When Performing Measurement</b> .....	<b>37</b>
<b>Noise Countermeasures</b> .....	<b>38</b>
<b>Setting the Date and Time</b> .....	<b>39</b>
How to Recharge the Rechargeable Battery .....	39
How to Set the Date and Time .....	39

## 2.SETTINGS AND MEASUREMENT

<b>Window names and functions</b> .....	<b>42</b>
<b>Key Operation</b> .....	<b>44</b>
(1) CH GROUP .....	44
(2) SPAN/TRACE/POSITION .....	45
(3) TIME/DIV .....	46
(4) MENU .....	46
(5) QUIT (LOCAL) .....	46
(6) Direction keys .....	47
(7) ENTER .....	47
(8) FAST FORWARD key (KEY LOCK) .....	47
(9) START/STOP (USB Drive Mode) .....	48
(10) REVIEW .....	49
(11) DISPLAY .....	50
(12) CURSOR (ALARM CLEAR) .....	51
(13) FILE .....	51
(14) NAVI .....	52
<b>Operation Modes</b> .....	<b>53</b>
(1) Free Running .....	53
(2) Capturing .....	54
(3) Dual View Replaying .....	54
(4) Replaying .....	55
<b>Setting Menus</b> .....	<b>56</b>
(1) AMP settings .....	56
(2) DATA settings .....	61
(3) TRIG settings .....	63
(4) USER settings .....	68
(5) Interface settings .....	70
(6) OTHR settings .....	71
(7) Other menus .....	73
<b>WEB Server Function</b> .....	<b>84</b>

## 3.SPECIFICATIONS

<b>Standard Specifications</b> .....	<b>90</b>
Standard Specifications .....	90
Main Functions .....	92
<b>Accessory/Option Specifications</b> .....	<b>94</b>
Accessories .....	94
Options .....	94
Humidity Sensor ZR-XRH1 .....	95

<b>External Dimensions</b> .....	<b>96</b>
<b>INDEX</b> .....	<b>97</b>
<b>Revision History</b> .....	<b>100</b>

# BEFORE USE

<b>Features</b>	<b>16</b>
<b>Part Names and Functions</b>	<b>17</b>
<b>Connecting the Power Cable</b>	<b>18</b>
<b>Connecting the Analog Input Terminal</b>	<b>21</b>
<b>Connecting the Logic Input Terminal</b>	<b>22</b>
<b>Attaching USB Memory Device</b>	<b>24</b>
<b>Connecting to a PC</b>	<b>25</b>
<b>Using the Battery Pack</b>	<b>27</b>
<b>Connecting the Humidity Sensor</b>	<b>29</b>
<b>Mounting and Removing the Terminal Unit</b>	<b>30</b>
<b>Mounting the Extension Terminal Base Set</b>	<b>32</b>
<b>Mounting the 20 Channel Extension Terminal Set</b>	<b>34</b>
<b>Precautions to Observe When Performing Measurement</b>	<b>37</b>
<b>Noise Countermeasures</b>	<b>38</b>
<b>Setting the Date and Time</b>	<b>39</b>
<b>Changing the Display Language</b>	<b>40</b>

# Features

The ZR-RX40 (with color monitor and internal memory) are compact, lightweight, multi-channel data loggers.

ZR-RX40 are provided with 20 channels as a standard measurement feature, or can be extended up to 200 channels by attaching additional terminal sets.

ZR-RX40 is equipped with an internal flash memory, and attaching USB memory device also allows you to directly capture a large volume of data to USB memory device.

Furthermore, the data loggers are equipped with USB and Ethernet interfaces to a PC to enable system configurations according to your application.

The Ethernet feature includes WEB and FTP server functions which allow monitoring from a remote location and data transfer.

## Input

- Adoption of a pluggable M3 screw type input terminal facilitates wiring.
- The ZR-RX40 is provided with 20 channels as a standard measurement feature, or can be extended up to 200 channels by attaching additional terminal sets.
- All channels are isolated, enabling measurement of signals of different references.

## Display & Operation

- With the ZR-RX40's 5.7-inch TFT color liquid crystal display, you can confirm the waveforms of measured data and each channel's settings at a glance.
- Easy operation is achieved through a straightforward menu structure and key allocation which resembles mobile phones.

## Data Capture

- Data can be directly captured and maintained in the internal or USB memory device.
- Internal memory used for the built-in memory maintains captured data even after the power is turned off.
- The Internal memory can be used with disk images thus multiple data items can be maintained.


## Data Control & Processing

- The PC software provided lets you set conditions and monitor data on a PC.
- The USB drive mode function enables the ZR-RX40's internal memory to be recognized as an external drive by your PC. (Connect the ZR-RX40 to your PC and turn on the power supply to the ZR-RX40 while holding down the START key.)
- Captured data can be read from the PC software to files and displayed for processing.
- Data can be transferred off-line to a computer using USB memory device.
- The WEB server function enables control and monitoring from a remote location without using dedicated software.
- The FTP server function enables handling internal memory and USB memory data from a PC.



# Part Names and Functions

This section describes the names and function of parts of the ZR-RX40.



# Connecting the Power Cable

This section describes how to connect the power cable and turn on the power. The connection method will vary depending on the type of power supply used.


## Connecting to an AC Power Supply

Use the AC cable and AC adapter that are provided as accessories.


### Important

Be sure to use only the AC cable and the AC adapter provided as standard accessories.


#### **1** Plug the AC cable into the AC adapter.



#### **2** Connect the output side of the AC adapter to the AC adapter connector.



- 3** Using the flat-blade screwdriver, press against the minus (-) button above the GND terminal, while connecting the grounding cable to the ZR-RX40. Connect the other end of the cable to ground.



**Note**

The grounding cable is not provided as a standard accessory and must be prepared separately.  
[Recommended Cord Diameter: AWG18/UL1007]

- 4** Plug the AC cable into the mains power outlet.
- 5** Press the power switch on the ZR-RX40 to the ON side to turn on the power.

**Important**

Connect the GND terminal for safe measurement. The ZR-RX40 must also be grounded when sharing a common ground level with other devices.


## Connecting to a DC Power Supply

Use the DC cable (option: ZR-XRD1).

**Important**

Be sure to use the separately sold DC cable (ZR-XRD1). Do not apply voltages exceeding the rated voltage (8.5 to 24 VDC).

- 1** Connect the DC output side to the power supply connector on the ZR-RX40.



## **2** Connect the DC input side to the DC power supply.

### **Important**


Be sure to check the polarity of the power supply when connecting the DC cable.

## **3** Press the power switch on the ZR-RX40 to the ON side to turn on the power.

# Connecting the Analog Input Terminal


This section describes how to connect the analog input terminal.

## Terminal Configuration and Signal Types




## Connection diagram


### Direct voltage input




### Thermocouple input



### Resistance temperature detector input



### Direct current input




- + ..... High-voltage terminal (terminal for high-voltage input signals)
- ..... Low-voltage terminal (terminal for low-voltage input signals)
- b ..... Dedicated terminal when connecting resistance temperature detector

\*Resistance temperature detector input terminals A (+) and B (-) are isolated within each channel. Terminal b is shorted within all channels.

Item	Description
Input configuration	Isolated input, scanning
Analog voltage	20, 50, 100, 200, 500 mV/F.S.; 1, 2, 5, 10, 20, 50 V/F.S.; 1-5V
Thermocouples	K, J, E, T, R, S, B, N, W (WRe 5-26)
Resistance temperature detector	PT100, JPT100, PT1000 (IEC751)

# Connecting the Logic Input Terminal

The logic alarm cable (ZR-XRL1) enables logic/pulse input, external trigger input, and alarm signal output. Connect the logic alarm cable (ZR-XRL1) to the external input/output terminal as shown below.



## Logic/Pulse Specifications

Item	Description
Number of input channels	4
Input voltage range	0 to +24V max. (single-ended ground input)
Threshold level	Approx. +2.5V
Hysteresis	Approx. 0.5 V (+2.5 to +3 V)

\*Switch between logic and pulse input.


## Trigger Input Specifications

Item	Description
Number of input channels	1
Input voltage range	0 to +24V max. (single-ended ground input)
Threshold level	Approx. +2.5V
Hysteresis	Approx. 0.5 V (+2.5 to +3 V)

## Alarm Output Specifications

Item	Description
Number of output channels	4
Output format	Open collector output +5 V, 10 K $\Omega$ pull-up resistance Contact capacity 5 V to 24 V, 100 mA or below

# Circuit Example of Relay Drive by Alarm Output




## Wiring

Cable tips are bare tips. Perform wiring for the necessary functions.

Signal Name	Channel Number	Wire Color
Logic/Pulse output	1	Orange with red dotted line
	2	Orange with black dotted line
	3	Grey with red dotted line
	4	Grey with black dotted line
Alarm output	1	White with red dotted line
	2	White with black dotted line
	3	Yellow with red dotted line
	4	Yellow with black dotted line
Trigger input		Pink with red dotted line
GND		Pink with black dotted line
		Shielded

\*Switch between logic and pulse.




# Attaching USB Memory Device

Attaching USB memory device to the ZR-RX40 allows you store measured data directly.

## Inserting a USB Memory Device

Attach the USB memory device to the USB memory terminal.



### Important

#### <Specifications of supported USB memory>

- Power source : +5 V
- Power consumption : 250 mA or below
- Capacity : No limit (except each file must be within 2 GB)

\* USB memory device with security functions such as fingerprint authentication cannot be used.




# Connecting to a PC

Use the USB, LAN Interface to connect the ZR-RX40 to a PC.

## Connection Using a USB Cable

Use the USB cable to connect the ZR-RX40 to a PC.

**Note**

If the USB cable is used, install the USB driver in your PC.




"Installing the USB driver" in the Software Manual

**Note**

The USB connector is adjacent to the LAN connector. Make sure the cable is inserted into the correct connector.


# LAN Connection

Use a LAN cable to connect the ZR-RX40 to a PC.




## Cable Types

- Use a crossing cable when connecting directly to a PC, without using a hub.



- Use a straight cable when using a hub.




# Using the Battery Pack


Be sure to use the dedicated battery pack (option: ZR-XRB1).

## Mounting the Battery Pack

- 1** While lightly pushing the grip of the battery cover, slid the cover in the direction indicated by the arrow.



- 2** Attach the battery pack (ZR-XRB1).



Attach the battery with care of polarity and insertion direction.


### Note

Either one or two battery packs can be attached.  
To connect one pack, connect to either one of the connectors.  
Attaching two battery packs allows longer operational time.

### Note

When attaching two battery packs, make sure the battery levels are equivalent.  
Do not use a new battery with an old battery at the same time.  
When attaching two battery packs, make sure the remaining amount are same.  
If you are not sure about the amount, charge each battery and then attach full-charged two battery packs.

### 3 Attach the battery cover.



## Charging the Battery


### Note

Expected time required for charging:


- battery pack x 1: approx. 4 hours
- battery pack x 2: approx. 8 hours

The battery pack is charged by mounting it in the ZR-RX40, attaching AC adapter to the ZR-RX40.


### 1 Mount the battery pack in the ZR-RX40.

 "Mounting the Battery Pack" p.27

### 2 Turn on the power to the ZR-RX40.


 "Connecting the Power Cable" p.18

The CHARGE LED lights.



# Connecting the Humidity Sensor

Connect the + and - lead wires of the humidity sensor (option: ZR-XRH1) to the desired terminals, and then insert the round connector into the 5V OUT connector on the ZR-RX40.



# Mounting and Removing the Terminal Unit


Remove and mount terminal units as shown below.

## Important

Make sure the ZR-RX40's power is OFF when removing or mounting terminal units.



## To Remove

Pull the terminal unit out towards the direction indicated by the arrow while pressing the two locks at the bottom of the unit.



## To Mount

Insert the tabs at the top of the terminal unit into the slots of the ZR-RX40, and push in the unit until the lock tabs at the bottom of the unit are securely locked.




# Mounting the Extension Terminal Base Set

Mount the extension terminal base set (ZR-XRE1) as shown below.


## Important

Make sure the ZR-RX40's power is OFF when mounting the extension terminals.

## Set Contents



Extension Terminal Base Unit : 1





Extension Terminal Cable : 1

## To Mount


- 1** Remove the terminal unit mounted to the ZR-RX40 ( p.26).
- 2** Insert the tabs at the top of the terminal unit into the slots of the extension terminal base unit, and push in the unit until the lock tabs at the bottom of the unit are securely locked.

(1) Insert tabs at the top of the terminal unit into the slots of the extension terminal base unit.



(2) Press the unit in the direction shown until it is securely locked.


- 3** Connect the extension terminal cable to the extension terminal base unit.  
\* Press in the cable until it is securely locked.





#### 4 Connect the other end of the extension terminal cable to ZR-RX40.

\* Press in the cable until it is securely locked.




# Mounting the 20 Channel Extension Terminal Set

Mount the 20 channel extension terminal set (ZR-XRT1) as shown below.


## Important

Make sure the ZR-RX40's power is OFF when mounting the extension terminals.


## Set Contents




Extension Terminal Base Unit : 1



20 Channel Terminals : 1




Connection Plate : 1



M4 x 6 Flat Head Screw : 4


## To Mount

- 1** Connect the extension terminal base unit connectors.




## 2 Screw on the connection plate using attached screws.

\* Recommended screw torque: 14 kgf/cm




## 3 Connect the extension terminal cable to the extension terminal base unit.

\* Press in the cable until it is securely locked.



## 4 Connect the other end of the extension terminal cable to ZR-RX40.

\* Press in the cable until it is securely locked.



### Important

When connecting additional terminals, make sure they are added in a continuous manner.  
Any terminals omitted will prevent subsequent terminals from being recognized.

# Precautions to Observe When Performing Measurement

Please be sure to read the following carefully in order to prevent electric shocks or shorts.


## Note

Electric shock or damage to the instrument may occur. Do not input voltages exceeding the rated voltage to the analog input terminal.

## Important

- Be sure to use only the AC cable and the AC adapter provided as standard accessories. Do not connect power supplies exceeding the rated voltage to the AC adapter.
- Do not input measurement voltages exceeding the rated voltage to the analog input terminal.

## Input Circuit Diagram for Analog Input (Voltage, Thermocouples)



## Important

Capacitors have been incorporated into the input circuit to increase the noise elimination capability. After voltage measurement, when the inputs have been disconnected, there will still be some electric charge remaining. Before starting another measurement operation, short-circuit the + and - terminals to enable self-discharge.

The ZR-RX40 has a scan system.

While in the status (open) in which signals are not input to the input terminal, measured results may be influenced by signals from other channels.

In such a case, turn OFF the input setting or short circuit +/-.


When being used for measurement, measured results are not influenced by other channels.

# Noise Countermeasures

Connect the ground wire in the following method if the measured values are unstable due to noise.


- Be sure to connect the chassis GND of the object to be measured.

It may become effective by ensuring that the chassis GND wire of the measurement object is connected to a good ground.



- Connect the signal chassis GND and the measurement device chassis ground.

Use a short, thick lead to connect the chassis GND of the measurement object to the ZR-RX40' chassis GND. It will become even more effective if the ground potentials are the same.



## Note

- The effects of the digital filter function will vary depending on the number of terminal channels and sampling speed.
- If measured values fluctuate due to noise, set the sampling speed to a value which enables the digital filter function.

For details on the setting method, see on p.71.

# Setting the Date and Time

The ZR-RX40 includes a rechargeable internal battery for backup.

If you are using the ZR-RX40 for the first time, charge the internal rechargeable battery and then make the date and time settings.

**Note**

If the ZR-RX40 is not used for a period of approximately six months, the internal rechargeable battery may be discharged and the date and time may revert to the initial settings. If this happens, recharge the battery before using the ZR-RX40.

## How to Recharge the Rechargeable Battery

Connect the ZR-RX40 and the AC power supply, turn on the power switch, and then leave the ZR-RX40 connected for at least 24 hours.

## How to Set the Date and Time

Press the MENU key, display the "OTHR" screen, and then set the date and time at the Date/Time Settings sub-menu.



For details, see "Date/Time" on p.71.

# Changing the Display Language

You can choose the language displayed on the screen. The default display language is set to English when the ZR-RX40 is shipped overseas.

ZR-RX40A: Japanese

ZR-RX40A-E, -CHRO: English


To change the display language, see the instructions in "OTHR:Language".




# SETTINGS AND MEASUREMENT

<b>Window names and functions</b>	<b>42</b>
<b>Key Operation</b>	<b>44</b>
<b>Operation Modes</b>	<b>53</b>
<b>Setting Menus</b>	<b>56</b>
<b>WEB Server Function</b>	<b>84</b>

# Window names and functions




Item	Description
1. Simplified message display:	Displays the operation status.
2. Time/DIV display:	Displays the current time scale.
3. Device access display:	Turns red when USB memory is accessed. When the internal memory is being accessed, the MEM lamp turns red.
4. Key lock display:	Displays the key lock status. (Yellow = Locked)
5. Remote display:	Lit when the ZR-RX40 is in remote mode. (Yellow = Remote mode)
6. Clock display:	Displays the current date and time.
7. AC/battery status display:	Displays the icon when AC power is used and indicates the level when the battery is used. <div data-bbox="532 1348 1226 1557" data-label="Figure"> <p>AC/battery indicator</p> <ul style="list-style-type: none"> <li> During AC supply operation</li> <li> High</li> <li> Mid</li> <li> Low</li> <li> Few</li> </ul> </div>
8. Waveform control display :	Displays the mode when using the SPAN/TRACE/POSITION key to control the waveform.
9. Digital display:	Displays the input value of each channel. Use the $\nabla/\Delta$ key to select the channel you want to activate (enlarged display). The waveform of the active channel is displayed at the top.
10. Quick settings:	Displays items available for easy operation. Use the $\nabla/\Delta$ key to activate the Quick setting area and the $\triangleleft/\triangleright$ key to change values.


Item	Description
11. Alarm display:	Displays the alarm output terminal status. (Red = Alarm generated issued)
12. Pen display:	<p>Displays the position of each channel signal, trigger and alarm range.</p>  <p>The diagram illustrates the components of the Pen display, which is used to show the position of each channel signal, trigger, and alarm range. It is divided into two main sections: 'Trigger position' and 'Alarm range'.</p> <p><b>Trigger position:</b> This section contains four sub-diagrams: <ul style="list-style-type: none"> <li><b>Rising:</b> A vertical rectangle with a dashed line and an upward-pointing arrow.</li> <li><b>Falling:</b> A vertical rectangle with a dashed line and a downward-pointing arrow.</li> <li><b>Win In:</b> A vertical rectangle with a dashed line and two upward-pointing arrows.</li> <li><b>Win Out:</b> A vertical rectangle with a dashed line and two downward-pointing arrows.</li> </ul> Below these sub-diagrams are labels: 'Rising', 'Falling', 'Win In', and 'Win Out'. To the left of the 'Rising' and 'Falling' sub-diagrams are labels 'Stop position' and 'Start position' with lines pointing to the dashed lines.</p> <p><b>Alarm range:</b> This section contains a single diagram of a vertical rectangle with an orange-shaded upper portion and a double-headed vertical arrow to its right, indicating the range.</p>
13. File name display:	Displays the name of the file used to capture data.
14. Lower limit scale:	Displays the lower limit scale of the currently active channel.
15. Waveform display:	Displays the waveform of the input signal.
16. Upper limit scale:	Displays the upper limit scale of the currently active channel.
17. Data capture bar:	Indicates the remaining capacity of the capture media during data capture. During replay, indicates information about the displayed position.

# Key Operation

This section describes key operation.



## (1) CH GROUP




Press this key to switch to the next group consisting of 10 channels.

Press the ◀ side to switch to the group consisting of the next 10 channels with a smaller number.

Press the ▶ side to switch to the group consisting of the next 10 channels with a larger number.

Pressing this key can switch among the following items.

- Switch channels of the digital display area
- Switch channels of the AMP settings
- Switch channels of the trigger/alarm level settings
- Switch channels of the calculation display







MONITOR


AMP settings

Level settings

Digital screen




## (2) SPAN/TRACE/POSITION



Switches the display in the digital display.

Used to change the settings related to waveform display during Free Running (when stopped), data capture and data replay.

Pressing this key will switch displays as shown below.




### Setting Procedure

- 1 Select the item you want to change (SPAN/TRACE/POSITION key).
- 2 Use the  $\nabla/\Delta$  keys to switch the channels, and  $\triangleleft/\triangleright$  keys to change the setting values.  
When ALL is set, setting values for CH1 is reflected on other channels.


#### Note

\* When CH1 is OFF, ALL cannot be set.


### (3) TIME/DIV



Press the left/right key of the TIME/DIV key to change the time axis display width.




### (4) MENU




Open the settings window to capture data. For details on settings, see "3.4 Setting Menus".

p.56




### (5) QUIT (LOCAL)



This key is primarily used for the following operations.

- To cancel a setting during menu configuration.
- To return to the MONITOR window when the SPAN/TRACE/POSITION window is displayed.
- To cancel remote status (in which keys are disabled) through interface control.
- To close the menu screen.
- To quit data replay.
- To return the Enlarged Waveform Screen/Digital + Calculation Display Screen to the Waveform + Digital Screen.


## (6) Direction keys



This key is primarily used for the following operations.

- To move a menu or setting item during menu configuration.
- To move the cursor during replay.
- To move the active channel in the Waveform + Digital screen (up/down keys).
- To change the setting of SPAN/TRACE/POSITION (left/right keys).


## (7) ENTER



This key is primarily used for the following operation:

- To finalize setting items during menu configuration or open submenus.


## (8) FAST FORWARD key (KEY LOCK)




This key is primarily used for the following operations.

- To move the cursor at high speed during replay.
- To change the operation mode in the file box.
- To set key lock. (Hold down the left/right FAST FORWARD key for at least two seconds. Press again to unlock.)

A password for canceling the key lock can be specified.


 "To cancel key lock by password" p.48

## (9) START/STOP (USB Drive Mode)



Press this key to start or stop capture.

- During Free Running, starts capture.
- During capture, stops capture.



- Press this key while turning the power ON to access USB DRIVE Mode.

In USB Drive Mode, the internal memory is recognized by the PC as external storage media.

### USB Drive Mode Operation Procedure


- 1 Use a USB cable to connect the ZR-RX40 and a PC.**  
(When the USB driver has not been installed, install it as described in the Software Manual "Installing the USB Driver".)
- 2 Connect the USB device to the ZR-RX40.**
- 3 While pressing the ZR-RX40 START/STOP key, turn the power ON.**
- 4 The external storage media is recognized by the PC and data exchange becomes possible.**



If the USB device is not connected, the internal memory is recognized as the external storage media.




## (10) REVIEW




This key is used to replay captured data.

- During Free Running, replays captured data.


The screen used to specify the data replay source file appears; specify the file you want to replay.



- While capturing data, recently captured data is replayed in two windows.




## (11) DISPLAY




This key is used to switch the window mode.

You can switch the window mode during Free Running (when stopped) and Capturing.

Pressing this key switches the window display as follows:



<Waveform + Digital Screen>  
Default




<Expanded Waveform screen>  
Displays the waveform in full screen mode.

CH	VALUE	RMS	Min
1	+ 25.5 °C	+ 25.8	+ 23.4
2	+0.2323 V	+0.2668	-0.3796
3	+0.2336 V	+0.2668	-0.3796
4	+0.2348 V	+0.2668	-0.3796
5	+0.2361 V	+0.2668	-0.3796
6	+0.2374 V	+0.2668	-0.3796
7	+0.2387 V	+0.2668	-0.3796
8	+0.2399 V	+0.2668	-0.3796
9	+0.2412 V	+0.2668	-0.3796
10	+0.2424 V	+0.2668	-0.3796
PLS1	1.49M c	3361	23
PLS2	6.000 RPH	6000	5940
PLS3	1.0 c	10	9
PLS4	1.49M c	3361	23

ALARM 1 2 3 4


<Digital + Calculation Display screen>  
Displays digital values and calculation results in large text.  
\* Calculation results are added up in real time.

## (12) CURSOR (ALARM CLEAR)




<When replaying captured data>

This key is used to toggle between cursors A and B during replay.




<When alarm generated>


When the alarm setting is "Hold generated Alarm", the maintained alarm is cleared.




## (13) FILE



- This key is used for operations related to the Internal memory and USB device (copy and delete).
- Copies the window.
- Saves data between cursor A and cursor B during replay (can be set during replay only).
- Saves or reads the currently set condition into the USB device.




## (14) NAVI




This key is used to display the key operation content during Free Running, capture or replay.

During display of the NAVI screen, an explanation of how the key is used is displayed in the window.



### Basic Procedures Used in Settings



The following are basic operation procedures for settings.

- 1** Press the MENU key to open each menu.
- 2** Use the  $\nabla \Delta$   $\triangleleft \triangleright$  key to move the cursor to the items you want to set.
- 3** Press the ENTER key to display a list of setting values.
- 4** Use the  $\nabla \Delta$   $\triangleleft \triangleright$  key to select a setting value.
- 5** Press the ENTER key to confirm the value.

The above operation is the basic procedure that may be used for each setting.


However, precise procedure may vary between setting items. Please follow the procedure indicated by each menu.

# Operation Modes


You can check the system operation status in the simplified message display.

operation	operation	simplified message display
Free Running	Start up status or data is not being captured	Free Running
Capturing	Data is being captured in the main memory or USB device.	Memory Recording USB Drv Recording
Dual View Replaying	The current waveform display and data on capturing is being replayed	Memory Recording USB Drv Recording
Replaying	Captured data is being replayed	Memory Review USB Drive Review

## Operation status transition



## (1) Free Running




When in Free Running status, you primarily set up the system to capture data.

You can check the current input signal as a waveform or digital values.

### Operations available during Free Running

Measurement parameters settings	The MENU key is used to change various setting items in configuration menus.
SPAN/TRACE/POSITION	The SPAN/TRACE/POSITION key is used to change settings.
Display mode	The DISPLAY key is used to change the display mode.
File operations	The FILE key is used to perform file-related operations.
Data replay	The REVIEW key is used to replay captured data.

## (2) Capturing



During data capture, data is captured into the Internal memory or USB device.


You cannot use the MENU key to change the setting.

### Operations available during capture

SPAN/TRACE/POSITION	The SPAN/TRACE/POSITION key is used to change settings.
Display mode	The DISPLAY key is used to change the display mode.
Dual View replay	The REVIEW key is used to replay captured data in two windows at the same time.

## (3) Dual View Replaying

Screen buffer usage rate (orange line)



You can replay data during capture.

Waveform on the right side is the current captured data and the left side is previously captured data. You can use the Direction keys (left/right) to move the cursor to captured data to check digital values.

### Operations available during dual view replaying


Moving cursor	The CURSOR key is used to switch between cursors A and B. The left/right or FAST FORWARD keys are used to move the cursors.
---------------	--

#### Important

Captured data can only be displayed for the double window buffer portion.

Dual view buffer capacity is 512 KB.

## (4) Replaying



Displays captured data.


### Available operation during replaying

SPAN/TRACE/POSITION	The SPAN/TRACE/POSITION key is used to change settings.
Menu operations during data replay	The MENU key is used to move the cursor, search data and replay set calculation.
Moving cursors	The CURSOR key is used to switch between cursors A and B. The left/right or FAST FORWARD keys are used to move the cursors
File operations	The FILE key is used to save the data between the cursors.

# Setting Menus


When you press the MENU key during Free Running, the following menu screens appear.

The menu screens are classified by the tab for each setting item.



## (1) AMP settings

This menu is used to specify input signal-related settings.




Setting		Selections available
Input		Off, Voltage, Temperature, Humidity Humidity: (CAUTION: The input range is compulsorily set to 1 V, and the scaling function set to ON. 0V→0%, 1V→100%)
Range		Voltage : 20, 50, 100, 200, 500 mV 1, 2, 5, 10, 20, 50, 1-5 V Temperature : TC-K, TC-J, TC-T, TC-R, TC-E, TC-B, TC-S, TC-N, TC-W, PT100, JPT100, PT1000
Filter		Off, 2, 5, 10, 20, 40
EU (Scaling settings)	Function	Off, On (effective when On has been selected)
	Lower – Upper	Settings
	Unit	Meas. Value (Upper/Lower) EU Value (Upper/Lower) Dec pt Unit Select
Misc.		Span setting (Span All Settings) Annotation setting Zero voltage adjustment Perform Auto Zero ADJ. Reset Auto Zero ADJ. [Zero point voltage value]



Setting	Selections available
Logic/Pulse	Off, Logic, Pulse
Logic	Filter: Off, On
Pulse	Input: Off, Revolution counts, Counts, Inst. Filter: Off, On Slope: H, L Scaling Function: Off, On Measured values settings EU output value settings Unit settings

## Switching displays

Analog and logic/pulse can be switched as shown below.



## Analog settings

When you use CH ALL to set an input range and filter, all channels are set to the same settings if the input is the same. Range is set only for the same input CHs.

Span All Settings, is set only for the same range CHs.

### Note

ALL and Span All Settings are set only for the currently displayed group (per 10 channels).

Input..... Selects input condition.

- Off : No signal input is accepted.
- Voltage : Used for measuring direct-current voltage.
- Temperature : Used for measuring temperature.
- Humidity : Used for measuring humidity.

Range ..... Specifies the range of signal input to be measured.

- Voltage : 20, 50, 100, 200, 500mV, 1, 2, 5, 10, 20, 50, 1-5V
- Temperature : TC-K, TC-J, TC-T, TC-R, TC-E, TC-B, TC-S, TC-N, TC-W, PT100, JPT100, PT1000

The available SPAN settings differ according to the measurement range.

The relationships between the measurement range and SPAN are as shown in the following chart.

#### <Voltage Ranges>

Range	Maximum SPAN	Minimum SPAN	Minimum Resolution
20mV	−22.000 to +22.000mV	0.200mV	0.001mV
50mV	−55.00 to +55.00mV	0.50mV	0.01mV
100mV	−110.00 to +110.00mV	1.00mV	0.01mV
200mV	−220.00 to +220.00mV	2.00mV	0.01mV
500mV	−550.0 to +550.0mV	5.0mV	0.1mV
1V	−1.1000 to +1.1000V	0.0100V	0.0001V
2V	−2.2000 to +2.2000V	0.0200V	0.0001V
5V	−5.500 to +5.500V	0.050V	0.001V
10V	−11.000 to +11.000V	0.100V	0.001V
20V	−22.000 to +22.000V	0.200V	0.001V
50V	−55.00 to +55.00V	0.50V	0.01V
1-5V	−5.500 to +5.500V	0.050V	0.001V

#### <Temperature Ranges>

Range	Maximum SPAN	Minimum SPAN (p-p)	Measurement Range	Minimum Resolution
K	−270 to +2000°C	50°C	−200 to +1370°C	0.1°C
J	−270 to +2000°C	50°C	−200 to +1100°C	
T	−270 to +2000°C	50°C	−200 to +400°C	
R	−270 to +2000°C	50°C	0 to +1600°C	
E	−270 to +2000°C	50°C	−200 to +800°C	
B	−270 to +2000°C	50°C	+600 to +1820°C	
S	−270 to +2000°C	50°C	0 to +1760°C	
N	−270 to +2000°C	50°C	0 to +1300°C	
W	−270 to +2000°C	50°C	0 to +2315°C	
PT100	−270 to +2000°C	50°C	−200 to +850°C	
JPT100	−270 to +2000°C	50°C	−200 to +500°C	
PT1000	−270 to +2000°C	50°C	−200 to +500°C	

#### <Humidity Range>

Range	Maximum SPAN	Minimum SPAN (p-p)	Minimum Resolution
	0 to +110%	1.0%	0.1%

Filter..... Sets the filter status.


Filter operation is on a moving average basis.

Off, 2, 5, 10, 20, 40 times


EU (Scaling)..... Scales the measured values and converts them to other units.

Function ..... Sets the function to Off or On.

Upper, Lower, Unit ..... Sets the EU function's conversion value and unit.



If this message appears, follow the instructions by reducing the number of digits to be output by one, or leaving the number of digits as is and changing the EU value.



#### Note


The Scaling operation is calculated using a ratio of the Meas. Value or EU Output Value settings. "++++/----" is displayed when the converted value cannot be processed by ZR-RX40.

- (1) Meas. Value  
Specifies the numeric value to be converted. Set two points, the Upper and Lower parameters.
- (2) EU Value  
Specifies output after conversion. Set two points, the Upper and Lower parameters.
- (3) Dec pt  
This parameter specifies the decimal point position of the numeral to be specified as the EU value(s).
- (4) Unit  
Selects the converted unit, which can be specified as a user-defined character string consisting of alphanumerics. The Unit parameter can also be specified by selecting the Select Unit setting.
- (5) Select  
Selects the type of engineering unit.
- (6) Choose  
Selects the converted unit. The Unit displayed here is the type of unit selected by the Select setting.

To specify a unit that is not displayed here, specify a user-defined character string as the Unit setting. Moreover, the setting specified here is displayed as the Unit setting.

### Setting Example

	Upper Value	Lower Value
Specified Value	+2.5000	-2.5000
EU Value	+10.000	-10.000




Misc..... SPAN settings : Set the detailed span for each channel.

Annotation Strings : Set a comment for each channel.

"Text input" p.78

Perform Auto Zero ADJ : Moves the current input voltage to zero position voltage value.

Reset Auto Zero ADJ : Cancels the zero position voltage value and displays input voltage.



## Logic and Pulse settings

Logic/Pulse Switching..... Switches the digital input.

- Off : Digital input is disabled.
- Logic : Digital input is processed as logic signals.
- Pulse : Digital input is processed as pulse signals.

Filter..... Sets the filter for digital input.

- Off : Disables filter circuit for digital input.
- On : Enables filter circuit for digital input.  
Filter is approximately 30 Hz (-3 dB).


Pulse Input..... Sets the counting method of input pulse for each channel.

- Off : Pulse input is disabled.
- Revol. : Counts the number of pulses per second and displays the value multiplied by 60 as rpm values.
- Counts : Displays the cumulative number of pulses for each sampling interval from the start of measurement.
- Inst. : Displays the number of pulses for each sampling interval.

Pulse Slope..... Sets the slope (direction) to count the number of pulses.

- H : Counts the rising pulse.
- L : Counts the falling pulse.


Pulse EU..... Sets scales for pulse measurement values.



- Function : Sets On/Off of the Scaling function.
- Meas. Value : Specifies the numeric value to be converted.
- EU Value : Specifies output after conversion.
- Unit : Selects the converted unit, which can be specified as a user-defined character string consisting of alphanumerics. The Unit parameter can also be specified by selecting the Select Unit setting.
- Select : Selects the type of engineering unit.
- Choose : Selects the converted unit. The Unit displayed here is the type of unit selected by the Select Unit setting.

## (2) DATA settings

This menu is used to specify capture-related items and calculations.



### DATA Menu Structure

Setting	Selections available
Record Settings	100, 200, 500ms 1, 2, 5, 10, 20, 30s
• Sampling Interval	1, 2, 5, 10, 20, 30min, 1h
File Name	<ul style="list-style-type: none"> <li>• File: Folder name, file name</li> <li>• Name Type: Auto, User</li> <li>• File Type: GBD, CSV</li> </ul>

Setting	Selections available
Statistical Calculation • Calculation Settings 1,2	Off, Average, Max, Min, Peak, RMS

### Important

When you save files, create a folder and then save the files in the folder. Regardless of the remaining capacity, if you try to save files in the root directory, due to file restrictions you may not be able to save files.

The displayed Capture Time may vary according to the sampling interval or number of capture channels.

Sampling Interval ..... Specifies the sampling interval for data capture.

The table below shows the number of measuring channels and sampling interval values that can be set.

If data fluctuate due to noise, set the sampling interval to a value which enables the digital filter function.

Number of Measuring Channels*	Allowed Sampling Interval	Sampling Interval which enables Digital Filter
10 channels or less	100 ms or above	500 ms or above
11CH to 20CH	200ms or above	1s or above
21CH to 50CH	500ms or above	2s or above
51CH to 100CH	1s or above	5s or above
101CH to 200CH	2s or above	10s or above

\* "Number of Measuring Channels" is the number of channels in which input settings are NOT set to "OFF".

### Note

To use the digital filter function, you must set the AC power supply frequency accurately.  
Follow the instructions on p.71 to ensure that the settings are accurate.

Captured data file name..... Select the name of a file to which you want to save captured data.

Set either the main memory or USB device (option).



"File box" p.75

Name Type..... Set how the file is named.

- Auto : Automatically uses the capture start time as the file name.

Example: 20050101-123456\_UG.GBD

- Number part: Created on January 1, 2005, 12: 34:56.

- UG part : Number of user capturing data

UG: Guest

U1: User 1

U2: User 2



(4) USER settings p.68

- User : Captures data using a user-defined name.

File Format..... Set the file format in which data is saved.

- GBD : Binary format
- CSV : CSV file format (such data cannot be replayed with the ZR-RX40)

Statistical calculation..... Two types of operation can be performed on all channels.

Operation results are displayed on the "Digital + Calculation Display" screen.

- Off: Calculation is not performed.
- Average: Displays the simple average value during data capture.


- Max: Displays the maximum value during data capture.
- Min: Displays the minimum value during data capture.
- Peak: Displays the peak value data during data capture.
- RMS: Displays the effective value of the data during data capture.

$$\text{R.M.S} = \sqrt{\Sigma D^2/n}$$

D: data    n: number of data

### (3) TRIG settings

This menu is used to specify trigger conditions and alarms.



Setting	Selections available
Start side source setting	Off, Level, Alarm, External Input, Date
	Level : Mode, Level, Combination
	Alarm : Alarm port number
	External input : none
	Date : Date, Time
Stop side source setting	Off, Level, Alarm, External Input, Date, Time
	Level : Mode, Level, Combination
	Alarm : Alarm port number
	External input : none
	Date : Date, Time
	Time : Duration
Repeated capturing	On, Off
Alarm level settings	Mode, Level, Output
Alarm Hold	On, Off
Send burnout alarm	On, Off

Start side source settings..... Specifies conditions to start data capture.

- Off: Starts capturing data unconditionally.
- Level: Starts capturing data when a specified level is reached.
- Alarm: Starts capturing data when the alarm with the specified number is generated.
- External Input: Starts capturing data when an input signal is received from an external trigger terminal.

- Date: Starts capturing data when a specified time arrives (when repeated capturing is set to Off).
- : Starts capturing data when a specified time arrives (when repeated capturing is set to On).  
This setting is used when you want to start capturing data at the same time every day.

Stop side source settings ..... Specifies conditions to stop data capture.

- Off: Does not stop data capture by a trigger.
- Level: Stops data capture when the specified level is reached.
- Alarm: Stops capturing data when the alarm with the specified number is generated.
- External Input: Stops capturing data when an input signal is received from an external trigger terminal.
- Date: Stops capturing data when a specified time arrives (when repeated capturing is set to Off).
- : Stops capturing data when a specified time arrives (when repeated capturing is set to On). This setting is used when you want to stop capturing data at the same time every day.
- Time: Stops capturing data at a specified time after starting data capture.

Repeated capturing ..... After a stop side trigger is generated, the next data capture process begins.

- Off: Does not repeat data capture.
- On: Repeats data capture.

Alarm level settings ..... When the setting level conditions are met, the alarm output terminal outputs an alarm.

The Digital screen showing the channel for which the alarm has been generated is displayed in red.

Alarm Hold ..... Specifies whether or not to maintain the alarm status when an alarm is generated and then canceled.

- Not Maintained: Alarm status is canceled when the alarm is canceled.
- Maintained: Alarm status is not canceled even though the alarm is canceled.


Send burnout Alarm ..... When burnout occurs, an alarm signal is output to the alarm output terminal.

 "(6) OTHR settings" p.71

- Does not occur: Alarm signal is not output to the alarm output terminal when burnout occurs.
- Occurs: Alarm signal is output to the alarm output terminal when burnout occurs.  
Alarm is output to the output terminal set in the Alarm level settings.




## Trigger level settings/Alarm level settings




Mode ..... Specifies mode trigger/alarm output conditions.

Off: Does not enable trigger/alarm.


H: A trigger/alarm is generated when the signal input rises to (or exceeds) the specified level.




L: A trigger/alarm is generated when the signal input falls to (or falls below) the specified level.



Win In: Used to specify the upper and lower limits for each channel. When the signal level goes within (or is within) either limit, a trigger/alarm is generated.




Win Out: Used to specify the upper and lower limits for each channel. When the signal level goes outside (or is outside) either limit, a trigger/alarm is generated.




Lower - Level - Upper ..... Specifies the trigger/alarm level(s) for the conditions set in Mode.

- H, L: Input a numeric value.



- Win In, Win Out: Input a numeric value for the upper and lower limit.



Combination (for trigger only)....Sets the combination of trigger conditions set for each channel.

OR: Starts (stops) capturing data when at least one trigger condition is met.

AND: Starts (stops) capturing data only when all trigger conditions are met.

## Pulse


Specifies the trigger/alarm for pulse input signals.

These conditions can be set when they have been enabled in the AMP settings.


Mode ..... Specifies the same conditions as for analog CH conditions ( p.65).

Lower - Level - Upper ..... Specifies the trigger/alarm level(s) for the conditions set in Mode.

- H, L: Input a numeric value.



- Win In, Win Out: Input numeric values for the upper and lower levels.




## Logic

Sets the trigger/alarm conditions for logic input.

These conditions can be set when they have been enabled in the AMP settings.

- Off: No trigger/alarm conditions set.
- H: Enabled when the logic signal goes from Low to High.
- L: Enabled when the logic signal goes from High to Low.




## (4) USER settings

This menu is used to store setting conditions for each user. By switching between users, these setting conditions can easily be read out.

This menu is used to specify the user name and switches user setting conditions.

You can specify that the user is a Guest, User 1 or User 2.





- User: Specify the user name. You cannot specify it as Guest.
- Department name: Specify the department name. You cannot specify it as Guest.
- Setting condition switch: Switches between Guest, User 1 and User 2. Since setting conditions are stored for each user, they can be called up easily by simply switching the user.
- Macro file name: Specify the macro file name to be executed.
- Macro run: Executes the specified macro file.


## About the Macro

Interface commands for ZR-RX40 can be described in a text file and read in. ZR-RX40 will operate as described in this file.

### <Macro operation flow>



Macro description example (file name: xxx.GMA)




### Note

Per the list of commands, please contact with Omron sales branches and offices.

## (5) Interface settings

This menu is used to specify conditions for PC connection.



Settings	Selections available
New Line code	CR+LF, LF, CR
USB ID	0 to 9
IP address	Numerical value
Subnet mask	Numerical value
Port number	Numerical value
Gateway	Numerical value

New Line code ..... Specifies the line feed code.

CR+LF : Starts a new line with CR+LF code (default value).

LF : Starts a new line with LF code.

CR : Starts a new line with CR code.

USB..... Specify settings relative to USB interface.

- USB ID : Sets the USB ID number of ZR-RX40.  
Specify a number from 0 to 9 (default value: 0).

TCP-IP ..... Specify TCP-IP settings of ZR-RX40.

- IP address : Specifies the IP address.  
Default value (192.168.0.1)
- Subnet mask : Sets the subnet mask.  
Default value (255.255.255.0)
- Port number : Sets the port number.  
Specify a value from 1024 to 65535.  
Default value (8023)
- Gateway : Sets the gateway address.  
Default value (0.0.0.0)


### Important

You must restart ZR-RX40 when any change is made to an interface setting value.

If you continue to operate ZR-RX40 without restarting after these changes, the new setting values will not be applied.  
As a result, the ZR-RX40 will not be able to establish a connection to your PC.

## (6) OTHR settings

Other miscellaneous settings are made here.



Setting	Selections available
LCD brightness	Light, Medium, Dark
Screen Saver	Off, 10, 30 (sec.), 1, 2, 5, 10, 30, 60 (min.)
Power On Start	Disable, Enable
Room Temp.	Internal, External
Temp. Unit	°C, °F
Burn Out	Off, On
AC Line cycle	50/60Hz (Off, On)
Date/Time	Date, time settings
Language	English (US), English (UK), French, German, Chinese, Korean, Japanese
Return to default settings	
Information	Firmware version System Control MAC Address
Demo Waveform Mode	Off, On
Game	Memory test game Number order game Reversi

LCD brightness..... Sets the brightness of the LCD backlight.

Available selections are Light, Medium, and Dark.

Selecting Dark allows longer operational time with batteries.

Screen Saver..... Automatically turns off the display if the ZR-RX40 is not operated within a specified interval.

Available selections are Off, 10, 30 s, 1, 2, 5, 10, 30, 60 min.

Turning off the display frequently using the Screen Saver function allows longer operational time with batteries and longer lifetime of the LCD screen.

Power On Start..... Sets the feature which initiates measurement as soon as the ZR-RX40 is turned on.

- Disable : Disables the Power On Start function.
- Enable : Enables the Power On Start function.

Room Temp. Compensation .. This parameter enables room temperature compensation settings when thermocouples are used. You can select either internal or external room temperature compensation.

- Internal : The ZR-RX40's room temperature compensation settings are used (usually, you use this parameter).
- External : This parameter is set to enable room temperature compensation settings in external devices.

Temp. Unit..... Toggles the temperature unit between °C and °F.

- °C: Celsius
- °F: Fahrenheit (the scaling function is compulsorily enabled)

Burn Out ..... Sets a feature which checks sensor burnout in a thermocouple.

- Off: Disables burnout check.
- On: Enables periodic burnout check.

#### Important

During a burnout check, voltage is applied to the ZR-RX40. Therefore, set Burn Out to "Off" when ZR-RX40 is connected in parallel with other devices to avoid any effect from these voltages.

AC Line cycle..... Select the frequency of the AC line used.  
 50Hz : For areas using line frequency of 50Hz  
 60Hz : For areas using line frequency of 60Hz

#### Important

This setting specifies the frequency in which noise can be eliminated with the digital filter function.

Note that specifying an incorrect value will not achieve line noise elimination.

The table below shows the sampling speed which enables the digital filter function.

Number of Measuring Channels*	Sampling Interval which enables Digital Filter
10 channels or less	500 ms or above
11CH to 20CH	1 s or above
21CH to 50CH	2 s or above
51CH to 100CH	5 s or above
101CH to 200CH	10 s or above

\* "Number of Measuring Channels" is the number of channels in which input settings are NOT set to "OFF".

Date/Time ..... This parameter sets the date and time.

Language..... This parameter sets the ZR-RX40's display language.

Return to default settings..... Returns all the settings to the factory defaults.

Information..... Displays system information.

Demo Waveform Mode ..... This parameter displays demo waveforms without analog signal input. Triangular waveforms, rectangular waveforms and noise are displayed in order. You can capture and replay demo waveforms.


- Off: Do not display demo waveforms.
- On: Display demo waveforms.

Game ..... Three games are available. The score is stored for each user.





## (7) Other menus

### FILE




This menu is used to perform file-related operations.

- **File Operation** Operate files in the main memory and USB device.  
 For details on file operation, see on p.75.
- **BMP Save** Saves a copy of the screen as a BMP file.



- Folder/File:** Specify a folder when the Name Type is set to Auto.  
Specify a file name when the Name Type is set to User.
- Name Type:** Specifies how files are named.
- **Auto** : Automatically uses the capture start time as the file name.
  - **User** : Sets to a user-defined name.
- Execute:** Executes bitmap save.

- **Save Data Between Cursors** When captured data is replayed, the data between cursors A and B is saved.



**Folder/File:** Specify a folder when Name Type is set to Auto.  
Specify a file name when the Name Type is set to User.


**File Format:** Specifies the file format used to save data.

- GBD : Binary format
- CSV : CSV file format (such data cannot be replayed with the ZR-RX40)

**Name Type:** Specifies how to name a file.

- Auto : Automatically uses the capture start time as the file name.
- User : Sets to a user-defined name.

- **Save current settings/Load settings** Saves or loads main unit condition settings.



**Folder/File:** Specify a folder when Name Type is set to Auto.  
Specify the file name when the Name Type is set to User.

**Name Type:** Specifies how to name a file.


- Auto : Automatically uses the capture start time as the file name.
- User : Sets to a user-defined name.

File format is fixed to CND.


## File box

The file box used to set captured data files using the DATA menu or for disk operations accessed using the FILE menu is operated as follows.

<File box by disk operations>




<File box using the DATA menu>




Key	Description
◀▶▶▶	Change the operation of the file box. <ul style="list-style-type: none"> <li>◻ Show properties ..... Display details of a file or folder.</li> <li>◻ Select file/folder ..... Select files or folders to write data.</li> <li>◻ Create new folder ..... Create a new folder.</li> <li>◻ Create new file ..... Create a new file.</li> <li>◻ Rename ..... Change the file or folder name.</li> <li>◻ Copy file/folder ..... Copy files or folders.</li> <li>◻ Select file to copy/delete ..... Select the file to copy or delete.</li> <li>◻ Select copy destination and copy... Select the copy destination and copy.</li> <li>◻ Delete file/folder ..... Delete files or folders.</li> <li>◻ Change file sort order ..... Change the order in which files are displayed.</li> <li>◻ View setting ..... Change displaying information for files.</li> <li>◻ Format disk ..... Format the disk.</li> </ul> * Details of allowed operation will depend on the operation target.
◀▶	Moves between folders. <ul style="list-style-type: none"> <li>◀ : Move up one folder.</li> <li>▶ : Move down one folder.</li> </ul>
ENTER	Finalize the operation.
QUIT	Close the file box.

## <Setting example>


The following shows an operation example where a folder named "TEST" is created for captured data and automatically saved.




In the [Data save Destination], choose [Select folder] and press the ENTER key.



Use the  $\triangleright$  key to move to the target folder.





Use the  $\triangleright\triangleright$  key to select [Create new folder].




Press the ENTER key.

In the [New folder name] box that appears, type in "TEST".






Use the << key to choose [Select file/folder].




Use the ▽ key to move the cursor to the created "TEST" folder, and press the ENTER key.



Select [OK] to close the screen.

## Text input

Related to text input operations such as annotation, EU (scaling) unit and captured data file name input.




### • Operation

Operation mode	Description		Operation method
Text input	A	Upper case alphabet mode	When the cursor key is moved to the uppermost part, operation can be selected using the left/right key. After selecting an operation, use the down key to move the cursor to the desired character.
	a	Lower case alphabet mode	
	0	Numeric mode	
	+	Symbol mode	
	←	Delete mode	
	↓	Insert mode	
	OK	Finalize mode	
When selecting operation	Text used for each operation		When you bring the cursor to a character and press ENTER, the character is entered. After you finish entering characters, move the cursor to OK and then press ENTER.

## Data replay menu

Data replay menus are displayed by pressing the MENU key during replay.



Setting	Selections available
Cursor Position	• Move to First Data
	• Move to Last Data
	• Move to Center
	• Move to Selected Position Method : Position, Time Move to : Relative time (position only) : Absolute time (time only)
Cursor Sync	Off, On
Data Search	• CH : CH1 to 200, Pulse, Logic, Alarm
	• Mode Analog : H, L Pulse : H, L Logic : H, L Alarm : Both, H, L
	• Level : Level: set numeric value (selectable only when analog or pulse)
	• Next Search
	• Prev. Search
Statistical Calculation between cursors	• Statistical Calculation: Off, Average, Max, Min, Peak, RMS
	• Execute


Cursor Position ..... There are other functions for Cursor Move apart from the Level search function.

Move to First Data: Moves the cursor to the start of the data.


Move to Last Data: Moves the cursor to the end of the data.

Move to Center: Moves the cursor to the center of the data.

Move to Selected Position: Specify the cursor position to be moved to.



- Position: Move at the specified time from the start of measurement. Interval until the end of measurement, in 0.1 s units



- Time : Move to the specified date/time.

Cursor Sync ..... Moves cursors A and B simultaneously. Cursor A is always the fulcrum.

Date Search ..... This function searches within the captured data using the specified method.

CH: Select the channel you want to search.

Mode: Select the mode used for search. The setting is changed depending on the searched channel.

(For analog CH, pulse, and logic)

- H: Operates when the searched data rises to a specified level.
- L: Operates when the searched data falls to a specified level.

(For alarm)


- Both: Operates when a searched alarm is generated or canceled.
- H: Operates when a searched alarm is generated.
- L: Operates when a searched alarm is canceled.

Level: Sets the level to be searched for analog CH and pulse.



## Statistical calculation between cursors

..... Statistical calculation is performed on the data between the cursors.



Function : There are five types of between-cursor calculation functions and one of these can be selected.


"(2) DATA settings" p.61

Calculation results are displayed for 10 channels each and may be switched to display another group of 10 channels.


## NAVI menu

The NAVI menu can be displayed in three modes, Free Running, Recording, and Replay.

Operation	Description
Open	Press the NAVI key to open the NAVI menu.
Close	Press the NAVI key to close the NAVI menu.
Browse explanation	Explanation is displayed when an enabled key is pressed.



## Quick settings



You can easily set two items on the digital area of the Waveform + Digital screen.

To set items, use the up/down key to go to the Quick setting area.

Content differs depending on the operation mode.

Operation mode	Content	Explanation
Free Running	SAMPLE	Left/right key can be used to change the sampling interval.
	ZONE	Left/right key can be used to change the zone division.
Recording	ZONE	Left/right key can be used to change the zone division.
Replaying	SEARCH	Left/right key can be used to perform search. Left: Searches past side Right: Searches future side
	ZONE	Left/right key can be used to change the zone division.


## To cancel key lock by password

A password can be set to ZR-RX40 to cancel the key lock.

(No password is set at factory default.)

<Operation flow>

### 1 Set the password.



Press the  $\triangleleft$ ,  $\triangleright$ , and ENTER keys at the same time to display the password setting screen shown below. Specify a 4 digit password.

The screenshot shows the 'Enter New Password' screen. It features a 4-digit password input field with the digits 0, 0, 0, 0. Below the input field is a vertical list of numbers from 0 to 9, with a green arrow pointing to the number 0. The screen is titled 'Enter New Password'.

Use the  $\triangleleft$   $\triangleright$   $\triangle$   $\nabla$  keys to select numbers. Press the ENTER key to confirm the password.

Specifying 0000 will disable password operation.

In case you forgot your password, please contact us to acquire the master password.

## 2 Set the key lock.

Hold down the ◀◀ and ▶▶ keys together for at least two seconds.

## 3 Cancel the key lock.

Hold down the ◀◀ and ▶▶ keys together again for at least two seconds.

The password setting screen shown below will be displayed. Set a password.

Enter your Password

0	0	0	0
---	---	---	---

9  
8  
7  
6  
5  
4  
3  
2  
1  
0 ◀

Entering an incorrect password will not cancel key lock.

Key lock state will be retained when power is turned off.

# WEB Server Function

This function allows operating and monitoring ZR-RX40 via a Web browser.

## Supported Web browsers

- Microsoft Internet Explorer 6.0 or later
- Netscape 6.2 or later
- Firefox 1.5 or later
- Opera 9.0 or later

## Available functions using a Web browser

- Operating ZR-RX40
- Monitoring ZR-RX40 display screen
- Enlarging ZR-RX40 display screen
- Linking to FTP
- Linking to our Web site

## Setting the URL

The URL (Uniform Resource Locator) must be correctly set according to your network environment.

Follow the procedure below to access the ZR-RX40.

http://IP address/Index.html


- http..... Protocol to access the server.  
HTTP (Hyper Text Transfer Protocol)
- IP address..... Type in the IP address of the ZR-RX40 to monitor.
- Index.html ..... File name. This is fixed to Index.html.

## Procedure

- 1** Open the Web browser.
- 2** Type in the URL (http://IP address/Index.html) in the address input field.



### 3 The following pages are displayed.



Remote key operation..... Allows ZR-RX40 operation.

Zoom..... Enlarges only the LCD screen of ZR-RX40.


Digital..... Displays the ZR-RX40 measured value digitally.

Download of device file..... Allows data captured with ZR-RX40 to be downloaded to your PC via FTP.


OMRON Web site..... Accesses to our Web site.

## Remote key operation

To operate ZR-RX40 from a remote location, click the corresponding ZR-RX40's panel keys on the screen.




## Zoom



- CH GROUP..... Digital values for 10 channels are displayed on a single screen.  
Press this key to display the next group consisting of 10 channels.
- DISPLAY ..... Switches the display mode.  
Press this key to switch among Waveform + Digital, Expanded Waveform, and Digital screens.
- SPAN/TRACE/POSTION..... Switches the display in the digital display area.  
Press this key to switch among MONITOR, SPAN, POSITION, and TRACE.
- ← → ↑ ↓..... Cursor keys
- Screen update speed..... Specifies the speed in which the screen is updated.  
Available update speeds are 2, 5, and 10 seconds.


## Digital



- Displayed CH ..... Select either 20 channel display or ALL channel display.
- Switch CH group ..... Displays digital values for 20 channels on a single screen.  
Press this key to display the next group consisting of 20 channels.
- Screen update speed..... Specifies the speed in which the screen is updated.  
Available update speeds are 2, 5, and 10 seconds.

## Download of device file

Allows memory data from ZR-RX40 and data in USB memory device to be downloaded to your PC.





# SPECIFICATIONS

---

**Standard Specifications**

**90**

**Accessory/Option Specifications**

**94**

**External Dimensions**

**96**

# Standard Specifications

## Standard Specifications

Specifications			ZR-RX40A	
Analog input section	Input method		Photo MOS relay scanning system; all channels isolated, balanced input	
	Input terminal shape		M3 screw type terminal	
	Number of input channels		Standard: 20 ch Max: 200 ch (When the terminal unit is connected)	
	Scan speed		100 ms/10 ch max	
	A/D resolution		16-bit	
	Measurement ranges	Voltage		20, 50, 100, 200, 500 mV; 1, 2, 5, 10, 20, 50 V; 1-5 V F.S.
Temperature		Thermocouples: K, J, E, T, R, S, B, N, W (WRe5-26) Resistance temperature detector: Pt100, JPt100, Pt1000 (IEC751)		
Humidity (*1)		0 to 100 % (Voltage 0 to 1 V scaling conversion)		
Measurement accuracy (*2) (*3)	Voltage		±0.1 % of F.S.	
	Thermocouple	Type	Measurement Temperature Range (°C)	Measurement Accuracy
		R/S	0 ≤ TS ≤ 100	± 5.2 °C
			100 < TS ≤ 300	± 3.0 °C
			R: 300 < TS ≤ 1600	± (0.05 % of rdg +2.0 °C)
			S: 300 < TS ≤ 1760	± (0.05 % of rdg +2.0 °C)
		B	400 ≤ TS ≤ 600	± 3.5 °C
			600 < TS ≤ 1820	± (0.05 % of rdg +2.0 °C)
		K	−200 ≤ TS ≤ −100	± (0.05 % of rdg +2.0 °C)
			−100 < TS ≤ 1370	± (0.05 % of rdg +1.0 °C)
		E	−200 ≤ TS ≤ −100	± (0.05 % of rdg +2.0 °C)
			−100 < TS ≤ 800	± (0.05 % of rdg +1.0 °C)
		T	−200 ≤ TS ≤ −100	± (0.1 % of rdg +1.5 °C)
			−100 < TS ≤ 400	± (0.1 % of rdg +0.5 °C)
		J	−200 ≤ TS ≤ −100	± 2.7 °C
			−100 < TS ≤ 100	± 1.7 °C
			100 < TS ≤ 1100	± (0.05 % of rdg +1.0 °C)
		N	0 ≤ TS ≤ 1300	± (0.1 % of rdg +1.0 °C)
		W	0 ≤ TS ≤ 2315	± (0.1 % of rdg +1.5 °C)
		Reference contact compensation accuracy		± 0.5 °C

Specifications				ZR-RX40A		
Analog input section	Measurement accuracy (*2) (*3)	Resistance temperature detector	Type	Measurement Temperature Range (°C)	Applied current	Measurement Accuracy
			Pt100	−200 to 850 (FS = 1050 °C)	1 mA	± 1.0 °C
			JPt100	−200 to 500 (FS = 700 °C)	1 mA	± 0.8 °C
			Pt1000	−200 to 500 (FS = 700 °C)	0.2 mA	± 0.8 °C
	Maximum input voltage			60 Vp-p (between +/− terminals, between input terminals, between input terminal/GND)		
	Reference contact compensation			Internal/External switching		
	Input impedance			1 MΩ ± 5 %		
	Allowable signal source resistance			300 Ω or less		
	Temperature coefficient			Gain: 0.01 % of F.S./°C		
	Common mode rejection ratio			At least 90 dB (50/60 Hz; signal source 300 Ω or less)		
	Noise			At least 48 dB (with +/− terminals shorted)		
	Withstand voltage			350 Vp-p (between input channel/GND; between each chs) 1 minute		
	Insulation resistance			Between input terminal/GND: At least 50 MΩ (at 500VDC)		
External Input/ Output Sections	Logic input/ Pulse input	Number of channels (*4)		4 ch		
		Pulse input modes	Revolutions mode	Spans	50, 500, 5000, 50 k, 500 k, 5 M, 50 M, 500 M RPM/F.S.	
				Maximum number of pulse inputs	50 k/sec	
			Counts mode	Spans	50, 500, 5000, 50 k, 500 k, 5 M, 50 M, 500 M C/F.S.	
				Maximum number of pulse inputs	50 k/sampling interval	
			Inst. mode	Spans	50, 500, 5000, 50 k, 500 k, 5 M, 50 M, 500 M C/F.S.	
				Maximum number of pulse inputs	50 k/sampling interval	
		Trigger input	Number of channels		1 ch	
	Specifications of each input section	Maximum input voltage		24 V		
		Threshold voltage		Approx. 2.5 V		
		Hysteresis range		Approx. 0.5 V (2.5 to 3 V)		
	Alarm output	Number of channels		4 ch		
		Output format		Open collector output (10 kΩ pull-up resistance)		
				5 to 24 VDC, up to 100 mA		
		Output conditions		Level judgment, window judgment, logic pattern judgment, pulse judgment		
Clock accuracy (*5)				± 0.002 % (approx. 50 sec/month)		
Operating environment				0 to 45 °C, 5 to 85 % RH (15 to 40 °C when the battery is used)		

Specifications	ZR-RX40A
Power supply	AC adapter: 100 to 240 VAC/50 to 60 Hz (*8) DC input: 8.5 to 24VDC Battery pack (ZR-RXB1) (*6) two batteries can be mounted
Power consumption	28 VA or less (when the AC adapter is used)
Vibration resistance	Equivalent to automobile parts Type 1 Category A classification
External dimensions	232 x 152 x 50 mm
Weight	Approx. 990 g (*7)

\*1 When ZR-XRH1 (Option) is used

\*2 Features under the following measurement parameters

- Operating environment 23 °C ± 3 °C
- Left for at least 30 minutes after the power supply is turned on
- Sampling interval 1 s (20 ch)
- Filter ON (Average: 10 times)
- GND connection
- Thermocouple used is T: 0.32Ω, other: 0.65Ω

\*3 Refer to the ZR-XRH1 (Option) specifications for humidity measurement accuracy.

\*4 Switch between logic and pulse input

\*5 When used at 23 °C

\*6 ZR-RXB1 is an option

\*7 Excluding the AC adapter and battery

\*8 Be sure to use only the AC cable and the AC adapter provided as standard accessories.

## Main Functions

Main unit specifications			ZR-RX40A
Sampling interval			100, 200, 500 ms; 1, 2, 5, 10, 20, 30 s; 1, 2, 5, 10, 20, 30 min; 1h 100 ms/10 ch max
Filter (*1)			Off, 2, 5, 10, 20, 40 times
Trigger Functions	Repeat Trigger		Off/On
	Trigger types		Start: Data capture starts when a trigger is generated
			Stop: Data capture stops when a trigger is generated
	Trigger conditions		Start: Off, Level, External, Date, Alarm
			Stop: Off, Level, External, Date, Time, Alarm
	Alarm judgment modes	Analog judgment	Analog: H, L, Window IN, Window OUT
		Logic judgment	Logic: H, L
		Pulse judgment	Pulse: H, L, Window IN, Window OUT
Channel combination		OR, AND	

Main unit specifications			ZR-RX40A
Miscellaneous Functions	Scaling (EU) function		4 points can be set for each channel
	Review function		Data replay during data capture
	Statistical calculation	Types of operation	Average value, peak value, maximum value, minimum value, RMS
		Number of operations	2 can be set simultaneously
		Method	Realtime and between cursors specified (during data replay) (*2)
	Data Search	Function	Search the captured data for the required number of points
		Search type	Channel, Pulse, Logic, Level, Alarm search
	Annotation input	Function	A comment can be input for each channel
		Inputtable characters	Alphanumeric, Kana
		Number of characters	11 (Displayed up to 8 characters)
Monitor	Display		5.7-inch TFT color LCD (QVGA: 320 x 240 dots)
	Display screen		Waveform screen + Digital screen/Waveform screen/Digital screen + Calculation Display screen
	Screen saver function		10, 30 s; 1, 2, 5, 10, 30, 60 min
PC I/F	Interface types		Ethernet (10BASE-T/100BASE-TX)
			USB (2.0)
	Functions	Software functions	Data transfer to the PC (realtime memory)
			PC control of the ZR-RX40
		Ethernet functions	Web server function (Operation of ZR-RX40, Displays ZR-RX40's screen image on browser)
			FTP function (Transfers and deletes measured data from internal memory via network)
		USB functions	USB drive mode (Transfers and deletes measured data from internal memory)
	Realtime data transfer speed (*3)		100 ms/10 ch max
Internal memory devices	Memory capacity	Internal memory	Approx. 12 MB Flash Memory
		Available USB memory capacity	Max 2 GB
	Memory contents		Setup conditions/Captured data/Screen copy
Data save functions	Measured data		Internal memory or direct capture in the USB memory device
	Other		Setup conditions, copy of data screen can be saved in the internal memory or USB memory device

\*1 Filter operation is on a moving average basis. The average value of the set sampling count is used.

\*2 When the Digital screen + Calculation Display screen has been specified the calculation results are displayed.

\*3 Differs according to the number of transfer channels

# Accessory/Option Specifications

## Accessories

### PC software Smart Viewer RX40 Specifications

Item	Description
Compatible operating system	Windows 2000/XP
Functions	Main unit control, realtime data capture, file format conversion
Allowed connection	10 max
Number of channels per connection	200 ch max
Maximum number of channels	500 ch max
Main unit settings	Input settings, memory settings, alarm settings, trigger settings, report settings, etc.
Captured data (CSV, Binary)	Realtime data, Internal memory data, USB memory data
Displayed contents	Analog waveforms, logic waveforms, pulse waveforms, digital values
Display modes	Y-T View, X-Y View, Digital View, Meter View, Report View
Monitor functions	Alarm monitor enables sending of email to the specified address
File format conversion	Between cursors, All data
Dual-screen function	Displays the current data alongside past data
Report function	Automatic creation of daily or monthly files
Statistic/History	Displays maximum, minimum and average values during measurement

## Options

### Battery Pack ZR-XRB1

Item		Description
Capacity		7.2 V/2200 mAh
Running time (*1) (*2) (*3)	When using the LCD display	Approx. 5 hours
	When using the screensaver	Approx. 9 hours
Battery type		Lithium secondary battery
Charging method		Mount in the main unit (ZR-RX20/RX40)
Time required for charging		Approx. 4 hours (*4)
Switchover in the case of a power failure		By using the battery together with the AC adapter, the power supply will be switched automatically to the battery in the event of a power failure.
Operation environment		15 to 40 °C

Item	Description
Other functions	When the battery is running low, measured data is saved and the file is closed automatically.

\*1 For ZR-RX40, when two battery packs are mounted.

\*2 When capturing to internal memory at a sampling speed of 1 sec, 20 channel terminals, using new battery packs at +25 °C environment.

\*3 The running time depends on the operating environment.


\*4 When one battery pack is charged.

## Humidity Sensor ZR-XRH1

Item	Description
Allowable temperature range	–25 to +80 °C
Allowable humidity range	0 to 100 % RH
Relative humidity measurement accuracy	± 3 % RH (5 to 98 % RH at 25 °C)
Response time	15 sec (90 % response when membrane filter is installed)
Sensor output	0 to 1 VDC
Power consumption	Approx. 4 mA
External dimensions	Ø14 × 80 mm (excluding cable)
Cable length	3 m

# External Dimensions

(Unit: mm)





# INDEX

## A

AC	
Power Supply, Connecting	18
AC Line Frequency	71, 72
ALARM CLEAR	51
Alarm Hold	64
Alarm level settings	64, 65
AMP settings	56
Analog Input Circuit Diagram	37
Annotation	60
Annotation setting	56

## B

Battery	
Charging	28
Pack	27
Battery Pack	
Mounting	27
Burn Out	71, 72

## C

Captured data file name	62
Capturing	54
CURSOR key	51

## D

Data replay menu	79
DATA settings	61
Date and Time	39
Date/Time	71, 72
DC	
Power Supply, Connecting	19
Demo Waveform Mode	71
Department name	68
Direction key	47
Display	
Language	40
DISPLAY key	50
Dual View Replaying	54

## E

ENTER key	47
EU (Scaling)	58
External	
Dimensions	96

## F

FAST FORWARD key	47
Features	16

File box	75
File Format	62
FILE key	51
FILE menu	73
Filter	56, 58
Free Running	53

## G

Game	71, 72
------	--------

## H

Humidity Sensor	29
-----------------	----

## I

Information	71, 72
Input	56, 57
Internal memory devices	93

## K

KEY LOCK	47
----------	----

## L

Language	71, 72
LCD brightness	71
LOCAL	46
Logic	57, 67
Lower - Level - Upper	66

## M

MENU key	46
Misc.	56, 60
Monitor function	94

## N

Name Type	62
NAVI key	52
NAVI menu	81

## O

OTHR settings	71
---------------	----

## P

Part Names and Functions	17
PC Software	94
Performing Measurement,	
Precautions to Observe	37
Power On Start	71
Pulse	57, 60, 67

## Q

Quick settings	82
----------------	----

QUIT key 46

## R

Range 56, 57

Repeated capturing 64

Replaying 55

Return to default settings 71, 72

REVIEW key 49

Room Temp. 71

Room Temp. Compensation 72

## S

Screen Saver 71

Send burnout Alarm 64

SPAN

Settings 58

Span 56, 60

Span setting 56

Standard

Specifications 90

Start side source settings 63

START/STOP key 48

Statistical calculation 62

## T

Temp. Unit 71, 72

Text input 78

TIME/DIV key 46

TRIG settings 63

Trigger level settings 65

## U

USB Drive Mode 48

User 68

USER settings 68

# Revision History

A manual revision code appears as a suffix to the catalog number at the bottom of the front and back covers of this manual.

Cat. No. Z260-E1-02



Revision code

Revision code	Date	Revised contents
01	April 2007	Original production
02	August 2007	Rear view added in External Dimensions and minor corrections

**OMRON Corporation**  
**Industrial Automation Company**

**Application Sensors Division**  
**Sensing Devices and Components Division H.Q.**  
Shiokoji Horikawa, Shimogyo-ku,  
Kyoto, 600-8530 Japan  
Tel: (81)75-344-7068/Fax: (81)75-344-7107

**Regional Headquarters**  
**OMRON EUROPE B.V.**  
**Sensor Business Unit,**  
Carl-Benz-Str. 4, D-71154 Nufringen,  
Germany  
Tel: (49)7032-811-0/Fax: (49)7032-811-199

**OMRON ELECTRONICS LLC**  
One Commerce Drive Schaumburg  
IL 60173-5302 U.S.A.  
Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

**OMRON ASIA PACIFIC PTE. LTD.**  
No. 438A Alexandra Road # 05-05/08 (Lobby 2),  
Alexandra Technopark,  
Singapore 119967  
Tel: (65) 6835-3011/Fax: (65) 6835-2711

**OMRON (CHINA) CO., LTD.**  
Room 2211, Bank of China Tower,  
200 Yin Cheng Zhong Road,  
Pu Dong New Area, Shanghai,  
200120, China  
Tel: (86)10-8391-3005/Fax: (86)10-8391-3688

**Authorized Distributor:**