

ERT1 Series

EtherNet/IP Slave Units

OPERATION MANUAL

OMRON

ERT1 Series EtherNet/IP Slave Units




Operation Manual

Revised November 2010

Notice:

OMRON products are manufactured for use according to proper procedures by a qualified operator and only for the purposes described in this manual.

The following conventions are used to indicate and classify precautions in this manual. Always heed the information provided with them. Failure to heed precautions can result in injury to people or damage to property.

-  **DANGER** Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. Additionally, there may be severe property damage.
-  **WARNING** Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury. Additionally, there may be severe property damage.
-  **Caution** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, or property damage.

OMRON Product References

All OMRON products are capitalized in this manual. The word “Unit” is also capitalized when it refers to an OMRON product, regardless of whether or not it appears in the proper name of the product.

The abbreviation “Ch,” which appears in some displays and on some OMRON products, often means “word” and is abbreviated “Wd” in documentation in this sense.

The abbreviation “PLC” means Programmable Controller. “PC” is used, however, in some Programming Device displays to mean Programmable Controller.

Visual Aids

The following headings appear in the left column of the manual to help you locate different types of information.

Note Indicates information of particular interest for efficient and convenient operation of the product.

1,2,3... 1. Indicates lists of one sort or another, such as procedures, checklists, etc.

Trademarks and Copyrights

EtherNet/IP is a registered trademark of the ODVA (Open DeviceNet Vendor Association).

Ethernet is a trademark of the Xerox Corporation.

Microsoft, Windows, Windows NT, Windows 2000, Windows XP, and Windows Vista are registered trademarks of the Microsoft Corporation.

Other names of systems or products that appear in this document are trademarks or registered trademarks of the respective company.

© OMRON, 2009

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

TABLE OF CONTENTS

PRECAUTIONS	xv
1 Intended Audience	xvi
2 General Precautions	xvi
3 Safety Precautions	xvi
4 Operating Environment Precautions	xvii
5 Application Precautions	xviii
6 Conformance to EC Directives	xix
 SECTION 1	
Features and Slave Units	1
1-1 Feature of EtherNet/IP Slave Units	2
1-2 EtherNet/IP Slaves	3
 SECTION 2	
System Startup Procedure	5
2-1 Overview of System Startup Procedure	6
2-2 Recommended Network Devices	37
 SECTION 3	
Basic Specifications of Slave Units	39
3-1 Basic Specifications of Slave Units	40
 SECTION 4	
Digital I/O Slave Units	43
4-1 Status Areas	44
4-2 Screw-less Clamp Terminals	45
 SECTION 5	
Environment-resistive Slave Units	59
5-1 Status Areas	60
5-2 Environment-resistive Slave Units	61
 SECTION 6	
Smart Functions	73
6-1 Functions Common to All Slave Units	74
 SECTION 7	
Troubleshooting and Maintenance	77
7-1 Indicator Meanings and Troubleshooting	78
7-2 Troubleshooting	78
7-3 Maintenance and Replacement	80
 Index	83
 Revision History	85

About this Manual:

This manual describes the installation and operation of ERT1-series EtherNet/IP Slave Units, and includes the sections described below.

Please read this manual carefully and be sure you understand the information provided before attempting to install or operate an ERT1-series EtherNet/IP Slave Unit. Be sure to read the precautions provided in the following section.

Precautions provides precautions for using the ERT1-series EtherNet/IP Slave Units.

Section 1 describes the features and models of EtherNet/IP Slave Units

Section 2 describes the overall procedure that is used to set up and start an EtherNet/IP system.

Section 3 provide the basic specifications of the EtherNet/IP Slave Units

Section 4 describes the Digital I/O Slave Units for EtherNet/IP.

Section 5 describes the Environment-resistive Slave Units for EtherNet/IP.


Section 6 describes the Smart Functions supported by the EtherNet/IP Slave Units.

Section 7 describes troubleshooting and maintenance for the EtherNet/IP Slave Units.

Relevant Manuals

The following table lists manuals that contain information relevant to EtherNet/IP Slave Units.

Manual number	Model	Name	Contents
W481	ERT1 Series	ERT1 Series EtherNet/IP Slave Units Operation Manual (this manual)	Provides information on operating and installing EtherNet/IP Slave Units.
W465	CS1W-EIP21 CJ1W-EIP21 CJ2H-CPU6□-EIP	EtherNet/IP Units Operation Manual	Provides information on operating and installing EtherNet/IP Units, including details on basic settings, tag data links, and FINS communications. Refer to the <i>Communications Commands Reference Manual</i> (W342) for details on FINS commands that can be sent to CS-series and CJ-series CPU Units when using the FINS communications service. Refer to the <i>Ethernet Units Operation Manual Construction of Applications</i> (W421) for details on constructing host applications that use FINS communications.
W342	CS1G/H-CPU□□H CS1G/H-CPU-□□V1 CS1W-SCU21 CS1W-SCB21/41 CJ2H-CPU6□-EIP CJ2H-CPU6□ CJ1G/H-CPU□□H CJ1G-CPU□□ CJ1W-SCU41	Communications Commands Reference Manual	Describes the C-series (Host Link) and FINS communications commands used when sending communications commands to CS-series and CJ-series CPU Units.
W463	CXONE-AL□□C-V3 CXONE-AL□□D-V3	CX-One Ver. 3.0 Setup Manual	Describes the setup procedures for the CX-One. Information is also provided on the operating environment for the CX-One.

 **WARNING** Failure to read and understand the information provided in this manual may result in personal injury or death, damage to the product, or product failure. Please read each section in its entirety and be sure you understand the information provided in the section and related sections before attempting any of the procedures or operations given.

Read and Understand this Manual

Please read and understand this manual before using the product. Please consult your OMRON representative if you have any questions or comments.

Warranty and Limitations of Liability

WARRANTY

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year (or other period if specified) from date of sale by OMRON.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

LIMITATIONS OF LIABILITY

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY.

In no event shall the responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.

IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR, OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED, AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE, OR INAPPROPRIATE MODIFICATION OR REPAIR.

Application Considerations

SUITABILITY FOR USE

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of products in the customer's application or use of the products.

At the customer's request, OMRON will provide applicable third party certification documents identifying ratings and limitations of use that apply to the products. This information by itself is not sufficient for a complete determination of the suitability of the products in combination with the end product, machine, system, or other application or use.

The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of the products, nor is it intended to imply that the uses listed may be suitable for the products:

- Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this manual.
- Nuclear energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations.
- Systems, machines, and equipment that could present a risk to life or property.

Please know and observe all prohibitions of use applicable to the products.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCTS ARE PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

PROGRAMMABLE PRODUCTS

OMRON shall not be responsible for the user's programming of a programmable product, or any consequence thereof.

Disclaimers

CHANGE IN SPECIFICATIONS

Product specifications and accessories may be changed at any time based on improvements and other reasons.

It is our practice to change model numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the products may be changed without any notice. When in doubt, special model numbers may be assigned to fix or establish key specifications for your application on your request. Please consult with your OMRON representative at any time to confirm actual specifications of purchased products.

DIMENSIONS AND WEIGHTS

Dimensions and weights are nominal and are not to be used for manufacturing purposes, even when tolerances are shown.

PERFORMANCE DATA

Performance data given in this manual is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of OMRON's test conditions, and the users must correlate it to actual application requirements. Actual performance is subject to the OMRON Warranty and Limitations of Liability.

ERRORS AND OMISSIONS

The information in this manual has been carefully checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical, or proofreading errors, or omissions.

PRECAUTIONS

This section provides general precautions for using the ERT1-series EtherNet/IP Slave Units.

The information contained in this section is important for the safe and reliable application of EtherNet/IP Slave Units. You must read this section and understand the information contained before attempting to set up or operate an EtherNet/IP Slave Unit.

1	Intended Audience	xvi
2	General Precautions	xvi
3	Safety Precautions	xvi
4	Operating Environment Precautions	xvii
5	Application Precautions	xviii
6	Conformance to EC Directives	xix
6-1	Applicable Directives	xix
6-2	Concepts	xix
6-3	Conformance to EC Directives	xix

1 Intended Audience

This manual is intended for the following personnel, who must also have knowledge of electrical systems (an electrical engineer or the equivalent).

- Personnel in charge of installing FA systems.
- Personnel in charge of designing FA systems.
- Personnel in charge of managing FA systems and facilities.


2 General Precautions

The user must operate the product according to the performance specifications described in the operation manuals.


Before using the product under conditions which are not described in the manual or applying the product to nuclear control systems, railroad systems, aviation systems, vehicles, combustion systems, medical equipment, amusement machines, safety equipment, and other systems, machines, and equipment that may have a serious influence on lives and property if used improperly, consult your OMRON representative.


Make sure that the ratings and performance characteristics of the product are sufficient for the systems, machines, and equipment, and be sure to provide the systems, machines, and equipment with double safety mechanisms.


This manual provides information for programming and operating the Unit. Be sure to read this manual before attempting to use the Unit and keep this manual close at hand for reference during operation.


 **WARNING** It is extremely important that a PLC and all PLC Units be used for the specified purpose and under the specified conditions, especially in applications that can directly or indirectly affect human life. You must consult with your OMRON representative before applying a PLC System to the above-mentioned applications.

3 Safety Precautions


 **WARNING** Do not attempt to take any Unit apart while the power is being supplied. Doing so may result in electric shock.

 **WARNING** Do not touch any of the terminals or terminal blocks while the power is being supplied. Doing so may result in electric shock.

 **WARNING** Do not attempt to disassemble, repair, or modify any Units. Any attempt to do so may result in malfunction, fire, or electric shock.

 **WARNING** Provide safety measures in external circuits (i.e., not in the Programmable Controller), including the following items, to ensure safety in the system if an abnormality occurs due to malfunction of the PLC or another external factor affecting the PLC operation. Not doing so may result in serious accidents.

- Emergency stop circuits, interlock circuits, limit circuits, and similar safety measures must be provided in external control circuits.
- The PLC outputs may remain ON or OFF due to destruction of the output transistors. As a countermeasure for such problems, external safety measures must be provided to ensure safety in the system.
- Data input and output errors may occur when a photocoupler reaches the end of its service life. As a countermeasure for such problems, external safety measures must be provided to ensure safety in the system.


 **WARNING** Do not use the indicators on the EtherNet/IP Slave Units for safety-related applications. Safety functions may be lost, occasionally resulting in serious injury.

4 Operating Environment Precautions











 **Caution** Install the EtherNet/IP Slave Units correctly as described in this manual.

 **Caution** Do not install the EtherNet/IP Slave Units in the following locations.

- Locations subject to direct sunlight.
- Locations subject to temperatures or humidity outside the range specified in the specifications.
- Locations subject to condensation as the result of severe changes in temperature.
- Locations subject to corrosive or flammable gases.
- Locations subject to dust (especially iron dust) or salts.
- Locations subject to exposure to water, oil, or chemicals.
- Locations subject to shock or vibration.

 **Caution** Take appropriate and sufficient countermeasures when installing systems in the following locations:

- Locations subject to static electricity or other forms of noise.
- Locations subject to strong electromagnetic fields.
- Locations subject to possible exposure to radioactivity.
- Locations close to power supplies.

-  **Caution** Install the EtherNet/IP Slave Units securely using M5 screws and tighten them to a torque of 1.47 to 1.96 N·m. Do not over tighten the screws. Doing so may damage them.
-  **Caution** Do not use the EtherNet/IP Slave Units where they would be continually subjected to water or water spray.
-  **Caution** Take appropriate measures to ensure that the specified power with the rated voltage is supplied in places where the power supply is unstable, or implement safety measures using a voltage monitor.
-  **Caution** Tighten the screws on the switch cover to a torque of 0.4 to 0.5 N·m. The specified degree of protection may not be achieved if the screws are loose.
-  **Caution** When attaching the switch cover, wipe it clean of dust, dirt, contamination, water, and other matter before attaching it. The specified degree of protection may not be achieved if the cover is not clean.
-  **Caution** Use the specified connectors and cables for wiring.
-  **Caution** Do not bend the cable past its natural bending radius and do not pull on the cable with excessive force.
-  **Caution** Use the specified DC power supply.
-  **Caution** Do not exceed the specified communications distance or the specified number of nodes.
-  **Caution** Do not use organic solvents to clean the EtherNet/IP Slave Units. They may dissolve or discolor the surface.

5 Application Precautions

Observe the following precautions when using the EtherNet/IP Slave Units.

- Do not attempt to disassemble, repair, or modify the EtherNet/IP Slave Units.
- Do not drop any Unit or subject any Unit to excessive shock or vibration. Otherwise, Unit failure or malfunction may occur.
- Tighten connector screws securely.
- Separate the communications cables from the power lines or high-voltage lines.
- Check wiring and switch settings completely before turning ON the power supply.
- Make sure that the power supply voltage, terminal polarity, communications paths, power supply wiring, and I/O voltages are within specifications. Mistakes in any of these can cause EtherNet/IP Slave Unit failure.
- Turn OFF the power supply to the PLC and all slaves and turn OFF all communications power supplies before connecting or disconnecting communications cables.

- For the Unit power supplies and output power supplies, use power supply units that will supply a stable output even if the input power is interrupted for up to 10 ms. The power supply must also have reinforced or double insulation.
- Do not place any objects on the cables.
- When transporting the Unit, use special packing boxes and protect it from being exposed to excessive vibration or impact during transportation.

6 Conformance to EC Directives

6-1 Applicable Directives

- EMC Directives
- Low Voltage Directive

6-2 Concepts

EMC Directives

OMRON devices that comply with EC Directives also conform to the related EMC standards so that they can be more easily built into other devices or the overall machine. The actual products have been checked for conformity to EMC standards (see the following note). Whether the products conform to the standards in the system used by the customer, however, must be checked by the customer.

EMC-related performance of the OMRON devices that comply with EC Directives will vary depending on the configuration, wiring, and other conditions of the equipment or control panel on which the OMRON devices are installed. The customer must, therefore, perform the final check to confirm that devices and the overall machine conform to EMC standards.

Note Applicable EMC (Electromagnetic Compatibility) standards are as follows:

EMS (Electromagnetic Susceptibility): EN 61131-2 and EN 61000-6-2

EMI (Electromagnetic Interference): EN 61131-2 and EN 61000-6-4

(Radiated emission: 10-m regulations)

Low Voltage Directive

Always ensure that devices operating at voltages of 50 to 1,000 V AC and 75 to 1,500 V DC meet the required safety standards for the PLC (EN61131-2).

6-3 Conformance to EC Directives

The OMRON products described in this manual comply with the related EMC Directives. To ensure that the machine or device in which the products are used complies with EC Directives, the products must be installed as follows:

1,2,3...

1. The products must be installed within a control panel.
2. A DC power supply with reinforced insulation or double insulation that can maintain a stable output even if the input is interrupted for 10 ms must be used for communications power, internal power, and I/O power. The OMRON S82J-series Power Supply is recommended. (See note.)
3. Products complying with EC Directives also conform to the Emission Standards (EN 61131-2 and EN 61000-6-4). Radiated emission characteristics (10-m regulations) may vary depending on the configuration of the control panel used, other devices connected to the control panel, wiring, and other conditions. You must therefore confirm that the overall machine or equipment complies with EC Directives.

4. Conformance with the EC Directives was confirmed with a system configuration using I/O wiring lengths of less than 30 m.

Note Conformance with the EMC Directive was confirmed when using the recommended power supply.

SECTION 1

Features and Slave Units

This section describes the features and models of EtherNet/IP Slave Units

1-1	Feature of EtherNet/IP Slave Units	2
1-1-1	Overview	2
1-1-2	Features	3
1-2	EtherNet/IP Slaves	3
1-2-1	General-purpose Slaves	4
1-2-2	Environment-resistive Slaves	4

1-1 Feature of EtherNet/IP Slave Units

1-1-1 Overview

EtherNet/IP is an industrial multi-vendor network that uses Ethernet components. The EtherNet/IP specifications are open standards managed by the ODVA (Open DeviceNet Vendor Association), just like DeviceNet.

EtherNet/IP is not just a network between controllers; it is also used as a field network. The EtherNet/IP Slave Unit have the following features.

High-speed, High-capacity Data Exchange through Tag Data Links

The EtherNet/IP protocol supports implicit communications, which allows cyclic communications (called tag data links in this manual) with EtherNet/IP devices.

The default settings for remote I/O communications with the PLC are the same as for previous Slaves, whereby real I/O is allocated for each node address. One difference with previous Slaves is that an area for Smart Slave status information can be allocated to the Smart Slaves within the IN Area of the Master. This is in addition to real I/O. (Settings are performed using the Network Configurator or explicit messages.)

Tag Data Link (Cyclic Communications) Cycle Time

Tag data links (cyclic communications) can operate at the cyclic period specified for each application, regardless of the number of nodes. Data is exchanged over the network at the refresh cycle set for each connection, so the communications refresh cycle will not increase even if the number of nodes is increased, i.e., the synchronicity of the connection's data is preserved.

Since the refresh cycle can be set for each connection, each application can communicate at its ideal refresh cycle. For example, a processes interlocks can be transferred at high speed while the production commands and the status monitor information are transferred at low speed.

Note The communications load to the nodes must be within the Units' allowed communications bandwidth.

Note The CIP (Common Industrial Protocol) is a shared industrial protocol for the OSI application layer. The CIP is used in networks such as EtherNet/IP, ControlNet, and DeviceNet. Data can be routed easily between networks that are based on the CIP, so a transparent network can be easily configured from the field device level to the host level.

The CIP has the following advantages.

- Destination nodes are specified by a relative path, without fixed routing tables.
- The CIP uses the producer/consumer model. Nodes in the network are arranged on the same level and it is possible to communicate with required devices whenever it is necessary.

The consumer node will receive data sent from a producer node when the connection ID in the packet indicates that the node requires the data. Since the producer can send the same data with the same characteristics in a multicast (either multicast or unicast can be selected), the time required for the transfer is fixed and not dependent on the number of consumer nodes.

1-1-2 Features

EtherNet/IP Slaves have the following features.

Common Features

Node Addresses Set Using Rotary Switches

Node addresses are set using rotary switches, which are clearer than the previous DIP switch settings.

Automatically Detected Baud Rate

Smart Slaves do not require the baud rate to be set. The Smart Slave automatically operates at the baud rate of the switching hub.

I/O Power Status Monitor

The I/O Power Status Monitor is used to detect whether the I/O power supply is connected and provide notification in the Status Area. The Configurator or explicit messages can be used to read the information.

Input Filter (Input Units Only)

The input filter is used to read the input value several times during the set interval and remove irregular data caused by noise and switch chattering.

This function can also be used to create ON/OFF delays.

These settings are made by using the Network Configurator.

Detection Functions (Standard Feature)

Detection results can be read by using explicit messages if the sensor short-circuit/disconnected and external load short-circuit/disconnected detection functions are used. The error location can be rapidly specified and restored.

Features of Screw-less Clamp Terminals

Labor-saving Clamp Terminal Block

For I/O wiring, a screw-less clamp terminal block is provided. Wiring is reduced by the use of ferrules that can be easily inserted and then later removed by simply pressing a release button.

Features of Environment-resistive Terminals

Dust-proof and Waterproof Construction (IP67) for High Resistance to Environment

The environment-resistive construction enables usage in locations subject to oil and water splashes (IP67). An environment-resistive box is not required, enabling greater downsizing and reducing wiring labor.

No Power Supply Wiring for Input Devices


Power for communications, internal circuits, and input devices is shared, making wiring necessary only for the communications power supply.

1-2 EtherNet/IP Slaves


The EtherNet/IP Slaves are classified into the following categories.

- General-purpose Slaves
Slaves with digital I/O functions using standard connectors for communications cables.
- Environment-resistive Slaves
Slaves with I/O functions using round waterproof connectors for communications cables.

1-2-1 General-purpose Slaves

Name	Appearance	I/O points	Model number	Remarks
Screw-less Clamp Terminal with Transistors		32 input points (PNP)	ERT1-ID32SLH-1	With detection function
		16 input points/16 output points (PNP)	ERT1-MD32SLH-1	
		32 input points (PNP)	ERT1-OD32SLH-1	

1-2-2 Environment-resistive Slaves

Name	Appearance	I/O points	Model number	Remarks
Environment-resistive Terminals		16 input points (PNP)	ERT1-HD16CH-1	Waterproof, oil-proof, and spatter-proof construction (IP67). Equipped with detection functions.
		16 output points (PNP)	ERT1-WD16CH-1	

SECTION 2

System Startup Procedure

This section describes the overall procedure that is used to set up and start an EtherNet/IP system.

2-1	Overview of System Startup Procedure	6
2-1-1	Basic Procedure	6
2-1-2	Setting IP Addresses	8
2-1-3	Setting Tag Data Links	9
2-1-4	Checking Operation	11
2-1-5	Common Operating Procedures	12
2-1-6	Edit Connection Dialog Boxes	34
2-2	Recommended Network Devices	37
2-2-1	Network Devices Manufactured by OMRON	37

2-1 Overview of System Startup Procedure

This section explains the overall procedure for using EtherNet/IP using a basic example.

2-1-1 Basic Procedure

The basic procedure is given below. For details on settings and connections, refer to the *Operation Manual* for the Master Unit, as well as the detailed descriptions of individual Slaves.

■ Preparations



■ Setting IP addresses



■ Setting tag data links



■ Checking operation

Preparations

The following Units are used in this example.


EtherNet/IP Unit: CJ2H-CPU68-EIP

EtherNet/IP Slave Unit: ERT1-WD16CH-1

If tag data links are used, a switching hub must be installed. Select a switching hub that is capable of handling the type of communications being performed over the network.

Refer to *2-2 Recommended Network Devices*.

The network devices and IP addresses that are used in the following procedures are shown below. All of the devices have a subnet mask of 255.255.255.0, and are set to the same network address.



1. Network Configurator Initial Settings


Start the Network Configurator. Refer to *Common Procedure 2. Starting the Network Configurator*.

Install the EDS files for the Slave Units. Refer to *Common Procedure 3. Installing the EDS Files*.

2. Connecting the Slave Units

• Connecting the Ethernet Cable


Align the polarizing key, insert the connector on the Ethernet cable into the Ethernet connector on the Slave Unit, and then tighten the lock nut.



- Connecting the Power Cable


Align the polarizing key, insert the connector of the power cable into the power connector on the Slave Unit, and then tighten the lock nut. The Slave Unit requires a 24-VDC power supply.

Note Do not turn ON the power to the Slave Unit yet.



- Rotary Switches

The relationship between the rotary switches on the Slave Unit and the IP address is shown below.



Rotary switches	IP address
00	BOOTP/software setting
01 to FE	192.168.250.n (n = 01 to FE hex: Rotary switch setting)
FF	Restores the default setting. (To restore the default setting, set the switches to FF hex, cycle the power supply, and then set the switches to 00 hex.)

- Slave Default Settings


The default settings are as follows:

- Rotary switches: 00
- IP address: BOOTP

The IP address will be as follows when the rotary switches are set to 01 to FE hex: 192.168.250.n (n = Decimal equivalent of value set on rotary switches).

2-1-2 Setting IP Addresses

Set the slave IP address for each device. Set same network address for all devices. The following shows an example of setting the IP addresses for use in this procedure.



	Personal computer	EtherNet/IP Unit	EtherNet/IP Slave Unit
IP address	192.168.0.100	192.168.0.10	192.168.0.20
Subnet mask	255.255.255.0	255.255.255.0	255.255.255.0
Default gateway	Not set.	Not set (0.0.0.0).	Not set.

Note After an IP address has been set, check whether the setting is correct by connecting the personal computer to the device, and then entering “ping *IP_address*” from the personal computer. For the EtherNet/IP Unit in the above example, enter “ping 192.168.0.10.” The setting is correct if the following is returned.

```
Pinging 192.168.0.10 with 32 bytes of data:

Reply from 192.168.0.10: bytes=32 time=1ms TTL=255
Reply from 192.168.0.10: bytes=32 time=1ms TTL=255
Reply from 192.168.0.10: bytes=32 time<1ms TTL=255
Reply from 192.168.0.10: bytes=32 time<1ms TTL=255

Ping statistics for 192.168.0.10:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 1ms, Average = 0ms
```

1,2,3...

1. Setting the IP Address of the Personal Computer
Set the IP address of the personal computer.
2. Setting the IP Address of the EtherNet/IP Unit
Set the IP address of the EtherNet/IP Unit. Refer to *Common Procedure 6-1. Address Setting for OMRON EtherNet/IP Units*.
3. Setting the IP Addresses of the EtherNet/IP Slave Units
The IP address of an EtherNet/IP Slave Unit can be set using any of the following three methods.
 - Setting the IP address with a CIP message (Network Configurator)
 - Setting the IP address with a BOOTP/DHCP server
 - Setting the IP address with the rotary switches

■ Setting the IP Address with a CIP Message (Network Configurator)

The Network Configurator can be used to set IP addresses.

This method involves first using the rotary switches to set an initial IP address, and then using the Network Configurator to set the desired IP address.

- 1,2,3...**
1. Set the rotary switches (hexadecimal) on the Slave Unit to the initial IP address.
The initial IP address will be 192.168.250.n (where n is the value to which the rotary switches are set).
(If the rotary switches are set to 0A, the initial IP address will be 192.168.250.10.)
After setting the rotary switches, turn ON the power to the Slave Unit.
 2. Check to be sure the initial IP address is correct.
 3. Step III: Set the IP address using the Network Configurator.
Refer to *Common Procedure 4. Connecting the Network Configurator On-line* and *Common Procedure 6-2 Setting IP Addresses Using the Network Configurator*.
 4. Set the rotary switches to 00 and then turning the cycle the power supply.
Operation will start with the new IP address.

■ Setting the IP Address with the BOOTP/DHCP Server

This method involves first using the rotary switches to set an initial IP address, and then using the Network Configurator and the BOOTP/DHCP server to set the desired IP addresses.

- 1,2,3...**
1. Set the rotary switches to 00.
 2. Set the IP address using the BOOTP/DHCP server.
Refer to *Common Procedure 6-3. Setting IP Address Using the BOOTP Server*.

■ Setting the IP Address with the Rotary Switches

- 1,2,3...**
1. Set the rotary switches (hexadecimal) on the Slave Unit to the desired IP address.
The initial IP address will be 192.168.250.n (where n is the value to which the rotary switches are set).
(If the rotary switches are set to 0A, the initial IP address will be 192.168.250.10.)
After setting the rotary switches, turn ON the power to the Slave Unit.

2-1-3 Setting Tag Data Links

Set data links using the OMRON Network Configurator.

■ Connecting to the Network

Refer to *Common Procedure 4. Connecting the Network Online*.




■ Uploading the Network Configuration

Refer to *Common Procedure 5. Uploading the Current Network Configuration*.

■ Setting Tag Data Links


Set the tag data links.

- 1,2,3...**
1. Refer to *Common Procedure 7-2. Registering a Tag Set with the PLC*.
Create a 2-byte output tag.
 2. Set a connection.
The subsequent steps are performed using the CJ2B-EIP21 Edit Device Parameters Dialog Box.




The Edit Connection Dialog Box will not be closed. If no further connections are to be set, click the **Close** Button.

The connection will appear in the list of registered devices.



After a connection has been set, a window like the one shown below will be displayed.



When the above window is displayed, setting the connection has been completed.

3. Write the connection settings to the devices.

Refer to *Common Procedure 7-4. Downloading Connection Settings to Devices*.

2-1-4 Checking Operation

Make sure that tag data link is operating normally.

■ EtherNet/IP Unit

Check the display and indicators on the EtherNet/IP Unit. The following status indicates that tag data link is operating normally.

- MS indicator: Lit green.
- NS indicator: Lit green.
- 7-segment display: Shows the rightmost digits of the EtherNet/IP Unit node address in hexadecimal (0A would be displayed for address 192.168.0.10).

■ EtherNet/IP Slave Unit

Check the indicators on the Slave Unit. The following status indicates that tag data link is operating normally.

- MS indicator: Lit green.

- NS indicator: Lit green.

2-1-5 Common Operating Procedures

This section provides the procedures that are used to set up and start an EtherNet/IP Unit.

Common Procedure 1. Configuration Used in Common Procedures

Common Procedure 2. Starting the Network Configurator

Common Procedure 3. Installing EDS Files

Common Procedure 4. Connecting the Network Online

Common Procedure 5. Uploading the Current Network Configuration

Common Procedure 6. Setting IP Addresses

Common Procedure 6-1. Setting IP Addresses for OMRON EtherNet/IP Units

Common Procedure 6-2. Setting IP Addresses Using the Network Configurator

Common Procedure 6-3. Setting IP Addresses Using the BOOTP Server

Common Procedure 6-3-1. Enabling BOOTP from the Network Configurator

Common Procedure 6-3-2. Setting IP Addresses Using the BOOTP Server

Common Procedure 7. Setting Tag Data Links

Common Procedure 7-1. Setting the I/O Sizes of Devices

Common Procedure 7-2. Registering Tag Sets in the PLC

Common Procedure 7-2-1. Setting Tag Sets Using Physical Addresses

Common Procedure 7-2-2. Setting a Tag Using a Symbol

Common Procedure 7-2-3. Combining Tags Into a Single Tag Set

Common Procedure 7-3. Setting Connections

Common Procedure 7-4. Downloading Connection Settings to Devices


Common Procedure 7-4-1. Downloading the Same Connection Settings to All of the Devices in the Network Configurator

Common Procedure 7-4-2. Downloading Connection Settings to Selected Devices

Common Procedure 1. Configuration Used in Common Procedures

The following figure shows the configuration and IP addresses used in the common procedures.


The subnet mask is set to 255.255.255.0 and the same network address is set for all devices.



Common Procedure 2. Starting the Network Configurator

Select **All Programs – OMRON – CX-One – Network Configurator for EtherNet/IP – Network Configurator** from the Windows Start Menu. The Network Configurator will start.

The following window will be displayed.




Common Procedure 3. Installing EDS Files


EDS is an acronym for Electronic Data Sheet. An EDS file contains network device information. The OVDA requires that every EtherNet/IP device has an EDS file. Contact the manufacturer of the device to obtain an EDS file. Use the following procedure to install the EDS file.

1,2,3...

- Using the Network Configurator, select **EDS File – Install** to install the EDS file for the device to be connected.




- Select the EDS file of the device to be installed, and then click the **Open** Button




Select the EDS file for the device to be added.

- If there is also a device icon to be installed, click the **Yes** Button to start the installation. If there is no icon, click the **No** Button.



If there is no icon, click the **No** Button.

When the EDS file has been installed, the device will have been added as shown in the following window.




Common Procedure 4. Connecting the Network Online


This section describes how to connect the Network Configurator online through Ethernet (i.e., through the EtherNet/IP Unit).

Note Make sure that each device is connected via an Ethernet cable as described in *Common Procedure 1*, and that each device has the same network address.


- 1,2,3...
1. Select the interface for the Network Configurator (select online connection from the personal computer).
Select **Options – Select Interface – Ethernet I/F**.



2. Establish an online connection.
Select **Network – Connect**.




Select the Ethernet interface of the personal computer being used.



In the following diagram, TCP 2 indicates the EtherNet/IP network. Click the **OK** Button.




After the connection has been established, the following window will be displayed.




Common Procedure 5. Uploading the Current Network Configuration

This section explains the procedure for uploading the configuration information from the devices connected to the EtherNet/IP network.


Select **Network – Upload** to start uploading the configuration of the current network.



If the IP address of a connected device does not appear in the IP addresses displayed in this dialog box, click the **Add** Button and register that IP address. There may also be instances where the IP address of an unconnected device is displayed. If that occurs, just click the **OK** Button.



After the configuration information has been uploaded, the following window will be displayed. Check whether all of the connected EtherNet/IP devices are displayed in the window.



Common Procedure 6. Setting IP Addresses

This section explains three ways of setting IP addresses:

- Setting IP addresses for OMRON EtherNet/IP Units
- Setting the IP addresses using the Network Configurator (CIP messages)
- Setting the IP addresses using the BOOTP server

Common Procedure 6-1. Setting IP Addresses for OMRON EtherNet/IP Units


Use the following procedure to set the IP address of the OMRON EtherNet/IP Unit (CJ1W-EIP21, CS1W-EIP21, or CJ2B-EIP21).

- 1,2,3...**
1. Check the current IP address of the EtherNet/IP Unit.
Use the 7-segment display to check the IP address.



7-segment display

When the power is turned ON or the Unit is restarted, all of the segments of the display will flash twice, and then the display will flash "IP" twice. Then, the IP address set for the EtherNet/IP Unit will be displayed once only, flowing from the right to the left.

Example 1: Displaying IP Address 192.168.250.10**2. Set the address of the EtherNet/IP Unit**


Refer to *Common Procedure 4. Connecting the Network Online*. For details on setting IP addresses using the Network Configurator (CIP messages), refer to *Common Procedure 6-2*. When setting the IP addresses using a BOOTP server, refer to *Common Procedure 6-3*.

3. Operation after Completing the Setting

If an F3 error occurs after setting the IP address, set the node switches on the front of the EtherNet/IP Unit to the hexadecimal equivalent of the low-order digit of the IP address.

Common Procedure 6-2. Setting IP Addresses Using the Network Configurator


- 1,2,3...** 1. Select **Tools – Setup TCP/IP Configuration** to open the Setup TCP/IP Configuration Dialog Box.



2. Input the IP address of the device that is to be changed in the **Target IP Address Box**.

Click the **Get from the Device** Button to get the current settings.


Change the IP address or subnet mask, and then click the **Set to the Device** Button. The new settings will be written to the device.



When the settings have been completed, the following message will be displayed.



Note If the following message is displayed, perform the steps given below.




- Check whether the device supports IP address setting using the Network Configurator (IP address setting with CIP messages). If this method is not supported, use a different method to set the IP address.
- Repeat the above setting procedure from the very beginning. The IP address that was set for the device with the Network Configurator using a CIP message may not be enabled.

Common Procedure 6-3. Setting IP Addresses Using the BOOTP Server


Common Procedure 6-3-1. Enabling BOOTP from the Network Configurator

- 1,2,3... 1. Select **Tools – Setup TCP/IP Configuration** to open the Setup TCP/IP Configuration Dialog Box.



2. Input the current IP address of the device to be set in *Target IP Address* Box.

In the *New Configuration* Area, select the *Set the IP address via BOOTP server* Option, and then click the **Set to the Device** Button.



When the settings have been completed, the following message will be displayed.



Note If a message like the one shown below is displayed, perform the steps given below.




Repeat the above setting procedure from the very beginning.


Common Procedure 6-3-2. IP Address Setting Using the BOOTP Server

This procedure uses the BOOTP_DHCP Server distributed by Rockwell Automation, Inc., as the BOOTP server. (This server can be downloaded from <http://www.ab.com/networks/bootp.html>.)

- 1,2,3...**
1. Select **All Programs – Rockwell Software – BOOTP-DHCP Server** from the Windows Start Button to start the BOOTP server.




2. Connect those devices in either BOOTP or DHCP mode to the computer. For details on how to set BOOTP or DHCP mode, refer to the manual for each device.




3. Adding to the Relation List

Check the MAC address of the device to be added. Click the **New** Button in the dialog box. A table is created listing MAC addresses and the corresponding IP addresses assigned to the devices.



After the new entry has been registered, it will be added to the list as shown in the following diagram.



This completes setting the IP address using the BOOTP server.

Note To change the setting so that the IP address is no longer set using the BOOTP server, click the **Disable BOOTP/DHCP** Button. Subsequently, even if the device is turned OFF and then ON again, the IP address will not be set by the BOOTP server, and the device will start with the previous IP address.

Common Procedure 7. Setting Tag Data Links

Common Procedure 7-1. Setting the I/O Sizes of Devices


Depending on the device, the I/O sizes may either be fixed or symbol. For details on setting the device I/O sizes, refer to the manual for each device.

Common Procedure 7-2. Registering Tag Sets in the PLC.

Set the tag set in the PLC that is to function as the master. The tag set size must be the same as the device I/O size of the communications partner.

Two methods of registering a tag set are provided: using the physical addresses (*Common Procedure 7-2-1*), and using symbols (*Common Procedure 7-2-2*)

Note The following diagram illustrates the relationship between tag sets and tags.




- A tag set contains one or more tags.
- The size of a tag set will be equal to the total of the sizes of all of the tags in the tag set.

Common Procedure 7-2-1. Setting Tag Sets Using Physical Addresses


Use the following procedure to directly set physical addresses (e.g., in the CIO or DM Area) in the CPU Unit a PLC in the tag set.

1,2,3...

1. Double-click the icon for the EtherNet/IP Unit (CJ2B-EIP21 in the figure).




The Edit Device Parameters Dialog Box for the EtherNet/IP Unit will be displayed.




2. Register the tags.

Set the input tags first. An input tag receives the data that is output from the target.


Click the **In-Consume** Tab, and then click the **Edit Tags** Button.



The Edit Tags Dialog Box will be displayed. Click the **New** Button.



Set the tag name and size. Set the size in increments of 2 bytes. The input size must be the same as the output size of the target device. Click the **Register** Button to register the tag.




The tag name depends on the physical address, as shown below. *Addresses that do not appear in the following table cannot be specified. Also, the number of EM banks varies with the CPU Unit of the PLC.

Physical address		Address (text to input in Name Field)
CIO Area		0000 to 6143
Holding Area		H000 to H511
Work Area		W000 to W511
DM Area		D00000 to D32767
EM Area	Bank 0	E0_00000 to E0_32767
	to	to
	Bank 24	E18_00000 to E18_32767


The Edit Tag Dialog Box shown below will be displayed. When you are finished registering tags, click the **Close** Button.



A tag will be registered.




In the same way, set the output tag.



3. Register the tag set.

A message will be displayed asking if the registered tags are to be registered as a tag set. Click the **Yes** Button.



Common Procedure 7-2-2. Setting Tags Using Symbols


Use the following procedure to use CX-Programmer to create a symbol, which can then be loaded as a tag by the Network Configurator.

1,2,3...


1. Register the symbol with the CX-Programmer.

Start the CX-Programmer specifying the model number of the CPU Unit you are using.

2. Register the symbol.



When a network symbol has been created, a window like the one shown below will be displayed.




For example, the symbols shown below are created.

名称	データ型	アドレス / 値	ネットワーク変数
in1	WORD	E0.0 [自動]	入力
in2	WORD	E0.1 [自動]	入力
out1	WORD	E0.2 [自動]	出力
out2	WORD	E0.3 [自動]	出力
P_0_01s	BOOL	CF105	
P_0_02s	BOOL	CF103	
P_0_1ms	BOOL	CF107	


3. Import the symbol to the Network Configurator.

Start the Network Configurator while CX-Programmer is running.


Double-click the icon for the EtherNet/IP Unit (CJ2B-EIP21 in the diagram).




The Edit Device Parameters Dialog Box for the EtherNet/IP Unit will be displayed.




A message like the one shown below will be displayed. Click the **OK** Button.



A message like the one shown below will be displayed. Click the **Yes** Button.




A dialog box like the one shown below will be displayed. Each network symbol has been registered as a tag set.




Common Procedure 7-2-3. Combining Multiple Tags Into a Single Tag Set

The procedure shows how to combine more than one tag into a tag set.


Delete the tag sets without deleting the tags.



A warning message like the one shown below will be displayed. When only the tag sets are to be deleted, click the **No** Button.





Also delete the output tag sets.



The tag sets will be deleted.


Create a new tag set into which the tags will be combined.






A message will appear asking whether another tag set is to be created. If no other tag sets are to be created, click the **Close** Button.


Note When tag data links operate, data is sent in the order in which the tags are registered in the tag set. When combining tags into a tag set, pay attention to the order and size of the tags.



The new tag set has been registered.




Also register the output tag set.



This completes the combining tags into a tag set.

Common Procedure 7-3. Setting Connections

This procedure is performed using the CJ2B-EIP21 Edit Device Parameters Dialog Box.



1. Input a name for the connection.

2. Input the RPI.

3. Select the consume and produce variables. Make sure that the sizes are the same.

4. Also register the output variables.

5. To register the connection, click the **Register** Button.

コネクション名: connection1

コネクション/Oタイプ: Discrete Exclusive Owner

ハワットインターバル (RPD): 50.0 ms (0.5 - 10000.0 ms)

タイムアウト値: ハワットインターバル (RPD x 4)

ターゲットデバイスから入力

オリジネータ変数: D00000 - [RPI]

ターゲット変数: Input_100 - [2Byte]

コネクションタイプ: Multi-cast connection

ターゲットデバイスへ出力

オリジネータ変数: D01000 - [RPI]

ターゲット変数: Output_150 - [2Byte]

コネクションタイプ: Point to Point connection

オリジネータデバイス

ノードアドレス: 192.168.0.10

説明: C.J2B-EIP21

ターゲットデバイス

ノードアドレス: 192.168.0.20

説明: SMC EX250-SEN1 SI UNIT

登録(R) 閉じる(C)

The dialog box for making connections will not close. If no more connections are to be created, click the **Close** Button.

コネクション名:

コネクション/Oタイプ: Discrete Exclusive Owner

ハワットインターバル (RPD): 50.0 ms (0.5 - 10000.0 ms)

タイムアウト値: ハワットインターバル (RPD x 4)

ターゲットデバイスから入力

オリジネータ変数:

ターゲット変数:

コネクションタイプ: Multi-cast connection

ターゲットデバイスへ出力

オリジネータ変数:

ターゲット変数:

コネクションタイプ: Point to Point connection

オリジネータデバイス

ノードアドレス: 192.168.0.10

説明: C.J2B-EIP21

ターゲットデバイス

ノードアドレス: 192.168.0.20

説明: SMC EX250-SEN1 SI UNIT

登録(R) 閉じる(C)

The new connection will be displayed in the Registered Device List.

コネクション [タブ]

未登録デバイス一覧

#	Product Name
1	192.168.0.20 SMC EX

コネクション数: 2/256 (O:2, T:0)

登録デバイス一覧


Product Name	Variable	Target Variable
192.168.0.20 SMC EX	connection1 [Input]	D00000
	connection1 [Output]	D01000

Click the **OK** Button to enable the settings.

新規(N) 編集(E) 削除(D) 一括編集(B) ターゲットノードの変更(C) 再作成(R)

OK キャンセル

After the connection settings have been made, a window like the one shown below will be displayed.



This completes the connection settings.

Common Procedure 7-4. Downloading the Connection Settings to a Device.


This section explains how the connection settings made with the Network Configurator are downloaded to the devices and enabled.

Either of the following two methods can be used.


- Downloading the same connection settings to all devices in the Network Configurator
- Downloading connection settings only to selected devices

Common Procedure 7-4-1 Downloading the Same Connection Settings to all Devices in the Network Configurator


Use the following procedure to download the same connection settings to all of the devices displayed in the window.



Depending on the status of the connected PLC, a window like the one shown below may be displayed.




After the connection settings have been downloaded, a message like the one shown below will be displayed. Click the **OK** Button.




Common Procedure 7-4-2 Downloading Connection Settings to Selected Devices

From the devices displayed in the window, select those to which the connection settings are to be downloaded.



Select devices from among those displayed in the window. In the following example, the device on the left and device on the right are selected.




Right-click and select **Parameter – Download**.



Depending on the status of the connected PLC, a window like the one shown below may be displayed.



After the connection settings have been downloaded, a message like the one shown below will be displayed. Click the **OK** Button.



2-1-6 Edit Connection Dialog Boxes

The following figures show examples of connection settings for various EtherNet/IP Slave Units.

• ERT1-WD16CH-1

192.168.0.20 ERT1-WD16CH-1へのコネクション割付

コネクション名: 01

コネクション/タイプ: 01_Output Only

パケットインターバル (RPD): 500 ms (0.5 - 10000.0 ms)

タイムアウト値: パケットインターバル (RPD) x 4

ターゲットデバイスから入力

オリジネータ変数:

ターゲット変数:

コネクションタイプ: Point to Point connection

ターゲットデバイスへ出力

オリジネータ変数: 000000 - [2Byte]

ターゲット変数: Output_35 - [2Byte]

コネクションタイプ: Point to Point connection

オリジネータデバイス

ノードアドレス: 192.168.0.10

説明: CJB-EIP21

ターゲットデバイス

ノードアドレス: 192.168.0.20

説明: ERT1-WD16CH-1

登録(R) 開じる(O)

1. Input a name for the connection.
2. Select 01_Output Only.
3. Input the RPI.
4. Select the consume and produce variables. For the produce variable, select Output_35. Make sure that the sizes of the variables are the same.

• ERT1-HD16CH-1

192.168.0.20 ERT1-HD16CH-1へのコネクション割付

コネクション名: 01

コネクション/タイプ: 01_Input Only

パケットインターバル (RPD): 500 ms (0.5 - 10000.0 ms)

タイムアウト値: パケットインターバル (RPD) x 4

ターゲットデバイスから入力

オリジネータ変数: 000000 - [2Byte]

ターゲット変数: Input_5 - [2Byte]

コネクションタイプ: Multi-cast connection

ターゲットデバイスへ出力

オリジネータ変数:

ターゲット変数:

コネクションタイプ: Point to Point connection

オリジネータデバイス

ノードアドレス: 192.168.0.10

説明: CJB-EIP21

ターゲットデバイス

ノードアドレス: 192.168.0.20

説明: ERT1-HD16CH-1

登録(R) 開じる(O)

1. Input a name for the connection.
2. Select 01_Input Only.
3. Input the RPI.
4. Select the consume and produce variables. For the produce variable, select Input_5. Make sure that the sizes of the variables are the same.

• ERT1-ID32SLH-1

192.168.250.3 ERT1-ID32SLH-1へのコネクション割付

コネクション名: 01

コネクション/タイプ: 01_Input Only

パケットインターバル (RPD): 500 ms (0.5 - 10000.0 ms)

タイムアウト値: パケットインターバル (RPD) x 4

ターゲットデバイスから入力

オリジネータ変数: Input_6 - [4Byte]

ターゲット変数: Input_6 - [4Byte]

コネクションタイプ: Multi-cast connection

ターゲットデバイスへ出力

オリジネータ変数:

ターゲット変数:

コネクションタイプ: Point to Point connection

オリジネータデバイス

ノードアドレス: 192.168.250.200

説明: CJB-EIP21

ターゲットデバイス

ノードアドレス: 192.168.250.3

説明: ERT1-ID32SLH-1

OK キャンセル

1. Input a name for the connection.
2. Select 01_Input Only.
3. Input the RPI.
4. Select the consume and produce variables. For the produce variable, select Input_6. Make sure that the sizes of the variables are the same.

• ERT1-OD32SLH-1

192.168.250.2 ERT1-OD32SLH-1へのコネクション割付

コネクション名: 1

コネクションI/Oタイプ: 01_Output Only

パケットインターバル (RPD): 500 ms (0.5 - 10000.0 ms)

タイムアウト値: パケットインターバル (RPD) x 4

ターゲットデバイスから入力

オリジネータ変数: []

ターゲット変数: []

コネクションタイプ: Point to Point connection

ターゲットデバイスへ出力

オリジネータ変数: [0005 - [4Byte]

ターゲット変数: [Input_36 - [4Byte]

コネクションタイプ: Point to Point connection

オリジネータデバイス

ノードアドレス: 192.168.250.200

説明: C-J1W-EIP21

ターゲットデバイス

ノードアドレス: 192.168.250.2

説明: ERT1-OD32SLH-1

OK

1. Input a name for the connection.

2. Select 01_Output Only.

3. Input the RPI.

4. Select the consume and produce variables. For the produce variable, select Input_36. Make sure that the sizes of the variables are the same.

• ERT1-MD32SLH-1

192.168.250.1 ERT1-MD32SLH-1へのコネクション割付

コネクション名: 1

コネクションI/Oタイプ: 01_Output and Input

パケットインターバル (RPD): 500 ms (0.5 - 10000.0 ms)

タイムアウト値: パケットインターバル (RPD) x 4

ターゲットデバイスから入力

オリジネータ変数: [0100 - [2Byte]

ターゲット変数: [Input_5 - [2Byte]

コネクションタイプ: Multi-point connection

ターゲットデバイスへ出力

オリジネータ変数: [0001 - [2Byte]

ターゲット変数: [Output_5 - [2Byte]

コネクションタイプ: Point to Point connection

オリジネータデバイス

ノードアドレス: 192.168.250.200

説明: C-J1W-EIP21

ターゲットデバイス

ノードアドレス: 192.168.250.1

説明: ERT1-MD32SLH-1

1. Input a name for the connection.

2. Select 01_Output Only.

3. Input the RPI.

4. Select the consume and produce variables. For the produce variable, select Input_35. Make sure that the sizes of the variables are the same.

5. Select the consume and produce variables. For the produce variable, select Output_5. Make sure that the sizes of the variables are the same.

2-2 Recommended Network Devices

The following table shows the devices recommended for use with the EtherNet/IP.

Part	Maker	Model number	Inquires
Switching Hub	Cisco Systems, Inc.	Consult the manufacturer.	Cisco Systems, Inc. Main Corporate HQ
	Contec USA, Inc.	Consult the manufacturer.	CONTEC USA Inc.
	Phoenix Contact	Consult the manufacturer.	Phoenix Contact USA Customer Service
Twisted-pair cable	100BASE-TX		
	Fujikura	F-LINK-E 0.5mm × 4P	Fujikura America, Inc.
	EtherNet/IP compliant cable		---
Connectors (Modular plug)	STP Plug		
	Panduit Corporation	MPS588	Panduit Corporation US Headquarters
Boots	Tsuko Company	MK boot (IV) LB	Tsuko Company Japan Headquarters

- Note**
- (1) Always use a switching hub when using tag data links in the network.
 - (2) If a repeater hub is used for EtherNet/IP tag data links (cyclic communications), the network's communications load will increase, data collisions will occur frequently, and stable communications will be impossible.

2-2-1 Network Devices Manufactured by OMRON

The following network devices are manufactured by OMRON for EtherNet/IP networks.

Name	Model	Function	Number of ports	Error detection output
Switching Hub	W4S1-03B	Packet priority control (QoS): EtherNet/IP control data priority	3	None
	W4S1-05B		5	None
	W4S1-05C	Failure detection: Broadcast storm, LSI error detection, 10/100Base-TX, Auto-Negotiation	5	Provided.
	W4S1-10B		10	None
	W4S1-10C		10	Provided.

SECTION 3

Basic Specifications of Slave Units

This section provide the basic specifications of the EtherNet/IP Slave Units

3-1	Basic Specifications of Slave Units	40
3-1-1	Communications Specifications	40
3-1-2	Performance Specifications	40
3-1-3	Communications Indicators	40

3-1 Basic Specifications of Slave Units

This section gives the specifications that are the same for all Slave Units. For specifications that vary with the Slave Unit, refer to the section for each Slave Unit.

3-1-1 Communications Specifications

Item		Specifications
Communications protocol		EtherNet/IP
Type		100Base-TX (See note.)
Transfer specifications	Media access method	CSMA/CD
	Modulation method	Baseband
	Transmission paths	Star form
	Baud rate	100 Mbit/s (100Base-TX)
	Transmission media	Shielded twisted-pair (STP) cable Categories: 100 Ω at 5, 5e or higher
	Transmission distance	100 m (distance between hub and node)
Number of cascade connections		There is no limitation when a switching hub is used.

Note If tag data links are being used, use 100Base-TX.

3-1-2 Performance Specifications










Item	Specifications
Unit power supply voltage	20.4 to 25 VDC
I/O power supply voltage	20.4 to 26.4 VDC (24 VDC, -15 to +10%)
Noise immunity	Power lines: Conforms to IEC 61000-4-4 2 kV. Conforms to the following EC Directives: IEC 61000-4-2 IEC 61000-4-3 IEC 61000-4-5 IEC 61000-4-6
Vibration resistance	10 to 60 Hz with 0.35-mm amplitude 10 times each up, down, right, and left 60 to 150 Hz, 50 m/s ²
Shock resistance	Maximum acceleration of 150 m/s ² 3 times each up, down, right, and left
Insulation resistance	20 M Ω min. (at 250 VDC) between current-carrying circuits and non-current-carrying circuits
Ambient temperature	-10 to 55°C
Ambient humidity	25% to 85% (with no condensation)
Storage temperature	-25 to 65°C
Mounting	Mounted on 35-mm DIN Track, or secured with M5 screws (depending on model)

3-1-3 Communications Indicators

The communications indicators have the following meanings.

MS (Module Status): Indicates the status of the node with a two-color LED (green/red).

NS (Network Status): Indicates the status of communications with a two-color LED (green/red).

Name	Indicator status	Node/communications status	Meaning
MS	Lit green. 	Normal status	The Unit is operating normally.
	Lit red. 	Fatal error	A hardware error has occurred in the Unit. The watchdog timer has timed-out.
	Flashing red. 	Non-fatal error	There is an error in the switch settings.
	Not lit. 	Power OFF or Startup	The power supply is OFF, the Unit is being reset, or the Unit is being initialized.
NS	Lit green. 	Online and participating	Tag data link communications have been established and normal communications are in progress.
	Flashing green. 	Online but not participating	Normal communications are in progress, but tag data link communications have not been established.
	Lit red. 	Fatal communications error	The address is set out of range. The same address has been set for more than one node.
	Flashing red. 	Non-fatal communications error	Communications has timed out.
	Not lit. 	Power OFF or offline	The power supply is OFF or the cable is not connected.

Note When flashing, indicators are lit for 0.5 s and not lit for 0.5 s.

SECTION 4

Digital I/O Slave Units

This section describes the Digital I/O Slave Units for EtherNet/IP.

4-1	Status Areas	44
4-1-1	Generic Status Area	44
4-1-2	I/O Status Area	45
4-2	Screw-less Clamp Terminals	45
4-2-1	Wiring to a Screw-less Clamp Terminal Block	45
4-2-2	Thirty-two-point Input Units (with Screw-less clamps)	47
4-2-3	Thirty-two-point Output Units (with Screw-less Clamps)	50
4-2-4	Sixteen-point Input and Sixteen-point Output Units (with Screw-less clamps)	53

4-1 Status Areas

A Digital I/O Slave Unit has two internal status areas: the Generic Status Area and the I/O Status Area. The status flags in these areas are turned ON and OFF based on the threshold values set by the user for each function in that Unit.

4-1-1 Generic Status Area

The Digital I/O Slave Unit's Generic Status Area contains the following 16 bits.

Bit	Content	Description
00	I/O Power Supply Status Flag 1 OFF: I/O power is ON ON: I/O power is not ON.	Turns ON when I/O power is not being supplied to terminal block 1.
01	I/O Power Supply Status Flag 2 OFF: I/O power is ON ON: I/O power is not ON.	Turns ON when I/O power is not being supplied to terminal block 2.
02	Reserved	---
03	Reserved	---
04	Power or Load Short-circuit Detection Flag OFF: Normal ON: Short-circuit	Turns ON when there is a short in the power supply or load connection to the connected devices, including wiring mistakes and connected device failure.
05	Disconnection Flag OFF: Connected ON: Disconnected	Turns ON when the sensor power supply is not connected or the load is disconnected due to a wiring error, failure in the connected device, etc.
06	Reserved	---
07	Reserved	---
08	EEPROM Data Error Flag OFF: Normal ON: Error occurred	Turns ON when there is an error in the EEPROM data.
09	Reserved	---
10	Reserved	---
11	Reserved	---
12	Reserved	---
13	Reserved	---
14	Reserved	---
15	Reserved	---

4-1-2 I/O Status Area

The I/O Status Area for a Digital I/O Slave Unit consists of the following 8 bytes (64 bits). The I/O Status Area indicates the short-circuit and disconnection error status for each terminal.

Byte offset	Data							
	Bit 07	06	05	04	03	02	01	00
0	Power or Load Short-circuit Detection Flags for Terminal Block 1							
	07	06	05	04	03	02	01	00
1	Power or Load Short-circuit Detection Flags for Terminal Block 1							
	15	14	13	12	11	10	09	08
2	Power or Load Short-circuit Detection Flags for Terminal Block 2							
	07	06	05	04	03	02	01	00
3	Power or Load Short-circuit Detection Flags for Terminal Block 2							
	15	14	13	12	11	10	09	08
4	Disconnection Flags for Terminal Block 1							
	07	06	05	04	03	02	01	00
5	Disconnection Flags for Terminal Block 1							
	15	14	13	12	11	10	09	08
6	Disconnection Flags for Terminal Block 2							
	07	06	05	04	03	02	01	00
7	Disconnection Flags for Terminal Block 2							
	15	14	13	12	11	10	09	08

4-2 Screw-less Clamp Terminals

The screw-less clamp terminal has a structure designed for clamping to a terminal block. It is a reduced-wiring, labor-saving Slave that can make wiring easy by simply inserting ferrules (with sleeves). The Unit and terminal block can be detached, making it possible to replace the Unit in the event of a failure without removing the wiring.

A detection function is also provided to help quickly discover short-circuits and disconnections for sensors or other devices.

4-2-1 Wiring to a Screw-less Clamp Terminal Block

Screw-less clamp terminals provide clamp-type terminal blocks that allow wiring without screws. When connecting a sensor or an external device, a ferrule must be attached to the cable for the sensor or device. The following ferrules are applicable.

Manufacturer	Model	
Phoenix Contact	AI-0.5-10	0.5 mm ² (AWG 20)
	AI-0.75-10	0.75 mm ² (AWG 18)
	AI-1.5-10	1.25 mm ² (AWG 16)
	AI-2.5-10	2.0 mm ² (AWG 14)
Nihon Weidmuller	H 0.5/16 D	0.5 mm ² (AWG 20)
	H 0.75/16 D	0.75 mm ² (AWG 18)
	H 1.5/16 D	1.25 mm ² (AWG 16)
	H 2.5/16 D	2.0 mm ² (AWG 15)


Wiring to a Clamp Terminal Block

Insertion

Insert the ferrule all the way to the end in any terminal hole.


Removal

Pull out the power line while pressing down with a small flat-blade screwdriver on the release button above the terminal hole.



Screwdriver Used to Remove Ferrules

You will need a screwdriver that is consistently thin for the entire length.



Recommended Screwdriver Model

Model	Manufacturer
SZF1	Phoenix Contact


Removing and Mounting a Clamp Terminal Block

Removal

Use a flat-blade screwdriver to loosen the four screws on the top of the terminal block, and then grasp the handles on both sides and remove the terminal block.

Mounting

Grasp the handles on both sides of the terminal block, and insert the terminal block firmly in place. Then use a flat-blade screwdriver to tighten the four screws on the top of the terminal block.



Note Tighten the screws to a torque of 0.2 to 0.25 N·m.


4-2-2 Thirty-two-point Input Units (with Screw-less clamps)

ERT1-ID32SLH-1

Input Specifications

Item	Specifications
Input points	32 points
Internal I/O common	PNP
ON voltage	15 V DC min. (between each input terminal and 0 V)
OFF voltage	5 V DC max. (between each input terminal and 0 V)
OFF current	1.0 mA max.
Input current	6.0 mA max. at 24 V DC 3.0 mA max. at 17 V DC
ON delay time	1.5 ms max.
OFF delay time	1.5 ms max.
Number of circuits	16 points with one common circuit
Isolation method	Photocoupler isolation
Input indicators	LEDs (yellow)
Power supply short-circuit protection	Operates at 50 mA/point min.
Disconnection detection	Operates at 0.2 mA/point max.
Current consumption	Communications power supply (including internal circuits): 110 mA max.
Connection forms	Screw-less clamp terminal blocks (orange)
Mounting	35-mm DIN Track mounting
Weight	485 g max.
Standard accessories	FKMCP1.52STF3.5AUSOO (Phoenix Contacts) (connector with lock screws)

Component Names and Functions



(1) Rotary Switches


These switches are used to set the node address.

(2) Ethernet Connector

The network communications cable is connected to this connector.

(3) Power Supply Connector

The communications and Unit power supply is connected to this connector.



Terminal	Specification
+	24 V DC
-	0 V DC

Applicable Ferrules

Manufacturer	Model	Applicable wire size
Phoenix Contact	AI-0.5-10	0.5 mm ² (AWG 20)
Nihon Weidmuller	H 0.5/16 D	0.5 mm ² (AWG 20)

(4) Communications Indicators: MS and NS

These indicators show the Unit communications status and network communications status.

(5) and (6) Terminal Blocks 1 and 2

The input devices and input power supply are connected to these terminal blocks.

(7) and (8) Input Indicators

These indicators show the ON/OFF status of the inputs and the error status of connected devices.

Indicators**Communications Indicators**

Refer to 3-1-3 *Communications Indicators*.

I/O Indicators

The meanings of the input indicators are given in the following table.

Indicator name	Status	Color	Meaning (main error)
0 to 15		Yellow	Lit yellow when input is ON.
		Red	Flashing red when the load is disconnected. Automatically reset when the load is connected.
		Red	Lit red when the load is short-circuited. Automatically reset when the short-circuit is removed.
		OFF	Not lit when input is OFF.
I/O		Green	Lit green when I/O power is being supplied.
		OFF	Not lit when I/O power is not being supplied.

Setting the Node Address

The rotary switches are used to set the lower digits of the IP address.

Setting method	Two hexadecimal digits
Setting range	01 to FE

**Rotary Switch Settings**


00 hex: BOOTP or tool setting enabled (factory setting)

01 to FE hex: Setting on rotary switches is lower 8 bits of IP address. (Default setting of upper 24 bits: 192.168.250.)

FF hex: Restores default setting.

(To restore the default setting, set the switches to FF hex, cycle the power supply, and then set the switches to 00 hex.)

Internal Circuits



Wiring

NC	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	NC
V	V0	V1	V2	V3	V4	V5	V6	V7	V8	V9	V10	V11	V12	V13	V14	V15	V
G	G	G	G	G	G	G	G	G	G	G	G	G	G	G	G	G	G

X

VX

G

Brown (White)

Blue (Black)

(IEC colors) (Previous colors)

2-wire sensors
(2-wire proximity sensors)

X

VX

G

Blue (Black)


Brown (Red)

Black (White)

(IEC colors) (Previous colors)

3-wire sensors
(photoelectric or proximity sensors)

X: 0 to 15


Dimensions**4-2-3 Thirty-two-point Output Units (with Screw-less Clamps)**

ERT1-OD32SLH-1

Output Specifications

Item	Specification
Output points	32 points
Internal I/O common	PNP
Output current	0.5 A/point, 4.0 A/common
Residual voltage	1.2 V max. (0.5 A DC, between each output terminal and the V terminal)
Leakage current	0.3 mA max. (24 V DC, between each output terminal and the V terminal)
ON delay	0.5 ms max.
OFF delay	1.5 ms max.
Number of circuits per common	16 outputs/common
Isolation method	Photocoupler
Output indicators	LED (yellow)
Power supply short-circuit protection	Operates when output current is exceeded.
Disconnection detection	Operates at current consumption of 3 mA/point max. (Not detected at 3 mA or less.)
Output handling for communications errors	Select either hold or clear from Network Configurator.
Current consumption	Communications power supply (including internal circuits): 120 mA max.
Connection forms	Screw-less clamp terminal blocks (yellow)
Mounting	35-mm DIN Track mounting
Weight	485 g max.
Standard accessories	FKMCP1.52STF3.5AUSOO (Phoenix Contacts) (connector with lock screws)

Component Names and Functions



(1) Rotary Switches


These switches are used to set the node address.

(2) Ethernet Connector

The network communications cable is connected to this connector.

(3) Power Supply Connector

The communications and Unit power supply is connected to this connector.



Terminal	Specification
+	24 V DC
-	0 V DC

Applicable Ferrules

Manufacturer	Model	Applicable wire size
Phoenix Contact	AI-0.5-10	0.5 mm ² (AWG 20)
Nihon Weidmuller	H 0.5/16 D	0.5 mm ² (AWG 20)

(4) Communications Indicators: MS and NS

These indicators show the Unit communications status and network communications status.

(5) and (6) Terminal Blocks 1 and 2

The output devices and output power supply are connected to these terminal blocks.

(7) and (8) Output Indicators

These indicators show the ON/OFF status of the outputs and the error status of connected devices.







Indicators

Communications Indicators

Refer to 3-1-3 Communications Indicators.

I/O Indicators

The meanings of the input indicators are given in the following table.

Indicator name	Status	Color	Meaning (main error)
0 to 15		Yellow	Lit yellow when output is ON.
		Red	Flashing red when the load is disconnected. Automatically reset when the load is connected.
		Red	Lit red when the load is short-circuited. Automatically reset when the short-circuit is removed.
		OFF	Not lit when output is OFF.
I/O		Green	Lit green when I/O power is being supplied.
		OFF	Not lit when I/O power is not being supplied.

Setting the Node Address

The rotary switches are used to set the lower digits of the IP address.

Setting method	Two hexadecimal digits
Setting range	01 to FE


**Rotary Switch Settings**

00 hex: BOOTP or tool setting enabled (factory setting)


01 to FE hex: Setting on rotary switches is lower 8 bits of IP address. (Default setting of upper 24 bits: 192.168.250.)

FF hex: Restores default setting.


(To restore the default setting, set the switches to FF hex, cycle the power supply, and then set the switches to 00 hex.)

Internal Circuits**Wiring**

NC	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	NC
V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
G	G	G	G	G	G	G	G	G	G	G	G	G	G	G	G	G	G



Dimensions



4-2-4 Sixteen-point Input and Sixteen-point Output Units (with Screw-less clamps)

ERT1-MD32SLH-1

Common Specifications

Item	Specifications
Current consumption	Communications power supply (including internal circuits): 110 mA max.
Mounting	35-mm DIN Track mounting
Weight	485 g max.
Standard accessories	FKMCP1.52STF3.5AUSOO (Phoenix Contacts) (connector with lock screws)

Input Specifications


Item	Specifications
Input points	16 points
Internal I/O common	PNP
ON voltage	15 V DC min. (between each input terminal and 0 V)
OFF voltage	5 V DC max. (between each input terminal and 0 V)
OFF current	1.0 mA max.

Item	Specifications
Input current	6.0 mA max. at 24 V DC 3.0 mA max. at 17 V DC
ON delay time	1.5 ms max.
OFF delay time	1.5 ms max.
Number of circuits	16 points with one common circuit
Isolation method	Photocoupler isolation
Input indicators	LEDs (yellow)
Power supply short-circuit	Operates at 50 mA/point min.
Disconnection detection	Operates at 0.2 mA/point max.
Connection forms	Screw-less clamp terminal blocks (orange)

Output Specifications

Item	Specification
Output points	16 points
Internal I/O common	PNP
Output current	0.5 A/point, 4.0 A/common
Residual voltage	1.2 V max. (0.5 A DC, between each output terminal and the V terminal)
Leakage current	0.3 mA max. (24 V DC, between each output terminal and the V terminal)
ON delay	0.5 ms max.
OFF delay	1.5 ms max.
Number of circuits per common	16 outputs/common
Isolation method	Photocoupler
Output indicators	LEDs (yellow)
Power supply short-circuit protection	Operates when output current is exceeded.
Disconnection detection	Operates at current consumption of 3 mA/point max. (Not detected at 3 mA or less.)
Output handling for communications errors	Select either hold or clear from Network Configurator.
Connection forms	Screw-less clamp terminal blocks (yellow)

Component Names and Functions



(1) Rotary Switches


These switches are used to set the node address.

(2) Ethernet Connector

The network communications cable is connected to this connector.

(3) Power Supply Connector

The communications and Unit power supply is connected to this connector.



Terminal	Specification
+	24 V DC
-	0 V DC

Applicable Ferrules

Manufacturer	Model	Applicable wire size
Phoenix Contact	AI-0.5-10	0.5 mm ² (AWG 20)
Nihon Weidmuller	H 0.5/16 D	0.5 mm ² (AWG 20)

(4) Communications Indicators: MS and NS

These indicators show the Unit communications status and network communications status.

(5) and (6) Terminal Blocks 1 and 2

The I/O devices and output power supply are connected to these terminal blocks.

(7) and (8) I/O Indicators

These indicators show the ON/OFF status of the I/O and the error status of connected devices.

Indicators**Communications Indicators**

Refer to 3-1-3 Communications Indicators.

I/O Indicators


The meanings of the input indicators are given in the following table.

Indicator name	Status	Color	Meaning (main error)
0 to 15		Yellow	Lit yellow when input or output is ON.
		Red	Flashing red when the load is disconnected. Automatically reset when the load is connected.
		Red	Lit red when the load is short-circuited. Automatically reset when the short-circuit is removed.
		OFF	Not lit when input or output is OFF.
I/O		Green	Lit green when I/O power is being supplied.
		OFF	Not lit when I/O power is not being supplied.

Setting the Node Address

The rotary switches are used to set the lower

Setting method	Two hexadecimal digits
Setting range	01 to FE





Rotary Switch Settings

00 hex: BOOTP or tool setting enabled (factory setting)


01 to FE hex: Setting on rotary switches is lower 8 bits of IP address. (Default setting of upper 24 bits: 192.168.250.)

FF hex: Restores default setting.

(To restore the default setting, set the switches to FF hex, cycle the power supply, and then set the switches to 00 hex.)


Internal Circuits**Inputs****Outputs****Wiring****Inputs**

NC	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	NC
V	V0	V1	V2	V3	V4	V5	V6	V7	V8	V9	V10	V11	V12	V13	V14	V15	V
G	G	G	G	G	G	G	G	G	G	G	G	G	G	G	G	G	G




Outputs

NC	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	NC
V	V0	V1	V2	V3	V4	V5	V6	V7	V8	V9	V10	V11	V12	V13	V14	V15	V
G	G	G	G	G	G	G	G	G	G	G	G	G	G	G	G	G	G



Dimensions



SECTION 5

Environment-resistive Slave Units

This section describes the Environment-resistive Slave Units for EtherNet/IP.

5-1	Status Areas	60
5-1-1	Generic Status Area	60
5-1-2	I/O Status Area	60
5-2	Environment-resistive Slave Units	61
5-2-1	Mounting in Control Panels	61
5-2-2	Environment-resistive Terminals with 16 Transistor Inputs (IP67) .	61
5-2-3	Environment-resistive Terminals with 16 Transistor Outputs (IP67)	66

5-1 Status Areas

An Environment-resistive Slave Unit has two internal status areas: the Generic Status Area and the I/O Status Area. The status flags in these areas are turned ON and OFF based on the threshold values set by the user for each function in that Unit.

5-1-1 Generic Status Area

The Environment-resistive Slave Unit's Generic Status Area contains the following 16 bits. These bits indicate minor errors in the Unit.

Bit	Content	Description
00	I/O Power Supply Status Flag OFF: I/O power is ON. ON: I/O power is not ON.	Turns ON when I/O power is not being supplied.
01	Reserved	---
02	Reserved	---
03	Reserved	---
04	Power or Load Short-circuit Detection Flag OFF: Normal ON: Short-circuit	Turns ON when there is a short in the power supply or load connection to the connected devices, including wiring mistakes and connected device failure.
05	Disconnection Flag OFF: Connected ON: Disconnected	Turns ON when the sensor power supply is not connected or the load is disconnected due to a wiring error, failure in the connected device, etc.
06	Reserved	---
07	Reserved	---
08	EEPROM Data Error Flag OFF: Normal ON: Error occurred	Turns ON when there is an error in the EEPROM data.
09	Reserved	---
10	Reserved	---
11	Reserved	---
12	Reserved	---
13	Reserved	---
14	Reserved	---
15	Reserved	---

5-1-2 I/O Status Area

The I/O Status Area for an Environment-resistive Slave Unit consists of the following 8 bytes (64 bits). The I/O Status Area indicates the short-circuit and disconnection error status for each terminal.

Byte offset	Data							
	Bit 07	06	05	04	03	02	01	00
0	Power or Load Short-circuit Detection Flags for Terminal Block 1							
	07	06	05	04	03	02	01	00
1	Power or Load Short-circuit Detection Flags for Terminal Block 1							
	15	14	13	12	11	10	09	08

Byte offset	Data							
	Bit 07	06	05	04	03	02	01	00
2	Power or Load Short-circuit Detection Flags for Terminal Block 2							
	07	06	05	04	03	02	01	00
3	Power or Load Short-circuit Detection Flags for Terminal Block 2							
	15	14	13	12	11	10	09	08
4	Disconnection Flags for Terminal Block 1							
	07	06	05	04	03	02	01	00
5	Disconnection Flags for Terminal Block 1							
	15	14	13	12	11	10	09	08
6	Disconnection Flags for Terminal Block 2							
	07	06	05	04	03	02	01	00
7	Disconnection Flags for Terminal Block 2							
	15	14	13	12	11	10	09	08

5-2 Environment-resistive Slave Units

The Environment-resistive Slave Units are designed to be easily connected with M12 connectors that lock by turning them 1/8 of a turn for less wiring.

5-2-1 Mounting in Control Panels

Use screws to mount a Waterproof Terminal in a control panel. These Terminals cannot be mounted on a DIN Track.

Drill the mounting holes in the control panel according to the dimensions shown in the dimensions diagrams and secure the Terminal with M5 screws. The appropriate tightening torque is 1.47 to 1.96 N·m.

Installation Direction

The Terminal can be mounted in any direction. Any one of the following 6 directions is acceptable.

5-2-2 Environment-resistive Terminals with 16 Transistor Inputs (IP67)


ERT1-HD16CH-1

Input Specifications

Item	Specifications
Input points	16 points
Internal I/O common	PNP
ON voltage	15 V DC min. (between each input terminal and 0 V)
OFF voltage	5 V DC max. (between each input terminal and 0 V)
OFF current	1.0 mA max.
Input current	6.0 mA max. at 24 V DC 3.0 mA max. at 17 V DC
ON delay time	1.5 ms max.
OFF delay time	1.5 ms max.
Number of circuits per common	16 inputs/common
Isolation method	Photocoupler
Input indicators	LEDs (yellow)
Power supply short-circuit protection	Operates at 50 mA/point min.
Disconnection detection	Operates at 0.2 mA/point max.

Item	Specifications
Current consumption	Communications power supply (including internal circuits): 110 mA max.
Connection forms	M12 connector: Smart Click (connectors that lock easily with 1/8 of a turn)
Weight	445 g max.
Standard accessories	None

Component Names and Functions




(1) Rotary Switches

These switches are used to set the node address

(2) Ethernet Connector

The network communications cable is connected to this connector.

This is a Smart-click D-coding M12 connector (connector that locks easily with 1/8 of a turn).




Pin	Signal
1	TD+
2	RD+
3	TD-
4	RD-

(3) Power Supply Connector

The power supply is connected to this connector.

This is a Smart-click D-coding M12 connector (connector that locks easily with 1/8 of a turn).



Pin	Signal
1	V+ (24 V: for internal circuits and inputs)
2	NC
3	V- (0 V: for internal circuits and inputs)
4	NC

(4) Communications Indicators: MS and NS

These indicators show the Unit communications status and network communications status.

(5) Input Connectors

The input devices are connected to these connectors.

(6) Input Indicators

These indicators show the ON/OFF status of the inputs and the error status of connected devices.

Indicators









































Communications Indicators

Refer to 3-1-3 *Communications Indicators*.

Input Indicators

These indicators show the ON/OFF status of the inputs and the error status of connected devices.

Indicator	Color	Status	Meaning (main error)
1-A		Lit yellow.	Input 0 is ON.
		Not lit.	Input 0 is OFF.
		Lit red.	Connector 1 is short-circuited.
		Flashing red.	Connector 1 is disconnected.
1-B		Lit yellow.	Input 1 is ON.
		Not lit.	Input 1 is OFF.
		Lit red.	---
		Flashing red.	---
2-A		Lit yellow.	Input 2 is ON.
		Not lit.	Input 2 is OFF.
		Lit red.	Connector 2 is short-circuited.
		Flashing red.	Connector 2 is disconnected.
2-B		Lit yellow.	Input 3 is ON.
		Not lit.	Input 3 is OFF.
		Lit red.	---
		Flashing red.	---

Indicator	Color	Status	Meaning (main error)
3-A		Lit yellow.	Input 4 is ON.
		Not lit.	Input 4 is OFF.
		Lit red.	Connector 3 is short-circuited.
		Flashing red.	Connector 3 is disconnected.
3-B		Lit yellow.	Input 5 is ON.
		Not lit.	Input 5 is OFF.
		Lit red.	---
		Flashing red.	---
4-A		Lit yellow.	Input 6 is ON.
		Not lit.	Input 6 is OFF.
		Lit red.	Connector 4 is short-circuited.
		Flashing red.	Connector 4 is disconnected.
4-B		Lit yellow.	Input 7 is ON.
		Not lit.	Input 7 is OFF.
		Lit red.	---
		Flashing red.	---
5-A		Lit yellow.	Input 8 is ON.
		Not lit.	Input 8 is OFF.
		Lit red.	Connector 5 is short-circuited.
		Flashing red.	Connector 5 is disconnected.
5-B		Lit yellow.	Input 9 is ON.
		Not lit.	Input 9 is OFF.
		Lit red.	---
		Flashing red.	---
6-A		Lit yellow.	Input 10 is ON.
		Not lit.	Input 10 is OFF.
		Lit red.	Connector 6 is short-circuited.
		Flashing red.	Connector 6 is disconnected.
6-B		Lit yellow.	Input 11 is ON.
		Not lit.	Input 11 is OFF.
		Lit red.	---
		Flashing red.	---
7-A		Lit yellow.	Input 12 is ON.
		Not lit.	Input 12 is OFF.
		Lit red.	Connector 7 is short-circuited.
		Flashing red.	Connector 7 is disconnected.
7-B		Lit yellow.	Input 13 is ON.
		Not lit.	Input 13 is OFF.
		Lit red.	---
		Flashing red.	---

Indicator	Color	Status	Meaning (main error)
8-A		Lit yellow.	Input 4 is ON.
		Not lit.	Input 14 is OFF.
		Lit red.	Connector 8 is short-circuited.
		Flashing red.	Connector 8 is disconnected.
8-B		Lit yellow.	Input 15 is ON.
		Not lit.	Input 15 is OFF.
		Lit red.	---
		Flashing red.	---

Setting the Node Address

The rotary switches are used to set the lower digits of the IP address.

Setting method	Two hexadecimal digits
Setting range	01 to FE



Rotary Switch Settings


00 hex: BOOTP or tool setting enabled (factory setting)

01 to FE hex: Setting on rotary switches is lower 8 bits of IP address. (Default setting of upper 24 bits: 192.168.250.)


FF hex: Restores default setting.

(To restore the default setting, set the switches to FF hex, cycle the power supply, and then set the switches to 00 hex.)


Internal Circuits



Wiring



Dimensions



5-2-3 Environment-resistive Terminals with 16 Transistor Outputs (IP67)


ERT1-WD16CH-1

Output Specifications

Item	Specification
Output points	16 points
Internal I/O common	PNP
Output current	0.5 A/point, 4.0 A/common
Residual voltage	1.2 V max. (0.5 A DC, between each output terminal and the V terminal)
Leakage current	0.3 mA max. (24 V DC, between each output terminal and the V terminal)
ON delay	0.5 ms max.
OFF delay	1.5 ms max.
Number of circuits per common	16 outputs/common
Isolation method	Photocoupler

Item	Specification
Output indicators	LEDs (yellow)
Power supply short-circuit protection	Operates when output current is exceeded.
Disconnection detection	Operates at current consumption of 3 mA/point max. (Not detected at 3 mA or less.)
Output handling for communications errors	Select either hold or clear from Network Configurator.
Current consumption	Communications power supply (including internal circuits): 120 mA max.
Connection forms	M12 connector: Smart Click (connectors that lock easily with 1/8 of a turn)
Mounting	35-mm DIN Track mounting
Weight	435 g max.
Standard accessories	None

Component Names and Functions




(1) Rotary Switches

These switches are used to set the node address.

(2) Ethernet Connector

The network communications cable is connected to this connector.

This is a Smart-click D-coding M12 connector (connector that locks easily with 1/8 of a turn).




Pin	Signal
1	TD+
2	RD+
3	TD-
4	RD-

(3) Power Supply Connector

The power supply is connected to this connector.

This is a Smart-click D-coding M12 connector (connector that locks easily with 1/8 of a turn).



Pin	Signal
1	V+ (24 V: for internal circuits)
2	24 V (for outputs)
3	V- (0 V: for internal circuits)
4	0 V (for outputs)

(4) Communications Indicators: MS and NS

These indicators show the Unit communications status and network communications status.

(5) Output Power Indicator

This indicator shows the status of the output power supply.

(6) Output Connectors

The output devices are connected to these connectors.

(7) Output Indicators

These indicators show the ON/OFF status of the outputs and the error status of connected devices.

Indicators









































Communications Indicators













Refer to 3-1-3 *Communications Indicators*.

Output Indicators

These indicators show the ON/OFF status of the outputs and the error status of connected devices.



Indicator	Color	Status	Meaning (main error)
1-A		Lit yellow.	Output 0 is ON.
		Not lit.	Output 0 is OFF.
		Lit red.	Output 0 is short-circuited.
		Flashing red.	Output 0 is disconnected.
1-B		Lit yellow.	Output 1 is ON.
		Not lit.	Output 1 is OFF.
		Lit red.	Output 1 is short-circuited.
		Flashing red.	Output 1 is disconnected.
2-A		Lit yellow.	Output 2 is ON.
		Not lit.	Output 2 is OFF.
		Lit red.	Output 2 is short-circuited.
		Flashing red.	Output 2 is disconnected.

Indicator	Color	Status	Meaning (main error)
2-B		Lit yellow.	Output 3 is ON.
		Not lit.	Output 3 is OFF.
		Lit red.	Output 3 is short-circuited.
		Flashing red.	Output 3 is disconnected.
3-A		Lit yellow.	Output 4 is ON.
		Not lit.	Output 4 is OFF.
		Lit red.	Output 4 is short-circuited.
		Flashing red.	Output 4 is disconnected.
3-B		Lit yellow.	Output 5 is ON.
		Not lit.	Output 5 is OFF.
		Lit red.	Output 5 is short-circuited.
		Flashing red.	Output 5 is disconnected.
4-A		Lit yellow.	Output 6 is ON.
		Not lit.	Output 6 is OFF.
		Lit red.	Output 6 is short-circuited.
		Flashing red.	Output 6 is disconnected.
4-B		Lit yellow.	Output 7 is ON.
		Not lit.	Output 7 is OFF.
		Lit red.	Output 7 is short-circuited.
		Flashing red.	Output 7 is disconnected.
5-A		Lit yellow.	Output 8 is ON.
		Not lit.	Output 8 is OFF.
		Lit red.	Output 8 is short-circuited.
		Flashing red.	Output 8 is disconnected.
5-B		Lit yellow.	Output 9 is ON.
		Not lit.	Output 9 is OFF.
		Lit red.	Output 9 is short-circuited.
		Flashing red.	Output 9 is disconnected.
6-A		Lit yellow.	Output 10 is ON.
		Not lit.	Output 10 is OFF.
		Lit red.	Output 10 is short-circuited.
		Flashing red.	Output 10 is disconnected.
6-B		Lit yellow.	Output 11 is ON.
		Not lit.	Output 11 is OFF.
		Lit red.	Output 11 is short-circuited.
		Flashing red.	Output 11 is disconnected.
7-A		Lit yellow.	Output 12 is ON.
		Not lit.	Output 12 is OFF.
		Lit red.	Output 12 is short-circuited.
		Flashing red.	Output 12 is disconnected.

Indicator	Color	Status	Meaning (main error)
7-B		Lit yellow.	Output 13 is ON.
		Not lit.	Output 13 is OFF.
		Lit red.	Output 13 is short-circuited.
		Flashing red.	Output 13 is disconnected.
8-A		Lit yellow.	Output 14 is ON.
		Not lit.	Output 14 is OFF.
		Lit red.	Output 14 is short-circuited.
		Flashing red.	Output 14 is disconnected.
8-B		Lit yellow.	Output 15 is ON.
		Not lit.	Output 15 is OFF.
		Lit red.	Output 15 is short-circuited.
		Flashing red.	Output 15 is disconnected.

Output Power Indicator


This indicator shows the status of the output power supply.

AUX (external power supply)		Lit green.	Output power is being supplied.
		Not lit.	Output power is not being supplied.

Setting the Node Address

The rotary switches are used to set the lower digits of the IP address.

Setting method	Two hexadecimal digits
Setting range	01 to FE

**Rotary Switch Settings**


00 hex: BOOTP or tool setting enabled (factory setting)

01 to FE hex: Setting on rotary switches is lower 8 bits of IP address. (Default setting of upper 24 bits: 192.168.250.)


FF hex: Restores default setting.

(To restore the default setting, set the switches to FF hex, cycle the power supply, and then set the switches to 00 hex.)


Internal Circuits



Wiring



Dimensions



SECTION 6

Smart Functions

This section describes the Smart Functions supported by the EtherNet/IP Slave Units.

6-1	Functions Common to All Slave Units	74
6-1-1	Automatic Baud Rate Detection	74
6-1-2	Hold/Clear Outputs	74
6-1-3	I/O Power Status Monitor	74
6-1-4	Input Filter (Input Units Only)	75
6-1-5	Power Short-circuit Detection (Input)	76
6-1-6	Load Short-circuit Detection (Output)	76

6-1 Functions Common to All Slave Units

This section describes the functions common to all EtherNet/IP Slave Units and the procedures for using these functions.

6-1-1 Automatic Baud Rate Detection

Description

The EtherNet/IP Slave Units are automatically set to the same baud rate as the hub. It is not necessary to set the baud rate separately for any Slave Unit.

The baud rate is set when communications is established with the hub after the power is turned ON. The baud rate setting is stored in memory until the power is turned ON again or until the Master Unit baud rate setting is changed.

6-1-2 Hold/Clear Outputs


Description

Output Units can be set to hold or clear outputs when an error occurs.

Procedure Using Network Configurator

1,2,3...

1. Turn ON the power to the EtherNet/IP Slave Unit.
2. Double-click the icon of the Slave Unit to set in the Network Edit Device Parameters Window to open the Configuration Window. (Alternatively, right-click the icon and select **Parameters - Edit** from the pop-up menu.)
3. The fault action (holding or clearing an output for a communications error) will be displayed for each output in the *Fault Action Setting* Group. Select *Hold Last State* or *Clear Data* for the terminals and then click the **OK** Button.



Clear	Clears all output data from the Master Unit to 0 when a communications error occurs.
Hold	Holds all output data from the Master Unit at its current status when a communications error occurs.

6-1-3 I/O Power Status Monitor

Description

Outputs can be set to be held or cleared when an error occurs in the Output Unit.

Checking Using the Status Areas

Refer to bits 0 and 1 in 4-1-1 Generic Status Area.

6-1-4 Input Filter (Input Units Only)**Description**


An input value is read more than once during a set time interval. The input value can be set to be enabled only when all the read values are the same. This function operates for all input points in one Slave Unit.

The following settings are possible:

No delay (no filter), or 4, 8, 16, 32, 64, 128, or 256 ms.

OFF-ON Delay


When the input data turns ON, the input data is read 4 times at a set time (1/4 of the time setting). The internal input data turns ON only when all four values are ON. The ON timing is delayed by the value of the input time constant.

**ON-OFF Delay**

When the input data turns OFF, the input data is read 5 times at a set interval (1/5 of the OFF response time setting). The internal input data turns OFF only when all values are OFF. The OFF timing is delayed by the value of the OFF response time.

This function can also be used to implement an OFF delay.

To enable reading pulses shorter than the communications cycle time, set the OFF response time to a value longer than the communications cycle time. (The input may remain ON if the input pulse interval is too short.)

**Settings Using the Network Configurator**

1,2,3...

1. Turn ON the power supply to the EtherNet/IP Slave Unit.
2. Double-click the icon of the Slave Unit to set in the Network Configuration Window to open the Edit Device Parameters Window. (Alternatively, right-click the icon and select **Parameters - Edit** from the pop-up menu.)
3. Select an input in the *Input Point Group Setting* Group and set the Off-On Delay or On-Off delay from the pull-down menu.



6-1-5 Power Short-circuit Detection (Input)

Description

This function monitors the sensor power supply current. If the current is 50 mA or higher per input contact, a power short-circuit is detected.

The Slave Unit I/O indicator can be used to check whether a power short-circuit has been detected. When a power short-circuit is detected, a flag in a status area in the Slave Unit turns ON to notify the Master Unit. The notification details can be read using explicit messages. When the cause of the short-circuit is removed, the Slave Unit is automatically reset, and the power output to the connector that had the short-circuit is turned ON again.

Setting Using the Status Areas

Refer to bit 4 in 4-1-1 *Generic Status Area* and to 4-1-2 *I/O Status Area*.

6-1-6 Load Short-circuit Detection (Output)

Description

This function monitors the load current for the output section and detects an load short-circuit if the current per contact (or common) exceeds a specific value. When a load short-circuit is detected, all Unit outputs are turned OFF to prevent damage to the Unit's output circuits.

The I/O power for the Unit turns OFF if a short-circuit is detected for even just one of the contacts being used.

When a load short-circuit is detected, a flag in a status area in the Slave Unit turns ON to notify the Master Unit. The notification details can be read using explicit messages.

When the cause of the short-circuit is removed, the Slave Unit is automatically reset, and the power output to the connector for which the short-circuit was detected is turned ON again.

Checking Using the Status Areas

Refer to bit 4 in 4-1-1 *Generic Status Area* and to 4-1-2 *I/O Status Area*.















SECTION 7

Troubleshooting and Maintenance

This section describes troubleshooting and maintenance for the EtherNet/IP Slave Units.

7-1	Indicator Meanings and Troubleshooting	78
7-2	Troubleshooting	78
7-2-1	Indicators Are Lit or Flashing Red	78
7-2-2	Troubleshooting by Slave Unit Type	79
7-3	Maintenance and Replacement	80
7-3-1	Cleaning	80
7-3-2	Inspection	80
7-3-3	Unit Replacement Procedure	80

7-1 Indicator Meanings and Troubleshooting

MS and NS indicators		Meaning		Remarks
	Lit green	Remote I/O communications or message communications are in progress.	Remote I/O communications are being executed.	Either remote I/O communications, message communications, or both are being executed. Status is normal.
	Lit green			
	Lit green	Offline	It is not possible to go online.	If only certain Slave Units show this status, check the cable connections.
	Not lit			
	Lit green	Waiting for a connection.	Waiting for a connection with the Master Unit to be established.	---
	Flashing green			
	Lit red	Watchdog timer error	A watchdog timer error has occurred in the Slave Unit.	Replace the Slave Unit.
	Not lit			
	Flashing red	Illegal switch setting	The setting of the IP address switches is illegal.	Correct the switch setting and then restart the Slave Units.
	Not lit			
	Lit green	Configuration error	• The same IP address has been used more than once.	Check that each IP address is used only once and then restart the Slave Units.
	Lit red			
	Lit green	Communications time-out	---	Check the following items then restart the Slave Units: • Is the cable length OK? • Is the cable disconnected or loose? • Is there too much noise?
	Flashing red			

7-2 Troubleshooting

7-2-1 Indicators Are Lit or Flashing Red

Problem	Cause and possible corrections
MS indicator is lit red.	<ul style="list-style-type: none"> • The Slave Unit is malfunctioning. Replace the Slave Unit.
MS indicator is flashing red.	<ul style="list-style-type: none"> • The rotary switch or other setting is illegal. Check the switch settings then restart the Slave Unit. • There is an error in the Slave Unit's EEPROM memory data. To restore the default setting, set the rotary switches to FF hex, cycle the power supply, and then set the rotary switches to 00 hex. Replace the Slave Unit if the MS indicator keeps flashing red even after the data has been returned to the default settings.
The NS indicator lights red without flashing green.	Check the following item and then restart the Slave Unit. <ul style="list-style-type: none"> • Check the node addresses of all nodes and change the settings as required so that each node has a unique node address.

Problem	Cause and possible corrections
NS indicator remains not lit and status does not change.	<p>The Slave Unit is not participating in the network.</p> <ul style="list-style-type: none"> • Check that all Slave Unit connectors are connected correctly. • Check that the Master Unit is operating correctly. If using an OMRON Master Unit, check the Master Unit mode and the Slave Unit node addresses. • If using a Master from another manufacturer, refer to the user's manual for that Master. • Check that the communications cable is wired correctly. • Check that the power supply cable and power supply are wired correctly and that the settings are correct. • Check connector wiring to make sure that the communications cable and power supply cables are not disconnected.
NS indicator remains lit green and status does not change.	<p>Check the following items and take corrective measures based on the Master Unit indicator display.</p> <ul style="list-style-type: none"> • Check that the Master Unit is operating correctly. Refer to the manual for the Master Unit. • Check that the tag data links are set correctly. • Reset the tag data links.

7-2-2 Troubleshooting by Slave Unit Type

Model	Problem	Cause
All Slave Units	The MS and NS indicators do not light green.	Refer to 7-2-1 <i>Indicators Are Lit or Flashing Red</i> .
Slave Units with outputs	Cannot hold outputs when communications errors occur.	The Unit is set to clear outputs for communications errors. Change the setting to hold outputs for communications errors.
	Cannot clear outputs when communications errors occur.	Change the setting to clear outputs for communications errors.
Slave Units with inputs	There is a delay with the ON and OFF timing for input values.	An input filter may be set. Set the input filter value to No Display. Alternatively, change the input filter to an appropriate value.
Slave Units with Unconnected Line Detection Function	The Unconnected Line Detection Status Flag turned ON for an unused input.	Unconnected line detection is enabled for an unused input. Disable unconnected line detection for that input.
	The Unconnected Line Detection Status Flag turned ON even though the sensor power supply was connected.	Current consumption is low. (Output current: 3 mA max.) Disable unconnected line detection for that input (so that the unconnected line detection function does not operate.)
Slaves with Disconnected Line Detection	The Disconnected Line Detection Status Flag turned ON for an unused output.	Disconnected line detection is enabled for an unused output. Disable disconnected line detection for that output.
	The Disconnected Line Detection Status Flag turned ON even though the external load was connected.	Current consumption is low. (Output current: 3 mA max.) Disable disconnected line detection for that output (so that the disconnected line detection function does not operate.)


7-3 Maintenance and Replacement

This section describes the routine cleaning and inspection recommended as regular maintenance, as well as the Unit replacement procedure required if an EtherNet/IP Unit needs to be replaced.

7-3-1 Cleaning

Clean the EtherNet/IP Unit regularly as described below in order to keep the network in its optimal operating condition.

- Wipe the Unit daily with a dry, soft cloth.
- When a spot can't be removed with a dry cloth, dampen the cloth with a neutral cleanser (2% solution), wring out the cloth, and wipe the Unit.
- A smudge may remain on the Unit from gum, vinyl, or tape that was left on for a long time. Remove the smudge when cleaning.

 **Caution** Never use volatile solvents such as paint thinner, benzene, or chemical wipes. These substances could damage the surface of the Unit.

7-3-2 Inspection

Be sure to inspect the system periodically to keep it in its optimal operating condition. In general, inspect the system once every 6 to 12 months, but inspect more frequently if the system is used with high temperature or humidity or under dirty/dusty conditions.

Inspection Equipment

Normally Required Equipment

Prepare the following equipment before inspecting the system.

Have a standard and Phillips-head screwdriver, multimeter, alcohol, and a clean cloth.

Occasionally Required Equipment

Depending on the system conditions, a synchroscope, oscilloscope, thermometer, or hygrometer (to measure humidity) might be needed.

Inspection Procedure

Check the items in the following table and correct any items that are below standard.

	Item	Standard	Inspection
Environmental conditions	Ambient and cabinet temperature	Refer to specifications for each Slave Unit.	Thermometer
	Ambient and cabinet humidity	Refer to specifications for each Slave Unit.	Hygrometer
	Dust/dirt accumulation	None	Visual
Installation	Are the Units secure?	No looseness	Phillips screwdriver
	Are the Ethernet cable connectors fully inserted?	No looseness	Phillips screwdriver
	Are the external wiring screws tight?	No looseness	Phillips screwdriver
	Are the cables in good condition?	No external abnormalities	Visual

7-3-3 Unit Replacement Procedure

The network consists of the EtherNet/IP Unit and EtherNet/IP Slave Units. The entire network is affected when a Unit is faulty. A faulty Unit must be repaired or replaced quickly.

Precautions

Observe the following precautions when replacing a faulty Unit.

- After replacement, verify that there are no errors with the new Unit.
- When a Unit is being returned for repair, attach a sheet of paper detailing the problem and return the Unit to your OMRON dealer.
- If there is a faulty contact, try wiping the contact with a clean, lint-free cloth dampened with alcohol.

**Settings Required
after Unit
Replacement**

After a Unit has been replaced, make sure that the switches and other settings on the new Unit are the same as those on the previous Unit.

Index

A

applications
 precautions, xviii
automatic baud rate detection, 74

B

baud rate, 3
 CS-series, 40
boots
 recommended models, 37

C

CIP, 2
classification, 3
cleaning, 80
communications
 message communications, 77
connectors (modular plug)
 recommended models, 37

D

distance
 transmission distance, 40

E

EC Directives, xix
electromagnetic fields, xvii
EMC Directives, xix
Environment-resistive Terminals
 power supply, 3
explicit message communications, 77

F

FINS message communications, 77

H

hold/clear outputs, 74

I

I/O Power Status Monitor, 3
indicator meanings and troubleshooting, 78
input filter, 3, 75

L

Low Voltage Directive, xix

M

maintenance, 80
message communications functions, 77
MS indicators, 78

N

network devices
 recommended devices, 37
noise, xvii
NS indicators, 78

O

operating environment
 precautions, xvii

P

power supply, xvii
 I/O power supply, 3
precautions, xv
 applications, xviii
 general, xvi
 operating environment, xvii
 safety, xvi

R

radioactivity, xvii
recommended network devices, 37
remote I/O communications, 3
replacing a Unit, 80

S

safety precautions, xvi

sensor power short-circuit detection, 76

Slave Units

 specifications, 40

static electricity, xvii

switches

 DIP switches, 3

 rotary switches

 setting node addresses, 3

switching hub

 recommended models, 37

T

troubleshooting

 specific slave troubleshooting, 79

twisted-pair cable

 recommended models, 37


U

Unit replacement, 80

Revision History

A manual revision code appears as a suffix to the catalog number on the front cover of the manual.

Cat. No. W481-E1-02



The following table outlines the changes made to the manual during each revision. Page numbers refer to the previous version.

Revision code	Date	Revised content
01	April 2009	Original production
02	November 2010	Corrected mistakes.

Revision History

OMRON Corporation **Industrial Automation Company**
Tokyo, JAPAN

Contact: www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V.

Wegalaan 67-69-2132 JD Hoofddorp
The Netherlands
Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ELECTRONICS LLC

One Commerce Drive Schaumburg,
IL 60173-5302 U.S.A.
Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

OMRON ASIA PACIFIC PTE. LTD.

No. 438A Alexandra Road # 05-05/08 (Lobby 2),
Alexandra Technopark,
Singapore 119967
Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON (CHINA) CO., LTD.

Room 2211, Bank of China Tower,
200 Yin Cheng Zhong Road,
PuDong New Area, Shanghai, 200120, China
Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

Authorized Distributor:

© OMRON Corporation 2009 All Rights Reserved.
In the interest of product improvement,
specifications are subject to change without notice.

Cat. No. W481-E1-02

Printed in Japan
1110