

SYSMAC CP Series

CP1H-X40D□-□

CP1H-XA40D□-□

CP1H-Y20DT-D

CP1H CPU Unit

OPERATION MANUAL

OMRON

NOTE

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

Trademarks

- Microsoft, Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- ODVA, CIP, CompoNet, DeviceNet, and EtherNet/IP are trademarks of ODVA.

Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

Copyrights

Microsoft product screen shots reprinted with permission from Microsoft Corporation.

CP1H-X40D□-□

CP1H-XA40D□-□

CP1H-Y20DT-D

CP1H CPU Unit


Operation Manual


Revised July 2017


Notice:

OMRON products are manufactured for use according to proper procedures by a qualified operator and only for the purposes described in this manual.

The following conventions are used to indicate and classify precautions in this manual. Always heed the information provided with them. Failure to heed precautions can result in injury to people or damage to property.

 **DANGER** Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. Additionally, there may be severe property damage.

 **WARNING** Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury. Additionally, there may be severe property damage.

 **Caution** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, or property damage.

OMRON Product References

All OMRON products are capitalized in this manual. The word “Unit” is also capitalized when it refers to an OMRON product, regardless of whether or not it appears in the proper name of the product.

The abbreviation “Ch,” which appears in some displays and on some OMRON products, often means “word” and is abbreviated “Wd” in documentation in this sense.

The abbreviation “PLC” means Programmable Controller. “PC” is used, however, in some CX-Programmer displays to mean Programmable Controller.

Visual Aids

The following headings appear in the left column of the manual to help you locate different types of information.

Note Indicates information of particular interest for efficient and convenient operation of the product.

1,2,3... 1. Indicates lists of one sort or another, such as procedures, checklists, etc.


Unit Versions of CP-series CPU Units

Unit Versions

A “unit version” has been introduced to manage CPU Units in the CP Series according to differences in functionality accompanying Unit upgrades.

Notation of Unit Versions on Products

The unit version is given to the right of the lot number on the nameplate of the products for which unit versions are being managed, as shown below.



Confirming Unit Versions with Support Software

CX-Programmer version 6.1 or higher can be used to confirm the unit version using one of the following two methods. (See note.)


- Using the **PLC Information**
- Using the **Unit Manufacturing Information**

Note CX-Programmer version 6.1 or lower cannot be used to confirm unit versions for CP-series CPU Units.

PLC Information

- If you know the device type and CPU type, select them in the *Change PLC* Dialog Box, go online, and select **PLC - Edit - Information** from the menus.
- If you don't know the device type and CPU type but are connected directly to the CPU Unit on a serial line, select **PLC - Auto Online** to go online, and then select **PLC - Edit - Information** from the menus.


In either case, the following *PLC Information* Dialog Box will be displayed.




Use the above display to confirm the unit version of the CPU Unit.

Unit Manufacturing Information

In the IO Table Window, right-click and select ***Unit Manufacturing information - CPU Unit.***




The following *Unit Manufacturing information* Dialog Box will be displayed.



Use the above display to confirm the unit version of the CPU Unit connected online.

Using the Unit Version Labels

The following unit version labels are provided with the CPU Unit.



These labels can be attached to the front of previous CPU Units to differentiate between CPU Units of different unit versions.

Functions Supported by Unit Version for CP-series CPU Units

Functions Supported by Unit Version 1.0 and 1.1

Functionality is the same as that for CS/CJ-series CPU Units with unit version 3.0. The functionality added for CS/CJ-series CPU Unit unit version 4.0 is not supported.

CP1H CPU Units

- CX-Programmer version 6.11 or higher is required to use CP1H-X□□□□-□/XA□□□□-□ with unit version 1.1 or 1.0.
- CX-Programmer version 6.20 or higher is required to use CP1H-Y□□□□-□ with unit version 1.1.

CPU Unit		CP1H CPU Unit		
Model		CP1H-□□□□-□ CP1H-XA□□□□-□ (See note 1.)		CP1H-Y□□□□-□ (See note 2.)
Unit version		Ver. 1.1 or later	Ver. 1.0	Ver. 1.1
Function				
Pulse outputs	Allocated built-in I/O terminals	4 axes at 100 kHz	2 axes at 100 kHz 2 axes at 30 kHz	2 axes at 100 kHz
	Special pulse output terminals	None		2 axes at 1 MHz

Note

1. The unit version for the CP1H-X□□□□-□/XA□□□□-□ begins at 1.0.
2. The unit version for the CP1H-Y□□□□-□ begins at 1.1.
3. CX-Programmer version 7.11 or higher is required to use CP1L CPU Units with unit version 1.0.
4. CX-Programmer version 7.3 or higher is required to use CP1L CPU Units with 10 I/O points.

TABLE OF CONTENTS

PRECAUTIONS xxiii

1	Intended Audience	xxiv
2	General Precautions	xxiv
3	Safety Precautions	xxiv
4	Operating Environment Precautions	xxvi
5	Application Precautions	xxvii
6	Conformance to EC Directives	xxx

SECTION 1

Features and System Configuration 1

1-1	Features and Main Functions	2
1-2	System Configuration	15
1-3	Connecting Programming Devices	26
1-4	Function Charts	37
1-5	Function Blocks	40

SECTION 2

Nomenclature and Specifications 43

2-1	Part Names and Functions	44
2-2	Specifications	50
2-3	CP1H CPU Unit Operation	76
2-4	CPU Unit Operation	84
2-5	CPU Unit Operating Modes	89
2-6	Power OFF Operation	91
2-7	Computing the Cycle Time	93

SECTION 3

Installation and Wiring 105

3-1	Fail-safe Circuits	106
3-2	Installation Precautions	107
3-3	Mounting	109
3-4	Wiring CP1H CPU Units	118
3-5	Wiring Methods	126
3-6	CP-series Expansion I/O Unit Wiring	135

SECTION 4

I/O Memory Allocation 143

4-1	Overview of I/O Memory Area	144
4-2	I/O Area and I/O Allocations	152
4-3	Built-in Analog I/O Area (XA CPU Units Only)	159
4-4	Data Link Area	160

TABLE OF CONTENTS

4-5	CPU Bus Unit Area	161
4-6	Special I/O Unit Area	162
4-7	Serial PLC Link Area	163
4-8	DeviceNet Area	163
4-9	Internal I/O Area	165
4-10	Holding Area (H).	165
4-11	Auxiliary Area (A).	166
4-12	TR (Temporary Relay) Area	166
4-13	Timers and Counters	167
4-14	Data Memory Area (D)	170
4-15	Index Registers	172
4-16	Data Registers	179
4-17	Task Flags	181
4-18	Condition Flags	181
4-19	Clock Pulses	183
SECTION 5		
Basic CP1H Functions		185
5-1	Interrupt Functions.	186
5-2	High-speed Counters	210
5-3	Pulse Outputs.	230
5-4	Quick-response Inputs	322
5-5	Analog I/O (XA CPU Units)	325
SECTION 6		
Advanced Functions		339
6-1	Serial Communications	340
6-2	Analog Adjuster and External Analog Setting Input.	362
6-3	7-Segment LED Display	364
6-4	Battery-free Operation.	366
6-5	Memory Cassette Functions	368
6-6	Program Protection	376
6-7	Failure Diagnosis Functions	384
6-8	Clock	388
SECTION 7		
Using CP-series Expansion Units and Expansion I/O Units		391
7-1	Connecting CP-series Expansion Units and Expansion I/O Units	392
7-2	Analog Input Units	393
7-3	Analog Output Units	406
7-4	Analog I/O Units	416
7-5	Temperature Sensor Units	446

TABLE OF CONTENTS

7-6	CompoBus/S I/O Link Units	480
SECTION 8		
LCD Option Board		485
8-1	Features	486
8-2	Specifications.	487
8-3	Part Names.	488
8-4	Installation and Removing.	489
8-5	Basic Operation	490
8-6	LCD Option Board Function	495
8-7	Trouble Shooting	544
SECTION 9		
Ethernet Option Board.		547
9-1	Ethernet Option Board Function Guide.	548
9-2	Features	551
9-3	System Configuration	552
9-4	Specifications.	553
9-5	FINS Communications	554
9-6	Part Names.	556
9-7	Comparison with Previous Models	557
9-8	Installation and Initial Setup	559
9-9	Memory Allocations	567
9-10	Web Browser Setup and Display	573
9-11	Trouble Shooting	584
9-12	Sample Application	588
9-13	Buffer Configuration (CP1W-CIF41)	592
SECTION 10		
Program Transfer, Trial Operation, and Debugging		593
10-1	Program Transfer.	594
10-2	Trial Operation and Debugging.	594
SECTION 11		
Troubleshooting		601
11-1	Error Classification and Confirmation.	602
11-2	Troubleshooting.	607
11-3	Error Log	619
11-4	Troubleshooting Unit Errors	620

TABLE OF CONTENTS

SECTION 12

Inspection and Maintenance 623

12-1 Inspections 624

12-2 Replacing User-serviceable Parts 626

Appendices 629

A Standard Models 629

B Dimensions Diagrams 637

C Auxiliary Area Allocations by Function 645

D Auxiliary Area Allocations by Address 665

E Memory Map 713

F Connections to Serial Communications Option Boards 715

G PLC Setup 741

H Specifications for External Power Supply Expansion 767

Index 769

Revision History 775

About this Manual:


This manual describes installation and operation of the CP-series Programmable Controllers (PLCs) and includes the sections described below. The CP Series provides advanced package-type PLCs based on OMRON's advanced control technologies and vast experience in automated control.

Please read this manual carefully and be sure you understand the information provided before attempting to install or operate a CP-series PLC. Be sure to read the precautions provided in the following section.

Definition of the CP Series

The CP Series is centered around the CP1H CPU Units and is designed with the same basic architecture as the CS and CJ Series. The Special I/O Units and CPU Bus Units of the CJ Series can thus be used. CJ-series Basic I/O Units, however, cannot be used. Always use CP-series Expansion Units and CP-series Expansion I/O Units when expanding I/O capacity.

I/O words are allocated in the same way as the CPM1A/CPM2A PLCs, i.e., using fixed areas for inputs and outputs.



Precautions provides general precautions for using the Programmable Controller and related devices.

Section 1 introduces the features of the CP1H and describes its configuration. It also describes the Units that are available and connection methods for Programming Devices and other peripheral devices.

Section 2 describes the names and functions of CP1H parts and provides CP1H specifications.

Section 3 describes how to install and wire the CP1H.

Section 4 describes the structure and functions of the I/O Memory Areas and Parameter Areas.

Section 5 describes the CP1H's interrupt and high-speed counter functions.

Section 6 describes all of the advanced functions of the CP1H that can be used to achieve specific application needs.

Section 7 describes how to use CP-series Expansion Units and Expansion I/O Units.

Section 8 gives an outline of the LCD Option Board, explains how to install and remove the LCD Option Board, and describes the functions including how to monitor and make settings for the PLC. It also lists the errors during operation and provides probable causes and countermeasures for troubleshooting.

Section 9 gives an outline of the Ethernet Option Board, explains how to install and remove the Ethernet Option Board, and how to monitor and make settings required for operation. It also lists the errors during operation and provides countermeasures for troubleshooting.

Section 10 describes the processes used to transfer the program to the CPU Unit and the functions that can be used to test and debug the program.

Section 11 provides information on hardware and software errors that occur during CP1H operation.

Section 12 provides inspection and maintenance information.

Appendices provide product lists, dimensions, tables of Auxiliary Area allocations, and a memory map.

Related Manuals

The following manuals are used for the CP-series CPU Units. Refer to these manuals as required.

Cat. No.	Model numbers	Manual name	Description
W450	CP1H-X40D□-□ CP1H-XA40D□-□ CP1H-Y20DT-D	SYSMAC CP Series CP1H CPU Unit Operation Manual	Provides the following information on the CP Series: <ul style="list-style-type: none"> • Overview, design, installation, maintenance, and other basic specifications • Features • System configuration • Mounting and wiring • I/O memory allocation • Troubleshooting Use this manual together with the <i>CP1H Programmable Controllers Programming Manual (W451)</i> .
W451	CP1H-X40D□-□ CP1H-XA40D□-□ CP1H-Y20DT-D	SYSMAC CP Series CP1H CPU Unit Pro- gramming Manual	Provides the following information on the CP Series: <ul style="list-style-type: none"> • Programming instructions • Programming methods • Tasks • File memory • Functions Use this manual together with the <i>CP1H Programmable Controllers Operation Manual (W450)</i> .
W342	CS1G/H-CPU□□H CS1G/H-CPU□□-V1 CS1D-CPU□□H CS1D-CPU□□S CS1W-SCU21 CS1W-SCB21-V1/41-V1 CJ1G/H-CPU□□H CJ1G-CPU□□P CP1H-CPU□□ CJ1G-CPU□□ CJ1W-SCU21-V1/41-V1	SYSMAC CS/CJ- series Communica- tions Commands Ref- erence Manual	Describes commands addressed to CS-series and CJ-series CPU Units, including C-mode commands and FINS commands. Note This manual describes on commands address to CPU Units regardless of the communications path. (CPU Unit serial ports, Serial Communications Unit/Board ports, and Communications Unit ports can be used.) Refer to the relevant operation manuals for information on commands addresses to Special I/O Units and CPU Bus Units.
W446	WS02-CXPC1-E-V70	SYSMAC CX-Pro- grammer Ver. 7.0 Operation Manual	Provides information on installing and operating the CX-Programmer for all functions except for function blocks.
W447	WS02-CXPC1-E-V70	SYSMAC CX-Pro- grammer Ver. 7.0 Operation Manual Function Blocks	Provides specifications and operating procedures for function blocks. Function blocks can be used with CX-Programmer Ver. 6.1 or higher and either a CS1-H/CJ1-H CPU Unit with a unit version of 3.0 or a CP1H CPU Unit. Refer to W446 for operating procedures for functions other than function blocks.
W444	CXONE-AL□□C-E	CX-One FA Inte- grated Tool Package Setup Manual	Provides an overview of the CX-One FA Integrated Tool and installation procedures.
W445	CXONE-AL□□C-E	CX-Integrator Opera- tion Manual	Describes CX-Integrator operating procedures and provides information on network configuration (data links, routing tables, Communications Units setup, etc.).
W344	WS02-PSTC1-E	CX-Protocol Opera- tion Manual	Provides operating procedures for creating protocol macros (i.e., communications sequences) with the CX-Protocol and other information on protocol macros. The CX-Protocol is required to create protocol macros for user-specific serial communications or to customize the standard system protocols.

Terms and Conditions Agreement

Warranty and Limitations of Liability

WARRANTIES

- **Exclusive Warranty**

Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

- **Limitations**

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right.

- **Buyer Remedy**

Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See <http://www.omron.com/global/> or contact your Omron representative for published information.

LIMITATION ON LIABILITY; ETC

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Application Considerations

SUITABILITY OF USE

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

PROGRAMMABLE PRODUCTS

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

Disclaimers

PERFORMANCE DATA

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

CHANGE IN SPECIFICATIONS

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

ERRORS AND OMISSIONS

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

PRECAUTIONS

This section provides general precautions for using the CP-series Programmable Controllers (PLCs) and related devices.

The information contained in this section is important for the safe and reliable application of Programmable Controllers. You must read this section and understand the information contained before attempting to set up or operate a PLC system.

1	Intended Audience	xxiv
2	General Precautions	xxiv
3	Safety Precautions.....	xxiv
4	Operating Environment Precautions	xxvi
5	Application Precautions	xxvii
6	Conformance to EC Directives	xxx
6-1	Applicable Directives	xxx
6-2	Concepts	xxx
6-3	Conformance to EC Directives.....	xxxi
6-4	Relay Output Noise Reduction Methods	xxxi
6-5	Conditions for Meeting EMC Directives when Using CP-series Relay Expansion I/O Units.....	xxxiii

1 Intended Audience

This manual is intended for the following personnel, who must also have knowledge of electrical systems (an electrical engineer or the equivalent).

- Personnel in charge of installing FA systems.
- Personnel in charge of designing FA systems.
- Personnel in charge of managing FA systems and facilities.


2 General Precautions

The user must operate the product according to the performance specifications described in the operation manuals.


Before using the product under conditions which are not described in the manual or applying the product to nuclear control systems, railroad systems, aviation systems, vehicles, combustion systems, medical equipment, amusement machines, safety equipment, and other systems, machines, and equipment that may have a serious influence on lives and property if used improperly, consult your OMRON representative.


Make sure that the ratings and performance characteristics of the product are sufficient for the systems, machines, and equipment, and be sure to provide the systems, machines, and equipment with double safety mechanisms.


This manual provides information for programming and operating the Unit. Be sure to read this manual before attempting to use the Unit and keep this manual close at hand for reference during operation.


 **WARNING** It is extremely important that a PLC and all PLC Units be used for the specified purpose and under the specified conditions, especially in applications that can directly or indirectly affect human life. You must consult with your OMRON representative before applying a PLC System to the above-mentioned applications.

3 Safety Precautions

 **WARNING** Do not attempt to take any Unit apart while the power is being supplied. Doing so may result in electric shock.


 **WARNING** Do not touch any of the terminals or terminal blocks while the power is being supplied. Doing so may result in electric shock.


 **WARNING** Do not attempt to disassemble, repair, or modify any Units. Any attempt to do so may result in malfunction, fire, or electric shock.


 **WARNING** Provide safety measures in external circuits (i.e., not in the Programmable Controller), including the following items, to ensure safety in the system if an abnormality occurs due to malfunction of the PLC or another external factor affecting the PLC operation. Not doing so may result in serious accidents.


- Emergency stop circuits, interlock circuits, limit circuits, and similar safety measures must be provided in external control circuits.


- The PLC will turn OFF all outputs when its self-diagnosis function detects any error or when a severe failure alarm (FALS) instruction is executed. Unexpected operation, however, may still occur for errors in the I/O control section, errors in I/O memory, and errors that cannot be detected by the self-diagnosis function.
As a countermeasure for all these errors, external safety measures must be provided to ensure safety in the system.
- The PLC or outputs may remain ON or OFF due to deposits on or burning of the output relays, or destruction of the output transistors. As a countermeasure for such problems, external safety measures must be provided to ensure safety in the system.
- When the 24-V DC output (service power supply to the PLC) is overloaded or short-circuited, the voltage may drop and result in the outputs being turned OFF. As a countermeasure for such problems, external safety measures must be provided to ensure safety in the system.


 **WARNING** Fail-safe measures must be taken by the customer to ensure safety in the event of incorrect, missing, or abnormal signals caused by broken signal lines, momentary power interruptions, or other causes. Not doing so may result in serious accidents.


 **WARNING** Do not apply the voltage/current outside the specified range to this unit. It may cause a malfunction or fire.

 **Caution** Execute online edit only after confirming that no adverse effects will be caused by extending the cycle time. Otherwise, the input signals may not be readable.


 **Caution** Confirm safety at the destination node before transferring a program to another node or editing the I/O area. Doing either of these without confirming safety may result in injury.

 **Caution** Tighten the screws on the terminal block of the AC power supply to the torque specified in this manual. The loose screws may result in burning or malfunction.

 **Caution** Do not touch anywhere near the power supply parts or I/O terminals while the power is ON, and immediately after turning OFF the power. The hot surface may cause burn injury.

 **Caution** Pay careful attention to the polarities (+/-) when wiring the DC power supply. A wrong connection may cause malfunction of the system.

⚠ Caution When connecting the PLC to a computer or other peripheral device, either ground the 0 V side of the external power supply or do not ground the external power supply at all. Otherwise the external power supply may be shorted depending on the connection methods of the peripheral device. DO NOT ground the 24 V side of the external power supply, as shown in the following diagram.




⚠ Caution After programming (or reprogramming) using the IOWR instruction, confirm that correct operation is possible with the new ladder program and data before starting actual operation. Any irregularities may cause the product to stop operating, resulting in unexpected operation in machinery or equipment.

⚠ Caution The CP1H CPU Units automatically back up the user program and parameter data to flash memory when these are written to the CPU Unit. I/O memory (including the DM Area, counter present values and Completion Flags, and HR Area), however, is not written to flash memory. The DM Area, counter present values and Completion Flags, and HR Area can be held during power interruptions with a battery. If there is a battery error, the contents of these areas may not be accurate after a power interruption. If the contents of the DM Area, counter present values and Completion Flags, and HR Area are used to control external outputs, prevent inappropriate outputs from being made whenever the Battery Error Flag (A402.04) is ON.


4 Operating Environment Precautions

⚠ Caution Do not operate the control system in the following locations:

- Locations subject to direct sunlight.
- Locations subject to temperatures or humidity outside the range specified in the specifications.
- Locations subject to condensation as the result of severe changes in temperature.
- Locations subject to corrosive or flammable gases.
- Locations subject to dust (especially iron dust) or salts.
- Locations subject to exposure to water, oil, or chemicals.
- Locations subject to shock or vibration.
- Locations subject to direct rain fall.
- Locations subject to direct strong UV.


 **Caution** Take appropriate and sufficient countermeasures when installing systems in the following locations:

- Locations subject to static electricity or other forms of noise.
- Locations subject to strong electromagnetic fields.
- Locations subject to possible exposure to radioactivity.
- Locations close to power supplies.


 **Caution** The operating environment of the PLC System can have a large effect on the longevity and reliability of the system. Improper operating environments can lead to malfunction, failure, and other unforeseeable problems with the PLC System. Make sure that the operating environment is within the specified conditions at installation and remains within the specified conditions during the life of the system.

5 Application Precautions

Observe the following precautions when using the PLC System.

 **WARNING** Always heed these precautions. Failure to abide by the following precautions could lead to serious or possibly fatal injury.

- Always connect to 100 Ω or less when installing the Units. Not connecting to a ground of 100 Ω or less may result in electric shock.
- Always turn OFF the power supply to the PLC before attempting any of the following. Not turning OFF the power supply may result in malfunction or electric shock.
 - Mounting or dismounting Expansion Units or any other Units
 - Connecting or removing the Memory Cassette or Option Board
 - Setting DIP switches or rotary switches
 - Connecting or wiring the cables
 - Connecting or disconnecting the connectors

 **Caution** Failure to abide by the following precautions could lead to faulty operation of the PLC or the system, or could damage the PLC or PLC Units. Always heed these precautions.

- When unpacking the Unit, check carefully for any external scratches or other damages. Also, shake the Unit gently and check for any abnormal sound.
- Install external breakers and take other safety measures against short-circuiting in external wiring. Insufficient safety measures against short-circuiting may result in burning.
- Mount the Unit only after checking the connectors and terminal blocks completely.
- Be sure that all the terminal screws and cable connector screws are tightened to the torque specified in the relevant manuals. Incorrect tightening torque may result in malfunction.
- Wire all connections correctly according to instructions in this manual.
- Keep the wire cuttings out of the Unit when wiring.

- Always use the power supply voltage specified in the operation manuals. An incorrect voltage may result in malfunction or burning.
- Take appropriate measures to ensure that the specified power with the rated voltage and frequency is supplied. Be particularly careful in places where the power supply is unstable. An incorrect power supply may result in malfunction.
- Leave the label attached to the Unit when wiring. Removing the label may result in malfunction.
- Remove the label after the completion of wiring to ensure proper heat dissipation. Leaving the label attached may result in malfunction.
- Use crimp terminals for wiring. Do not connect bare stranded wires directly to terminals. Connection of bare stranded wires may result in burning.
- Do not apply voltages to the input terminals in excess of the rated input voltage. Excess voltages may result in burning.
- Do not apply voltages or connect loads to the output terminals in excess of the maximum switching capacity. Excess voltage or loads may result in burning.
- Be sure that the terminal blocks, connectors, Option Boards, and other items with locking devices are properly locked into place. Improper locking may result in malfunction.
- Disconnect the functional ground terminal when performing withstand voltage tests. Not disconnecting the functional ground terminal may result in burning.
- Wire correctly and double-check all the wiring or the setting switches before turning ON the power supply. Incorrect wiring may result in burning.
- Check that the DIP switches and data memory (DM) are properly set before starting operation.
- Check the user program for proper execution before actually running it on the Unit. Not checking the program may result in an unexpected operation.
- Resume operation only after transferring to the new CPU Unit and/or Special I/O Units the contents of the DM, HR, and CNT Areas required for resuming operation. Not doing so may result in an unexpected operation.
- Confirm that no adverse effect will occur in the system before attempting any of the following. Not doing so may result in an unexpected operation.
 - Changing the operating mode of the PLC (including the setting of the startup operating mode).
 - Force-setting/force-resetting any bit in memory.
 - Changing the present value of any word or any set value in memory.
- Do not pull on the cables or bend the cables beyond their natural limit. Doing either of these may break the cables.
- Do not place objects on top of the cables. Doing so may break the cables.
- When replacing parts, be sure to confirm that the rating of a new part is correct. Not doing so may result in malfunction or burning.
- Before touching the Unit, be sure to first touch a grounded metallic object in order to discharge any static buildup. Not doing so may result in malfunction or damage.
- Install the Unit properly as specified in the operation manual. Improper installation of the Unit may result in malfunction.

- Do not touch the Expansion I/O Unit Connecting Cable while the power is being supplied in order to prevent malfunction due to static electricity.
- Do not turn OFF the power supply to the Unit while data is being transferred.
- When transporting or storing the product, cover the PCBs and the Units or put there in the antistatic bag with electrically conductive materials to prevent LSIs and ICs from being damaged by static electricity, and also keep the product within the specified storage temperature range.
- Do not touch the mounted parts or the rear surface of PCBs because PCBs have sharp edges such as electrical leads.
- Double-check the pin numbers when assembling and wiring the connectors.
- Wire correctly according to specified procedures.
- Do not connect pin 6 (+5V) on the RS-232C Option Board on the CPU Unit to any external device other than the NT-AL001 or CJ1W-CIF11 Conversion Adapter. The external device and the CPU Unit may be damaged.
- Use the dedicated connecting cables specified in this manual to connect the Units. Using commercially available RS-232C computer cables may cause failures in external devices or the CPU Unit.
- Check that data link tables and parameters are properly set before starting operation. Not doing so may result in unexpected operation. Even if the tables and parameters are properly set, confirm that no adverse effects will occur in the system before running or stopping data links.
- Transfer a routing table to the CPU Unit only after confirming that no adverse effects will be caused by restarting CPU Bus Units, which is automatically done to make the new tables effective.
- The user program and parameter area data in the CPU Unit is backed up in the built-in flash memory. The BKUP indicator will light on the front of the CPU Unit when the backup operation is in progress. Do not turn OFF the power supply to the CPU Unit when the BKUP indicator is lit. The data will not be backed up if power is turned OFF.
- Do not turn OFF the power supply to the PLC while the Memory Cassette is being accessed. Doing so may corrupt the data in the Memory Cassette. The 7-segment LED will light to indicate writing progress while the Memory Cassette is being accessed. Wait for the LED display to go out before turning OFF the power supply to the PLC.
- Before replacing the battery, supply power to the CPU Unit for at least 5 minutes and then complete battery replacement within 5 minutes of turn OFF the power supply. Memory data may be corrupted if this precaution is not observed.
- Always use the following size wire when connecting I/O Units, Special I/O Units, and CPU Bus Units: AWG22 to AWG18 (0.32 to 0.82 mm²).
- UL standards required that batteries be replaced only by experienced technicians. Do not allow unqualified persons to replace batteries. Also, always follow the replacement procedure provided in the manual.
- Never short-circuit the positive and negative terminals of a battery or charge, disassemble, heat, or incinerate the battery. Do not subject the battery to strong shocks or deform the battery by applying pressure. Doing any of these may result in leakage, rupture, heat generation, or ignition of the battery. Dispose of any battery that has been dropped on the floor or otherwise subjected to excessive shock. Batteries that have been subjected to shock may leak if they are used.

- Always construct external circuits so that the power to the PLC is turned ON before the power to the control system is turned ON. If the PLC power supply is turned ON after the control power supply, temporary errors may result in control system signals because the output terminals on DC Output Units and other Units will momentarily turn ON when power is turned ON to the PLC.
- Fail-safe measures must be taken by the customer to ensure safety in the event that outputs from Output Units remain ON as a result of internal circuit failures, which can occur in relays, transistors, and other elements.
- If the I/O Hold Bit is turned ON, the outputs from the PLC will not be turned OFF and will maintain their previous status when the PLC is switched from RUN or MONITOR mode to PROGRAM mode. Make sure that the external loads will not produce dangerous conditions when this occurs. (When operation stops for a fatal error, including those produced with the FALS(007) instruction, all outputs from Output Unit will be turned OFF and only the internal output status will be maintained.)
- Dispose of the product and batteries according to local ordinances as they apply.
Have qualified specialists properly dispose of used batteries as industrial waste.



6 Conformance to EC Directives

6-1 Applicable Directives

- EMC Directives
- Low Voltage Directive

6-2 Concepts

EMC Directives

OMRON devices that comply with EC Directives also conform to the related EMC standards so that they can be more easily built into other devices or the overall machine. The actual products have been checked for conformity to EMC standards (see the following note). Whether the products conform to the standards in the system used by the customer, however, must be checked by the customer.

EMC-related performance of the OMRON devices that comply with EC Directives will vary depending on the configuration, wiring, and other conditions of the equipment or control panel on which the OMRON devices are installed. The customer must, therefore, perform the final check to confirm that devices and the overall machine conform to EMC standards.

Note The applicable EMC (Electromagnetic Compatibility) standard is EN61131-2.

Low Voltage Directive

Always ensure that devices operating at voltages of 50 to 1,000 V AC and 75 to 1,500 V DC meet the required safety standards for the PLC (EN61131-2).

6-3 Conformance to EC Directives

The CP1H PLCs comply with EC Directives. To ensure that the machine or device in which the CP1H PLC is used complies with EC Directives, the PLC must be installed as follows:

- 1,2,3...**
1. The CP1H PLC must be installed within a control panel.
 2. You must use reinforced insulation or double insulation for the DC power supplies used for I/O Units and CPU Units requiring DC power. The output holding time must be 10 ms minimum for the DC power supply connected to the power supply terminals on Units requiring DC power.
 3. CP1H PLCs complying with EC Directives also conform to EN61131-2. Radiated emission characteristics (10-m regulations) may vary depending on the configuration of the control panel used, other devices connected to the control panel, wiring, and other conditions. You must therefore confirm that the overall machine or equipment complies with EC Directives.

6-4 Relay Output Noise Reduction Methods

The CP1H PLCs conforms to the Common Emission Standards (EN61131-2) of the EMC Directives. However, noise generated by relay output switching may not satisfy these Standards. In such a case, a noise filter must be connected to the load side or other appropriate countermeasures must be provided external to the PLC.

Countermeasures taken to satisfy the standards vary depending on the devices on the load side, wiring, configuration of machines, etc. Following are examples of countermeasures for reducing the generated noise.

Countermeasures




Countermeasures are not required if the frequency of load switching for the whole system with the PLC included is less than 5 times per minute.

Countermeasures are required if the frequency of load switching for the whole system with the PLC included is more than 5 times per minute.

Note Refer to EN61131-2 for more details.


Countermeasure Examples

When switching an inductive load, connect an surge protector, diodes, etc., in parallel with the load or contact as shown below.

Circuit	Current		Characteristic	Required element
	AC	DC		
CR method 	Yes	Yes	<p>If the load is a relay or solenoid, there is a time lag between the moment the circuit is opened and the moment the load is reset.</p> <p>If the supply voltage is 24 or 48 V, insert the surge protector in parallel with the load. If the supply voltage is 100 to 200 V, insert the surge protector between the contacts.</p>	<p>The capacitance of the capacitor must be 1 to 0.5 μF per contact current of 1 A and resistance of the resistor must be 0.5 to 1 Ω per contact voltage of 1 V. These values, however, vary with the load and the characteristics of the relay. Decide these values from experiments, and take into consideration that the capacitance suppresses spark discharge when the contacts are separated and the resistance limits the current that flows into the load when the circuit is closed again.</p> <p>The dielectric strength of the capacitor must be 200 to 300 V. If the circuit is an AC circuit, use a capacitor with no polarity.</p>
Diode method 	No	Yes	<p>The diode connected in parallel with the load changes energy accumulated by the coil into a current, which then flows into the coil so that the current will be converted into Joule heat by the resistance of the inductive load.</p> <p>This time lag, between the moment the circuit is opened and the moment the load is reset, caused by this method is longer than that caused by the CR method.</p>	<p>The reversed dielectric strength value of the diode must be at least 10 times as large as the circuit voltage value. The forward current of the diode must be the same as or larger than the load current.</p> <p>The reversed dielectric strength value of the diode may be two to three times larger than the supply voltage if the surge protector is applied to electronic circuits with low circuit voltages.</p>
Varistor method 	Yes	Yes	<p>The varistor method prevents the imposition of high voltage between the contacts by using the constant voltage characteristic of the varistor. There is time lag between the moment the circuit is opened and the moment the load is reset.</p> <p>If the supply voltage is 24 or 48 V, insert the varistor in parallel with the load. If the supply voltage is 100 to 200 V, insert the varistor between the contacts.</p>	---


When switching a load with a high inrush current such as an incandescent lamp, suppress the inrush current as shown below.

Countermeasure 1



Providing a dark current of approx. one-third of the rated value through an incandescent lamp

Countermeasure 2




Providing a limiting resistor

6-5 Conditions for Meeting EMC Directives when Using CP-series Relay Expansion I/O Units

EN61131-2 immunity testing conditions when using the CP1W-40EDR, CP1W-32ER or CP1W-16ER with a CP1W-CN811 I/O Connecting Cable are given below.


Recommended Ferrite Core

Ferrite Core (Data Line Filter): 0443-164151 manufactured by Nisshin Electric
Minimum impedance: 90 Ω at 25 MHz, 160 Ω at 100 MHz




Recommended Connection Method

- 1,2,3... 1. Cable Connection Method



2. Connection Method
As shown below, connect a ferrite core to each end of the CP1W-CN811 I/O Connecting Cable.



SECTION 1

Features and System Configuration

This section introduces the features of the CP1H and describes its configuration. It also describes the Units that are available and connection methods for the CX-Programmer and other peripheral devices.

1-1	Features and Main Functions	2
1-1-1	CP1H Overview	2
1-1-2	Features.....	6
1-2	System Configuration	15
1-2-1	Basic System.....	15
1-2-2	System Expansion.....	17
1-2-3	System Expansion with CJ-series Units.....	21
1-2-4	Restrictions on System Configuration	23
1-3	Connecting Programming Devices	26
1-3-1	Connecting to a USB Port.....	26
1-3-2	Connecting to a Serial Port.....	35
1-4	Function Charts.....	37
1-5	Function Blocks	40
1-5-1	Overview of Function Blocks.....	40
1-5-2	Advantages of Function Blocks	40

1-1 Features and Main Functions


1-1-1 CP1H Overview

The SYSMAC CP1H is an advanced high-speed, package-type Programmable Controller. While the CP1H employs the same architecture as the CS/CJ Series and provides the same I/O capacity of 40 I/O points as the CPM2A, the CP1H is approximately ten times faster.

There are three types of CP1H CPU Units to select from: a basic CPU Unit (X), a CPU Unit with built-in analog I/O terminals (XA), and a CPU Unit with Dedicated Pulse I/O Terminals (Y).

Basic CPU Units: X

The X CPU Units are the standard models in the CP1H Series.




- The CPU Unit has 24 inputs and 16 outputs built in.
- High-speed counters and pulse outputs can be used on four axes with the CPU Unit alone.
- The CP1H can be expanded to a maximum total of 320 I/O points by using CP-series Expansion I/O Units.
- Using CP-series Expansion Units also allows extra functions (such as temperature sensor inputs) to be added.
- Installing an Option Board enables RS-232C and RS-422A/485 communications for Programmable Terminals, Bar Code Readers, Inverters, etc.
- Using CJ-series CPU Bus Units enables communications with higher and lower level devices.

- Note** Settings in the PLC Setup determine whether each input point is to be used as a normal input, interrupt input, quick-response input, or high-speed counter. The instruction used to control each output point determines whether it is used as a normal output, pulse output, or PWM output.

CPU Units with Built-in Analog I/O **Terminals: XA**

The XA CPU Unit adds analog I/O functionality to the X CPU Unit capabilities.




- The CPU Unit has 24 inputs and 16 outputs built in.
- High-speed counters and pulse outputs can be used on four axes with the CPU Unit alone.
- The CPU Unit has 4 analog voltage/current inputs and 2 analog voltage/current outputs built in.
- The CP1H can be expanded to a maximum total of 320 I/O points by using CP-series Expansion I/O Units.
- Using CP-series Expansion Units also allows extra functions (such as temperature sensor inputs) to be added.
- Installing an Option Board enables RS-232C and RS-422A/485 communications for connecting to Programmable Terminals, Bar Code Readers, Inverters, etc.
- Using CJ-series CPU Bus Units enables communications with higher and lower level devices.

- Note** Settings in the PLC Setup determine whether each input point is to be used as a normal input, interrupt input, quick-response input, or high-speed counter. The instruction used to control each output point determines whether it is used as a normal output, pulse output, or PWM output.

CPU Unit with Dedicated Pulse I/O Terminals: Y

In place of the X CPU Units' more numerous built-in I/O points, the Y CPU Unit provides dedicated pulse I/O terminals (1 MHz).



- The CPU Unit has 12 inputs and 8 outputs built in.
- High-speed counters and pulse outputs can be used on four axes with the CPU Unit alone.
The CPU Unit provides a high-speed pulse output of up to 1 MHz, and can handle linear servos.
- The CP1H can be expanded to a maximum total of 300 I/O points by using CP-series Expansion I/O Units.
- Using CP-series Expansion Units also allows extra functions (such as temperature sensor inputs) to be added.
- Installing an Option Board enables RS-232C and RS-422A/485 communications for connecting to Programmable Terminals, Bar Code Readers, Inverters, etc.
- Using CJ-series CPU Bus Units enables communications with higher and lower level devices.


Note Settings in the PLC Setup determine whether each input point is to be used as a normal input, interrupt input, quick-response input, or high-speed counter. The instruction used to control each output point determines whether it is used as a normal output, pulse output, or PWM output.

CP1H CPU Unit Models

Model		X CPU Units		XA CPU Units		Y CPU Units
		CP1H-X40DR-A (relay outputs)	CP1H-X40DT-D (transistor outputs, sinking) CP1H-X40DT1-D (transistor outputs, sourcing)	CP1H-XA40DR-A (relay outputs)	CP1H-XA40DT-D (transistor outputs, sinking) CP1H-XA40DT1-D (transistor outputs, sourcing)	CP1H-Y20DT-D (transistor outputs, sinking)
Power supply		100 to 240 VAC 50/60 Hz	24 VDC	100 to 240 VAC 50/60 Hz	24 VDC	24 VDC
Program capacity		20K steps				
Max. number of I/O points (See note.)		320				
Normal I/O	I/O points	40				
	Input points	24				
	Input specifications	24 VDC				
	Interrupt or quick-response inputs	8 max.				
	Output points	16				
	Output specifications	Relay output	Transistor output	Relay output	Transistor output	Transistor output
High-speed counter inputs	High-speed counter inputs	4 axes, 100 kHz (single phase)/50 kHz (differential phases)				
	Dedicated high-speed counter input terminals	None				
Pulse outputs	Built-in I/O terminal allocation	Unit version 1.0 and earlier: 2 axes; 100 kHz, 2 axes, 30 kHz Unit version 1.1 and later: 4 axes, 100 kHz				
	Dedicated pulse output terminals	None				
Built-in analog I/O		None			Analog voltage/current inputs: 4 Analog voltage/current outputs: 2	

Note When CP-series Expansion I/O Units are used.


Interpreting CP1H CPU Unit Model Numbers



1-1-2 Features

This section describes the main features of the CP1H.

Basic CP1H Configuration



Note In this manual, unless otherwise specified, “CP1W-CIF12” refers to the CP1W-CIF12 and CP1W-CIF12-V1 Option Boards.

Faster Processing Speed (All Models)


- Top-class performance has been achieved in a micro PLC, with an instruction processing speed equivalent to the CJ1M.
- Approximately 500 instructions are processed at high speed.
- Program creation and control are simplified by using function blocks (FB) and tasks.

Full Complement of High-speed Counter Functions (All Models)

High-speed counter inputs can be enabled by connecting rotary encoders to the built-in inputs. The ample number of high-speed counter inputs makes it possible to control a multi-axis device with a single PLC.

- X and XA CPU Units


Four 100-kHz (single phase)/50-kHz (differential phases) high-speed counter inputs are provided as a standard feature. (See note.)



Note Settings in the PLC Setup determine whether each input point is to be used as a normal input, interrupt input, quick-response input, or high-speed counter.

- Y CPU Units

Along with two 100-kHz (single phase)/50-kHz (differential phases) high-speed counter inputs, two 1-MHz (single phase)/500-kHz (differential phases) dedicated high-speed counter terminals are provided.



Note Settings in the PLC Setup determine whether each input point is to be used as a normal input, interrupt input, quick-response input, or high-speed counter.

Full Complement of High-speed Counter Functions (All Models)

High-speed Processing for High-speed Counter Present Value (PV) Target Values or Range Comparison Interrupts

An interrupt task can be started when the count reaches a specified value or falls within a specified range.

High-speed Counter Input Frequency (Speed) Monitoring

The input pulse frequency can be monitored using the PRV instruction (one point only).

High-speed Counter PV Holding/Refreshing

It is possible to toggle between holding and refreshing the high-speed counter PV by turning ON and OFF the High-speed Counter Gate Flag from the ladder program.


Versatile Pulse Control (All Models)

Positioning and speed control by a pulse-input servo driver is enabled by outputting fixed duty ratio pulse output signals from the CPU Unit's built-in outputs.

Four axes (X, Y, Z, and θ) can be controlled. A 1-MHz speed pulse rate is also possible for Y CPU Units.

- X and XA CPU Units

Pulse outputs for 4 axes at 100 kHz maximum are provided as standard features. (See note.) (Unit version 1.0 or earlier: Pulse outputs for 2 axes at 100 kHz maximum and 2 axes at 30 kHz maximum.)




Note The instruction used to control each output point determines whether it is used as a normal output, pulse output, or PWM output.

- Y CPU Units

Along with pulse outputs for two axes at 100 kHz maximum, dedicated pulse output terminals for two axes at 1 MHz are provided as standard features. (See note.)

High-speed, high-precision positioning by linear servomotor, direct drive motor, etc., is enabled using 1-MHz pulses.



Note The instruction used to control each output point determines whether it is used as a normal output, pulse output, or PWM output.

Full Complement of Pulse Output Functions (All Models)

Select CW/CCW Pulse Outputs or Pulse Plus Direction Outputs for the Pulse Outputs

The pulse outputs can be selected to match the pulse input specifications of the motor driver.

Easy Positioning with Absolute Coordinate System Using Automatic Direction Setting

For operations in an absolute coordinate system (i.e., when the origin is established or when the PV is changed by the INI instruction), the CW/CCW direction can be automatically set when PULSE OUTPUT instructions are executed according to whether the specified number of output pulses is more or less than the pulse output PV.

Triangular Control

If the amount of output pulses required for acceleration and deceleration (the target frequency times the time to reach the target frequency) exceeds the preset target number of output pulses during positioning (when the ACC instruction in independent mode or the PLS2 instruction is executed), the acceleration and deceleration will be shortened and triangular control will be executed instead of trapezoidal control. In other words, the trapezoidal pulse output will be eliminated, with no period of constant speed.

Target Position Changes during Positioning (Multiple Start)

While positioning using a PULSE OUTPUT (PLS2) instruction is in progress, the target position, target speed, acceleration rate, and deceleration rate can be changed by executing another PLS2 instruction.

Positioning Changes during Speed Control (Interrupt Feeding)

While speed control in continuous mode is in effect, it is possible to change to positioning in independent mode by executing a PULSE OUTPUT (PLS2) instruction. By this means, interrupt feeding (moving a specified amount) can be executed under specified conditions.

Target Speed, Acceleration Rate, and Deceleration Rate Changes during Acceleration or Deceleration

When a PULSE OUTPUT instruction with trapezoidal acceleration and deceleration is executed (for speed control or positioning), the target speed and acceleration and deceleration rates can be changed during acceleration or deceleration.

Lighting and Power Control by Outputting Variable Duty Ratio Pulses

Operations, such as lighting and power control, can be handled by outputting variable duty ratio pulse (PWM) output signals from the CPU Unit's built-in outputs.

Origin Searches (All Models)**Origin Search and Origin Return Operations Using a Single Instruction**

An accurate origin search combining all I/O signals (origin proximity input signal, origin input signal, positioning completed signal, error counter reset output, etc.) can be executed with a single instruction. It is also possible to move directly to an established origin using an origin return operation.

Input Interrupts (All Models)

In direct mode, an interrupt task can be started when a built-in input turns ON or OFF. In counter mode, the rising or falling edges of built-in inputs can be counted, and an interrupt task started when the count reaches a specified value. The maximum number of points is 8 for X and XA CPU Units and 6 for Y CPU Units. (See note.)

Note For each input point, a selection in the PLC Setup determines whether it is to be used as a normal input, interrupt input, quick-response input, or high-speed counter. The interrupt input response frequency in counter mode must be 5 kHz or less total for all interrupts.

Quick-response Inputs (All Models)


By using quick-response inputs, built-in inputs up to a minimum input signal width of 30 μ s can be read regardless of the cycle time.

The maximum number of points is 8 for X and XA CPU Units and 6 for Y CPU Units. (See note.)

Note For each input, a PLC Setup parameter determines whether it is to be used as a normal input, interrupt input, quick-response input, or high-speed counter.

Analog I/O Function (XA CPU Units Only)

XA CPU Units have analog I/O functionality, with 4 analog voltage/current inputs and 2 analog voltage/current outputs built in.




- A wide range of applications is possible at a resolution of 6,000 or 12,000.
- Application is also possible for process-control sensor input or Inverter control without using Expansion I/O Units.

Analog Settings (All Models)


Changing Settings Using Analog Adjustment

By adjusting the analog adjuster with a Phillips screwdriver, the value in the Auxiliary Area can be changed to any value between 0 and 255. This makes it easy to change set values such as timers and counters without Programming Devices.



Changing Settings Using External Analog Setting Inputs


External analog values of 0 to 10 V (resolution: 256) are converted to digital values and stored in a word in the AR Area. This enables applications that require on-site adjustment of settings that do not demand a particularly high degree of accuracy, such as for example, a setting based on changes in outdoor temperatures or potentiometer inputs.



Connectability with Various Components (All Models)

USB Port for Programming Devices


CX-One Support Software, such as the CX-Programmer, connects from the USB port on a computer to the CP1H built-in peripheral USB port via commercially available USB cable.



Expansion Capability for Two Serial Ports (All Models)


A maximum of two Serial Communications Boards each with one RS-232C port or one RS-422A/485 port can be added. With a total of up to three ports, including the USB port, this makes it possible to simultaneously connect a computer, PT, CP1H, and/or various components, such as an Inverter, Temperature Controller, or Smart Sensor.

NS-series PT, personal computer, bar code reader, etc.




- Note** (1) The Modbus-RTU easy master (available for all models) makes it easy to control Modbus Slaves (such as Inverters) with serial communications. After the Modbus Slave address, function, and data have been preset in a fixed memory area (DM), messages can be sent or received independently of the program by turning software switches.

Communications can be executed independently of the program by setting a Modbus-RTU command in the DM and turning ON a software switch.




- (2) By using the serial PLC Links (available for all models), a maximum of 10 words of data per CPU Unit can be shared independently of the program among a maximum of nine CPU Units (CP1H-CP1H-CJ1M) using RS-422A/485 Option Boards.



7-segment LED Display (All Models)

A two-digit 7-segment LED display makes it easy to monitor PLC status.

This improves the human-machine interface for maintenance, making it easier to detect troubles that may occur during machine operation.



- Displays error codes and details for errors detected by the CPU Unit.


- Displays the progress of transfers between the CPU Unit and Memory Cassette.
- Displays changes in values when using the analog control.
- Displays user-defined codes from special display instructions in the ladder program.

No-battery Operation (All Models)

Programs, the PLC Setup, and other data can be automatically saved to the CPU Unit's built-in flash memory. Moreover, DM Area data can be saved to the flash memory and then used as initial data when the power is turned ON.


This allows programs and initial values (such as recipe setup data) in the DM Area to be saved in the CPU Unit without the need to maintain a backup battery.

CP1H CPU Unit



Memory Cassettes (All Models)

Built-in flash memory data, such as programs and DM initial-value data, can be stored on a Memory Cassette (optional) as backup data. In addition, programs and initial-value data can be easily copied to another CPU Unit using the Memory Cassette to recreate the same system.



Security (All Models)


A password registration function is provided for the CPU Unit to prevent unauthorized copy of ladder programs. If an attempt is made to read a ladder program from a CX-Programmer, access to the program is denied if the password that is entered does not match the registered password. If incorrect passwords are entered for five consecutive attempts, the CPU Unit does not accept any more passwords for two hours.

Read Protection Using Extended Passwords

With unit version 1.3 or later and CX-Programmer version 9.6 or higher, you can extend protection with UM read protection and task read protection to ensure better protection for your design assets.


Expansion Capability for CJ-series Special I/O Units and CPU Bus Units (All Models)

A maximum of two CJ-series Special I/O Units or CPU Bus Units can be connected via a CJ Unit Adapter. It is also possible to connect to upper level and lower level networks, and to expand the system by using analog I/O.



1-2 System Configuration

1-2-1 Basic System



Maximum Number of Normal I/O Points

Type	Description	Power supply voltage	Model	Normal built-in inputs	Normal built-in outputs	Weight
X	Basic CPU Units	100 to 240 VAC	CP1H-X40DR-A	24 DC inputs	16 relay outputs	740 g max.
		24 VDC	CP1H-X40DT-D		16 transistor (sinking) outputs	590 g max.
			CP1H-X40DT1-D		16 transistor (sourcing) outputs	590 g max.
XA	CPU Units with built-in analog I/O terminals	100 to 240 VAC	CP1H-XA40DR-A		16 relay outputs	740 g max.
		24 VDC	CP1H-XA40DT-D		16 transistor (sinking) outputs	590 g max.
			CP1H-XA40DT1-D		16 transistor (sourcing) outputs	590 g max.
Y	CPU Unit with dedicated pulse I/O terminals	24 VDC	CP1H-Y20DT-D	12 DC inputs	8 transistor (sinking) outputs	560 g max.

Optional Products


Item	Model	Specifications	Weight
Memory Cassette	CP1W-ME05M	Can be used to store user programs in flash memory, parameters, DM initial values, comment memory, FB programs, and data in RAM.	10 g max.
LCD Option Board	CP1W-DAM01	Can be used to monitor and change user-specified messages, time or other data of the PLC.	20 g max.
Ethernet Option Board	CP1W-CIF41	Can be used to communicate with these units supported OMRON FINS/TCP, FINS/UDP protocol.	20 g max.

Serial Communications Expansion



When serial communications are required for a CP1H CPU Unit, an RS-232C or RS-422A/485 Option Board can be added.

This enables connection by serial communications to NS-series PTs, Bar Code Readers, components such as Inverters, and computers without USB ports (such as when using the CX-Programmer).

NS-series PT, personal computer, bar code reader, etc.



Option Boards for Serial Communications

Appearance	Name	Model	Port	Serial communications modes
	RS-232C Option Board	CP1W-CIF01	One RS-232C port (D-Sub, 9 pins, female)	Host Link, NT Link (1: N mode), No-protocol, Serial PLC Link Slave, Serial PLC Link Master, Serial Gateway (conversion to CompoWay/F, conversion to Modbus-RTU), peripheral bus
	RS-422A/485 Option Board	CP1W-CIF11/CIF12	One RS-422A/485 port (terminal block for ferrules)	

Unit Consumption Currents

Unit	Model	Current consumption		External power supply
		5 V DC	24 V DC	
CPU Unit	CP1H-XA40DR-A	0.430 A	0.180 A	0.3 A max.
	CP1H-XA40DT-D	0.510 A	0.120 A	---
	CP1H-XA40DT1-D	0.510 A	0.150 A	---
	CP1H-X40DR-A	0.420 A	0.070 A	0.3 A max.
	CP1H-X40DT-D	0.500 A	0.010 A	---
	CP1H-X40DT1-D	0.500 A	0.020 A	---
	CP1H-Y20DT-D	0.55 A	---	---

Note

- (1) The current consumption of the following is included with the current consumption of the CPU Unit: CP1W-ME05M Memory Cassette, CP1W-CIF-1 or CP1W-CIF11 Option Board, and CP1W-EXT01 CJ Unit Adapter.
- (2) The current consumption of the following is not included with the current consumption of the CPU Unit: CP1W-CIF12.


Unit	Model	Current consumption		External power supply
		5 V DC	24 V DC	
Interface Unit	CP1W-CIF12	0.075 A	---	---

- (3) CPU Units taking a DC power supply do not provide an external power supply.


1-2-2 System Expansion

A maximum of seven CP-series Expansion Units or Expansion I/O Units can be connected to a CP1H CPU Unit.

This allows for the expansion of various functions such as I/O points or temperature sensor inputs.



When CP1W-CN811 I/O Connecting Cable is used, the cable length can be extended by up to 80 cm, enabling installing the Units in two rows.






Up to seven Units can be added, and the maximum number of I/O points per Unit is 40, so the maximum total number of expansion I/O points is 280.







Maximum Normal I/O Points

Type	Power supply voltage	Model	Built-in normal inputs	Built-in normal outputs	Max. number of Expansion I/O Units	Max. number of expansion points	Max. total I/O points
X (Basic CPU Units)	100 to 240 VAC	CP1H-X40DR-A	24 DC inputs	16 relay outputs	7	280 (7 Units × 40 points)	320
	24 VDC	CP1H-X40DT-D		16 transistor outputs (sinking)			
		CP1H-X40DT1-D		16 transistor outputs (sourcing)			
XA (CPU Units with built-in analog I/O terminals)	100 to 240 VAC	CP1H-XA40DR-A		16 relay outputs			
	24 VDC	CP1H-XA40DT-D		16 transistor outputs (sinking)			
		CP1H-XA40DT1-D		16 transistor outputs (sourcing)			
Y (CPU Unit with dedicated pulse I/O terminals)	24 VDC	CP1H-Y20DT-D	12 DC inputs	8 transistor outputs (sinking)			300

CP-series Expansion I/O Units

Appearance	Model	Normal inputs	Normal outputs	Weight
	CP1W-40EDR	24 VDC: 24 inputs	16 relay outputs	380 g max.
	CP1W-40EDT		16 transistor outputs (sinking)	320 g max.
	CP1W-40EDT1		16 transistor outputs (sourcing)	
	CP1W-32ER	None	32 relay outputs	465 g max.
	CP1W-32ET		32 transistor outputs (sinking)	325 g max.
	CP1W-32ET1		32 transistor outputs (sourcing)	
	CP1W-20EDR1	24 VDC: 12 inputs	8 relay outputs	300 g max.
	CP1W-20EDT		8 transistor outputs (sinking)	
	CP1W-20EDT1		8 transistor outputs (sourcing)	
	CP1W-16ER	None	16 relay outputs	280 g max.
	CP1W-16ET		16 transistor outputs (sinking)	225 g max.
	CP1W-16ET1		16 transistor outputs (sourcing)	
	CP1W-8ED	24 VDC: 8 inputs	None	200 g max.
	CP1W-8ER	None	8 relay outputs	250 g max.
	CP1W-8ET		8 transistor outputs (sinking)	
	CP1W-8ET1		8 transistor outputs (sinking)	

CP-series Expansion Units

Name and appearance	Model	Specifications			Weight
<div>Analog I/O Units</div> <div></div>	CP1W-MAD11	2 analog inputs	0 to 5 V/1 to 5 V/0 to 10 V/-10 to +10 V/0 to 20 mA/4 to 20 mA	Resolution: 6,000	150 g max.
		1 analog output	1 to 5 V/0 to 10 V/-10 to +10 V/0 to 20 mA/4 to 20 mA		
	CP1W-MAD42	4 analog inputs	0 to 5 V/1 to 5 V/0 to 10 V/-10 to +10 V/0 to 20 mA/4 to 20 mA	Resolution: 12,000	260 g max.
		2 analog outputs	1 to 5 V/0 to 10 V/-10 to +10 V/0 to 20 mA/4 to 20 mA		
	CP1W-MAD44	4 analog inputs	0 to 5 V/1 to 5 V/0 to 10 V/-10 to +10 V/0 to 20 mA/4 to 20 mA		
		4 analog outputs	1 to 5 V/0 to 10 V/-10 to +10 V/0 to 20 mA/4 to 20 mA		
<div>Analog Input Units</div> <div></div>	CP1W-AD041	4 analog inputs	0 to 5 V/1 to 5 V/0 to 10 V/-10 to +10 V/0 to 20 mA/4 to 20 mA	Resolution: 6,000	200 g max.
	CP1W-AD042	4 analog inputs	0 to 5 V/1 to 5 V/0 to 10 V/-10 to +10 V/0 to 20 mA/4 to 20 mA	Resolution: 12,000	
<div>Analog Output Units</div> <div></div>	CP1W-DA021	2 analog outputs	1 to 5 V/0 to 10 V/-10 to +10 V/0 to 20 mA/4 to 20 mA	Resolution: 6,000	200 g max.
	CP1W-DA041	4 analog outputs			
	CP1W-DA042	4 analog outputs	1 to 5 V/0 to 10 V/-10 to +10 V/0 to 20 mA/4 to 20 mA	Resolution: 12,000	
<div>Temperature Sensor Units</div> <div> </div>	CP1W-TS001	2 inputs	Thermocouple input K, J		250 g max.
	CP1W-TS002	4 inputs			
	CP1W-TS003	4 inputs	Thermocouple input K or J, 4 inputs or 2 analog inputs 0 to 10V/1 to 5V/4 to 20mA	Resolution: 12,000	225 g max.
	CP1W-TS004	12 inputs	Thermocouple input K, J		380 g max.
	CP1W-TS101	2 inputs	Platinum resistance thermometer input Pt100, JPt100		250 g max.
	CP1W-TS102	4 inputs			
<div>CompoBus/S I/O Link Unit</div> <div></div>	CP1W-SRT21	As a CompoBus/S slave, 8 inputs and 8 outputs are allocated.			200 g max.


Number of Allocated Words and Current Consumption for Expansion Units and Expansion I/O Units

Unit name		Model	I/O words		Current		
			Input	Output	5 VDC	24 VDC	
Expansion I/O Units	40 I/O points 24 inputs 16 outputs	CP1W-40EDR	2	2	0.080 A	0.090 A	
		CP1W-40EDT			0.160 A	---	
		CP1W-40EDT1					
	32 outputs	CP1W-32ER	None	2	0.049 A	0.131 A	
		CP1W-32ET			0.113 A	---	
		CP1W-32ET1					
	20 I/O points 12 inputs 8 outputs	CP1W-20EDR1	1	1	0.103 A	0.044 A	
		CP1W-20EDT			0.130 A	---	
		CP1W-20EDT1					
	16 outputs	CP1W-16ER	None	2	0.042 A	0.090 A	
		CP1W-16ET			0.076 A	---	
		CP1W-16ET1					
	8 inputs	CP1W-8ED	1	None	0.018 A	---	
	8 outputs	CP1W-8ER	None	1	0.026 A	0.044 A	
		CP1W-8ET			0.075 A	---	
		CP1W-8ET1					
Expansion Units	Analog I/O Units	2 inputs 1 output	CP1W-MAD11	2	1	0.083 A	0.110 A
		4 inputs 2 outputs	CP1W-MAD42	4	2	0.120 A	0.120 A
		4 inputs 4 outputs	CP1W-MAD44	4	4	0.120 A	0.170 A
		4 inputs	CP1W-AD041	4	2	0.100 A	0.090 A
			CP1W-AD042			0.100 A	0.050 A
		2 outputs	CP1W-DA021	None	2	0.040 A	0.095 A
		4 outputs	CP1W-DA041	None	4	0.080 A	0.124 A
			CP1W-DA042			0.070 A	0.160 A
	Temperature Sensor Units	K/J thermocouple inputs	CP1W-TS001	2	None	0.040 A	0.059 A
			CP1W-TS002	4			
			CP1W-TS004	2	1	0.080 A	0.050 A
		K/J thermocouple or analog inputs	CP1W-TS003	4	None	0.070 A	0.030 A
		Pt/JPt platinum resistance inputs	CP1W-TS101	2	None	0.054 A	0.073 A
			CP1W-TS102	4			
	CompoBus/S I/O Link Unit	8 inputs 8 outputs	CP1W-SRT21	1	1	0.029 A	---

Note CP1W-32ER/32ET/32ET1's maximum number of simultaneously ON points is 24 (75%).

1-2-3 System Expansion with CJ-series Units

A maximum of two CJ-series Special I/O Units or CPU Bus Units can be connected. In order to connect them, a CP1W-EXT01 CJ Unit Adapter and a CJ1W-TER01 End Cover are required. These Units make it possible to add serial communication functions, such as network communications or protocol macros.



Required Units

Name	Model	Description	Weight
CJ Unit Adapter	CP1W-EXT01	Mounting a CJ Unit Adapter to the right of the CP1H CPU Unit makes it possible to connect up to two CJ-series Special I/O Units or CPU Bus Units. Note The CJ Unit Adapter comes packaged with one CJ1W-TER01 End Cover.	40 g max.

Main Connectable CJ-series Units

The main CPU Bus Units and Special I/O Units that can be connected are listed in the following table.

Classification	Unit name	Model	Current consumption (5 VDC)	Weight
CPU Bus Units	High-speed Analog Input Unit	CJ1W-ADG41	0.65A	150g max.
	Controller Link Unit	CJ1W-CLK23	0.35A	110g max.
	Serial Communication Unit	CJ1W-SCU41-V1	0.38A (See note 1.)	110g max.
		CJ1W-SCU21-V1	0.28A (See note 1.)	
		CJ1W-SCU31-V1	0.38A	
	Ethernet Unit	CJ1W-ETN21	0.37A	100g max.
	EtherNet/IP Unit	CJ1W-EIP21	0.41A	94g max.
	FL-net Unit	CJ1W-FLN22	0.37A	100g max.
	DeviceNet Unit	CJ1W-DRM21	0.33A	118g max. (See note 2.)
	Position Control Unit for MECHATROLINK-II	CJ1W-NC271	0.36A	95g max.
		CJ1W-NC471		
		CJ1W-NCF71		
		CJ1W-NCF71-MA		
	Motion Control Unit for MECHATROLINK-II	CJ1W-MCH71	0.60A	210g max.
	Storage/Processing Unit	CJ1W-SPU01-V2	0.56A	180g max.

Classification	Unit name	Model	Current consumption (5 VDC)	Weight
Special I/O Units	Analog Input Unit	CJ1W-AD081-V1	0.42A	140 g max.
		CJ1W-AD041-V1		
	Analog Output Unit	CJ1W-DA08V	0.14A	150 g max.
		CJ1W-DA08C		
		CJ1W-DA041	0.12A	150 g max.
		CJ1W-DA021		
	Analog I/O Unit	CJ1W-MAD42	0.58A	150g max.
	Process Input Unit	CJ1W-PH41U	0.30A	150g max.
		CJ1W-AD04U	0.32A	150g max.
		CJ1W-PTS51	0.25A	150g max.
		CJ1W-PTS52		
		CJ1W-PTS15	0.18A	150g max.
		CJ1W-PTS16		
		CJ1W-PDC15		
	Temperature Control Unit	CJ1W-TC001	0.25A	150g max.
		CJ1W-TC002		
		CJ1W-TC003		
		CJ1W-TC004		
		CJ1W-TC101		
		CJ1W-TC102		
		CJ1W-TC103		
		CJ1W-TC104		
	High-speed Counter Unit	CJ1W-CT021	0.28A	100g max.
	Position Control Unit	CJ1W-NC113	0.25A	100g max.
		CJ1W-NC213		
		CJ1W-NC413	0.36A	150g max.
		CJ1W-NC133	0.25A	100g max.
		CJ1W-NC233		
		CJ1W-NC433	0.36A	150g max.
	Space Unit	CJ1W-SP001	-	50g max.
	ID Sensor Unit	CJ1W-V680C11	0.26A	120g max.
		CJ1W-V680C12	0.32A	130g max.
		CJ1W-V600C11	0.26A	120g max.
		CJ1W-V600C12	0.32A	130g max.
	CompoNet Master Unit	CJ1W-CRM21	0.40A	130g max.
	CompoBus/S Master Unit	CJ1W-SRM21	0.15A	66g max. (See note 2.)


- Note**
1. The current consumption increases 0.15A each unit, when using NT-AL001 Link Adapter.
The current consumption increases 0.04A each unit, when using CJ1W-CIF11 RS-422A Convert Adapter.
The current consumption increases 0.20A each unit, when using NV3W-M□20L Programmable Controller.
 2. The weight of optional connector is included.

Simultaneously Connecting Expansion I/O Units and CJ-series Units

When Expansion Units or Expansion I/O Units are connected simultaneously with CJ-series Special I/O Units or CPU Bus Units, they cannot be connected in a straight line with the CP1H CPU Unit.

As shown in the diagram below, use a DIN Track to mount the CP1H CPU Unit and CJ-series Units, and use CP1W-CN811 I/O Connecting Cable to connect the Expansion Units or Expansion I/O Units.

Note Only one I/O Connecting Cable can be used per System.



1-2-4 Restrictions on System Configuration

The following restrictions apply to the CP-series Expansion Units, CP-series Expansion I/O Units, and CJ-series Units that can be connected to CP1H CPU Units.

■ Number of Expansion Units and Expansion I/O Units Connected

A maximum of seven Units can be connected. If eight or more Units are connected, an I/O UNIT OVER error will occur and the PLC will not operate.

■ Number of Words Allocated

The total number of either input or output words allocated to Expansion Units and Expansion I/O Units must be no more than 15. Even if no more than seven Units are connected, an I/O UNIT OVER error will be generated if 16 or more input or output words are allocated.

■ Current Consumption

The total combined current consumption of the CP1H CPU Unit, Expansion Units, Expansion I/O Units, and CJ-series Units must be no more than 2 A for 5 V and 1 A for 24 V and the total power consumption must be no more than 30 W. For CPU Units with AC power supply, the current consumption from external 24-VDC power supply output must be included.

■ Number of CJ-series Units Connected

No more than two CJ-series Special I/O Units or CPU Bus Units can be connected to the CP1H via a CJ Unit Adapter. No CJ-series Basic I/O Units can be connected.

Example: Calculating the Limit on the Number of Connected Units

In this example, because each CP1W-TS002 Temperature Sensor Unit is allocated four input words, no more than three of these Units can be connected. (Three Units \times four words = 12 words.) After these have been connected, there remain unallocated three input words and 15 output words. The following table provides an example of Units that can be mounted in combination without exceeding these limits.

Combination Example

Number of Units		CP1H-X40DR-A	TS002 × 3	+ TS001 × 1	+ 20EDT × 1	+ 8ER × 2	Total: 7 Units	≤ 7 Units
Input words		---	4 words × 3 Units = 12 words	2 words × 1 Unit = 2 words	1 word × 1 Unit = 1 word	0 words	Total: 15 words	≤ 15 words
Output words		---	0 words	0 words	1 word × 1 Unit = 1 word	1 word × 2 Units = 2 words	Total: 3 words	≤ 15 words
Current consumption	5 V	0.420 A	0.040 A × 3 = 0.120 A	0.040 A × 1 = 0.040 A	0.130 A × 1 = 0.130 A	0.026 A × 2 = 0.0520 A	Total: 0.762 A	≤ 2 A
	24 V	0.070 A	0.059 A × 3 = 0.177 A	0.059 A × 1 = 0.059 A	0 A	0.044 A × 2 = 0.088 A	Total: 0.394 A	≤ 1 A
Power consumption		5 V × 0.762 A = 3.81 W 24 V × 0.394 A = 9.46 W					Total: 13.27 W	≤ 30 W







■ Restrictions on the number of simultaneously ON output points

CP1W-32ER/32ET/32ET1's maximum number of simultaneously ON points is 24 (75%).

■ Restrictions for the Ambient Temperature

Restrictions in the System Configuration

Configure the system within the restrictions for the output load current, simultaneously ON inputs, and total power consumption.


Model	Output load current	Simultaneously ON inputs	Total power consumption
CP1H-X40DT-D CP1H-X40DT1-D CP1H-XA40DT-D CP1H-XA40DT1-D CP1H-Y20DT-D			
CP1H-X40DR-A CP1H-XA40DR-A			

Power Supply Voltage Specifications for CPU Units with DC Power and Transistor Outputs

When connecting CP-series Expansion I/O Units with Relay Outputs to CPU Units with DC Power and Transistor Outputs (CP1H-X40DT(1)-D, CP1H-XA40DT(1)-D, and CP1H-Y20DT-D), use a power supply voltage of 24 VDC ±10% if connecting more than three Expansion I/O Units or if the ambient temperature is greater than 45°C.

Mounting Restriction

When connecting CP-series Expansion Units or Expansion I/O Units, provide a space of approximately 10 mm between the CPU Unit and the first Expansion Unit or Expansion I/O Unit.



If sufficient space cannot be provided between the CPU Unit and the first Expansion Unit or Expansion I/O Unit, reduce the temperatures in the above derating curves for the output load current, number of simultaneously ON inputs, and total power consumption by 5°C.

1-3 Connecting Programming Devices

“Programming Device” is a general term for a computer running programming and debugging software used with OMRON Programmable Controllers.


The CX-Programmer (Ver. 6.1 and later), which runs on Windows, can be used with CP-series Programmable Controllers. (See note.)

Note A Programming Console cannot be used with CP-series Programmable Controllers.

Devices can be connected to the USB port or to a serial port.

1-3-1 Connecting to a USB Port

Connect the computer running the CX-One Support Software (e.g., the CX-Programmer) using commercially available USB cable to a standard peripheral USB port.



The peripheral USB port (conforming to USB 1.1, B connector) is a dedicated port for connecting Support Software, such as the CX-Programmer.

Items Required for USB Connection

Operating system	Windows 98, Me, 2000, or XP
Support Software	CX-Programmer Ver. 6.1 (CX-One Ver. 1.1)
USB driver	Included with above Support Software.
USB cable	USB 1.1(or 2.0) cable (A connector-B connector), 5 m max.

USB Connection Procedure

The procedure for first connecting a computer to the CP1H peripheral USB port is described below.

It is assumed that the Support Software has already been installed in the computer.


Installing the USB Driver

The installation procedure depends on the OS of the computer. The following procedures are for Windows XP and Windows 2000.

Windows XP

Turn ON the power supply to the CP1H, and connect USB cable between the USB port of the computer and the peripheral USB port of the CP1H.


After the cable has been connected, the computer will automatically recognize the device and the following message will be displayed.




- 1,2,3... 1. If the following window appears, select the *No, not this time* Option and then click the **Next** Button. This window is not always displayed.




2. The following window will be displayed. Select the *Install from a list of specific location* Option and then click the **Next** Button.




3. The following window will be displayed. Click the **Browse** Button for the *Include this location in the search* Field, specify C:\Program Files\OMRON\CX-Server\USB\win2000_XP\Inf, and then click the **Next** Button. The driver will be installed. ("C:\" indicates the installation drive and may be different on your computer.)



4. Ignore the following window if it is displayed and click the **Continue Anyway** Button.



5. The following window will be displayed if the installation is completed normally. Click the **Finish** Button.




Windows 2000

Turn ON the power supply to the CP1H, and connect USB cable between the USB port of the computer and the peripheral USB port of the CP1H.

After the cable has been connected, the computer will automatically recognize the device and the following message will be displayed.




- 1,2,3... 1. The following message will be displayed. Click the **Next** Button.




2. The following window will be displayed.




3. Select the *Search for a suitable driver for the device (recommended)* Option and then click the **Next** Button. The following window will be displayed. From the list in the window, select the *Specify location* Checkbox and then click the **Next** Button.



4. Click the **Browse** Button, specify C:\Program Files\OMRON\CX-Server\USB\win2000_XP\Inf, and then click the **Next** Button. ("C:\\" indicates the installation drive and may be different on your computer.)



5. A search will be made for the driver and the following window will be displayed. Click the **Next** Button. The driver will be installed.




6. After the driver has been successfully installed, the following window will be displayed. Click the **Finish** Button.



Connection Setup Using the CX-Programmer


- 1,2,3...** 1. Select *CP1H* as the device type in the Change PLC Dialog Box and confirm that *USB* is displayed in the *Network Type* Field.



2. Click the **OK** Button to finish setting the PLC model. Then connect to the CP1H by executing the CX-Programmer's online connection command.

Checking after Installation

- 1,2,3...
1. Display the Device Manager at the computer.
 2. Click *USB (Universal Serial Bus) Controller*, and confirm that *OMRON SYSMAC PLC Device* is displayed.




Re-installing the USB Driver

If the USB driver installation fails for some reason or is cancelled in progress, the USB driver must be reinstalled.

Checking USB Driver Status

- 1,2,3...
1. Display the Device Manager on the computer.
 2. If *USB Device* is displayed for *Other devices*, it means that the USB driver installation has failed.



Reinstalling the USB Driver

- 1,2,3...
1. Right-click *USB Device* and select **Delete** from the pop-up menu to delete the driver.
 2. Reconnect the USB cable. The USB Driver Installation Window will be displayed.
 3. Reinstall the USB driver.


Restrictions when Connecting by USB

In conformity with USB specifications, the following restrictions apply when connecting a computer running Support Software.

- A USB connection is possible for only one CP1H from a single computer. It is not possible to connect multiple CP1Hs simultaneously.
- Do not disconnect the USB cable while the Support Software is connected online. Before disconnecting the USB cable, be sure to place the application in offline status. If the USB cable is disconnected while online, the situations described below will occur as a result of OS error.
 - Windows Me, 2000, or XP:
The Support Software cannot be returned to online status by simply reconnecting the USB cable. First return the Support Software to offline status, and then reconnect the USB cable. Then perform the online connection procedure for the Support Software.
 - Windows 98:
If the USB cable is disconnected while online, an error message may be displayed on a blue screen. If that occurs, it will be necessary to reboot the computer.

1-3-2 Connecting to a Serial Port

Mounting a CP1W-CIF01 RS-232C Option Board in a CP1H Option Board slot makes it possible to connect Support Software with serial communications, just as with previous models.



Connect the CX-Programmer to the RS-232C port of the CP1W-CIF01 Option Board by XW2Z-200S-CV/500S-CV RS-232C cable.

Connection Method

Connect the Programming Device using the Connecting Cable that is appropriate for the serial communications mode of the computer and CPU Unit.

Computer		Connecting Cable		CP1H CPU Unit	
Model	Connector	Model	Length	Connector	Serial communications mode
IBM PC/AT or compatible	D-Sub 9 pin, male	XW2Z-200S-CV	2 m	D-Sub 9 pin, female (With a CP1W-CIF01 RS-232C Option Board mounted in Option Board Slot 1 or 2.)	Peripheral bus or Host Link (SYSWAY)
		XW2Z-500S-CV	5 m		


Serial Communications Mode

Serial communications mode	Features	CPU Unit setting method
Peripheral bus (toolbus)	<p>This is the faster mode, so it is generally used for CX-Pro-grammer connections.</p> <ul style="list-style-type: none"> • Only 1: 1 connections are possible. • When a CP1H CPU Unit is used, the baud rate is automatically detected by the Support Software. 	<p>Turn ON pins SW4 (Serial Port 1) and SW5 (Serial Port 2) on the DIP switch on the front panel of the CPU Unit. These settings enable connection by peripheral bus regardless of the serial port settings in the PLC Setup.</p>
Host Link (SYSWAY)	<p>A standard protocol for host computers with either 1: 1 or 1: N connections.</p> <ul style="list-style-type: none"> • Slower than the peripheral bus mode. • Allows modem or optical adapter connections, or long-distance or 1: N connections using RS-422A/485. 	<p>Turn OFF pins SW4 (Serial Port 1) and SW5 (Serial Port 2) on the DIP switch on the front panel of the CPU Unit.</p> <p>The mode will then be determined by the serial port settings in the PLC Setup. The default settings are for Host Link with a baud rate of 9,600 bits/s, 1 start bit, data length of 7 bits, even parity, and 2 stop bits.</p>


Note When a Serial Communications Option Board is mounted in Option Board Slot 1, it is called "Serial Port 1." When mounted in Option Board Slot 2, it is called "Serial Port 2."

1-4 Function Charts


X and XA CPU Units



Y CPU Units



Functions Common to All Models



1-5 Function Blocks


In the SYSMAC CP Series, function blocks can be used in programming just as in the CS/CJ Series.

1-5-1 Overview of Function Blocks

A function block is a basic program element containing a standard processing function that has been defined in advance. Once the function block has been defined, the user just has to insert the function block in the program and set the I/O in order to use the function.

As a standard processing function, a function block is not created with actual physical addresses, but local variables. The user sets parameters (addresses or values) in those variables to use the function block. The addresses used for the variables themselves are automatically assigned by the system (CX-Programmer) each time they are placed in the program.

In particular, each function block is saved by the CX-Programmer as an individual file that can be reused with programs for other PLCs. This makes it possible to create a library of standard processing functions.



1-5-2 Advantages of Function Blocks

Function blocks allow complex programming units to be reused easily. Once standard program sections have been created as function blocks and saved in files, they can be reused just by placing a function block in a program and setting the parameters for the function block's I/O. Reusing standardized function blocks reduces the time required for programming/debugging, reduces coding errors, and makes programs easier to understand.

Structured Programming

Structured programs created with function blocks have better design quality and required less development time.

Easy-to-read “Block Box” Design

The I/O operands are displayed as local variable names in the program, so the program is like a “black box” when entering or reading the program and no extra time is wasted trying to understand the internal algorithm.

Different Processes Easily Created from a Single Function Block

Many different processes can be created easily from a single function block by using input variables for the parameters (such as timer SVs, control constants, speed settings, and travel distances) in the standard process.

Reduced Coding Errors

Coding mistakes can be reduced, because blocks that have already been debugged can be reused.

Data Protection

The local variables in the function block cannot be accessed directly from the outside, so the data can be protected. (Data cannot be changed unintentionally.)

Improved Reusability through Programming with Variables

The function block's I/O is entered as local variables, so the data addresses in the function block do not have to be changed as they do when copying and reusing a program section.

Creating Libraries

Processes that are independent and reusable (such as processes for individual steps, machinery, equipment, or control systems) can be saved as function block definitions and converted to library functions.


The function blocks are created with local variable names that are not tied to physical addresses, so new programs can be developed easily just by reading the definitions from the file and placing them in a new program.

Nesting Multiple Languages

Mathematical expressions can be entered in structured text (ST) language.

Nesting function blocks is supported for CX-Programmer Ver. 6.0 or higher. For example, it is possible to express only special operations in ST language within a function block in a ladder diagram.

Function block (ladder language)



Call (Nesting)

Function block (ST language)

```

RESULT:=0.0;
IF M=TRUE THEN
  RESULT:=SIN(data);
ENDIF;

```

For details on using function blocks, refer to the *CX-Programmer Ver. 7.0 Operation Manual: Function Blocks* (Cat. No. W447).

SECTION 2


Nomenclature and Specifications

This section describes the names and functions of CP1H parts and provides CP1H specifications.

2-1	Part Names and Functions.	44
2-1-1	CP1H CPU Units	44
2-1-2	CP1W-CIF01 RS-232C Option Boards	48
2-1-3	CP1W-CIF11/CIF12 RS-422A/485 Option Boards	49
2-2	Specifications	50
2-2-1	CP1H CPU Units	50
2-2-2	I/O Memory Details	54
2-2-3	I/O Specifications for XA and X CPU Units	55
2-2-4	Built-in Analog I/O Specifications (XA CPU Units Only)	63
2-2-5	I/O Specifications for Y CPU Units	65
2-2-6	CP-series Expansion I/O Unit I/O Specifications.	72
2-3	CP1H CPU Unit Operation	76
2-3-1	Overview of CPU Unit Configuration	76
2-3-2	Flash Memory Data Transfers	80
2-3-3	Memory Cassette Data Transfers	82
2-4	CPU Unit Operation	84
2-4-1	General Flow.	84
2-4-2	I/O Refreshing and Peripheral Servicing	85
2-4-3	I/O Refresh Methods.	86
2-4-4	Initialization at Startup	88
2-5	CPU Unit Operating Modes	89
2-5-1	Operating Modes	89
2-5-2	Status and Operations in Each Operating Mode.	89
2-5-3	Operating Mode Changes and I/O Memory	90
2-5-4	Startup Mode Setting	90
2-6	Power OFF Operation	91
2-6-1	Overview.	91
2-6-2	Instruction Execution for Power Interruptions	92
2-7	Computing the Cycle Time	93
2-7-1	CPU Unit Operation Flowchart	93
2-7-2	Cycle Time Overview	94
2-7-3	Functions Related to the Cycle Time	96
2-7-4	I/O Refresh Times for PLC Units	97
2-7-5	Cycle Time Calculation Example.	99
2-7-6	Online Editing Cycle Time Extension	99
2-7-7	I/O Response Time	100
2-7-8	Interrupt Response Times	101
2-7-9	Serial PLC Link Response Performance	103
2-7-10	Pulse Output Start Time	103
2-7-11	Pulse Output Change Response Time.	104

2-1 Part Names and Functions

2-1-1 CP1H CPU Units



Note 1: XA CPU Units only.
Note 2: CPU Units with AC Power Supply only.


- (1) **Battery Cover**
Covers the location where the battery is stored.
- (2) **Operation Indicators**
Show CP1H operation status.

<input type="checkbox"/> POWER	<input type="checkbox"/> RUN
<input type="checkbox"/> ERR/ALM	<input type="checkbox"/> INH
<input type="checkbox"/> BKUP	<input type="checkbox"/> PRPHL

POWER (Green)	Lit	Power is ON.
	Not lit	Power is OFF.
RUN (Green)	Lit	The CP1H is executing a program in either RUN or MONITOR mode.
	Not lit	Operation is stopped in PROGRAM mode or due to a fatal error.
ERR/ALM (Red)	Lit	A fatal error (including FALS execution) or a hardware error (WDT error) has occurred. CP1H operation will stop and all outputs will be turned OFF.
	Flashing	A non-fatal error has occurred (including FAL execution). CP1H operation will continue.
	Not lit	Operation is normal.
INH (Yellow)	Lit	The Output OFF Bit (A500.15) has turned ON. All outputs will be turned OFF.
	Not lit	Operation is normal.

BKUP (Yellow)	Lit	A user program, parameters, or Data Memory are being written or accessed in the built-in flash memory (backup memory). The BKUP indicator also lights while user programs, parameters, and Data Memory are being restored when the PLC power supply is turned ON. Note Do not turn OFF the PLC power supply while this indicator is lit.
	Not lit	Other than the above.
PRPHL (Yellow)	Flashing	Communications (either sending or receiving) are in progress through the peripheral USB port.
	Not lit	Other than the above.

- (3) Peripheral USB Port
Used for connecting to a personal computer for programming and monitoring by the CX-Programmer.
- (4) 7-segment Display
The 2-digit 7-segment display shows CP1H CPU Unit status, such as error information and the PV during analog adjustment.
Also, various codes can be displayed from the ladder program. (Refer to 6-3 7-Segment LED Display.)
- (5) Analog Adjuster
By turning the analog adjuster, it is possible to adjust the value of A642 within a range of 0 to 255. (Refer to 6-2 Analog Adjuster and External Analog Setting Input.)
- (6) External Analog Setting Input Connector
By applying 0 to 10 V of external voltage, it is possible to adjust the value of A643 within a range of 0 to 256. This input is not isolated. (Refer to 6-2 Analog Adjuster and External Analog Setting Input.)
- (7) DIP Switch



No.	Setting	Description	Application	Default
SW1	ON	User memory write-protected (See note.)	Used to prevent programs from being inadvertently overwritten by a Peripheral Device (CX-Programmer) onsite.	OFF
	OFF	User memory not write-protected.		
SW2	ON	Data automatically transferred from Memory Cassette at startup.	Used to enable programs, Data Memory, or parameters saved on a Memory Cassette to be opened by the CPU Unit at startup.	OFF
	OFF	Data not transferred.		
SW3	---	Not used.	---	OFF
SW4	ON	Used for peripheral bus.	Used to enable a Serial Communications Option Board mounted in Option Board Slot 1 to be used by the peripheral bus.	OFF
	OFF	According to PLC Setup.		

No.	Setting	Description	Application	Default
SW5	ON	Used for peripheral bus.	Used to enable a Serial Communications Option Board mounted in Option Board Slot 2 to be used by the peripheral bus.	OFF
	OFF	According to PLC Setup.		
SW6	ON	A395.12 ON	Used to bring about a given condition without using an Input Unit. A395.12 is used in the program by setting SW6 to ON or OFF.	OFF
	OFF	A395.12 OFF		

Note The following data will be write-protected if pin SW1 is turned ON:

- The entire user program (all tasks)
- All data in parameter areas (such as the PLC Setup)

When SW1 is turned ON, the user program and the data in the parameter areas will not be cleared even if the All Clear operation is performed from a Peripheral Device (i.e., the CX-Programmer).


(8) Built-in Analog I/O Terminal Block and Terminal Block Base (XA CPU Units Only)

There are four analog inputs and two analog outputs.

Mount the terminal block (included with the CPU Unit) to the terminal block base. (Refer to 5-5 Analog I/O (XA CPU Units).)

(9) Built-in Analog Input Switch (XA CPU Units Only)

This DIP switch determines whether each analog input is to be used for voltage input or current input.



No.	Setting	Description	Default
SW1	ON	Analog input 1: Current input	OFF
	OFF	Analog input 1: Voltage input	
SW2	ON	Analog input 2: Current input	
	OFF	Analog input 2: Voltage input	
SW3	ON	Analog input 3: Current input	
	OFF	Analog input 3: Voltage input	
SW4	ON	Analog input 4: Current input	
	OFF	Analog input 4: Voltage input	

Note The built-in analog input switch is located on the PCB inside the case. To make setting the switch easier, make the switch settings before mounting the terminal block to the base.

While setting this switch, be very careful not to damage the wiring on the PCB.

(10) Memory Cassette Slot

Used for mounting a CP1W-ME05M Memory Cassette. When mounting a Memory Cassette, remove the dummy cassette.

Data, such as CP1H CPU Unit programs, parameters, and data memory, can be transferred to the Memory Cassette to be saved.


(11) Power Supply, Ground, and Input Terminal Block

Power supply terminals	Used to provide a 100- to 240-VAC or 24-VDC power supply.
Ground terminals	Functional ground (\perp): Connect this ground to strengthen noise immunity and to prevent electric shock. (AC power supply models only.) Protective ground (\oplus): To prevent electric shock, ground to 100 Ω or less.
Input terminals	Used to connect input devices.

(12) Option Board Slots

The following Option Boards can be mounted in either slot 1 (left) or slot 2 (right).

- CP1W-CIF01 RS-232C Option Board
- CP1W-CIF11/CIF12 RS-422A/485 Option Board
- CP1W-DAM01 LCD Option Board
- CP1W-CIF41 Ethernet Option Board

 **Caution** Always turn OFF the power supply to the PLC before mounting or removing an Option Board.

(13) Input Indicators

The input indicators light when input terminal contacts turn ON.

(14) Expansion I/O Unit Connector

A maximum of seven CP-series Expansion I/O Units (40 I/O points, 20 I/O points, 8 input points, 8 or output points) and Expansion Units (Analog I/O Units, Temperature Sensor Units, CompoBus/S I/O Link Units, or DeviceNet I/O Link Units) can be connected. (For details on using Expansion Units and Expansion I/O Units, refer to *SECTION 7 Using CP-series Expansion Units and Expansion I/O Units*.)

(15) Output Indicators


The output indicators light when output terminal contacts turn ON.

(16) External Power Supply and Output Terminal Block

External power supply terminals	XA and X CPU Units with AC power supply specifications have external 24-VDC, 300-mA max., power supply terminals. They can be used as service power supplies for input devices.
Output terminals	Used for connecting output devices.

(17) Connector for CJ Unit Adapter

A maximum total of two CJ-series Special I/O Units or CPU Bus Units can be connected by mounting a CP1W-EXT01 CJ Unit Adapter to the side of a CP1H CPU Unit. CJ-series Basic I/O Units, however, cannot be connected.




2-1-2 CP1W-CIF01 RS-232C Option Boards

RS-232C Option Boards can be mounted to Option Board slots 1 or 2 on the CPU Unit.


When mounting an Option Board, first remove the slot cover. Grasp both of the cover's up/down lock levers at the same time to unlock the cover, and then pull the cover out.

Then to mount the Option Board, check the alignment and firmly press it in until it snaps into place.

Caution Always turn OFF the power supply to the PLC before mounting or removing an Option Board.



RS-232C Connector



Pin	Abbr.	Signal name	Signal direction
1	FG	Frame Ground	---
2	SD (TXD)	Send Data	Output
3	RD (RXD)	Receive Data	Input
4	RS (RTS)	Request to Send	Output
5	CS (CTS)	Clear to Send	Input
6	5V	Power Supply	---
7	DR (DSR)	Data Set Retry	Input
8	ER (DTR)	Equipment Ready	Output
9	SG (0V)	Signal Ground	---
Connector hood	FG	Frame Ground	---


2-1-3 CP1W-CIF11/CIF12 RS-422A/485 Option Boards

RS-422A/485 Option Boards can be mounted to Option Board slots 1 or 2 on the CPU Unit.


When mounting an Option Board, first remove the slot cover. Grasp both of the cover's up/down lock levers at the same time to unlock the cover, and then pull the cover out.

Then to mount the Option Board, check the alignment and firmly press it in until it snaps into place.

Caution Always turn OFF the power supply to the PLC before mounting or removing an Option Board.






RS-422A/485 Terminal Block



Tighten the terminal block screws to a torque of 0.28 N·m (2.5 Lb In.).

DIP Switch for Operation Settings

CP1W-CIF11/12		CP1W-CIF12-V1		Settings		
	Pin		Pin			
SW 	1	SW1 	1	ON	ON (both ends)	Terminating resistance selection
				OFF	OFF	Resistance value: 220Ω typical
	2		2	ON	2-wire	2-wire or 4-wire selection (See note 1.)
				OFF	4-wire	
	3		3	ON	2-wire	2-wire or 4-wire selection (See note 1.)
				OFF	4-wire	
	4		4	---	---	Not used.
	5	SW2 	1	ON	RS control enabled	RS control selection for RD (See note 2.)
				OFF	RS control disabled (Data always received.)	
	6		2	ON	RS control enabled	RS control selection for SD (See note 3.)
				OFF	RS control disabled (Data always sent.)	

Note

- (1) Set both pins 2 and 3 to either ON (2-wire) or OFF (4-wire).
- (2) To disable the echo-back function, set pin 5 to ON (RS control enabled).
- (3) When connecting to a device on the N side in a 1: N connection with the 4-wire method, set pin 6 to ON (RS control enabled).
Also, when connecting by the 2-wire method, set pin 6 to ON (RS control enabled).

2-2 Specifications

2-2-1 CP1H CPU Units

General Specifications

Power supply classification	AC power supply		DC power supply	
Model numbers	<ul style="list-style-type: none"> • XA CPU Units CP1H-XA40DR-A • X CPU Units CP1H-X40DR-A 		<ul style="list-style-type: none"> • XA CPU Units CP1H-XA40DT-D CP1H-XA40DT1-D • X CPU Units CP1H-X40DT-D CP1H-X40DT1-D 	<ul style="list-style-type: none"> • Y CPU Units CP1H-Y20DT-D
Power supply	100 to 240 VAC 50/60 Hz		24 VDC	
Operating voltage range	85 to 264 VAC		20.4 to 26.4 VDC (with 4 or more Expansion Units and Expansion I/O Units: 21.6 to 26.4 VDC)	
Power consumption	100 VA max.		50 W max.	
Inrush current (See note.)	100 to 120 VAC inputs: 20 A max.(for cold start at room temperature.) 8 ms max. 200 to 240 VAC inputs: 40 A max.(for cold start at room temperature.) 8 ms max.		30 A max.(for cold start) 20 ms max.	
External power supply	300 mA at 24 VDC		None	
Insulation resistance	20 MΩ min. (at 500 VDC) between the external AC terminals and GR terminals		No insulation between primary and secondary DC power supplies.	

Power supply classification	AC power supply	DC power supply	
Model numbers	<ul style="list-style-type: none">• XA CPU Units CP1H-XA40DR-A• X CPU Units CP1H-X40DR-A	<ul style="list-style-type: none">• XA CPU Units CP1H-XA40DT-D CP1H-XA40DT1-D• X CPU Units CP1H-X40DT-D CP1H-X40DT1-D	<ul style="list-style-type: none">• Y CPU Units CP1H-Y20DT-D
Dielectric strength	2,300 VAC 50/60 Hz for 1 min between the external AC and GR terminals, leakage current: 5 mA max.	No insulation between primary and secondary DC power supplies.	
Noise resistance	Conforms to IEC 61000-4-4 2 kV (power supply line)		
Vibration resistance	10 to 57 Hz, 0.075-mm amplitude, 57 to 150 Hz, acceleration: 9.8 m/s ² in X, Y, and Z directions for 80 minutes each (time coefficient of 8 minutes × coefficient factor of 10 = total time of 80 minutes)		
Shock resistance	147 m/s ² three times each in X, Y, and Z directions		
Ambient operating temperature	0 to 55°C		
Ambient humidity	10% to 90% (with no condensation)		
Atmosphere	No corrosive gas.		
Ambient storage temperature	−20 to 75°C (excluding battery)		
Terminal screw size	M3		
Power interrupt time	10 ms min.	2 ms min.	
Weight	740 g max.	590 g max.	560 g max.

Note (1) The above values are for a cold start at room temperature for an AC power supply, and for a cold start for a DC power supply.

- A thermistor (with low-temperature current suppression characteristics) is used in the inrush current control circuitry for the AC power supply. The thermistor will not be sufficiently cooled if the ambient temperature is high or if a hot start is performed when the power supply has been OFF for only a short time, so in those cases the inrush current values may be higher (as much as two times higher) than those shown above.
- A capacitor delay circuit is used in the inrush current control circuitry for the DC power supply. The capacitor will not be charged if a hot start is performed when the power supply has been OFF for only a short time, so in those cases the inrush current values may be higher (as much as two times higher) than those shown above.
- Always allow for this when selecting fuses and breakers for external circuits.

(2) General specification of Expansion I/O Units and Expansion Units will be the same criteria with CPU Units.

Characteristics

Type	X CPU Units	XA CPU Units	Y CPU Units
Model	CP1H-X40DR-A CP1H-X40DT-D CP1H-X40DT1-D	CP1H-XA40DR-A CP1H-XA40DT-D CP1H-XA40DT1-D	CP1H-Y20DT-D
Program capacity	20 Ksteps		
Control method	Stored program method		
I/O control method	Cyclic scan with immediate refreshing		
Program language	Ladder diagram		

Type		X CPU Units	XA CPU Units	Y CPU Units
Model		CP1H-X40DR-A CP1H-X40DT-D CP1H-X40DT1-D	CP1H-XA40DR-A CP1H-XA40DT-D CP1H-XA40DT1-D	CP1H-Y20DT-D
Function blocks		Maximum number of function block definitions: 128 Maximum number of instances: 256 Languages usable in function block definitions: Ladder diagrams, structured text (ST)		
Instruction length		1 to 7 steps per instruction		
Instructions		Approx. 500 (function codes: 3 digits)		
Instruction execution time		Basic instructions: 0.10 μ s min. Special instructions: 0.15 μ s min.		
Common processing time		0.7 ms		
Number of connectable Expansion Units and Expansion I/O Units		7 Units (CP Series) (There are restrictions on the Units that can be used in combination, however, based on the total number of I/O words and the total current consumption.)		
Max. number of I/O points		320 (40 built in + 40 per Expansion Unit/ Expansion I/O Unit \times 7 Units)		300 (20 built in + 40 per Expansion Unit/ Expansion I/O Unit \times 7 Units)
Number of connectable CJ-series Units		2 Units (CPU Bus Units or Special I/O Units only. Basic I/O Units cannot be used. A CP1W-EXT01CJ Unit Adapter is required.)		
Built-in input terminals (Functions can be assigned.)	Normal I/O		40 terminals (24 inputs and 16 outputs)	20 (12 inputs and 8 outputs) Note Aside from the above, 2 1-MHz high-speed counter inputs and 2 1-MHz pulse outputs can be added as special pulse I/O terminals.
	Interrupt inputs	Direct mode	8 inputs (Shared by the external interrupt inputs (counter mode) and the quick-response inputs.) Rising or falling edge Response time: 0.3 ms	6 inputs (Shared by the external interrupt inputs (counter mode) and the quick-response inputs.) Rising or falling edge Response time: 0.3 ms
		Counter mode	8 inputs, response frequency: 5 kHz total, 16 bits Incrementing counter or decrementing counter	6 inputs, response frequency: 5 kHz total, 16 bits Incrementing counter or decrementing counter
	Quick-response inputs		8 points (Min. input pulse width: 50 μ s max.)	6 points (Min. input pulse width: 50 μ s max.)
	High-speed counters		4 inputs (24 VDC) • Single phase (pulse plus direction, up/down, increment), 100 kHz • Differential phases (4 \times), 50 kHz Value range: 32 bits, Linear mode or ring mode Interrupts: Target value comparison or range comparison	2 inputs (24 VDC) • Single phase (pulse plus direction, up/down, increment), 100 kHz • Differential phases (4 \times), 50 kHz Value range: 32 bits, Linear mode or ring mode Interrupts: Target value comparison or range comparison
Special high-speed counter terminals	High-speed counters		None	2 inputs (Line-driver inputs) • Single phase (pulse plus direction, up/down, increment), 1 MHz • Differential phases (4 \times), 500 kHz Value range: 32 bits, linear mode or ring mode Interrupts: Target value comparison or range comparison Note High-speed counter terminals are line-driver inputs, so they cannot be used as normal inputs.

Type		X CPU Units	XA CPU Units	Y CPU Units
Model		CP1H-X40DR-A CP1H-X40DT-D CP1H-X40DT1-D	CP1H-XA40DR-A CP1H-XA40DT-D CP1H-XA40DT1-D	CP1H-Y20DT-D
Pulse outputs (Transistor output models only)	Pulse outputs	Unit version 1.0 and earlier: 2 outputs, 1 Hz to 100 kHz 2 outputs, 1 Hz to 30 kHz Unit version 1.1 and later: 4 outputs, 1 Hz to 100 kHz (CCW/CW or pulse plus direction) Trapezoidal or S-curve acceleration and deceleration (Duty ratio: 50% fixed)		2 outputs, 1 Hz to 100 kHz Trapezoidal or S-curve acceleration and deceleration (Duty ratio: 50% fixed)
	PWM outputs	2 outputs, 0.1 to 6,553.5 Hz Duty ratio: 0.0% to 100.0% variable (Unit: 0.1%) (Accuracy: $\pm 5\%$ at 1 kHz)		
Special pulse output terminals	Pulse outputs	None		2 outputs, 1 Hz to 1 M Hz (CCW/CW or pulse plus direction, line-driver outputs) Trapezoidal or S-curve acceleration and deceleration (Duty ratio: 50% fixed) Note Special pulse output terminals are line-driver outputs, so they cannot be used as normal outputs.
Built-in analog I/O terminals		None	4 analog inputs and 2 analog outputs (See note 1.)	None
Analog settings	Analog adjuster	1 (Setting range: 0 to 255)		
	External analog setting input	1 input (Resolution: 1/256, Input range: 0 to 10 V)		
Serial port	Peripheral USB port	Supported. (1-port USB connector, type B): Special for a Peripheral Device such as the CX-Programmer. (Set the network classification to USB in the Peripheral Device's PLC model setting.) • Serial communications standard: USB 1.1		
	RS-232C port, RS-422A/485 port	Ports not provided as standard equipment. (2 ports max.) The following Option Boards can be mounted: • CP1W-CIF01: One RS-232C port • CP1W-CIF11/CIF12: One RS-422A/485 port Applicable communications modes (same for all of the above ports): Host Link, NT Link (1: N mode), No-protocol, Serial PLC Link Slave, Serial PLC Link Master, Serial Gateway (conversion to CompoWay/F, conversion to Modbus-RTU), peripheral bus (See note 2.)		
7-segment display		2-digit 7-segment LED display (red) • At startup: The Unit version is displayed. • When a CPU Unit error occurs: The error code and error details are displayed in order (fatal error, non-fatal error). • When a special instruction is executed: The DISPLAY 7-SEGMENT LED WORD DATA (SCH) instruction displays the upper or lower byte of specified word data, and the 7-SEGMENT LED CONTROL (SCTRL) instruction controls the ON/OFF status of each segment. • While data is being transferred between a Memory Cassette and the CPU, the remaining amount to be transferred is displayed as a percentage. • When the analog adjuster is adjusted, the value is displayed from 00 to FF.		
Number of tasks		288 (32 cycle execution tasks and 256 interrupt tasks) Scheduled interrupt tasks: 1 (interrupt task 2, fixed) Input interrupt tasks: 8 (interrupt tasks 140 to 147, fixed) Note Y CPU Units have 6 input interrupt tasks. (Interrupt tasks 140 to 145 can be used.) (High-speed counter interrupts and interrupt tasks specified by external interrupts can also be executed.)		

Type		X CPU Units	XA CPU Units	Y CPU Units
Model		CP1H-X40DR-A CP1H-X40DT-D CP1H-X40DT1-D	CP1H-XA40DR-A CP1H-XA40DT-D CP1H-XA40DT1-D	CP1H-Y20DT-D
Maximum subroutine number		256		
Maximum jump number		256		
Scheduled interrupts		1		
Clock function		Supported. Accuracy (monthly deviation): –4.5 min to –0.5 min (ambient temperature: 55°C), –2.0 min to +2.0 min (ambient temperature: 25°C), –2.5 min to +1.5 min (ambient temperature: 0°C)		
Memory Backup	Built-in flash memory	User programs and parameters (such as the PLC Setup) are automatically saved to the flash memory. It is also possible to save and read data memory initial data. The data is automatically transferred to RAM when the power supply is turned ON. (Data memory initial data, however, may or may not be transferred, depending on the selection in the PLC Setup.		
	Battery backup	The HR Area, DM Area, and counter values (flags, PV) are backed up by a battery. Battery model: CJ1W-BAT01 (Built into the CP1H CPU Unit.) Maximum battery service life: 5 years Guaranteed (ambient temperature: 55°C): 13,000 hours (approx. 1.5 years) Effective value (ambient temperature: 25°C): 43,000 hours (approx. 5 years)		
Memory Cassette function		A CP1W-ME05M Memory Cassette (512K words, optional) can be mounted. It can be used to back up the following data on the CPU Unit's RAM and to transfer the data at startup. <ul style="list-style-type: none"> • Data saved on Memory Cassette: User programs, parameters (such as the PLC Setup), DM Area, data memory initial data, comment memory (CX-Programmer conversion tables, comments, program indices), and FB program memory. • Writing to Memory Cassette: By operations from the CX-Programmer. • Reading from Memory Cassette: At startup, or by operations from the CX-Programmer. 		

- Note**
- (1) For detailed specifications, refer to 5-5 Analog I/O (XA CPU Units).
 - (2) Can be used as Modbus-RTU easy master function.

2-2-2 I/O Memory Details

Type		X CPU Units	XA CPU Units	Y CPU Units
Model		CP1H-X40DR-A CP1H-X40DT-D CP1H-X40DT1-D	CP1H-XA40DR-A CP1H-XA40DT-D CP1H-XA40DT1-D	CP1H-Y20DT-D
I/O Areas	Input bits	272 bits (17 words): CIO 0.00 to CIO 16.15		
	Output bits	272 bits (17 words): CIO 100.00 to CIO 116.15		
	Built-in Analog Input Area	---	CIO 200 to CIO 203	---
	Built-in Analog Output Area	---	CIO 210 to CIO 211	---
	Data Link Area	3,200 bits (200 words): CIO 1000.00 to CIO 1119.15 (words CIO 1000 to CIO 1119)		
	CJ-series CPU Bus Unit area	6,400 bits (400 words): CIO 1500.00 to CIO 1899.15 (words CIO 1500 to CIO 1899)		
	CJ-series Special I/O Unit Area	15,360 bits (960 words): CIO 2000.00 to CIO 2959.15 (words CIO 2000 to CIO 2959)		
	Serial PLC Link Area	1,440 bits (90 words): CIO 3100.00 to CIO 3189.15 (words CIO 3100 to CIO 3189)		
	DeviceNet Area	9,600 bits (600 words): CIO 3200.00 to CIO 3799.15 (words CIO 3200 to CIO 3799)		
	Work bits	4,800 bits (300 words): CIO 1200.00 to CIO 1499.15 (words CIO 1200 to CIO 1499) 37,504 bits (2,344 words): CIO 3800.00 to CIO 6143.15 (words CIO 3800 to CIO 6143)		
Work bits		8,192 bits (512 words): W000.00 to W511.15 (words W0 to W511)		


Type Model	X CPU Units	XA CPU Units	Y CPU Units
	CP1H-X40DR-A CP1H-X40DT-D CP1H-X40DT1-D	CP1H-XA40DR-A CP1H-XA40DT-D CP1H-XA40DT1-D	CP1H-Y20DT-D
TR Area	16 bits: TR0 to TR15		
HR Area	8,192 bits (512 words): H0.00 to H511.15 (words H0 to H511)		
AR Area	Read-only (Write-prohibited) 7,168 bits (448 words): A0.00 to A447.15 (words A0 to A447) Read/Write 8,192 bits (512 words): A448.00 to A959.15 (words A448 to A959)		
Timers	4,096 bits: T0 to T4095		
Counters	4,096 bits: C0 to C4095		
DM Area	32 Kwords: D0 to D32767 Note Initial data can be transferred to the CPU Unit's built-in flash memory using the data memory initial data transfer function. A setting in the PLC Setup can be used so that the data in flash memory is transferred to RAM at startup. DM Area words for CJ-series Special I/O Units: D20000 to D29599 (100 words × 96 Units) DM Area words for CJ-series CPU Bus Units: D30000 to D31599 (100 words × 16 Units) DM fixed allocation words for Modbus-RTU Easy Master D32200 to D32249 for Serial Port 1, D32300 to D32349 for Serial Port 2		
Data Register Area	16 registers (16 bits): DR0 to DR15		
Index Register Area	16 registers (16 bits): IR0 to IR15		
Task Flag Area	32 flags (32 bits): TK0000 to TK0031		
Trace Memory	4,000 words (500 samples for the trace data maximum of 31 bits and 6 words.)		

2-2-3 I/O Specifications for XA and X CPU Units

Relationship between Built-in Inputs and Terminal Block Arrangement

Terminal Block Arrangement

Upper Terminal Block (Example: AC Power Supply Models)



Setting Input Functions in the PLC Setup

Functions for the normal input terminals in the built-in inputs can be individually allocated by making selections in the PLC Setup.

Input terminal block		Input operation			High-speed counter operation	Origin search function
Word	Bit	Normal inputs	Interrupt inputs (See note.)	Quick-response inputs	High-speed counters 0 to 3 set to be used.	Origin search function for pulse outputs 0 to 3 set to be used.
CIO 0	00	Normal input 0	Interrupt input 0	Quick-response input 0	---	Pulse 0: Origin input signal
	01	Normal input 1	Interrupt input 1	Quick-response input 1	High-speed counter 2 (phase-Z/reset)	Pulse 0: Origin proximity input signal
	02	Normal input 2	Interrupt input 2	Quick-response input 2	High-speed counter 1 (phase-Z/reset)	Pulse output 1: Origin input signal
	03	Normal input 3	Interrupt input 3	Quick-response input 3	High-speed counter 0 (phase-Z/reset)	Pulse output 1: Origin proximity input signal
	04	Normal input 4	---	---	High-speed counter 2 (phase-A, increment, or count input)	---
	05	Normal input 5	---	---	High-speed counter 2 (phase-B, decrement, or direction input)	---
	06	Normal input 6	---	---	High-speed counter 1 (phase-A, increment, or count input)	---
	07	Normal input 7	---	---	High-speed counter 1 (phase-B, decrement, or direction input)	---
	08	Normal input 8	---	---	High-speed counter 0 (phase-A, increment, or count input)	---
	09	Normal input 9	---	---	High-speed counter 0 (phase-B, decrement, or direction input)	---
	10	Normal input 10	---	---	High-speed counter 3 (phase-A, increment, or count input)	---
	11	Normal input 11	---	---	High-speed counter 3 (phase-B, decrement, or direction input)	---
CIO 1	00	Normal input 12	Interrupt input 4	Quick-response input 4	High-speed counter 3 (phase-Z/reset)	Pulse output 2: Origin input signal
	01	Normal input 13	Interrupt input 5	Quick-response input 5	---	Pulse output 2: Origin proximity input signal
	02	Normal input 14	Interrupt input 6	Quick-response input 6	---	Pulse output 3: Origin input signal
	03	Normal input 15	Interrupt input 7	Quick-response input 7	---	Pulse output 3: Origin proximity input signal
	04	Normal input 16	---	---	---	---
	05	Normal input 17	---	---	---	---
	06	Normal input 18	---	---	---	---
	07	Normal input 19	---	---	---	---
	08	Normal input 20	---	---	---	---
	09	Normal input 21	---	---	---	---
	10	Normal input 22	---	---	---	---
	11	Normal input 23	---	---	---	---

Note

(1) Set using the MSKS instruction in direct mode or counter mode.

(2) Prohibiting repeated use of input terminal number




The input terminals are used for input interrupts, quick-response inputs, high-speed counters, origin searches and normal inputs. Therefore, do not use the input terminals repeatedly.

A priority is as follows when used repeatedly.

Origin search settings > High-speed counter settings > Input settings


Input Specifications

Normal Inputs

Item	Specification		
	CIO 0.04 to CIO 0.11	CIO 0.00 to CIO 0.03 and CIO 1.00 to CIO 1.03	CIO 1.04 to CIO 1.11
Input voltage	24 VDC $+10\%$ / -15%		
Applicable inputs	2-wire and 3-wire sensors		
Input impedance	3.0 k Ω	3.0 k Ω	4.7 k Ω
Input current	7.5 mA typical	7.5 mA typical	5 mA typical
ON voltage	17.0 VDC min.	17.0 VDC min.	14.4 VDC min.
OFF voltage/current	1 mA max. at 5.0 VDC max.	1 mA max. at 5.0 VDC max.	1 mA max. at 5.0 VDC max.
ON delay	2.5 μ s max.	50 μ s max.	1 ms max.
OFF delay	2.5 μ s max.	50 μ s max.	1 ms max.
Circuit configuration	<p>Input bits: CIO 0.04 to CIO 0.11</p>  <p>Input bits: CIO 0.00 to CIO 0.03, CIO 1.00 to CIO 1.03</p>  <p>Input bits: CIO 1.04 to CIO 1.11</p> 		

Inputs CIO 0.00 to CIO 0.11 and CIO 1.00 to CIO 1.11 can be used not only as normal inputs but also as high-speed counter, interrupt, or quick-response inputs.

Simultaneously ON Inputs-Ambient Temperature Characteristic



High-speed Counter Inputs

	Differential phase mode	Pulse plus direction input mode	Up/down input mode	Increment mode
CIO 0.04, CIO 0.06, CIO 0.08, CIO 0.10	A-phase pulse input	Pulse input	Increment pulse input	Increment pulse input
CIO 0.05, CIO 0.07, CIO 0.09, CIO 0.11	B-phase pulse input	Direction input	Decrement pulse input	Normal input
CIO 0.01, CIO 0.02, CIO 0.03, CIO 1.00	Z-phase pulse input or hardware reset input (Can be used as ordinary inputs when high-speed counter is not being used.)			
Max. count frequency	50 kHz (4×)	100 kHz		

Input Bits for High-speed Counters


	Phase A	Phase B	Phase Z
High-speed counter 0	CIO 0.08	CIO 0.09	CIO 0.03
High-speed counter 1	CIO 0.06	CIO 0.07	CIO 0.02
High-speed counter 2	CIO 0.04	CIO 0.05	CIO 0.01
High-speed counter 3	CIO 0.10	CIO 0.11	CIO 1.00

Input Bits Phase A: CIO 0.04, CIO 0.06, CIO 0.08, CIO 0.10


Phase B: CIO 0.05, CIO 0.07, CIO 0.09, CIO 0.11

Pulse plus direction input mode, Increment mode


Up/down input mode



Differential phase mode



Input bits: CIO 0.00 to CIO 0.03 and CIO 1.00 to CIO 1.03



Interrupt Inputs and Quick-response Inputs

Input bits CIO 0.00 to CIO 0.03 and CIO 1.00 to CIO 1.03 can be used not only as normal inputs but also as interrupt or quick-response inputs depending on the settings in the PLC Setup.


Input bit	Interrupt inputs	Quick-response inputs
CIO 0.00	Interrupt input 0	Quick-response input 0
CIO 0.01	Interrupt input 1	Quick-response input 1
CIO 0.02	Interrupt input 2	Quick-response input 2
CIO 0.03	Interrupt input 3	Quick-response input 3
CIO 1.00	Interrupt input 4	Quick-response input 4
CIO 1.01	Interrupt input 5	Quick-response input 5
CIO 1.02	Interrupt input 6	Quick-response input 6
CIO 1.03	Interrupt input 7	Quick-response input 7

The ON/OFF response time is 8 ms for normal inputs, but it can be changed in the PLC Setup to 0, 0.5, 1, 2, 4, 8, 16, or 32 ms.

Relationship between Built-in Outputs and Terminal Block Arrangement

Terminal Block Arrangement

Lower Terminal Block (Example: Transistor Outputs)



Setting Functions Using Instructions and PLC Setup


Pulses can be output from the normal output terminals in the built-in outputs by executing pulse output instructions. To use the ORIGIN SEARCH (ORG) instruction, all of the pulse output settings in the PLC Setup must be set.

Output terminal block		When the instructions to the right are not executed	When a pulse output instruction (SPED, ACC, PLS2, or ORG) is executed		When the origin search function is set to be used in the PLC Setup, and an origin search is executed by the ORG instruction	When the PWM instruction is executed
Word	Bit	Normal outputs	Fixed duty ratio pulse output			Variable duty ratio pulse output
			CW/CCW	Pulse plus direction	+ When the origin search function is used	
CIO 100	00	Normal output 0	Pulse output 0 (CW)	Pulse output 0 (pulse)	---	---
	01	Normal output 1	Pulse output 0 (CCW)	Pulse output 1 (pulse)	---	---
	02	Normal output 2	Pulse output 1 (CW)	Pulse output 0 (direction)	---	---
	03	Normal output 3	Pulse output 1 (CCW)	Pulse output 1 (direction)	---	---
	04	Normal output 4	Pulse output 2 (CW)	Pulse output 2 (pulse)	---	---
	05	Normal output 5	Pulse output 2 (CCW)	Pulse output 2 (direction)	---	---
	06	Normal output 6	Pulse output 3 (CW)	Pulse output 3 (pulse)	---	---
	07	Normal output 7	Pulse output 3 (CCW)	Pulse output 3 (direction)	---	---



Output terminal block		When the instructions to the right are not executed	When a pulse output instruction (SPED, ACC, PLS2, or ORG) is executed	When the origin search function is set to be used in the PLC Setup, and an origin search is executed by the ORG instruction	When the PWM instruction is executed	
Word	Bit	Normal outputs	Fixed duty ratio pulse output			Variable duty ratio pulse output
			CW/CCW	Pulse plus direction	+ When the origin search function is used	PWM output
CIO 101	00	Normal output 8	---	---	---	PWM output 0
	01	Normal output 9	---	---	---	PWM output 1
	02	Normal output 10	---	---	Origin search 0 (Error counter reset output)	---
	03	Normal output 11	---	---	Origin search 1 (Error counter reset output)	---
	04	Normal output 12	---	---	Origin search 2 (Error counter reset output)	---
	05	Normal output 13	---	---	Origin search 3 (Error counter reset output)	---
	06	Normal output 14	---	---	---	---
	07	Normal output 15	---	---	---	---

Output Specifications

Relay Outputs

Item			Specification
Max. switching capacity			2 A, 250 VAC ($\cos\phi = 1$) 2 A, 24 VDC (4 A/common)
Min. switching capacity			10 mA, 5 VDC
Service life of relay	Electrical	Resistive load	100,000 operations (24 VDC)
		Inductive load	48,000 operations (250 VAC, $\cos\phi = 0.4$)
	Mechanical		20,000,000 operations
ON delay			15 ms max.
OFF delay			15 ms max.
Circuit configuration			





Under the worst conditions, the service life of output contacts is as shown above. The service life of relays is as shown in the following diagram as a guideline.



Transistor Outputs (Sinking or Sourcing)


Normal Outputs

Item	Specification		
	CIO 100.00 to CIO 100.07	CIO 101.00 and CIO 101.01	CIO 101.02 to CIO 101.07
Max. switching capacity	4.5 to 30 VDC, 300 mA/output, 0.9 A/common, 3.6 A/Unit (See notes 2 and 3.)		
Min. switching capacity	4.5 to 30 VDC, 1 mA		
Leakage current	0.1 mA max.		
Residual voltage	0.6 V max.	1.5 V max.	
ON delay	0.1 ms max.		
OFF delay	0.1 ms max.		1 ms max.

Item	Specification		
	CIO 100.00 to CIO 100.07	CIO 101.00 and CIO 101.01	CIO 101.02 to CIO 101.07
Fuse	1 fuse/common (See note 1.)		
Circuit configuration	<ul style="list-style-type: none"> Normal outputs CIO 100.00 to CIO 100.07 (Sinking Outputs)  <ul style="list-style-type: none"> Normal outputs CIO 100.00 to CIO 100.07 (Sourcing Outputs) 		
	<ul style="list-style-type: none"> Normal outputs CIO 101.00, CIO 101.01 and CIO 101.02 to CIO 101.07 (Sinking Outputs)  <ul style="list-style-type: none"> Normal outputs CIO 101.00, CIO 101.01 and CIO 101.02 to CIO 101.07 (Sourcing Outputs) 		


Note

- (1) The fuse cannot be replaced by the user.
- (2) Also do not exceed 0.9 A for the total of CIO 100.00 to CIO 100.03, which are different common.
- (3) If the ambient temperature is maintained below 50°C, up to 0.9 A/common can be used.



Caution Do not connect a load to an output terminal or apply a voltage in excess of the maximum switching capacity.


Pulse Outputs (CIO 100.00 to CIO 100.07)

Item	Specification
Max. switching capacity	30 mA/4.75 to 26.4 VDC
Min. switching capacity	7 mA/4.75 to 26.4 VDC
Max. output frequency	100 kHz
Output waveform	 <p>The OFF and ON refer to the output transistor. The output transistor is ON at level "L".</p>

Note

- (1) The load for the above values is assumed to be the resistance load, and does not take into account the impedance for the connecting cable to the load.
- (2) Due to distortions in pulse waveforms resulting from connecting cable impedance, the pulse widths in actual operation may be smaller than the values shown above.

PWM Outputs (CIO 101.00 and CIO 101.01)

Item	Specification
Max. switching capacity	30 mA/4.75 to 26.4 VDC
Max. output frequency	1 kHz
PWM output accuracy	For ON duty +5%, -0%/1 kHz output.
Output waveform	 <p>The OFF and ON refer to the output transistor. The output transistor is ON at level "L".</p>

2-2-4 Built-in Analog I/O Specifications (XA CPU Units Only)

Analog I/O Terminal Block Arrangement



Pin	Function
1	IN1+
2	IN1-
3	IN2+
4	IN2-
5	IN3+
6	IN3-
7	IN4+
8	IN4-

Pin	Function
9	OUT V1+
10	OUT I1+
11	OUT 1-
12	OUT V2+
13	OUT I2+
14	OUT 2-
15	IN AG*
16	IN AG*

Note

Do not connect the shield.

Analog I/O Specifications

Model		CP1H-XA40DR-A CP1H-XA40DT-D CP1H-XA40DT1-D	
Item		Voltage I/O (See note 1.)	Current I/O (See note 1.)
Analog Input Section	Number of inputs	4 inputs (4 words allocated)	
	Input signal range	0 to 5 V, 1 to 5 V, 0 to 10 V, or –10 to 10 V	0 to 20 mA or 4 to 20 mA
	Max. rated input	±15 V	±30 mA
	External input impedance	1 MΩ min.	Approx. 250 Ω
	Resolution	1/6000 or 1/12000 (full scale) (See note 2.)	
	Overall accuracy	25°C: ±0.3% full scale/0 to 55°C: ±0.6% full scale	25°C: ±0.4% full scale/0 to 55°C: ±0.8% full scale
	A/D conversion data	Full scale for –10 to 10 V: F448 (E890) to 0BB8 (1770) hex Full scale for other ranges: 0000 to 1770 (2EE0) hex	
	Averaging function	Supported (Set for individual inputs in the PLC Setup.)	
	Open-circuit detection function	Supported (Value when disconnected: 8000 hex)	
Analog Output Section	Number of outputs	2 outputs (2 words allocated)	
	Output signal range	0 to 5 V, 1 to 5 V, 0 to 10 V, or –10 to 10 V	0 to 20 mA or 4 to 20 mA (See note 4.)
	Allowable external output load resistance	1 kΩ min.	600 Ω max.
	External output impedance	0.5 Ω max.	---
	Resolution	1/6000 or 1/12000 (full scale) (See note 2.)	
	Overall accuracy	25°C: ±0.4% full scale/0 to 55°C: ±0.8% full scale	
	D/A conversion data	Full scale for –10 to 10 V: F448 (E890) to 0BB8 (1770) hex Full scale for other ranges: 0000 to 1770 (2EE0) hex	
	Conversion time	1 ms/point (See note 3.)	
Isolation method		Photocoupler isolation between analog I/O terminals and internal circuits. No isolation between analog I/O signals.	


Note

- (1) The built-in analog input switch is used for toggling between voltage input and current input. (The default setting at the time of shipping is for voltage input.)
- (2) Switching between 1/6,000 and 1/12,000 resolution is done in the PLC Setup. The same resolution setting is used for all I/O words. It is not possible to set them individually.
- (3) The total conversion time is the total of the conversion times for all the points that are used. It would be 6 ms for 4 analog inputs and 2 analog outputs.
- (4) When the analog current output is within 0 to 20 mA, the accuracy cannot be ensured if below 0.2 mA.

2-2-5 I/O Specifications for Y CPU Units

Relationship between Built-in Inputs and Terminal Block Arrangement

Terminal Block Arrangement



Setting Input Functions in the PLC Setup

Functions for the normal input terminals in the built-in inputs can be individually allocated by making selections in the PLC Setup.

Note High-speed counter terminals are line -river inputs, so they cannot be used as normal inputs.

Input terminal block		Input operation setting			High-speed counter operation setting	Origin search function
Word	Terminal/Bit	Normal inputs	Interrupt inputs (See note.)	Quick-response inputs	High-speed counters 0 to 3 set to be used.	Origin search function for pulse outputs 0 and 1 set to be used.
---	A0	---	---	---	High-speed counter 0 (phase-A, increment, or count input) fixed	---
---	B0	---	---	---	High-speed counter 0 (phase-B, decrement, or direction input) fixed	---
---	Z0	---	---	---	High-speed counter 0 (phase-Z/reset) fixed	Pulse 0 origin input signal (line driver)
---	A1	---	---	---	High-speed counter 1 (phase-A, increment, or count input) fixed	---
---	B1	---	---	---	High-speed counter 1 (phase-B, decrement, or direction input) fixed	---
---	Z1	---	---	---	High-speed counter 1 (phase-Z/reset) fixed	Pulse 1 origin input signal (line driver)
CIO 0	00	Normal input 0	Interrupt input 0	Quick-response input 0	---	Pulse 2 origin proximity input signal
	01	Normal input 1	Interrupt input 1	Quick-response input 1	High-speed counter 2 (phase-Z/reset)	---
	04	Normal input 2	---	---	High-speed counter 2 (phase-A, increment, or count input)	---
	05	Normal input 3	---	---	High-speed counter 2 (phase-B, decrement, or direction input)	---
	10	Normal input 4	---	---	High-speed counter 3 (phase-A, increment, or count input)	---
	11	Normal input 5	---	---	High-speed counter 3 (phase-B, decrement, or direction input)	Pulse 3 origin proximity input signal

Input terminal block		Input operation setting			High-speed counter operation setting	Origin search function
Word	Terminal/Bit	Normal inputs	Interrupt inputs (See note.)	Quick-response inputs	High-speed counters 0 to 3 set to be used.	Origin search function for pulse outputs 0 and 1 set to be used.
CIO 1	00	Normal input 6	Interrupt input 2	Quick-response input 2	High-speed counter 3 (phase-Z/reset)	Pulse 3 origin input signal
	01	Normal input 7	Interrupt input 3	Quick-response input 3	---	Pulse 2 origin input signal
	02	Normal input 8	Interrupt input 4	Quick-response input 4	---	Pulse 1 origin input signal (open collector)
	03	Normal input 9	Interrupt input 5	Quick-response input 5	---	Pulse 0 origin input signal (open collector)
	04	Normal input 10	---	---	---	Pulse 1 origin proximity input signal
	05	Normal input 11	---	---	---	Pulse 0 origin proximity input signal

Note

(1) Set using the MSKS instruction in direct mode or counter mode.






(2) Prohibiting repeated use of input terminal number

The input terminals are used for input interrupts, quick-response inputs, high-speed counters, origin searches and normal inputs. Therefore, do not use the input terminals repeatedly.

A priority is as follows when used repeatedly.

Origin search settings > High-speed counter settings > Input settings.




Input Specifications**Special High-speed Counter Inputs**

Item	High-speed counter inputs, phase A and phase B	High-speed counter inputs, phase Z
Input voltage	RS-422A line-driver, AM26LS31 or equivalent (See note.)	
Applicable inputs	Line-driver inputs	
Input current	10 mA typical	13 mA typical
Circuit configuration		
ON/OFF delay	<ul style="list-style-type: none"> 1-MHz 50% duty ratio pulses, in phase-A or phase-B pulse plus direction input mode, increment mode, or up/down mode  <ul style="list-style-type: none"> Differential phase mode  <p>T₁, T₂, T₃, T₄: 0.5 μs min.</p>	<ul style="list-style-type: none"> Phase Z 

Note

The power supply at the line-driver must 5 V ±5% max.

Normal Inputs

Item	Specification		
	CIO 0.04, CIO 0.05, CIO 0.10, and CIO 0.11	CIO 0.00, CIO 0.01, and CIO 1.00 to CIO 1.03	CIO 1.04 and CIO 1.05
Input voltage	24 VDC +10%/–15%		
Applicable inputs	2-wire and 3-wire sensors		
Input impedance	3.0 k Ω	3.0 k Ω	4.7 k Ω
Input current	7.5 mA typical	7.5 mA typical	5 mA typical
ON voltage	17.0 VDC min.	17.0 VDC min.	14.4 VDC min.
OFF voltage/current	5.0 VDC max., 1 mA max.	5.0 VDC max., 1 mA max.	5.0 VDC max., 1 mA max.
ON delay	2.5 μ s max.	50 μ s max.	1 ms max.
OFF delay	2.5 μ s max.	50 μ s max.	1 ms max.
Circuit configuration	<p>Input bits: CIO 0.04, CIO 0.05, CIO 0.10, CIO 0.11</p>  <p>Input bits: CIO 0.00, CIO 0.01, CIO 1.00 to CIO 1.03</p>  <p>Input bits: CIO 1.04, CIO 1.05</p> 		

High-speed Counter Inputs

	Differential input mode	Pulse plus direction input mode	Up/down input mode	Increment mode
A0+/A0– A1+/A1–	A-phase pulse input	Pulse input	Increment pulse input	Increment pulse input
B0+/B0– B1+/B1–	B-phase pulse input	Direction input	Decrement pulse input	Normal input
Z0+/Z0– Z1+/Z1–	Z-phase pulse input or hardware reset input (Can be used as ordinary inputs when high-speed counter is not being used.)			

	Differential input mode	Pulse plus direction input mode	Up/down input mode	Increment mode
Max. count frequency	500 kHz (4×)	1 MHz		
0.04, 0.10	A-phase pulse input	Pulse input	Increment pulse input	Increment pulse input
0.05, 0.11	B-phase pulse input	Direction input	Decrement pulse input	Normal input
0.01, 1.00	Z-phase pulse input or hardware reset input (Can be used as ordinary inputs when high-speed counter is not being used.)			
Max. count frequency	50 kHz (4×)	100 kHz		

Inputs and Terminal Numbers for High-speed Counters

	Phase A	Phase B	Phase Z
High-speed counter 0	A0+/A0–	B0+/B0–	Z0+/Z0–
High-speed counter 1	A1+/A1–	B1+/B1–	Z0+/Z0–
High-speed counter 2	CIO 0.04	CIO 0.05	CIO 0.01
High-speed counter 3	CIO 0.10	CIO 0.11	CIO 1.00


Input terminals: A0+/A0–/A1+/A1– (Phase A)

B0+/B0–/B1+/B1– (Phase B)


Pulse plus direction input mode

Increment mode


Up/down input mode



Differential phase mode



Input terminals/bits: Z0+/Z1+/CIO 0.01/CIO 1.00



Interrupt Inputs and Quick-response Inputs


The following inputs can be used not only as normal inputs but also as interrupt or quick-response inputs depending on the settings in the PLC Setup.

Input bit	Interrupt inputs	Quick-response inputs
CIO 0.00	Interrupt input 0	Quick-response input 0
CIO 0.01	Interrupt input 1	Quick-response input 1
CIO 1.00	Interrupt input 2	Quick-response input 2
CIO 1.01	Interrupt input 3	Quick-response input 3
CIO 1.02	Interrupt input 4	Quick-response input 4
CIO 1.03	Interrupt input 5	Quick-response input 5

The ON/OFF response time is 8 ms for normal inputs, but it can be changed in the PLC Setup to 0, 0.5, 1, 2, 4, 8, 16, or 32 ms.

Relationship between Built-in Outputs and Terminal Block Arrangement

Terminal Block Arrangement



Note 24-VDC input terminals can be used as the power supply terminals for CIO100.04 to CIO100.07. Supply the power of 24-VDC when using CIO100.04 to CIO100.07.

Setting Output Functions by Instructions and PLC Setup

Pulses can be output from the normal output terminals in the built-in outputs by executing pulse output instructions.


To use the ORIGIN SEARCH (ORG) instruction, all of the pulse output settings in the PLC Setup must be set.

Note Special pulse output terminals are line-driver outputs, so they cannot be used as normal outputs.

Address			When the instructions to the right are not executed	When a pulse output instruction (SPED, ACC, PLS2, or ORG) is executed	When the origin search function is set to be used in the PLC Setup, and an origin search is executed by the ORG instruction	When the PWM instruction is executed	
Terminal	Word	Bit	Normal output	Fixed duty ratio pulse output			Variable duty ratio pulse output
				CW/CCW	Pulse plus direction	When the origin search function is used	PWM output
CW0		00	Disabled	Pulse output 0 (CW) fixed	Pulse output 0 (pulse) fixed	---	---
CCW0		01	Disabled	Pulse output 0 (CCW) fixed	Pulse output 1 (pulse) fixed	---	---
CW1		02	Disabled	Pulse output 1 (CW) fixed	Pulse output 0 (direction) fixed	---	---
CCW1		03	Disabled	Pulse output 1 (CCW) fixed	Pulse output 1 (direction) fixed	---	---
	CIO 100	04	CIO 100.04	Pulse output 2 (CW)	Pulse output 2 (pulse)	---	---
		05	CIO 100.05	Pulse output 2 (CCW)	Pulse output 2 (direction)	---	---
		06	CIO 100.06	Pulse output 3 (CW)	Pulse output 3 (pulse)	---	---
		07	CIO 100.07	Pulse output 3 (CCW)	Pulse output 3 (direction)	---	---
	CIO 101	00	CIO 101.00	---	---	Origin search 2 (Error counter reset output)	PWM output 0
		01	CIO 101.01	---	---	Origin search 3 (Error counter reset output)	PWM output 1
		02	CIO 101.02	---	---	Origin search 0 (Error counter reset output)	---
		03	CIO 101.03	---	---	Origin search 1 (Error counter reset output)	---



Output Specifications

Special Pulse Outputs

Item	Specification
Special pulse outputs	Line-driver output, AM26LS31 or equivalent
Max. output current	20 mA
Max. output frequency	1 MHz
Circuit configuration	


Caution Connect a load of 20 mA or less to the output load. Connecting a load exceeding 20 mA may cause the Unit to malfunction.

Normal Outputs

Item	Specification		
	CIO 100.04 to CIO 100.07	CIO 101.00 and CIO 101.01	CIO 101.02 and CIO 101.03
Max. switching capacity	4.5 to 30 VDC, 300 mA/output, 0.9 A/common, 1.8 A/Unit (See note 2.)		
Min. switching capacity	4.5 to 30 VDC, 1 mA		
Leakage current	0.1 mA max.		
Residual voltage	0.6 V max.	1.5 V max.	
ON delay	0.1 ms max.		
OFF delay	0.1 ms max.		1 ms max.
Fuse	1 fuse/common (See note 1.)		
Circuit configuration	<ul style="list-style-type: none"> Normal outputs CIO 100.04 to CIO 100.07 (Sinking Outputs) 	<ul style="list-style-type: none"> Normal outputs CIO 101.00 to CIO 101.03 (Sinking Outputs) 	

Note (1) The fuse cannot be replaced by user.

- (2) If the ambient temperature is maintained below 50°C, up to 0.9 A/common can be used.



Caution Do not connect a load to an output terminal or apply a voltage in excess of the maximum switching capacity.

Pulse Outputs (CIO 100.04 to CIO 100.07)

Item	Specification
Max. switching capacity	30 mA/4.75 to 26.4 VDC
Min. switching capacity	7 mA/4.75 to 26.4 VDC
Max. output frequency	100 kHz
Output waveform	<p>The diagram shows a pulse waveform with a high level labeled 'OFF 90%' and a low level labeled 'ON 10%'. The pulse width (ON time) is indicated as 4 μs min. and the period (time between pulses) is indicated as 2 μs min.</p>


- Note**
- (1) The load for the above values is assumed to be the resistance load, and does not take into account the impedance for the connecting cable to the load.
 - (2) Due to distortions in pulse waveforms resulting from connecting cable impedance, the pulse widths in actual operation may be smaller than the values shown above.

PWM Outputs (CIO 101.00 and CIO 101.01)

Item	Specification
Max. switching capacity	30 mA/4.75 to 26.4 VDC
Max. output frequency	1 kHz
PWM output accuracy	For ON duty +5%, -0%/1 kHz output.
Output waveform	<p>The diagram shows a PWM waveform with a high level labeled 'OFF' and a low level labeled 'ON'. The pulse width is labeled t_{ON} and the period is labeled T. The formula for ON duty is given as $\text{ON duty} = \frac{t_{ON}}{T} \times 100\%$.</p>

2-2-6 CP-series Expansion I/O Unit I/O Specifications


Input Specifications (CP1W-40EDR/40EDT/40EDT1/20EDR1/20EDT/20EDT1/8ED)

Item	Specification
Input voltage	24 VDC $+10\%/-15\%$
Input impedance	4.7 k Ω
Input current	5 mA typical
ON voltage	14.4 VDC min.
OFF voltage	5.0 VDC max.
ON delay	0 to 32 ms max. Default: 8 ms (See note 1.)
OFF delay	0 to 32 ms max. Default: 8 ms (See note 1.)
Circuit configuration	


- Note**
- (1) This setting can be changed to 0, 0.5, 1/2, 4, 8, 16, or 32 ms in the PLC Setup.
 - (2) Do not apply voltage in excess of the rated voltage to the input terminal

Output Specifications


Relay Outputs (CP1W-40EDR/32ER/20EDR1/16ER/8ER)

Item			Specification
Max. switching capacity			2 A, 250 VAC ($\cos\phi = 1$), 2 A, 24 VDC (4 A/common)
Min. switching capacity			5 VDC, 10 mA
Service life of relay (See note.)	Electrical	Resistive load	150,000 operations (24 VDC)
		Inductive load	100,000 operations (240 VAC, $\cos\phi = 0.4$)
	Mechanical		20,000,000 operations
ON delay			15 ms max.
OFF delay			15 ms max.
Circuit configuration			


- Note** (1) Under the worst conditions, the service life of output contacts is as shown above. The service life of relays is as shown in the following diagram as a guideline.



- (2) With the CP1W-32ER/CP1W-16ER, the load current is restricted depending on the ambient temperature. Design the system considering the load current based on the following graph.




- (3) CP1W-32ER's maximum number of simultaneously ON output points is 24 (75%). Design the system considering the simultaneously ON points and load current based on the following curve.



■ Output Load Current and Ambient Temperature (CP1W-32ER/16ER)

With the CP1W-32ER/16ER, the load current is restricted depending on the ambient temperature. Design the system considering the load current based on the following graph.




Transistor Output (Sinking or Sourcing)

Item	Specification				
	CP1W-40EDT CP1W-40EDT1	CP1W-32ET CP1W-32ET1	CP1W-20EDT CP1W-20EDT1	CP1W-16ET CP1W-16ET1	CP1W-8ET CP1W-8ET1
Max. switching capacity (See note2.)	4.5 to 30 VDC 0.3 A/output	4.5 to 30 VDC 0.3 A/output	24 VDC ^{10%/-5%} 0.3 A/output	4.5 to 30 VDC 0.3 A/output	<ul style="list-style-type: none"> • OUT00/01 4.5 to 30 VDC, 0.2 A/output • OUT02 to 07 4.5 to 30 VDC, 0.3 A/output
	0.9 A/common 3.6 A/Unit	0.9 A/common 7.2 A/Unit	0.9 A/common 1.8 A/Unit	0.9 A/common 3.6 A/Unit	0.9 A/common 1.8 A/Unit
Leakage current	0.1 mA max.	0.1 mA max.	0.1 mA max.	0.1 mA max.	0.1 mA max.
Residual voltage	1.5 V max.	1.5 V max.	1.5 V max.	1.5 V max.	1.5 V max.
ON delay	0.1 ms max.	0.1 ms max.	0.1 ms.	0.1 ms max.	0.1 ms max.
OFF delay	1 ms max. 24 VDC ^{+10%/-5%} 5 to 300 mA	1 ms max. 24 VDC ^{+10%/-5%} 5 to 300 mA	1 ms max. 24 VDC ^{+10%/-5%} 5 to 300 mA	1 ms max. 24 VDC ^{+10%/-5%} 5 to 300 mA	1 ms max. 24 VDC ^{+10%/-5%} 5 to 300 mA
Max. number of Simultaneously ON Points of Output	16 pts (100%)	24 pts (75%)	8 pts (100%)	16 pts (100%)	8 pts (100%)
Fuse (See note 1.)	1 fuse/common				
Circuit configuration	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Sinking Outputs</p> </div> <div style="text-align: center;"> <p>Sourcing Outputs</p> </div> </div>				

Note (1) The fuse cannot be replaced by the user.

- (2) If the ambient temperature is maintained below 50°C, up to 0.9 A/common can be used.




Caution Do not connect a load to an output terminal or apply a voltage in excess of the maximum switching capacity.

2-3 CP1H CPU Unit Operation

2-3-1 Overview of CPU Unit Configuration

The CP1H CPU Unit memory consists of the following blocks.



Note:

1. Y models. Two 1-MHz high-speed counter inputs are also provided separately on special terminals.
2. Y models. Two 1-MHz pulse inputs are also provided separately on special terminals.
3. XA models only.

- (1)
 - Data is backed up from RAM to the built-in flash memory when changes are made, e.g., from the CX-Programmer.
 - When the power supply is turned ON, data is transferred from the built-in flash memory to RAM.
- (2)
 - A CX-Programmer operation can be used to transfer DM Area initial values from RAM to the built-in flash memory.
 - The PLC Setup can be set so that DM Area initial values are transferred from the built-in flash memory to RAM when the power supply is turned ON.

- (3)
 - CX-Programmer operations can be used to transfer data from RAM to the Memory Cassette or from the built-in flash memory to the Memory Cassette.
 - When the power supply is turned ON, data is transferred from the Memory Cassette to the built-in flash memory.

User Program

The user program consists of up to 288 tasks, including interrupt tasks. Each task is programmed from the CX-Programmer and then transferred to the CPU Unit.

There are two types of tasks: cyclic tasks and interrupt tasks. Cyclic tasks are executed once each cycle and interrupt tasks are executed only when the interrupt conditions are met. There can be up to 32 cyclic tasks and up to 256 interrupt tasks. Cyclic tasks are executed in the order of the task numbers.

Instructions programmed in the tasks are executed in order from the first instruction and then I/O memory is refreshed. When all cyclic tasks have been executed, I/O refreshing with PLC Units is performed and then the cyclic tasks are executed again starting from the one with the lowest task number. This is called the cyclic scan method.

I/O Memory

The I/O memory area is a RAM area read and written by the user. Some parts of the I/O memory are cleared when the power is interrupted. Other parts are maintained. There are parts that used for data exchange with PLC Units and parts that are used internally.

There are two ways to refresh the parts of I/O memory used for data exchange with PLC Units: Once each program execution cycle and immediately when needed when executing specific instructions.

Parameter Area

In addition to the I/O memory used as instructions operands by the user, there is also a separate memory area that can be manipulated only from the CX-Programmer. This area, called the parameter area, contains the following.

- PLC Setup
- Routing tables (when CJ-series Units are used)
- Unit Setups for CPU Bus Units


PLC Setup

The PLC Setup contains configuration parameters that can be set by the user to define the basic specifications of the CPU Unit. Included are serial port settings, a minimum cycle time setting, and other parameters. For details, refer to the *CX-Programmer Operation Manual*.

Routing Tables

Tables specifying the communications paths from the Communications Units on the local PLC to remote PLCs connected on other networks must be registered in all the CPU Units in network PLCs to send and receive data between networks. These tables are called the routing tables. The routing tables consist of the relay network table and local network table.

Routing tables are created from the CX-Programmer or Support Software for Communications Units (e.g., CX-Integrator) and then transferred to each CPU Unit.



Remote Network Table

The remote network tables lists the node number and network address of the first relay node that must be passed through to reach any remote network to which the PLC is not directly connected. Once the routing tables have been registered, any remote network can be reached by passing through relay nodes.

Local Network Table


The local network table contains the unit number and network address of all Communications Units that are part of the local PLC.

CPU Bus Unit Setup Area

The CPU Bus Unit Setup Area contains the system settings for CPU Bus Unit controlled by the CPU Unit. The specific settings that are available depend on the CPU Bus Unit that is being used. Refer to the operation manual for the CPU Bus Unit for details.

This area cannot be directly accessed by the user in the same way as I/O memory. All settings are made from the CX-Programmer. Refer to the *CX-Programmer Operation Manual* for setting procedures.

CX-Programmer



Built-in Flash Memory

Flash memory is built into the CP1H CPU Units. Data in the following areas is automatically backed up to the flash memory whenever it is written in any way other than by instructions in the user program, e.g., when the CX-Programmer or PT is used to transfer or edit data, edit the program online, or transfer data from a Memory Cassette.

- User program area
- Parameter area (PLC Setup, routing tables, and unit setups for CJ-series CPU Bus Units)

The next time the power supply is turned ON, the data in the built-in flash memory is automatically transferred to user memory (i.e., the user program area and parameter area).

It is also possible to save data from data areas in I/O memory in the built-in flash memory using operations from the CX-Programmer.

The symbol table, comment file, and program index file can be stored in the comment memory in flash memory. When the program is transferred from the CX-Programmer to the CPU Unit, function block program information is also stored automatically in flash memory.

Note The BKUP indicator on the front of the CPU Unit will light whenever the built-in flash memory is being written or the Memory Cassette is being accessed. Never turn OFF the power supply to the CPU Unit when the BKUP indicator is lit.

Memory Cassette


Memory Cassettes can be used as required in system operation and maintenance. For example, they can be used to save programs, data memory contents, PLC Setup data, or I/O comments from the CX-Programmer. The contents of a Memory Cassette can also be automatically transferred if desired.

2-3-2 Flash Memory Data Transfers

Built-in Flash Memory

Writing to Flash Memory


Data	Transfer method
User program and parameter data	This data is automatically transferred from RAM to flash memory when a project is transferred from the CX-Programmer, when the data is written to RAM from a PT or other external device, or when the data is transferred from a Memory Cassette.
DM Area data	This data is transferred to flash memory only when the transfer is specified from the CX-Programmer.
Comment memory data	This data is written to flash memory when a project is transferred from the CX-Programmer and transferring comment memory is specified.
Function block source data	This data is written to flash memory when a project containing one or more function blocks is transferred from the CX-Programmer.



FB = Function block

Reading from Flash Memory


Data	Read method
User program and parameter data	This data is automatically read to RAM when power is turned ON.
DM Area data	Reading this data when power is turned ON can be enabled or disabled in the PLC Setup.
Comment memory data	When the project is transferred from the CX-Programmer, comment memory can be specified as a destination to transfer the comment memory data to built-in flash memory.
Function block source data	When a project that contains function blocks is transferred from the CX-Programmer, the function block source data is transferred to built-in flash memory.



2-3-3 Memory Cassette Data Transfers


Writing to a Memory Cassette

Data	Method	Source
User program and parameter data	Data is written to a Memory Cassette using write operations from the CX-Programmer.	Data in the built-in flash memory is written to the Memory Cassette.
Comment memory and function block source data		Either of both of the following can be transferred to the Memory Cassette.
DM Area data		<ul style="list-style-type: none"> • Data in the built-in flash memory. • Data in RAM.



Reading from a Memory Cassette


Data	Method	Destination
User program and parameter data	This data is transferred by turning SW2 on the DIP switch to ON and turning ON the power supply.	Data in the Memory Cassette is transferred to RAM and then automatically transferred to the built-in flash memory.
Comment memory and function block source data		Data is transferred to the built-in flash memory.
DM Area data		DM Area data originally from the built-in flash memory is transferred back to the flash memory and DM Area data originally from RAM is transferred to RAM.



2-4 CPU Unit Operation

2-4-1 General Flow

The following flowchart shows the overall operation of the CPU Unit. First the user program is executed and then I/O is refreshed and peripheral servicing is performed. These processes are then repeated in cyclic fashion.



2-4-2 I/O Refreshing and Peripheral Servicing

I/O Refreshing

I/O refreshing involves cyclically transferring data with external devices using preset words in memory. I/O refreshing includes the following:

- Refreshing between CPU Unit built-in I/O, CP-series Expansion Units, and CP-series Expansion I/O Units and I/O words in the CIO Area
- Refreshing between CJ-series Special I/O Units and CJ-series CPU Bus Units and the words allocated to these in the CIO Area (and for CPU Bus Units, words allocated in the DM Area)

All I/O refreshing is performed in the same cycle (i.e., time slicing is not used). I/O refreshing is always performed after program execution.

Units			Max. data exchange	Data exchange area
CPU Unit built-in I/O			2 input words 2 output words	I/O Bit Area
CP-series Expansion Units and Expansion I/O Units			Fixed depending on Units	I/O Bit Area
CJ-series Special I/O Units	Words allocated in CIO Area		10 words/Unit (Depends on the Unit.)	Special I/O Unit Area
	Unit- specific data	CompoBus/S Master Unit	Depends on the Unit.	Remote I/O Communications Area
CJ-series CPU Bus Units	Words allocated in CIO Area		25 words/Unit	CPU Bus Unit Area in CIO Area
	Words allocated in DM Area		100 words/Unit	CPU Bus Unit Area in DM Area
	Unit-specific data	Controller Link Unit	Depends on the Unit.	Words set for data links (for either fixed or user-set allocations)
		DeviceNet Unit	Depends on the Unit.	Words set for remote I/O communications (for either fixed or user-set allocations)
		Serial Communications Unit	Depends on the protocol macros.	Communications data set for protocol macros
		Ethernet Unit	Depends on the Unit.	Communications data for socket services initiated by specific control bit operations.

Peripheral Servicing

Peripheral servicing involves servicing non-scheduled events for external devices. This includes both events from external devices and service requests to external devices.

Most peripheral servicing involves FINS commands. The specific amount of time set in the system is allocated to each type of servicing and executed every cycle. If all servicing cannot be completed within the allocated time, the remaining servicing is performed the next cycle.

Service	Description
Event servicing for CJ-series Special I/O Units	<ul style="list-style-type: none"> • Non-scheduled servicing for FINS commands from CJ-series Special I/O Units and CJ-series CPU Bus Units • Non-scheduled servicing for FINS commands from the CPU Unit to the above Units.
Event servicing for CJ-series CPU Bus Units	
USB port servicing	<ul style="list-style-type: none"> • Non-scheduled servicing for FINS or Host Link commands received via a USB port or serial port from the CX-Programmer, PTs, or host computers (e.g., requests for program transfers, monitoring, forced-set/reset operations, or online editing) • Non-scheduled servicing from the CPU Unit transmitted from a serial port (non-solicited communications)
Communications port servicing	

Service	Description
Communications port servicing	<ul style="list-style-type: none"> • Servicing to execute network communications or serial communications for the SEND, RECV, CMND or PMCR instructions using communications ports 0 to 7 (internal logical ports) • Servicing to execute background execution using communications ports 0 to 7 (internal logical ports)
Built-in flash memory access servicing	• Read/write processing for built-in flash memory
Memory Cassette access servicing	• Read/write processing for a Memory Cassette

Note

- (1) CJ-series Special I/O Unit, CJ-series CPU Bus Unit, USB port, serial port, and communications port servicing is allocated 4% of the previous cycle time by default (the default can be changed) for each service. If servicing is separated over many cycles, delaying completion of the servicing, set the same allocated time (same time for all services) rather than a percentage under execute time settings in the PLC Setup.
- (2) An error will be occurred if the cycle time is too long.
 Modify the CX-Programmer's response monitoring time longer according to the following method.
 Start the CX-Programmer. Select **Change Model** from the **PLC** Menu. The **Change PLC** Dialog Box will be displayed. Click the **Settings** Button on the right side of **Network Type**. The **Network Settings [USB]** Dialog Box will be displayed. Click the **Network** Tab and increase the value in **Response Timeout(s)**.

2-4-3 I/O Refresh Methods


I/O for CPU Unit built-in I/O and I/O on CP-series Expansion Units and Expansion I/O Units is performed at the following times.

1,2,3...

1. Cyclic refresh period
2. When instructions with an immediate refresh variation are executed
3. When IORF(097) is executed


Cyclic Refreshing

I/O is refreshed after all the instructions in executable tasks have been executed.



Immediate Refreshing


When the immediate refreshing variation of an instruction is specified and the instruction's operand is an input bit or word in the Built-in I/O Area, the word containing the bit or the word itself will be refreshed.

**Note**

- (1) Immediate refreshing is possible only for the Built-in I/O Area. Use IORF(097) for I/O on CP-series Expansion Units and Expansion I/O Units.
- (2) Refreshing Range
 - Bit Operands
The ON/OFF status of the 16 I/O points allocated to the word containing the specified bit will be refreshed.
 - Word Operands
The ON/OFF status of the 16 I/O points allocated to the specified word will be refreshed.
- (3) Refresh Timing
 - Input or source operands are read just before the instruction is executed.
 - Output or destination (results) operands are written just after the instruction is executed.
- (4) Using instructions with the immediate refresh option, instruction execution time will be increased, increasing the overall cycle time. Be sure to confirm that this will not adversely affect system operation.

IORF(097) Refreshing

When IORF(097) (I/O REFRESH) is executed, the I/O bits in the specified range of words are refreshed. IORF(097) can be used for CP-Series Expansion Units, CP-series Expansion I/O Units, and CJ-series Special I/O Units.



If high-speed response is required from input to output, execute IORF(097) before and after the relevant instructions.

Note

IORF(097) has a relatively long execution time which increases with the number of words being refreshed. Be sure to consider the affect of this time on the overall cycle time. Refer to the *CP Series CP1H Programmable Controllers Programming Manual* for instruction execution times.

2-4-4 Initialization at Startup

The following initializing processes will be performed once each time the power is turned ON.

- Confirm mounted Units and I/O allocations.
- Clear the non-holding areas of I/O memory according to the status of the IOM Hold Bit. (See note 1.)
- Clear forced status according to the status of the Forced Status Hold Bit. (See note 2.)
- Automatically transfer data from the Memory Cassette if one is mounted and automatic transfer at startup is specified.
- Perform self-diagnosis (user memory check).
- Restore the user program. (See note 3.)

Note

- (1) The I/O memory is held or cleared according to the status of the IOM Host Bit and the setting for IOM Hold Bit Status at Startup in the PLC Setup (read only when power is turned ON).

Auxiliary bit		IOM Hold Bit (A500.12)	
PLC Setup setting		Clear (OFF)	Hold (ON)
IOM Hold Bit Status at Startup	Clear (OFF)	At power ON: Clear At mode change: Clear	At power ON: Clear At mode change: Hold
	Hold (ON)		At power ON: Hold At mode change: Hold

Note When the mode is changed between PROGRAMMING mode and RUN or MONITOR mode, I/O memory initialization is according to the status of the IOM Hold Bit at that time.

- (2) The forced status held or cleared according to the status of the Force Status Hold Bit and the setting for Forced Status Hold Bit Status at Startup in the PLC Setup (read only when power is turned ON).

Auxiliary bit		Forced Status Hold Bit (A500.13)	
PLC Setup setting		Clear (OFF)	Hold (ON)
Forced Status Hold Bit Status at Startup	Clear (OFF)	At power ON: Clear At mode change: Clear	At power ON: Clear At mode change: Hold
	Hold (ON)		At power ON: Hold At mode change: Hold

Note When the mode is changed between PROGRAMMING mode and RUN or MONITOR mode, forced status initialization is according to the status of the Forced Status Hold Bit at that time.

- (3) User program recovery is performed if online editing is performed but the power supply to the PLC is turned OFF before the CPU Unit can complete backup processing. The BKUP indicator will light during backup processing.

2-5 CPU Unit Operating Modes

2-5-1 Operating Modes

The CPU Unit has three operating modes that control the entire user program and are common to all tasks.

PROGRAM: Programs are not executed and preparations, such as initializing the PLC Setup and other settings, transferring programs, checking programs, force-setting and force-resetting can be executed prior to program execution.

MONITOR: Programs are executed, but some operations, such as online editing, forced-set/reset, and changes to present values in I/O memory, are enabled for trial operation and other adjustments.

RUN: Programs are executed and some operations are disabled.

2-5-2 Status and Operations in Each Operating Mode

The following table lists status and operations for each mode.

Operation		PROGRAM mode	RUN mode	MONITOR mode
Program execution		Stopped	Executed	Executed
I/O refreshing		Executed	Executed	Executed
External I/O status		OFF	According to program	According to program
I/O memory	Non-holding memory	Cleared	According to program	According to program
	Holding memory	Held		
CX-Programmer operations	I/O memory monitoring		OK	OK
	Program monitoring		OK	OK
	Program transfers	From CPU Unit	OK	OK
		To CPU Unit	X	X
	Checking program		X	X
	Setting PLC Setup		X	X
	Changing program		X	OK
	Force-setting/resetting		X	OK
	Changing timer/counter SV		X	OK
	Changing timer/counter PV		X	OK
	Change I/O memory PV		X	OK

Note The following table shows the relationship of operating modes to tasks.

Mode	Cyclic task status	Interrupt task status
PROGRAM	Disabled status (INI)	Stopped
RUN	<ul style="list-style-type: none"> Any task that has not yet been executed, will be in disabled status (INI). A task will go to READY status if the task is set to go to READY status at start-up or the TASK ON (TKON) instruction has been executed for it. A task in READY status will be executed (RUN status) when it obtains the right to execute. A status will go to Standby status (WAIT) if a READY task is put into Standby status by a TASK OFF (TKOF) instruction. 	Executed if interrupt condition is met.
MONITOR		

2-5-3 Operating Mode Changes and I/O Memory

Operating Mode Changes and I/O Memory

Mode Changes	Non-holding areas	Holding Areas
	<ul style="list-style-type: none"> I/O bits Data Link bits CPU Bus Unit bits Special I/O Unit bits Work bits Timer PV/Completion Flags Index Registers Data Registers Task Flags Auxiliary Area bits/words are holding or non-holding depending on the address.	<ul style="list-style-type: none"> HR Area DM Area Counter PV and Completion Flags Auxiliary Area bits/words are holding or non-holding depending on the address.
RUN or MONITOR to PROGRAM	Cleared (See note 1.)	Held
PROGRAM to RUN or MONITOR	Cleared (See note 1.)	Held
RUN to MONITOR or MONITOR to RUN	Held (See note 2.)	Held


- Note**
1. The following processing is performed if the I/O Memory Hold Bit is ON. Outputs from Output Units will be turned OFF when operation stops even if I/O bit status is held in the CPU Unit.
 2. The cycle time will increase by approximately 10 ms when the operating mode is changed from MONITOR to RUN mode. This will not, however, cause an error for exceeding the maximum cycle time limit.

I/O Memory Hold Bit status (A500.12)	I/O Memory			Output bits allocated to Output Units		
	Mode changed between PROGRAM and RUN/MONITOR	Operation stopped		Mode changed between PROGRAM and RUN/MONITOR	Operation stopped	
		Fatal error other than FALS	FALS executed		Fatal error other than FALS	FALS executed
OFF	Cleared	Cleared	Held	OFF	OFF	OFF
ON	Held	Held	Held	Held	OFF	OFF

Note Refer to *SECTION 4 I/O Memory Allocation*.


2-5-4 Startup Mode Setting

This setting in the PLC Setup determines the operating mode that will be used by the CPU Unit when the power supply is turned ON.



PLC Setup

Name	Description	Settings	Default
Startup Mode	Specifies the CPU Unit operating mode at startup	<ul style="list-style-type: none"> Program Monitor Run Use programming console 	Use programming console



Note A Programming Console cannot be connected to a CP1H CPU Unit. If *Use programming console* is set, the CPU Unit will start in RUN mode.

2-6 Power OFF Operation

2-6-1 Overview

The following processing is performed when CPU Unit power is turned OFF. Power OFF processing will be performed if the power supply voltage falls below the specified value while the CPU Unit is in RUN or MONITOR mode.


- 1,2,3...**
1. The CPU Unit will stop.
 2. Outputs from all Output Units will be turned OFF.

- Note**
- (1) All outputs will turn OFF despite the status of the I/O Memory Hold Bit or I/O Memory Hold Bit at power ON settings in the PLC Setup.
 - (2) AC Power
85% of the rated voltage: 85 V or less for a 100 to 240 V AC system
 - (3) DC Power
90% of rated voltage: 20.4 V DC or less

The following processing will be performed if power drops only momentarily (momentary power interruption).


- 1,2,3...**
1. The system will continue to run unconditionally if the momentary power interruption lasts less than 10 ms for AC power or 2 ms for DC power, i.e., the time it takes the rated voltage at 85% or less to return to 85% or higher is less than 10 ms for AC power or the time it takes the rated voltage at 90% or less to return to 90% or higher is less than 2 ms for DC power.

2. A momentary power interruption that lasts more than 10 ms for AC power or more than 2 ms for DC power may or may not be detected.



The following timing chart shows the CPU Unit power OFF operation in more detail.

Power OFF Timing Chart



Power OFF detection time:

The time from when the power supply voltages drops to 85% or less of the rated voltage for AC power or 90% for DC power until the power OFF condition is detected.

Holding time for 5 V internal power supply after power OFF detection:

The maximum time that the 5 V internal power supply voltage will be maintained after the power OFF condition is detected. The holding time is fixed at 1 ms.

Description of Operation

Power OFF will be detected if the 100 to 240 V AC power supply falls below 85% of the rated voltage or the DC power supply falls below 90% of the rated voltage for the power OFF detection time (10 ms minimum for AC power and 2 ms minimum for DC power). The CPU reset signal will turn ON while the internal power supply is being held and the CPU Unit will be reset.

Note The CP1H CPU Unit cannot use the power OFF interrupt task and cannot set the power OFF detection delay time.


2-6-2 Instruction Execution for Power Interruptions

If power is interrupted and the interruption is detected when the CPU Unit is operating in RUN or MONITOR mode, the instruction currently being executed will be completed and then the CPU Unit will be reset.

2-7 Computing the Cycle Time

2-7-1 CPU Unit Operation Flowchart

The CPU Unit processes data in repeating cycles from the overseeing processing up to peripheral servicing as shown in the following diagram.



2-7-2 Cycle Time Overview

The cycle time depends on the following conditions.

- Type and number of instructions in the user program (in all cyclic tasks that are executed during a cycle, and within interrupt tasks for which the execution conditions have been satisfied)
- Type and number of CP-series Expansion Units and Expansion I/O Units
- Type and number of CJ-series Special I/O Units and CJ-series CPU Bus Units
- Specific servicing for the following Special I/O Units
 - Data link refreshing and the number of data link words for Controller Link Units
 - Remote I/O for DeviceNet and the number of remote I/O words
 - Use of protocol macros and the largest communications message
 - Socket services for specific control bits for Ethernet Units and the number of send/receive words
- Fixed cycle time setting in the PLC Setup
- Event servicing for CJ-series Special I/O Units, CJ-series CPU Bus Units, and communications ports
- Use of USB and serial ports
- Fixed peripheral servicing time in the PLC Setup

- Note**
1. The cycle time is not affected by the number of tasks that are used in the user program. The tasks that affect the cycle time are those cyclic tasks that are READY in the cycle.
 2. When the mode is switched from MONITOR mode to RUN mode, the cycle time will be extended by 10 ms (this will not, however, take the cycle time over its limit).

The cycle time is the total time required for the PLC to perform the five operations given in the following tables.

$$\text{Cycle time} = (1) + (2) + (3) + (4) + (5)$$

1: Overseeing

Details	Processing time and fluctuation cause
Checks the I/O bus and user program memory, checks for battery errors, etc.	0.7 ms

2: Program Execution

Details	Processing time and fluctuation cause
Executes the user program, and calculates the total time taken for the instructions to execute the program.	Total instruction execution time

3: Cycle Time Calculation

Details	Processing time and fluctuation cause
Waits for the specified cycle time to elapse when a minimum (fixed) cycle time has been set in the PLC Setup. Calculates the cycle time.	When the cycle time is not fixed, the time for step 3 is approximately 0. When the cycle time is fixed, the time for step 3 is the preset fixed cycle time minus the actual cycle time ((1) + (2) + (4) + (5)).

4: I/O Refreshing

Details			Processing time and fluctuation cause
CPU Unit built-in I/O and I/O on CP-series Expansion Units and Expansion I/O Units	Outputs from the CPU Unit to the actual outputs are refreshed first for each Unit, and then inputs.		I/O refresh time for each Unit multiplied by the number of Units used.
CJ-series Special I/O Units	Words allocated in CIO Area		I/O refresh time for each Unit multiplied by the number of Units used.
	Unit- specific data	Example: CompoBus/S remote I/O	
CJ-series CPU Bus Units	Words allocated in CIO and DM Areas		I/O refresh time for each Unit multiplied by the number of Units used.
	Unit- specific data	Examples: <ul style="list-style-type: none"> • Data links for Controller Link Units • DeviceNet remote I/O • Send/receive data for protocol macros • Socket services for specific control bits for Ethernet Units 	


5: Peripheral Servicing

Details		Processing time and fluctuation cause
Services events for CJ-series Special I/O Units.	Note Peripheral servicing does not include I/O refreshing, Services events for CJ-series CPU Bus Units. Note Peripheral servicing does not include I/O refreshing.	If a uniform peripheral servicing time hasn't been set in the PLC Setup for this servicing, 4% of the previous cycle's cycle time (calculated in step (3)) will be allowed for peripheral servicing. If a uniform peripheral servicing time has been set in the PLC Setup, servicing will be performed for the set time. Servicing will be performed for at least 0.1 ms, however, whether the peripheral servicing time is set or not. If no Units are mounted, the servicing time is 0 ms.
Services USB port.		
Services serial ports		If a uniform peripheral servicing time hasn't been set in the PLC Setup for this servicing, 4% of the previous cycle's cycle time (calculated in step (3)) will be allowed for peripheral servicing. If a uniform peripheral servicing time has been set in the PLC Setup, servicing will be performed for the set time. Servicing will be performed for at least 0.1 ms, however, whether the peripheral servicing time is set or not. If the ports are not connected, the servicing time is 0 ms.
Services communications ports.		If a uniform peripheral servicing time hasn't been set in the PLC Setup for this servicing, 4% of the previous cycle's cycle time (calculated in step (3)) will be allowed for peripheral servicing. If a uniform peripheral servicing time has been set in the PLC Setup, servicing will be performed for the set time. Servicing will be performed for at least 0.1 ms, however, whether the peripheral servicing time is set or not. If no communications ports are used, the servicing time is 0 ms.
Services built-in flash memory access.	Serves Memory Cassette access.	If a uniform peripheral servicing time hasn't been set in the PLC Setup for this servicing, 4% of the previous cycle's cycle time (calculated in step (3)) will be allowed for peripheral servicing. If a uniform peripheral servicing time has been set in the PLC Setup, servicing will be performed for the set time. Servicing will be performed for at least 0.1 ms, however, whether the peripheral servicing time is set or not. If there is no access, the servicing time is 0 ms.


2-7-3 Functions Related to the Cycle Time

Minimum Cycle Time

Set the minimum cycle time to a non-zero value to eliminate inconsistencies in I/O responses. A minimum cycle time can be set in the PLC Setup between 1 and 32,000 ms in 1-ms increments.



This setting is effective only when the actual cycle time is shorter than the minimum cycle time setting. If the actual cycle time is longer than the minimum cycle time setting, the actual cycle time will remain unchanged.



PLC Setup

Name	Settings	Default
Minimum cycle time	0000 to 7D00 hex (1 to 32,000 ms in 1-ms increments)	0000 hex: Variable cycle time

Watch Cycle Time

If the cycle time exceeds the watch (maximum) cycle time setting, the Cycle Time Too Long Flag (A401.08) will be turned ON and PLC operation will be stopped.

PLC Setup

Name	Settings	Default
Enable Watch Cycle Time Setting	0: Default (1 s) 1: User setting	0000 hex: Watch cycle time of 1 s
Watch Cycle Time	001 to FA0: 10 to 40,000 ms (10-ms increments)	

Related Flags

Name	Address	Description
Cycle Time Too Long Flag	A401.08	Turns ON if the present cycle time exceeds the Watch Cycle Time set in the PLC Setup.

Cycle Time Monitoring

The maximum cycle time is stored in A262 and A263 and the present cycle time is stored in A264 and A265 every cycle.

Related Words

Name	Addresses	Description
Maximum Cycle Time	A262 and A263	These words contain the maximum cycle time in increments of 0.1 ms. The time is updated every cycle and is recorded in 32-bit binary (0 to FFFF FFFF hex, or 0 to 429,496,729.5 ms). (A263 is the leftmost word.)
Present Cycle Time	A264 and A265	These words contain the present cycle time in increments of 0.1 ms. The time is updated every cycle and is recorded in 32-bit binary (0 to FFFF FFFF, or 0 to 429,496,729.5 ms). (A265 is the leftmost word.)

The average cycle time for the past eight cycles can be read from the CX-Programmer.

Note The following methods are effective in reducing the cycle time.

- Place tasks that do not need to be executed on standby.
- Use JMP-JME instructions to skip instructions that do not need to be executed.

2-7-4 I/O Refresh Times for PLC Units

CP-series Expansion Unit and Expansion I/O Unit I/O Refresh Times

Name	Model	I/O refresh time per Unit
Expansion I/O Units	CP1W-40EDR	0.39 ms
	CP1W-40EDT	0.39 ms
	CP1W-40EDT1	0.39 ms
	CP1W-32ER	0.33 ms
	CP1W-32ET	0.33 ms
	CP1W-32ET1	0.33 ms
	CP1W-20EDT	0.18 ms
	CP1W-20EDT1	0.18 ms
	CP1W-16ER	0.25 ms
	CP1W-16ET	0.25 ms
	CP1W-16ET1	0.25 ms
	CP1W-8ED	0.13 ms
	CP1W-8ER	0.08 ms
	CP1W-8ET	0.08 ms
	CP1W-8ET1	0.08 ms
Analog Input Units	CP1W-AD041	0.61 ms
	CP1W-AD042	0.87 ms
Analog Output Units	CP1W-DA021	0.33 ms
	CP1W-DA041	0.33 ms
	CP1W-DA042	0.40 ms
Analog I/O Units	CP1W-MAD11	0.32 ms
	CP1W-MAD42	0.87 ms
	CP1W-MAD44	0.97 ms

Name	Model	I/O refresh time per Unit
Temperature Sensor Units	CP1W-TS001	0.25 ms
	CP1W-TS002	0.52 ms
	CP1W-TS003	0.67 ms
	CP1W-TS004	0.47 ms
	CP1W-TS101	0.25 ms
	CP1W-TS102	0.52 ms
CompoBus/S I/O Link Unit	CP1W-SRT21	0.21 ms

Note The I/O refresh time for CPU Unit built-in I/O is included in overhead processing.

CJ-series Special I/O Unit I/O Refresh Times (Examples)

Name	Model	I/O refresh time per Unit	
CompoBus/S Master Unit	CJ1W-SRM21	Allocated one unit number	0.15 ms
		Allocates two unit numbers	0.17 ms
Analog Input Unit	CJ1W-AD041/081(-V1)	0.16 ms	
Analog Output Unit	CJ1W-DA021/041/08V	0.16 ms	
Analog I/O Unit	CJ1W-MAD42	0.167 ms	
Temperature Controller Unit	CJ1W-TC□□□□	0.367 ms	

Increase in Cycle Time Caused by CPU Bus Units

Name	Model	Time	Remarks
Controller Link Unit	CJ1W-CLK21-V1	0.15 ms	There will be an increase of $1.0 \text{ ms} + 0.7 \mu\text{s} \times \text{number of data link words}$. There will be an additional increase of the event execution times when message services are used.
Serial Communications Unit	CJ1W-SCU41 CJ1W-SCU21	0.24 ms	There will be an increase of up to the following time when a protocol macro is executed: $0.7 \mu\text{s} \times \text{maximum number of data words sent or received (0 to 500 words)}$ There will be an increase of the event execution times when Host Links or 1:N NT Links are used.
Ethernet Unit	CJ1W-ETN11/21	0.17 ms	If socket services are executed with software switches, there will be an increase of $1.4 \mu\text{s} \times \text{the number of bytes sent/received}$. There will be an increase of the event execution times when FINS communications services, socket services for CMND instructions, or FTP services are performed.
DeviceNet Unit	CJ1W-DRM21	$0.5 \text{ ms} + 0.7 \mu\text{s} \times \text{Number of allocated words}$	The number of allocated words includes all I/O areas allocated to all slaves, even unused words within the I/O areas. If message communications are performed, the number of words for message communications must be added to the number of allocated words at the left, but only during the cycles when the message communications are performed.

Note The refresh time for I/O built into the CPU Unit is included in the overseeing time.

When pulse output ports 2 and 3 are used, the cycle time increases in proportion to the output frequency.

Cycle time rate of increase (%) from pulse output ports 2 and 3 = Output frequency (kHz) \times 0.1.

Examples:

30 kHz: Approx. 3%

100 kHz: Approx. 10%

2-7-5 Cycle Time Calculation Example

The following example shows the method used to calculate the cycle time when CP-series Expansion I/O Units only are connected to a CP1H CPU Unit.

Conditions

Item	Details	
CP1H	CP1W-40EDR 40-pt I/O Unit	2 Units
	CP1W-20EDT 20-pt I/O Unit	2 Units
	CP1W-8ED 8-pt Output Unit	1 Unit
User program	5 K steps	LD instructions: 2.5 Ksteps, OUT instructions: 2.5 Ksteps
USB port connection	Yes and no	
Fixed cycle time processing	No	
Serial port connection	No	
Peripheral servicing with other devices (Special I/O Units and CPU Bus Units)	No	

Calculation Example

Process name	Calculation	Processing time	
		USB port connected	USB port not connected
(1) Overseeing	---	0.7 ms	0.7 ms
(2) Program execution	$0.1 \mu\text{s} \times 2,500 + 0.1 \mu\text{s} \times 2,500$	0.5 ms	0.5 ms
(3) Cycle time calculation	(Minimum cycle time not set)	0 ms	0 ms
(4) I/O refreshing	$0.39 \text{ ms} \times 2 + 0.18 \text{ ms} \times 2 + 0.08$	1.22 ms	1.22 ms
(5) Peripheral servicing	(Only USB port connected)	0.1 ms	0 ms
Cycle time	(1) + (2) + (3) + (4) + (5)	2.52 ms	2.42 ms

2-7-6 Online Editing Cycle Time Extension

When online editing is executed to change the program from the CX-Programmer while the CPU Unit is operating in MONITOR mode, the CPU Unit will momentarily suspend operation while the program is being changed. The period of time that the cycle time is extended is determined by the following conditions.

- Number of steps changed
- Editing operations (insert/delete/overwrite)
- Types of instructions

The cycle time extension for online editing is negligibly affected by the size of task programs. If the maximum program size for a task is 20 Ksteps, the online editing cycle time extension will be as follows:

CPU Unit	Increase in cycle time for online editing
CP1H CPU Unit	Maximum: 26 ms, Normal: 14 ms (for a program size of 20 Ksteps)

When editing online, the cycle time will be extended by according to the editing that is performed. Be sure that the additional time will not adversely affect system operation.

Note When there is one task, online editing is processed all in the cycle time following the cycle in which online editing is executed (written). When there are multiple tasks (cyclic tasks and interrupt tasks), online editing is separated, so that for n tasks, processing is executed over n to $n \times 2$ cycles max.

2-7-7 I/O Response Time

The I/O response time is the time it takes from when an input turns ON, the data is recognized by the CPU Unit, and the user program is executed, up to the time for the result to be output to an output terminal. The length of the I/O response time depends on the following conditions.


- Timing of Input Bit turning ON.
- Cycle time.

Minimum I/O Response Time

The I/O response time is shortest when data is retrieved immediately before I/O refresh of the CPU Unit. The minimum I/O response time is calculated as follows:

Minimum I/O response time = Input ON delay + Cycle time + Output ON delay


Note The input and output ON delays depend on the type of terminals used on the CPU Unit or the model number of the Unit being used.



Maximum I/O Response Time

The I/O response time is longest when data is retrieved immediately after I/O refresh period of the CPU Unit. The maximum I/O response time is calculated as follows:

Maximum I/O response time = Input ON delay + (Cycle time \times 2) + Output ON delay



Calculation Example


Conditions: Input ON delay 1 ms
 Output ON delay 0.1 ms
 Cycle time 20 ms

Minimum I/O response time = 1 ms + 20 ms + 0.1 ms = 21.1 ms

Maximum I/O response time = 1 ms + (20 ms × 2) + 0.1 ms = 41.1 ms

Input Response Times

Input response times can be set in the PLC Setup. Increasing the response time reduces the effects of chattering and noise. Decreasing the response time allows reception of shorter input pulses, (but the pulse width must be longer than the cycle time).



PLC Setup

Name	Description	Settings	Default
Input constants	Input response times	00 hex: 8 ms 10 hex: 0 ms 11 hex: 0.5 ms 12 hex: 1 ms 13 hex: 2 ms 14 hex: 4 ms 15 hex: 8 ms 16 hex: 16 ms 17 hex: 32 ms	00 hex (8 ms)

2-7-8 Interrupt Response Times

Input Interrupt Tasks

The interrupt response time for I/O interrupt tasks is the time taken from when a built-in input has turned ON (or OFF) until the I/O interrupt task has actually


been executed. The length of the interrupt response time for I/O interrupt tasks depends on the following conditions. About 0.3 ms

Item	Interrupt response time	Counter interrupts
Hardware response	Rise time: 50 μ s	---
	Fall time: 50 μ s	---
Software interrupt response	Minimum: 98 μ s	Minimum: 187 μ s
	Maximum: 198 μ s + Wait time (See note 1.)	Maximum: 287 μ s + Wait time (See note 1.)

- Note**
- (1) The wait time occurs when there is competition with other interrupts. As a guideline, the wait time will be 3 to 153 μ s.
 - (2) I/O interrupt tasks can be executed during execution of the user program (even while an instruction is being executed by stopping the execution of an instruction), I/O refresh, peripheral servicing, or overseeing. The interrupt response time is not affected by which of the above processing operations during which the interrupt inputs turns ON. I/O interrupts, however, are not executed during execution of other interrupt tasks even if the I/O interrupt conditions are satisfied. Instead, the I/O interrupts are executed in order of priority after the current interrupt task has completed execution and the software interrupt response time has elapsed.

The interrupt response time of input interrupt tasks is calculated as follows:

Interrupt response time = Input ON delay + Software interrupt response time




The time from completing the ladder program in the input interrupt task until returning to cyclic task execution is 60 μ s.

Scheduled Interrupt Tasks

The interrupt response time of scheduled interrupt tasks is the time taken from after the scheduled time specified by the MSKS(690) instruction has elapsed until the interrupt task has actually been executed. The length of the interrupt response time for scheduled interrupt tasks is 1 ms max. There is also an error of 80 μ s in the time to the first scheduled interrupt (0.5 ms min.).

- Note**
- (1) Scheduled interrupt tasks can be executed during execution of the user program (even while an instruction is being executed by stopping the execution of an instruction), I/O refresh, peripheral servicing, or overseeing. The interrupt response time is not affected by which of the above processing operations during which the scheduled interrupt time occurs. Scheduled interrupts, however, are not executed during execution of other interrupt tasks even if the interrupt conditions are satisfied. Instead, the interrupts are executed in order of priority after the current interrupt task has completed execution and the software interrupt response time has elapsed.



- (2) When using input interrupt or pulse output 2/3 and analog input/output (XA type only), pay attention to the possibility that timer interrupt cannot be executed within short time interval.

External Interrupt Tasks

The interrupt response time for external interrupt tasks depends on the Unit or Board (CJ-series Special I/O Unit or CJ-series CPU Bus Unit) that is requesting the external interrupt task of the CPU Unit and the type of service requested by the interrupt. For details, refer to the operation manual for the Unit or Board being used.

2-7-9 Serial PLC Link Response Performance

The response times for CPU Units connected via a Serial PLC Link (master to slave or slave to master) can be calculated as shown below. If a PT is in the Serial PLC Link, however, the amount of communications data will not be fixed and the values will change.


- Maximum I/O response time (not including hardware delay) =
Master cycle time + Communications cycle time + Slave cycle time + 4 ms
- Minimum I/O response time (not including hardware delay) =
Slave communications time + 1.2 ms

Here,

Number of participating slave nodes	The number of slaves to which links have been established within the maximum unit number set in the master.
Number of non-participating slave nodes	The number of slaves not participating in the links within the maximum unit number set in the master
Communications cycle time (ms)	Slave communications time × Number of participating slave nodes + 10 × Number of non-participating slave nodes
Slave communications time (ms)	<ul style="list-style-type: none"> • Communications time set to <i>Standard</i> $24.6 + 0.494 \times ((\text{No. of slaves} + 1) \times \text{No. of link words} \times 2 + 12)$ • Communications time set to <i>Fast</i> $25.7 + 0.242 \times ((\text{No. of slaves} + 1) \times \text{No. of link words} \times 2 + 12)$

2-7-10 Pulse Output Start Time

The pulse output start time is the time required from executing a pulse output instruction until pulses are output externally. This time depends on the pulse output instruction that is used and operation that is performed.



Pulse output instruction	Start time
SPED: continuous	53 μ s
SPED: independent	55 μ s
ACC: continuous	65 μ s
ACC: independent, trapezoidal	69 μ s
ACC: independent, triangular	70 μ s
PLS2: trapezoidal	74 μ s
PLS2: triangular	76 μ s

2-7-11 Pulse Output Change Response Time

The pulse output change response time is the time for any change made by executing an instruction during pulse output to actually affect the pulse output operation.

Pulse output instruction	Change response time
INI: immediate stop	57 μ s + 1 pulse output time
SPED: immediate stop	54 μ s + 1 pulse output time
ACC: deceleration stop	1 control cycle (4 ms) minimum, 2 control cycles (8 ms) maximum
PLS2: deceleration stop	
SPED: speed change	
ACC: speed change	
PLS2: target position change in reverse direction	
PLS2: target position change in same direction at same speed	
PLS2: target position change in same direction at different speed	

SECTION 3

Installation and Wiring

This section describes how to install and wire the CP1H.

3-1	Fail-safe Circuits	106
3-2	Installation Precautions	107
3-2-1	Installation and Wiring Precautions	107
3-3	Mounting	109
3-3-1	Mounting in a Panel	109
3-3-2	Connecting CP-series Expansion Units and Expansion I/O Units . . .	113
3-3-3	Connecting CJ-series Units	115
3-3-4	DIN Track Installation	116
3-4	Wiring CP1H CPU Units	118
3-4-1	Wiring Power Supply and Ground Lines	119
3-4-2	Wiring Built-in I/O	121
3-4-3	Wiring Safety and Noise Controls	125
3-5	Wiring Methods	126
3-5-1	Example I/O Wiring for X and XA CPU Units	126
3-5-2	Example I/O Wiring for Y CPU Units	128
3-5-3	Pulse Input Connection Examples	129
3-5-4	Pulse Output Connection Examples	130
3-5-5	Wiring Built-in Analog I/O (XA CPU Units Only)	132
3-6	CP-series Expansion I/O Unit Wiring	135

3-1 Fail-safe Circuits

Always set up safety circuits outside of the PLC to prevent dangerous conditions in the event of errors in the PLC or external power supply. In particular, be careful of the following points.

Supply Power to the PLC before the Controlled System

If the PLC's power supply is turned ON after the controlled system's power supply, outputs in Units such as DC Output Units may malfunction momentarily. To prevent any malfunction, add an external circuit that prevents the power supply to the controlled system from going ON before the power supply to the PLC itself.

Managing PLC Errors

When any of the following errors occurs, PLC operation (program execution) will stop and all outputs from Output Units will be turned OFF.

- A CPU error (watchdog timer error) or CPU on standby
- A fatal error (memory error, I/O bus error, duplicate number error, too many I/O points error, I/O setting error, program error, cycle time too long error, or FALS(007) error) (See note.)

Always add any circuits necessary outside of the PLC to ensure the safety of the system in the event of an error that stops PLC operation.

Note

When a fatal error occurs, all outputs from Output Units will be turned OFF even if the IOM Hold Bit has been turned ON to protect the contents of I/O memory. (When the IOM Hold Bit is ON, the outputs will retain their previous status after the PLC has been switched from RUN/MONITOR mode to PROGRAM mode.)


Managing Output Malfunctions

It is possible for an output to remain ON due to a malfunction in the internal circuitry of the Output Unit, such as a relay or transistor malfunction. Always add any circuits necessary outside of the PLC to ensure the safety of the system in the event that an output fails to go OFF.

Interlock Circuits

When the PLC controls an operation such as the clockwise and counterclockwise operation of a motor and if there is any possibility of an accident or mechanical damage due to faulty PLC operation, provide an external interlock such as the one shown below to prevent both the forward and reverse outputs from turning ON at the same time.

Example



This circuit prevents outputs MC1 and MC2 from both being ON at the same time even if both PLC outputs CIO 100.00 and CIO 100.01 are both ON, so the motor is protected even if the PLC is programmed improperly or malfunctions.

3-2 Installation Precautions

3-2-1 Installation and Wiring Precautions

Always consider the following factors when installing and wiring the PLC to improve the reliability of the system and make the most of the CP1H functions.

Ambient Conditions

Do not install the PLC in any of the following locations.

- Locations subject to ambient temperatures lower than 0°C or higher than 55°C.
- Locations subject to drastic temperature changes or condensation.
- Locations subject to ambient humidity lower than 10% or higher than 90%.
- Locations subject to corrosive or flammable gases.
- Locations subject to excessive dust, salt, or metal filings.
- Locations that would subject the PLC to direct shock or vibration.
- Locations exposed to direct sunlight.
- Locations that would subject the PLC to water, oil, or chemical reagents.

Always enclose or protect the PLC sufficiently in the following locations.

- Locations subject to static electricity or other forms of noise.
- Locations subject to strong electromagnetic fields.
- Locations subject to possible exposure to radioactivity.
- Locations close to power lines.


Installation in Cabinets or Control Panels

Temperature Control

When the CP1H is being installed in a cabinet or control panel, always provide proper ambient conditions as well as access for operation and maintenance.

The ambient temperature within the enclosure must be within the operating range of 0°C to 55°C. When necessary, take the following steps to maintain the proper temperature.

- Provide enough space for good air flow.
- Do not install the PLC above equipment that generates a large amount of heat, such as heaters, transformers, or high-capacity resistors.
- If the ambient temperature exceeds 55°C, install a cooling fan or air conditioner.



Accessibility for Operation and Maintenance


- To ensure safe access for operation and maintenance, separate the PLC as much as possible from high-voltage equipment and moving machinery.
- The PLC will be easiest to install and operate if it is mounted at a height of about 1,000 to 1,600 mm.

⚠ Caution Do not touch the power supply or the area around the I/O terminals while power is being supplied or immediately after power has been turned OFF. Doing so may result in burns.

⚠ Caution After the power supply has been turned OFF, wait until the PLC has sufficiently cooled before touching it.


Improving Noise Resistance

- Do not mount the PLC in a control panel containing high-voltage equipment.
- Install the PLC at least 200 mm from power lines.




- Ground the mounting plate between the PLC and the mounting surface.
- The CP1H must be installed in the orientation shown below to ensure adequate cooling.

Mounting in a Panel



- Do not install the CP1H in any of the following orientations.



3-3 Mounting


3-3-1 Mounting in a Panel

When mounting the CP1H CPU Unit in a panel, use either surface installation or DIN Track installation.

Surface Installation


Even if a DIN Track is not used, a CP1H CPU Unit and CP-series Expansion Units or Expansion I/O Units can be mounted using M4 screws. For restrictions on the number of Expansion Units and Expansion I/O Units that can be connected, refer to *1-2 System Configuration*.

CP1H CPU Unit





DIN Track Installation

CJ-series Special I/O Units or CPU Bus Units must be mounted to a DIN Track, along with the CP1H CPU Unit. Secure the DIN Track with screws in at least three places.


**Using I/O Connecting Cable**

When using CP-series Expansion Units and Expansion I/O Units, it is possible to use CP1W-CN811 Connecting Cable to arrange the Units in upper and lower rows. The following restrictions apply:

- I/O Connecting Cable can be used between only the CPU Unit and the first four Expansion Units and Expansion I/O Units. It cannot be used from the fifth Unit onwards.
- I/O Connecting Cable can be used in one place only, and not in multiple places.




Use I/O Connecting Cable when connecting CP-series Expansion Units and Expansion I/O Units at the same time as CJ-series Special I/O Units or CPU Bus Units.



Wiring Ducts


Whenever possible, route I/O wiring through wiring ducts. Install the duct so that it is easy to wire from the I/O Units through the duct. It is handy to have the duct at the same height as the Racks.



Note Tighten terminal block screws and cable screws to the following torque.
M4: 1.2 N·m
M3: 0.5 N·m


Routing Wiring Ducts

Install the wiring ducts at least 20 mm between the tops of the Racks and any other objects, (e.g., ceiling, wiring ducts, structural supports, devices, etc.) to provide enough space for air circulation and replacement of Units.




Dimensions

External Dimensions



Mounting Dimensions



For the dimensions of Units other than CP1H CPU Units, refer to *Appendix B Dimensions Diagrams*.


Mounting Height

The mounting height is approximately 90 mm.


When a cable is connected to an Option Board, however, the additional height must be factored in. Always allow for the additional height when considering the depth of the control panel in which the PLC is to be mounted.

3-3-2 Connecting CP-series Expansion Units and Expansion I/O Units

Leave approximately 10 mm of space between the CPU Unit and the Expansion Units or Expansion I/O Units.




Mounting Method




Unit	A (mm)
CP1H CPU Unit	140 ±0.5
Expansion I/O Unit, 32 or 40 I/O points	140 ±0.2
Expansion I/O Unit, 20 I/O points	76 ±0.2
Expansion I/O Unit, 16 outputs	76 ±0.2
Expansion I/O Unit, 8 inputs	56 ±0.2
Expansion I/O Unit, 8 outputs	56 ±0.2
Analog I/O Unit	76 ±0.2
Temperature Sensor Unit except CP1W-TS004	76 ±0.2
Temperature Sensor Unit CP1W-TS004	140 ±0.2
CompoBus/S I/O Link Unit	56 ±0.2
DeviceNet I/O Link Unit	56 ±0.2


Space between Units When Expansion I/O Units Are Connected




- 1,2,3...**
1. Remove the cover from the CPU Unit's or the Expansion I/O Unit's expansion connector. Use a flat-blade screwdriver to remove the cover from the Expansion I/O Connector.



2. Insert the Expansion I/O Unit's connecting cable into the CPU Unit's or the Expansion I/O Unit's expansion connector.



3. Replace the cover on the CPU Unit's or the Expansion I/O Unit's expansion connector.




3-3-3 Connecting CJ-series Units


Units can be connected together through their respective connectors, and secured by locking the sliders. Connect an End Cover to the Unit on the end on the right.

1,2,3...


1. After the CPU Unit has been mounted to the DIN Track, mount a CJ Adapter.



2. Connect the CJ-series Special I/O Units or CPU Bus Units. A maximum of two Units can be connected.
 - Connect the Units to each other by securely fitting their connectors together.



- Slide the yellow sliders at the top and bottom of each Unit to lock the Units together.



Note If the sliders are not secured properly, the Unit may not function properly.

3. Attach the End Cover to the Unit on the far right side of the Rack.


Note Attach the End Cover to the Unit on the far right side of the Rack. An I/O bus error will occur and CP1H CPU Unit will not operate in either RUN or MONITOR mode if the End Cover is not connected. If this occurs, the following information will be set in memory.

Name	Address	Status
I/O Bus Error Flag	A401.14	ON
I/O Bus Error Details	A404	0E0E hex


- Always turn OFF the power supply before connecting Units to each other.

3-3-4 DIN Track Installation


- 1,2,3...**
1. Use a screwdriver to pull down the DIN Track mounting pins from the back of the Units, and mount the Units to the DIN Track.




2. Lower the Units so that they catch on the top of the DIN Track, and then press them forward all the way to the DIN Track at the bottom.



3. Press in all of the DIN Track mounting pins to securely lock the Units in place.




4. When connecting CJ-series Units, the Units must be mounted to a DIN Track and held at both ends by a pair of End Plates. When mounting an End Plate, pull up on the End Plate so that it catches on the DIN Track at the bottom, catch the top on the DIN Rack, and then pull down.



Finally, tighten the End Plate screw to secure the End Plate in place.


- Two PFP-M End Plates



DIN Track


Mount the DIN Track in the control panel with screws in at least three places.

- DIN Track: PFP-50N (50 cm), PFP-100N (100 cm), or PFP-100N2 (100 cm)




Secure the DIN Track to the control panel using M4 screws separated by 210 mm (6 holes). The tightening torque is 1.2 N·m.

PFP-100N2



PFP-100N/50N



Note: PFP-50N dimensions are given in parentheses.


3-4 Wiring CP1H CPU Units**Note**

- (1) Do not remove the protective label from the top of the Unit until wiring has been completed. This label prevents wire strands and other foreign matter from entering the Unit during wiring procedures.
- (2) Remove the label after the completion of wiring to ensure proper heat dissipation.


3-4-1 Wiring Power Supply and Ground Lines

CPU Units with AC Power Supply

Wiring the AC Power Supply and Ground Lines



- Wire a separate circuit for the power supply circuit so that there is no voltage drop from the inrush current that flows when other equipment is turned ON.
- When several CP1H PLCs are being used, it is recommended to wire the PLCs on separate circuits to prevent a voltage drop from the inrush current or incorrect operation of the circuit breaker.
- Use twisted-pair power supply cables to prevent noise from the power supply lines. Adding a 1:1 isolating transformer reduces electrical noise even further.
- Consider the possibility of voltage drops and the allowable current, and always use thick power lines.
- Use round crimp terminals for AC power supply wiring.



- AC Power Supply
Provide a power supply of 100 to 240 VAC.
- Use a power supply within the following voltage fluctuation range.

Power supply voltage	Allowable voltage fluctuation range
100 to 240 VAC	85 to 264 VAC

Note

- (1) Before connecting the power supply, make sure that the CPU Unit requires an AC power supply and not a DC power supply. The CPU Unit's internal circuitry will be damaged if AC power is mistakenly supplied to a CPU Unit that requires a DC power supply.
- (2) The power supply input terminals are at the top of the CPU Unit; the terminals at the bottom of the CPU Unit output 24-VDC power for external devices. The CPU Unit's internal circuitry will be damaged if AC power is mistakenly supplied to a CPU Unit's power supply output terminals.

Caution Tighten the terminal block screws for the AC power supply to the torque of 0.5 N·m. Loose screws may result in fire or malfunction.

- Always ground the ground terminal to 100 Ω or less to protect against electric shock and incorrect operation from electrical noise.
- If one phase of the power supply is grounded, connect the grounded phase to the L2/N terminal.


- The GR terminal is a ground terminal. To prevent electrical shock, use a dedicated ground line (2 mm² min.) of 100 Ω or less.
- The line ground terminal (LG) is a noise-filtered neutral terminal. If noise is a significant source of errors or if electrical shocks are a problem, connect the line ground terminal (LG) to the ground terminal (GR) and ground both with a ground resistance of 100 Ω or less.
- To prevent electrical shock when short-circuiting between the LG and GR terminals, always use a ground of 100 Ω or less.
- Do not connect ground lines to other devices or to the frame of a building. Doing so will reverse the effectiveness of the ground and instead have a bad influence.

Isolating Transformer


The PLC's internal noise control is sufficient for the general noise to which power supply lines are subjected. Ground noise can be further reduced by providing the power supply through a 1:1 isolating transformer. Leave the isolating transformer's secondary side ungrounded.

CPU Units with DC Power Supply

DC Power Supply Wiring



- Use crimp terminals or solid wire for wiring the power supply. Do not connect bare stranded wires directly to terminals.



- M3 self-rising terminal screws are used. Tighten the terminal screws to the torque of 0.5 N·m.
- To prevent noise, use a ground of 100 Ω or less.

DC Power Supply

- Provide a power supply of 20.4 to 26.4 VDC unless there are two or more Expansion Units and Expansion I/O Units. Provide a power supply of 21.6 to 26.4 VDC if there are two or more Expansion Units and Expansion I/O Units.
- The maximum current consumption is 50 W per device.
- When the power supply is turned ON, the inrush current is approximately five times the normal current.
- The GR terminal is a ground terminal. To prevent electrical shock, use a dedicated ground line (2 mm² min.) of 100 Ω or less.

Note

- (1) Never reverse the positive and negative leads when wiring the power supply terminals.
- (2) Supply all power to the power supply terminals from the same source.

3-4-2 Wiring Built-in I/O

Wiring Precautions

Double-checking I/O Specifications

Double-check the specifications for the I/O Units. In particular, do not apply a voltage that exceeds the input voltage for Input Units or the maximum switching capacity for Output Units. Doing so may result in breakdown, damage, or fire.

When the power supply has positive and negative terminals, always wire them correctly.

Electric Wires


- AWG24 to AWG28 (0.2 to 0.08 mm²) power lines are recommended. Use cable with a maximum diameter of 1.61 mm including the insulation covering.
- The current capacity of electric wire depends on factors such as the ambient temperature and insulation thickness, as well as the gauge of the conductor.
- M3 self-rising screws are used for all screw terminals including terminal screws for crimp terminal power supply wiring.
- Use crimp terminals or solid wire for wiring.
- Do not connect bare stranded wires directly to terminals.
- Tighten the terminal block screws to the torque of 0.5 N·m.
- Use crimp terminals (M3) having the dimensions shown below.



Wiring

- Wire the Units so that they can be easily replaced.
- Make sure that the I/O indicators are not covered by the wiring.
- Do not place the I/O wiring in the same conduits or ducts as high-voltage or power lines. Inductive noise can cause errors or damage.
- Tighten the terminal screws to the torque of 0.5 N·m.

Unit type	Terminal width	Terminal pitch
CPU Units	6.4 mm	7.6 mm
Expansion I/O Units 40ED□/32E□/20EDT□	6.4 mm	7.7 mm
Expansion I/O Units AD04□/DA0□□/MAD□□/TS□0□ SRT21/20EDR1/16E□/8E□	6.8 mm	8.4 mm



Note







- (1) Never apply a voltage that exceeds the input voltage for Input Units or the maximum switching capacity for Output Units.
- (2) When the power supply has positive and negative terminals, always wire them correctly.
- (3) When required by EC Low Voltage Directive, use reinforced insulation or double insulation on the DC power supply connected to DC-power-supply CPU Units and I/O.
For the DC power supply connected to a DC-power-supply CPU Unit, use a power supply with a minimum output holding time of 10 ms.
- (4) Do not pull on the cables or bend the cables beyond their natural limit. Doing either of these may break the cables.

Connecting I/O Devices


DC Input Devices

Use the following information for reference when selecting or connecting input devices.

Connectable DC Input Devices (for DC Output Models)



- The circuit below should not be used for I/O devices with a voltage output.



Precautions when Connecting a Two-wire DC Sensor

1,2,3...

1. Relation between voltage when the PLC is ON and the sensor residual voltage:

$$V_{ON} \leq V_{CC} - V_R$$

2. Relation between current when the PLC is ON and sensor control output (load current):

$$I_{OUT} (\text{min}) \leq I_{ON} \leq I_{OUT} (\text{max})$$

$$I_{ON} = (V_{CC} - V_R - 1.5 [\text{PLC internal residual voltage}]) / R_{IN}$$

When I_{ON} is smaller than $I_{OUT} (\text{min})$, connect a bleeder resistor R . The bleeder resistor constant can be calculated as follows:

$$R \leq (V_{CC} - V_R) / (I_{OUT} (\text{min}) - I_{ON})$$

$$\text{Power } W \geq (V_{CC} - V_R)^2 / R \times 4 [\text{allowable margin}]$$


3. Relation between current when the PLC is OFF and sensor leakage current:

$$I_{OFF} \geq I_{leak}$$

Connect a bleeder resistor if I_{leak} is greater than I_{OFF} . Use the following equation to calculate the bleeder resistance constant.

$$R \leq R_{IN} \times V_{OFF} / (I_{leak} \times R_{IN} - V_{OFF})$$

$$\text{Power } W \geq (V_{CC} - V_R)^2 / R \times 4 (\text{allowable margin})$$



V_{CC} : Power voltage

V_{ON} : PLC ON voltage

V_{OFF} : PLC OFF voltage

I_{ON} : PLC ON current

I_{OFF} : PLC OFF current

R_{IN} : PLC input impedance

V_R : Sensor output residual current

I_{OUT} : Sensor control output (load current)

I_{leak} : Sensor leakage current


R : Bleeder resistance

4. Precautions on Sensor Inrush Current

An incorrect input may occur due to sensor inrush current if a sensor is turned ON after the PLC has started up to the point where inputs are possible. Determine the time required for sensor operation to stabilize after the sensor is turned ON and take appropriate measures, such as inserting into the program a timer delay after turning ON the sensor.

Program Example

In this example, the sensor's power supply voltage is provided to input bit CIO 0.00 and a 100-ms timer delay (the time required for an OMRON Proximity Sensor to stabilize) is created in the program. After the Completion Flag for the timer turns ON, the sensor input on input bit CIO 0.01 will cause output bit CIO 100.00 to turn ON.

**Output Wiring Precautions****Output Short-circuit Protection**


If a load connected to the output terminals is short-circuited, output components and the printed circuit boards may be damaged. To guard against this, incorporate a fuse in the external circuit. Use a fuse with a capacity of about twice the rated output.

Connecting to a TTL Circuit


A TTL circuit cannot be connected directly to a transistor output because of the transistor's residual voltage. It is necessary to connect a pull-up resistor and a CMOS IC between the two.

Inrush Current Considerations

When connecting a transistor or triac output to a load having a high inrush current (such as an incandescent lamp), steps must be taken to avoid damage to the transistor or triac. Use either of the following methods to reduce the inrush current.

Example Method 1

Use a dark current of approximately 1/3 the rated current of the incandescent lamp.


Example Method 2

Install a limit resistance.

3-4-3 Wiring Safety and Noise Controls

I/O Signal Wiring


Whenever possible, place I/O signal lines and power lines in separate ducts or conduits both inside and outside of the control panel.




If the I/O wiring and power wiring must be routed in the same duct, use shielded cables and connect the shields to the GR terminal to reduce noise.

Inductive Loads

When an inductive load is connected to an I/O Unit, connect a surge suppressor or diode in parallel with the load as shown below.



Note Use surge suppressors and diodes with the following specifications.

Surge Suppressor Specifications 

Resistance: 50 Ω
 Capacitance: 0.47 μF
 Voltage: 200 V


Diode Specifications 

Breakdown voltage: 3 times load voltage min.
 Mean rectification current: 1 A


Noise from External Wiring

Take the following points into account when externally wiring I/O, power supply, and power lines.

- When multi-conductor signal cable is being used, avoid combining I/O wires and other control wires in the same cable.
- If wiring racks are parallel, allow at least 300 mm between the Racks.



- If the I/O wiring and power cables must be placed in the same duct, they must be shielded from each other using grounded steel sheet metal.




3-5 Wiring Methods

3-5-1 Example I/O Wiring for X and XA CPU Units

Input Wiring (Terminal Block is Removable)

The input circuits for X and XA CPU Units have 24 points/common. Use power lines with sufficient current capacity for the COM terminals.

Upper Terminal Block




AC-power-supply models have a 24-VDC output terminals on the lower terminal block. They can be used as a DC power supply for the input circuit.

To use high-speed counters, make the following setting in the PLC Setup. Enable using the high-speed counters with *Built-in Input - High Speed Counter 0 to 3 - Use high speed counter 0 to 3*. For details on high-speed counter inputs, refer to 2-2-3 I/O Specifications for XA and X CPU Units.

Output Wiring (Terminal Block is Removable)


CP1H-XA40DR-A and
CP1H-X40DR-A (Relay
Output)

Lower Terminal Block




CP1H-XA40DT-D and
CP1H-X40DT-D (Sinking
Transistor Output)

Lower Terminal Block



CP1H-XA40DT1-D and
CP1H-X40DT1-D
(Sourcing Transistor
Output)

Lower Terminal Block




To use as pulse outputs, make the setting under *Pulse Output 0 to 3* in the PLC Setup.

3-5-2 Example I/O Wiring for Y CPU Units


Input Wiring (Terminal Block is Removable)

The input circuits for Y CPU Units have 24 points/common. Use power lines with sufficient current capacity for the COM terminals.



To use high-speed counters 2 and 3, make the following setting in the PLC Setup. Set the high-speed counters to be used under Enable using the high-speed counters with *Built-in Input - High Speed Counter 2 and 3 - Use high speed counter 2 and 3*. For details on high-speed counter inputs, refer to 2-2-5 I/O Specifications for Y CPU Units.


Output Wiring (Terminal Block is Removable)




3-5-3 Pulse Input Connection Examples

For a 24-VDC Open-collector Encoder


This example shows the connections to an encoder with phase-A, phase-B, and phase-Z inputs.




(Do not use the same I/O power supply as other equipment.)



For a Line-driver Output Encoder (Am26LS31 Equivalent)






3-5-4 Pulse Output Connection Examples

This example shows a connection to a motor driver. Always check the specifications of the motor driver before actually connecting it.

For open-collector output, use a maximum of 3 m of wiring between the CP1H CPU Unit and the motor driver.


No pulses are output while the pulse output transistor is OFF. For a direction output, OFF indicates that CCW output is in progress.

Do not use the same power supply for both pulse output 24-VDC/5-VDC power and other I/O power.



CW/CCW Pulse Output and Pulse Plus Direction Output


Using a 24-VDC Photocoupler Input Motor Driver



Note The values inside the parentheses are for using pulse and direction outputs.

Using a 5-VDC Photocoupler Input Motor Driver

Connection Example 1




Note The values inside the parentheses are for a pulse plus direction output connection.

In this example, a 5-V input motor driver is used with a 24-VDC power supply. Be careful to ensure that the Position Control Unit output current does not damage the input circuit at the motor driver and yet is sufficient to turn it ON.

Take into account the power derating for the 1.6-k Ω resistance.


Connection Example 2



Note The values inside the parentheses are for using pulse and direction outputs.


3-5-5 Wiring Built-in Analog I/O (XA CPU Units Only)

XA CPU Units come with an analog I/O terminal block. To use the analog I/O, first set the voltage/current input switch and then mount the terminal block.




Setting the Analog Voltage/Current Input Switch

This switch must be set before the terminal block is mounted. Use a screwdriver with a thin blade and be careful not to damage the internal board.




Pin	Input	Function
1	Input 1	ON: Current input OFF: Voltage input (Default: Voltage input)
2	Input 2	
3	Input 3	
4	Input 4	

Analog Input Terminal Block (Terminal Block is Removable)




Analog Output Terminal Block (Terminal Block is Removable)



Note Do not connect the shield.

Analog I/O Wiring Example




- Note**
- (1) When using a current input, turn ON voltage/current input switch pins IN1 to IN4, and make the suitable setting in the PLC Setup.
 - (2) For any inputs that are not to be used, set them to not be used by clearing the selection of the Use checkbox.
If an input that is set to be used is not actually used, the data for that input may be unstable. If that occurs, the instability can be removed by short-

circuiting the plus and minus terminals. If the range is set for 1 to 5 V and 4 to 20 mA, however, the Open-circuit Detection Flag will turn ON when the plus and minus terminals are short-circuited.

Terminal Block Wiring

When wiring the analog I/O terminal block, either use ferrules or solid wires.




- Wire the terminal block while it is mounted to the CPU Unit and do not remove it from the CPU Unit after completing wiring.
- To make the connection, insert the ferrule or solid wire into the round hole in the terminal block it locks inside.
- To disconnect the wiring, press the release button in with a small flat-blade screwdriver and pull the line out while the lock is released.

The screwdriver shown below is recommended for disconnecting wiring.

Recommended Screwdriver

Model	Manufacturer
SZF1	Phoenix Contact



Recommended Ferrules and Crimp Tools

The following crimp terminals and crimping tool are recommended.

Crimp terminals	Crimping tool
PHOENIX CONTACT	Phoenix Contact
AI-TWIN2 × 0.5-8WH (Product code: 3200933)	UD6 (Product code: 1204436)

The following ferrules can also be used.

Manufacturer	Model	Applicable wire
Phoenix Contact	AI-0.5-10	0.5 mm ² (AWG20)
	AI-0.75-10	0.75 mm ² (AWG18)
	AI-1.5-10	1.25 mm ² (AWG16)
Nihon Weidmuller Co., Ltd.	H 0.5/16 D	0.5 mm ² (AWG20)
	H 0.75/16 D	0.75 mm ² (AWG18)
	H 1.5/16 D	1.25 mm ² (AWG16)

I/O Wiring Precautions




To enable using the analog I/O under optimal conditions, be careful of the following points for noise reduction.




- Use 2-conductor shielded twisted-pair cable for the I/O wiring, and do not connect the shield.
- Wire I/O lines apart from power lines (AC power supply lines, three-phase power lines, etc.), and do not place them in the same duct.
- If noise is received from power supply lines (e.g., when sharing a power supply with electric welding machines or electric charging devices, or when near a high-frequency source), insert a noise filter in the power supply input section.

3-6 CP-series Expansion I/O Unit Wiring**CP-series Expansion I/O Units**


	Model	Inputs	Outputs
40-point I/O Units	CP1W-40EDR	24 24-VDC inputs	16 relay outputs
	CP1W-40EDT		16 transistor outputs (sinking)
	CP1W-40EDT1		16 transistor outputs (sourcing)
32-point Output Units	CP1W-32ER	None	32 relay outputs
	CP1W-32ET		32 transistor outputs (sinking)
	CP1W-32ET1		32 transistor outputs (sourcing)
20-point I/O Units	CP1W-20EDR1	12 24-VDC inputs	8 relay outputs
	CP1W-20EDT		8 transistor outputs (sinking)
	CP1W-20EDT1		8 transistor outputs (sourcing)
16-point Output Units	CP1W-16ER	None	16 relay outputs
	CP1W-16ET		16 transistor outputs (sinking)
	CP1W-16ET1		16 transistor outputs (sourcing)
8-point Input Units	CP1W-8ED	8 24-VDC inputs	None
8-point Output Units	CP1W-8ER	None	8 relay outputs
	CP1W-8ET		8 transistor outputs (sinking)
	CP1W-8ET1		8 transistor outputs (sourcing)

For details on wiring Expansion Units, such as Analog I/O Units, Temperature Sensor Units, CompoBus I/O Link Units, and DeviceNet I/O Link Units, refer to *SECTION 7 Using CP-series Expansion Units and Expansion I/O Units*.


40-point I/O Units (CP1W-40ED□□) (Terminal Block is not Removable)**Input Wiring****Output Wiring****CP1W-40EDR (Relay Output)****CP1W-40EDT (Sinking Transistor Output)**

CP1W-40EDT1 (Sourcing Transistor Output)**32-point Output Units (CP1W-32E□□) (Terminal Block is not Removable)****Output Wiring****CP1W-32ER (Relay Outputs)****Output Wiring****CP1W-32ET (Sinking Transistor Outputs)**


Output Wiring

CP1W-32ET1 (Sourcing Transistor Outputs)**20-point I/O Units (CP1W-20ED□□) (Terminal Block is not Removable)**


Input Wiring




Output Wiring

CP1W-20EDR1 (Relay Output)

CP1W-20EDT (Sinking Transistor Output)




CP1W-20EDT1 (Sourcing Transistor Output)





16-point Output Units (CP1W-16E□□) (Terminal Block is not Removable)

Output Wiring


CP1W-16ER (Relay Outputs)






Output Wiring

CP1W-16ET (Sinking Transistor Outputs)**CP1W-16ET1 (Sourcing Transistor Outputs)****8-point Input Units (CP1W-8ED) (Terminal Block is not Removable)**

Input Wiring



The Unit's upper terminal block COM and lower terminal block COM are connected internally, but connect them externally as well.

8-point Output Units (CP1W-8E□) (Terminal Block is not Removable)**Output Wiring****CP1W-8ER (Relay Output)****CP1W-8ET (Sinking Transistor Output)****CP1W-8ET1 (Sourcing Transistor Output)**

SECTION 4

I/O Memory Allocation


This section describes the structure and functions of the I/O Memory Areas and Parameter Areas.

4-1	Overview of I/O Memory Area	144
4-1-1	I/O Memory Area	144
4-1-2	Overview of the Data Areas	146
4-1-3	Clearing and Holding I/O Memory	150
4-1-4	Hot Start/Hot Stop Functions	150
4-2	I/O Area and I/O Allocations	152
4-2-1	Overview	152
4-2-2	Allocations to Built-in General Purpose I/O on the CPU Unit	153
4-2-3	Allocations to CP1H Y CPU Units (12 Inputs/8 Outputs)	154
4-2-4	Allocations to CP1W Expansion Units and Expansion I/O Units	154
4-2-5	I/O Allocation Examples	158
4-3	Built-in Analog I/O Area (XA CPU Units Only)	159
4-4	Data Link Area	160
4-5	CPU Bus Unit Area	161
4-6	Special I/O Unit Area	162
4-7	Serial PLC Link Area	163
4-8	DeviceNet Area	163
4-9	Internal I/O Area	165
4-10	Holding Area (H)	165
4-11	Auxiliary Area (A)	166
4-12	TR (Temporary Relay) Area	166
4-13	Timers and Counters	167
4-13-1	Timer Area (T)	167
4-13-2	Counter Area (C)	169
4-13-3	Changing the BCD or Binary Mode for Counters and Timers	170
4-14	Data Memory Area (D)	170
4-15	Index Registers	172
4-15-1	Using Index Registers	175
4-15-2	Precautions for Using Index Registers	177
4-16	Data Registers	179
4-17	Task Flags	181
4-18	Condition Flags	181
4-19	Clock Pulses	183

4-1 Overview of I/O Memory Area

4-1-1 I/O Memory Area

This region of memory contains the data areas that can be accessed as instruction operands. I/O memory includes the CIO Area, Work Area, Holding Area, Auxiliary Area, DM Area, Timer Area, Counter Area, Task Flag Area, Data Registers, Index Registers, Condition Flag Area, and Clock Pulse Area.



Area			Size	Range	Task usage	Allocation	Bit access	Word access	Access		Change from CX-Programmer	Forcing bit status
									Read	Write		
CIO Area	I/O Area	Input Area	272 bits (17 words)	CIO 0 to CIO 16	Shared by all tasks	CP1H CPU Units and CP-series Expansion Units or Expansion I/O Units	OK	OK	OK	OK	OK	OK
		Output Area	272 bits (17 words)	CIO 100 to CIO 116			OK	OK	OK	OK	OK	OK
	Built-in analog I/O Areas (XA CPU Units only)	Built-in Analog Input Area	4 words	CIO 200 to CIO 203		Built-in analog input terminals	OK	OK	OK	OK	OK	OK
		Built-in Analog Output Area	2 words	CIO 210 to 211		Built-in analog output terminals	OK	OK	OK	OK	OK	OK
	Data Link Area		3,200 bits (200 words)	CIO 1000 to CIO 1199		Data Links	OK	OK	OK	OK	OK	OK
	CPU Bus Unit Area		6,400 bits (400 words)	CIO 1500 to CIO 1899		CPU Bus Units	OK	OK	OK	OK	OK	OK
	Special I/O Unit Area		15,360 bits (960 words)	CIO 2000 to CIO 2959		Special I/O Units	OK	OK	OK	OK	OK	OK
	Serial PLC Link Area		1,440 bits (90 words)	CIO 3100 to CIO 3189		Serial PLC Links	OK	OK	OK	OK	OK	OK
	DeviceNet Area		9,600 bits (600 words)	CIO 3200 to CIO 3799		DeviceNet Masters using fixed allocations	OK	OK	OK	OK	OK	OK
	Work Area		4,800 bits (300 words) 37,504 bits (2344 words)	CIO 1200 to CIO 1499 CIO 3800 to CIO 6143		---	OK	OK	OK	OK	OK	OK
Work Area			8,192 bits (512 words)	W000 to W511	---	OK	OK	OK	OK	OK	OK	
Holding Area			8,192 bits (512 words)	H000 to H511 (Note 1)	---	OK	OK	OK	OK	OK	OK	
Auxiliary Area			15,360 bits (960 words)	A000 to A959	---	OK	---	OK	Read-only: A000 to A447 Read/write:A448 to A959	Read-only: A000 to A447 Read/write: A448 to A959	No	

Area	Size	Range	Task usage	Allocation	Bit access	Word access	Access		Change from CX-Programmer	Forcing bit status
							Read	Write		
TR Area	16 bits	TR0 to TR15	Shared by all tasks	---	OK	OK	OK	OK	No	No
Data Memory Area	32,768 words	D00000 to D32767		---	No (Note 2)	OK	OK	OK	OK	No
Timer Completion Flags	4,096 bits	T0000 to T4095		---	OK	---	OK	OK	OK	OK
Counter Completion Flags	4,096 bits	C0000 to C4095		---	OK	---	OK	OK	OK	OK
Timer PVs	4,096 words	T0000 to T4095		---	---	OK	OK	OK	OK	No (Note 4)
Counter PVs	4,096 words	C0000 to C4095		---	---	OK	OK	OK	OK	No (Note 5)
Task Flag Area	32 bits	TK0 to TK31	Function separately in each task (Note 3)	---	OK	---	OK	No	No	No
Index Registers	16 registers	IR0 to IR15		---	OK	OK	Indirect addressing only	Specific instructions only	No	No
Data Registers	16 registers	DR0 to DR15		---	No	OK	OK	OK	No	No

Note

1. H512 to H1535 are used as a Function Block Holding Area. These words can be used only for function block instances (internally allocated variable area).
2. Bits can be manipulated using TST(350), TSTN(351), SET, SETB(532), RSTB(533), and OUTB(534).
3. Index registers and data registers can be used either individually by task or they can be shared by all the tasks (the default is individual use by task).
4. Timer PVs can be refreshed indirectly by force-setting/resetting the Timer Completion Flags.
5. Counter PVs can be refreshed indirectly by force-setting/resetting the Counter Completion Flags.

4-1-2 Overview of the Data Areas

■ CIO Area

It is not necessary to input the “CIO” acronym when specifying an address in the CIO Area. The CIO Area is generally used for data exchanges, such as I/O refreshing with PLC Units. Words that are not allocated to Units may be used as work words and work bits in the program.

X and Y CPU Units			XA CPU Units		
Word	CIO	Bit 15 00	Word	CIO	Bit 15 0
	CIO 0	Input Area		CIO 0	Input Area
	CIO 16			CIO 16	
	CIO 17	Not used (see note).		CIO 17	Not used (see note).
	CIO 99			CIO 99	
	CIO 100	Output Area		CIO 100	Output Area
	CIO 116			CIO 116	
	CIO 117	Not used (see note).		CIO 117	Not used (see note).
	CIO 999			CIO 199	
	CIO 1000	Data Link Area		CIO 200	Built-in Analog I/O Areas
	CIO 1199			CIO 211	
	CIO 1200	Work Area		CIO 212	Not used (see note).
				CIO 999	Data Link Area
	CIO 1499			CIO 1000	
	CIO 1500	CPU Bus Unit Area (25 words/Unit)		CIO 1199	Work Area
	CIO 1899			CIO 1200	
	CIO 1900	Not used (see note).		CIO 1499	
	CIO 1999			CIO 1500	CPU Bus Unit Area (25 words/Unit)
	CIO 2000	Special Unit Area (10 words/Unit)		CIO 1899	
	CIO 2959			CIO 1900	Not used (see note).
	CIO 2960	Not used (see note).		CIO 1999	
	CIO 3100			CIO 2000	Special Unit Area (10 words/Unit)
	(CIO 3199)	Serial PLC Link Area		CIO 2959	
	CIO 3200			CIO 2960	Not used (see note).
	CIO 3799	DeviceNet Area		CIO 3100	
	CIO 3800			(CIO 3199)	Serial PLC Link Area
	CIO 6143	Work Area		CIO 3200	DeviceNet Area
				CIO 3799	
				CIO 3800	
				CIO 6143	Work Area

Note The parts of the CIO Area that are labelled “not used” may be used in programming as work bits. In the future, however, unused CIO Area bits may be used when expanding functions. Always use Work Area bits first.

I/O Area (Inputs: CIO 0 to CIO 16, Outputs: CIO 100 to CIO 116)

These words are allocated to built-in I/O terminals of CP1H CPU Units and CP-series Expansion Units or Expansion I/O Units. Input words and output bits that aren't allocated may be used in programming.

Built-in Analog Input Area (Built-in Analog Inputs: CIO 200 to CIO 203, CIO 210 to CIO 211) (XA CPU Units Only)

These words are allocated to built-in analog I/O terminals of CP1H XA CPU Units. Words that aren't used in data links may be used in programming.

Data Link Area

These words are used when the Controller Link auto-setting area is set to the link area or for PLC links. Words that aren't used in data links may be used in programming.

CPU Bus Unit Area

These words are used when connecting the CJ-series CPU Bus Units. Words that aren't used by CPU Bus Units may be used in programming.

Special I/O Unit Area

These words are used when connecting the CJ-series Special I/O Units. Words that aren't used by Special I/O Units may be used in programming.

Serial PLC Link Area

These words are allocated for use for data links (Serial PLC Links) with other CP1H CPU Units or CJ1M CPU Units. Addresses not used for Serial PLC Links can be used in programming.

DeviceNet Area


These words are allocated to slaves for remote I/O communications for CJ-series DeviceNet Units. Allocations are fixed and cannot be changed. Words that aren't used by DeviceNet devices can be used in programming.

Internal I/O Area

These words can be used in programming; they cannot be used for I/O exchange with external I/O terminals. Be sure to use the work words provided in the Work Area before using words in the Internal I/O Area or other unused words in the CIO Area. It is possible that these words will be assigned to new functions in future versions of the CPU Units. The parts of the CIO Area that are labelled "Not used" are functionally identical to the Internal I/O Area.

Work Area (W)


Words in the Work Area can be used in programming; they cannot be used for I/O exchange with external I/O terminals. Use this area for work words and bits before any words in the CIO Area.



Note These words should be used first in programming be assigned to new functions in future versions of CP1H CPU Units.

Holding Area (H)


Words in the Holding Area can be used in programming. These words retain their content when the PLC is turned ON or the operating mode is switched between PROGRAM mode and RUN or MONITOR mode.



Note H512 to H1535 are used as a Function Block Holding Area. These words can be used only for function block instances (internally allocated variable area). These words cannot be specified as instruction operands in the user program.

Auxiliary Area (A)


These words are allocated to specific functions in the system. Refer to *Appendix C Auxiliary Area Allocations by Function* and *Appendix D Auxiliary Area Allocations by Address* for details on the Auxiliary Area.

**Temporary Relay Area (TR)**

The TR Area contains bits that record the ON/OFF status of program branches. Refer to the *CP1H Programming Manual* for details.

Data Memory Area (D)

The DM Area is a multi-purpose data area that is normally accessed only in word-units. These words retain their content when the PLC is turned ON or the operating mode is switched between PROGRAM mode and RUN or MONITOR mode.

**Timer Area (T)**

There are two parts to the Timer Area: the Timer Completion Flags and the timer Present Values (PVs). Up to 4,096 timers with timer numbers T0 to T4095 can be used.

Timer Completion Flags

These flags are read as individual bits. A Completion Flag is turned ON by the system when the corresponding timer times out (i.e., when the set time elapses).

Timer PVs

The PVs are read and written as words (16 bits). The PVs count up or down as the timer operates.

Counter Area (C)	<p>There are two parts to the Counter Area: the Counter Completion Flags and the Counter Present Values (PVs). Up to 4,096 counters with counter numbers C0 to C4095 can be used.</p> <p><u>Counter Completion Flags</u></p> <p>These flags are read as individual bits. A Completion Flag is turned ON by the system when the corresponding counter counts out (i.e., when the set value is reached).</p> <p><u>Counter PVs</u></p> <p>The PVs are read and written as words (16 bits). The PVs count up or down as the counter operates.</p>
Condition Flags	<p>These flags include the Arithmetic Flags, such as the Error Flag and Equals Flag, which indicate the results of instruction execution as well as the Always ON and Always OFF Flags. The Condition Flags are specified with symbols rather than addresses.</p>
Clock Pulses	<p>The Clock Pulses are turned ON and OFF by the CPU Unit's internal timer. These bits are specified with symbols rather than addresses.</p>
Task Flag Area (TK)	<p>A Task Flag will be ON when the corresponding cyclic task is in executable (RUN) status and OFF when the cyclic task hasn't been executed (INI) or is in standby (WAIT) status.</p>
Index Registers (IR)	<p>Index registers (IR0 to IR15) are used to store PLC memory addresses (i.e., absolute memory addresses in RAM) to indirectly address words in I/O memory. The Index Registers can be used separately in each task or they can be shared by all tasks.</p>
Data Registers (DR)	<p>Data registers (DR0 to DR15) are used together with Index Registers. When a Data Register is input just before an Index Register, the content of the Data Register is added to the PLC memory address in the Index Register to offset that address. The Data Registers can be used separately in each task or they can be shared by all tasks.</p>

4-1-3 Clearing and Holding I/O Memory

Area		Mode changed ¹		Fatal error generated				PLC power turned ON			
				Execution of FALS		Other fatal errors		PLC Setup set to clear IOM Hold Bit status ²		PLC Setup set to hold IOM Hold Bit status ²	
		IOM Hold Bit OFF	IOM Hold Bit ON	IOM Hold Bit OFF	IOM Hold Bit ON	IOM Hold Bit OFF	IOM Hold Bit ON	IOM Hold Bit OFF	IOM Hold Bit ON	IOM Hold Bit OFF	IOM Hold Bit ON
CIO Area	I/O Area	Cleared	Retained	Retained	Retained	Cleared	Retained	Cleared	Cleared	Cleared	Retained
	Built-in Analog I/O Areas (XA CPU Units only)										
	Data Link Area										
	CPU Bus Unit Area										
	Special I/O Unit Area										
	Serial PC Link Area										
	DeviceNet Area										
	Internal I/O Area										
Work Area (W)		Cleared	Retained	Retained	Retained	Cleared	Retained	Cleared	Cleared	Cleared	Retained
Holding Area (H)		Retained	Retained	Retained	Retained	Retained	Retained	Retained	Retained	Retained	Retained
Auxiliary Area (A)		Status treatment depends on address.									
Data Memory Area (D)		Retained	Retained	Retained	Retained	Retained	Retained	Retained	Retained	Retained	Retained
Timer Completion Flags (T)		Cleared	Retained	Retained	Retained	Cleared	Retained	Cleared	Cleared	Cleared	Retained
Timer PVs (T)		Cleared	Retained	Retained	Retained	Cleared	Retained	Cleared	Cleared	Cleared	Retained
Counter Completion Flags (C)		Retained	Retained	Retained	Retained	Retained	Retained	Retained	Retained	Retained	Retained
Counter PVs (C)		Retained	Retained	Retained	Retained	Retained	Retained	Retained	Retained	Retained	Retained
Task Flags (TK)		Cleared	Cleared	Retained	Retained	Cleared	Cleared	Cleared	Cleared	Cleared	Cleared
Index Registers (IR)		Cleared	Retained	Retained	Retained	Cleared	Retained	Cleared	Cleared	Cleared	Retained
Data Registers (DR)		Cleared	Retained	Retained	Retained	Cleared	Retained	Cleared	Cleared	Cleared	Retained


- Note**
1. Mode changed from PROGRAM to RUN/MONITOR or vice-versa.
 2. The PLC Setup's *IOM Hold Bit Status at Startup* setting determines whether the IOM Hold Bit's status is held or cleared when the PLC is turned ON.

4-1-4 Hot Start/Hot Stop Functions

Operating Mode Changes


Hot Start

Turn ON the IOM Hold Bit to retain all data* in I/O memory when the CPU Unit is switched from PROGRAM mode to RUN/MONITOR mode to start program execution.



Hot Stop

When the IOM Hold Bit is ON, all data* in I/O memory will also be retained when the CPU Unit is switched from RUN or MONITOR mode to PROGRAM mode to stop program execution.



Note *The following areas of I/O memory will be cleared during mode changes (between PROGRAM and RUN/MONITOR) unless the IOM Hold Bit is ON: the CIO Area (I/O Area, Data Link Area, CPU Bus Unit Area, Special I/O Unit Area, DeviceNet (CompoBus/D) Area, and Internal I/O Areas), Work Area, Timer Completion Flags, and Timer PVs.

Auxiliary Area Flags and Words

Name	Address	Description
IOM Hold Bit	A500.12	Specifies whether the I/O memory will be retained or not when the CPU Unit operating mode is changed (between PROGRAM and RUN/MONITOR) or when the power is cycled. OFF: I/O memory is cleared to 0 when the operating mode is changed. ON: I/O memory is retained when the operating mode is changed between PROGRAM and RUN or MONITOR.

When the IOM Hold Bit is ON, all outputs from Output Units will be maintained when program execution stops. When the program starts again, outputs will have the same status that they had before the program was stopped and instructions will be executed. (When the IOM Hold Bit is OFF, instructions will be executed after the outputs have been cleared.)

PLC Power ON

In order for all data* in I/O memory to be retained when the PLC is turned ON, the IOM Hold Bit must be ON and it must be protected in the PLC Setup using the *IOM Hold Bit Status at Startup* parameter.



Auxiliary Area Flags and Words

Name	Address	Description
IOM Hold Bit	A500.12	Specifies whether the I/O memory will be retained or not when the CPU Unit operating mode is changed (between PROGRAM and RUN/MONITOR) or when the power is cycled. OFF: I/O memory is cleared to 0 when the operating mode is changed. ON: I/O memory is retained when the operating mode is changed between PROGRAM and RUN or MONITOR.

PLC Setup

Name	Description	Setting	Default
IOM Hold Bit Status at Startup	To retain all data in I/O memory when the PLC is turned ON, set the <i>IOM Hold Bit at startup</i> parameter to hold the status of the I/O Hold Bit.	OFF: The IOM Hold Bit is cleared to 0 when power is cycled. ON: The status of the IOM Hold Bit is retained when power is cycled.	OFF (Cleared)

4-2 I/O Area and I/O Allocations

Input Bits: CIO 0.00 to CIO 16.15 (17 words)

Output Bits: CIO 100.00 to CIO 116.15 (17 words)

The starting words for inputs and outputs are predetermined for CP1H CPU Unit. Input bits in CIO 0 and CIO 1 and output bits in CIO 100 and CIO 101 are automatically allocated to the built-in I/O on the CPU Unit. CP-series Expansion Units and CP-series Expansion I/O Units are automatically allocated input bits in words starting from CIO 2 and output bits in words starting from CIO 102.

Note CJ-series Basic Units cannot be connected to a CP1H PLCs.

Bits in the I/O Area can be force-set/reset from the CX-Programmer.


The I/O Area will be cleared at the following times:

- (1) When the operating mode is changed between PROGRAM mode and RUN or MONITOR mode
- (2) When the power is cycled
- (3) When I/O memory is cleared from the CX-Programmer
- (4) When operation fails due to a fatal error other than one created by executing a FALS(007) instruction (Memory will be retained if operation fails due to execution of a FALS(007) instruction.)

4-2-1 Overview

CIO 0 and CIO 1 are allocated to the built-in inputs and CIO 100 and CIO 101 are allocated to the built-in outputs on the CPU Unit.

For CP-series Expansion Units and Expansion I/O Units, inputs are allocated in the order that the Units are connected starting from CIO 2 in the Input Area and from CIO 102 in the Output Area. (See note.)




A total of up to seven CP-series Expansion Units and Expansion I/O Units can be connected. The total number of input words and output words must be 17 or less. A fatal error (Too Many I/O Points) will occur if this limit is exceeded, and operation will stop.

4-2-2 Allocations to Built-in General Purpose I/O on the CPU Unit


The bits that are allocated depend on the model of CPU Unit, as shown in the following figures.

Allocations for X and XA CPU Units (24 Inputs/16 Outputs)

Bits are allocated for X and XA CPU Units as shown in the following figure.




Input Bit Allocations



For X and XA CPU Units, a total of 24 input bits are allocated: 12 bits in CIO 0 from bit 00 to bit 11 and 12 bits in CIO 1 from bit 00 to bit 11. Bits 12 to 15 in CIO 0 and CIO 1 are always cleared and cannot be used as work bits.


Output Bit Allocations




For X and XA CPU Units, a total of 16 output bits are allocated: eight bits in CIO 100 from bit 00 to bit 07 and eight bits in CIO 101 from bit 00 to bit 07. Bits 08 to 15 in CIO 100 and CIO 101 can be used as work bits.

4-2-3 Allocations to CP1H Y CPU Units (12 Inputs/8 Outputs)

Bits are allocated to a Y CPU Unit in discontinuous positions, as shown in the figure below, due to allocations for the pulse I/O terminals.




Input Bit Allocations



As shown above, a total of 12 input bits in CIO 0 and CIO 1 are allocated for the Y CPU Unit. Unused bits in CIO 0 and CIO 1 are always cleared and cannot be used as work bits.

Output Bit Allocations



As shown above, a total of 8 output bits in CIO 100 and CIO 101 are allocated for the Y CPU Unit. Unused bits can be used as work bits.

4-2-4 Allocations to CP1W Expansion Units and Expansion I/O Units

Expansion I/O Units

There are Expansion I/O Units for expanding inputs, for expanding outputs, and for expanding both input and outputs. I/O bits starting from bit 00 in the next word after the word allocated to the previous Expansion Unit, Expansion


I/O Unit, or CPU Unit are automatically allocated. This word is indicated as “CIO m” for input words and as “CIO n” for output words.

Unit			Input bits			Output bits		
			No. of bits	No. of words	Addresses	No. of bits	No. of words	Addresses
Unit with 8 inputs		CP1W-8ED	8 bits	1 word	CIO m (bits 00 to 07)	---	None	None
Unit with 8 outputs	Relays	CP1W-8ER	---	None	None	8 bits	1 word	CIO n (bits 00 to 07)
	Sinking transistors	CP1W-8ET	---	None	None	8 bits	1 word	CIO n (bits 00 to 07)
	Sourcing transistors	CP1W-8ET1	---	None	None	8 bits	1 word	CIO n (bits 00 to 07)
Unit with 16 out-puts	Relays	CP1W-16ER	---	None	None	16 bits	2 words	CIO n (bits 00 to 07) CIO n+1 (bits 00 to 07)
	Sinking transistors	CP1W-16ET	---	None	None	16 bits	2 words	CIO n (bits 00 to 07) CIO n+1 (bits 00 to 07)
	Sourcing transistors	CP1W-16ET1	---	None	None	16 bits	2 words	CIO n (bits 00 to 07) CIO n+1 (bits 00 to 07)
Unit with 20 I/O	Relays	CP1W-20EDR1	12 bits	1 word	CIO m (bits 00 to 11)	8 bits	1 word	CIO n (bits 00 to 07)
	Sinking transistors	CP1W-20EDT	12 bits	1 word	CIO m (bits 00 to 11)	8 bits	1 word	CIO n (bits 00 to 07)
	Sourcing transistors	CP1W-20EDT1	12 bits	1 word	CIO m (bits 00 to 11)	8 bits	1 word	CIO n (bits 00 to 07)
Unit with 32 outputs	Relays	CP1W-32ER	---	None	None	32 bits	4 words	CIO n (bits 00 to 07) CIO n+1 (bits 00 to 07) CIO n+2 (bits 00 to 07) CIO n+3 (bits 00 to 07)
	Sinking transistors	CP1W-32ET	---	None	None	32 bits	4 words	CIO n (bits 00 to 07) CIO n+1 (bits 00 to 07) CIO n+2 (bits 00 to 07) CIO n+3 (bits 00 to 07)
	Sourcing transistors	CP1W-32ET1	---	None	None	32 bits	4 words	CIO n (bits 00 to 07) CIO n+1 (bits 00 to 07) CIO n+2 (bits 00 to 07) CIO n+3 (bits 00 to 07)
Unit with 40 I/O	Relays	CP1W-40EDR	24 bits	2 words	CIO m (bits 00 to 11) CIO m+1 (bits 00 to 11)	16 bits	2 words	CIO n (bits 00 to 07) CIO n+1 (bits 00 to 07)
	Sinking transistors	CP1W-40EDT	24 bits	2 words	CIO m (bits 00 to 11) CIO m+1 (bits 00 to 11)	16 bits	2 words	CIO n (bits 00 to 07) CIO n+1 (bits 00 to 07)
	Sourcing transistors	CP1W-40EDT1	24 bits	2 words	CIO m (bits 00 to 11) CIO m+1 (bits 00 to 11)	16 bits	2 words	CIO n (bits 00 to 07) CIO n+1 (bits 00 to 07)

■ I/O Bit Addresses

Units 8 Input Points (CP1W-8ED)


Eight input bits are allocated in one word (bits 00 to 07 in CIO m).



Only one word (8 bits) is allocated to an 8-input Expansion Input Unit. No output words are allocated. Input bits 08 to 15 are always cleared by the system and cannot be used as work bits.

Units with 8 Output Points (CP1W-8E□□)


Eight output bits are allocated in one word (bits 00 to 07 in CIO n+1).



Only one word (8 bits) is allocated to an 8-output Expansion Output Unit. No input words are allocated. Output bits 08 to 15 can be used as work bits.

Units with 16 Output Points (CP1W-16E□□)


Sixteen output bits in two words are allocated in two words (bits 00 to 07 in CIO n and bits 00 to 07 in CIO n+1).



Two words (16 bits) are allocated to a 16-output Expansion Output Unit. No input words are allocated. Output bits 08 to 15 can be used as work bits.

Units with 20 I/O Points (CP1W-20ED□□)

Twelve input bits are allocated in one word (bits 00 to 11 in CIO m). Eight output bits are allocated in one word (bits 00 to 07 in CIO n).




One input word (12 bits) and one output word (8 bits) are allocated for a 20-point Expansion I/O Unit.

Input bits 12 to 15 are always cleared by the system and cannot be used as work bits. Output bits 08 to 15, however, can be used as work bits.

Units with 32 Output Points (CP1W-32E□□)


Thirty-two output bits are allocated in four words (bits 00 to 07 in CIO n, bits 00 to 07 in CIO n+1, bits 00 to 07 in CIO n+2 and bits 00 to 07 in CIO n+3).



Four words (32 bits) are allocated to a 32-output Expansion Output Unit. No input words are allocated. Output bits 08 to 15 can be used as work bits.

Units with 40 I/O Points (CP1W-40ED□□)

Twenty-four input bits in two words are allocated (bits 00 to 11 in CIO m and bits 00 to 11 CIO m+1). Sixteen output bits in two words are allocated (bits 00 to 07 in CIO n and bits 00 to 07 in CIO n+1).



Two input words (24 bits) and two output words (16 bits) are allocated to a 40-point Expansion I/O Unit. Input bits 12 to 15 cannot be used as work bits. Output bits 08 to 15, however, can be used as work bits.

Expansion Units

Unit		Input words		Output words	
Analog I/O Units	CP1W-MAD11	2 words	CIO m to CIO m+1	1 word	CIO n
	CP1W-MAD42	4 words	CIO m to CIO m+3	2 words	CIO n to CIO n+1
	CP1W-MAD44	4 words	CIO m to CIO m+3	4 words	CIO n to CIO n+3
Analog Input Units	CP1W-AD041	4 words	CIO m to CIO m+3	2 words	CIO n to CIO n+1
	CP1W-AD042				


Unit		Input words		Output words	
Analog Output Units	CP1W-DA021	None	---	2 words	CIO n to CIO n+1
	CP1W-DA041	None	---	4 words	CIO n to CIO n+3
	CP1W-DA042				
Temperature Sensor Units	CP1W-TS001	2 words	CIO m to CIO m+1	None	---
	CP1W-TS002	4 words	CIO m to CIO m+3	None	---
	CP1W-TS003	4 words	CIO m to CIO m+3	None	---
	CP1W-TS004	2 words	CIO m to CIO m+1	1 word	CIO n
	CP1W-TS101	2 words	CIO m to CIO m+1	None	---
	CP1W-TS102	4 words	CIO m to CIO m+3	None	---
CompoBus/S I/O Link Units	CP1W-SRT21	1 word	CIO m	1 word	CIO n

m: Indicates the next input word after the input word allocated to the Expansion Unit, Expansion I/O Unit, or CPU Unit to the left of the current Unit.

n: Indicates the next output word after the output word allocated to the Expansion Unit, Expansion I/O Unit, or CPU Unit to the left of the current Unit.

■ I/O Word Allocations to Expansion Units

CPU Unit with 40 I/O Points + TS002 + DA041 + 40ED




4-2-5 I/O Allocation Examples

Do not exceed the connection restrictions when connecting Expansion Units and Expansion I/O Units.

1. A maximum of up to 7 Units can be connected.
2. A maximum of 15 input and output words can be allocated (Input: up to CIO 16, output: up to CIO 116).


Also, the number of Units that can be connected is also restricted by the current consumption. Refer to *1-2-4 Restrictions on System Configuration* for details.

Example 1: Connecting Seven Expansion Units and Expansion I/O Units



If there is a Unit that does not use input or output words, the words are allocated to the next Unit.

Example 2: Including a CP1W-TS002/TS102 Temperature Sensor Unit



A total of up to seven Expansion Units and Expansion I/O Units can be connected. Four input words, however, are allocated to one TS002/TS102 Unit. Therefore, a maximum of three TS002/TS102 Units can be connected due to the input word limit.

4-3 Built-in Analog I/O Area (XA CPU Units Only)

Built-in Analog Input Bits: CIO 200 to CIO 203 (4 words)

Built-in Analog Output Bits: CIO 210 to CIO 211 (2 words)

The built-in analog inputs and built-in analog outputs for XA CPU Units are always allocated words between CIO 200 and CIO 211.

Data	Allocated words	Description		
		Data	1/6000 resolution	1/12000 resolution
Analog input A/D conversion data	CIO 200	Analog input 0	–10 to 10 V: F448 to 0BB8 hex Other ranges: 0000 to 1770 hex	–10 to 10 V: E890 to 1770 hex Other ranges: 0000 to 2EE0 hex
	CIO 201	Analog input 1		
	CIO 202	Analog input 2		
	CIO 203	Analog input 3		
Analog output D/A conversion data	CIO 210	Analog output 0		
	CIO 211	Analog output 1		

The Analog I/O Area will be cleared at the following times:

1. When the operating mode is changed between PROGRAM and RUN or MONITOR mode (See note.)
2. When the power is cycled
3. When analog I/O memory is cleared from the CX-Programmer
4. When operation fails due to a fatal error other than one created by executing a FALS(007) instruction (Memory will be retained if operation fails due to execution of a FALS(007) instruction.)

Note The built-in analog outputs will operate as follows when the operating mode is switched between RUN or MONITOR mode and PROGRAM mode:


I/O Memory Hold Bit (A500.12)	Operation
OFF	The analog output values in the words allocated in memory will be cleared and the 0000 hex will be output for the output refresh.
ON	The analog output values in the words allocated in memory will retain their values from right before the operating mode was changed and the previous values will be output for the output refresh.

Note Control of the built-in analog outputs will temporarily stop when Memory Cassette data is being transferred or verified. Therefore, if the operating mode is switched between PROGRAM and RUN or MONITOR mode when the built-in analog output is being used and the I/O Memory Hold Bit is set to ON to retain analog values output externally, the values will change; the analog values output externally will not be retained while Memory Cassette data is being transferred or verified. The analog output values will return to the original retained values when the transfer or verification has been completed.

4-4 Data Link Area

Data Link Area addresses range from CIO 1000 to CIO 1199 (bits CIO 1000.00 to CIO 1199.15). Words in the Link Area are used for data links when *LR* is set as the data link area for Controller Link Networks. It is also used for PLC Links. Words in the Link Area can be used in the program when *LR* is not set as the data link area for Controller Link Networks and PLC Links are not used.

Data links can be generated automatically (using the same number of words for each node) or manually. When a user defines the data links manually, any number of words can be assigned to each node, and nodes can be made receive-only or transmit-only. Refer to the *Controller Link Units Operation Manual (W309)* for details.



Forcing Bit Status

Bits in the Data Link Area can be force-set and force-reset.

Links to C200HX/HG/HE, C200HS, and C200H PLCs

Link Area words CIO 1000 to CIO 1063 in CP1H CPU Units correspond to Link Relay Area words LR 0 to LR 63 for data links created in C200HX/HG/HE(-Z) PLCs. When converting C200HX/HG/HE(-Z), C200HS, or C200H programs for use in CP1H CPU Units, change addresses LR 0 through LR 63 to Link Area addresses CIO 1000 through CIO 1063.

Link Area Initialization


The contents of the Link Area will be cleared in the following cases:

1. When the operating mode is changed from PROGRAM mode to RUN/MONITOR mode or vice-versa and the IOM Hold Bit is OFF
2. When the power is cycled
3. When the Data Link Area is cleared from the CX-Programmer
4. When PLC operation is stopped when a fatal error other than an FALS(007) error occurs. (The contents of the Link Area will be retained if FALS(007) is executed.)

4-5 CPU Bus Unit Area

The CPU Bus Unit Area contains 400 words with addresses ranging from CIO 1500 to CIO 1899. Words in the CPU Bus Unit Area can be allocated to CPU Bus Units to transfer data such as the operating status of the Unit. Each Unit is allocated 25 words based on the Unit's unit number setting.

Data is exchanged with CPU Bus Units once each cycle during I/O refreshing, which occurs after program execution. (Words in this data area cannot be refreshed with immediate-refreshing or IORF(097).)



Each CPU Bus Unit is allocated 25 words based on its unit number, as shown in the following table.

Unit number	Allocated words	Unit number	Allocated words
0	CIO 1500 to CIO 1524	8	CIO 1700 to CIO 1724
1	CIO 1525 to CIO 1549	9	CIO 1725 to CIO 1749
2	CIO 1550 to CIO 1574	A	CIO 1750 to CIO 1774
3	CIO 1575 to CIO 1599	B	CIO 1775 to CIO 1799
4	CIO 1600 to CIO 1624	C	CIO 1800 to CIO 1824
5	CIO 1625 to CIO 1649	D	CIO 1825 to CIO 1849
6	CIO 1650 to CIO 1674	E	CIO 1850 to CIO 1874
7	CIO 1675 to CIO 1699	F	CIO 1875 to CIO 1899

The function of the 25 words depends upon the CPU Bus Unit being used. For details, refer to the Unit's operation manual.

Words in the CPU Bus Unit Area that aren't allocated to CPU Bus Units can be used in programming.

Forcing Bit Status

CPU Bus Unit Area Initialization

Bits in the CPU Bus Unit Area can be force-set and force-reset.


The contents of the CPU Bus Unit Area will be cleared in the following cases:

1. When the operating mode is changed from PROGRAM to RUN or MONITOR mode or vice-versa and the IOM Hold Bit is OFF
2. When the power is cycled and the IOM Hold Bit is OFF or not protected in the PLC Setup
3. When the CPU Bus Unit Area is cleared from the CX-Programmer
4. When PLC operation is stopped when a fatal error other than an FALS(007) error occurs (The contents of the CPU Bus Unit Area will be retained when FALS(007) is executed.)

4-6 Special I/O Unit Area

The Special I/O Unit Area contains 960 words with addresses ranging from CIO 2000 to CIO 2959. Words in the Special I/O Unit Area are allocated to transfer data, such as the operating status of the Unit. Each Unit is allocated 10 words based on its unit number setting.

Data is exchanged with Special I/O Units once each cycle during I/O refreshing, which occurs after program execution. The words can also be refreshed with IORF(097).



Each Special I/O Unit is allocated 25 words based on its unit number, as shown in the following table.

Unit number	Allocated words
0	CIO 2000 to CIO 2009
1	CIO 2010 to CIO 2019
2	CIO 2020 to CIO 2029
3	CIO 2030 to CIO 2039
⋮	⋮
95	CIO 2950 to CIO 2959

Words in the Special I/O Unit Area that are not allocated to Special I/O Units can be used in programming.

Forcing Bit Status

Special I/O Unit Area Initialization

Bits in the Special I/O Unit Area can be force-set and force-reset.

The contents of the Special I/O Unit Area will be cleared in the following cases:

1. When the operating mode is changed from PROGRAM mode to RUN/MONITOR mode or vice-versa and the IOM Hold Bit is OFF
2. When the power is cycled
3. When the Special I/O Unit Area is cleared from the CX-Programmer
4. When PLC operation is stopped when a fatal error other than an FALS(007) error occurs (The contents of the Special I/O Unit Area will be retained when FALS(007) is executed).


4-7 Serial PLC Link Area

The Serial PLC Link Area contains 90 words with addresses ranging from CIO 3100 to CIO 3189 (bits CIO 3100.00 to CIO 3189.15). Words in the Serial PLC Link Area can be used for data links with other PLCs.

Serial PLC Links exchange data among CPU Units via the built-in RS-232C ports, with no need for special programming.

The Serial PLC Link allocations are set automatically by means of the following PLC Setup in the Polling Unit.

- Serial PLC Link Mode
- Number of Serial PLC Link transfer words
- Maximum Serial PLC Link unit number



Addresses not used for Serial PLC Links can be used in programming, the same as the Work Area.

Forcing Bit Status

Bits in the Serial PLC Link Area can be force-set and force-reset.

Serial PLC Link Area Initialization

The contents of the Serial PLC Link Area will be cleared in the following cases:

1. When the operating mode is changed from PROGRAM mode to RUN/MONITOR mode or vice-versa and the IOM Hold Bit is OFF
2. When the power is cycled
3. When the Serial PLC Link Area is cleared from the CX-Programmer
4. When PLC operation is stopped when a fatal error other than an FALS(007) error occurs (The contents of the Serial PLC Link Area will be retained when FALS(007) is executed.)

4-8 DeviceNet Area

The DeviceNet Area consists of 600 words from CIO 3200 to CIO 3799. Words in the DeviceNet Area are allocated to Slaves for DeviceNet remote I/O communications.

Words are allocated to Slaves using fixed allocations according to fixed allocation settings 1, 2, and 3. One of these fixed areas must be selected.

Area	Output Area (master to slaves)	Input Area (slaves to master)
Fixed Allocation Area 1	CIO 3200 to CIO 3263	CIO 3300 to CIO 3363
Fixed Allocation Area 2	CIO 3400 to CIO 3463	CIO 3500 to CIO 3563
Fixed Allocation Area 3	CIO 3600 to CIO 3663	CIO 3700 to CIO 3763

The following words are allocated to the DeviceNet Unit when the remote I/O slave function is used with fixed allocations.

Area	Output Area (master to slaves)	Input Area (slaves to master)
Fixed Allocation Area 1	CIO 3370	CIO 3270
Fixed Allocation Area 2	CIO 3570	CIO 3470
Fixed Allocation Area 3	CIO 3770	CIO 3670

The DeviceNet Area can be used in programming if a CJ-series DeviceNet Unit is not used.

Forcing Bit Status

Bits in the DeviceNet Area can be force-set and force-reset.

Note There are two ways to allocated I/O in DeviceNet networks: Fixed allocations according to node addresses and user-set allocations.

- With fixed allocations, words are automatically allocated to the slaves in the specified fixed allocation area according to node addresses.
- With user-set allocations, the user can allocate words to Slaves from the following words.

CIO 17 to CIO 99, CIO 117 to CIO 6143(See note.)

W0 to W511


H0 to H511

D0 to D32767

For details on word allocations, refer to the *DeviceNet Operation Manual (W267)*.

Note 0~16CH cannot be assigned as input relay area and 100~116CH as output relay area.

For XA type, 200~203CH and 210~213CH cannot be assigned as built-in analog input/output area.



DeviceNet Area Initialization

The contents of the DeviceNet Area will be cleared in the following cases:

1. When the operating mode is changed from PROGRAM to RUN or MONITOR mode or vice-versa and the IOM Hold Bit is OFF
2. When the power is cycled
3. When the DeviceNet Area is cleared from the CX-Programmer
4. When PLC operation is stopped when a fatal error other than an FALS(007) error occurs (The contents of the DeviceNet Area will be retained when FALS(007) is executed.)

4-9 Internal I/O Area

The Internal I/O (Work) Area contains 512 words with addresses ranging from W0 to W511. These words can be used in programming as work words.

There are unused words in the CIO Area (CIO 1200 to CIO 1499 and CIO 3800 to CIO 6143) that can also be used in the program, but use any available words in the Work Area first because the unused words in the CIO Area may be allocated to other applications when functions are expanded.

Forcing Bit Status

Bits in the Work Area can be force-set and force-reset.

Work Area Initialization

The contents of the Work Area will be cleared in the following cases:

1. When the operating mode is changed from PROGRAM to RUN or MONITOR mode or vice-versa and the IOM Hold Bit is OFF
2. When the power is cycled
3. When the Work Area is cleared from the CX-Programmer.
4. When PLC operation is stopped when a fatal error other than an FALS(007) error occurs. (The contents of the Work Area will be retained when FALS(007) is executed.)

4-10 Holding Area (H)

The Holding Area contains 512 words with addresses ranging from H0 to H511 (bits H0.00 to H511.15). These words can be used in programming.

Holding Area Initialization

Data in the Holding Area is not cleared when the power is cycled or the PLC's operating mode is changed from PROGRAM mode to RUN or MONITOR mode or vice-versa.


A Holding Area bit will be cleared if it is programmed between IL(002) and ILC(003) and the execution condition for IL(002) is OFF. To keep a bit ON even when the execution condition for IL(002) is OFF, turn ON the bit with the SET instruction just before IL(002).

Self-maintaining Bits

When a self-maintaining bit is programmed with a Holding Area bit, the self-maintaining bit won't be cleared even when the power is reset.

Note

1. If a Holding Area bit is not used for the self-maintaining bit, the bit will be turned OFF and the self-maintaining bit will be cleared when the power is reset.
2. If a Holding Area bit is used but not programmed as a self-maintaining bit as in the following diagram, the bit will be turned OFF by execution condition A when the power is reset.




3. H512 to H1535 are used as a Function Block Holding Area. These words can be used only for function block instances (internally allocated variable


area). These words cannot be specified as instruction operands in the user program.

Precautions

When a Holding Area bit is used in a KEEP(011) instruction, never use a normally closed condition for the reset input if the input device uses an AC power supply. When the power supply goes OFF or is temporarily interrupted, the input will go OFF before the PLC's internal power supply and the Holding Area bit will be reset.



Instead, use a configuration like the one shown below.



There are no restrictions in the order of using bit address or in the number of N.C. or N.O. conditions that can be programmed.

4-11 Auxiliary Area (A)

The Auxiliary Area contains 960 words with addresses ranging from A0 to A959). These words are preassigned as flags and control bits to monitor and control operation.

A0 through A447 are read-only, but A448 through A959 can be read or written from the program or the CX-Programmer.

Refer to *Appendix C Auxiliary Area Allocations by Function* and *Appendix D Auxiliary Area Allocations by Address* for Auxiliary Area functions.

Forcing Bit Status

Read/write bits in the Auxiliary Area cannot be force-set and force-reset continuously.

4-12 TR (Temporary Relay) Area

The TR Area contains 16 bits with addresses ranging from TR0 to TR15. These temporarily store the ON/OFF status of an instruction block for branching and are used only with mnemonics. TR bits are useful when there are several output branches and interlocks cannot be used.

The TR bits can be used as many times as required and in any order required as long as the same TR bit is not used twice in the same instruction block.


TR bits can be used only with the OUT and LD instructions. OUT instructions (OUT TR0 to OUT TR15) store the ON OFF status of a branch point and LD instructions recall the stored ON OFF status of the branch point.

Forcing Bit Status

TR bits cannot be changed from the CX-Programmer.


Examples

In this example, a TR bit is used when two outputs have been directly connected to a branch point.




Instruction	Operand
LD	0.00
OR	0.01
OUT	TR 0
AND	0.02
OUT	0.03
LD	TR 0
AND	0.04
OUT	0.05

In this example, a TR bit is used when an output is connected to a branch point without a separate execution condition.



Instruction	Operand
LD	0.00
OUT	TR 0
AND	0.01
OUT	0.02
LD	TR 0
OUT	0.03

Note A TR bit is not required when there are no execution conditions after the branch point or there is an execution condition only in the last line of the instruction block.



Instruction	Operand
LD	0.00
OUT	0.01
OUT	0.02

Instruction	Operand
LD	0.00
OUT	0.01
AND	0.02
OUT	0.03

4-13 Timers and Counters

4-13-1 Timer Area (T)

The 4,096 timer numbers (T0000 to T4095) are shared by the TIM, TIMX(550), TIMH(015), TIMHX(551), TMHH(540), TIMHHX(552), TTIM(087), TTIMX(555), TIMW(813), TIMWX(816), TMHW(815), and TIMHWX(817) instructions. Timer Completion Flags and present values (PVs) for these instructions are accessed with the timer numbers.

The TIML(542), TIMLX(553), MTIM(543), and MTIMX(554) instructions do not use timer numbers.

When a timer number is used in an operand that requires bit data, the timer number accesses the Completion Flag of the timer. When a timer number is used in an operand that requires word data, the timer number accesses the PV of the timer. Timer Completion Flags can be used as often as necessary as normally open and normally closed conditions and the values of timer PVs can be read as normal word data.

The refresh method for timer PVs can be set from the CX-Programmer to either BCD or binary.

Note It is not recommended to use the same timer number in two timer instructions because the timers will not operate correctly if they are timing simultaneously. (If two or more timer instructions use the same timer number, an error will be generated during the program check, but the timers will operate as long as the instructions are not executed in the same cycle.)

The following table shows when timers will be reset or maintained.

Instruction name	Effect on PV and Completion Flag			Operation in Jumps and Interlocks	
	Mode change ¹	PLC start-up ²	CNR(545)/CN RX(547)	Jumps (JMP-JME) or Tasks on standby ⁴	Interlocks (IL-ILC)
TIMER: TIM/TIMX(550)	PV → 0 Flag → OFF	PV → 0 Flag → OFF	PV → 9999 Flag → OFF	PVs refreshed in operating timers	PV → SV (Reset to SV.) Flag → OFF
HIGH-SPEED TIMER: TIMH(015)/TIMHX(551)					
ONE-MS TIMER: TMHH(540)/TMHHX(552)					
ACCUMULATIVE TIMER: TTIM(087)/TTIMX(555)				PV Maintained	PV Maintained
TIMER WAIT: TIMW(813)/TIMWX(816)				PVs refreshed in operating timers	---
HIGH-SPEED TIMER WAIT: TMHW(815)/TMHWX(817)					---

- Note**
1. If the IOM Hold Bit (A500.12) is ON, the PV and Completion Flag will be retained when a fatal error occurs (including execution of FALS instructions) or the operating mode is changed from PROGRAM mode to RUN or MONITOR mode or vice-versa. The PV and Completion Flag will be cleared when power is cycled.
 2. If the IOM Hold Bit (A500.12) is ON and the PLC Setup's *IOM Hold Bit Status at Startup* setting is set to protect the IOM Hold Bit, the PV and Completion Flag will be retained when the PLC's power is cycled.
 3. Since the TIML(542), TIMLX(553), MTIM(543), and MTIMX(554) instructions do not use timer numbers, they are reset under different conditions. Refer to the descriptions of these instructions for details.
 4. The present value of TIM, TIMX(550), TIMH(015), TIMHX(551), TMHH(540), TMHHX(552), TIMW(813), TIMWX(816), TMHW(815) and TMHWX(817) timers programmed with timer numbers 0000 to 2047 will be updated even when jumped between JMP and JME instructions or when in a task that is on standby. The present value of timers programmed with timer numbers 2048 to 4095 will be held when jumped or when in a task that is on standby.

Forcing Bit Status

Timer Completion Flags can be force-set and force-reset.

Timer PVs cannot be force-set or force-reset, although the PVs can be refreshed indirectly by force-setting/resetting the Completion Flag.

Restrictions

There are no restrictions in the order of using timer numbers or in the number of N.C. or N.O. conditions that can be programmed. Timer PVs can be read as word data and used in programming.

4-13-2 Counter Area (C)

The 4,096 counter numbers (C0000 to C4095) are shared by the CNT, CNTX(546), CNTR(012), CNTRX(548), CNTW(814), and CNTWX(818) instructions. Counter Completion Flags and present values (PVs) for these instructions are accessed with the counter numbers.

When a counter number is used in an operand that requires bit data, the counter number accesses the Completion Flag of the counter. When a counter number is used in an operand that requires word data, the counter number accesses the PV of the counter.

The refresh method for counter PVs can be set from the CX-Programmer to either BCD or binary. (Refer to the previous page).

It is not recommended to use the same counter number in two counter instructions because the counters will not operate correctly if they are counting simultaneously. If two or more counter instructions use the same counter number, an error will be generated during the program check, but the counters will operate as long as the instructions are not executed in the same cycle.

The following table shows when counter PVs and Completion Flags will be reset.

Instruction name	Effect on PV and Completion Flag					
	Reset	Mode change	PLC startup	Reset Input	CNR(545)/CN RX(547)	Interlocks (IL-ILC)
COUNTER: CNT/CNTX(546)	PV → 0 Flag → OFF	Maintained	Maintained	Reset	Reset	Maintained
REVERSIBLE COUNTER: CNTR(012)/CNTRX(548)						
COUNTER WAIT: CNTW(814)/CNTWX(818)						

Forcing Bit Status

Counter Completion Flags can be force-set and force-reset.

Counter PVs cannot be force-set or force-reset, although the PVs can be refreshed indirectly by force-setting/resetting the Completion Flag.

Restrictions


There are no restrictions in the order of using counter numbers or in the number of N.C. or N.O. conditions that can be programmed. Counter PVs can be read as word data and used in programming.

4-13-3 Changing the BCD or Binary Mode for Counters and Timers


The refresh method for set values and present values for timers and counters can be changed from BCD mode (0000 to 9999) to binary method (0000 to FFFF) using the CX-Programmer

This setting is made in common for all tasks for all timers and counters.

1. Right-click **New PLC** in the project tree and select **Properties**.



2. Select the *Execute Timer/Counter as Binary* Option in the PLC Properties Dialog Box. The timers and counters for all tasks will be executed in binary mode.



4-14 Data Memory Area (D)

The DM Area contains 32,768 words with addresses ranging from D0 to D32767. This data area is used for general data storage and manipulation and is accessible only by word.

Data in the DM Area is retained when the PLC's power is cycled or the PLC's operating mode is changed from PROGRAM mode to RUN/MONITOR mode or vice-versa.

Although bits in the DM Area cannot be accessed directly, the status of these bits can be accessed with the BIT TEST instructions, TST(350) and TSTN(351).

Forcing Bit Status

Bits in the DM Area cannot be force-set or force-reset.

Indirect Addressing

Words in the DM Area can be indirectly addressed in two ways: binary-mode and BCD-mode.

Binary-mode Addressing (@D)

When a “@” character is input before a DM address, the content of that DM word is treated as binary and the instruction will operate on the DM word at that binary address. The entire DM Area (D0 to D32767) can be indirectly addressed with hexadecimal values 0000 to 7FFF.

**BCD-mode Addressing (*D)**

When a “*” character is input before a DM address, the content of that DM word is treated as BCD and the instruction will operate on the DM word at that BCD address. Only part of the DM Area (D0 to D09999) can be indirectly addressed with BCD values 0000 to 9999.

**DM Area Allocation to Special I/O Units**

Parts of the DM Area are allocated to Special I/O Units and CPU Bus Units for functions such as initial Unit settings. The timing for data transfers is different for these Units, but may occur at any of the three following times.


1,2,3...

1. Transfer data when the PLC's power is cycled or the Unit is restarted.
2. Transfer data once each cycle.
3. Transfer data when required.

Refer to the Unit's operation manual for details on data transfer timing.


Special I/O Units (D20000 to D29599)

Each Special I/O Unit is allocated 100 words based on unit numbers 0 to 95. Refer to the Unit's operation manual for details on the function of these words.



CPU Bus Units (D30000 to D31599)

Each CPU Bus Unit is allocated 100 words (based on unit numbers 0 to F). Refer to the Unit's operation manual for details on the function of these words. With some CPU Bus Units such as Ethernet Units, initial settings must be registered in the CPU Unit's Parameter Area; this data can be registered with the CX-Programmer.

**■ DM Fixed Allocation Words for Modbus-RTU Easy Master**

The following DM area words are used as command and response storage areas for the Modbus-RTU Easy Master function.

D32200 to D32299: Serial port 1

D32300 to D32399: Serial port 2

For use of these areas, refer to 6-1-3 *Modbus-RTU Easy Master Function*.

4-15 Index Registers

The sixteen Index Registers (IR0 to IR15) are used for indirect addressing. Each Index Register can hold a single PLC memory address, which is the absolute memory address of a word in I/O memory. Use MOVR(560) to convert a regular data area address to its equivalent PLC memory address and write that value to the specified Index Register. (Use MOVW(561) to set the PLC memory address of a timer/counter PV in an Index Register.)


Note Refer to *Appendix E Memory Map* for more details on PLC memory addresses.

Indirect Addressing

When an Index Register is used as an operand with a “,” prefix, the instruction will operate on the word indicated by the PLC memory address in the Index Register, not the Index Register itself. Basically, the Index Registers are I/O memory pointers.

- All addresses in I/O memory (except Index Registers, Data Registers, and Condition Flags) can be specified seamlessly with PLC memory addresses. It isn't necessary to specify the data area. I/O memory addresses for IR, DR, and Condition Flags, however, cannot be held.
- In addition to basic indirect addressing, the PLC memory address in an Index Register can be offset with a constant or Data Register, auto-incremented, or auto-decremented. These functions can be used in loops to read or write data while incrementing or decrementing the address by one each time that the instruction is executed.

With the offset and increment/decrement variations, the Index Registers can be set to base values with MOVR(560) or MOVW(561) and then modified as pointers in each instruction.



Note It is possible to specify regions outside of I/O memory and generate an Illegal Access Error when indirectly addressing memory with Index Registers. Refer to *Appendix E Memory Map* for details on the limits of PLC memory addresses.


The following table shows the variations available when indirectly addressing I/O memory with Index Registers. (IR□ represents an Index Register from IR0 to IR15.)

Variation	Function	Syntax	Example	
Indirect addressing	The content of IR□ is treated as the PLC memory address of a bit or word.	,IR□	LD ,IR0	Loads the bit at the PLC memory address contained in IR0.
Indirect addressing with constant offset	The constant prefix is added to the content of IR□ and the result is treated as the PLC memory address of a bit or word. The constant may be any integer from -2,048 to 2,047.	Constant ,IR□ (Include a + or - in the constant.)	LD +5,IR0	Adds 5 to the contents of IR0 and loads the bit at that PLC memory address.
Indirect addressing with DR offset	The content of the Data Register is added to the content of IR□ and the result is treated as the PLC memory address of a bit or word.	DR□,IR□	LD DR0,IR0	Adds the contents of DR0 to the contents of IR0 and loads the bit at that PLC memory address.
Indirect addressing with auto-increment	After referencing the content of IR□ as the PLC memory address of a bit or word, the content is incremented by 1 or 2.	Increment by 1: ,IR□+ Increment by 2: ,IR□++	LD ,IR0++	Loads the bit at the PLC memory address contained in IR0 and then increments the content of IR0 by 2.
Indirect addressing with auto-decrement	The content of IR□ is decremented by 1 or 2 and the result is treated as the PLC memory address of a bit or word.	Decrement by 1: ,-IR□ Decrement by 2: ,--IR□	LD ,--IR0	Decrement the content of IR0 by 2 and then loads the bit at that PLC memory address.

Example

This example shows how to store the PLC memory address of a word (CIO 2) in an Index Register (IR0), use the Index Register in an instruction, and use the auto-increment variation.

MOVR(560)	2	IR0	Stores the PLC memory address of CIO 2 in IR0.
MOV(021)	#0001	,IR0	Writes #0001 to the PLC memory address contained in IR0.
MOV(021)	#0020	+1,IR0	Reads the content of IR0, adds 1, and writes #0020 to that PLC memory address.



Note The PLC memory addresses are listed in the diagram above, but it isn't necessary to know the PLC memory addresses when using Index Registers.

Since some operands are treated as word data and others are treated as bit data, the meaning of the data in an Index Register will differ depending on the operand in which it is used.

1,2,3...

1. Word Operand:

```
MOVR(560) 0000 IR2
MOV(021) D0 , IR2
```

When the operand is treated as a word, the contents of the Index Register are used "as is" as the PLC memory address of a word.

In this example MOVR(560) sets the PLC memory address of CIO 2 in IR2 and the MOV(021) instruction copies the contents of D0 to CIO 2.

2. Bit Operand:

```
MOVR(560) 000013 ,IR2
SET +5 , IR2
```

When the operand is treated as a bit, the leftmost 7 digits of the Index Register specify the word address and the rightmost digit specifies the bit number. In this example, MOVR(560) sets the PLC memory address of CIO 13 (0C000D hex) in IR2. The SET instruction adds +5 from bit 13 to this PLC memory address, so it turns ON bit CIO 1.02.

Index Register Initialization

The Index Registers will be cleared in the following cases:

1. When the operating mode is changed from PROGRAM to RUN or MONITOR mode or vice-versa
2. When the power is cycled

Setting Index Registers

Always set the required value in an index register before using it. The contents of an index register will be unpredictable if it is not set in advance.

The contents of an index register is also unpredictable after an interrupt task is started. When using index registers inside an interrupt task, use MOVR(560) (for anything but timer/counter PVs) or MOVRW(561) (for timer/counter PVs) to set the required value.

Direct Addressing

When an Index Register is used as an operand without a "," prefix, the instruction will operate on the contents of the Index Register itself (a two-word or "double" value). Index Registers can be directly addressed only in the instruc-

tions shown in the following table. Use these instructions to operate on the Index Registers as pointers.


The Index Registers cannot be directly addressed in any other instructions, although they can usually be used for indirect addressing.

Instruction group	Instruction name	Mnemonic
Data Movement Instructions	MOVE TO REGISTER	MOVR(560)
	MOVE TIMER/COUNTER PV TO REGISTER	MOVW(561)
	DOUBLE MOVE	MOVL(498)
	DOUBLE DATA EXCHANGE	XCGL(562)
Table Data Processing Instructions	SET RECORD LOCATION	SETR(635)
	GET RECORD NUMBER	GETR(636)
Increment/Decrement Instructions	DOUBLE INCREMENT BINARY	++L(591)
	DOUBLE DECREMENT BINARY	--L(593)
Comparison Instructions	DOUBLE EQUAL	=L(301)
	DOUBLE NOT EQUAL	<>L(306)
	DOUBLE LESS THAN	<L(311)
	DOUBLE LESS THAN OR EQUAL	<=L(316)
	DOUBLE GREATER THAN	>L(321)
	DOUBLE GREATER THAN OR EQUAL	>=L(326)
	DOUBLE COMPARE	CMPL(060)
Symbol Math Instructions	DOUBLE SIGNED BINARY ADD WITHOUT CARRY	+L(401)
	DOUBLE SIGNED BINARY SUBTRACT WITHOUT CARRY	-L(411)

The SRCH(181), MAX(182), and MIN(183) instructions can output the PLC memory address of the word with the desired value (search value, maximum, or minimum) to IR0. In this case, IR0 can be used in later instructions to access the contents of that word.

4-15-1 Using Index Registers

Processing of multiple (identical) instructions such as consecutive addresses for table data can be merged into one instruction by combining repetitive processing (e.g., FOR(513) and NEXT(514) instructions) with indirect addressing using Index Registers, thereby simplifying programming.



The Index operation uses the following procedure.


1. PLC memory addresses for the addresses in the Index Registers are stored using a MOVR instruction.
2. Operation is then executed by indirectly addressing Index Registers to the operand for Instruction A.
3. The addresses are moved using processing such as adding, subtracting, incrementing, or decrementing the Index Register (see note).

4. Steps 2 and 3 are processed repeatedly until the conditions are met.

Note Adding, subtracting incrementing, or decrementing for the Index Register is performed using one of the following methods.

- Each Type of Indirect Addressing for Index Registers:
Auto-increment ($,IR\Box+$ or $,IR\Box++$), auto-decrement ($,-IR\Box$ or $--IR\Box$), constant offset ($constant,IR\Box$), and DR offset ($DR\Box,IR\Box$) for Index Registers
- Instructions for Direct Addressing of Index Registers:
DOUBLE SIGNED BINARY ADD WITHOUT CARRY (+L), DOUBLE SIGNED BINARY SUBTRACT WITHOUT CARRY (-L), DOUBLE INCREMENT BINARY (++L), DOUBLE DECREMENT BINARY (--L)


Example:




If, for example, instruction A above is a comparison instruction, table data could be read from start to the end of the table to compare all of the data with a specific value. In this way, blocks of user-defined processing can be freely created depending by applying Index Registers.

■ Example Using Index Registers

In the following example, TIM instructions for timer numbers 0 to 99 use set values in D100 to D109. This can be achieved by using one TIM instruction, using an index register for the timer number, using another index register for the Completion Flags, and repeatedly executing the TIM instruction to start the timers.





4-15-2 Precautions for Using Index Registers

Precautions

Do not use a Index Register until a PLC memory address has been set in the register. The pointer operation will be unreliable if the registers are used without setting their values.

The values in Index Registers are unpredictable at the start of an interrupt task. When an Index Register will be used in an interrupt task, always set a PLC memory address in the Index Register with MOVW(560) or MOVRW(561) before using the register in that task.


Each Index Register task is processed independently, so they do not affect each other. For example, IR0 used in Task 1 and IR0 used in Task 2 are different. Consequently, each Index Register task has 16 Index Registers.

Limitations when Using Index Registers

- It is only possible to read the Index Register for the last task executed within the cycle from the CX-Programmer. If using Index Registers with the same number to perform multiple tasks, it is only possible with the CX-Programmer to read the Index Register value for the last task performed within the cycle from the multiple tasks, nor is it possible to write the Index Register value from the CX-Programmer.
- It is not possible to either read or write to the Index Registers using Host Link commands or FINS commands.
- A setting can be made from the CX-Programmer to share Index Registers between tasks. This setting will be enabled uniformly for all Index Registers and Data Registers.

Sharing Index Registers

The following setting can be made from the PLC Properties Dialog Box on the CX-Programmer to control sharing Index and Data Registers between tasks.




Monitoring Index Registers

It is possible to monitor Index Registers as follows:

To use the Programming Devices to monitor the final Index Register values for each task, or to monitor the Index Register values using Host Link commands or FINS commands, write a program to store Index Register values from each task to another area (e.g., DM area) at the end of each task, and to read Index Register values from the storage words (e.g., DM area) at the beginning of each task. The values stored for each task in other areas (e.g., DM area) can then be edited using the CX-Programmer, Host Link commands, or FINS commands.

Note Be sure to use PLC memory addresses in Index Registers.



4-16 Data Registers


The sixteen Data Registers (DR0 to DR15) are used to offset the PLC memory addresses in Index Registers when addressing words indirectly.

The value in a Data Register can be added to the PLC memory address in an Index Register to specify the absolute memory address of a bit or word in I/O memory. Data Registers contain signed binary data, so the content of an Index Register can be offset to a lower or higher address.

Normal instructions can be used to store data in Data Registers.

Forcing Bit Status

Bits in Data Registers cannot be force-set and force-reset.



Examples

The following examples show how Data Registers are used to offset the PLC memory addresses in Index Registers.

- LD DR0,IR0** Adds the contents of DR0 to the contents of IR0 and loads the bit at that PLC memory address.
- MOV(021) #0001 DR0,IR1** Adds the contents of DR0 to the contents of IR1 and writes #0001 to that PLC memory address.

Range of Values

The contents of data registers are treated as signed binary data and thus have a range of -32,768 to 32,767.

Hexadecimal content	Decimal equivalent
8000 to FFFF	-32,768 to -1
0000 to 7FFF	0 to 32,767

Data Register Initialization

The Data Registers will be cleared in the following cases:

1. When the operating mode is changed from PROGRAM mode to RUN/MONITOR mode or vice-versa and the IOM Hold Bit is OFF
2. When the power is cycled and the IOM Hold Bit is OFF or not protected in the PLC Setup

IOM Hold Bit Operation

If the IOM Hold Bit (A500.12) is ON, the Data Registers won't be cleared when a FALS error occurs or the operating mode is changed from PROGRAM mode to RUN/MONITOR mode or vice-versa.

If the IOM Hold Bit (A500.12) is ON and the PLC Setup's "IOM Hold Bit Status at Startup" setting is set to protect the IOM Hold Bit, the Data Registers won't be cleared when the PLC's power supply is reset (ON → OFF → ON).

Precautions

Data Registers are normally local to each task. For example, DR0 used in task 1 is different from DR0 used in task 2. (A PLC Setup setting can be made from the CX-Programmer to share Data Registers between tasks.)

The content of Data Registers cannot be accessed (read or written) from the CX-Programmer.

Do not use Data Registers until a value has been set in the register. The register's operation will be unreliable if they are used without setting their values.

The values in Data Registers are unpredictable at the start of an interrupt task. When a Data Register will be used in an interrupt task, always set a value in the Data Register before using the register in that task.

4-17 Task Flags

Task Flags range from TK00 to TK31 and correspond to cyclic tasks 0 to 31. A Task Flag will be ON when the corresponding cyclic task is in executable (RUN) status and OFF when the cyclic task hasn't been executed (INI) or is in standby (WAIT) status.

Note These flags indicate the status of cyclic tasks only, they do not reflect the status of interrupt tasks.

Task Flag Initialization

The Task Flags will be cleared in the following cases, regardless of the status of the IOM Hold Bit.

1. When the operating mode is changed from PROGRAM mode to RUN/MONITOR mode or vice-versa
2. When the power is cycled.

Forcing Bit Status

The Task Flags **cannot** be force-set and force-reset.

4-18 Condition Flags

These flags include the Arithmetic Flags, such as the Error Flag and Equals Flag, which indicate the results of instruction execution.

The Condition Flags are specified with symbols, such as P_CY and P_ER, rather than addresses. The status of these flags reflects the results of instruction execution, but the flags are read-only; they cannot be written directly from instructions or the CX-Programmer.

Note The CX-Programmer treats condition flags as global symbols beginning with P_.

All Condition Flags are cleared when the program switches tasks, so the status of the ER and AER flags are maintained only in the task in which the error occurred.

Forcing Bit Status

The Condition Flags **cannot** be force-set and force-reset.

Summary of the Condition Flags


The following table summarizes the functions of the Condition Flags, although the functions of these flags will vary slightly from instruction to instruction. Refer to the description of the instruction for complete details on the operation of the Condition Flags for a particular instruction.

Name	Symbol	Function
Error Flag	P_ER	<p>Turned ON when the operand data in an instruction is incorrect (an instruction processing error) to indicate that an instruction ended because of an error.</p> <p>When the PLC Setup is set to stop operation for an instruction error (Instruction Error Operation), program execution will be stopped and the Instruction Processing Error Flag (A29508) will be turned ON when the Error Flag is turned ON.</p>
Access Error Flag	P_AER	<p>Turned ON when an Illegal Access Error occurs. The Illegal Access Error indicates that an instruction attempted to access an area of memory that should not be accessed.</p> <p>When the PLC Setup is set to stop operation for an instruction error (Instruction Error Operation), program execution will be stopped and the Instruction Processing Error Flag (A429510) will be turned ON when the Access Error Flag is turned ON.</p>

Name	Symbol	Function
Carry Flag	P_CY	Turned ON when there is a carry in the result of an arithmetic operation or a "1" is shifted to the Carry Flag by a Data Shift instruction. The Carry Flag is part of the result of some Data Shift and Symbol Math instructions.
Greater Than Flag	P_GT	Turned ON when the first operand of a Comparison Instruction is greater than the second or a value exceeds a specified range.
Equals Flag	P_EQ	Turned ON when the two operands of a Comparison Instruction are equal the result of a calculation is 0.
Less Than Flag	P_LT	Turned ON when the first operand of a Comparison Instruction is less than the second or a value is below a specified range.
Negative Flag	P_N	Turned ON when the most significant bit (sign bit) of a result is ON.
Overflow Flag	P_OF	Turned ON when the result of calculation overflows the capacity of the result word(s).
Underflow Flag	P_UF	Turned ON when the result of calculation underflows the capacity of the result word(s).
Greater Than or Equals Flag	P_GE	Turned ON when the first operand of a Comparison Instruction is greater than or equal to the second.
Not Equal Flag	P_NE	Turned ON when the two operands of a Comparison Instruction are not equal.
Less Than or Equals Flag	P_LE	Turned ON when the first operand of a Comparison Instruction is less than or equal to the second.
Always ON Flag	P_On	Always ON. (Always 1.)
Always OFF Flag	P_Off	Always OFF. (Always 0.)

Using the Condition Flags

The Condition Flags are shared by all of the instructions, so their status may change often in a single cycle. Be sure to read the Condition Flags immediately after the execution of instruction, preferably in a branch from the same execution condition.



Instruction	Operand
LD	
Instruction A	
AND	=
Instruction B	


Since the Condition Flags are shared by all of the instructions, program operation can be changed from its expected course by interruption of a single task. Be sure to consider the effects of interrupts when writing the program. Refer to *SECTION 2 Programming of CS/CJ Series Programming Manual (W394)* for more details.

The Condition Flags are cleared when the program switches tasks, so the status of a Condition Flag cannot be passed to another task. For example the status of a flag in task 1 cannot be read in task 2.

Saving and Loading Condition Flag Status

The CP1-H CPU Units support instructions to save and load the Condition Flag status (CCS(282) and CCL(283)). These can be used to access the status of the Condition Flags at other locations in a task or in a different task.

The following example shows how the Equals Flag is used at a different location in the same task.



4-19 Clock Pulses

The Clock Pulses are flags that are turned ON and OFF at regular intervals by the system.

Name	Symbol	Operation	
0.02 s Clock Pulse	P_0_02_s		ON for 0.01 s OFF for 0.01 s
0.1 s Clock Pulse	P_0_1s		ON for 0.05 s OFF for 0.05 s
0.2 s Clock Pulse	P_0_2s		ON for 0.1 s OFF for 0.1 s
1 s Clock Pulse	P_1s		ON for 0.5 s OFF for 0.5 s
1 min Clock Pulse	P_1min		ON for 30 s OFF for 30 s

The Clock Pulses are specified with symbols rather than addresses.


Note The CX-Programmer treats condition flags as global symbols beginning with P_.

The Clock Pulses are read-only; they cannot be overwritten from instructions or the CX-Programmer.

The Clock Pulses are cleared at the start of operation.

Using the Clock Pulses

The following example turns CIO 100.00 ON and OFF at 0.5 s intervals.



Instruction	Operand
LD	1 s
OUT	100.00

SECTION 5

Basic CP1H Functions

This section describes the CP1H's interrupt and high-speed counter functions.

5-1	Interrupt Functions	186
5-1-1	Overview of CP1H Interrupt Functions	186
5-1-2	Input Interrupts (Direct Mode)	190
5-1-3	Input Interrupts (Counter Mode)	195
5-1-4	Scheduled Interrupts	198
5-1-5	High-speed Counter Interrupts	201
5-1-6	External Interrupts	210
5-2	High-speed Counters	210
5-2-1	Overview	210
5-2-2	High-speed Counter Specifications	211
5-2-3	Procedure	217
5-2-4	PLC Setup	218
5-2-5	High-speed Counter Terminal Allocation	218
5-2-6	Pulse Input Connection Examples	221
5-2-7	Ladder Program Example	222
5-2-8	Additional Capabilities and Restrictions	225
5-3	Pulse Outputs	230
5-3-1	Overview	230
5-3-2	Pulse Output Specifications	232
5-3-3	Pulse Output Terminal Allocations	234
5-3-4	Pulse Output Patterns	240
5-3-5	Origin Search and Origin Return Functions	255
5-3-6	Origin Return	275
5-3-7	Pulse Output Procedures	277
5-3-8	Instructions used for Pulse Outputs	279
5-3-9	Variable Duty Factor Pulse Outputs (PWM(891) Outputs)	290
5-3-10	Example Pulse Output Applications	291
5-4	Quick-response Inputs	322
5-5	Analog I/O (XA CPU Units)	325

5-1 Interrupt Functions

5-1-1 Overview of CP1H Interrupt Functions

The CP1H CPU Unit's processing is normally cyclical (overseeing processing → program execution → I/O refreshing → peripheral servicing), with cyclic tasks executed in the program execution stage of the cycle. The interrupt functions can be used to temporarily interrupt this cyclic processing and execute a particular program when a predefined condition occurs.

Types of Interrupt Functions

Input Interrupts (Direct Mode)

When one of the CPU Unit's built-in inputs goes from OFF to ON (or ON to OFF), the corresponding interrupt task is executed. Interrupt tasks 140 to 147 are allocated to the 8 input terminals used for the input interrupts.

Input Interrupts (Counter Mode)

This function counts input pulses at one of the CPU Unit's built-in inputs and executes the corresponding interrupt task when the count reaches the SV.

The maximum input response frequency for input interrupts (in counter mode) is 5 kHz.

Scheduled Interrupts

This function executes an interrupt task at a fixed time interval measured by the CPU Unit's built-in timer. The time interval units can be set to 10 ms, 1 ms, or 0.1 ms. The minimum timer SV is 0.5 ms.

Interrupt task 2 is allocated to scheduled interrupt.

High-speed Counter Interrupts

This function counts input pulses with the CPU Unit's built-in high-speed counter and executes an interrupt task when the count reaches the preset value or falls within a preset range (target-value or zone comparison). An interrupt task between 0 and 255 can be allocated with an instruction.

Refer to 5-2 *High-speed Counters* for details on high-speed counters.

External Interrupts


When a CJ-series Special I/O Unit or CPU Bus Unit is connected, an interrupt task between 0 and 255 can be specified and executed.

Note


- (1) Power OFF interrupts cannot be used with CP1H CPU Units.
- (2) The input terminals are used for input interrupts, but cannot be used for quick-response inputs, high-speed counters, origin searches and normal inputs.

Creating an Interrupt Task Program


- 1,2,3... 1. Select **NewPLC1 [CP1H] Offline** in the project workspace, right-click, and select **Insert Program** in the pop-up menu. A new program called **NewProgram2 (unassigned)** will be inserted in the project workspace.



2. Right-click **NewProgram2 (unassigned)** and select **Properties** from the pop-up menu to display the Program Properties Window.



3. Set the **Task type** in the Program Properties Window. In this example, interrupt task 140 was allocated to NewProgram2.




If you click the **X** Button in the upper-right corner of the window, you can create the program that will be executed as interrupt task 140.

The programs allocated to each task are independent and an END(001) instruction must be input at the end of each program.

Interrupt Task Priority

The input interrupts (direct mode and counter mode), high-speed counter interrupts, scheduled interrupts, and external interrupts all have the same priority. If interrupt task A (an input interrupt, for example) is being executed when interrupt task B (a scheduled interrupt, for example) is called, task A processing will not be interrupted. Task B processing will be started when task A is completed.

If two different types of interrupt occur simultaneously, they are executed in the following order:



If two of the same type interrupt occur simultaneously, the task with the lower interrupt task number is executed first.

Note

If a user program is likely to generate multiple interrupts simultaneously, the interrupt tasks will be executed in the order shown above, so it may take some time from the occurrence of the interrupt condition to the actual execution of the corresponding interrupt task. In particular, it is possible that scheduled interrupts will not be executed in the preset time, so the program must be designed to avoid interrupt conflicts if necessary.


Duplicate Processing in Cyclic and Interrupt Tasks

If a memory address is processed both by a cyclic task and an interrupt task, an interrupt mask must be set to disable interrupts.


When an interrupt occurs, execution of the cyclic task will be interrupted immediately, even during execution of a cyclic task's instruction, and the partially processed data is saved. After the interrupt task is completed, processing returns to the cyclic task and the interrupted processing restarts with the data saved before the interrupt processing. If the interrupt task overwrites a memory address used by one of the interrupted instruction's operands, that overwrite may not be reflected after the saved data is restored as processing returns to the cyclic task.

To prevent an instruction from being interrupted during processing, enter DI(693) just before the instruction to disable interrupts and EI(694) just after the instruction to enable interrupts again.

- a. The following example shows duplicate processing by an interrupt task, which interrupts processing of a +B instruction between the first and third operands and overwrites the same memory address.




Flow of Processing




The interrupt occurs during processing of the +B instruction and the result is saved temporarily without being written to the destination word (D0).

The interrupt task transfers the value of #0010 to D0, but the saved result of the +B instruction (1235) is written to D0 when processing returns to the cyclic task. In the end, the interrupt task's processing has no effect.

Prevention of Duplicate Processing




- b. The following example shows duplicate processing by an interrupt task, which interrupts processing while BSET is writing to a block of words and yields an incorrect comparison result.



Since the interrupt occurs during BSET(071) processing and before #1234 is set in D10, the content of D0 and D10 do not match when the comparison is made in the interrupt task (*1) and output A remains OFF.

In the end (*2), the D0 and D10 both contain #1234 and match, but the correct comparison result is not reflected in comparison result output A.

Prevention of Duplicate Processing



5-1-2 Input Interrupts (Direct Mode)

This function executes an interrupt task when the corresponding input signal (up or down differentiated) is received.


Input Interrupt Bit and Terminal Allocations

X/XA CPU Units

The following diagrams show the input bits and terminals that are used for the input interrupt function in each CPU Unit.

The 8 input bits CIO 0.00 to CIO 0.03 and CIO 1.00 to CIO 1.03 can be used for input interrupts.

Input Terminal Arrangement



Setting the Input Functions in the PLC Setup


Normally, bits CIO 0.00 to CIO 0.03 and CIO 1.00 to CIO 1.03 are used as normal inputs. When using these inputs for input interrupts, use the CX-Programmer to change the input's setting in the PLC Setup.

Input terminal block		Input operation setting		Task number
Word	Bit	Normal inputs	Input interrupt	
CIO 0	00	Normal input 0	Input interrupt 0	Interrupt task 140
	01	Normal input 1	Input interrupt 1	Interrupt task 141
	02	Normal input 2	Input interrupt 2	Interrupt task 142
	03	Normal input 3	Input interrupt 3	Interrupt task 143
	04 to 11	Normal inputs 4 to 11	---	---
CIO 1	00	Normal input 12	Input interrupt 4	Interrupt task 144
	01	Normal input 13	Input interrupt 5	Interrupt task 145
	02	Normal input 14	Input interrupt 6	Interrupt task 146
	03	Normal input 15	Input interrupt 7	Interrupt task 147
	04 to 11	Normal inputs 16 to 23	---	---

Y CPU Units

The 6 input bits CIO 0.00 to CIO 0.01 and CIO 1.00 to CIO 1.03 can be used for input interrupts.


Input Terminal Arrangement



Setting the Input Functions in the PLC Setup


Normally, bits CIO 0.00 to CIO 0.01 and CIO 1.00 to CIO 1.03 are used as normal inputs. When using these inputs for input interrupts, use the CX-Programmer to change the input's setting in the PLC Setup.

Input terminal block		Input operation setting		Task number
Word	Bit	Normal inputs	Input interrupt	
CIO 0	00	Normal input 0	Input interrupt 0	Interrupt task 140
	01	Normal input 1	Input interrupt 1	Interrupt task 141
	04, 05, 10 and 11	Normal inputs 2, 3, 4, and 5	---	---
CIO 1	00	Normal input 6	Input interrupt 2	Interrupt task 142
	01	Normal input 7	Input interrupt 3	Interrupt task 143
	02	Normal input 8	Input interrupt 4	Interrupt task 144
	03	Normal input 9	Input interrupt 5	Interrupt task 145
	04 and 05	Normal inputs 10 and 11	---	---

Procedure

PLC Setup

Click the Built-in Input Tab to display the *Interrupt Input* settings (at the bottom of the tab). Set the input function to *Interrupt* for each input that will be used as an input interrupt.




- Note**
- (1) Interrupt Input settings IN0 to IN7 correspond to input interrupt numbers 0 to 7.
 - (2) When using an input as a general-purpose (normal) input, set the input function to *Normal*.

Writing the Ladder Program

MSKS(690) Settings

The MSKS(690) instruction must be executed in order to use input interrupts. The settings made with MSKS(690) are enabled with just one execution, so in general execute MSKS(690) in just one cycle using an up-differentiated condition.

MSKS(690) has the following two functions and two of the instructions are used in combination. If an up-differentiated input interrupt is being used, the first MSKS(690) instruction can be omitted since the input is set for up-differentiation by default.



MSKS(690) Operands

Input interrupt number	Interrupt task number	1. Up-differentiation or Down-differentiation		2. Enabling/Disabling the input interrupt	
		N	S	N	S
		Input interrupt number	Execution condition	Input interrupt number	Enable/Disable
Input interrupt 0	140	110 (or 10)	#0000: Up-differentiated #0001: Down-differentiated	100 (or 6)	#0000: Enable interrupt #0001: Disable interrupt
Input interrupt 1	141	111 (or 11)		101 (or 7)	
Input interrupt 2	142	112 (or 12)		102 (or 8)	
Input interrupt 3	143	113 (or 13)		103 (or 9)	
Input interrupt 4	144	114		104	
Input interrupt 5	145	115		105	
Input interrupt 6*	146*	116		106	
Input interrupt 7*	147*	117		107	

Note *Input interrupts 6 and 7 are not supported by the Y CPU Units.

Writing the Interrupt Task's Program

Create programs for interrupt tasks 140 to 147, which are executed by the corresponding input interrupt. Always put an END(001) instruction at the last address of the program.


Input Interrupt Settings and Operation

This example shows how to execute interrupt task 140 when input CIO 0.00 goes ON.

Settings

1,2,3...


1. Connect an input device to input 0.00.
2. Use the CX-Programmer to set input 0 as an input interrupt in the PLC Set-up.
3. Use the CX-Programmer to create the program to use for interrupt processing and allocate the program to interrupt task 140.
4. Use the CX-Programmer to write MSKS(690) in the program.



Operation

When execution condition W0.00 goes ON, MSKS(690) is executed to enable CIO 0.00 as an up-differentiated input interrupt.

If CIO 0.00 goes from OFF to ON (up-differentiation), processing of the cyclic task that is currently being executed will be interrupted and processing of interrupt task 140 will start. When the interrupt task processing is completed, processing of the interrupted ladder program will restart.



Restrictions

Inputs cannot be used for input interrupts when they are being used as general-purpose (normal) inputs or quick-response inputs.

5-1-3 Input Interrupts (Counter Mode)

Overview

This function counts up-differentiated or down-differentiated input signals and executes an interrupt task when the count reaches the set value.


- The counter-mode input interrupts use the same input terminals as the direct-mode input interrupts. Refer to 5-1-2 *Input Interrupts (Direct Mode)* for details.
- The counter input mode can be set to up or down (incrementing or decrementing) with MSKS(690).
- The counter-mode input interrupts start the same interrupt tasks (140 to 147) as the direct-mode input interrupts.
- The maximum input response frequency is 5 kHz total for all counter-mode input interrupts.

Relationship of Input Bits, Task Numbers, and Counters

Input bits		Function		Counter words	
X/XA CPU Unit	Y CPU Unit	Input interrupt number	Interrupt task number	SV (0000 to FFFF)	PV
0.00	0.00	Input interrupt 0	140	A532	A536
0.01	0.01	Input interrupt 1	141	A533	A537
0.02	1.00	Input interrupt 2	142	A534	A538
0.03	1.01	Input interrupt 3	143	A535	A539
1.00	1.02	Input interrupt 4	144	A544	A548
1.01	1.03	Input interrupt 5	145	A545	A549
1.02	---	Input interrupt 6	146 (see note)	A546	A550
1.03	---	Input interrupt 7	147 (see note)	A547	A551

Note *Input interrupts 6 and 7 are not supported by the Y CPU Units.

Procedure



Note The input interrupt (counter mode) function is one of the input interrupt functions and executes an interrupt based on the pulse count. If the input pulse frequency is too high, interrupts will occur too frequently and prevent normal cyclic task processing. In this case, cycle time too long errors may occur or the pulse input may not be read.

The maximum total frequency of the counter-mode interrupt inputs is 5 kHz. Even in this case, the high frequencies may adversely affect other devices' operation or the system load, so check the system's operation thoroughly before using the counters at high frequencies.

PLC Setup


The procedures for using the CX-Programmer to set the PLC Setup are the same as the procedures for input interrupts (direct mode). Refer to *5-1-2 Input Interrupts (Direct Mode)* for details.

Writing the Ladder Program

MSKS(690) Settings

The MSKS(690) instruction must be executed in order to use input interrupts. The settings made with MSKS(690) are enabled with just one execution, so in general execute MSKS(690) in just one cycle using an up-differentiated condition.

MSKS(690) has the following two functions and three of the instructions are used in combination. If up-differentiated input pulses are being used, the first MSKS(690) instruction can be omitted since the input is set for up-differentiation by default.



MSKS(690) Operands

Input interrupt number	Interrupt task number	1. Up-differentiation or Down-differentiation		2. Enabling/Disabling the input interrupt	
		N	S	N	S
		Input interrupt number	Count trigger	Input interrupt number	Enable/Disable
Input interrupt 0	140	110 (or 10)	#0000: Up-differentiated pulses #0001: Down-differentiated pulses	100 (or 6)	#0002: Start counting down (decrementing) and enable interrupts
Input interrupt 1	141	111 (or 11)		101 (or 7)	
Input interrupt 2	142	112 (or 12)		102 (or 8)	
Input interrupt 3	143	113 (or 13)		103 (or 9)	
Input interrupt 4	144	114		104	#0003: Start counting up (incrementing) and enable interrupts
Input interrupt 5	145	115		105	
Input interrupt 6*	146*	116		106	
Input interrupt 7*	147*	117		107	

Note *Input interrupts 2 and 3 are not supported by the Y CPU Units.

Writing the Interrupt Task's Program

Create programs for interrupt tasks 140 to 147, which are executed by the corresponding input interrupt. Always put an END(001) instruction at the last address of the program.


Input Interrupt Settings and Operation

This example shows how to execute interrupt task 141 when 200 up-differentiated pulses have been counted at input CIO 0.01. (The counter is an incrementing counter.)

Settings


1,2,3...

1. Connect an input device to input 0.00.
2. Use the CX-Programmer to set input 0.01 as an input interrupt in the PLC Setup.
3. Use the CX-Programmer to create the program to use for interrupt processing and allocate the program to interrupt task 141.
4. Use the CX-Programmer to set a high-speed counter SV of 00C8 hex (200 decimal) in A533.
5. Use the CX-Programmer to write MSKS(690) in the program.

**Operation**

When execution condition W0.00 goes ON, MSKS(690) is executed to enable operation of the input interrupt in counter mode.

When CIO 0.01 goes from OFF to ON 200 times, processing of the cyclic task that is currently being executed will be interrupted and processing of interrupt task 141 will start. When the interrupt task processing is completed, processing of the interrupted ladder program will restart.




Restrictions

Inputs cannot be used for input interrupts when they are being used as general-purpose (normal) inputs or quick-response inputs.

5-1-4 Scheduled Interrupts


This function executes an interrupt task at a fixed time interval measured by the CPU Unit's built-in timer. Interrupt task 2 is allocated to scheduled interrupt.

Procedure



PLC Setup


Click the **Timings** Tab and set the input function to *Scheduled Interrupt Interval* (the scheduled interrupt timer's units). The timing units can be set to 10 ms, 1 ms, or 0.1 ms. The scheduled interrupt timer SV is calculated by multiplying this interval setting by the timer SV set with MSKS(690).

Scheduled Interrupt Interval Setting**Note**

- (1) Set a scheduled interrupt time (interval) that is longer than the time required to execute the corresponding interrupt task.
- (2) If the scheduled time interval is too short, the scheduled interrupt task will be executed too frequently, which may cause a long cycle time and adversely affect the cyclic task processing.
- (3) If an interrupt task is being executed for another interrupt (input interrupt, high-speed counter interrupt, or external interrupt) when the scheduled interrupt occurs, the scheduled interrupt will not be executed until the other interrupt task is completed.
When different kinds of interrupts are being used, design the program to handle multiple interrupts smoothly. Even if two interrupts occur at the same time, the scheduled interrupts will continue as programmed, so the scheduled interrupt tasks will continue to occur at the scheduled times even if specific scheduled interrupts are delayed.
- (4) When using input interrupt or pulse output 2/3 and analog input/output (XA type only), pay attention to the possibility that timer interrupt cannot be executed within short time interval.

Writing the Ladder Program**MSKS(690) Settings**

The MSKS(690) instruction must be executed in order to use the scheduled interrupt. The settings made with MSKS(690) are enabled with just one execution, so in general execute MSKS(690) in just one cycle using an up-differentiated condition.




MSKS(690) Operands

Operand		Interrupt time interval (period)	
N	S	Time units set in PLC Setup	Scheduled time interval
Scheduled interrupt number	Interrupt time		
Scheduled interrupt 0 (interrupt task 2) 14: Reset start 4: Start without reset	#0000 to #270F (0 to 9999)	10 ms	10 to 99,990 ms
		1 ms	1 to 9,999 ms
		0.1 ms	0.5 to 999.9 ms

Writing the Scheduled Interrupt Task's Program


Create the program for interrupt task 2 (scheduled interrupt 0), which is executed by the input interrupt. Always put an END(001) instruction at the last address of the program.

Selecting the Scheduled Interrupt Task**Input Interrupt Settings and Operation****Settings**

This example shows how to execute interrupt task 2 at 30.5 ms intervals.


1,2,3...

1. Use the CX-Programmer to set the scheduled interrupt time units to 0.1 ms.
2. Use the CX-Programmer to create the interrupt program allocated to interrupt task 2.

**Operation**

When execution condition W0.00 goes ON, MSKS(690) is executed to enable the scheduled interrupt with the reset start specified. The timer is reset and timing starts.

Scheduled interrupt 2 is executed every 30.5 ms.




5-1-5 High-speed Counter Interrupts

This function executes the specified interrupt task (0 to 255) when the CP1H CPU Unit's built-in high-speed counter PV matches a pre-registered value (target value comparison) or lies within a pre-registered range (range comparison).

- CTBL(882) is used to register the comparison table.
- Either CTBL(882) or INI(880) can be used to start comparison.
- INI(880) is used to stop comparison.


For details on the built-in high-speed counter, refer to *5-2 High-speed Counters*.

Procedure



PLC Setup

Click the **Built-in Input** Tab to and set the high-speed counters that will be used for interrupts.




PLC Setup

Item	Setting
Use high speed counter 0 to 3	Use counter
Counting mode	Linear mode
	Circular mode (ring mode)
Circular Max. Count	0 to FFFF FFFF hex (When circular (ring) mode is selected as the counting mode, set maximum ring value here.)
Reset method	Phase Z and software reset
	Software reset
	Phase Z and software reset (continue comparing)
	Software reset (continue comparing)
Input Setting	Differential phase inputs (4x)
	Pulse + direction inputs
	Up/Down inputs
	Increment pulse input

High-speed Counter
Terminal Allocation

The following diagrams show the input terminals that can be used for high-speed counters in each CPU Unit.

X/XA CPU Units


Input Terminal Arrangement**Input Function Settings in the PLC Setup**

The CPU Unit's built-in inputs can be set for high-speed counter inputs in the PLC Setup's Built-in Input Tab. (When an input is set for use as a high-speed counter input, the corresponding words and bits cannot be used for general-purpose (normal) inputs, input interrupts, or quick-response inputs.)

Input terminal block		Bit function when the high-speed counter is enabled by selecting "Use high-speed counter <input type="checkbox"/> " in the PLC Setup
Word	Bit	
CIO 0	00	---
	01	High-speed counter 2 (Phase Z or reset input)
	02	High-speed counter 1 (Phase Z or reset input)
	03	High-speed counter 0 (Phase Z or reset input)
	04	High-speed counter 2 (Phase A, Increment, or Count input)
	05	High-speed counter 2 (Phase B, Decrement, or Direction input)
	06	High-speed counter 1 (Phase A, Increment, or Count input)
	07	High-speed counter 1 (Phase B, Decrement, or Direction input)
	08	High-speed counter 0 (Phase A, Increment, or Count input)
	09	High-speed counter 0 (Phase B, Decrement, or Direction input)
	10	High-speed counter 3 (Phase A, Increment, or Count input)
	11	High-speed counter 3 (Phase B, Decrement, or Direction input)
CIO 1	00	High-speed counter 3 (Phase Z or reset input)
	01 to 11	---

Y CPU Units

Input Terminal Arrangement



Input Function Settings in the PLC Setup

The CPU Unit's built-in inputs can be set for high-speed counter inputs in the PLC Setup's Built-in Input Tab. (When an input is set for use as a high-speed counter input, the corresponding words and bits cannot be used for general-purpose (normal) inputs, input interrupts, or quick-response inputs.)

Input terminal block		Bit function when the high-speed counter is enabled by selecting "Use high-speed counter <input type="checkbox"/> in the PLC Setup
Word	Bit	
---	A0	High-speed counter 0 (Phase A, Increment, or Count input)
---	B0	High-speed counter 0 (Phase B, Decrement, or Direction input)
---	Z0	High-speed counter 0 (Phase Z or reset input)
---	A1	High-speed counter 1 (Phase A, Increment, or Count input)
---	B1	High-speed counter 1 (Phase B, Decrement, or Direction input)
---	Z1	High-speed counter 1 (Phase Z or reset input)
CIO 0	00	---
	01	High-speed counter 2 (Phase A, Increment, or Count input)
	04	High-speed counter 2 (Phase B, Decrement, or Direction input)
	05	High-speed counter 2 (Phase Z or reset input)
	10	High-speed counter 3 (Phase A, Increment, or Count input)
	11	High-speed counter 3 (Phase B, Decrement, or Direction input)
CIO 1	00	High-speed counter 3 (Phase Z or reset input)
	01 to 05	---


High-speed Counter Memory Areas (All CP1H CPU Units)

Content		High-speed counter			
		0	1	2	3
PV	Leftmost 4 digits	A271	A273	A317	A319
	Rightmost 4 digits	A270	A272	A316	A318
Range Comparison Condition Met Flags	ON for match in range 1	A274.00	A275.00	A320.00	A321.00
	ON for match in range 2	A274.01	A275.01	A320.01	A321.01
	ON for match in range 3	A274.02	A275.02	A320.02	A321.02
	ON for match in range 4	A274.03	A275.03	A320.03	A321.03
	ON for match in range 5	A274.04	A275.04	A320.04	A321.04
	ON for match in range 6	A274.05	A275.05	A320.05	A321.05
	ON for match in range 7	A274.06	A275.06	A320.06	A321.06
	ON for match in range 8	A274.07	A275.07	A320.07	A321.07
Comparison In-progress Flags	ON while the comparison is in progress.	A274.08	A275.08	A320.08	A321.08
Overflow/Underflow Flags	ON if a PV overflow or underflow occurred while operating in linear mode.	A274.09	A275.09	A320.09	A321.09
Count Direction Flags	0: Decrementing 1: Incrementing	A274.10	A275.10	A320.10	A321.10

Note The comparison table and comparison conditions 1 to 8 are different for target-value comparison and range comparison operations. For details, refer to 5-2 *High-speed Counters*.

REGISTER COMPARISON TABLE Instruction: CTBL(882)

CTBL(882) compares the PV of a high-speed counter (0 to 3) to target values or target value ranges and executes the corresponding interrupt task (0 to 255) when the specified condition is met.




Operand		Settings	
P	High-speed counter number	#0000	High-speed counter 0
		#0001	High-speed counter 1
		#0002	High-speed counter 2
		#0003	High-speed counter 3
C	Control data	#0000	Registers a target-value comparison table and starts the comparison operation.
		#0001	Registers a range comparison table and starts the comparison operation.
		#0002	Registers a target-value comparison table.
		#0003	Registers a range comparison table.
TB	First comparison table word	Specifies the leading word address of the comparison table, which is described below.	

Contents of the Comparison Table


Target-value Comparison Table

Depending on the number of target values in the table, the target-value comparison table requires a continuous block of 4 to 145 words.



Range Comparison Table


The range comparison table requires a continuous block of 40 words because comparison conditions 1 to 8 require 5 words each (2 words for the upper range value, 2 words for the lower range value, and one word for the interrupt task number).



Note Always set the upper limit greater than or equal to the lower limit in each range.


MODE CONTROL Instruction: INI(880)

INI(880) can be used to start/stop comparison with the high-speed counter's comparison table, change the high-speed counter's PV, change the PV of interrupt inputs in counter mode, and control the pulse output functions.



Operand		Settings	
P	Port specifier	#0000 to #0003	Pulse outputs 0 to 3
		#0010	High-speed counter 0
		#0011	High-speed counter 1
		#0012	High-speed counter 2
		#0013	High-speed counter 3
		#0100 to #0107	Input interrupts 0 to 7 (in counter mode)
		#1000 or #1001	PWM(891) output 0 or 1
C	Control data	#0000	Start comparison.
		#0001	Stop comparison.
		#0002	Change the PV.
		#0003	Stop pulse output.
NV	First word of new PV	NV and NV+1 contain the new PV when C is set to #0002 (change the PV).	

New PV Setting in NV and NV+1



Setting range for pulse outputs and high-speed counter inputs:
0000 0000 to FFFF FFFF hex

Setting range for input interrupts (counter mode):
0000 0000 to 0000 FFFF hex

Ladder Program Examples

Example 1: High-speed Counter (Linear Mode)

In this example, high-speed counter 0 operates in linear mode and starts interrupt task 10 when the PV reaches 30,000 (0000 7530 hex).

1,2,3...

- Set high-speed counter 0 in the PLC Setup's Built-in Input Tab.


Item	Setting
High-speed counter 0	Use counter
Counting mode	Linear mode
Circular Max. Count	---
Reset method	Software reset
Input Setting	Up/Down inputs

- Set the target-value comparison table in words D10000 to D10003.

Word	Setting	Function	
D10000	#0001	Number of target values = 1	
D10001	#7530	Rightmost 4 digits of the target value 1 data	Target value = 30,000 (0000 7530 hex)
D10002	#0000	Leftmost 4 digits of the target value 1 data	
D10003	#000A	Bit 15: 0 (incrementing) Bits 0 to 7: A hex (interrupt task number 10)	

- Create the program for interrupt task 10. Always put an END(001) instruction at the program's last address.


- Use CTBL(882) to start the comparison operation with high-speed counter 0 and interrupt task 10.



5. Operation

When execution condition W0.00 goes ON, the comparison starts with high-speed counter 0.

When the PV of high speed counter 0 reaches 30,000, cyclic task processing is interrupted, and interrupt task 10 is processed. When interrupt task 10 processing is completed, processing of the interrupted cyclic task resumes.



Example 2: High-speed Counter (Ring Mode)

In this example, high-speed counter 1 operates in circular (ring) mode and starts interrupt task 12 when the PV is between 25,000 (0000 61A8 hex) and 25,500 (0000 639C hex).

The maximum ring count is set at 50,000 (0000 C350Hex).

1,2,3...

- Set high-speed counter 1 in the PLC Setup's Built-in Input Tab.


Item	Setting
High-speed counter 1	Use counter
Counting mode	Circular mode
Circular Max. Count	50,000
Reset method	Software reset (continue comparing)
Input Setting	Up/Down inputs

- Set the range comparison table starting at word D20000. Even though range 1 is the only range being used, all 40 words must still be dedicated to the range comparison table.

Word	Setting	Function	
D20000	#61A8	Rightmost 4 digits of range 1 lower limit	Lower limit value: 25,000
D20001	#0000	Leftmost 4 digits of range 1 lower limit	
D20002	#639C	Rightmost 4 digits of range 1 upper limit	Upper limit value: 25,500
D20003	#0000	Leftmost 4 digits of range 1 upper limit	

Word	Setting	Function	
D20004	#000C	Range 1 interrupt task number = 12 (C hex)	
D20005 to D20008	All #0000	Range 2 lower and upper limit values (Not used and don't need to be set.)	Range 2 settings
D20009	#FFFF	Disables range 2.	
~			
D20014 D20019 D20024 D20029 D20034	#FFFF	Set the fifth word for ranges 3 to 7 (listed at left) to #FFFF to disable those ranges.	
~			
D20035 to D20038	All #0000	Range 8 lower and upper limit values (Not used and don't need to be set.)	Range 8 settings
D20039	#FFFF	Disables range 8.	


3. Create the program for interrupt task 12. Always put an END(001) instruction at the program's last address.
4. Use CTBL(882) to start the comparison operation with high-speed counter 1 and interrupt task 12.



5. Operation

When execution condition W0.00 goes ON, the comparison starts with high-speed counter 1.

When the PV of high speed counter 1 is between 25,000 and 25,500, cyclic task processing is interrupted, and interrupt task 12 is processed. When interrupt task 12 processing is completed, processing of the interrupted cyclic task resumes.




5-1-6 External Interrupts

An external interrupt task performs interrupt processing in the CPU Unit in response to an input from a CJ-series Special I/O Unit or CPU Bus Unit connected to the CPU Unit. The reception of these interrupts is always enabled.

External interrupts require no special settings in the CPU Unit, although an interrupt task with the specified number must be included in the user program.

Example: External interrupt from a CJ1W-CT021-V1 High-speed Counter Unit



Note When the same interrupt number is used for both an external interrupt task (task 0 to 255), and scheduled interrupt task (task 2) or high-speed counter interrupt task (0 to 255), the task will be executed for both the external interrupt condition and the other interrupt condition. As a general rule, do not use the same interrupt number for different interrupt conditions.

5-2 High-speed Counters

5-2-1 Overview

- A rotary encoder can be connected to a built-in input to produce a high-speed pulse input.
- High-speed interrupt processing can be performed when the high-speed counter PV matches a target value or is within a target value range.
- The PRV(881) instruction can be used to measure the input pulse frequency (one input only).
- The high-speed counter PVs can be maintained or refreshed.
- The High-speed Counter Gate Bit can be turned ON/OFF from the ladder program to select whether the high-speed counter PVs will be maintained or refreshed.
- Any one of the following input signals can be selected as the counter input mode.

Response Frequencies for 24 VDC Inputs to High-speed Counters 0 to 3 in X/XA CPU Units or High-speed Counters 2 and 3 in Y CPU Units:

- Differential phase inputs (4x): 50 kHz
- Pulse + direction inputs: 100 kHz
- Up/Down pulse inputs: 100 kHz
- Increment pulse inputs: 100 kHz

Response Frequencies for Line Driver Inputs to High-speed Counters 0 and 1 in Y CPU Units:

- Differential phase inputs (4x): 500 kHz
- Pulse + direction inputs: 1 MHz
- Up/Down pulse inputs: 1 MHz
- Increment pulse inputs: 1 MHz

- The counting mode can be set to linear mode or circular (ring) mode.
- The counter reset method can be set to Z phase signal + software reset, software reset, Z phase signal + software reset (continue comparing), or software reset (continue comparing).

Pulse Input Functions

Purpose	Function used	Description
Receive incremental rotary encoder inputs to calculate length or position.	High-speed counter function	Built-in input terminals can be used for high-speed counter inputs. The PV for the high-speed counters are stored in the Auxiliary Area. The counters can be operated in ring mode or linear mode.
Measure a workpiece's length or position. (Start counting when a certain condition is established or pause counting when a certain condition is established.)	High-speed Counter Gate Bit	The high-speed counter can be started or stopped (PV held) from the Unit's program by turning ON/OFF the High-speed Counter Gate Bit when the desired condition is met.
Measure a workpiece's speed from its position data (frequency measurement.)	PRV(881) HIGH-SPEED COUNTER PV READ	The PRV(881) instruction can be used to measure the pulse frequency. <ul style="list-style-type: none"> • Range with differential phase inputs: 0 to 50 kHz (Y models: 0 to 500 kHz) • Range with all other input modes: 0 to 100 kHz (Y models: 0 to 1 MHz)
	PRV2(883) PULSE FREQUENCY CONVERT	PRV2(883) reads the pulse frequency and converts it to a rotational speed (r/min) or it converts the counter PV to a total number of rotations. Results are calculated by the number of pulses/rotation.

5-2-2 High-speed Counter Specifications

Specifications

Item				Specification			
Number of high-speed counters				4 (High-speed counters 0 to 3)			
Pulse input modes (Selected in the PLC Setup)				Differential phase inputs	Up/down inputs	Pulse + direction inputs	Increment inputs
Input terminal allocation				Phase-A input	Increment pulse input	Pulse input	Increment pulse input
				Phase-B input	Decrement pulse input	Direction input	---
				Phase-Z input	Reset input	Reset input	Reset input
Input method				Differential phase, 4x (Fixed)	Two single-phase inputs	Single-phase pulse + direction inputs	Single-phase input
Response frequency	X/XA CPU Unit	Counters 0 to 3	24 VDC inputs	50 kHz	100 kHz	100 kHz	100 kHz
	Y CPU Unit	Counters 0 and 1	Line driver inputs	500 kHz	1 MHz	1 MHz	1 MHz
		Counters 2 and 3	24 VDC inputs	50 kHz	100 kHz	100 kHz	100 kHz
Counting mode				Linear mode or circular (ring) mode (Select in the PLC Setup.)			

Item		Specification
Count values		Linear mode: 80000000 to 7FFFFFFF hex Ring mode: 00000000 to Ring SV (The Ring SV (Circular Max. Count) is set in the PLC Setup and the setting range is 00000001 to FFFFFFFF hex.)
High-speed counter PV storage locations		High-speed counter 0: A271 (leftmost 4 digits) and A270 (rightmost 4 digits) High-speed counter 1: A273 (leftmost 4 digits) and A272 (rightmost 4 digits) High-speed counter 2: A317 (leftmost 4 digits) and A316 (rightmost 4 digits) High-speed counter 3: A319 (leftmost 4 digits) and A318 (rightmost 4 digits) Target value comparison interrupts or range comparison interrupts can be executed based on these PVs. Note The PVs are refreshed in the overseeing processes at the start of each cycle. Use PRV(881) to read the most recent PVs.
		Data format: 8 digit hexadecimal Range in linear mode: 80000000 to 7FFFFFFF hex Range in ring mode: 00000000 to Ring SV (Circular Max. Count)
Control method	Target value comparison	Up to 48 target values and corresponding interrupt task numbers can be registered.
	Range comparison	Up to 8 ranges can be registered, with a separate upper limit, lower limit, and interrupt task number for each range.
Counter reset method		Select one of the following methods in the PLC Setup. •Phase-Z + Software reset The counter is reset when the phase-Z input goes ON while the Reset Bit is ON. •Software reset The counter is reset when the Reset Bit goes ON. (Set the counter reset method in the PLC Setup.) Note Operation can be set to stop or continue the comparison operation when the high-speed counter is reset.

Auxiliary Area Data Allocation


Function		High-speed counter number			
		0	1	2	3
PV storage words	Leftmost 4 digits	A271	A273	A317	A319
	Rightmost 4 digits	A270	A272	A316	A318
Range Comparison Condition Met Flags	Range 1 Comparison Condition Met Flag	A274.00	A275.00	A320.00	A321.00
	Range 2 Comparison Condition Met Flag	A274.01	A275.01	A320.01	A321.01
	Range 3 Comparison Condition Met Flag	A274.02	A275.02	A320.02	A321.02
	Range 4 Comparison Condition Met Flag	A274.03	A275.03	A320.03	A321.03
	Range 5 Comparison Condition Met Flag	A274.04	A275.04	A320.04	A321.04
	Range 6 Comparison Condition Met Flag	A274.05	A275.05	A320.05	A321.05
	Range 7 Comparison Condition Met Flag	A274.06	A275.06	A320.06	A321.06
	Range 8 Comparison Condition Met Flag	A274.07	A275.07	A320.07	A321.07
Comparison In-progress Flags	ON when a comparison operation is being executed for the high-speed counter.	A274.08	A275.08	A320.08	A321.08
Overflow/Underflow Flags	ON when an overflow or underflow has occurred in the high-speed counter's PV. (Used only when the counting mode is set to Linear Mode.)	A274.09	A275.09	A320.09	A321.09
Count Direction Flags	0: Decrementing 1: Incrementing	A274.10	A275.10	A320.10	A321.10

Function		High-speed counter number			
		0	1	2	3
Reset Bit	Used for the PV software reset.	A531.00	A531.01	A531.02	A531.03
High-speed Counter Gate Bit	When a counter's Gate Bit is ON, the counter's PV will not be changed even if pulse inputs are received for the counter.	A531.08	A531.09	A531.10	A531.11

Counter Input Modes

Differential Phase Mode (4x)

The differential phase mode uses two phase signals (phase A and phase B) and increments/decrements the count according to the status of these two signals.




Conditions for Incrementing/Decrementing the Count

Phase A	Phase B	Count value
↑	L	Increment
H	↑	Increment
↓	H	Increment
L	↓	Increment
L	↑	Decrement
↑	H	Decrement
H	↓	Decrement
↓	L	Decrement

Pulse + Direction Mode

The pulse + direction mode uses a direction signal input and pulse signal input. The count is incremented or decremented depending on the status (ON or OFF) of the direction signal.




Conditions for Incrementing/Decrementing the Count

Direction signal	Pulse signal	Count value
↑	L	No change
H	↑	Increment
↓	H	No change
L	↓	No change
L	↑	Decrement
↑	H	No change
H	↓	No change
↓	L	No change

- The count is incremented when the direction signal is ON and decremented when it is OFF.
- Only up-differentiated pulses (rising edges) can be counted.

Up/Down Mode

The up/down mode uses two signals, an increment pulse input and a decrement pulse input.


**Conditions for Incrementing/Decrementing the Count**

Decrement pulse	Increment pulse	Count value
↑	L	Decrement
H	↑	Increment
↓	H	No change
L	↓	No change
L	↑	Increment
↑	H	Decrement
H	↓	No change
↓	L	No change

- The count is incremented for each increment pulse input and decremented for each decrement pulse input.
- Only up-differentiated pulses (rising edges) can be counted.

Increment Mode

The increment mode counts single-phase pulse signal inputs. This mode only increments the count.

**Conditions for Incrementing/Decrementing the Count**

Pulse	Count value
↑	Increment
H	No change
↓	No change
L	No change

- Only up-differentiated pulses (rising edges) can be counted.


Note The count of the high-speed counter can be monitored to see if it is currently being incremented or decremented. The count in the current cycle is compared with the count in the previous cycle to determine if it is being incremented or decremented. The results are reflected in the High-speed Counter Count Direction Flags (A274.10 for high-speed counter 0, A275.10 for high-speed counter 1, A320.10 for high-speed counter 2, and A321.10 for high-speed counter 3.)

Counting Modes**Linear Mode**

Input pulses can be counted in the range between the lower limit and upper limit values. If the pulse count goes beyond the lower/upper limit, an under-flow/overflow will occur and counting will stop.

Lower and Upper Limits of the Range


The following diagrams show the lower limit and upper limit values for increment mode and up/down mode.

Increment Mode**Up/Down Mode****Circular (Ring) Mode**

Input pulses are counted in a loop within the set range. The loop operates as follows:

- If the count is incremented from the max. ring count, the count will be reset to 0 automatically and incrementing will continue.
- If the count is decremented from 0, the count will be set to the max. ring count automatically and decrementing will continue.

Consequently, underflows and overflows cannot occur when ring mode is used.

**Max. Ring Count**

Use the PLC Setup to set the max. ring count (Circular Max. Count), which is the max. value of the input pulse counting range. The max. ring count can be set to any value between 00000001 and FFFFFFFF hex.

Restrictions


- There are no negative values in ring mode.
- If the max. ring count is set to 0 in the PLC Setup, the counter will operate with a max. ring count of FFFFFFFF hex.

Reset Methods**Phase-Z Signal + Software Reset**

The high-speed counter's PV is reset when the phase-Z signal (reset input) goes from OFF to ON while the corresponding High-speed Counter Reset Bit is ON.

The CPU Unit recognizes the ON status of the High-speed Counter Reset Bit only at the beginning of the PLC cycle during the overseeing processes. Con-


sequently, when the Reset Bit is turned ON in the ladder program, the phase-Z signal does not become effective until the next PLC cycle.



Software Reset

The high-speed counter's PV is reset when the corresponding High-speed Counter Reset Bit goes from OFF to ON.


The CPU Unit recognizes the OFF-to-ON transition of the High-speed Counter Reset Bit only at the beginning of the PLC cycle during the overseeing processes. Reset processing is performed at the same time. The OFF-to-ON transition will not be recognized if the Reset Bit goes OFF again within the same cycle.



Note


- (1) The comparison operation can be set to stop or continue when a high-speed counter is reset. This enables applications where the comparison operation can be restarted from a counter PV of 0 when the counter is reset.
- (2) When using analog input/output (XA type only) or pulse output 2/3, pay attention to the possibility that it may take up to 100μs to reset the existing value of the high-speed counter due to Z-phase signal (reset input) of the high-speed counter 3.
- (3) When the counter mode is set to incremental pulse and numeric range mode to ring mode, pay attention to the possibility that it may take time to reset the existing value of the high-speed counter due to Z-phase signal (reset input).

5-2-3 Procedure



5-2-4 PLC Setup

The settings for high-speed counters 0 to 3 are located in the Built-in Input Tab of the CX-Programmer's PLC Settings Window.



Settings in the Built-in Input Tab


Item	Setting
Use high speed counter 0 to 3	Use counter
Counting mode	Linear mode
	Circular mode (ring mode)
Circular Max. Count (max. ring count)	0 to 4,294,967,295 (0 to FFFF FFFF hex)
Reset method	Phase Z and software reset
	Software reset
	Phase Z and software reset (continue comparing)
	Software reset (continue comparing)
Input Setting	Differential phase inputs (4x)
	Pulse + direction inputs
	Up/Down inputs
	Increment pulse input

5-2-5 High-speed Counter Terminal Allocation

The following diagrams show the input terminals that can be used for high-speed counters in each CPU Unit.

X/XA CPU Units

Input Terminal Arrangement




Input Function Settings in the PLC Setup

The CPU Unit's built-in inputs can be set for high-speed counter inputs in the PLC Setup's Built-in Input Tab. (When an input is set for use as a high-speed counter input, the corresponding words and bits cannot be used for general-purpose (normal) inputs, input interrupts, or quick-response inputs.)

Input terminal block		Bit function when the high-speed counter is enabled by selecting "Use high-speed counter <input type="checkbox"/> " in the PLC Setup
Word	Bit	
CIO 0	00	---
	01	High-speed counter 2 (Phase Z or Reset input)
	02	High-speed counter 1 (Phase Z or Reset input)
	03	High-speed counter 0 (Phase Z or Reset input)
	04	High-speed counter 2 (Phase A, Increment, or Count input)
	05	High-speed counter 2 (Phase B, Decrement, or Direction input)
	06	High-speed counter 1 (Phase A, Increment, or Count input)
	07	High-speed counter 1 (Phase B, Decrement, or Direction input)
	08	High-speed counter 0 (Phase A, Increment, or Count input)
	09	High-speed counter 0 (Phase B, Decrement, or Direction input)
	10	High-speed counter 3 (Phase A, Increment, or Count input)
	11	High-speed counter 3 (Phase B, Decrement, or Direction input)
CIO 1	00	High-speed counter 3 (Phase Z or Reset input)
	01 to 11	---

Y CPU Units

Input Terminal Arrangement



Input Function Settings in the PLC Setup


The CPU Unit's built-in inputs can be set for high-speed counter inputs in the PLC Setup's Built-in Input Tab. (When an input is set for use as a high-speed counter input, the corresponding words and bits cannot be used for general-purpose (normal) inputs, input interrupts, or quick-response inputs.)

Input terminal block		Bit function when the high-speed counter is enabled by selecting "Use high-speed counter <input type="checkbox"/> in the PLC Setup
Word	Bit	
---	A0	High-speed counter 0 (Phase A, Increment, or Count input)
---	B0	High-speed counter 0 (Phase B, Decrement, or Direction input)
---	Z0	High-speed counter 0 (Phase Z or reset input)
---	A1	High-speed counter 1 (Phase A, Increment, or Count input)
---	B1	High-speed counter 1 (Phase B, Decrement, or Direction input)
---	Z1	High-speed counter 1 (Phase Z or reset input)
CIO 0	00	---
	01	High-speed counter 2 (Phase A, Increment, or Count input)
	04	High-speed counter 2 (Phase B, Decrement, or Direction input)
	05	High-speed counter 2 (Phase Z or reset input)
	10	High-speed counter 3 (Phase A, Increment, or Count input)
	11	High-speed counter 3 (Phase B, Decrement, or Direction input)
CIO 1	00	High-speed counter 3 (Phase Z or reset input)
	01 to 05	---


5-2-6 Pulse Input Connection Examples

Encoders with 24 VDC Open-collector Outputs

This example shows how to connect an encoder that has phase-A, phase-B, and phase-Z outputs.



Encoders with Line Driver Outputs (Conforming to Am26LS31)



5-2-7 Ladder Program Example

Inspecting a Dimension by Counting Pulse Inputs

- An X CP1H CPU Unit with an AC power supply is used.
- High-speed counter 0 is used.
- When the edge of the workpiece is detected, the counter PV is reset by a phase-Z pulse.
- The workpiece is passes inspection if the final count is between 30,000 and 30,300, otherwise the workpiece fails.
- If the workpiece passes, output CIO 100.00 is turned ON by an interrupt and the indicator PL1 is lit. If the workpiece fails, output CIO 100.01 is turned ON by an interrupt and indicator PL2 is lit.
- The interrupt program is interrupt task 10.

■ I/O Allocation

Input Terminals

Input terminal		Usage
Word	Bit	
CIO 0	00	Start measurement by pushbutton switch (normal input).
	01	Detect trailing edge of measured object (normal input).
	02	Not used. (normal input)
	03	Detect leading edge of measured object for high-speed counter 0 phase-Z/reset input (see note). Bit status is reflected in A531.00.
	04 to 07	Not used. (normal input)
	08	High-speed counter 0 phase-A input (See note.)
	09	High-speed counter 0 phase-B input (See note.)
	10 and 11	Not used. (normal input)
CIO 1	00 to 11	Not used. (normal input)

Note The high-speed counter inputs are enabled when the *Use high speed counter 0* Option is selected in the PLC Setup's Built-in Input Tab.

Output Terminals

Output terminal		Usage	
Word	Bit		
CIO 100	00	Normal input	PL1: Dimension pass output
	01	Normal input	PL2: Dimension fail output
	02 to 07	Normal input	Not used.
CIO 101	00 to 07	Normal input	Not used.

Auxiliary Area Addresses for High-speed Counter 0

Function		Address
PV storage words	Leftmost 4 digits	A271
	Rightmost 4 digits	A270
Range Comparison Condition Met Flag	Range 1 Comparison Condition Met Flag	A274.00
Comparison In-progress Flag	ON when a comparison operation is being executed for the high-speed counter.	A274.08
Overflow/Underflow Flag	ON when an overflow or underflow has occurred in the high-speed counter's PV. (Used only when the counting mode is set to Linear Mode.)	A274.09
Count Direction Flag	0: Decrementing 1: Incrementing	A274.10
Reset Bit	Used for the PV software reset.	A531.00
High-speed Counter Gate Bit	When ON, the counter's PV will not be changed even if pulse inputs are received for the counter.	A531.08

Range Comparison Table

The range comparison table is stored in D10000 to D10039.


■ PLC Setup

Select the *Use high speed counter 0* Option in the PLC Setup's Built-in Input Tab.


Item	Setting
High-speed counter 0	Use high speed counter 0
Counting mode	Linear mode
Circular Max. Count	---
Reset method	Software reset
Input Setting	Up/Down inputs

■ I/O Wiring

Input Wiring



Output Wiring



■ Range Comparison Table Settings

The inspection standards data is set in the DM Area with the CX-Programmer. Even though range 1 is the only range being used, all 40 words must still be dedicated to the range comparison table.


Word	Setting	Function	
D10000	#7430	Rightmost 4 digits of range 1 lower limit	Lower limit value: 30,000
D10001	#0000	Leftmost 4 digits of range 1 lower limit	
D10002	#765C	Rightmost 4 digits of range 1 upper limit	Upper limit value: 30,300
D10003	#0000	Leftmost 4 digits of range 1 upper limit	
D10004	#000A	Range 1 interrupt task number = 10 (A hex)	

Word	Setting	Function	
D10005 to D10008	All #0000	Range 2 lower and upper limit values (Not used and don't need to be set.)	Range 2 settings
D10009	#FFFF	Disables range 2.	
~			
D10014 D10019 D10024 D10029 D10034	#FFFF	Set the fifth word for ranges 3 to 7 (listed at left) to #FFFF to disable those ranges.	
~			
D10035 to D10038	All #0000	Range 8 lower and upper limit values (Not used and don't need to be set.)	Range 8 settings
D10039	#FFFF	Disables range 8.	

■ Creating the Ladder Program


Programming in Cyclic Task

Use CTBL(882) to start the comparison operation with high-speed counter 0 and interrupt task 10.



Programming in Interrupt Task 10

Create the processing performed by interrupt task 10.



5-2-8 Additional Capabilities and Restrictions

Restrictions on High-speed Counter Inputs

- The Phase-Z signal + Software reset method cannot be used when the high speed counters are operating in Differential Phase or Pulse + Direction Input Modes and the origin search function is enabled for the pulse output (in the PLC Setup).

- When a high-speed counter is being used (enabled in the PLC Setup), the input cannot be used as a general-purpose (normal) input, interrupt input, or quick-response input.

Starting Interrupt Tasks based on Comparison Conditions

Data registered in advance in a comparison table can be compared with the actual counter PVs during operation. The specified interrupt tasks (registered in the table) will be started when the corresponding comparison condition is met.


There are two comparison methods available: Target value comparison and range comparison.

- Use the CTBL(882) instruction to register the comparison table.
- Use either the CTBL(882) instruction or INI(880) instruction to start the comparison operation.
- Use the INI(880) instruction to stop the comparison operation.

Target Value Comparison

The specified interrupt task is executed when the high-speed counter PV matches a target value registered in the table.

- The comparison conditions (target values and counting directions) are registered in the comparison table along with the corresponding interrupt task number. The specified interrupt task will be executed when the high-speed counter PV matches the registered target value.
- Up to 48 target values (between 1 and 48) can be registered in the comparison table.
- A different interrupt task can be registered for each target value.
- The target value comparison is performed on all of the target values in the table, regardless of the order in which the target values are registered.
- If the PV is changed, the changed PV will be compared with the target values in the table, even if the PV is changed while the target value comparison operation is in progress.




Restrictions

A comparison condition (target value and count direction) cannot appear in the table more than once. An error will occur if a comparison condition is specified two or more times.

Note When the count direction (incrementing/decrementing) changes at a PV that matches a target value, the next target value cannot be matched in that direction.

Set the target values so that they do not occur at the peak or trough of count value changes.




Range Comparison

The specified interrupt task is executed when the high-speed counter PV is within the range defined by the upper and lower limit values.

- The comparison conditions (upper and lower limits of the range) are registered in the comparison table along with the corresponding interrupt task number. The specified interrupt task will be executed once when the high-speed counter PV is in the range ($\text{Lower limit} \leq \text{PV} \leq \text{Upper limit}$).
- A total of 8 ranges (upper and lower limits) are registered in the comparison table.
- The ranges can overlap.
- A different interrupt task can be registered for each range.
- The counter PV is compared with the 8 ranges once each cycle.
- The interrupt task is executed just once when the comparison condition goes from unmet to met.

Restrictions

When more than one comparison condition is met in a cycle, the first interrupt task in the table will be executed in that cycle. The next interrupt task in the table will be executed in the next cycle.



Note

- (1) The range comparison table can be used without starting an interrupt task when the comparison condition is met. The range comparison function can be useful when you just want to know whether or not the high-speed counter PV is within a particular range. Use the Range Comparison Condition Met Flags to determine whether the high-speed counter PV is within a registered range.
- (2) When the count direction (incrementing/decrementing) changes at a PV that matches a target value, or when starting the target value comparison at a PV that matches a target value, the next target value cannot be matched in that direction. Set the target values so that they do not occur at the peak or trough of count value changes.

Pausing Input Signal Counting (Gate Function)

If the High-speed Counter Gate Bit is turned ON, the corresponding high-speed counter will not count even if pulse inputs are received and the counter PV will be maintained at its current value. Bits A53108 to A53111 are the High-speed Counter Gate Bits for high-speed counters 0 to 3.

When the High-speed Counter Gate Bit is turned OFF again, the high-speed counter will resume counting and the counter PV will be refreshed.

Restrictions

- The Gate Bit will be disabled if the high-speed counter's reset method is set to Phase-Z signal + Software reset and the Reset Bit is ON (waiting for the phase-Z input to reset the counter PV.)

High-speed Counter Frequency Measurement

This function measures the frequency of the high-speed counter (input pulses.)

The input pulse frequency can be read by executing the PRV(881) instruction. The measured frequency is output in 8-digit hexadecimal and expressed in Hz. The frequency measurement function can be used with high-speed counter 0 only.

The frequency can be measured while a high-speed counter 0 comparison operation is in progress. Frequency measurement can be performed at the same time as functions such as the high-speed counter and pulse output without affecting the performance of those functions.

Procedure

- 1,2,3...**
1. High-speed Counter Enable/Disable Setting (Required)
Select the *Use high speed counter 0* Option in the PLC Setup.
 2. Pulse Input Mode Setting (Required)
Set the High-speed Counter 0 Pulse Input Mode (*Input Setting*) in the PLC Setup.
 3. Counting Mode Setting (Required)
Set the High-speed Counter 0 *Counting Mode* in the PLC Setup.
If ring mode counting is selected, set the High-speed Counter 0 *Circular Max. Count* (max. ring count) in the PLC Setup.
 4. Reset Method Setting (Required)
Set the High-speed Counter 0 Reset Method in the PLC Setup.
 5. PRV(881) Instruction Execution (Required)
N: Specify the high-speed counter number. (High-speed counter 0: #0010)
C: #0003 (Read frequency)
D: Destination word for frequency data

Restrictions

- The frequency measurement function can be used with high-speed counter 0 only.

Specifications

Item	Specifications
Number of frequency measurement inputs	1 input (high-speed counter 0 only)
Frequency measurement range	<p>High-speed counter 0 in X/XA CPU Units: Differential phase inputs: 0 to 50 kHz All other input modes: 0 to 100 kHz</p> <p>High-speed counter 0 in Y CPU Units: Differential phase inputs: 0 to 500 kHz All other input modes: 0 to 1 MHz</p> <p>Note If the frequency exceeds the maximum value, the maximum value will be stored.</p>

Item	Specifications
Measurement method	Execution of the PRV(881) instruction
Output data range	Units: Hz Range: Differential phase input: 0000 0000 to 0003 0D40 hex (Y models: 0000 0000 to 0007 A120 hex) All other input modes: 0000 0000 to 0001 86A0 hex (Y models: 0000 0000 to 000F 4240 hex)

Pulse Frequency Conversion

The pulse frequency input to a high-speed counter can be converted to a rotational speed (r/min) or the PV of the counter can be converted to the total number of rotations. The converted value is output as 8-digit hexadecimal. This function is supported only for high-speed counter 0.

Frequency–Rotational Speed Conversion

The rotational speed in r/min is calculated from the pulse frequency input to a high-speed counter and the number of pulses per rotation.

Counter PV–Total Number of Rotations Conversion

The total number of rotations is calculated from the present value of the counter and the number of pulses per rotation.

Procedure

- 1,2,3...**
1. High-speed Counter Enable/Disable Setting (Required)
Select the *Use high speed counter 0* Option in the PLC Setup.
 2. Pulse Input Mode Setting (Required)
Set the High-speed Counter 0 Pulse Input Mode (*Input Setting*) in the PLC Setup.
 3. Counting Mode Setting (Required)
Set the High-speed Counter 0 *Counting Mode* in the PLC Setup.
If ring mode counting is selected, set the *Circular Max. Count* (max. ring count) in the PLC Setup.
 4. Reset Method Setting (Required)
Set the High-speed Counter 0 Reset Method in the PLC Setup.
 5. Execute PRV2(883) as described below (required).

Converting the Frequency to a Rotational Speed

Execute PRV2(883) with the following operands.

C: Control data (Set to #0000 for frequency-rotational speed conversion.)

P: Coefficient (pulses/rotation (hex))

D: First word for result

Converting the Counter PV to the Total Number of Rotations

Execute PRV2(883) with the following operands.

C: Control data (Set to #0001 for counter PV-total number of rotations conversion.)

P: Coefficient (pulses/rotation (hex))

D: First word for result

Restrictions

Pulse frequency conversion is possible only for high-speed counter 0.

5-3 Pulse Outputs

5-3-1 Overview

Fixed duty factor pulses can be output from the CPU Unit's built-in outputs to perform positioning or speed control with a servo driver that accepts pulse inputs.

■ CW/CCW Pulse Outputs or Pulse + Direction Outputs

The pulse output mode can be set to match the motor driver's pulse input specifications.

■ Various Output Frequency Ranges Available

Several output frequency ranges are available in different CPU Units and pulse output ports.

- X/XA CPU Units

Unit version 1.1 and later

Pulse outputs 0, 1, 2, 3: 1 Hz to 100 kHz

(Unit version 1.0 and earlier: Pulse outputs 0 and 1: 1 Hz to 100 kHz; pulse outputs 2 and 3: 1 Hz to 30 kHz)

- Y CPU Units

Pulse outputs 0 and 1: 1 Hz to 1 MHz (line driver outputs)

Pulse outputs 2 and 3: 1 Hz to 100 kHz

■ Automatic Direction Selection for Easy Positioning with Absolute Coordinates

When operating in absolute coordinates (origin defined or PV changed with the INI(880) instruction), the CW/CCW direction will be selected automatically when the pulse output instruction is executed. (The CW/CCW direction is selected by determining whether the number of pulses specified in the instruction is greater than or less than the pulse output PV.)

■ Triangular Control

Triangular control (trapezoidal control without a constant-speed plateau) will be performed during positioning executed by an ACC(888) instruction (independent) or PLS2(887) instruction if the number of output pulses required for acceleration/deceleration exceeds the specified target pulse Output Amount.

■ Change Target Position during Positioning (Multiple Start)

When positioning was started with a PULSE OUTPUT (PLS2(887)) instruction and the positioning operation is still in progress, another PLS2(887) instruction can be executed to change the target position, target speed, acceleration rate, and deceleration rate.

■ Switch from Speed Control to Positioning (Fixed Distance Feed Interrupt)

A PLS2(887) instruction can be executed during a speed control (continuous mode) operation to change to positioning mode (independent mode). This feature allows a fixed distance feed interrupt (moving a specified amount) to be executed when specific conditions occur.

■ Change Target Speed and Acceleration/Deceleration Rate during Acceleration or Deceleration

When trapezoidal acceleration/deceleration is being executed according to a pulse output instruction (speed control or positioning), the target speed and acceleration/deceleration rate can be changed during acceleration or deceleration.

■ Use Variable Duty Factor Pulse Outputs for Lighting, Power Control, Etc.

The PULSE WITH VARIABLE DUTY FACTOR instruction (PWM(891)) can be used to output variable duty factor pulses from the CPU Unit's built-in outputs for applications such as lighting and power control.

Controlling Pulse Outputs

Purpose	Function	Description
Perform simple positioning by outputting pulses to a motor driver that accepts pulse-train inputs.	Pulse output functions <ul style="list-style-type: none"> Single-phase pulse output without acceleration/deceleration Controlled by SPED. Single-phase pulse output with acceleration/deceleration (equal acceleration and deceleration rates for trapezoidal form) Controlled by ACC. Single-phase pulse output with trapezoidal acceleration/deceleration (Supports a startup frequency and different acceleration/deceleration rates.) Controlled by PLS2(887). 	In X/XA CPU Units, built-in outputs can be used as pulse outputs 0 to 3. In Y CPU Units, pulse outputs 0 and 1 can be used as pulse line-driver outputs and built-in output bits can be used as pulse outputs 2 and 3. Target frequency ranges in X/XA CPU Units: Unit version 1.1 and later: Pulse outputs 0, 1, 2, 3: 1 Hz to 100 kHz Unit version 1.0 and earlier: Pulse outputs 0 and 1: 1 Hz to 100 kHz (1 Hz units) Pulse outputs 2 and 3: 1 Hz to 30 kHz (1 Hz units) Target frequency ranges in Y CPU Units: Pulse outputs 0 and 1: 1 Hz to 1 MHz Pulse outputs 2 and 3: 1 Hz to 100 kHz Duty factor: 50% The pulse output mode can be set to CW/CCW pulse control or Pulse plus direction control, but the same output mode must be used for pulse outputs 0 and 1. Note The pulse output PVs are stored in the Auxiliary Area.
Perform origin search and origin return operations.	Origin functions (Origin search and origin return)	Origin search and origin return operations can be executed through pulse outputs. <ul style="list-style-type: none"> Origin search: To start the origin search, set the PLC Setup to enable the origin search operation, set the various origin search parameters, and execute the ORIGIN SEARCH instruction (ORG(889)). The Unit will determine the location of the origin based on the Origin Proximity Input Signal and Origin Input Signal. The coordinates of the pulse output's PV will automatically be set as the absolute coordinates. Origin return: To return to the predetermined origin, set the various origin return parameters and execute the ORIGIN SEARCH instruction (ORG(889)).
Change the target position during positioning. (For example, perform an emergency avoid operation with the Multiple Start feature.)	Positioning with the PLS2(887) instruction	When a positioning operation started with the PULSE OUTPUT (PLS2(887)) instruction is in progress, another PLS2(887) instruction can be executed to change the target position, target speed, acceleration rate, and deceleration rate.

Purpose	Function	Description
Change speed in steps (polyline approximation) during speed control.	Use the ACC(888) instruction (continuous) to change the acceleration rate or deceleration rate.	When a speed control operation started with the ACC(888) instruction (continuous) is in progress, another ACC(888) instruction (continuous) can be executed to change the acceleration rate or deceleration rate.
Change speed in steps (polyline approximation) during positioning.	Use the ACC(888) instruction (independent) or PLS2(887) to change the acceleration rate or deceleration rate.	When a positioning operation started with the ACC(888) instruction (independent) or PLS2(887) instruction is in progress, another ACC(888) (independent) or PLS2(887) instruction can be executed to change the acceleration rate or deceleration rate.
Perform fixed distance feed interrupt.	Execute positioning with the PLS2(887) instruction during an operation started with SPED(885) (continuous) or ACC(888) (continuous).	When a speed control operation started with the SPED(885) instruction (continuous) or ACC(888) instruction (continuous) is in progress, the PLS2(887) instruction can be executed to switch to positioning, output a fixed number of pulses, and stop.
After determining the origin, perform positioning simply in absolute coordinates without regard to the direction of the current position or target position.	The positioning direction is selected automatically in the absolute coordinate system.	When operating in absolute coordinates (with the origin determined or INI(880) instruction executed to change the PV), the CW or CCW direction is selected automatically based on the relationship between the pulse output PV and the pulse Output Amount specified when the pulse output instruction is executed.
Perform triangular control.	Positioning with the ACC(888) instruction (independent) or PLS2(887) instruction.	When a positioning operation started with the ACC(888) instruction (independent) or PLS2(887) instruction is in progress, triangular control (trapezoidal control without the constant-speed plateau) will be performed if the number of output pulses required for acceleration/deceleration exceeds the specified target pulse Output Amount. (The number of pulses required for acceleration/deceleration equals the time required to reach the target frequency x the target frequency.)
Use variable duty factor outputs for time-proportional temperature control.	Control with analog inputs and the variable duty factor pulse output function (PWM(891)).	Two built-in outputs can be used as PWM(891) outputs 0 and 1 by executing the PWM(891) instruction.

5-3-2 Pulse Output Specifications

Specifications

Item	Specifications
Output mode	Continuous mode (for speed control) or independent mode (for position control)
Positioning (independent mode) instructions	PULS(886) and SPED(885), PULS(886) and ACC(888), or PLS2(887)
Speed control (continuous mode) instructions	SPED(885) or ACC(888)
Origin (origin search and origin return) instructions	ORG(889)
Output frequency	X/XA CPU Units: Unit version 1.1 and later: Pulse outputs 0, 1, 2, 3: 1 Hz to 100 kHz (1 Hz units) Unit version 1.0 and earlier: Pulse outputs 0 and 1: 1 Hz to 100 kHz (1 Hz units) Pulse outputs 2 and 3: 1 Hz to 30 kHz (1 Hz units) Y CPU Units: Pulse outputs 0 and 1: 1 Hz to 1 MHz (1 Hz units) Pulse outputs 2 and 3: 1 Hz to 100 kHz (1 Hz units)

Item	Specifications
Frequency acceleration and deceleration rates	Set in 1 Hz units for acceleration/deceleration rates from 1 Hz to 65,635 Hz (every 4 ms). The acceleration and deceleration rates can be set independently only with PLS2(887).
Changing SVs during instruction execution	The target frequency, acceleration/deceleration rate, and target position can be changed.
Duty factor	Fixed at 50%
Pulse output method	CW/CCW inputs or Pulse + direction inputs The method is selected with an instruction operand. The same method must be used for pulse outputs 0 and 1.
Number of output pulses	Relative coordinates: 00000000 to 7FFFFFFF hex (Each direction accelerating or decelerating: 2,147,483,647) Absolute coordinates: 80000000 to 7FFFFFFF hex (-2147483648 to 2147483647)
Pulse output PV's relative/absolute coordinate specification	Absolute coordinates are specified automatically when the origin location has been determined by setting the pulse output PV with INI(880) or performing an origin search with ORG(889). Relative coordinates are used when the origin location is undetermined.
Relative pulse specification/ Absolute pulse specification	The pulse type can be specified with an operand in PULS(886) or PLS2(887). Note The absolute pulse specification can be used when absolute coordinates are specified for the pulse output PV, i.e. the origin location has been determined. The absolute pulse specification cannot be used when relative coordinates are specified, i.e. the origin location is undetermined. An instruction error will occur.
Pulse output PV's storage location	The following Auxiliary Area words contain the pulse output PVs: Pulse output 0: A277 (leftmost 4 digits) and A276 (rightmost 4 digits) Pulse output 1: A279 (leftmost 4 digits) and A278 (rightmost 4 digits) Pulse output 2: A323 (leftmost 4 digits) and A322 (rightmost 4 digits) Pulse output 3: A325 (leftmost 4 digits) and A324 (rightmost 4 digits) The PVs are refreshed during regular I/O refreshing.
Acceleration/deceleration curve specification	Trapezoidal or S-curve acceleration/deceleration

Pulse Output Modes

There are two pulse output modes. In independent mode the number of output pulses is specified and in continuous mode the number of output pulses is not specified.

Mode	Description
Independent mode	This mode is used for positioning. Operation stops automatically when the preset number of pulses has been output. It is also possible to stop the pulse output early with INI(880).
Continuous mode	This mode is used for speed control. The pulse output will continue until it is stopped by executing another instruction or switching the PLC to PROGRAM mode.


5-3-3 Pulse Output Terminal Allocations

The following diagrams show the terminals that can be used for pulse outputs in each CPU Unit.

X/XA CPU Units

■ Output Terminal Block Arrangement

Lower Terminal Block
(Example: Transistor Outputs)




■ Setting Functions Using Instructions and PLC Setup

Output terminal block		When the instructions to the right are not executed	When a pulse output instruction (SPED, ACC, PLS2, or ORG) is executed		When the origin search function is enabled in the PLC Setup, and an origin search is executed by the ORG instruction	When the PWM instruction is executed
Word	Bit	Normal output	Fixed duty factor pulse output			Variable duty factor pulse output
			CW/CCW	Pulse plus direction	When the origin search function is used	PWM output
CIO 100	00	Normal output 0	Pulse output 0 (CW) fixed	Pulse output 0 (pulse) fixed	---	---
	01	Normal output 1	Pulse output 0 (CCW) fixed	Pulse output 1 (pulse) fixed	---	---
	02	Normal output 2	Pulse output 1 (CW) fixed	Pulse output 0 (direction) fixed	---	---
	03	Normal output 3	Pulse output 1 (CCW) fixed	Pulse output 1 (direction) fixed	---	---
	04	Normal output 4	Pulse output 2 (CW)	Pulse output 2 (pulse)	---	---
	05	Normal output 5	Pulse output 2 (CCW)	Pulse output 2 (direction)	---	---
	06	Normal output 6	Pulse output 3 (CW)	Pulse output 3 (pulse)	---	---
	07	Normal output 7	Pulse output 3 (CCW)	Pulse output 3 (direction)	---	---
CIO 101	00	Normal output 8	---	---	---	PWM output 0
	01	Normal output 9	---	---	---	PWM output 1
	02	Normal output 10	---	---	Origin search 0 (Error counter reset output)	---
	03	Normal output 11	---	---	Origin search 1 (Error counter reset output)	---
	04	Normal output 12	---	---	Origin search 2 (Error counter reset output)	---
	05	Normal output 13	---	---	Origin search 3 (Error counter reset output)	---
	06	Normal output 14	---	---	---	---
	07	Normal output 15	---	---	---	---

■ Input Terminal Block Arrangement

Upper Terminal Block (Example: AC Power Supply Models)




■ Setting Input Functions in the PLC Setup

Input terminal block		Input operation			High-speed counters	Origin search
Word	Bit	Normal inputs	Interrupt inputs	Quick-response inputs	High-speed counter operation enabled. (Use <i>high speed counter</i> <input type="checkbox"/> Option selected.)	Pulse output origin search function enabled for pulse outputs 0 to 3.
CIO 0	00	Normal input 0	Interrupt input 0	Quick-response input 0	---	Pulse 0: Origin input signal
	01	Normal input 1	Interrupt input 1	Quick-response input 1	High-speed counter 2 (phase-Z/reset)	Pulse 0: Origin proximity input signal
	02	Normal input 2	Interrupt input 2	Quick-response input 2	High-speed counter 1 (phase-Z/reset)	Pulse output 1: Origin input signal
	03	Normal input 3	Interrupt input 3	Quick-response input 3	High-speed counter 0 (phase-Z/reset)	Pulse output 1: Origin proximity input signal
	04	Normal input 4	---	---	High-speed counter 2 (phase-A, increment, or count input)	---
	05	Normal input 5	---	---	High-speed counter 2 (phase-B, decrement, or direction input)	---
	06	Normal input 6	---	---	High-speed counter 1 (phase-A, increment, or count input)	---
	07	Normal input 7	---	---	High-speed counter 1 (phase-B, decrement, or direction input)	---
	08	Normal input 8	---	---	High-speed counter 0 (phase-A, increment, or count input)	---
	09	Normal input 9	---	---	High-speed counter 0 (phase-B, decrement, or direction input)	---
	10	Normal input 10	---	---	High-speed counter 3 (phase-A, increment, or count input)	---
	11	Normal input 11	---	---	High-speed counter 3 (phase-B, decrement, or direction input)	---
CIO 1	00	Normal input 12	Interrupt input 4	Quick-response input 4	High-speed counter 3 (phase-Z/reset)	Pulse output 2: Origin input signal
	01	Normal input 13	Interrupt input 5	Quick-response input 5	---	Pulse output 2: Origin proximity input signal
	02	Normal input 14	Interrupt input 6	Quick-response input 6	---	Pulse output 3: Origin input signal
	03	Normal input 15	Interrupt input 7	Quick-response input 7	---	Pulse output 3: Origin proximity input signal
	04 to 11	Normal input 16 to 23	---	---	---	---

Y CPU Units

■ Output Terminal Block Arrangement


Lower Terminal Block



■ Setting Functions using Instructions and PLC Setup

Output terminal block		When the instructions to the right are not executed	When a pulse output instruction (SPED, ACC, PLS2, or ORG) is executed		When the origin search function is enabled in the PLC Setup, and an origin search is executed by the ORG instruction	When the PWM instruction is executed
Word	Bit	Normal output	Fixed duty factor pulse output			Variable duty factor pulse output
			CW/CCW	Pulse plus direction	When the origin search function is used	PWM output
---	CW0	Cannot be used.	Pulse output 0 (CW) fixed	Pulse output 0 (pulse) fixed	---	---
---	CCW0	Cannot be used.	Pulse output 0 (CCW) fixed	Pulse output 1 (pulse) fixed	---	---
---	CW1	Cannot be used.	Pulse output 1 (CW) fixed	Pulse output 0 (direction)	---	---
---	CCW1	Cannot be used.	Pulse output 1 (CCW) fixed	Pulse output 1 (direction)	---	---
CIO 100	04	Normal output 4	Pulse output 2 (CW)	Pulse output 2 (pulse)	---	---
	05	Normal output 5	Pulse output 2 (CCW)	Pulse output 2 (direction)	---	---
	06	Normal output 6	Pulse output 3 (CW)	Pulse output 3 (pulse)	---	---
	07	Normal output 7	Pulse output 3 (CCW)	Pulse output 3 (direction)	---	---
CIO 101	00	Normal output 8	---	---	Origin search 2 (Error counter reset output)	PWM output 0
	01	Normal output 9	---	---	Origin search 3 (Error counter reset output)	PWM output 1
	02	Normal output 10	---	---	Origin search 0 (Error counter reset output)	---
	03	Normal output 11	---	---	Origin search 1 (Error counter reset output)	---
	04 to 07	Normal output 12 to 15	---	---	---	---

Input Terminal Block Arrangement



Setting Input Functions in the PLC Setup

Input terminal block		Input operation			High-speed counters	Origin search
Word	Bit	Normal inputs	Interrupt inputs	Quick-response inputs	High-speed counter operation enabled. (Use <i>high speed counter</i> <input type="checkbox"/> Option selected.)	Pulse output origin search function enabled for pulse outputs 0 and 1.
---	A0	---	---	---	High-speed counter 0 (phase-A, increment, or count input)	---
---	B0	---	---	---	High-speed counter 0 (phase-B, decrement, or direction input)	---
---	Z0	---	---	---	High-speed counter 0 (phase-Z/reset)	Pulse 0: Origin input signal (line driver)
---	A1	---	---	---	High-speed counter 1 (phase-A, increment, or count input)	---
---	B1	---	---	---	High-speed counter 1 (phase-B, decrement, or direction input)	---
---	Z1	---	---	---	High-speed counter 1 (phase-Z/reset)	Pulse 1: Origin input signal (line driver)
CIO 0	00	Normal input 0	Interrupt input 0	Quick-response input 0	---	Pulse 2: Origin proximity input signal
	01	Normal input 1	Interrupt input 1	Quick-response input 1	High-speed counter 2 (phase-Z/reset)	---
	04	Normal input 2	---	---	High-speed counter 2 (phase-A, increment, or count input)	---
	05	Normal input 3	---	---	High-speed counter 2 (phase-B, decrement, or direction input)	---
	10	Normal input 4	---	---	High-speed counter 3 (phase-A, increment, or count input)	---
	11	Normal input 5	---	---	High-speed counter 3 (phase-B, decrement, or direction input)	Pulse 3: Origin proximity input signal

Input terminal block		Input operation			High-speed counters	Origin search
Word	Bit	Normal inputs	Interrupt inputs	Quick-response inputs	High-speed counter operation enabled. (Use <i>high speed counter</i> □ Option selected.)	Pulse output origin search function enabled for pulse outputs 0 and 1.
CIO 1	00	Normal input 6	Interrupt input 2	Quick-response input 2	High-speed counter 3 (phase-Z/reset)	Pulse 3: Origin input signal
	01	Normal input 7	Interrupt input 3	Quick-response input 3	---	Pulse 2: Origin input signal
	02	Normal input 8	Interrupt input 4	Quick-response input 4	---	Pulse 1: Origin input signal (open collector)
	03	Normal input 9	Interrupt input 5	Quick-response input 5	---	Pulse 0: Origin input signal (open collector)
	04	Normal input 10	---	---	---	Pulse 1: Origin proximity input signal
	05	Normal input 11	---	---	---	Pulse 0: Origin proximity input signal

Auxiliary Area Data Allocation (All Models)

Function		Pulse output number			
		0	1	2	3
Pulse output PV storage words PV range: 80000000 to 7FFFFFFF hex (-2,147,483,648 to 2,147,483,647)	Leftmost 4 digits	A277	A279	A323	A325
	Rightmost 4 digits	A276	A278	A322	A324
Reset Bits The pulse output PV will be cleared when this bit is turned from OFF to ON.	0: Not cleared. 1: Clear PV.	A540.00	A541.00	A542.00	A543.00
CW Limit Input Signal Flags This is the CW limit input signal, which is used in the origin search.	ON when turned ON from an external input.	A540.08	A541.08	A542.08	A543.08
CCW Limit Input Signal Flags This is the CCW limit input signal, which is used in the origin search.	ON when turned ON from an external input.	A540.09	A541.09	A542.09	A543.09
Positioning completed input signals This is the positioning completed input signal, which is used in the origin search.	ON when turned ON from an external input.	A540.10	A541.10	A542.10	A543.10
Accel/Decel Flags ON when pulses are being output according to an ACC(888) or PLS2(887) instruction and the output frequency is being changed in steps (accelerating or decelerating).	0: Constant speed 1: Accelerating or decelerating	A280.00	A281.00	A326.00	A327.00
Overflow/Underflow Flags ON when an overflow or underflow has occurred in the pulse output PV.	0: Normal 1: Overflow or underflow	A280.01	A281.01	A326.01	A327.01
Output Amount Set Flags ON when the number of output pulses has been set with the PULS instruction.	0: No setting 1: Setting made	A280.02	A281.02	A326.02	A327.02
Output Completed Flags ON when the number of output pulses set with the PULS(886)/PLS2(887) instruction has been output.	0: Output not completed. 1: Output completed.	A280.03	A281.03	A326.03	A327.03
Output In-progress Flags ON when pulses are being output from the pulse output.	0: Stopped 1: Outputting pulses.	A280.04	A281.04	A326.04	A327.04

Function		Pulse output number			
		0	1	2	3
No-origin Flags ON when the origin has not been determined for the pulse output.	0: Origin established. 1: Origin not established.	A280.05	A281.05	A326.05	A327.05
At-origin Flags ON when the pulse output PV matches the origin (0).	0: Not stopped at origin. 1: Stopped at origin.	A280.06	A281.06	A326.06	A327.06
Output Stopped Error Flags ON when an error occurred while outputting pulses in the origin search function.	0: No error 1: Stop error occurred.	A280.07	A281.07	A326.07	A327.07
Stop Error Codes	---	A444	A445	A438	A439

5-3-4 Pulse Output Patterns




The following tables show the kinds of pulse output operations that can be performed by combining various pulse output instructions.

Continuous Mode (Speed Control)

Starting a Pulse Output

Operation	Example application	Frequency changes	Description	Procedure	
				Instruction	Settings
Output with specified speed	Changing the speed (frequency) in one step	<p>Pulse frequency</p> <p>Target frequency</p> <p>Time</p> <p>Execution of SPED(885)</p>	Outputs pulses at a specified frequency.	SPED(885) (Continuous)	<ul style="list-style-type: none"> •Port "CW/CCW" or "Pulse + direction" •Continuous •Target frequency
Output with specified acceleration and speed	Accelerating the speed (frequency) at a fixed rate	<p>Pulse frequency</p> <p>Target frequency</p> <p>Acceleration/deceleration rate</p> <p>Time</p> <p>Execution of ACC(888)</p>	Outputs pulses and changes the frequency at a fixed rate.	ACC(888) (Continuous)	<ul style="list-style-type: none"> •Port "CW/CCW" or "Pulse + direction" •Continuous •Acceleration/deceleration rate •Target frequency

Changing Settings

Operation	Example application	Frequency changes	Description	Procedure	
				Instruction	Settings
Change speed in one step	Changing the speed during operation		Changes the frequency (higher or lower) of the pulse output in one step.	SPED(885) (Continuous) ↓ SPED(885) (Continuous)	<ul style="list-style-type: none"> •Port •Continuous •Target frequency
Change speed smoothly	Changing the speed smoothly during operation		Changes the frequency from the present frequency at a fixed rate. The frequency can be accelerated or decelerated.	ACC(888) or SPED(885) (Continuous) ↓ ACC(888) (Continuous)	<ul style="list-style-type: none"> •Port •Continuous •Target frequency •Acceleration/deceleration rate
	Changing the speed in a polyline curve during operation		Changes the acceleration or deceleration rate during acceleration or deceleration.	ACC(888) (Continuous) ↓ ACC(888) (Continuous)	<ul style="list-style-type: none"> •Port •Continuous •Target frequency •Acceleration/deceleration rate
Change direction	Not supported.				
Change pulse output method	Not supported.				

Stopping a Pulse Output

Operation	Example application	Frequency changes	Description	Procedure	
				Instruction	Settings
Stop pulse output	Immediate stop	<p>Pulse frequency</p> <p>Present frequency</p> <p>Time</p> <p>Execution of INI(880)</p>	Stops the pulse output immediately.	SPED(885) or ACC(888) (Continuous) ↓ INI(880)	<ul style="list-style-type: none"> •Port •Stop pulse output
Stop pulse output	Immediate stop	<p>Pulse frequency</p> <p>Present frequency</p> <p>Time</p> <p>Execution of SPED(885)</p>	Stops the pulse output immediately.	SPED(885) ↓ SPED(885) (Continuous)	<ul style="list-style-type: none"> •Port •Continuous •Target frequency=0
Stop pulse output smoothly	Decelerate to a stop	<p>Pulse frequency</p> <p>Present frequency</p> <p>Target frequency = 0</p> <p>Time</p> <p>Execution of ACC(888)</p> <p>Acceleration/ deceleration rate (Rate set at the start of the operation.)</p>	<p>Decelerates the pulse output to a stop.</p> <p>Note If ACC(888) started the operation, the original acceleration/deceleration rate will remain in effect. If SPED(885) started the operation, the acceleration/deceleration rate will be invalid and the pulse output will stop immediately.</p>	SPED(885) or ACC(888) (Continuous) ↓ ACC(888) (Continuous)	<ul style="list-style-type: none"> •Port •Continuous •Target frequency=0


Independent Mode (Positioning)

Starting a Pulse Output

Operation	Example application	Frequency changes	Description	Procedure	
				Instruction	Settings
Output with specified speed	Positioning without acceleration or deceleration		<p>Starts outputting pulses at the specified frequency and stops immediately when the specified number of pulses has been output.</p> <p>Note The target position (specified number of pulses) cannot be changed during positioning.</p>	PULS(886) ↓ SPED(885)	<ul style="list-style-type: none"> •Number of pulses •Relative or absolute pulse specification •Port •“CW/CCW” or “Pulse + direction” •Independent •Target frequency
Simple trapezoidal control	Positioning with trapezoidal acceleration and deceleration (Same rate used for acceleration and deceleration; no starting speed) The number of pulses cannot be changed during positioning.		<p>Accelerates and decelerates at the same fixed rate and stops immediately when the specified number of pulses has been output. (See note.)</p> <p>Note The target position (specified number of pulses) cannot be changed during positioning.</p>	PULS(886) ↓ ACC(888) (Independent)	<ul style="list-style-type: none"> •Number of pulses •Relative or absolute pulse specification •Port •“CW/CCW” or “Pulse + direction” •Independent •Acceleration and deceleration rate •Target frequency
Complex trapezoidal control	Positioning with trapezoidal acceleration and deceleration (Separate rates used for acceleration and deceleration; starting speed) The number of pulses can be changed during positioning.		<p>Accelerates and decelerates at a fixed rates. The pulse output is stopped when the specified number of pulses has been output. (See note.)</p> <p>Note The target position (specified number of pulses) can be changed during positioning.</p>	PLS2(887)	<ul style="list-style-type: none"> •Number of pulses •Relative or absolute pulse specification •Port •“CW/CCW” or “Pulse + direction” •Acceleration rate •Deceleration rate •Target frequency •Starting frequency



Note Triangular Control

If the specified number of pulses is less than the number required just to reach the target frequency and return to zero, the function will automatically reduce the acceleration/deceleration time and perform triangular control (acceleration and deceleration only.) An error will not occur.



Changing Settings

Operation	Example application	Frequency changes	Description	Procedure	
				Instruction	Settings
Change speed in one step	Changing the speed in one step during operation	<p>Execution of SPED(885) (independent mode)</p> <p>SPED(885) (independent mode) executed again to change the target frequency. (The target position is not changed.)</p>	<p>SPED(885) can be executed during positioning to change (raise or lower) the pulse output frequency in one step.</p> <p>The target position (specified number of pulses) is not changed.</p>	<p>PULS(886) ↓ SPED(885) (Independent) ↓ SPED(885) (Independent)</p>	<ul style="list-style-type: none"> •Number of pulses •Relative or absolute pulse specification •Port •“CW/CCW” or “Pulse + direction” •Independent •Target frequency
Change speed smoothly (with acceleration rate = deceleration rate)	Changing the target speed (frequency) during positioning (acceleration rate = deceleration rate)	<p>Execution of ACC(888) (independent mode)</p> <p>ACC(888) (independent mode) executed again to change the target frequency. (The target position is not changed, but the acceleration/deceleration rate is changed.)</p>	<p>ACC(888) can be executed during positioning to change the acceleration/deceleration rate and target frequency.</p> <p>The target position (specified number of pulses) is not changed.</p>	<p>PULS(886) ↓ ACC(888) or SPED(885) (Independent) ↓ ACC(888) (Independent)</p> <p>PLS2(887) ↓ ACC(888) (Independent)</p>	<ul style="list-style-type: none"> •Number of pulses •Relative or absolute pulse specification •Port •“CW/CCW” or “Pulse + direction” •Independent •Acceleration and deceleration rate •Target frequency



Operation	Example application	Frequency changes	Description	Procedure	
				Instruction	Settings
Change speed smoothly (with unequal acceleration and deceleration rates)	Changing the target speed (frequency) during positioning (different acceleration and deceleration rates)	 <p>Execution of ACC(888) (independent mode)</p> <p>PLS2(887) executed to change the target frequency and acceleration/deceleration rates. (The target position is not changed. The original target position is specified again.)</p>	<p>PLS2(887) can be executed during positioning to change the acceleration rate, deceleration rate, and target frequency.</p> <p>Note To prevent the target position from being changed intentionally, the original target position must be specified in absolute coordinates.</p>	PULS(886) ↓ ACC(888) (Independent) ↓ PLS2(887) ↓ PLS2(887) ↓ PLS2(887)	<ul style="list-style-type: none"> •Number of pulses •Relative or absolute pulse specification •Port •“CW/CCW” or “Pulse + direction” •Acceleration rate •Deceleration rate •Target frequency •Starting frequency
Change target position	Change the target position during positioning (multiple start function)	 <p>Execution of PLS2(887)</p> <p>PLS2(887) executed to change the target position. (The target frequency and acceleration/deceleration rates are not changed)</p>	<p>PLS2(887) can be executed during positioning to change the target position (number of pulses).</p> <p>Note When the target position cannot be changed without maintaining the same speed range, an error will occur and the original operation will continue to the original target position.</p>	PULS(886) ↓ ACC(888) (Independent) ↓ PLS2(887) ↓ PLS2(887) ↓ PLS2(887) ↓ PLS2(887)	<ul style="list-style-type: none"> •Number of pulses •Relative or absolute pulse specification •Port •“CW/CCW” or “Pulse + direction” •Acceleration rate •Deceleration rate •Target frequency •Starting frequency

Operation	Example application	Frequency changes	Description	Procedure	
				Instruction	Settings
Change target position and speed smoothly	Change the target position and target speed (frequency) during positioning (multiple start function)	<p>Execution of PLS2(887)</p> <p>ACC(888) executed to change the target frequency. (The target position is not changed, but the acceleration/ deceleration rates are changed.)</p>	PLS2(887) can be executed during positioning to change the target position (number of pulses), acceleration rate, deceleration rate, and target frequency.	PULS(886) ↓ ACC(888) (Independent) ↓ PLS2(887)	<ul style="list-style-type: none"> •Number of pulses •Relative or absolute pulse specification •Port •“CW/ CCW” or “Pulse + direction” •Acceleration rate •Deceleration rate •Target frequency •Starting frequency
	Change the acceleration and deceleration rates during positioning (multiple start function)	<p>Execution of PLS2(887) #1</p> <p>Execution of PLS2(887) #2</p> <p>Execution of PLS2(887) #3</p>	PLS2(887) can be executed during positioning (acceleration or deceleration) to change the acceleration rate or deceleration rate.	PULS(886) ↓ ACC(888) (Independent) ↓ PLS2(887) ↓ PLS2(887) ↓ PLS2(887)	<ul style="list-style-type: none"> •Number of pulses •Acceleration rate •Deceleration rate
Change direction	Change the direction during positioning	<p>Execution of PLS2(887)</p> <p>Execution of PLS2(887)</p>	PLS2(887) can be executed during positioning with relative pulse specification to change to absolute pulses and reverse direction.	PULS(886) ↓ ACC(888) (Independent) ↓ PLS2(887) ↓ PLS2(887) ↓ PLS2(887)	<ul style="list-style-type: none"> •Number of pulses •Absolute pulse specification •Port •“CW/ CCW” or “Pulse + direction” •Acceleration rate •Deceleration rate •Target frequency •Starting frequency
Change pulse output method	Not supported.				

Stopping a Pulse Output

Operation	Example application	Frequency changes	Description	Procedure	
				Instruction	Settings
Stop pulse output (Number of pulses setting is not preserved.)	Immediate stop	<p>Pulse frequency</p> <p>Present frequency</p> <p>Time</p> <p>Execution of SPED(885)</p> <p>Execution of INI(880)</p>	Stops the pulse output immediately and clears the number of output pulses setting.	PULS(886) ↓ ACC(888) or SPED(885) (Independent) ↓ INI(880)	•Stop pulse output
Stop pulse output (Number of pulses setting is not preserved.)	Immediate stop	<p>Pulse frequency</p> <p>Present frequency</p> <p>Time</p> <p>Execution of SPED(885)</p> <p>Execution of SPED(885)</p>	Stops the pulse output immediately and clears the number of output pulses setting.	PULS(886) ↓ SPED(885) (Independent) ↓ SPED(885)	•Port •Independent •Target frequency = 0
Stop sloped pulse output smoothly. (Number of pulses setting is not preserved.)	Decelerate to a stop	<p>Pulse frequency</p> <p>Present frequency</p> <p>Target frequency = 0</p> <p>Time</p> <p>Execution of ACC(888)</p> <p>Original deceleration rate</p>	Decelerates the pulse output to a stop. Note If ACC(888) started the operation, the original acceleration/deceleration rate will remain in effect. If SPED(885) started the operation, the acceleration/deceleration rate will be invalid and the pulse output will stop immediately.	PULS(886) ↓ ACC(888) or SPED(885) (Independent) ↓ ACC(888) (Independent) PLS2(887) ↓ ACC(888) (Independent)	•Port •Independent •Target frequency = 0

Switching from Continuous Mode (Speed Control) to Independent Mode (Positioning)

Example application	Frequency changes	Description	Procedure	
			Instruction	Settings
Change from speed control to fixed distance positioning during operation	 <p>Outputs the number of pulses specified in PLS2(887) (Both relative and absolute pulse specification can be used.)</p>	<p>PLS2(887) can be executed during a speed control operation started with ACC(888) to change to positioning operation.</p> <p>Note An error will occur if a constant speed cannot be achieved after switching the mode. If this happens, the instruction execution will be ignored and the previous operation will be continued.</p>	<p>ACC(888) (Continuous) ↓ PLS2(887)</p>	<ul style="list-style-type: none"> •Port •Acceleration rate •Deceleration rate •Target frequency •Number of pulses <p>Note The starting frequency is ignored.</p>
Fixed distance feed interrupt	 <p>Execution of PLS2(887) with the following settings</p> <ul style="list-style-type: none"> • Number of pulses = number of pulses until stop • Relative pulse specification • Target frequency = present frequency • Acceleration rate = Not 0 • Deceleration rate = target deceleration rate 			

Relative Pulse Outputs and Absolute Pulse Outputs**Selecting Relative or Absolute Coordinates**



The pulse output PV's coordinate system (absolute or relative) is selected automatically, as follows:


- When the origin is undetermined, the system operates in relative coordinates.
- When the origin has been determined, the system operates in absolute coordinates.

Conditions	Origin has been determined by an origin search	Origin has been determined by executing INI(880) to change the PV	Origin not established (Origin search has not been performed and PV has not been changed with INI(880).)
Pulse output PV's coordinate system	Absolute coordinates		Relative coordinates

Relationship between the Coordinate System and Pulse Specification

The following table shows the pulse output operation for the four possible combinations of the coordinate systems (absolute or relative) and the pulse output (absolute or relative) specified when PULS(886) or PLS2(887) is executed.

Pulse output specified in PULS(886) or PLS2(887)	Coordinate system	
	Relative coordinate system	Absolute coordinate system
	Origin not established: The No-origin Flag will be ON in this case.	Origin established: The No-origin Flag will be OFF in this case.
	<p>Positions the system to another position relative to the current position. Number of movement pulses = number of pulses setting</p> <p>The pulse output PV after instruction execution = Number of movement pulses = Number of pulses setting</p> <p>Note The pulse output PV is reset to 0 just before pulses are output. After that, the specified number of pulses is output.</p> <p>The following example shows the number of pulses setting = 100 counterclockwise.</p>  <p>Pulse output PV range: 80000000 to 7FFFFFFF hex</p> <p>Number of pulses setting range: 00000000 to 7FFFFFFF hex</p>	<p>The pulse output PV after instruction execution = PV + Number of movement pulses. The following example shows the number of pulses setting = 100 counterclockwise.</p>  <p>Pulse output PV range: 80000000 to 7FFFFFFF hex</p> <p>Number of pulses setting range: 00000000 to 7FFFFFFF hex</p>

Pulse output specified in PULS(886) or PLS2(887)	Coordinate system	
	Relative coordinate system	Absolute coordinate system
	Origin not established: The No-origin Flag will be ON in this case.	Origin established: The No-origin Flag will be OFF in this case.
Absolute pulse specification	The absolute pulse specification cannot be used when the origin location is undetermined, i.e., when the system is operating in the relative coordinate system. An instruction execution error will occur.	<p>Positions the system to an absolute position relative to the origin.</p> <p>The number of movement pulses and movement direction are calculated automatically from the current position (pulse output PV) and target position.</p> <p>The following example shows the number of pulses setting = +100.</p>  <p>Number of movement pulses = Number of pulses setting - Pulse output PV when instruction is executed</p> <p>The movement direction is determined automatically.</p> <p>Pulse output PV when instruction is executed = Number of pulses setting</p> <p>Pulse output PV range: 80000000 to 7FFFFFFF hex</p> <p>Number of pulses setting range: 80000000 to 7FFFFFFF hex</p>

Operations Affecting the Origin Status (Established/Not Established Status)

The following table shows the operations that can affect the origin status (origin established or no-origin), such as changing the operating mode and executing certain instructions.

The No-origin Flag will be ON when the corresponding pulse output's origin is not established and OFF when the origin is established.

Operation		PROGRAM mode		RUN mode or MONITOR mode	
		Origin established	Origin not established	Origin established	Origin not established
Operating mode change	Switch to RUN or MONITOR	Status changes to "Origin not established."	"Origin not established" status continues.	---	---
	Switch to PROGRAM	---	---	"Origin established" status continues.	"Origin not established" status continues.

Current status Operation		PROGRAM mode		RUN mode or MONITOR mode	
		Origin established	Origin not established	Origin established	Origin not established
Instruction execution	Origin search performed by ORG(889)	---	---	Status changes to "Origin established."	Status changes to "Origin established."
	PV changed by INI(880)	---	---	"Origin established" status continues.	Status changes to "Origin established."
The Pulse Output Reset Bit (A54000 or A54100) goes from OFF to ON.		Status changes to "Origin not established."	"Origin not established" status continues.	Status changes to "Origin not established."	"Origin not established" status continues.

Movement Direction when Using Absolute Pulse Specification

When operating with the absolute pulse specification, the movement direction is selected automatically based on the relationship between the pulse output PV when the instruction is executed and the specified target position. The direction (CW/CCW) specified in an ACC(888) or SPED(885) instruction is not effective.

Using CW/CCW Limit Inputs for Pulse Output Functions Other than Origin Searches

Pulse outputs will stop when either the CW or CCW limit input signals turns ON. It is also possible to select whether or not the established origin will be cleared when a CW or CCW limit input signal turns ON for an origin search or other pulse output function.


S-curve Acceleration/Deceleration

S-curve acceleration/deceleration can be used for pulse output instructions involving acceleration/deceleration. When there is leeway in the maximum allowable speed, S-curve accelerations/decelerations will help control shock and vibration by reducing the initial acceleration rate in comparison with linear acceleration/deceleration.

Note The setting for S-curve acceleration/deceleration applies to all pulse outputs.

Output Pattern

The output pattern for S-curve acceleration/deceleration is shown below.

Example for PLS2(887)

The same type of S-curve acceleration/deceleration can be used for ACC(888) as well.

Note The curve for S-curve acceleration/deceleration is formed by applying a cubic equation to the straight line of the set acceleration/deceleration rates (a cubic polynomial approximation). The curve's parameters cannot be changed. The maximum acceleration will be 1.5 times that of trapezoidal acceleration/deceleration for the same acceleration/deceleration rate.

Procedure

Make the following settings in the PLC Setup.

Pulse Output 0 to 3


Speed Curve	Trapezium	When a pulse output is executed with acceleration/deceleration, this setting determines whether the acceleration/deceleration rate is linear (trapezium) or S-shaped.
	S-shaped	

Restrictions


The following restrictions apply when using S-curve acceleration/deceleration.

Starting Frequency


The starting frequency must be 100 Hz or greater. If the starting frequency is set to less than 100 Hz, it will automatically be increased to 100 Hz if S-curve acceleration/deceleration is set.

**Target Frequency**

S-curve acceleration/deceleration will not be performed if the target frequency is less than 100 Hz.

**Precautions when using the Pulse Output Function**

The CP1H CPU Unit's pulse output frequency is determined by dividing the source clock frequency by an integer ratio. (The source clock frequency for ports 0 and 1 is 20 MHz and the frequency for ports 2 and 3 is 16.4 MHz.) Consequently, there may be a slight difference between the set frequency and the actual frequency, and that difference increases as the frequency increases. The actual frequency can be calculated from the following equations.

Pulse Output System

$$\text{Actual frequency (kHz)} = \frac{\text{Source clock frequency}}{\text{Dividing ratio}}$$

$$\text{Dividing ratio} = \text{INT} \left[\frac{(\text{Clock frequency} \times 2) + \text{Set frequency}}{\text{Set frequency (kHz)} \times 2} \right]$$

Differences between Set Frequencies and Actual Frequencies

- Port 2/3 (Source clock frequency: 16.4 MHz)

	Set frequency (kHz)	Actual frequency (kHz)
164	99.696 to 100.000	100.000
165	99.093 to 99.696	99.393
166	98.498 to 99.093	98.795
	:	:
327	50.076 to 50.229	50.152
328	49.923 to 50.076	50.000
329	49.772 to 49.923	49.848
	:	:
819	20.012 to 20.036	20.024
820	19.987 to 20.012	20.000
821	19.963 to 19.987	19.975
	:	:
1639	10.003 to 10.009	10.006
1640	9.996 to 10.003	10.000
1641	9.990 to 9.996	9.993
	:	:
3279	5.000 to 5.002	5.001
3280	4.999 to 5.000	5.000
3281	4.997 to 4.999	4.998
	:	:
5464	3.001 to 3.001	3.001
5466	3.000 to 3.000	3.000
5468	2.998 to 2.999	2.999

5-3-5 Origin Search and Origin Return Functions

The CP1H CPU Units have two functions that can be used to determine the machine origin for positioning.

1,2,3...

1. Origin Search

The ORG instruction outputs pulses to turn the motor according to the pattern specified in the origin search parameters. As the motor turns, the origin search function determines the machine origin from the following 3 kinds of position input signals.

- Origin input signal
- Origin proximity input signal
- CW limit input signal and CCW limit input signal

2. Changing the Pulse Output PV

When you want to set the current position as the origin, execute INI(880) to reset the pulse output PV to 0.

The origin location can be determined after using either method.

The CP1H CPU Units are also equipped with the origin return function, which can be executed to return the system to the origin after the origin location has been determined by one of the methods above.

• Origin Return

If the motor is stopped, ORG(889) can be executed to perform an origin return operation that moves the motor back to the origin position. The origin position must be determined in advance by performing an origin search or changing the pulse output PV.

Note The motor can be moved even if the origin position has not been determined, but positioning operations will be limited as follows:

- Origin return: Cannot be used.
- Positioning with absolute pulse specification: Cannot be used.
- Positioning with relative pulse specification: Outputs the specified number of pulses after setting the current position to 0.


5-3-5-1 Origin Search

When ORG(889) executes an origin search, it outputs pulses to actually move the motor and determines the origin position using the input signals that indicate the origin proximity and origin positions.


The input signals that indicate the origin position can be received from the servomotor's built-in phase-Z signal or external sensors such as photoelectric sensors, proximity sensors, or limit switches.

Several origin search patterns can be selected.

In the following example, the motor is started at a specified speed, accelerated to the origin search high speed, and run at that speed until the origin proximity position is detected. After the Origin Proximity Input is detected, the motor is decelerated to the origin search low speed and run at that speed until the origin position is detected. The motor is stopped at the origin position.



Procedure



Restrictions

- The Phase-Z signal + Software reset method cannot be used for a high-speed counter when the origin search function has been enabled in the PLC Setup.

PLC Setup

■ **Origin Search Function Enable/Disable Settings**

These PLC Setup indicate whether or not the origin search function will be used for each pulse output.

■ Limit Input Signal Setting

Specify in the following PLC Setup whether to use the CW/CCW limit input signals only for origin searches or for all pulse output functions. These settings affect all pulse outputs.

(This setting is called the *Limited Input Signal Operation* setting.)

■ Pulse Output 0 Undefined Origin Setting

■ Acceleration/Deceleration Curve Settings

Note The acceleration/deceleration curve setting applies to all pulse outputs, not just to origin searches. Refer to S-curve Acceleration/Deceleration on page 251 for details.

Origin Search Parameters

The various origin search parameters are set in the PLC Setup.

Name		Settings	Time when read
Operating mode		Operating mode 0, 1, or 2	Start of operation
Origin search operation setting		0: Reversal mode 1 1: Reversal mode 2	Start of operation
Origin detection method		0: Read the Origin Input Signal after the Origin Proximity Input Signal goes from OFF→ON→OFF. 1: Read the Origin Input Signal after the Origin Proximity Input Signal goes from OFF→ON. 2: Just read the Origin Input Signal without using the Origin Proximity Input Signal.	Start of operation
Origin search direction		0: CW direction 1: CCW direction	Start of operation
Origin search speed (See note.)	Origin search/return initial speed	X/XA CPU Units: Unit version 1.1 and later: • Pulse outputs 0 to 3: 00000000 to 000186A0 hex (0 Hz to 100 kHz) Unit version 1.0 and earlier: • Pulse outputs 0 and 1: 00000000 to 000186A0 hex (0 Hz to 100 kHz) • Pulse outputs 2 and 3: 00000000 to 00007530 hex (0 Hz to 30 kHz) Y CPU Units: • Pulse outputs 0 and 1: 00000000 to 000F4240 hex (0 Hz to 1 MHz) • Pulse outputs 2 and 3: 00000000 to 000186A0 hex (0 Hz to 100 kHz)	Start of operation

Name		Settings	Time when read
Origin search speed (See note.)	Origin search high speed	X/XA CPU Units: Unit version 1.1 and later: • Pulse outputs 0 to 3: 00000001 to 000186A0 hex (1 Hz to 100 kHz) Unit version 1.0 and earlier: • Pulse outputs 0 and 1: 00000001 to 000186A0 hex (1 Hz to 100 kHz) • Pulse outputs 2 and 3: 00000001 to 00007530 hex (1 Hz to 30 kHz) Y CPU Units: • Pulse outputs 0 and 1: 00000001 to 000F4240 hex (1 Hz to 1 MHz) • Pulse outputs 2 and 3: 00000001 to 000186A0 hex (1 Hz to 100 kHz)	Start of operation
	Origin search proximity speed	Same as above.	Start of operation
	Origin search acceleration rate	0001 to FFFF hex (1 to 65,535 Hz/4 ms)	Start of operation
	Origin search deceleration rate	0001 to FFFF hex (1 to 65,535 Hz/4 ms)	Start of operation
Origin compensation		80000000 to 7FFFFFFF hex (-2147483648 to 2147483647)	Start of operation
I/O settings		Limit Input Signal type 0: Normally closed (NC) 1: Normally open (NO)	Start of operation
		Origin Proximity Input Signal type 0: Normally closed (NC) 1: Normally open (NO)	Start of operation
		Origin Input Signal type X/XA CPU Units 0: Normally closed (NC) 1: Normally open (NO) Y CPU Units (Pulse outputs 0 and 1) 0: Normally closed (NC) (Open collector) 1: Normally open (NO) (Open collector) 2: Normally closed (NC) (Line driver) 3: Normally open (NO) (Line driver) Y CPU Units (Pulse outputs 2 and 3) 0: Normally closed (NC) 1: Normally open (NO)	When power is turned ON
Positioning monitor time		0000 to 270F hex (0 to 9,999 ms)	Start of operation

Note An origin search will not be started unless the origin search proximity speed is less than the origin search high speed and unless the origin search/return initial speed is less than the origin search proximity speed.

Explanation of the Origin Search Parameters

Operating Mode

The operating mode parameter specifies the kind of I/O signals that are used in the origin search. The 3 operating modes indicate whether the Error Counter Reset Output and Positioning Completed Input are used.

Operating mode	I/O signal			Remarks
	Origin Input Signal	Error Counter Reset Output	Positioning Completed Input	Operation when the origin is detected during deceleration from the origin search's high speed
0	The origin position is determined when the Origin Input Signal goes from OFF to ON.	Not used. The origin search operation ends after the origin is detected.	Not used.	The Origin Input Signal will be detected during deceleration. An Origin Input Signal Error (error code 0202) will occur and the motor will decelerate to a stop.
1		Goes ON for 20 to 30 ms when the origin is detected.	After the origin is detected, the origin search will not be end until the Positioning Completed Input is received from the driver.	The Origin Input Signal will not be detected during deceleration. When the Origin Input Signal is detected after the motor has reached the proximity speed for origin search, the motor will be stopped and the origin search operation will end.
2				

The following table shows the proper operating mode settings for different drivers and applications.

Driver	Remarks	Operating mode
Stepping motor driver (See note.)		0
Servo driver	Use this mode when you want to reduce the processing time, even at the expense of positioning accuracy. (The Servo Driver's positioning complete signal is not used.)	1
	Use this mode when you want high positioning accuracy. (The Servo Driver's positioning complete signal is used.)	2


Note There are stepping motor drivers that are equipped with a positioning completed signal like a Servo driver. Operating modes 1 and 2 can be used with these stepping motor drivers.

■ Remarks: Operations Detecting the Origin During Deceleration from High Speed

Operating Mode 0 (without Error Counter Reset Output, without Positioning Completed Input)


Connect the sensor's open collector output signal to the Origin Input Signal. The Origin Input Signal's response time is 0.1 ms when set as a NO contact.

When the Origin Proximity Input Signal is received, the motor will begin decelerating from the origin search high speed to the origin search proximity speed. In this operating mode, the Origin Input Signal will be detected if it is received during this deceleration and an Origin Input Signal Error (error code 0202) will be generated. In this case, the motor will decelerate to a stop.



Operating Mode 1 (with Error Counter Reset Output, without Positioning Completed Input)


Connect the phase-Z signal from the Servo Driver to the Origin Input Signal. When the Origin Input Signal is received, the pulse output will be stopped and the Error Counter Reset Signal will be output for about 20 to 30 ms.



When the Origin Proximity Input Signal is received, the motor will begin decelerating from the origin search high speed to the origin search proximity speed. In this operating mode, the motor will stop at the Origin Input Signal after deceleration is completed.


Operating Mode 1 with Origin Proximity Input Signal Reverse (Origin Detection Method Setting = 0)

When the deceleration time is short, the Origin Input Signal can be detected immediately after the Origin Proximity Input Signal goes from ON to OFF. Set a Origin Proximity Input Signal dog setting that is long enough (longer than the deceleration time.)



Operating Mode 1 without Origin Proximity Input Signal Reverse (Origin Detection Method Setting = 1)


Depending on the length of the deceleration time, the stopping position may change when the Origin Input Signal is detected during deceleration.



Operating Mode 2 (with Error Counter Reset Output, with Positioning Completed Input)

This operating mode is the same as mode 1, except the Positioning Completed Signal (INP) from the Servo Driver is used. Connect the Positioning Completed Signal from the Servo Driver to a normal input (origin search 0 to 3 input).

If origin compensation is not being applied, the Positioning Completed Signal is checked after the Error Counter Reset Output. If origin compensation is being applied, the Positioning Completed Signal is checked after the compensation operation is completed.



Origin Search Operation Setting

Select either of the following two reverse modes for the origin search operation pattern.


Setting	Description
0: Reversal mode 1	When the limit input signal is received in the origin search direction, reverse and continue operation.
1: Reversal mode 2	When the limit input signal is received in the origin search direction, generate an error and stop operation.

Origin Detection Method


The origin detection method depends on the Origin Proximity Input Signal settings. Select one of the following three methods in each port's parameters.

Setting	Description
0: Origin Proximity Input Signal reversal required.	Reads the first Origin Input Signal after the Origin Proximity Input Signal goes OFF→ON→OFF.
1: Origin Proximity Input Signal reversal not required.	Reads the first Origin Input Signal after the Origin Proximity Input Signal goes OFF→ON.
2: Origin Proximity Input Signal not used.	Just read the Origin Input Signal without using the Origin Proximity Input Signal.


Origin Detection Method 0: Origin Proximity Input Signal Reversal Required



Origin Detection Method 1: Origin Proximity Input Signal Reversal Not Required



Origin Detection Method 2: Origin Proximity Input Signal Reversal Not Used



Origin Search Operating Mode and Origin Detection Method Settings

The following examples explain how the operation patterns are affected by the origin search operation and origin detection method settings.

These examples have a CW origin search direction. (The search direction and limit input signal direction would be different for an origin search in the CCW direction.)

Using Reversal Mode 1

<div>Origin search operation</div> <div>Origin detection method</div>	0: Reversal mode 1
0: Origin Proximity Input Signal reversal required.	<p>Origin Proximity Input Signal</p> <p>Origin Input Signal</p> <p>Pulse output</p> <p>CCW</p> <p>CW</p> <p>Start</p> <p>Stop</p> <p>High speed for origin search</p> <p>Proximity speed for origin search</p> <p>Stop</p> <p>Start</p> <p>Stop</p> <p>Start</p> <p>CW limit input signal (See note.)</p> <p>Stop</p> <p>Start</p> <p>Stop</p> <p>Start</p> <p>Note When the limit input signal is received, the motor stops without deceleration, reverses direction, and accelerates.</p>
1: Origin Proximity Input Signal reversal not required.	<p>Origin Proximity Input Signal</p> <p>Origin Input Signal</p> <p>Pulse output</p> <p>CCW</p> <p>CW</p> <p>Start</p> <p>Stop</p> <p>Stop</p> <p>Start</p> <p>Stop</p> <p>Start</p> <p>CW limit input signal (See note.)</p> <p>Stop</p> <p>Start</p> <p>Stop</p> <p>Start</p> <p>Note When the limit input signal is received, the motor stops without deceleration, reverses direction, and accelerates.</p>
2: Origin Proximity Input Signal not used.	<p>Origin Input Signal</p> <p>Pulse output</p> <p>CCW</p> <p>CW</p> <p>Start</p> <p>Stop</p> <p>Stop</p> <p>Start</p> <p>Stop</p> <p>Start</p> <p>CW limit input signal (See note.)</p> <p>Stop</p> <p>Start</p> <p>Stop</p> <p>Start</p> <p>Note When the direction of operation is reversed, it is reversed immediately without deceleration or acceleration.</p>

Using Reversal Mode 2

<div>Origin search operation</div> <div>Origin detection method</div>	1: Reversal mode 2
0: Origin Proximity Input Signal reversal required.	<div data-bbox="456 346 1220 877"><p>Origin Proximity Input Signal</p><p>Origin Input Signal</p><p>Pulse output</p><p>CCW ← Start → CW</p><p>Stop</p><p>CCW ← Start → CW</p><p>Stop</p><p>CCW ← Start → CW</p><p>Stop</p><p>CW limit input signal (See note.)</p><p>Start Limit stop (error code 0200)</p></div> <p>Note When the limit input signal is received, the motor stops without deceleration.</p>

Origin search operation Origin detection method	1: Reversal mode 2
2: Origin Proximity Input Signal not used.	<p>Note When the limit input signal is received, the motor stops without deceleration.</p>

Specifying the Origin Search Direction (CW or CCW Direction)

Sets the direction to move when detecting the Origin Input Signal.

Typically, the origin search is performed so that the Origin Input Signal's rising edge is detected when moving in the origin search direction.

Setting	Description
0	CW direction
1	CCW direction

Origin Search Speed

These are the motor speed settings used in the origin search.

Note

The origin search will not be performed in these cases:
 Origin search high speed \leq Origin search proximity speed
 Origin search proximity speed \leq Origin search initial speed

Origin Search/Return Initial Speed

Sets the motor's starting speed when the origin search is executed. Specify the speed in the number of pulses per second (pps).

Origin Search High Speed

Sets the motor's target speed when the origin search is executed. Specify the speed in the number of pulses per second (pps).

Origin Search Proximity Speed

Sets the motor's speed after the Origin Proximity Input Signal is detected. Specify the speed in the number of pulses per second (pps).

Origin Search Acceleration Rate

Sets the motor's acceleration rate when the origin search is executed. Specify the amount to increase the speed (Hz) per 4-ms interval.

Origin Search Deceleration Rate

Sets the motor's acceleration rate when the origin search function is decelerating. Specify the amount to decrease the speed (Hz) per 4-ms interval.

Origin Compensation

After the origin has been determined, the origin compensation can be set to compensate for a shift in the Proximity Sensor's ON position, motor replacement, or other change.

Once the origin has been detected in an origin search, the number of pulses specified in the origin compensation is output, the current position is reset to 0, and the pulse output's No-origin Flag is turned OFF.

Setting range: 80000000 to 7FFFFFFF hex (–2,147,483,648 to 2,147,483,647) pulses

I/O Settings**Limit Input Signal Type (NC/NO)**

Specifies the type of input signal (normally closed or normally open) being used for the limit inputs.

0: NC

1: NO

Origin Proximity Input Signal Type (NC/NO)

Specifies the type of input signal (normally closed or normally open) being used for the Origin Proximity Input Signal.

0: NC

1: NO

Origin Input Signal Type (NC/NO)

Specifies the type of input signal (normally closed or normally open) being used for the Origin Input Signal.

0: NC

1: NO

Positioning Monitor Time

When the operating mode is set to mode 2, this setting specifies how long to wait (in ms) for the Positioning Completed Signal after the positioning operation has been completed, i.e., the pulse output has been completed. A Positioning Timeout Error (error code 0300) will be generated if the motor driver's Positioning Completed Signal does not come ON within the specified time.


Setting range: 0000 to 270F hex (0 to 9,999 ms)

The actual monitoring time will be the Positioning Monitor Time rounded up to the nearest 10-ms unit + 10 ms max.

If the Positioning Monitor Time is set to 0, the function will be disabled and the Unit will continue waiting for the Positioning Completed Signal to come ON. (A Positioning Timeout Error will not be generated.)

Executing an Origin Search

Execute ORG(889) in the ladder program to perform an origin search with the specified parameters.



Restrictions

The motor can be moved even if the origin position has not been determined with the origin search function, but positioning operations will be limited as follows:

Function	Operation
Origin return	Cannot be used.
Positioning with absolute pulse specification	Cannot be used.
Positioning with relative pulse specification	Outputs the specified number of pulses after setting the current position to 0.

An origin search will not be started unless the origin search proximity speed is less than the origin search high speed and unless the origin search/return initial speed is less than the origin search proximity speed.

Origin Search Error Processing

The CP1H CPU Unit's pulse output function performs a basic error check before starting to output pulses (when the instruction is executed) and will not output pulses if the settings are incorrect. There are other errors that can occur with the origin search function during pulse output, which may stop the pulse output.

If an error occurs that stops pulse output, the pulse output's Output Stopped Error Flag will be turned ON and the Pulse Output Stop Error Code will be written to Error Code word. Use these flags and error codes to identify the cause of the error.

The Pulse Output Stop Errors will not affect the CPU Unit's operating status. (The Pulse Output Stop Errors do not cause a fatal or non-fatal error in the CPU Unit.)

Related Auxiliary Area Flags

Function		Pulse output number			
		0	1	2	3
Output Stopped Error Flags ON when an error occurred while outputting pulses in the origin search function.	0: No error 1: Stop error occurred.	A280.07	A281.07	A326.07	A327.07
Stop Error Codes When a Pulse Output Stop Error occurs, the error code is stored in that pulse outputs corresponding Stop Error Code word.		A444	A445	A438	A439

Pulse Output Stop Error Codes

Error name	Error code	Likely cause	Corrective action	Operation after error
CW Limit Stop Input Signal	0100	Stopped due to a CW limit signal input.	Move in the CCW direction.	Immediate stop, No effect on other port
CCW Limit Stop Input Signal	0101	Stopped due to a CCW limit signal input.	Move in the CW direction.	
No Origin Proximity Input Signal	0200	The parameters indicate that the Origin Proximity Input Signal is being used, but a Origin Proximity Input Signal was not received during the origin search.	Check the wiring of the Origin Proximity Input Signal as well as the PLC Setup's Origin Proximity Input Signal Type setting (NC or NO) and execute the origin search again. Turn the power supply OFF and then ON if the signal type setting was changed.	No effect on other port
No Origin Input Signal	0201	The Origin Input Signal was not received during the origin search.	Check the wiring of the Origin Input Signal as well as the PLC Setup's Origin Input Signal Type setting (NC or NO) and execute the origin search again. Turn the power supply OFF and then ON if the signal type setting was changed.	
Origin Input Signal Error	0202	During an origin search in operating mode 0, the Origin Input Signal was received during the deceleration started after the Origin Proximity Input Signal was received.	Take one or both of the following steps so that the Origin Input Signal is received after deceleration is completed. <ul style="list-style-type: none"> •Increase the distance between the Origin Proximity Input Signal sensor and Origin Input Signal sensor. •Decrease the difference between the origin search's high speed and proximity speed settings. 	Decelerates to a stop, No effect on other port
Limit Inputs in Both Directions	0203	The origin search cannot be performed because the limit signals for both directions are being input simultaneously.	Check the wiring of the limit signals in both directions as well as the PLC Setup's Limit Signal Type setting (NC or NO) and execute the origin search again. Turn the power supply OFF and then ON if the signal type setting was changed.	Operation will not start. No effect on other port
Simultaneous Origin Proximity and Limit Inputs	0204	The Origin Proximity Input Signal and the Limit Input Signal in the search direction are being input simultaneously during an origin search.	Check the wiring of the Origin Proximity Input Signal and the Limit Input Signal. Also check the PLC Setup's Origin Proximity Input Signal Type and Limit Signal Type settings (NC or NO) and then execute the origin search again. Turn the power supply OFF and then ON if a signal type setting was changed.	Immediate stop, No effect on other port
Limit Input Signal Already Being Input	0205	<ul style="list-style-type: none"> •When an origin search in one direction is being performed, the Limit Input Signal is already being input in the origin search direction. •When a non-regional origin search is being performed, the Origin Input Signal and the Limit Input Signal in the opposite direction (from the search direction) are being input simultaneously. 	Check the wiring of the Limit Input Signal and the PLC Setup's I/O settings. Also check the PLC Setup's Limit Signal Type setting (NC or NO) and then execute the origin search again. Turn the power supply OFF and then ON if the signal type setting was changed.	Immediate stop, No effect on other port

Error name	Error code	Likely cause	Corrective action	Operation after error
Origin Proximity Input Signal Origin Reverse Error	0206	<ul style="list-style-type: none"> When an origin search with reversal at the limit is being performed, the Limit Input Signal in the search direction was input while the Origin Proximity Input Signal was reversing. When an origin search with reversal at the limit is being performed and the Origin Proximity Input Signal is not being used, the Limit Input Signal in the search direction was input while the Origin Input Signal was reversing. 	Check the installation positions of the Origin Proximity Input Signal, Origin Input Signal, and Limit Input Signal as well as the PLC Setup's I/O settings. Also check the PLC Setup's Signal Type settings (NC or NO) for each input signal and then execute the origin search again. Turn the power supply OFF and then ON if a signal type setting was changed.	Immediate stop, No effect on other port
Positioning Timeout Error	0300	The Servo Driver's Positioning Completed Signal does not come ON within the Positioning Monitor Time specified in the PLC Setup.	Adjust the Positioning Monitor Time setting or Servo system gain setting. Check the Positioning Completed Signal wiring, correct it if necessary, and then execute the origin search again.	Decelerates to a stop, No effect on other port

Origin Search Examples


Operation

Connect a Servo Driver and execute an origin search based on the Servomotor's built-in encoder phase-Z signal and a Origin Proximity Input Signal.

Conditions

- Operating mode: 1
(Uses the Servomotor encoder's phase-Z signal as the Origin Input Signal.)
- Origin search operation setting: 0
(Sets reverse mode 1. Reverses direction when the limit input signal is input in the origin search direction.)
- Origin detection method: 0
(Reads the Origin Input Signal after the Origin Input Signal goes OFF→ON→OFF.)
- Origin search direction: 0 (CW direction)

System Configuration



Instructions Used

ORG(889)


I/O Allocations
(Example: X/XA CPU
Units)■ **Inputs**

Input terminal		Name
Word	Bit	
CIO 0	00	Pulse Output 0 Origin Input Signal
	01	Pulse Output 0 Origin Proximity Input Signal
CIO 1	06	CW limit detection sensor
	07	CCW limit detection sensor

Word	Bit	Name
A540	08	Pulse Output 0 CW Limit Input Signal
	09	Pulse Output 0 CCW Limit Input Signal


■ **Outputs**

Output terminal		Name
Word	Bit	
CIO 100	00	Pulse Output 0 CW output
	01	Pulse Output 0 CCW output

Operation

PLC Setup

Function	Setting (example)
Pulse Output 0 Origin Search Function Enable/Disable	1 hex: Enabled
Pulse Output 0 Origin Search Operating Mode	1 hex: Mode 1
Pulse Output 0 Origin Search Operation Setting	0 hex: Reverse mode 1
Pulse Output 0 Origin Detection Method	0 hex: Origin detection method 0
Pulse Output 0 Origin Search Direction Setting	0 hex: CW direction
Pulse Output 0 Origin Search/Return Initial Speed	0064 hex (100 pps) 0000 hex
Pulse Output 0 Origin Search High Speed	07D0 hex (2,000 pps) 0000 hex
Pulse Output 0 Origin Search Proximity Speed	03E8 hex (1,000 pps) 0000 hex
Pulse Output 0 Origin Compensation	0000 hex 0000 hex
Pulse Output 0 Origin Search Acceleration Rate	0032 hex (50 Hz/4 ms)
Pulse Output 0 Origin Search Deceleration Rate	0032 hex (50 Hz/4 ms)
Pulse Output 0 Limit Input Signal Type	1: NO
Pulse Output 0 Origin Proximity Input Signal Type	1: NO
Pulse Output 0 Origin Input Signal Type	1: NO


Ladder Program

5-3-6 Origin Return


Overview

Moves the motor to the origin position from any other position. The origin return operation is controlled by ORG(889).

The origin return operation returns the motor to the origin by starting at the specified speed, accelerating to the target speed, moving at the target speed, and then decelerating to a stop at the origin position.



Procedure



PLC Setup

The various origin return parameters are set in the PLC Setup.

Origin Return Parameters

Name	Settings	Remarks
Origin search/return initial speed	X/XA CPU Units: Unit version 1.1 and later: • Pulse outputs 0 to 3: 00000000 to 000186A0 hex (0 Hz to 100 kHz) Unit version 1.0 and earlier: • Pulse outputs 0 and 1: 00000000 to 000186A0 hex (0 Hz to 100 kHz) • Pulse outputs 2 and 3: 00000000 to 00007530 hex (0 Hz to 30 kHz) Y CPU Units: • Pulse outputs 0 and 1: 00000000 to 000F4240 hex (0 Hz to 1 MHz) • Pulse outputs 2 and 3: 00000000 to 000186A0 hex (0 Hz to 100 kHz)	Start of operation
Origin return target speed	X/XA CPU Units: Unit version 1.1 and later: • Pulse outputs 0 to 3: 00000001 to 000186A0 hex (1 Hz to 100 kHz) Unit version 1.0 and earlier: • Pulse outputs 0 and 1: 00000001 to 000186A0 hex (1 Hz to 100 kHz) • Pulse outputs 2 and 3: 00000001 to 00007530 hex (1 Hz to 30 kHz) Y CPU Units: • Pulse outputs 0 and 1: 00000001 to 000F4240 hex (1 Hz to 1 MHz) • Pulse outputs 2 and 3: 00000001 to 000186A0 hex (1 Hz to 100 kHz)	Start of operation
Origin return acceleration rate	0001 to FFFF hex (1 to 65,535 Hz/4 ms)	
Origin return deceleration rate	0001 to FFFF hex (1 to 65,535 Hz/4 ms)	

Explanation of the Origin Return Parameters

Origin Search/Return Initial Speed

Sets the motor's starting speed when the origin return is executed. Specify the speed in the number of pulses per second (pps).

Origin Return Target Speed

Sets the motor's target speed when the origin return is executed. Specify the speed in the number of pulses per second (pps).

Origin Return Acceleration Rate

Sets the motor's acceleration rate when the origin return operation starts. Specify the amount to increase the speed (Hz) per 4-ms interval.

Origin Return Deceleration Rate

Sets the motor's acceleration rate when the origin return function is decelerating. Specify the amount to decrease the speed (Hz) per 4-ms interval.

Executing an Origin Return

ORG(889)	P: Port specifier (Pulse output 0: #0000, Pulse output 1: #0001)
P	Pulse output 0: #0000
	Pulse output 1: #0001
C	Pulse output 2: #0002
	Pulse output 3: #0003
	C: Control data
	(Origin return and CW/CCW method: #1000, Origin search and pulse + direction method: #1100)


Note An instruction execution error will occur if the origin is not determined (relative coordinate system) when ORG(889) is executed to perform an origin return operation.

5-3-7 Pulse Output Procedures

Single-phase Pulse Output without Acceleration/Deceleration


The number of output pulses setting cannot be changed during positioning.

■ PULS(886) and SPED(885)




Single-phase Pulse Output with Acceleration/Deceleration

■ PULS(886) and ACC(888)



Pulse Output with Trapezoidal Acceleration/Deceleration (Using PLS2(887))



5-3-8 Instructions used for Pulse Outputs

The pulse output functions can be used by executing the pulse control instructions in the ladder program. For some instructions, the PLC Setup must be set in advance. The following instructions can be combined for positioning and speed control.

Supported Pulse Instructions

Use the following 8 instructions to control the pulse outputs.

The following table shows the kinds of pulse outputs controlled by each instruction.

Instruction	Function	Positioning (independent mode)			Speed control (continuous mode)		Origin search
		Pulse output without acceleration/ deceleration	Pulse output with acceleration/ deceleration		Pulse output without acceleration/ deceleration	Pulse output with acceleration/ deceleration	
			Trapezoidal, equal acceleration/ deceleration rates	Trapezoidal, separate acceleration/ deceleration rates			
PULS(886) SET PULSES	Sets the number of pulses to be output.	Used	---	---	---	---	---
SPED(885) SPEED OUTPUT	Performs pulse output control without acceleration or deceleration. (When positioning, the number of pulses must be set in advance with PULS(886).)	Used	---	---	Used	---	---
ACC(888) ACCELERATION CONTROL	Performs pulse output control with acceleration and deceleration. (When positioning, the number of pulses must be set in advance with PULS(886).)	---	Used	---	---	Used	---
PLS2(887) PULSE OUTPUT	Performs pulse output control with independent acceleration and deceleration rates. (Also sets the number of pulses.)	---	---	Used	---	---	---
ORG(889) ORIGIN SEARCH	Actually moves the motor with pulse outputs and determines the machine origin based on the Origin Proximity Input and Origin Input signals	---	---	---	---	---	Used
INI(880) MODE CONTROL	Stops the pulse output. Changes the pulse output PV. (This operation determines the origin location.)	Used	Used	Used	Used	Used	---
PRV(881) HIGH-SPEED COUNTER PV READ	Reads the pulse output PV.	Used	Used	Used	Used	Used	---
PWM(891) PULSE WITH VARIABLE DUTY FACTOR	Performs pulse output control with variable duty factor pulse output.	---	---	---	---	---	---

SET PULSES: PULS(886)

PULS(886) is used to set the pulse output amount (number of output pulses) for pulse outputs that are started later in the program using SPED(885) or ACC(888) in independent mode.

PULS(886)	
P	P: Port specifier
T	T: Pulse type
N	N: Number of pulses

Operand		Contents
P	Port specifier	#0000: Pulse output 0 #0001: Pulse output 1 #0002: Pulse output 2 #0003: Pulse output 3
T	Pulse type	#0000: Relative pulse output #0001: Absolute pulse output
N	First number of pulses word	N and N+1 contain the number of pulses setting. (N contains the rightmost 4 digits and N+1 contains the leftmost 4 digits.) Relative pulse output: 00000000 to 7FFFFFFF hex (0 to 2,147,483,647) Absolute pulse output: 80000000 to 7FFFFFFF hex (-2,147,483,648 to 2,147,483,647)

SPEED OUTPUT: SPED(885)

SPED(885) can be used to perform pulse output without acceleration or deceleration. Either independent mode positioning or continuous mode speed control is possible. For independent mode positioning, the number of pulses is set using PULS(886).

SPED(885) can also be executed during pulse output to change the output frequency, creating stepwise changes in the speed.

SPED(885)	
P	P: Port specifier
T	T: Output mode
F	F: First pulse frequency word

Operand			Contents
P	Port specifier		#0000: Pulse output 0 #0001: Pulse output 1 #0002: Pulse output 2 #0003: Pulse output 3
T	Output mode	Bits 0 to 3	Mode 0 hex: Continuous 1 hex: Independent
		Bits 4 to 7	Direction 0 hex: CW 1 hex: CCW
		Bits 8 to 11	Pulse output method (See note.) 0 hex: CW/CCW 1 hex: Pulse + direction
		Bits 12 to 15	Not used. (Always 0 hex.)

Operand		Contents
F	First pulse frequency word	<p>F and F+1 contain the pulse frequency setting, in units of 1 Hz. (F contains the rightmost 4 digits and F+1 contains the leftmost 4 digits.)</p> <p>X/XA CPU Units:</p> <p>Unit version 1.1 and later:</p> <ul style="list-style-type: none"> Pulse outputs 0 to 3: 00000000 to 000186A0 hex (0 Hz to 100 kHz) <p>Unit version 1.0 and earlier:</p> <ul style="list-style-type: none"> Pulse outputs 0 and 1: 00000000 to 000186A0 hex (0 Hz to 100 kHz) Pulse outputs 2 and 3: 00000000 to 00007530 hex (0 Hz to 30 kHz) <p>Y CPU Units:</p> <ul style="list-style-type: none"> Pulse outputs 0 and 1: 00000000 to 000F4240 hex (0 Hz to 1 MHz) Pulse outputs 2 and 3: 00000000 to 000186A0 hex (0 Hz to 100 kHz)

ACCELERATION CONTROL: ACC(888)

Use ACC(888) to set the target frequency and acceleration and deceleration rate and output pulses with acceleration and deceleration. (Acceleration rate is the same as the deceleration rate.)

Either independent mode positioning or constant mode speed control is possible when used in combination with PULS(886). ACC(888) can also be executed during pulse output to change the target frequency or acceleration/deceleration rate, enabling smooth (sloped) speed changes.

ACC(888)	
P	P: Port specifier
M	M: Output mode
S	S: First word of settings tab

Operand			Contents
P	Port specifier		#0000: Pulse output 0 #0001: Pulse output 1 #0002: Pulse output 2 #0003: Pulse output 3
M	Output mode	Bits 0 to 3	Mode 0 hex: Continuous 1 hex: Independent
		Bits 4 to 7	Direction 0 hex: CW 1 hex: CCW
		Bits 8 to 11	Pulse output method (See note.) 0 hex: CW/CCW 1 hex: Pulse + direction
		Bits 12 to 15	Not used. (Always 0 hex.)

Operand			Contents
S	First settings table word	S	Acceleration/deceleration rate: 0001 to FFFF hex (1 to 65,535 Hz) Specify the increase or decrease in the frequency per pulse control period (4 ms).
		S+1 and S+2	S and S+1 contain the target frequency setting, in units of 1 Hz. (S+1 contains the rightmost 4 digits and S+2 contains the leftmost 4 digits.) X/XA CPU Units: Unit version 1.1 and later: <ul style="list-style-type: none"> Pulse outputs 0 to 3: 00000000 to 000186A0 hex (0 Hz to 100 kHz) Unit version 1.0 and earlier: <ul style="list-style-type: none"> Pulse outputs 0 and 1: 00000000 to 000186A0 hex (0 Hz to 100 kHz) Pulse outputs 2 and 3: 00000000 to 00007530 hex (0 Hz to 30 kHz) Y CPU Units: <ul style="list-style-type: none"> Pulse outputs 0 and 1: 00000000 to 000F4240 hex (0 Hz to 1 MHz) Pulse outputs 2 and 3: 00000000 to 0000186A0 hex (0 Hz to 100 kHz)

PULSE OUTPUT: PLS2(887)

Use PLS2(887) to set the startup frequency, acceleration rate, and deceleration rate, and output a specified number of pulses. Only independent mode positioning is supported.

PLS2(887) can also be executed during pulse output to change the number of output pulses, target frequency, acceleration rate, or deceleration rate.

PLS2(887)	
P	P: Port specifier
M	M: Output mode
S	S: First word of settings table
F	F: First word of starting frequency

Operand			Contents
P	Port specifier		#0000: Pulse output 0 #0001: Pulse output 1 #0002: Pulse output 2 #0003: Pulse output 3
M	Output mode	Bits 0 to 3	Mode #0000: Relative pulse output #0001: Absolute pulse output
		Bits 4 to 7	Direction 0 hex: CW 1 hex: CCW
		Bits 8 to 11	Pulse output method (See note.) 0 hex: CW/CCW 1 hex: Pulse + direction
		Bits 12 to 15	Not used. (Always 0 hex.)

Operand			Contents
S	First settings table word	S	Acceleration rate: 0001 to FFFF hex (1 to 65,535 Hz) Specify the increase or decrease in the frequency per pulse control period (4 ms).
		S+1	Deceleration rate: 0001 to FFFF hex (1 to 65,535 Hz) Specify the increase or decrease in the frequency per pulse control period (4 ms).
		S+2 and S+3	S+2 and S+3 contain the target frequency setting, in units of 1 Hz. (S+2 contains the rightmost 4 digits and S+3 contains the leftmost 4 digits.) X/XA CPU Units: Unit version 1.1 and later: <ul style="list-style-type: none"> • Pulse outputs 0 to 3: 00000001 to 000186A0 hex (0 Hz to 100 kHz) Unit version 1.0 and earlier: <ul style="list-style-type: none"> • Pulse outputs 0 and 1: 00000000 to 000186A0 hex (0 Hz to 100 kHz) • Pulse outputs 2 and 3: 00000000 to 00007530 hex (0 Hz to 30 kHz) Y CPU Units: <ul style="list-style-type: none"> • Pulse outputs 0 and 1: 00000000 to 000F4240 hex (0 Hz to 1 MHz) • Pulse outputs 2 and 3: 00000000 to 0000186A0 hex (0 Hz to 100 kHz)
		S+4 and S+5	S+4 and S+5 contain the number of pulses setting. (S+4 contains the rightmost 4 digits and S+5 contains the leftmost 4 digits.) Relative pulse output: 00000000 to 7FFFFFFF hex (0 to 2,147,483,647) Absolute pulse output: 80000000 to 7FFFFFFF hex (-2,147,483,648 to 2,147,483,647)
F	First starting frequency word		F and F+1 contain the starting frequency setting, in units of 1 Hz. (F contains the rightmost 4 digits and F+1 contains the leftmost 4 digits.) X/XA CPU Units: Unit version 1.1 and later: <ul style="list-style-type: none"> • Pulse outputs 0 to 3: 00000000 to 000186A0 hex (0 Hz to 100 kHz) Unit version 1.0 and earlier: <ul style="list-style-type: none"> • Pulse outputs 0 and 1: 00000000 to 000186A0 hex (0 Hz to 100 kHz) • Pulse outputs 2 and 3: 00000000 to 00007530 hex (0 Hz to 30 kHz) Y CPU Units: <ul style="list-style-type: none"> • Pulse outputs 0 and 1: 00000000 to 000F4240 hex (0 Hz to 1 MHz) • Pulse outputs 2 and 3: 00000000 to 000186A0 hex (0 Hz to 100 kHz)

**ORIGIN SEARCH:
ORG(889)**

ORG(889) performs an origin search or origin return operation. The required PLC Setup parameters must be set before performing an origin search or origin return operation.

Origin Search

Positions the system to the origin based on the origin proximity input and origin input signals.

Origin Return

Returns the system from its present position to the pre-established origin.

ORG(889)	
P	P: Port specifier
C	C: Control data

Operand			Contents
P	Port specifier		#0000: Pulse output 0 #0001: Pulse output 1 #0002: Pulse output 2 #0003: Pulse output 3
C	Control data	Bits 0 to 3	Not used. (Always 0 hex.)
		Bits 4 to 7	Not used. (Always 0 hex.)
		Bits 8 to 11	Pulse output method (See note.) 0 hex: CW/CCW 1 hex: Pulse + direction
		Bits 12 to 15	Mode 0 hex: Origin search 1 hex: Origin return

MODE CONTROL: INI(880)

In addition to the various interrupt and high-speed counter functions, INI(880) can be used to change the pulse output PV or stop the pulse output.

Note

This section explains the functions related to pulse outputs only. For details on the INI(880) instruction's high-speed counter or interrupt functions, refer to 5-1 *Interrupt Functions* or 5-2 *High-speed Counters*.

INI(880)	
P	P: Port specifier
C	C: Control data
NV	NV: First word of new PV

Operand			Contents
P	Port specifier		#0000: Pulse output 0 #0001: Pulse output 1 #0002: Pulse output 2 #0003: Pulse output 3 #1000: PWM output 0 #1001: PWM output 1
C	Control data		#0002: Change the PV. #0003: Stop pulse output.
NV	First word of new PV		NV and NV+1 contain the new PV when changing the PV. (N contains the rightmost 4 digits and N+1 contains the leftmost 4 digits.) 00000000 to FFFFFFFF hex

HIGH-SPEED COUNTER

PV READ: PRV(881)

In addition to its interrupt and high-speed counter functions, PRV(881) can be used to read the pulse output PV or pulse output status information.

The status of the following flags is read as status information:

- Pulse Output Status Flag
- PV Underflow/Overflow Flag
- Pulse Output Amount Set Flag
- Pulse Output Completed Flag
- Pulse Output Flag
- No-origin Flag
- At Origin Flag
- Pulse Output Stopped Error Flag

PRV(881)	
P	P: Port specifier
C	C: Control data
D	D: First destination word

Note This section explains the functions related to pulse outputs only. For details on the PRV(881) instruction's high-speed counter or interrupt functions, refer to *5-1 Interrupt Functions* or *5-2 High-speed Counters*.

Operand		Contents
P	Port specifier	#0000: Pulse output 0 #0001: Pulse output 1 #0002: Pulse output 2 #0003: Pulse output 3 #1000: PWM output 0 #1001: PWM output 1
C	Control data	#0000: Read the PV. #0001: Read the status. #0003: Read the pulse output frequency.

Operand			Contents	
D	First destination word	Reading PV (D and D+1)	After the pulse output PV is read, the 8-digit hexadecimal data is stored in D and D+1. (D contains the rightmost 4 digits and D+1 contains the leftmost 4 digits.)	
		Reading pulse output status (D)	Bit 0	Pulse Output Status Flag 0: Constant speed 1: Accelerating/decelerating
			Bit 1	PV Underflow/Overflow Flag 0: Normal 1: Error
			Bit 2	Pulse Output Amount Set Flag 0: Not set 1: Set
			Bit 3	Pulse Output Completed Flag 0: Output not completed 1: Output completed
			Bit 4	Pulse Output Flag 0: Stopped 1: Outputting pulses
			Bit 5	No-origin Flag 0: Origin established 1: Origin not established
			Bit 6	At Origin Flag 0: Not stopped at origin 1: Stopped at origin
			Bit 7	Pulse Output Stopped Error Flag 0: No error 1: Pulse output stopped due to error
			Bits 8 to 15	Not used.
		Reading PWM output status (D)	Bit 0	PWM Output Flag 0: Stopped 1: Outputting pulses
			Bits 1 to 15	Not used.

PULSE WITH VARIABLE DUTY FACTOR: PWM(891)

PWM(891) is used to output pulses with the specified duty factor.

PWM	
P	P: Port specifier
F	F: Frequency
D	D: Duty factor

Operand		Contents
P	Port specifier	#0000: Pulse output 0 (duty factor set in 1% units) #0001: Pulse output 1 (duty factor set in 1% units) #1000: Pulse output 0 (duty factor set in 0.1% units) #1001: Pulse output 1 (duty factor set in 0.1% units)
T	Frequency	0001 to FFFF hex (0.1 to 6553.5 Hz, in 0.1 Hz units)
S	Duty factor	Specify the duty factor of the pulse output, i.e., the percentage of time that the output is ON. 0000 to 03E8 hex (0.0% to 100.0%)

Combinations of Pulse Control Instructions

The following tables show when a second pulse control instruction can be started if a pulse control operation is already being executed.

Generally, a second independent-mode positioning instruction can be started if an independent-mode positioning instruction is being executed, and a second continuous-mode speed control instruction can be started if a continuous-mode speed control instruction is being executed. Operation cannot be switched between the independent and continuous modes, although PLS2(887) can be started while ACC(888) (continuous mode) is being executed.

It is possible to start another operation during acceleration/deceleration and start another positioning instruction during positioning.

Instruction being executed		Starting instruction (○: Can be executed., ×: Instruction Error occurs and Error Flag goes ON)						
		INI(880)	SPED(885) (Independent)	SPED(885) (Continuous)	ACC(888) (Independent)	ACC(888) (Continuous)	PLS2(887)	ORG(889)
SPED(885) (Independent)		○	○ (note 1)	×	○ (note 3)	×	×	×
SPED(885) (Continuous)		○	×	○ (note 2)	×	○ (note 5)	×	×
ACC(888) (Independent)	Steady speed	○	×	×	○ (note 4)	×	○ (note 6)	×
	Accelerating or decelerating	○	×	×	○ (note 4)	×	○ (note 6)	×
ACC(888) (Continuous)	Steady speed	○	×	×	×	○ (note 5)	○ (note 7)	×
	Accelerating or decelerating	○	×	×	×	○ (note 5)	○ (note 7)	×
PLS2(887)	Steady speed	○	×	×	○ (note 4)	×	○ (note 8)	×
	Accelerating or decelerating	○	×	×	○ (note 4)	×	○ (note 8)	×
ORG(889)	Steady speed	○	×	×	×	×	×	×
	Accelerating or decelerating	○	×	×	×	×	×	×

Note

(1) SPED(885) (Independent) to SPED(885) (Independent)

- The number of pulses cannot be changed.
- The frequency can be changed.
- The output mode and direction cannot be switched.

(2) SPED(885) (Continuous) to SPED(885) (Continuous)

- The frequency can be changed.
- The output mode and direction cannot be switched.

(3) SPED(885) (Independent) to ACC(888) (Independent)

- The number of pulses cannot be changed.
- The frequency can be changed.
- The acceleration/deceleration rate can be changed.
- The output mode and direction cannot be switched.

(4) ACC(888) (Independent) to ACC(888) (Independent)
or PLS2(887) to ACC(888) (Independent)

- The number of pulses cannot be changed.
- The frequency can be changed.
- The acceleration/deceleration rate can be changed. (The rate can even be changed during acceleration or deceleration.)
- The output mode and direction cannot be switched.

(5) SPED(885) (Continuous) to ACC(888) (Continuous)
or ACC(888) (Continuous) to ACC(888) (Continuous)

- The frequency can be changed. (The target frequency can even be changed during acceleration or deceleration.)
- The acceleration/deceleration rate can be changed. (The rate can even be changed during acceleration or deceleration.)
- The output mode and direction cannot be switched.

(6) ACC(888) (Independent) to PLS2(887)

- The number of pulses can be changed. (The setting can even be changed during acceleration or deceleration.)
- The frequency can be changed. (The target frequency can even be changed during acceleration or deceleration.)
- The acceleration/deceleration rate can be changed. (The rate can even be changed during acceleration or deceleration.)
- The output mode and direction cannot be switched.

(7) ACC(888) (Continuous) to PLS2(887)

- The frequency can be changed. (The target frequency can even be changed during acceleration or deceleration.)
- The acceleration/deceleration rate can be changed. (The rate can even be changed during acceleration or deceleration.)
- The output mode and direction cannot be switched.

(8) PLS2(887) to PLS2(887)

- The number of pulses can be changed. (The setting can even be changed during acceleration or deceleration.)
- The frequency can be changed. (The target frequency can even be changed during acceleration or deceleration.)
- The acceleration/deceleration rate can be changed. (The rate can even be changed during acceleration or deceleration.)
- The output mode and direction cannot be switched.

5-3-9 Variable Duty Factor Pulse Outputs (PWM(891) Outputs)

Overview


PWM (Pulse Width Modulation) pulse outputs can be output with a specified duty factor. The duty factor is the ratio of the pulse's ON time and OFF time in one pulse cycle. Use the PWM(891) instruction to generate variable duty factor pulses from a built-in output.

The duty factor can be changed while pulses are being output.

Bit Allocations

Word	Bit	Function
CIO 101	00	PWM output 0
	01	PWM output 1

Procedure



Restrictions on the PWM(891) Outputs

- In the Y CPU Units, PWM outputs 0 and 1 cannot be used for pulse outputs 2 and 3 if the origin search function is enabled for pulse outputs 2 and 3.

Specifications

Item	Specifications
Duty factor	0.0% to 100.0% in 0.1% increments (Duty factor accuracy is $\pm 5\%$ at 1 kHz.)
Frequency	0.1 Hz to 6,553.5 Hz Set in 0.1 Hz units. (See note.)
Output mode	Continuous mode
Instruction	PWM(891)


Note The frequency can be set up to 6553.5 Hz in the PWM(891) instruction, but the duty factor accuracy declines significantly at high frequencies because of limitations in the output circuit at high frequencies.

5-3-10 Example Pulse Output Applications

Outputting Pulses after a Preset Delay

This example program waits for a preset time (0.5 ms) after the interrupt input (CIO 0.00) goes ON and then outputs 100,000 pulses at 100 kHz from pulse output 0.

Input interrupt task 0 (interrupt task number 140) starts a scheduled interrupt with a scheduled time of 0.5 ms. The scheduled interrupt task executes the pulse output instructions and stops the scheduled interrupt.



- Instructions Used
- MSKS(690)

Enables the I/O interrupt. Starts the scheduled interrupt.
- PULS(886)

Sets the number of output pulses.
- SPED(885)


Starts the pulse output.

Preparation

■ PLC Setup


Built-in Input Settings

PLC Setup setting details
Use built-in input 0.00 as the interrupt input.




Pulse Output 0 Settings

PLC Setup setting details
Do not use high-speed counter 0.
Do not use the pulse output 0 origin search function.




Scheduled Interrupt Time Unit Setting

PLC Setup setting details	Data
Set the scheduled interrupt time units to 0.1 ms.	0002 hex




Ladder Program

Cyclic Task (Task 0)




Built-in Input 0 Interrupt Task (Interrupt Task 140)



* Select 0.1 ms for the setting units in the PLC Setup.


Scheduled Interrupt Task 0 (Interrupt Task 2)



Positioning (Trapezoidal Control)

Specifications and Operation

When the start input (1.04) goes ON, this example program outputs 600,000 pulses from pulse output 0 and turns the motor.



Instructions Used

PLS2(887)

Preparation

■ PLC Setup


There are no settings that need to be made in the PLC Setup.

DM Area Settings

PLS2(887) Settings (D00000 to D00007)

Setting details	Address	Data
Acceleration rate: 300 Hz/4 ms	D0	#012C
Deceleration rate: 200 Hz/4 ms	D1	#00C8
Target frequency: 50,000 Hz	D2	#C350
	D3	#0000
Number of output pulses: 600,000 pulses	D4	#27C0
	D5	#0009
Starting frequency: 100 Hz	D6	#0064
	D7	#0000

Ladder Program




Remarks

- Absolute pulses can be specified when the origin position has been determined.
- If a target frequency that cannot be reached has been set, the target frequency will be reduced automatically, i.e., triangular control will be performed. In some cases where the acceleration rate is substantially greater than the deceleration rate, the operation won't be true triangular control. The motor will be operated at a constant speed for a short time between the acceleration and deceleration.


Jog Operation

Specifications and Operation

- Low-speed jog operation (CW) will be executed from pulse output 1 while input 1.04 is ON.
- Low-speed jog operation (CCW) will be executed from pulse output 1 while input 1.05 is ON.



- High-speed job operation (CW) will be executed from pulse output 1 while input 1.06 is ON.
- High-speed jog operation (CCW) will be executed from pulse output 1 while input 1.07 is ON.



Instructions Used

- SPED(885) Starts and stops (immediate stop) the low-speed jog operations.
- ACC(888) Starts and stops (decelerate to a stop) the high-speed jog operations.

Preparation

■ PLC Setup


There are no settings that need to be made in the PLC Setup.


DM Area Settings

**Settings to Control Speed while Jogging
(D0 to D1 and D10 to D15)**

Setting details	Address	Data
Target frequency (low speed): 1,000 Hz	D0	#03E8
	D1	#0000
Acceleration rate: 100 Hz/4 ms	D10	#0064
Target frequency (high speed): 100,000 Hz	D011	#86A0
	D12	#0001
Deceleration rate: 100 Hz/4 ms (Not used.)	D13	#0064
Target frequency (stop): 0 Hz	D14	#0000
	D15	#0000

Ladder Program





Remarks


PLS2(887) can be used to set a starting frequency or unequal acceleration and deceleration rates, but there are limitations on the operating range because the end point must be specified in PLS2(887).

Cutting Long Material Using Fixed Feeding


Specifications and Operation

■ Outline

In this example, first jogging is used to position the material and then fixed-distance positioning is used to feed the material.



■ System Configuration



■ Operation

- 1,2,3...**
1. The workpiece is set at the starting position using the Jogging Switch Input (IN 1.04).
 2. The workpiece is feed the specified distance (relative) using the Positioning Switch Input (IN 1.05).
 3. When feeding has been completed, the cutter is activated using the Cutter Start Output (OUT 101.00).
 4. Feeding is started again when the Cutter Finished Input (IN 1.06) turns ON.
 5. The feeding/cutting operation is repeated for the number of times specified for the counter (C0, 100 times).
 6. When the operation has been completed, the Cutting Operation Finished Output (OUT 101.01). is turned ON.

The feeding operation can be canceled and operation stopped at any point using the Emergency Switch Input (IN 1.07).

Instructions Used SPED(885)
 PLS2(887)

Preparation

■ PLC Setup

There are no settings that need to be made in the PLC Setup.

■ DM Area Settings


Speed Settings for Jogging (D0 to D3)

Setting details	Address	Data
Target frequency: 1,000 Hz	D0	#03E8
	D1	#0000
Target frequency: 0 Hz	D2	#0000
	D3	#0000

Settings for PLS2(887) for Fixed-distance Feeding (D10 to D20)

Setting details	Address	Data
Acceleration rate: 1,000 Hz/4 ms	D10	#03E8
Deceleration rate: 1,000 Hz/4 ms	D11	#03E8
Target frequency: 10,000 Hz	D12	#2710
	D13	#0000
Number of output pulses: 50,000 pulses	D14	#C350
	D15	#0000
Starting frequency: 0000 Hz	D16	#0000
	D17	#0000
Counter setting: 100 times	D20	#0100

Ladder Program




Remarks

- 1,2,3...**
1. PLS22(887) used a relative pulse setting. This enables operation even if the origin is not defined. The present position in A276 (lower 4 digits) and A277 (upper 4 digits) is set to 0 before pulse output and then contains the specified number of pulses.
 2. ACC(888) can be used instead of SPED(885) for the jog operation. If ACC(888) is used, acceleration/deceleration can be included in the jog operation.


Vertically Conveying PCBs (Multiple Progressive Positioning)**Specifications and Operation****■ Outline**

- 1,2,3...**
1. PCBs with components mounted are stored in a stocker.
 2. When a stocker becomes full, it is moved to the conveyance point.


Positioning Operation for Vertical Conveyor

■ Operation Pattern

- 1,2,3...
1. An origin search is performed.
 2. Fixed-distance positioning is repeated.
 3. The system is returned to the original position.




Wiring Example Using SmartStep A-series Servo Driver



CP1H CPU Unit

SMARTSTEP A-series Servo Driver



Operation

- 1,2,3...**
1. An origin search is performed using the Origin Search Switch (CIO 0.02).
 2. When the origin search is finished, the PCB Storage Enabled Output (CIO 100.03) is turned ON.
 3. When a PCB has been stored, the stocker is raised (relative positioning) using the PCB Storage Completed Input (CIO 0.03).
 4. Storing PCBs is repeated until the stocker is full.
 5. The number of PCBs in the stocker is counted with counter C0 by counting the number of times the stocker is raised.
 6. When the stocker is full, it is moved (CIO 1.01) and only the conveyor is lowered (absolute positioning) when stoker movement is completed (CIO 0.03).


The operation can be canceled and pulse output stopped at any point using the Emergency Switch Input (CIO 0.05).

Preparation

■ PLC Setup

Setting details
Enable origin search function for pulse output 0.

Note The origin search enable setting is read when the power supply is turned ON.



DM Area Settings

Settings for PLS2(887) for Fixed-distance Positioning (D0 to D7)


Setting details	Address	Data
Acceleration rate: 1,000 Hz/4 ms	D0	#03E8
Deceleration rate: 1,000 Hz/4 ms	D1	#03E8
Target frequency: 50,000 Hz	D2	#C350
	D3	#0000
Number of output pulses: 10,000 pulses	D4	#2710
	D5	#0000
Starting frequency: 0 Hz	D6	#0000
	D7	#0000


Settings for PLS2(887) to Return to Start (D10 to D17)

Setting details	Address	Data
Acceleration rate: 300 Hz/4 ms	D10	#012C
Deceleration rate: 200 Hz/4 ms	D11	#00C8
Target frequency: 50,000 Hz	D12	#C350
	D13	#0000
Number of output pulses: 10,000 × 15 pulses	D14	#49F0
	D15	#0002
Starting frequency: 100 Hz	D16	#0000
	D17	#0000

Number of Repeats of Fixed-distance Positioning Operation (D20)

Setting details	Address	Data
Number of repeats of fixed-distance positioning operation (number of PCBs in stocker)	D20	#0015


Ladder Program



Palletize: Two-axis Multipoint Positioning


Specifications and Operation

■ Outline




■ Operation Pattern

- 1,2,3...
1. An origin search is performed.
 2. A workpiece is grasped and moved to position A.
 3. The workpiece is grasped at one position and moved back and forth to several assembly positions.




Note The X and Y axes are moved independently, i.e., interpolation is not performed.


Wiring Example Using SmartStep A-series Servo Driver, XW2Z Cables, and XW2B I/O Terminal



X Axis



Y Axis



Operation


- 1,2,3...**
1. An origin search is performed using the Origin Search Switch (CIO 0.04).
 2. When the origin search is finished, the following operations are performed continuously.
Move to A.
Move to B and return to A.
Move to C and return to A.
Move to D and return to A.
 3. An emergency stop can be performed using the Emergency Stop Input (CIO 0.05)


Preparation

■ PLC Setup

Setting details
Enable origin search function for pulse output 0.

Note The origin search enable setting is read when the power supply is turned ON.





■ DM Area Settings

Starting Frequency

Setting details	Address	Data
X-axis starting frequency	D0	#0000
Y-axis starting frequency	D2	#0000

PLS2(887) Settings to Move from Origin to Position A

Setting details		Address	Data
X axis	Acceleration rate: 2,000 Hz/4 ms	D10	#07D0
	Deceleration rate: 2,000 Hz/4 ms	D11	#07D0
	Target frequency: 100,000 Hz	D12	#86A0
		D13	#0001
	Number of output pulses: 5,000 pulses	D14	#1388
		D15	#0000
Y axis	Acceleration rate: 2,000 Hz/4 ms	D20	#07D0
	Deceleration rate: 2,000 Hz/4 ms	D21	#07D0
	Target frequency: 100,000 Hz	D22	#86A0
		D23	#0001
	Number of output pulses: 5,000 pulses	D24	#1388
		D25	#0000

PLS2(887) Settings to Move from Position A to Position B

Setting details		Address	Data
X axis	Acceleration rate: 2,000 Hz/4 ms	D30	#07D0
	Deceleration rate: 2,000 Hz/4 ms	D31	#07D0
	Target frequency: 100,000 Hz	D32	#86A0
		D33	#0001
	Number of output pulses: 25,000 pulses	D34	#61A8
		D35	#0000


Setting details		Address	Data
Y axis	Acceleration rate: 2,000 Hz/4 ms	D40	#07D0
	Deceleration rate: 2,000 Hz/4 ms	D41	#07D0
	Target frequency: 100,000 Hz	D42	#86A0
		D43	#0001
	Number of output pulses: 50,000 pulses	D44	#C350
		D45	#0000


PLS2(887) Settings to Move from Position A to Position C


Setting details		Address	Data
X axis	Acceleration rate: 2,000 Hz/4 ms	D50	#07D0
	Deceleration rate: 2,000 Hz/4 ms	D51	#07D0
	Target frequency: 100,000 Hz	D52	#86A0
		D53	#0001
	Number of output pulses: 35,000 pulses	D54	#88B8
		D55	#0000
Y axis	Acceleration rate: 2,000 Hz/4 ms	D60	#07D0
	Deceleration rate: 2,000 Hz/4 ms	D61	#07D0
	Target frequency: 100,000 Hz	D62	#86A0
		D63	#0001
	Number of output pulses: 50,000 pulses	D64	#C350
		D65	#0000


PLS2(887) Settings to Move from Position A to Position D


Setting details		Address	Data
X axis	Acceleration rate: 2,000 Hz/4 ms	D70	#07D0
	Deceleration rate: 2,000 Hz/4 ms	D71	#07D0
	Target frequency: 100,000 Hz	D72	#86A0
		D73	#0001
	Number of output pulses: 25,000 pulses	D74	#61A8
		D75	#0000
Y axis	Acceleration rate: 2,000 Hz/4 ms	D80	#07D0
	Deceleration rate: 2,000 Hz/4 ms	D81	#07D0
	Target frequency: 100,000 Hz	D82	#86A0
		D83	#0001
	Number of output pulses: 30,000 pulses	D84	#7530
		D85	#0000

Ladder Program










Feeding Wrapping Material: Interrupt Feeding


Specifications and Operation

Feeding Wrapping Material in a Vertical Pillow Wrapper



■ Operation Pattern

Speed control is used to feed wrapping material to the initial position. When the marker sensor input is received, fixed-distance positioning is performed before stopping.



■ Operation


- 1,2,3... 1. Speed control is used to feed wrapping material to the initial position when the Start Switch (CIO 1.04) is activated.
2. When the Marker Sensor Input (IN0) is received, PLS2(887) is executed in interrupt task 140.
3. Fixed-distance positioning is executed with PLS2(887) before stopping.

Preparation

■ PLC Setup

Setting details
Enable using built-in input IN0 as an interrupt input.

Note The interrupt input setting is read when the power supply is turned ON.



■ DM Area Settings

Speed Control Settings to Feed Wrapping Material to Initial Position


Setting details	Address	Data
Acceleration rate: 1,000 Hz/4 ms	D0	#03E8
Target frequency: 10,000 Hz	D1	#2710
	D2	#0000

Positioning Control Settings for Wrapping Material


Setting details	Address	Data
Acceleration rate: 500 Hz/4 ms	D10	#01F4
Deceleration rate: 500 Hz/4 ms	D11	#01F4
Target frequency: 10,000 Hz	D12	#2710
	D13	#0000
Number of output pulses: 5,000 pulses	D14	#1388
	D15	#0000
Starting frequency: 0 Hz	D16	#0000
	D17	#0000

Ladder Program

Cyclic Task Program
(Executed at Startup)



Program for Interrupt Task
140



5-4 Quick-response Inputs


Overview

The quick-response inputs can read pulses with an ON time shorter than the cycle time (as short as 30 μ s). Use the quick-response inputs to read signals shorter than the cycle time, such as inputs from photomicrosensors.

Up to 8 quick-response inputs can be used in the X/XA CPU Units and up to 6 quick-response inputs can be used in the Y CPU Units.

PLC Setup

Use the CX-Programmer to set a built-in input as a quick-response input in the PLC Setup. Click the Built-in Input Tab to display the *Interrupt Input* settings (at the bottom of the tab). Set the input function from *Normal* to *Quick* for each input that will be used as a quick-response input.




Bit Allocation for Quick-Response Inputs

X/XA CPU Units

The following diagrams show the input bits and terminals that can be used for quick-response inputs in each CPU Unit.

The 8 input bits CIO 0.00 to CIO 0.03 and CIO 1.00 to CIO 1.03 can be used as quick-response inputs.


Terminal Arrangement**Setting the Input Functions in the PLC Setup**

Normally, bits CIO 0.00 to CIO 0.03 and CIO 1.00 to CIO 1.03 are used as normal inputs. When using these inputs as quick-response inputs, use the CX-Programmer to change the input's setting in the PLC Setup.

Input terminal block		Input operation setting		
Word	Bit	Normal inputs	Input interrupt	Quick-response inputs
CIO 0	00	Normal input 0	Input interrupt 0	Quick-response input 0
	01	Normal input 1	Input interrupt 1	Quick-response input 1
	02	Normal input 2	Input interrupt 2	Quick-response input 2
	03	Normal input 3	Input interrupt 3	Quick-response input 3
	04 to 11	Normal inputs 4 to 11	---	---
CIO 1	00	Normal input 12	Input interrupt 4	Quick-response input 4
	01	Normal input 13	Input interrupt 5	Quick-response input 5
	02	Normal input 14	Input interrupt 6	Quick-response input 6
	03	Normal input 15	Input interrupt 7	Quick-response input 7
	04 to 11	Normal inputs 16 to 23	---	---

Y CPU Units

The 6 input bits CIO 0.00 to CIO 0.01 and CIO 1.00 to CIO 1.03 can be used as quick-response inputs.

Input Terminal Arrangement


Setting the Input Functions in the PLC Setup

Normally, bits CIO 0.00 to CIO 0.01 and CIO 1.00 to CIO 1.03 are used as normal inputs. When using these inputs for input interrupts, use the CX-Programmer to change the input's setting in the PLC Setup.

Input terminal block		Input operation setting		
Word	Bit	Normal inputs	Input interrupt	Quick-response inputs
CIO 0	00	Normal input 0	Input interrupt 0	Quick-response input 0
	01	Normal input 1	Input interrupt 1	Quick-response input 1
	04, 05, 10 and 11	Normal inputs 2 to 5	---	---
CIO 1	00	Normal input 6	Input interrupt 2	Quick-response input 2
	01	Normal input 7	Input interrupt 3	Quick-response input 3
	02	Normal input 8	Input interrupt 4	Quick-response input 4
	03	Normal input 9	Input interrupt 5	Quick-response input 5
	04 and 05	Normal inputs 10 and 11	---	---

Interrupt Input and Quick-response Input Specifications


Item	Specification
ON delay	30 μ s max.
OFF delay	150 μ s max.
Response pulse	

Procedure**Restrictions**

Inputs cannot be used as quick-response inputs when they are being used as general-purpose (normal) inputs, input interrupts, or high-speed counter inputs.

5-5 Analog I/O (XA CPU Units)

The XA CPU Units of the CP1H CPU Units are equipped with 4 built-in analog inputs and 2 built-in analog outputs.



I/O Specifications

Analog Input Specifications

Item		Voltage input	Current input
Number of inputs		4 inputs (Allocated 4 words: CIO 200 to CIO 203.)	
Switchable voltage/current input		The 4 inputs can be set independently with the Analog Voltage/Current Input Switches.	
Input signal range		0 to 5 V, 1 to 5 V, 0 to 10 V, or -10 to 10 V (Set in PLC Setup.)	0 to 20 mA or 4 to 20 mA (Set in PLC Setup.)
Max. rated input		±15 V	±30 mA
External input impedance		1 MΩ min.	Approx. 250 Ω
Resolution		1/6000 or 1/12000 (Select in PLC Setup.)	
Overall accuracy	At 25°C	±0.3% full scale	±0.4% full scale
	0 to 55°C	±0.6% full scale	±0.8% full scale
A/D conversion data	-10 to 10 V	Resolution of 1/6000: F448 to 0BB8 hex FS Resolution of 1/12000: E890 to 1770 hex FS	
	Other ranges	Resolution of 1/6000: 0000 to 1770 hex FS Resolution of 1/12000: 0000 to 2EE0 hex FS	
Averaging function		Supported (Set for individual inputs in the PLC Setup.)	
Open-circuit detection function		Supported (Value when disconnected: 8000 hex)	

Analog Output Specifications

Item		Voltage output	Current output
Number of outputs		2 outputs (Allocated 2 words: CIO 210 to CIO 211.)	
Output signal range		0 to 5 V, 1 to 5 V, 0 to 10 V, or -10 to 10 V	0 to 20 mA or 4 to 20 mA
Max. rated input		±15 V	±30 mA
Allowable external output load resistance		1 kΩ min.	600 Ω max.
External input impedance		0.5 Ω max.	---

Item		Voltage output	Current output
Resolution		1/6000 or 1/12000 (Select in PLC Setup.)	
Overall accuracy	At 25°C	±0.4% full scale	
	0 to 55°C	±0.8% full scale	
D/A conversion data	–10 to 10 V	Resolution of 1/6000: F448 to 0BB8 hex FS Resolution of 1/12000: E890 to 1770 hex FS	
	Other ranges	Resolution of 1/6000: 0000 to 1770 hex FS Resolution of 1/12000: 0000 to 2EE0 hex FS	

Shared I/O Specifications

Item	Specification
Conversion time	1 ms/point (6 ms total for 4 analog inputs and 2 analog outputs.)
Insulation resistance	20 MΩ min. (at 250 VDC) between isolated circuits
Isolation method	Photocoupler isolation between analog I/O terminals and internal circuits. No isolation between analog I/O signals.
Dielectric strength	500 VAC for 1 minute

Analog I/O Signal Ranges

Analog I/O data is digitally converted according to the analog I/O signal range as shown below.

Note When the input exceeds the specified range, the AD converted data will be fixed at either the lower limit or upper limit.

Analog Input Signal Ranges


–10 to 10 V Input

When the resolution is set to 1/6,000, the –10 to 10-V range corresponds to hexadecimal values F448 to 0BB8 (–3,000 to 3,000). The entire data range is F31C to 0CE4 (–3,300 to 3,300).

When the resolution is set to 1/12,000, the –10 to 10-V range corresponds to hexadecimal values E890 to 1770 (–6,000 to 6,000). The entire data range is E638 to 19C8 (–6,600 to 6,600).

A negative voltage is expressed as a two's complement.

The following diagram shows conversion values for 1/6,000 resolution.




0 to 10 V Input

When the resolution is set to 1/6,000, the 0 to 10-V range corresponds to hexadecimal values 0000 to 1770 (0 to 6,000). The entire data range is FED4 to 189C (–300 to 6,300).

When the resolution is set to 1/12,000, the 0 to 10-V range corresponds to hexadecimal values 0000 to 2EE0 (0 to 12,000). The entire data range is FDA8 to 3138 (–600 to 12,600).

A negative voltage is expressed as a two's complement.

The following diagram shows conversion values for 1/6,000 resolution.




0 to 5 V Input

When the resolution is set to 1/6,000, the 0 to 5-V range corresponds to hexadecimal values 0000 to 1770 (0 to 6,000). The entire data range is FED4 to 189C (–300 to 6,300).

When the resolution is set to 1/12,000, the 0 to 5-V range corresponds to hexadecimal values 0000 to 2EE0 (0 to 12,000). The entire data range is FDA8 to 3138 (–600 to 12,600).

A negative voltage is expressed as a two's complement.

The following diagram shows conversion values for 1/6,000 resolution.




1 to 5 V Input

When the resolution is set to 1/6,000, the 1 to 5-V range corresponds to hexadecimal values 0000 to 1770 (0 to 6,000). The entire data range is FED4 to 189C (–300 to 6,300).

When the resolution is set to 1/12,000, the 1 to 5-V range corresponds to hexadecimal values 0000 to 2EE0 (0 to 12,000). The entire data range is FDA8 to 3138 (–600 to 12,600).

Inputs between 0.8 and 1 V are expressed as two's complements. If the input falls below 0.8 V, open-circuit detection will activate and converted data will be 8000.

The following diagram shows conversion values for 1/6,000 resolution.




0 to 20 mA Inputs

When the resolution is set to 1/6,000, the 0 to 20-mA range corresponds to hexadecimal values 0000 to 1770 (0 to 6,000). The entire data range is FED4 to 189C (–300 to 6,300).

When the resolution is set to 1/12,000, the 0 to 20-mA range corresponds to hexadecimal values 0000 to 2EE0 (0 to 12,000). The entire data range is FDA8 to 3138 (–600 to 12,600).

A negative voltage is expressed as a two's complement.

The following diagram shows conversion values for 1/6,000 resolution.




4 to 20 mA

When the resolution is set to 1/6,000, the 4- to 20-mA range corresponds to hexadecimal values 0000 to 1770 (0 to 6,000). The entire data range is FED4 to 189C (–300 to 6,300).

When the resolution is set to 1/12,000, the 4- to 20-mA range corresponds to hexadecimal values 0000 to 2EE0 (0 to 12,000). The entire data range is FDA8 to 3138 (–600 to 12,600).

Inputs between 3.2 and 4 mA are expressed as two's complements. If the input falls below 3.2 mA, open-circuit detection will activate and converted data will be 8000.

The following diagram shows conversion values for 1/6,000 resolution.



Analog Output Signal Ranges


-10 to 10 V Outputs

When the resolution is set to 1/6,000, the hexadecimal values F448 to 0BB8 (-3,000 to 3,000) correspond to an analog voltage range of -10 to 10 V.

When the resolution is set to 1/12,000, the hexadecimal values E890 to 1770 (-6,000 to 6,000) correspond to an analog voltage range of -10 to 10 V. The entire output range is -11 to 11 V.

Specify a negative voltage as a two's complement.

The following diagram shows conversion values for 1/6,000 resolution.




0 to 10 V Outputs

When the resolution is set to 1/6,000, the hexadecimal values 0000 to 1770 (0 to 6,000) correspond to an analog voltage range of 0 to 10 V.

When the resolution is set to 1/12,000, the hexadecimal values 0000 to 2EE0 (0 to 12,000) correspond to an analog voltage range of 0 to 10 V. The entire output range is -0.5 to 10.5 V.

Specify a negative voltage as a two's complement.

The following diagram shows conversion values for 1/6,000 resolution.




0 to 5 V Outputs

When the resolution is set to 1/6,000, the hexadecimal values 0000 to 1770 (0 to 6,000) correspond to an analog voltage range of 0 to 5 V.

When the resolution is set to 1/12,000, the hexadecimal values 0000 to 2EE0 (0 to 12,000) correspond to an analog voltage range of 0 to 5 V. The entire output range is -0.25 to 5.25 V.

Specify a negative voltage as a two's complement.


The following diagram shows conversion values for 1/6,000 resolution.

**1 to 5 V Outputs**

When the resolution is set to 1/6,000, the hexadecimal values 0000 to 1770 (0 to 6,000) correspond to an analog voltage range of 1 to 5 V.

When the resolution is set to 1/12,000, the hexadecimal values 0000 to 2EE0 (0 to 12,000) correspond to an analog voltage range of 0 to 5 V. The entire output range is 0.8 to 5.2 V.


The following diagram shows conversion values for 1/6,000 resolution.

**0 to 20 mA Outputs**

When the resolution is set to 1/6,000, the hexadecimal values 0000 to 1770 (0 to 6,000) correspond to an analog current range of 0 to 20 mA.

When the resolution is set to 1/12,000, the hexadecimal values 0000 to 2EE0 (0 to 12,000) correspond to an analog current range of 0 to 20 mA. The entire output range is 0 to 21 mA.

The following diagram shows conversion values for 1/6,000 resolution.




4 to 20 mA Outputs

When the resolution is set to 1/6,000, the hexadecimal values 0000 to 1770 (0 to 6,000) correspond to an analog current range of 4 to 20 mA.

When the resolution is set to 1/12,000, the hexadecimal values 0000 to 2EE0 (0 to 12,000) correspond to an analog current range of 4 to 20 mA. The entire output range is 3.2 to 20.8 mA.

The following diagram shows conversion values for 1/6,000 resolution.

**Averaging Function for Analog Inputs**

The averaging function stores the average (a moving average) of the last eight input values as the converted value. Use this function to smooth inputs that vary at a short interval.

Use the CX-Programmer to set the averaging function in the PLC Setup. The averaging function can be set independently for each input.




Open-circuit Detection Function for Analog Inputs

The open-circuit detection function is activated when the input range is set to 1 to 5 V and the voltage drops below 0.8 V, or when the input range is set to 4 to 20 mA and the current drops below 3.2 mA. When the open-circuit detection function is activated, the converted data will be set to 8,000.

The time for enabling or clearing the open-circuit detection function is the same as the time for converting the data. If the input returns to the convertible range, the open-circuit detection is cleared automatically and the output returns to the normal range.


Auxiliary Area bits A434.00 to A434.03 are allocated as open-circuit detection flags.

Bit	Function	
A434.00	Analog Input 0 Open-circuit Error Flag	0: No error 1: Open-circuit error detected
A434.01	Analog Input 1 Open-circuit Error Flag	
A434.02	Analog Input 2 Open-circuit Error Flag	
A434.03	Analog Input 3 Open-circuit Error Flag	

Procedure**Reading A/D Conversion Values****Writing D/A Conversion Values**

1. Setting the Analog Voltage/Current Input Switches

Each analog input can be set for use as a voltage input or current input.




Each input's input range is set independently in the PLC Setup. The voltage input range can be set to 0 to 5 V, 1 to 5 V, 0 to 10 V, or –10 to 10 V. The current input range can be set to 0 to 20 mA or 4 to 20 mA.

Note The built-in analog input switch is located on the PCB inside the case. To make setting the switch easier, make the switch settings before mounting the terminal block to the base. When setting this switch, be very careful not to damage the wiring on the PCB.

2. PLC Setup



Use the CX-Programmer to set the various PLC Setup including whether the I/O point is being used, the input range, output range, averaging function usage, and resolution. The I/O point usage, input range, output range, and averaging function usage can be set independently for each I/O point, but the resolution setting applies to all of the I/O points.



- The input range can be set to –10 to 10 V, 0 to 10 V, 1 to 5 V, 0 to 5 V, 0 to 20 mA or 4 to 20 mA.
- The output range can be set to –10 to 10 V, 0 to 10 V, 1 to 5 V, 0 to 5 V, 0 to 20 mA or 4 to 20 mA.
- Once the range has been set, it cannot be changed as long as the CP1H CPU Unit's power is ON. To change the input range or output range, change the setting in the PLC Setup, turn the CPU Unit OFF, and then turn the CPU Unit ON again.



3. Wiring Analog I/O

Wiring Analog Inputs



VIN0/IIN0	Analog input 1 voltage/current input
COM0	Analog input 1 common
VIN1/IIN1	Analog input 2 voltage/current input
COM1	Analog input 2 common
VIN2/IIN2	Analog input 3 voltage/current input
COM2	Analog input 3 common
VIN3/IIN3	Analog input 4 voltage/current input
COM3	Analog input 4 common

Wiring Analog Outputs




VOUT1	Analog output 1 voltage output
IOUT1	Analog output 1 current output
COM1	Analog output 1 common
VOUT2	Analog output 2 voltage output
IOUT2	Analog output 2 current output
COM2	Analog output 2 common
AG	Analog 0 V

- Note**
- (1) Use 2-conductor shielded twisted-pair cable for the I/O wiring, and do not connect the shield.
 - (2) If an input is not being used, connect (short) the input's + and – terminals.
 - (3) Wire I/O lines apart from power lines (AC power supply lines, three-phase power lines, etc.).
 - (4) If noise is received from power supply lines, insert a noise filter in the power supply input section.
 - (5) When noise disturbs the analog input/output cable, install the core as shown below to improve anti-noise performance.


Recommended ferrite core

Ferrite core (data line noise filter): 0443-164151 (manufactured by Nisshin Electric Co., Ltd.)


Min. impedance 25MHz: 90Ω, 100 MHz : 160Ω



Recommended installation method



- (6) Refer to the following diagram regarding wiring disconnections when voltage input is being used.



Example: If analog input device 2 is outputting 5 V and the same power supply is being used for both devices as shown above, approximately 1/3, or 1.6 V, will be applied to the input for input device 1.

If a wiring disconnection occurs when voltage input is being used, the situation described below will result. Either separate the power supplies for the connected devices, or use an isolator for each input.

If the same power supply is being used by the connected devices and a disconnection occurs at points A or B in the above diagram, an unwanted circuit path will occur as shown along the dotted line in the diagram. If that occurs, a voltage of approximately 1/3 to 1/2 of the output voltage of the other connected device will be generated. If that voltage is generated while the setting is for 1 to 5 V, open-circuit detection may not be possible. Also, if a disconnection occurs at point C in the diagram, the negative (-) side will be used in for both devices and open-circuit detection will not be possible.

This problem will not occur for current inputs even if the same power supply is used.

Note When external power is supplied (when setting the range code), or when there is a power interruption, pulse-form analog output of up to 1 ms may be generated. If this causes problems with operation, take countermeasures such as those suggested below.

- Turn ON the power supply for the CP1H CPU Unit first, and then turn ON the power supply for the load after confirming correct operation.
- Turn OFF the power supply for the load before turning OFF the power supply for the CP1H CPU Unit.

4. Creating a Ladder Program

I/O Allocation

I/O conversion data is stored in CIO words between CIO 200 and CIO 211. The analog voltage inputs are converted to digital values and output to CIO words CIO 200 to CIO 203.

The digital values in CIO 210 and CIO 211 are converted (D/A conversion) and output as analog voltage or analog current outputs.

Data	Word	Content		
		I/O point	For 1/6,000 resolution	For 1/12,000 resolution
A/D conversion data	CIO 200	Analog input 0	-10 to 10 V range: F448 to 0BB8 hex Other ranges: 0000 to 1770 hex	-10 to 10 V range: E890 to 1770 hex Other ranges: 0000 to 2EE0 hex
	CIO 201	Analog input 1		
	CIO 202	Analog input 2		
	CIO 203	Analog input 3		
D/A conversion data	CIO 210	Analog output 0		
	CIO 211	Analog output 1		

Auxiliary Area Flags

Auxiliary Area bits A434.00 to A434.03 are used as open-circuit detection flags for the open-circuit detection function.

Bit	Function	
A434.00	Analog Input 0 Open-circuit Error Flag	0: No error 1: Open-circuit error detected
A434.01	Analog Input 1 Open-circuit Error Flag	
A434.02	Analog Input 2 Open-circuit Error Flag	
A434.03	Analog Input 3 Open-circuit Error Flag	

The Analog Initialization Completed Flag (A434.04) indicates when the built-in analog I/O has been initialized.

Bit	Function	
A434.04	Analog Initialization Completed Flag	0: Initializing 1: Initialization completed

Reading Converted Analog Input Data

The ladder program can be used to read the memory area words where the converted values are stored. The converted digital values are output to CIO 200 to CIO 203.

Writing Analog Output SV Data

The ladder program can be used to write data to the memory area words where the set value is stored. Write the output SV data to CIO 210 to CIO 211.

The Analog Initialization Completed Flag (A434.04) indicates when the built-in analog I/O has been initialized.

Bit	Function	
A434.04	Analog Initialization Completed Flag	0: Initializing 1: Initialization completed


Startup Operation

After power is turned ON, it takes approximately 1.5 s before the initial data is converted and stored in the input words. The Analog Initialization Completed Flag (A434.04) will go ON when initial processing is completed. If the system starts operating, use this flag in the program to delay reading converted data from analog inputs until the data is valid.

Handling Unit Errors

When an error occurs in the built-in analog I/O system, analog input data will be set to 0000 and the analog output will be set to 0 V or 0 mA.

If a CPU error occurs, the analog output will be set to 0 V or 0 mA even if the output range is 1 to 5 V or 4 to 20 mA. For any other fatal errors in the CPU Unit, 1 V or 4 mA will be output if the output range is 1 to 5 V or 4 to 20 mA.

 **Caution** If an interrupt task program is executed continuously for more than 6 ms, the built-in analog function will not operate properly and a Built-in Analog Error will occur. When using the built-in analog function, design the system so that interrupt task programs are not executed too long or too frequently. Test the system thoroughly in trial operation before operating the system.

SECTION 6

Advanced Functions




This section describes all of the advanced functions of the CP1H that can be used to achieve specific application needs.




6-1	Serial Communications	340
6-1-1	Overview	340
6-1-2	No-protocol Communications	342
6-1-3	Modbus-RTU Easy Master Function	344
6-1-4	Communications: Smart Active Parts and Function Blocks	347
6-1-5	Serial PLC Links	349
6-1-6	1:N NT Links	357
6-1-7	Host Link Communications	358
6-2	Analog Adjuster and External Analog Setting Input	362
6-2-1	Analog Adjuster	362
6-2-2	External Analog Setting Input	363
6-3	7-Segment LED Display	364
6-4	Battery-free Operation	366
6-4-1	Overview	366
6-4-2	Using Battery-free Operation	366
6-5	Memory Cassette Functions	368
6-5-1	Overview	368
6-5-2	Mounting and Removing a Memory Cassette	369
6-5-3	Operation Using the CX-Programmer	371
6-5-4	Memory Cassette Data Transfer Function	372
6-5-5	Procedure for Automatic Transfer from the Memory Cassette at Startup	376
6-6	Program Protection	376
6-6-1	Read Protection	377
6-6-2	Write Protection	381
6-6-3	Protecting Program Execution Using the Lot Number	383
6-7	Failure Diagnosis Functions	384
6-7-1	Failure Alarm Instructions: FAL(006) and FALS(007)	385
6-7-2	Failure Point Detection: FPD(269)	385
6-7-3	Simulating System Errors	387
6-7-4	Output OFF Bit	388
6-8	Clock	388

6-1 Serial Communications

6-1-1 Overview

The CP1H CPU Units support the following serial communications functions.


Protocol	Connected devices	Description	Serial port 1	Serial port 2
No-protocol	<p>Standard devices supporting serial communications</p>  <p>CP1H CPU Unit</p> <p>RS-232C or RS-422A/485</p> <p>Standard device with serial communications</p>	<p>Communicates with standard devices with an RS-232C or RS-422A/485 port without a command-response format. Instead the TXD(236) and RXD(235) instructions are executed from the program to transmit data from the transmission port or read data in the reception port. The frame headers and end codes can be specified.</p>	OK	OK
Serial gateway (to CompoWay/F or Modbus-RTU)	<p>OMRON components supporting CompoWay/F or Modbus-RTU slave devices</p>  <p>CP1H CPU Unit</p> <p>RS-485 (CompoWay/F or Modbus-RTU)</p> <p>OMRON CompoWay/F-compliant components or Modbus-RTU slave devices</p>	<p>Converts received FINS commands into CompoWay/F or Modbus-RTU commands and transfers them on the serial communications path.</p>	OK	OK
Serial PLC Link	<p>CP1H or CJ1M CPU Units</p>  <p>CP1H CPU Unit Polling Unit</p> <p>RS-422A/485 Option Board</p> <p>RS-422A/485</p> <p>Shared data</p> <p>CP1H CPU Unit Polled Unit</p> <p>CP1H CPU Unit Polled Unit</p>	<p>Up to ten words per Unit can be shared by up to nine CPU Units, including one Polling Unit and eight Polled Units.</p> <p>An RS-422A/485 Option Boards (CP1W-CIF11/CIF12) are used to communicate via RS-422A/485, or RS-232C Option Boards (CP1W-CIF01) can be used to communicate between two CPU Units via an RS-232C connection.</p> <p>CJ1M CPU Units can also be included in Serial PLC Links, and the Serial PLC Links can also include PTs as Polled Units via 1:N NT Links.</p> <p>Note Serial PLC Links can be created on serial port 1 or serial port 2, but not on both ports at the same time.</p>	OK	OK

Protocol	Connected devices	Description	Serial port 1	Serial port 2
1:N NT links (1:N NT Links are also used for 1:1 connections.)	OMRON PTs (Programmable Terminals) 	Data can be exchanged with PTs without using a communications program in the CPU Unit.	OK	OK
Host Link	Host computer or OMRON PT (Programmable Terminal) 	1) Various control commands such as reading and writing I/O memory, changing the operating mode, and force-setting/resetting bits can be executed by sending C-mode host link commands or FINS commands from the host computer to the CPU Unit. 2) It is also possible to send FINS commands from the CPU Unit to the host computer to send data or information. Use Host Link communications to monitor data, such as operating status, error information, and quality data in the PLC or send data, such as production planning information, to the PLC.	OK	OK
Peripheral bus (toolbus)	CX-Programmer 	Provides high-speed communications with the CX-Programmer.	OK	OK

6-1-2 No-protocol Communications

No-protocol communications enable sending and receiving data using the TRANSMIT (TXD(236)) and RECEIVE (RXD(235)) instructions without using a protocol and without data conversion (e.g., no retry processing, data type conversion, or process branching based on received data). The communications mode for the serial port must be set for no-protocol communications in the PLC Setup.


No-protocol communications are used to send data in one direction to or from standard devices that have an RS-232C or RS-422A/485 port using TXD(236) or RXD(235).



For example, simple (non-protocol) communications can be used to input data from a barcode reader or output data to a printer.

The following table lists the no-protocol communication functions supported by CP1H PLCs.

Transfer direction	Method	Max. amount of data	Frame format		Other functions
			Start code	End code	
Data transmission (PLC → External device)	Execution of TXD(236) in the program	256 bytes	Yes: 00 to FF No: None	Yes: 00 to FF or CR+LF No: None (The amount of data to receive is specified between 1 and 256 bytes when no end code is specified.)	<ul style="list-style-type: none"> Send delay time (delay between TXD(236) execution and sending data from specified port): 0 to 99,990 ms (unit: 10 ms) Controlling RS and ER signals
Data reception (External device → PLC)	Execution of RXD(235) in the program	256 bytes			Monitoring CS and DR signals

Procedure**Message Frame Formats**

Data can be placed between a start code and end code for transmission by TXD(236) and data between a start code and end code can be received by RXD(235). When transmitting with TXD(236), data from I/O memory is transmitted, and when receiving with RXD(235), the data (without start/end codes) is stored in I/O memory. Up to 256 bytes (including the start and end codes) can be transferred in no-protocol mode.


The start and end codes are set in the PLC Setup.

The following table shows the message formats that can be set for transmissions and receptions in no-protocol mode.

Start code	End code		
	No	Yes	CR+LF
No	<div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; display: inline-block;">data</div> 256 bytes max. </div>	<div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; display: inline-block;">data</div> ED 256 bytes max. </div>	<div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; display: inline-block;">data</div> CR+LF 256 bytes max. </div>
Yes	<div style="text-align: center;"> ST <div style="border: 1px solid black; padding: 5px; display: inline-block;">data</div> 256 bytes max. </div>	<div style="text-align: center;"> ST <div style="border: 1px solid black; padding: 5px; display: inline-block;">data</div> ED 256 bytes max. </div>	<div style="text-align: center;"> ST <div style="border: 1px solid black; padding: 5px; display: inline-block;">data</div> CR+LF 256 bytes max. </div>

- When more than one start code is used, the first start code will be effective.
- When more than one end code is used, the first end code will be effective.
- If the data being transferred contains the end code, the data transfer will be stopped midway. In this case, change the end code to CR+LF.

Note A setting can be made to delay the transmission of data after the execution of TXD(236).



Refer to the *SYSMAC CP Series CP1H CPU Unit Programming Manual* (W451) for more details on TXD(236) and RXD(235).


6-1-3 Modbus-RTU Easy Master Function

Overview


If an RS-232C or RS-422A/485 Option Board is used, the CP1H CPU Unit can function as a Modbus-RTU Master to send Modbus-RTU commands by manipulating software switches. This enables easily controlling Modbus-compliant slaves, such as Inverters, through serial communications.

The following OMRON Inverters support Modbus-RTU slave operation: 3G3JV, 3G3MV, and 3G3RV.

The communications mode in the PLC Setup must be set to the Gateway Mode to enable this functionality.



Modbus-RTU commands can be set simply by turning ON a software switch after setting the Modbus slave address, function, and data in the DM fixed allocation words for the Modbus-RTU Easy Master. The response when received is also store in the DM fixed allocation words for the Modbus-RTU Easy Master.



DM Fixed Allocation Words for the Modbus-RTU Easy Master

Modbus-RTU commands are stored in the DM Area in D32200 to D32249 for serial port 1 and in D32300 to D32349 for serial port 2. When a response is received after turning ON the Modbus-RTU Master Execution Bit, it is stored in D32250 to D32299 for serial port 1 and in D32350 to D32399 for serial port 2.

Words		Bits	Contents	
Serial port 1	Serial port 2			
D32200	D32300	00 to 07	Command	Slave address (00 to F7 hex)
		08 to 15		Reserved (Always 00.)
D32201	D32301	00 to 07		Function code
		08 to 15		Reserved (Always 00.)
D32202	D32302	00 to 15		Number of communications data bytes (0000 to 005E hex)
D32203 to D32249	D32303 to D32349	00 to 15		Communications data (94 bytes maximum)
D32250	D32350	00 to 07	Response	Slave address (00 to F7 hex)
		08 to 15		Reserved (Always 00.)
D32251	D32351	00 to 07		Function code
		08 to 15		Reserved
D32252	D32352	00 to 07		Error code
		08 to 15		Reserved (Always 00.)
D32253	D32353	00 to 15		Number of response bytes (0000 to 03EA hex)
D32254 to D32299	D32354 to D32399	00 to 15		Response data (92 bytes maximum)

Error Codes

The following error codes are stored in an allocated DM Area word when an error occurs in Modbus-RTU Easy Master function execution.

Code	Name	Description
0x00	Normal end	Not an error.
0x01	Illegal address	The slave address specified in the parameter is illegal (248 or higher).
0x02	Illegal function code	The function code specified in the parameter is illegal.
0x03	Data length overflow	There are more than 94 data bytes.
0x04	Serial communications mode error	The Modbus-RTU Easy Master function was executed when the serial communications mode was not the Serial Gateway Mode.
0x80	Response timeout	A response was not received from the Servo.
0x81	Parity error	A parity error occurred.
0x82	Framing error	A framing error occurred.
0x83	Overrun error	An overrun error occurred.
0x84	CRC error	A CRC error occurred.
0x85	Incorrect confirmation address	The slave address in the response is difference from the one in the request.
0x86	Incorrect confirmation function code	The function code in the response is difference from the one in the request.
0x87	Response size overflow	The response frame is larger than the storage area (92 bytes).
0x88	Exception response	An exception response was received from the slave.
0x89	Service being executed	A service is already being executed (reception traffic congestion).
0x8A	Execution canceled	Executing the service has been canceled.
0x8f	Other error	Other FINS response code was received.

Auxiliary Area Flags and Bits

The Modbus-RTU command set in the DM fixed allocation words for the Modbus-RTU Easy Master is automatically sent when the Modbus-RTU Master Execution Bit is turned ON. The results (normal or error) will be given in corresponding flags.

Word	Bit	Port	Contents
A640	00	Port 2	Modbus-RTU Master Execution Bit Turned ON: Execution started ON: Execution in progress. OFF: Not executed or execution completed.
	01		Modbus-RTU Master Execution Normal Flag ON: Execution normal. OFF: Execution error or still in progress.
	02		Modbus-RTU Master Execution Error Flag ON: Execution error. OFF: Execution normal or still in progress.

Word	Bit	Port	Contents
A641	00	Port 1	Modbus-RTU Master Execution Bit Turned ON: Execution started ON: Execution in progress. OFF: Not executed or execution completed.
	01		Modbus-RTU Master Execution Normal Flag ON: Execution normal. OFF: Execution error or still in progress.
	02		Modbus-RTU Master Execution Error Flag ON: Execution error. OFF: Execution normal or still in progress.


6-1-4 Communications: Smart Active Parts and Function Blocks

Overview

OMRON components that support CompoWay/F communications or Modbus-RTU slave functionality (such as Temperature Controllers) can be easily accessed from a CP1H CPU Unit equipped with an RS-422A/485 or RS-232C Option Board using Smart Active Parts (SAPs) on an NS-series PT or using function blocks in the ladder program in the CP1H CPU Unit.

The communications mode in the PLC Setup must be set to the Gateway Mode to enable this functionality.

System Configuration



Note Refer to OMRON's Smart Library website for the most recent information on using SAPs and function blocks.


Serial Gateway Function

When a FINS command is received, it is automatically converted to the protocol corresponding to the message and sent on the serial communications path. Responses are also converted in the same way.

Note Serial ports 1 and 2 on the CP1H CPU Unit can be used to convert to the following protocols.


- CompoWay/F
- Modbus-RTU

This functionality is enabled when the serial communications mode is set to *Serial Gateway*.



Contents of FINS header

- Destination network address(DNA)
 - a) When the routing table for network control of serial communication channel is developed:
It is the network address that corresponds to serial communication port according to the routing table.
 - b) When the routing table for networking serial communication channel is not developed:
It is the network address when actual destination PLC is specified.
- Destination node address (DA1)
 - a) When the routing table for network control of serial communication channel is developed:
00Hex (means PLC internal communication)
 - b) When the routing table for network control of serial communication channel is not developed:
It is the node address when actual destination PLC is specified.
- Destination model address (DA2)
It needs to be the model address of serial communication port.



Serial communication port of CP1H	Model address of serial communication port
Serial port 1	FDHex (decimal 253)
Serial port 2	FCHex (decimal 252)

CPU Unit Serial Gateway Function Specifications

Item	Specification
Pre-conversion data	FINS (via FINS network, Host Link FINS, toolbus, NT Link, or CPU bus)
Conversion functions	FINS commands addressed to serial port 1 or 2 on the CPU Unit are converted to CompoWay/F commands (after removing the header) if the FINS command code is 2803 hex and to Modbus-RTU commands (after removing the header) if the FINS command code is 2804 hex.
Post-conversion data	CompoWay/F command or Modbus-RTU command
Serial communications method	1:N half-duplex
Maximum number of nodes	31
Enabling serial communications mode	Serial Gateway Mode
Response timeout	The time from when a message converted to a different protocol is set until a response is received is monitored by the serial gateway function. Default: 5 s, User setting: 0.1 to 25.5 s Note A FINS response code of 0205 hex (response timeout) is sent to the source of the FINS command if a timeout occurs.
Send delay function	None

Note If a CJ-series Serial Communications Unit is connected via a CJ Unit Adapter, messages can also be converted to Modbus-ASCII or Host Link FINS. Refer to the *SYSMAC CS/CJ Series Serial Communications Boards/Units Operation Manual (W336)* for details.

6-1-5 Serial PLC Links

Overview


Serial PLC Links can be used to allow data to be exchanged among CP1H and CJ1M CPU Units via the RS-422A/485 or RS-232C Option Boards mounted to the CPU Units without requiring special programming. The communications mode in the PLC Setup must be set to the Serial PLC Link Mode to enable this functionality.

- Either serial port 1 or 2 can be used. (See note.)
- Words are allocated in memory in the Serial PLC Link Words (CIO 3100 to CIO 3199).
- A maximum of 10 words can be transferred by each CPU1H CPU Unit, but the number of linked words can be set to fewer words. (The size must be the same for all CP1H CPU Units.)


Note Serial PLC Links cannot be used on serial ports 1 and 2 at the same time. If one port is set as a Serial PLC Link slave or master, it will not be possible to set the other port for a Serial PLC Link. A PLC Setup error will occur if an attempt is made to set both ports for Serial PLC Links.

Configuration

1:N Connections between CP1H/CJ1M CPU Units (8 Nodes Maximum)



1:1 Connections between CP1H/CJ1M CPU Units



Specifications

Item	Specifications
Applicable serial ports	Serial port 1 or 2. Both ports cannot be used for PLC Links at the same time. If both ports are set for PLC Links (either as polling node or polled node), a PLC Setup setting error (non-fatal error) will occur and the PLC Setup Setting Error Flag (A40210) will turn ON.
Connection method	RS-422A/485 or RS-232C connection via RS-422A/485 or RS-232C Option Board.
Allocated data area	Serial PLC Link Words: CIO 3100 to CIO 3199 (Up to 10 words can be allocated for each CPU Unit.)
Number of Units	9 Units max., comprising 1 Polling Unit and 8 Polled Units (A PT can be placed on the same network in an 1:N NT Link, but it must be counted as one of the 8 Polled Units.)
Link methods (data refresh methods)	Complete link method or Polling Unit link method

Data Refresh Methods

The following two methods can be used to refresh data.

- Complete link method
- Polling Unit link method


Complete Link Method

The data from all nodes in the Serial PLC Links are reflected in both the Polling Unit and the Polled Units. (The only exceptions are the address allocated

to the connected PT's unit number and the addresses of Polled Units that are not present in the network. These data areas are undefined in all nodes.)


Example: Complete Link Method, Highest Unit Number: 3

In the following diagram, Polled Unit No. 2 is either a PT or is a Unit not present in the network, so the area allocated for Polled Unit No. 2 is undefined in all nodes.



Example: Complete Link Method, Number of Link Words: 10

Each CPU Unit (either CP1H or CJ1M) sends data to the same words in all other CPU Units for the Polling Unit and all Polled Units. The Polling Unit is a CP1H CPU Unit in the following example, but it could also be a CJ1M CPU Unit.




Polling Unit Link Method


The data for all the Polled Units in the Serial PLC Links are reflected in the Polling Unit only, and each Polled Unit reflects the data of the Polling Unit only. The advantage of the Polling Unit link method is that the addresses allocated for the local Polled Unit data are the same in each Polled Unit, allowing data to be accessed using common ladder programming. The areas allocated for the unit numbers of the PT or Polled Units not present in the network are undefined in the Polling Unit only.

Example: Polling Unit Link Method, Highest Unit Number: 3

In the following diagram, Polled Unit No. 2 is a PT or a Unit not participating in the network, so the corresponding area in the Polling Unit is undefined.

**Example: Polling Unit Link Method, Number of Link Words: 10**

The CPU Unit that is the Polling Unit (either CP1H or CJ1M) sends its data (CIO 3100 to CIO 3109) to the same words (CIO 3100 to CIO 3109) in all other CPU Units. The Polled Units send their data (CIO 3110 to CIO 3119) to consecutive sets of 10 words in the Polling Unit. The Polling Units is a CP1H CPU Unit in the following example, but it could also be a CJ1M CPU Unit. (Only the first three Polled Units are shown below.)



Allocated Words**Complete Link Method**

Address

CIO 3100

Serial PLC
Link Words

CIO 3199

Link words	1 word	2 words	3 words	to	10 words
Polling Unit	CIO 3100	CIO 3100 to CIO 3101	CIO 3100 to CIO 3102		CIO 3100 to CIO 3109
Polled Unit No. 0	CIO 3101	CIO 3102 to CIO 3103	CIO 3103 to CIO 3105		CIO 3110 to CIO 3119
Polled Unit No. 1	CIO 3102	CIO 3104 to CIO 3105	CIO 3106 to CIO 3108		CIO 3120 to CIO 3129
Polled Unit No. 2	CIO 3103	CIO 3106 to CIO 3107	CIO 3109 to CIO 3111		CIO 3130 to CIO 3139
Polled Unit No. 3	CIO 3104	CIO 3108 to CIO 3109	CIO 3112 to CIO 3114		CIO 3140 to CIO 3149
Polled Unit No. 4	CIO 3105	CIO 3110 to CIO 3111	CIO 3115 to CIO 3117		CIO 3150 to CIO 3159
Polled Unit No. 5	CIO 3106	CIO 3112 to CIO 3113	CIO 3118 to CIO 3120		CIO 3160 to CIO 3169
Polled Unit No. 6	CIO 3107	CIO 3114 to CIO 3115	CIO 3121 to CIO 3123		CIO 3170 to CIO 3179
Polled Unit No. 7	CIO 3108	CIO 3116 to CIO 3117	CIO 3124 to CIO 3126		CIO 3180 to CIO 3189
Not used.	CIO 3109 to CIO 3199	CIO 3118 to CIO 3199	CIO 3127 to CIO 3199		CIO 3190 to CIO 3199

Polling Unit Link Method

Address

CIO 3100

Serial PLC
Link Words

CIO 3199

Link words	1 word	2 words	3 words	to	10 words
Polling Unit	CIO 3100	CIO 3100 to CIO 3101	CIO 3100 to CIO 3102		CIO 3100 to CIO 3109
Polled Unit No. 0	CIO 3101	CIO 3102 to CIO 3103	CIO 3103 to CIO 3105		CIO 3110 to CIO 3119
Polled Unit No. 1	CIO 3101	CIO 3102 to CIO 3103	CIO 3103 to CIO 3105		CIO 3110 to CIO 3119
Polled Unit No. 2	CIO 3101	CIO 3102 to CIO 3103	CIO 3103 to CIO 3105		CIO 3110 to CIO 3119
Polled Unit No. 3	CIO 3101	CIO 3102 to CIO 3103	CIO 3103 to CIO 3105		CIO 3110 to CIO 3119
Polled Unit No. 4	CIO 3101	CIO 3102 to CIO 3103	CIO 3103 to CIO 3105		CIO 3110 to CIO 3119
Polled Unit No. 5	CIO 3101	CIO 3102 to CIO 3103	CIO 3103 to CIO 3105		CIO 3110 to CIO 3119
Polled Unit No. 6	CIO 3101	CIO 3102 to CIO 3103	CIO 3103 to CIO 3105		CIO 3110 to CIO 3119
Polled Unit No. 7	CIO 3101	CIO 3102 to CIO 3103	CIO 3103 to CIO 3105		CIO 3110 to CIO 3119
Not used.	CIO 3102 to CIO 3199	CIO 3104 to CIO 3199	CIO 3106 to CIO 3199		CIO 3120 to CIO 3199

Procedure

The Serial PLC Links operate according to the following settings in the PLC Setup in the Polling Unit and Polled Units.

Settings at the Polling Unit

- 1,2,3...**
1. Set the serial communications mode of serial port 1 or 2 to Serial PLC Links (Polling Unit).
 2. Set the link method to the Complete Link Method or Polling Unit Link Method.
 3. Set the number of link words (up to 10 words for each Unit).
 4. Set the maximum unit number in the Serial PLC Links (0 to 7).

Settings at the Polled Units

- 1,2,3...**
1. Set the serial communications mode of serial port 1 or 2 to Serial PLC Links (Polled Unit).
 2. Set the unit number of the Serial PLC Link Polled Unit.

PLC Setup**Settings at the Polling Unit**

Item		Set value	Default	Refresh timing
Serial port 1 or 2	Mode: Communications mode	PC Link (Master): PLC Link Polling Unit	Host Link	Every cycle
	Baud: Baud rate	38,400 bps, 115,200 bps	9,600 bps	
	PC link mode: PLC Link method	ALL: Complete link method Masters: Polling Unit method	ALL	
	Link words: No. of link words	1 to 10 words	10 words	
	PC Link Unit No.: Max. unit No.	0 to 7	0 hex	

Settings at the Polled Unit

Item		Set value	Default	Refresh timing
Serial port 1 or 2	Mode: Communications mode	PC Link (Slave): PLC Link Polled Unit	Host Link	Every cycle
	Baud: Baud rate	38,400 bps, 115,200 bps	9,600 bps	
	Unit number	0 to 7	0	

Note Both serial ports cannot be used for PLC Links at the same time. If both ports are set for PLC Links (either as polling node or polled node), a PLC Setup setting error (non-fatal error) will occur and the PLC Setup Setting Error Flag (A40210) will turn ON. If PLC Links is set for one serial port, set the other serial port to a different mode.

Related Auxiliary Area Flags for Serial Port 1

Name	Address	Details	Read/write	Refresh timing
Serial Port 1 Communicating with PT Flags (See note.)	A394.00 to A394.07	When serial port 1 is being used in NT link mode, the bit corresponding to the Unit performing communications will be ON. Bits 00 to 07 correspond to unit numbers 0 to 7, respectively. ON: Communicating OFF: Not communicating	Read	<ul style="list-style-type: none"> Cleared when power is turned ON. Turns ON the bit corresponding to the unit number of the PT/Polled Unit that is communicating via serial port 1 in NT link mode or Serial PLC Link mode. Bits 00 to 07 correspond to unit numbers 0 to 7, respectively.
Serial Port 1 Restart Bit	A526.01	Turn ON this bit to restart serial port 1.	Read/write	<ul style="list-style-type: none"> Cleared when power is turned ON. Turn ON to restart serial port 1, (except when communicating in peripheral bus mode). <p>Note The bit is automatically turned OFF by the system when restart processing has been completed.</p>
Serial Port 1 Error Flags	A528.08 to A528.15	When an error occurs at serial port 1, the corresponding error bit is turned ON. Bit 08: Not used. Bit 09: Not used. Bit 10: Parity error Bit 11: Framing error Bit 12: Overrun error Bit 13: Timeout error Bit 14: Not used. Bit 15: Not used.	Read/write	<ul style="list-style-type: none"> Cleared when power is turned ON. When an error occurs at serial port 1, the corresponding error bit is turned ON. The flag is automatically turned OFF by the system when serial port 1 is restarted. In NT link mode, only bit 05 (timeout error) is enabled. <p>In Serial PLC Link mode, only the following bits are enabled.</p> <ul style="list-style-type: none"> Errors at the Polling Unit: Bit 05: Timeout error Errors at Polled Units: Bit 05: Timeout error Bit 04: Overrun error Bit 03: Framing error <p>Note If the error occurred in Serial PLC link mode, the console will retry before communication establish. Rehabilitation of the communications is no need for port restart. If user eliminates error, the communication will automatically establish between console and servo. However, error flag will be saved as the record. If you want to clear the error flag, please restart port.</p>
Serial Port 1 Settings Changed Flag	A619.01	Turns ON when the communications conditions of serial port 1 are being changed. ON: Changed OFF: No change	Read/write	<ul style="list-style-type: none"> Cleared when power is turned ON. Turns ON while communications conditions settings for serial port 1 are being changed. Turns ON when the CHANGE SERIAL PORT SETUP instruction (STUP(237)) is executed. Turns OFF when the changes to settings are completed.

Note In the same way as for the existing 1:N NT Link, the status (communicating/not communicating) of PTs in Serial PLC Links can be checked from the Polling Unit (CPU Unit) by reading the Serial Port 1 Communicating with PT Flag (A394 bits 00 to 07 for unit numbers 0 to 7).


Related Auxiliary Area Flags for Serial Port 2

Name	Address	Details	Read/write	Refresh timing
Serial Port 2 Communicating with PT Flags (See note.)	A393.00 to A393.07	When Serial Port 2 is being used in NT link mode, the bit corresponding to the Unit performing communications will be ON. Bits 00 to 07 correspond to unit numbers 0 to 7, respectively. ON: Communicating OFF: Not communicating	Read	<ul style="list-style-type: none"> Cleared when power is turned ON. Turns ON the bit corresponding to the unit number of the PT/Polled Unit that is communicating via Serial Port 2 in NT link mode or Serial PLC Link mode. Bits 00 to 07 correspond to unit numbers 0 to 7, respectively.
Serial Port 2 Restart Bit	A526.00	Turn ON this bit to restart Serial Port 2.	Read/write	<ul style="list-style-type: none"> Cleared when power is turned ON. Turn ON to restart Serial Port 2, (except when communicating in peripheral bus mode). <p>Note The bit is automatically turned OFF by the system when restart processing has been completed.</p>
Serial Port 2 Error Flags	A528.00 to A528.07	When an error occurs at Serial Port 2, the corresponding error bit is turned ON. Bit 00: Not used. Bit 01: Not used. Bit 02: Parity error Bit 03: Framing error Bit 04: Overrun error Bit 05: Timeout error Bit 06: Not used. Bit 07: Not used.	Read/write	<ul style="list-style-type: none"> Cleared when power is turned ON. When an error occurs at Serial Port 2, the corresponding error bit is turned ON. The flag is automatically turned OFF by the system when Serial Port 2 is restarted. In NT link mode, only bit 05 (timeout error) is enabled. <p>In Serial PLC Link mode, only the following bits are enabled.</p> <ul style="list-style-type: none"> Errors at the Polling Unit: Bit 05: Timeout error Errors at Polled Units: Bit 05: Timeout error Bit 04: Overrun error Bit 03: Framing error <p>Note If the error occurred in Serial PLC link mode, the console will retry before communication establish. Rehabilitation of the communications is no need for port restart. If user eliminates error, the communication will automatically establish between console and servo. However, error flag will be saved as the record. If you want to clear the error flag, please restart port.</p>
Serial Port 2 Settings Changed Flag	A619.02	Turns ON when the communications conditions of Serial Port 2 are being changed. ON: Changed OFF: No change	Read/write	<ul style="list-style-type: none"> Cleared when power is turned ON. Turns ON while communications conditions settings for Serial Port 2 are being changed. Turns ON when the CHANGE SERIAL PORT SETUP instruction (STUP(237)) is executed. Turns OFF when the changes to settings are completed.

Note In the same way as for the existing 1:N NT Link, the status (communicating/not communicating) of PTs in Serial PLC Links can be checked from the Polling Unit (CPU Unit) by reading the Serial Port 2 Communicating with PT Flag (A393 bits 00 to 07 for unit numbers 0 to 7).

6-1-6 1:N NT Links


In the CP Series, communications are possible with PTs (Programmable Terminals) using NT Links in 1:N mode.



Note Communications are not possible using the 1:1-mode NT Link protocol.

High-speed NT Links are possible in addition to the previous standard NT Links by using the PT system menu and the following PLC Setup. High-speed NT Links are possible, however, only with NS-series PTs or with the NT31(C)-V2 or NT631(C)-V2 PTs.

PLC Setup



Port	Name	Settings contents	Default values	Other conditions
Serial port 1 or 2	Mode: Communications mode	NT Link (1:N): 1:N NT Links	Host Link	Turn OFF pin 4 on the CPU Unit DIP switch hen using serial port 1 and turn OFF pin 5 when using serial port 2.
	Baud: Baud rate	38,400 (standard) 115,200 (high speed)	9,600 (disabled)	
	NT/PC Link Max: Highest unit number	0 to 7	0	---











PT System Menu


Set the PT as follows:

- 1,2,3...
1. Select NT Link (1:N) from Comm. A Method or Comm. B Method on the Memory Switch Menu under the System Menu on the PT Unit.
 2. Press the SET Touch Switch to set the Comm. Speed to High Speed.

6-1-7 Host Link Communications

The following table shows the host link communication functions available in CP1H PLCs. Select the method that best suits your application.

Command flow	Command type	Communications method	Configuration
Host computer 	Host link command (C Mode) 	Create frame in the host computer and send the command to the PLC. Receive the response from the PLC. Application: Use this method when communicating primarily from the host computer to the PLC.	Directly connect the host computer in a 1:1 or 1:N system. 
	FINS command (with Host Link header and terminator) sent. 	Create frame in the host computer and send the command to the PLC. Receive the response from the PLC. Application: Use these methods when communicating primarily from the host computer to PLCs in the network. Remarks: The FINS command must be placed between a Host Link header and terminator and then sent by the host computer.	Directly connect the host computer in a 1:1 or 1:N system. 
			Communicate with other PLCs in the network from the host computer. (Convert from Host Link to network protocol.) 
 Host computer	FINS command (with Host Link header and terminator) is sent. 	Send the command frame with the CPU Unit's SEND, RECV, or CMND instruction. Receive response from the host computer. Application: Use this method when communicating primarily from the PLC to the host computer to transmit status information, such as error information. Remarks: The FINS command will be placed between a Host Link header and terminator when it is sent. The FINS command must be interpreted at the host computer and then the host computer must return a response.	Directly connect the host computer in a 1:1 system. 
			Communicate with the host computer through other PLCs in the network. (Convert from Host Link to network protocol.) 

Procedure**Host Link Commands**

The following table lists the host link commands. Refer to the *SYSMAC CS/CJ-series Communications Commands Reference Manual* (W342) for more details.

Type	Header code	Name	Function
I/O memory read commands	RR	CIO AREA READ	Reads the contents of the specified number of CIO Area words starting from the specified word.
	RL	LINK AREA READ	Reads the contents of the specified number of Link Area words starting from the specified word.
	RH	HR AREA READ	Reads the contents of the specified number of Holding Area words starting from the specified word.
	RC	PV READ	Reads the contents of the specified number of timer/counter PVs (present values) starting from the specified timer/counter.
	RG	T/C STATUS READ	Reads the status of the Completion Flags of the specified number of timers/counters starting from the specified timer/counter.
	RD	DM AREA READ	Reads the contents of the specified number of DM Area words starting from the specified word.
	RJ	AR AREA READ	Reads the contents of the specified number of Auxiliary Area words starting from the specified word.

Type	Header code	Name	Function
I/O memory write commands	WR	CIO AREA WRITE	Writes the specified data (word units only) to the CIO Area, starting from the specified word.
	WL	LINK AREA WRITE	Writes the specified data (word units only) to the Link Area, starting from the specified word.
	WH	HR AREA WRITE	Writes the specified data (word units only) to the Holding Area, starting from the specified word.
	WC	PV WRITE	Writes the PVs (present values) of the specified number of timers/counters, starting from the specified timer/counter.
	WD	DM AREA WRITE	Writes the specified data (word units only) to the DM Area, starting from the specified word.
	WJ	AR AREA WRITE	Writes the specified data (word units only) to the Auxiliary Area, starting from the specified word.
Timer/counter SV read commands	R#	SV READ 1	Reads the 4-digit BCD constant or word address in the SV of the specified timer/counter instruction.
	R\$	SV READ 2	Searches for the specified timer/counter instruction beginning at the specified program address and reads the 4-digit constant or word address in the SV.
	R%	SV READ 3	Searches for the specified timer/counter instruction beginning at the specified program address and reads the 4-digit BCD constant or word address in the SV.
Timer/counter SV write commands	W#	SV CHANGE 1	Changes the 4-digit BCD constant or word address in the SV of the specified timer/counter instruction.
	W\$	SV CHANGE 2	Searches for the specified timer/counter instruction beginning at the specified program address and changes the 4-digit constant or word address in the SV.
	W%	SV CHANGE 3	Searches for the specified timer/counter instruction beginning at the specified program address and changes the 4-digit constant or word address in the SV.
CPU Unit status commands	MS	STATUS READ	Reads the operating status of the CPU Unit (operating mode, force-set/reset status, fatal error status).
	SC	STATUS CHANGE	Changes the CPU Unit's operating mode.
	MF	ERROR READ	Reads and clears errors in the CPU Unit (non-fatal and fatal).
Force-set/force-reset commands	KS	FORCE SET	Force-sets the specified bit.
	KR	FORCE RESET	Force-resets the specified bit.
	FK	MULTIPLE FORCE SET/RESET	Force-sets, force-resets, or clears the forced status of the specified bits.
	KC	FORCE SET/RESET CANCEL	Cancels the forced status of all force-set and force-reset bits.
Model read command	MM	PLC MODEL READ	Reads the model type of the PLC.
Test command	TS	TEST	Returns, unaltered, one block of data transmitted from the host computer.
Program area access commands	RP	PROGRAM READ	Reads the contents of the CPU Unit's user program area in machine language (object code).
	WP	PROGRAM WRITE	Writes the machine language (object code) program transmitted from the host computer into the CPU Unit's user program area.
I/O memory compound read commands	QQMR	COMPOUND COMMAND	Registers the desired bits and words in a table.
	QQIR	COMPOUND READ	Reads the registered words and bits from I/O memory.

Type	Header code	Name	Function
Host Link communications processing commands	XZ	ABORT (command only)	Aborts the host link command that is currently being processed.
	**	INITIALIZE (command only)	Initializes the transmission control procedure of all PLCs connected to the host computer.
	IC	Undefined command (response only)	This response is returned if the header code of a command was not recognized.

FINS Commands


The following table lists the FINS commands. Refer to the *FINS Commands Reference Manual (W227)* for more details.

Type	Command code		Name	Function
I/O Memory Area Access Commands	01	01	MEMORY AREA READ	Reads consecutive data from the I/O memory area.
	01	02	MEMORY AREA WRITE	Writes consecutive data to the I/O memory area.
	01	03	MEMORY AREA FILL	Fills the specified range of I/O memory with the same data.
	01	04	MULTIPLE MEMORY AREA READ	Reads non-consecutive data from the I/O memory area.
	01	05	MEMORY AREA TRANSFER	Copies and transfers consecutive data from one part of the I/O memory area to another.
Parameter Area Access Commands	02	01	PARAMETER AREA READ	Reads consecutive data from the parameter area.
	02	02	PARAMETER AREA WRITE	Writes consecutive data to the parameter area.
	02	03	PARAMETER AREA FILL	Fills the specified range of the parameter area with the same data.
Program Area Access Commands	03	06	PROGRAM AREA READ	Reads data from the user program area.
	03	07	PROGRAM AREA WRITE	Writes data to the user program area.
	03	08	PROGRAM AREA CLEAR	Clears the specified range of the user program area.
Execution Control Commands	04	01	RUN	Switches the CPU Unit to RUN or MONITOR mode.
	04	02	STOP	Switches the CPU Unit to PROGRAM mode.
Configuration Read Commands	05	01	CONTROLLER DATA READ	Reads CPU Unit information.
	05	02	CONNECTION DATA READ	Reads the model numbers of the specified Units.
Status Read Commands	06	01	CONTROLLER STATUS READ	Reads the CPU Unit's status information.
	06	20	CYCLE TIME READ	Reads the average, maximum, and minimum cycle times.
Clock Access Commands	07	01	CLOCK READ	Reads the clock.
	07	02	CLOCK WRITE	Sets the clock.
Message Access Commands	09	20	MESSAGE READ/CLEAR	Reads/clears messages and FAL (FALS) messages.
Access Right Commands	0C	01	ACCESS RIGHT ACQUIRE	Acquires the access right if no other device holds it.
	0C	02	ACCESS RIGHT FORCED ACQUIRE	Acquires the access right even if another device currently holds it.
	0C	03	ACCESS RIGHT RELEASE	Releases the access right regardless of what device holds it.
Error Access Commands	21	01	ERROR CLEAR	Clears errors and error messages.
	21	02	ERROR LOG READ	Reads the error log.
	21	03	ERROR LOG CLEAR	Clears the error log pointer to zero.
Forced Status Commands	23	01	FORCED SET/RESET	Force-sets, force-resets, or clears the forced status of the specified bits.
	23	02	FORCED SET/RESET CANCEL	Cancels the forced status of all force-set and force-reset bits.

Message Communications Functions

The FINS commands listed in the table above can also be transmitted through the network from other PLCs to the CPU Unit. Observe the following points when transmitting FINS commands through the network.

FINS commands are sent with CMND(490) from the CPU Unit's program.




Refer to the CPU Bus Unit's Operation Manual for more details on the message communications functions.


6-2 Analog Adjuster and External Analog Setting Input

6-2-1 Analog Adjuster

By turning the analog adjuster on the CP1H CPU Unit with a Phillips screwdriver, the PV in the Auxiliary Area (A642) can be changed to any value within a range of 0 to 255. During the adjustment, the value is displayed from 00 to FF (hex) on the 7-segment LED display regardless of the CP1H operating mode.

**Application Example**


Setting the value for timer T100 in A642 makes it possible to use T100 as a variable timer with a range of 0 to 25.5 s (0 to 255). A change in the set value is reflected with the next scan.



Note Set values from the analog adjuster may vary with changes in the ambient temperature and the power supply voltage. Do not use it for applications that require highly precise set values.


6-2-2 External Analog Setting Input

When a voltage of 0 to 10 V is applied to the CP1H CPU Unit's external analog setting input terminal, the voltage is converted from analog to digital and the PV in A643 can be changed to any value within a range of 0 to 256 (0000 to 0100 hex).




External Analog Setting Input Wiring

Use the 1-m lead wire (included) for wiring to the external analog setting input connector on the CP1H CPU Unit.



Relationship between Input Voltage and PV in A643


A643 PV (BCD)



The maximum input voltage is 11 VDC. Do not apply a voltage greater than that.

Application Example


Setting the value for timer T101 in A643 makes it possible to use T101 as a variable timer with a range of 0 to 25.6 s (0 to 256). A change in the set value is reflected with the next scan.



Note External analog setting input values may vary with changes in the ambient temperature. Do not use the external analog setting input for applications that require highly precise set values.

6-3 7-Segment LED Display

A two-digit 7-segment LED display makes it easy to monitor PLC status. This improves the human-machine interface for maintenance, making it easier to detect troubles that may occur during machine operation. The items indicated below can be displayed.



Contents of Display

The following items can be displayed in the 7-segment LED.

- Unit version (only when the power supply is ON)
- Error codes for errors that occur during CPU Unit operation
- Progress of transfers between the CPU Unit and Memory Cassette
- Changes in values when using the analog adjuster
- User-defined codes from special display instructions in the ladder program

Unit Version Display

The CPU Unit version is displayed for approximately 1 s when the power supply is turned ON.




CPU Unit Error Display

When an error occurs at the CPU Unit, the error code is displayed. If multiple errors occur simultaneously, they are prioritized for display in order of importance. Then, as each error is cleared, the error code for the next one is displayed.

For details, refer to *11-1 Error Classification and Confirmation*.

Memory Cassette Transfer
Progress Display

When data is transferred between the Memory Cassette and the CPU Unit, or when a verification is started, the percentage of data remaining to be transferred or verified is displayed as a percentage (99% to 00%). It is also displayed for automatic transfers at startup.



Analog Adjuster Set Value
Display

When the analog adjuster is used to change a set value, that value is displayed in the 7-segment LED from 00 to FF hex (0 to 255). The set value is displayed regardless of the operating mode of the CP1H CPU Unit. The display is cleared when the set value remains unchanged for at least 4 seconds.


7-segment LED display	00	—	7d	—	FF
Value in word A642	00000 (0)	—	007D (125)	—	00FF (255)



User-defined Code
Display

The DISPLAY 7-SEGMENT LED WORD DATA (SCH(047)) and 7-SEGMENT LED CONTROL (SCTRL(048)) instructions can be used to display any codes or characters from the ladder program.


DISPLAY 7-SEGMENT LED WORD DATA: SCH (047)



When W0.01 turns ON, 2d is displayed on the 7-segment display on the CPU Unit.


Individually Displaying 7-segment LED Segments and Dots

Any code can be displayed by using SCTRL(048) to turn ON the bits corresponding to individual segments and dots.



Clearing the 7-segment LED Display

Setting #0000 for SCTRL(048) and executing the instruction clears the entire user-defined 7-segment LED display.



6-4 Battery-free Operation

6-4-1 Overview

With the CP1H CPU Unit, saving backup data in the built-in flash memory (non-volatile memory) enables operation with no battery mounted (i.e., battery-free operation).

I/O memory (such as CIO), however, is constantly refreshed during operation, so backup data is not saved in the built-in flash memory. When battery-free operation is used, therefore, programs must be created assuming that I/O memory data will not be saved.

For example, if a battery is mounted, then HR, CNT, and DM data is saved during power interruptions if a battery is mounted but not when battery-free operation is used.

In that case it is necessary to set the required values in the ladder program. It is also possible to save to the built-in flash memory in advance the DM initial values that are to be set for the DM on RAM at startup.


6-4-2 Using Battery-free Operation

Precautions when Creating Programs for Battery-free Operation

Be careful of the following points, and create programs for which it will not be a problem even if the correct I/O memory values are not held.

- For unstable parts of I/O memory, include programming at the start of operation to set required data.

- When battery-free operation is used, the Output OFF Flag (A500.15) in the Auxiliary Area becomes unstable. When the Output OFF Flag turns ON, all outputs turn OFF, so include the following program for clearing the Output OFF Flag at the start of operation.



- Do not reference the clock function, (the clock data in words A351 to A354 of the Auxiliary Area, or the various kinds of time data).

Saving DM Initial Values (Only when Required)

Use the following procedure to save to the built-in flash memory the DM initial values that are to be set at startup.


1,2,3...

- First set in the DM Area the data that is to be set as initial values at startup.
- Execute a backup to flash memory from the CX-Programmer's Memory Cassette Transfer/Data Memory Backup Dialog Box.

The procedure is as follows:

- Select **PLC - Edit - Memory Cassette/DM**.

The following Memory Cassette Transfer/DM Backup Dialog Box will be displayed.



- Select the *Data Memory* Option in the *Backup to Flash Memory* Area and click the **Backup** Button.

The DM data will be written to the built-in flash memory.

Note The DM data that is saved and written at startup is the entire DM Area (D0 to D32767).

PLC Setup

1,2,3...

- Set *Do not detect Low Battery (run without battery)* to *Do not detect*.

2. Set *IOM Hold Bit Status at Startup* and *Forced Status Hold Bit Status at Startup* to *Clear (OFF)*.
3. Set *Read DM from flash memory* to *Read*. (Only when DM initial values have been saved as described above.)

⚠ Caution The CP1H CPU Units automatically back up the user program and parameter data to flash memory when these are written to the CPU Unit. Also, the CX-Programmer can be used to save all of the data in the DM Area to the flash memory for use as initial values when the power supply is turned ON. Neither of these functions saves the I/O memory data (including HR Area data, counter PVs and Completion Flags, and DM Area data other than initial values). The HR Area data, counter PVs and Completion Flags, and DM Area data other than initial values are held during power interruptions with a battery. If there is a battery error, the contents of these areas may not be accurate after a power interruption. If HR Area data, counter PVs and Completion Flags, and DM Area data other than initial values are used to control external outputs, prevent inappropriate outputs from being made whenever the Battery Error Flag (A402.04) is ON.

6-5 Memory Cassette Functions

6-5-1 Overview

CP1H CPU Units have Memory Cassette functions that enable data in the CPU Unit to be stored on and read from a special CP1W-ME05M Memory Cassette. These functions can be used for the following applications.

- Copying data to other CPU Units to produce duplicate devices.
- Backing up data in case the CPU Unit needs to be replaced due to any malfunction.
- Writing and updating data when existing device versions are upgraded.

Memory Cassette Specifications

Use the following Memory Cassette.

Model	Specifications
CP1W-ME05M	<ul style="list-style-type: none"> • Memory size 512 Kwords • Storage capacity The following CPU Unit data (for each Unit) <ul style="list-style-type: none"> • User programs • Parameters • Comment memory • Function Block (FB) sources • DM initial values in the built-in flash memory • DM in RAM • Write method Operations from the CX-Programmer • Read method Powering up with DIP switch pin SW2 set to ON, or operations from the CX-Programmer

Data that Can be Stored on a Memory Cassette

The following data can be stored on a Memory Cassette.

Data stored on Memory Cassette		Location in CPU Unit
User programs		Built-in RAM, built-in flash memory (User Program Area)
Parameters	PLC Setup, CPU Bus Unit settings, routing tables	Built-in RAM, built-in flash memory (Parameter Area)

Data stored on Memory Cassette		Location in CPU Unit
Comment data for user programs	Variable tables	Built-in flash memory (Comment Memory Area)
	(I/O comments, rung comments, program comments)	Built-in flash memory (Comment Memory Area)
	Program indexes (section names, section comments, program comments)	Built-in flash memory (Comment Memory Area)
Function Block (FB) sources		Built-in flash memory (FB Source Memory Area)
DM		Built-in RAM (D0 to D32767 in DM Area)
DM initial values (See note.)		Built-in flash memory (DM Initial Values Area)

The areas for storing various types of data have fixed allocations in the Memory Cassette, and a single Memory Cassette corresponds to a single CPU Unit.

Therefore it is not possible to simultaneously store multiple items of the same type of data (e.g., two user programs).

Also, the data can only be read to a CPU Unit. It cannot be directly managed from a personal computer like files.


The only data that can be stored on a Memory Cassette is the data from a CPU Unit. Even when a CJ-series Special I/O Unit or CPU Bus Unit is connected using a CJ Unit Adapter, any data that is stored on those Units themselves cannot be stored on a Memory Cassette.

Note The CX-Programmer's function for saving DM initial values is used for saving the values in the DM Area (D0 to D32767) to the built-in flash memory as initial values. By means of a setting in the PLC Setup, these initial values can then be automatically written to the DM Area (D0 to D32767) when the power is turned ON.

6-5-2 Mounting and Removing a Memory Cassette


Mounting

- 1,2,3...**
1. Turn OFF the power supply to the PLC.
 2. Holding the Memory Cassette with the side with the nameplate facing upwards, insert the Memory Cassette all the way into the slot.



Removal

- 1,2,3...**
1. Turn OFF the power supply to the PLC.
 2. Grasp the end of the Memory Cassette between the thumbnail and index finger, and slide it upwards to remove it.



- Note**
- (1) Turn OFF the power supply before mounting or removing the Memory Cassette.
 - (2) Absolutely do not remove the Memory Cassette while the BKUP indicator and 7-segment LED are flashing (i.e., during a data transfer or verification). Doing so could make the Memory Cassette unusable.
 - (3) The Memory Cassette is small, so be careful to not let it be dropped or lost when it is removed.


6-5-3 Operation Using the CX-Programmer

Use the following procedure for the Memory Cassette function.

1,2,3...

1. Select **PLC - Edit - Memory Cassette/DM**.

The following Memory Cassette Transfer/Data Memory Backup Dialog Box will be displayed.




2. Under *Transfer Data Area*, check whatever types of data are to be transferred.
3. Execute any of the following operations.
 - To transfer data from the CPU Unit to the Memory Cassette:
Click the **Transfer to Memory Cassette** Button.
 - To transfer data from the Memory Cassette to the CPU Unit:
Click the **Transfer to PLC** Button.
 - To verify data transferred between the CPU Unit and the Memory Cassette:
Click the **Compare** Button. This will cause all areas to be verified regardless of the items checked under Transfer Area.
 - To format the Memory Cassette:
Click the **Format** Button. This will cause all areas to be formatted regardless of the items checked under Transfer Area.

6-5-4 Memory Cassette Data Transfer Function

Writing from the CPU Unit to the Memory Cassette


The CX-Programmer's Memory Cassette function can be used to write data from the CPU Unit to the Memory Cassette. The data to be written can be individually specified.



- When creating a Memory Cassette for a device version upgrade, select and save only the required data (such as the user program and DM).
- When creating a Memory Cassette for backup or duplication, save all of the data to the Memory Cassette.

CPU Unit and Memory Cassette Verification

When using the CX-Programmer's Memory Cassette function to store data in the Memory Cassette, verify that data by comparing it to the data in the CPU Unit.



This function can be used for operations such as confirmation after data has been written to the Memory Cassette, or confirming that the data in the backup matches the data in the CPU Unit.


Automatic Transfer from the Memory Cassette at Startup

With just a simple DIP switch setting, data stored in advance in the Memory Cassette can be automatically read when the power is turned ON, and written to the corresponding areas in the CPU Unit.


Mount a Memory Card and set DIP switch pin SW2 to ON, and then turn the power OFF and back ON.

All valid data in the Memory Card will be automatically transferred to the CPU Unit.

Note When this function is executed, at least the user program must be stored on the Memory Cassette.




This function can be used to copy data to another CPU Unit without using the CX-Programmer.



User programs can be overwritten to upgrade equipment versions without using the CX-Programmer.

Reading Data from the Memory Cassette to the CPU Unit


The CX-Programmer's Memory Cassette function can be used to read data stored on the Memory Cassette, and transfer it to the corresponding areas in the CPU Unit. The data to be read can be individually specified.



This function can be used for operations such as writing the required backup data to the CPU Unit for maintenance.

Precautions when Using the Memory Cassette Data Transfer Function

- In order for Memory Cassette data to be transferred, the Memory Cassette must be mounted in the CPU Unit.
- The BKUP indicator lights while a Memory Cassette data transfer or verification is in progress. At the same time, the remaining amount of data to be transferred or verified is displayed as a percentage in the 7-segment LED. (When the transfer or is completed, **99** flashes for 5 seconds and then the display is cleared. If the data transfer fails, **Er** flashes for 5 seconds and then the display is cleared.



While the BKUP and 7-segment LED indicators are flashing, 1) do not turn OFF the power supply to the PLC and 2) do not remove the Memory Cassette. If either of these is done, in the worst case it may make the Memory Cassette unusable.

- Memory Cassette data transfers and verification are possible only when the CPU Unit operating mode is PROGRAM mode. The Memory Cassette transfer function cannot be used in either RUN or MONITOR mode.
- The operating mode cannot be switched from PROGRAM mode to RUN or MONITOR mode while a Memory Cassette data transfer or verification is in progress.


- For XA CPU Units, the built-in analog output control is temporarily stopped while a Memory Cassette data transfer or verification is in progress. Therefore, if the IOM Hold Bit (A500.12) is ON and the externally transmitted analog output value is being held when the operating mode is switched from RUN or MONITOR to PROGRAM and a Memory Cassette data transfer or verification is executed, the analog output value cannot be held during the transfer or verification and the value will be changed. When the transfer or verification has been completed, the analog output value will revert to the originally held value.
- The following table shows whether data transfers are enabled when the CPU Unit is protected in various ways.

Type of protection	Transfer from CPU Unit to Memory Cassette	Transfer from Memory Cassette to CPU Unit
Not protected.	Yes	Yes
System protected by DIP switch pin SW1 set to ON.	Yes	No
Protected by password. Overwriting and duplication both permitted.	Yes	Yes
Protected by password. Overwriting prohibited and duplication permitted.	Yes	Transfer enabled only at startup.
Protected by password. Overwriting permitted and duplication prohibited.	No	Yes
Protected by password. Overwriting and duplication both prohibited.	No	Transfer enabled only at startup.

Note A program file that has extended passwords cannot be automatically transferred at startup to a CPU Unit that does not support extended passwords.

(1) CPU Units That Do Not Support Extended Passwords


- CP1H CPU Units, unit versions 1.2 and earlier



6-5-5 Procedure for Automatic Transfer from the Memory Cassette at Startup

Use the following procedure to enable automatic transfer at startup.

- 1,2,3...**
1. Prepare a Memory Cassette with the required data stored.
 2. With the power supply turned OFF to the CPU Unit, remove the cover from the Memory Cassette slot and insert the Memory Cassette.
 3. Open the cover for the CPU Unit's PERIPHERAL section and set DIP switch pin SW2 to ON.



4. Turn ON the power supply to the CPU Unit.
5. The automatic transfer from the Memory Cassette will begin, and the progress of the transfer will be displayed at the 7-segment LED indicator.
6. After the automatic transfer has been completed, turn OFF the power supply to the CPU Unit.
7. Remove the Memory Cassette, and replace the Memory Cassette slot cover.
8. Return the setting of DIP switch pin SW2 to OFF, and close the cover.
9. Turn the power supply to the CPU Unit back ON.

Note After the automatic transfer from the Memory Cassette at startup has been completed, the transfer will not start again automatically (regardless of the Startup Mode setting in the PLC Setup). As described in the procedure above, to start operation turn the power supply OFF, return the setting of DIP switch SW2 to OFF, and then turn the power supply back ON.

6-6 Program Protection

The following protection functions are supported by the CP1H CPU Units.

- Read protection from the CX-Programmer
- Write protection using a DIP switch setting
- Write protection setting from the CX-Programmer
- Write protection against FINS commands sent to the CPU Unit via networks

6-6-1 Read Protection

Overview

It is possible to read-protect individual program tasks (called task read protection) or the entire user program (called UM read protection).

Read protection prevents anyone from displaying or editing the read-protected set of tasks or entire user program from CX-Programmer without inputting the correct password. If the password is input incorrectly five times consecutively, password input will be disabled for two hours, providing even better security for PLC data.

Read Protection Using Extended Passwords

With unit version 1.3 or later and CX-Programmer version 9.6 or higher, you can extend protection with UM read protection and task read protection to ensure better protection for your design assets.


Operating Procedure

Setting Protection


Register a password either online or offline.

1,2,3...

1. Select the PLC name, then select **View - Properties**.
2. Click the *Protection* Tab in the PLC Properties Dialog Box and enter the passwords.



With unit version 1.3 or later and CX-Programmer version 9.6 or higher, you can use longer passwords for UM read protection and task read protection. Click the *Protection* Tab in the PLC Properties Dialog Box and enter the passwords.




The limits to the password text string lengths are given in the following table.

Unit version	Number of input characters	Type of input characters
Unit version 1.2 or earlier	8 characters max.	Alphanumeric characters
Unit version 1.3 or later	16 characters max.	


Protection Release Procedure

- 1,2,3... 1. Go online and select **PLC - Protection - Release Password**. The following Release Read Protection Dialog Box will be displayed.




2. Input the password. If the password is incorrect, one of the following messages will be displayed and protection will not be released.

UM Read Protection



Task Read Protection



3. If an incorrect password is input five times consecutively, read protection will not be released even if the correct password is input on the sixth attempt and displaying and editing the entire user program or the specified tasks will be disabled for two hours.


Read Protection for Individual Tasks Using Passwords

Overview

It is possible to read-protect individual program tasks (referred to as “task read protection” below) or the entire PLC. The same password controls access to all of the read-protected tasks.


Task read protection prevents anyone from displaying or editing the read-protected set of tasks from CX-Programmer without inputting the correct password. In this case, the entire program can be uploaded, but the read-protected tasks cannot be displayed or edited without inputting the correct password. Tasks that are not read-protected can be displayed, edited, or modified with online editing.

Note Task read protection cannot be set if UM read protection is already set. However, it is possible to set UM read protection after task read protection has been set.




Operating Procedure

- 1,2,3...** 1. Right-click the tasks that will be password-protected, select **Properties** from the pop-up menu, and select the *Task read protect* Option on the *Program Protection* Tab Page.



2. Display the *Protection* Tab of the PLC Properties Dialog Box and register a password in the *Task read protection* Box.




3. Connect online and select **PLC - Transfer - To PLC** to transfer the program. The tasks registered in step 2 will be password-protected.

Note The program can be transferred after step 1, above, and then password protection be set by selecting **PLC - Protection - Set Password**. The tasks registered in step 1 will be password-protected.

Usage

Apply read protection to tasks when you want to convert those task programs to "black box" programs.



- Note**
1. If the CX-Programmer is used to read a task with task read protection applied, an error will occur and the task will not be read. Likewise, if the PT Ladder Monitor function is used to read a password protected task, an error will occur and the task will not be read.
 2. The entire program can be transferred to another CPU Unit even if individual tasks in the program are read-protected. The task read protection will remain in effective for the password-protected tasks.
 3. When the CX-Programmer is used to compare a user program in the computer's memory with a user program in the CPU Unit, password-protected tasks will be compared too.

Restrictions to Function Block Use

Function block definitions can be read even if the entire program or individual tasks in a program containing function blocks are read-protected.

Auxiliary Area Flags and Bits Related to Password Protection

Name	Bit address	Description
UM Read Protection Flag	A99.00	Indicates whether or not the PLC (the entire user program) is read-protected. OFF: UM read protection is not set. ON: UM read protection is set.
Task Read Protection Flag	A99.01	Indicates whether or not selected program tasks are read-protected. OFF: Task read protection is not set. ON: Task read protection is set.
Program Write Protection for Read Protection	A99.02	Indicates whether or not the write protection option has been selected to prevent overwriting of password-protected tasks or programs. OFF: Overwriting allowed ON: Overwriting prohibited (write-protected)
Enable/Disable Bit for Program Backup	A99.03	Indicates whether or not a backup program file (.OBJ file) can be created when UM read protection or task read protection is set. OFF: Creation of backup program file allowed ON: Creation of backup program file prohibited

6-6-2 Write Protection

Write-protection Using the DIP Switch

The user program can be write-protected by turning ON pin 1 of the CPU Unit's DIP switch. When this pin is ON, it won't be possible to change the user program or parameter area (e.g., PLC Setup and routing tables) from the CX-Programmer. This function can prevent the program from being overwritten inadvertently at the work site.

It is still possible to read and display the program from the CX-Programmer when it is write-protected.

CPU Unit DIP Switch

Pin	Name	Settings
SW1	User Program Memory Write Protection	ON: Protected OFF: Not protected

Confirming the User Program Date


The dates the program and parameters were created can be confirmed by checking the contents of A90 to A97.

Auxiliary Area Words

Name	Address	Description
User Program Date	A90 to A93	The time and date the user program was last overwritten in memory is given in BCD.
		A90.00 to A90.07 Seconds (00 to 59 BCD)
		A90.08 to A90.15 Minutes (00 to 59 BCD)
		A91.00 to A91.07 Hour (00 to 23 BCD)
		A91.08 to A91.15 Day of month (01 to 31 BCD)
		A92.00 to A92.07 Month (01 to 12 BCD)
		A92.08 to A92.15 Year (00 to 99 BCD)
		A93.00 to A93.07 Day (00 to 06 BCD) Day of the week: 00: Sunday, 01: Monday, 02: Tuesday, 03: Wednesday, 04: Thursday, 05: Friday, 06: Saturday
Parameter Date	A94 to A97	The time and date the parameters were last overwritten in memory is given in BCD. The format is the same as that for the User Program Date given above.

Write-protection Using Passwords


The program (or selected tasks) can also be write-protected if the write protection option is selected from the CX-Programmer when a password is being registered for the entire program or those selected tasks. The write protection setting can prevent unauthorized or accidental overwriting of the program.



- Note**
1. If the selected tasks are write-protected by selecting this option when registering a password, only the tasks (program) that are password-protected will be protected from overwriting. It will still be possible to overwrite other tasks with operations such as online editing and task downloading.
 2. All tasks (programs) can be overwritten when program read protection is not enabled.

Operating Procedure

- 1,2,3... 1. When registering a password in the *UM read protection password* Box or *Task read protection* Box, select the *Prohibit from overwriting to a protected program* Option.



2. Either select **PLC - Transfer - To PLC** to transfer the program or select **PLC - Protection - Set Password** and click the **OK** button.

Note The setting to enable/disable creating file memory program files will not take effect unless the program is transferred to the CPU Unit. Always transfer the program after changing this setting.

Write Protection against FINS Commands Sent to the CPU Unit via Networks

It is possible to prohibit write operations and other editing operations sent to the PLC's CPU Unit as FINS commands through a network (including write operations from CX-Programmer, CX-Protocol, CX-Process, and other applications using Fins Gateway). Read processes are not prohibited.

FINS write protection can disable write processes such as downloading the user program, PLC Setup, or I/O memory, changing the operating mode, and performing online editing.


It is possible to exclude selected nodes from write protection so that data can be written from those nodes.

An event log in the CPU Unit automatically records all write processes sent through the network and that log can be read with a FINS command.

6-6-3 Protecting Program Execution Using the Lot Number

The lot number is stored in A310 and A311 and can be used to prevent the program from being executed on a CPU Unit with the wrong lot number. The lot number stored in A310 and A311 cannot be changed by the user.

The upper digits of the lot number are stored in A311 and the lower digits are stored in A310, as shown below.




X, Y, and Z in the lot number are converted to 10, 11, and 12, respectively, in A310 and A311. Some examples are given below.

Lot number	A311	A310
01805	0005	0801
30Y05	0005	1130


Application Examples

The following instructions can be added to the program to create a fatal error and thus prevent program execution if an attempt is made to execute the program on a CPU Unit with the incorrect lot number. A password can also be set to read-protect the program so that it cannot be copied, e.g., using a Memory Cassette.


- The following instructions will create a fatal error to prevent the program from being executed when the lot number is not 23905.



- The following instructions will create a fatal error to prevent the program from being executed when the lot number does not end in 05.



- The following instructions will create a fatal error to prevent the program from being executed when the lot number does not begin with 23Y.



6-7 Failure Diagnosis Functions

This section introduces the following functions.

- Failure Alarm Instructions: FAL(006) and FALS(007)
- Failure Point Detection: FPD(269)
- Output OFF Bit


6-7-1 Failure Alarm Instructions: FAL(006) and FALS(007)

The FAL(006) and FALS(007) instructions generate user-defined errors. FAL(006) generates a non-fatal error that allows program execution to continue and FALS(007) generates a fatal error that stops program execution.

When the user-defined error conditions (i.e., the execution conditions for FAL(006) or FALS(007)) are met, the instruction will be executed and the following processing will be performed.

- 1,2,3...**
1. The FAL Error Flag (A402.15) or FALS Error Flag (A401.06) is turned ON.
 2. The corresponding error code is written to A400.
 3. The error code and time of occurrence are stored in the Error Log.
 4. The error indicator on the front of the CPU Unit will flash or light.
 5. If FAL(006) has been executed, the CPU Unit will continue operating.
If FALS(007) has been executed, the CPU Unit will stop operating. (Program execution will stop.)

Operation of FAL(006)



When execution condition A goes ON, an error with FAL number 002 is generated, A402.15 (FAL Error Flag) is turned ON, and A360.02 (FAL Number 002 Flag) is turned ON. Program execution continues.

Errors generated by FAL(006) can be cleared by executing FAL(006) with FAL number 00 or performing the error read/clear operation from the CX-Programmer.

Operation of FALS(007)



When execution condition B goes ON, an error with FALS number 003 is generated, and A401.06 (FALS Error Flag) is turned ON. Program execution is stopped.

Errors generated by FAL(006) can be cleared by eliminating the cause of the error and performing the error read/clear operation from the CX-Programmer.

6-7-2 Failure Point Detection: FPD(269)

FPD(269) performs time monitoring and logic diagnosis. The time monitoring function generates a non-fatal error if the diagnostic output isn't turned ON within the specified monitoring time. The logic diagnosis function indicates which input is preventing the diagnostic output from being turned ON.

Time Monitoring Function

FPD(269) starts timing when it is executed and turns ON the Carry Flag if the diagnostic output isn't turned ON within the specified monitoring time. The

Carry Flag can be programmed as the execution condition for an error processing block. Also, FPD(269) can be programmed to generate a non-fatal FAL error with the desired FAL number.

When an FAL error is generated, a preset message will be registered and can be displayed on the CX-Programmer. FPD(269) can be set to output the results of logic diagnosis (the address of the bit preventing the diagnostic output from being turned ON) just before the message.


The teaching function can be used to automatically determine the actual time required for the diagnostic output to go ON and set the monitoring time.

Logic Diagnosis Function

FPD(269) determines which input bit is causing the diagnostic output to remain OFF and outputs the result. The output can be set to bit address output (PLC memory address) or message output (ASCII).

If bit address output is selected, the PLC memory address of the bit can be transferred to an Index Register and the Index Register can be indirectly addressed in later processing.

If the message output is selected, an error message can be displayed on the CX-Programmer at the same time as a FAL error is generated for time monitoring.



Time Monitoring

Monitors whether output C goes ON with 10 seconds after input A. If C doesn't go ON within 10 seconds, a failure is detected and the Carry Flag is turned ON. The Carry Flag executes the error-processing block. Also, an FAL error (non-fatal error) with FAL number 004 is generated.

Logic Diagnosis

FPD(269) determines which input bit in block B is preventing output C from going ON. That bit address is output to D1000 and D1001.

Auxiliary Area Flags and Words

Name	Address	Operation
Error Code	A400	When an error occurs, the error code is stored in A400.
FAL Error Flag	A402.15	Turns ON when FAL(006) is executed.
FALS Error Flag	A401.06	Turns ON when FALS(007) is executed.
Executed FAL Number Flags	A360 to A391	The corresponding flag turns ON when an FAL(006) error occurs.
Error Log Area	A100 to A199	The Error Log Area contains information on the most recent 20 errors.

Name	Address	Operation
Error Log Pointer	A300	When an error occurs, the Error Log Pointer is incremented by 1 to indicate where the next error record will be recorded as an offset from the beginning of the Error Log Area (A100).
Error Log Pointer Reset Bit	A500.14	Turn this bit ON to reset the Error Log Pointer (A300) to 00.
FPD Teaching Bit	A598.00	Turn this bit ON when you want the monitoring time to be set automatically when FPD(269) is executed.

6-7-3 Simulating System Errors

FAL(006) and FALS(007) can be used to intentionally create fatal and non-fatal system errors. This can be used in system debugging to test display messages on Programmable Terminals (PTs) or other operator interfaces.

Use the following procedure.


- 1,2,3...**
1. Set the FAL or FALS number to use for simulation in A529. A529 is used when simulating errors for both FAL(006) and FALS(007).
 2. Set the FAL or FALS number to use for simulation as the first operand of FAL(006) or FALS(007).
 3. Set the error code and error to be simulated as the second operand (two words) of FAL(006) or FALS(007). Indicate a nonfatal error for FAL(006) and a fatal error for FALS(007).

To simulate more than one system error, use more than one FAL(006) or FALS(007) instruction with the same value in A529 and different values for the second operand.

Auxiliary Area Flags and Words

Name	Address	Operation
FAL/FALS Number for System Error Simulation	A529	Set a dummy FAL/FALS number to use to simulate a system error. 0001 to 01FF hex: FAL/FALS numbers 1 to 511 0000 or 0200 to FFFF hex: No FAL/FALS number for system error simulation.

Example for a Battery Error



Note Use the same methods as for actual system errors to clear the simulated system errors. Refer to the *11-2 Troubleshooting* for details. All system errors simulated with FAL(006) and FALS(007) can be cleared by cycling the power supply.

6-7-4 Output OFF Bit

As an emergency measure when an error occurs, all outputs from Output Units can be turned OFF by turning ON the Output OFF Bit (A500.15). The operating mode will remain in RUN or MONITOR mode, but all outputs will be turned OFF.

Note Normally (when IOM Hold Bit = OFF), all outputs from Output Units are turned OFF when the operating mode is changed from RUN/MONITOR mode to PROGRAM mode. The Output OFF Bit can be used to turn OFF all outputs without switching to PROGRAM mode.

6-8 Clock

A clock is built into the CP1H CPU Unit and is backed up by a battery. The current data is stored in the following words and refreshed each cycle.

Name	Addresses	Function
Clock data: A351 to A354	A351.00 to A351.07	Second: 00 to 59 (BCD)
	A351.08 to A351.15	Minute: 00 to 59 (BCD)
	A352.00 to A352.07	Hour: 00 to 23 (BCD)
	A352.08 to A352.15	Day of the month: 00 to 31 (BCD)
	A353.00 to A353.07	Month: 00 to 12 (BCD)
	A353.08 to A353.15	Year: 00 to 99 (BCD)
	A354.00 to A354.07	Day of the week: 00: Sunday, 01: Monday, 02: Tuesday, 03: Wednesday, 04: Thursday, 05: Friday, 06: Saturday

Note The clock cannot be used if a battery is not installed or the battery voltage is low.

Auxiliary Area Flags and Words

Name	Addresses	Contents
Start-up Time	A510 and A511	The time at which the power was turned ON (year, month, day of month, hour, minutes, and seconds).
Power Interruption Time	A512 and A513	The time at which the power was last interrupted (year, month, day of month, hour, minutes, and seconds).
Power ON Clock Data 1	A720 to A722	Consecutive times at which the power was turned ON (year, month, day of month, hour, minutes, and seconds). The times are progressively older from number 1 to number 10.
Power ON Clock Data 2	A723 to A725	
Power ON Clock Data 3	A726 to A728	
Power ON Clock Data 4	A729 to A731	
Power ON Clock Data 5	A732 to A734	
Power ON Clock Data 6	A735 to A737	
Power ON Clock Data 7	A738 to A740	
Power ON Clock Data 8	A741 to A743	
Power ON Clock Data 9	A744 to A746	
Power ON Clock Data 10	A747 to A749	
Operation Start Time	A515 to A517	The time that operation started (year, month, day of month, hour, minutes, and seconds).
Operation End Time	A518 to A520	The time that operation stopped (year, month, day of month, hour, minutes, and seconds).
User Program Date	A090 to A093	The time when the user program was last overwritten (year, month, day of month, hour, minutes, and seconds).
Parameter Date	A094 to A097	The time when the parameters were last overwritten (year, month, day of month, hour, minutes, and seconds).

Time-related Instructions

Name	Mnemonic	Function
HOURS TO SECONDS	SEC(065)	Converts time data in hours/minutes/seconds format to an equivalent time in seconds only.
SECONDS TO HOURS	HMS(066)	Converts seconds data to an equivalent time in hours/minutes/seconds format.
CALENDAR ADD	CADD(730)	Adds time to the calendar data in the specified words.
CALENDAR SUBTRACT	CSUB(731)	Subtracts time from the calendar data in the specified words.
CLOCK ADJUSTMENT	DATE(735)	Changes the internal clock setting to the setting in the specified source words.

SECTION 7

Using CP-series Expansion Units and Expansion I/O Units

This section describes how to use CP-series Expansion Units and Expansion I/O Units.

7-1	Connecting CP-series Expansion Units and Expansion I/O Units	392
7-2	Analog Input Units	393
7-3	Analog Output Units	406
7-4	Analog I/O Units	416
7-4-1	CP1W-MAD11 Analog I/O Units	416
7-4-2	CP1W-MAD42/CP1W-MAD44 Analog I/O Units	429
7-5	Temperature Sensor Units	446
7-5-1	CP1W-TS□01/TS□02 Temperature Sensor Units	446
7-5-2	CP1W-TS003 Temperature Sensor Units	460
7-5-3	CP1W-TS004 Temperature Sensor Units	469
7-6	CompoBus/S I/O Link Units	480

7-1 Connecting CP-series Expansion Units and Expansion I/O Units

CP-series Expansion Units and Expansion I/O Units can be connected to the CP1H. The combined maximum number of Expansion Units and Expansion I/O Units that can be connected is seven. CP1W-AD041/AD042 Analog Input Units, CP1W-DA041/DA042 Analog Output Units, CP1W-MAD42/MAD44 Analog I/O Units, and CP1W-TS002/TS102/TS003 Temperature Sensor Units are allocated four words in the I/O area, however, so when any of these Units is included, the total number of Expansion Units and Expansion I/O Units must be reduced.

Number of I/O Words


Unit name		Model	Current consumption (mA)		I/O words	
			5 VDC	24 VDC	Input	Output
Expansion Units	Analog Input Unit	CP1W-AD041	100	90	4	2
		CP1W-AD042	100	50	4	2
	Analog Output Unit	CP1W-DA021	40	95	---	2
		CP1W-DA041	80	124	---	4
		CP1W-DA042	70	160	---	4
	Analog I/O Unit	CP1W-MAD11	83	110	2	1
		CP1W-MAD42	120	120	4	2
		CP1W-MAD44	120	170	4	4
	Temperature Control Unit	CP1W-TS001	40	59	2	---
		CP1W-TS101	54	73		
		CP1W-TS002	40	59	4	---
		CP1W-TS102	54	73		
		CP1W-TS003	70	30	4	---
		CP1W-TS004	80	50	2	1
	CompoBus/S I/O Link Unit	CP1W-SRT21	29	---	1	1
Expansion I/O Units	40-point I/O Unit	CP1W-40EDR	80	90	2	2
		CP1W-40EDT	160	---		
		CP1W-40EDT1	160	---		
	32-point Output Unit	CP1W-32ER	49	131	---	2
		CP1W-32ET	113	---		
		CP1W-32ET1	113	---		
	20-point I/O Unit	CP1W-20EDR1	103	44	1	1
		CP1W-20EDT	130	---		
		CP1W-20EDT1	130	---		
	16-point Output Unit	CP1W-16ER	42	90	---	2
		CP1W-16ET	76	---		
		CP1W-16ET1	76	---		
	8-point Input Unit	CP1W-8ED	18	---	1	---
	8-point Output Unit	CP1W-8ER	26	44	---	1
		CP1W-8ET	75	---		
		CP1W-8ET1	75	---		

Note CP1W-32ER/32ET/32ET1's maximum number of simultaneously ON points is 24 (75%).

- Up to 15 words can be used by Expansion Units and Expansion I/O Units for inputs and up to 15 words can be used for outputs.
- Be careful not to exceed a total current consumption of 2 A at 5 V or 1 A at 24 V, or a total power consumption of 30W, for the Expansion Units and Expansion I/O Units (including the CPU Unit).

Allocation of I/O Words

Expansion Units and Expansion I/O Units are allocated I/O words in the order the Units are connected starting from the CPU Unit. The required number of I/O words is allocated to each Unit starting with CIO 2 for inputs and CIO 102 for outputs.



Input words CIO 0 and CIO 1, and output words CIO 100 and CIO 101 are always allocated to the CPU Unit.

Connected Units: 7 max.

Total input words: 15 max.

Total output words: 15 max.

Total combined current consumption including CPU Unit: 2 A max. for 5 V and 1 A max. for 24 V
(Total power consumption: 30 W max.)


7-2 Analog Input Units

Each CP1W-AD041/CP1W-AD042 Analog Input Unit provides four analog inputs.

- The analog input signal ranges are 0 to 5 V, 1 to 5 V, 0 to 10 V, -10 to +10 V, 0 to 20 mA, and 4 to 20 mA.
The resolution of CP1W-AD041 is 1/6,000.
The resolution of CP1W-AD042 is 1/12,000.
The open-circuit detection function is activated in the ranges of 1 to 5 V and 4 to 20 mA.
- The Analog Input Unit uses four input words and two output words, so a maximum of three Units can be connected.


Part Names

CP1W-AD041/CP1W-AD042



1. Analog Input Terminals
Connected to analog output devices.

■ Input Terminal Arrangement



V IN1	Voltage input 1
I IN1	Current input 1
COM1	Input common 1
V IN2	Voltage input 2
I IN2	Current input 2
COM2	Input common 2
V IN3	Voltage input 3
I IN3	Current input 3
COM3	Input common 3
V IN4	Voltage input 4
I IN4	Current input 4
COM4	Input common 4

- Note

When using current inputs, voltage input terminals must be short-circuited with current input terminals.
2.

Expansion I/O Connecting Cable

Connected to the CPU Unit or Expansion Unit expansion connector. The cable is attached to the Analog Input Unit and cannot be removed.
- Note

Do not touch the cables during operation. Static electricity may cause operating errors.
3.


Expansion Connector

Connected to the next Expansion Unit or Expansion I/O Unit to enable expansion.

Main Analog Input Unit Specifications

A maximum of seven Units can be connected, including other Expansion Units and Expansion I/O Units.

But a maximum of three Analog Input Units can be connected, because each unit is allocated four words.



Item		CP1W-AD041		CP1W-AD042	
		Voltage Input	Current Input	Voltage Input	Current Input
Number of inputs		4 inputs (4 words allocated)			
Input signal range		0 to 5 VDC, 1 to 5 VDC, 0 to 10 VDC, or -10 to 10 VDC	0 to 20 mA or 4 to 20 mA	0 to 5 VDC, 1 to 5 VDC, 0 to 10 VDC, or -10 to 10 VDC	0 to 20 mA or 4 to 20 mA
Max. rated input		±15 V	±30 mA	±15 V	±30 mA
External input impedance		1 MΩ min.	Approx. 250 Ω	1 MΩ min.	Approx. 250 Ω
Resolution		1/6000 (full scale)		1/12000 (full scale)	
Overall accuracy	25°C	0.3% full scale	0.4% full scale	0.2% full scale	0.3% full scale
	0 to 55°C	0.6% full scale	0.8% full scale	0.5% full scale	0.7% full scale
A/D conversion data		16-bit binary (4-digit hexadecimal) Full scale for -10 to 10 V: F448 to 0BB8 Hex Full scale for other ranges: 0000 to 1770 Hex		16-bit binary (4-digit hexadecimal) Full scale for -10 to 10 V: E890 to 1770 Hex Full scale for other ranges: 0000 to 2EE0 Hex	
Averaging function		Supported (Set in output words n+1 and n+2.)			
Open-circuit detection function		Supported			
Conversion time		2 ms/point (8 ms/all points)		1 ms/point (4 ms/all points)	
Isolation method		Photocoupler isolation between analog I/O terminals and internal circuits. No isolation between analog I/O signals.			
Current consumption		5 VDC: 100 mA max.; 24 VDC: 90 mA max.		5 VDC: 100 mA max.; 24 VDC: 50 mA max.	

Analog Input Signal Ranges

Analog input data is digitally converted according to the input signal range as shown below.


Note When the input exceeds the specified range, the A/D conversion data will be fixed at either the lower limit or upper limit.

Analog Input Signal Ranges

■ -10 to 10 V Inputs


When the resolution is 1/6,000, the -10 to 10 V range corresponds to hexadecimal values F448 to 0BB8 (-3,000 to 3,000). The range of data that can be converted is F31C to 0CE4 hex (-3,300 to 3,300).

A negative voltage is expressed as two's complement.



When the resolution is 1/12,000, the -10 to 10 V range corresponds to hexadecimal values E890 to 1770 (-6,000 to 6,000). The entire data range is E638 to 19C8 hex (-6,600 to 6,600).


A negative voltage is expressed as a two's complement.



■ 0 to 10 V Inputs


When the resolution is 1/6,000, the 0 to 10 V range corresponds to hexadecimal values 0000 to 1770 (0 to 6,000). The range of data that can be converted is FED4 to 189C hex (–300 to 6,300).

A negative voltage is expressed as two's complement.



When the resolution is 1/12,000, the 0 to 10 V range corresponds to hexadecimal values 0000 to 2EE0 (0 to 12,000). The entire data range is FDA8 to 3138 hex (–600 to 12,600).


A negative voltage is expressed as a two's complement.



■ 0 to 5 V Inputs


When the resolution is 1/6,000, the 0 to 5 V range corresponds to hexadecimal values 0000 to 1770 (0 to 6,000). The range of data that can be converted is FED4 to 189C hex (–300 to 6,300).

A negative voltage is expressed as two's complement.



When the resolution is 1/12,000, the 0 to 5 V range corresponds to hexadecimal values 0000 to 2EE0 (0 to 12,000). The entire data range is FDA8 to 3138 hex (–600 to 12,600).

A negative voltage is expressed as a two's complement.




■ 1 to 5 V Inputs

When the resolution is 1/6,000, the 1 to 5 V range corresponds to hexadecimal values 0000 to 1770 (0 to 6,000). The range of data that can be converted is FED4 to 189C hex (–300 to 6,300).

Voltage in the range of 0.8 to 1 V is expressed as two's complement.


If an input is below the range (i.e., less than 0.8 V), the open-circuit detection function is activated and the data becomes 8,000.



When the resolution is 1/12,000, the 1 to 5 V range corresponds to hexadecimal values 0000 to 2EE0 (0 to 12,000). The entire data range is FDA8 to 3138 hex (–600 to 12,600).

Voltage in the range of 0.8 to 1 V is expressed as two's complement.


If an input is below the range (i.e., less than 0.8 V), the open-circuit detection function is activated and the data becomes 8,000.



■ 0 to 20 mA Inputs


When the resolution is 1/6,000, the 0 to 20 mA range corresponds to hexadecimal values 0000 to 1770 (0 to 6,000). The range of data that can be converted is FED4 to 189C hex (–300 to 6,300).

A negative current is expressed as two's complement.



When the resolution is 1/12,000, the 0 to 20 mA range corresponds to hexadecimal values 0000 to 2EE0 (0 to 12,000). The entire data range is FDA8 to 3138 hex (–600 to 12,600).

A negative current is expressed as a two's complement.




■ 4 to 20 mA Inputs

When the resolution is 1/6,000, the 4 to 20 mA range corresponds to hexadecimal values 0000 to 1770 (0 to 6,000). The range of data that can be converted is FED4 to 189C hex (–300 to 6,300).

Current in the range of 3.2 to 4 mA is expressed as two's complement.


If an input is below the range (i.e., less than 3.2 mA), the open-circuit detection function is activated and the data becomes 8,000.



When the resolution is 1/12,000, the 4 to 20 mA range corresponds to hexadecimal values 0000 to 2EE0 (0 to 12,000). The entire data range is FDA8 to 3138 hex (–600 to 12,600).

Current in the range of 3.2 to 4 mA is expressed as two's complement.

If an input is below the range (i.e., less than 3.2 mA), the open-circuit detection function is activated and the data becomes 8,000.



Averaging Function

For analog inputs, the averaging function operates when the averaging bit is set to 1. The averaging function outputs the average (a moving average) of the last eight input values as the converted value. If there is only a slight variation in inputs, it is handled by the averaging function as a smooth input.


The averaging function stores the average (a moving average) of the last eight input values as the converted value. Use this function to smooth inputs that vary at a short interval.

Open-circuit Detection Function

The open-circuit detection function is activated when the input range is set to 1 to 5 V and the voltage drops below 0.8 V, or when the input range is set to 4 to 20 mA and the current drops below 3.2 mA. When the open-circuit detection function is activated, the converted data will be set to 8,000.


The time for enabling or clearing the open-circuit detection function is the same as the time for converting the data. If the input returns to the convertible range, the open-circuit detection is cleared automatically and the output returns to the normal range.

Procedure




- Connect Analog Input Units.
- Wire to analog output devices.
- Write set data to output words (n+1, n+2).
 - Set use of inputs.
 - Select input signals using range codes.
 - Set use of averaging.
- Read A/D converted values from input words (m+1 to m+4).
- For current inputs, confirm that there is no open circuit.

Writing Set Data and Reading A/D Converted Values




1. Connecting the Analog Input Unit

Connect the Analog Input Unit to the CPU Unit.





2. Wiring Analog Inputs

Internal Circuits




■ Wiring for Analog Inputs



Note

- (1) Connect the shield to the FG terminal to prevent noise.
- (2) When an input is not being used, short the + and – terminals.
- (3) Separate wiring from power lines (AC power supply lines, high-voltage lines, etc.)
- (4) When there is noise in the power supply line, install a noise filter on the input section and the power supply.
- (5) Refer to the following information on open circuits when using voltage inputs.



For example, if analog input device 2 is outputting 5 V and the same power supply is being used as shown above, about 1/3, or 1.6 V, will be applied at the input for input device 1.


Consider the following information on open input circuits when using voltage inputs. Either use separate power supplies, or install an isolator at each input.

If the same power supply is used as shown in the following diagram and an open circuit occurs at point A or B, an unwanted current flow will occur as shown by the dotted lines in the diagram, creating a voltage at the other input of about 1/3 to 1/2. If the 1 to 5 V range is being used, the open-circuit detection function will not operate. Also, if there is an open circuit at C, the open-circuit detection function will not operate because the negative sides are the same.

3. Creating the Ladder Program


Allocating I/O Words

Four input words and two output words are allocated from the next words following the last I/O words allocated to the CPU Unit or an existing Expansion Unit or Expansion I/O Unit.




Writing Set Data

Write the settings for input use, averaging use, and range codes for words $n+1$ and $n+2$. When the set data is transferred from the CPU Unit to the Analog I/O Unit, the A/D conversion will be started.



■ Set Data



- The Analog Input Unit will not start converting analog input values until the set data has been written.
- Once the range code has been set, it is not possible to be changed while power is being supplied to the CPU Unit. To change the range code, turn the CPU Unit OFF then ON again.

Averaging

Set whether averaging is to be used for set data. When the averaging bit is set to 1, the average (moving average) for the past eight inputs is output as conversion data.


Reading Analog Input Conversion Values

Read the conversion value storage area with the ladder program. With word m as the last input word allocated to the CPU Unit or an already-connected Expansion Unit, the A/D conversion data will be output to the following words m+1 to m+4.

Startup Operation

After the power is turned ON, it will require two cycle times plus approximately 50 ms before the first conversion data is stored in the input words. Therefore, create a program as shown below, so that the ladder can start to operate with valid conversion data in input words.

The analog input data will be 0000 until the first conversion data is stored in the input words.




TIM0005 is started when the power is turned ON. After 0.2 s (200 ms) elapses, the TIM0005 contact turns ON and the analog input 1 conversion data stored in word 2 is transferred to D0.

Handling Unit Errors

- When an error occurs in an Analog Input Unit, the analog input conversion data becomes 0000.
- CP-series Expansion Unit errors are output to bits 0 to 6 of word A436. The bits are allocated from A436.00 in order starting with the Unit nearest the CPU Unit. Use these flags in the program when it is necessary to detect errors.


Ladder Program Example

Analog input	Input range	Range code	Averaging	Set data	Destination word
Input 1	0 to 10 V	01	Yes	1101 (D hex)	n+1
Input 2	4 to 20 mA	10	Yes	1110 (E hex)	n+1
Input 3	-10 to +10 V	00	No	1000 (8 hex)	n+2
Input 4	Not used.	-(00)	---	0000 (0 hex)	n+2



■ **Example:Scaling analog input values**


When a 0 to 10V voltage is input to the analog input word (CIO 3) of CP1W-AD042 as 0 to 12,000, convert the value into a value between 0 and 24,000 and output the result to D200.




Data Memory Settings

Setting	Address	Data
Control word	D100	#0800
Unscaled minimum value (0)	D101	&0
Scaled minimum value (0)	D102	&0
Unscaled maximum value (12,000)	D103	&12,000
Scaled maximum value (24,000)	D104	&24,000

Ladder Program




Descriptions of APR Instruction



C: Control word
Set for "Signed Integer Data (Binary)".

Control word setting
#0800: Binary numeral (0000 1000 0000 0000)



Setting	Address	Data
Control word	C	#0800
Unscaled minimum value (X_0)	C+1	X_0
Scaled minimum value (Y_0)	C+2	Y_0
Unscaled maximum value ($X_m = X_1$)	C+3	X_1
Scaled maximum value ($Y_m = Y_1$)	C+4	Y_1

S: Source data
Specify the word address of the input data before scaling.

R: Result word
Specify the word address where the data will be output after scaling.

7-3 Analog Output Units


Each CP1W-DA021 Analog Output Unit provides two analog outputs.

Each CP1W-DA041/CP1W-DA042 Analog Output Unit provides four analog outputs.

- The analog output signal ranges are 1 to 5 V, 0 to 10 V, –10 to +10 V, 0 to 20 mA, and 4 to 20 mA.
The resolution of CP1W-DA041 is 1/6,000.
The resolution of CP1W-DA042 is 1/12,000.
- The CP1W-DA021 uses two output words, so a maximum of seven Units can be connected.
- The CP1W-DA041/CP1W-DA042 uses four output words, so a maximum of three Units can be connected.


Part Names

CP1W-DA021/CP1W-DA041/CP1W-DA042




1. Analog Output Terminals
Connected to analog input devices.

■ Output Terminal Arrangement for CP1W-DA041/CP1W-DA042



V OUT1	Voltage output 1
I OUT1	Current output 1
COM1	Output common 1
V OUT2	Voltage output 2
I OUT2	Current output 2
COM2	Output common 2
V OUT3	Voltage output 3
I OUT3	Current output 3
COM3	Output common 3
V OUT4	Voltage output 4
I OUT4	Current output 4
COM4	Output common 4

■ Output Terminal Arrangement for CP1W-DA021



V OUT1	Voltage output 1
I OUT1	Current output 1
COM1	Output common 1
V OUT2	Voltage output 2
I OUT2	Current output 2
COM2	Output common 2


2. Expansion I/O Connecting Cable
Connected to the CPU Unit or previous Expansion Unit. The cable is provided with the Unit and cannot be removed.

Note Do not touch the cables during operation. Static electricity may cause operating errors.

3. Expansion Connector
Connected to the next Expansion Unit or Expansion I/O Unit.

Main Analog Output Unit Specifications

A maximum of seven Units can be connected, including other Expansion Units and Expansion I/O Units.



Item		CP1W-DA021/CP1W-DA041		CP1W-DA042	
		Voltage Output	Current Output	Voltage Output	Current Output
Number of outputs		CP1W-DA021: 2 outputs (2 words allocated) CP1W-DA041: 4 outputs (4 words allocated)		4 outputs (4 words allocated)	
Output signal range		1 to 5 VDC, 0 to 10 VDC, or −10 to 10 VDC	0 to 20 mA or 4 to 20 mA	1 to 5 VDC, 0 to 10 VDC, or −10 to 10 VDC	0 to 20 mA or 4 to 20 mA
External output allowable load resistance		2 kΩ min.	350 Ω max.	2 kΩ min.	350 Ω max.
External output impedance		0.5 Ω max.	---	0.5 Ω max.	---
Resolution		1/6000 (full scale)		1/12000 (full scale)	
Overall accuracy	25°C	0.4% full scale		0.3% full scale	
	0 to 55°C	0.8% full scale		0.7% full scale	
D/A conversion data		16-bit binary (4-digit hexadecimal) Full scale for −10 to 10 V: F448 to 0BB8 Hex Full scale for other ranges: 0000 to 1770 Hex		16-bit binary (4-digit hexadecimal) Full scale for −10 to 10 V: E890 to 1770 Hex Full scale for other ranges: 0000 to 2EE0 Hex	
Conversion time		CP1W-DA021: 2 ms/point (4 ms/all points) CP1W-DA041: 2 ms/point (8 ms/all points)		1 ms/point (4 ms/all points)	
Isolation method		Photocoupler isolation between analog I/O terminals and internal circuits. No isolation between analog I/O signals.			
Current consumption		CP1W-DA021: 5 VDC 40 mA max.; 24 VDC 95 mA max. CP1W-DA041: 5 VDC 80 mA max.; 24 VDC 124 mA max.		5 VDC: 70 mA max.; 24 VDC: 160 mA max.	

Analog Output Signal Ranges

The analog values depend on the output signal ranges, as shown in the following diagrams.


Note When the output exceeds the specified range, the output signal will be fixed at either the lower limit or upper limit.

Analog Output Signal Ranges**■ -10 to 10 V**

When the resolution is 1/6,000, the hexadecimal values F448 to 0BB8 (–3000 to 3000) correspond to an analog voltage range of –10 to 10 V.

The entire output range is –11 to 11 V.


Specify a negative voltage as a two's complement.



When the resolution is 1/12,000, the hexadecimal values E890 to 1770 (–6000 to 6000) correspond to an analog voltage range of –10 to 10 V.

The entire output range is –11 to 11 V.


Specify a negative voltage as a two's complement.

**■ 0 to 10 V**

When the resolution is 1/6,000, the hexadecimal values 0000 to 1770 (0 to 6000) correspond to an analog voltage range of 0 to 10 V.

The entire output range is –0.5 to 10.5 V.


Specify a negative voltage as a two's complement.



When the resolution is 1/12,000, the hexadecimal values 0000 to 2EE0 (0 to 12000) correspond to an analog voltage range of 0 to 10 V.

The entire output range is -0.5 to 10.5 V.


Specify a negative voltage as a two's complement.



■ 1 to 5 V


When the resolution is 1/6,000, the hexadecimal values 0000 to 1770 (0 to 6000) correspond to an analog voltage range of 1 to 5 V.

The entire output range is 0.8 to 5.2 V.



When the resolution is 1/12,000, the hexadecimal values 0000 to 2EE0 (0 to 12000) correspond to an analog voltage range of 1 to 5 V.


The entire output range is 0.8 to 5.2 V.



■ 0 to 20 mA


When the resolution is 1/6,000, the hexadecimal values 0000 to 1770 (0 to 6000) correspond to an analog current range of 0 to 20 mA.

The entire output range is 0 to 21 mA.



When the resolution is 1/12,000, the hexadecimal values 0000 to 2EE0 (0 to 12000) correspond to an analog voltage range of 0 to 20 mA.


The entire output range is 0 to 21 mA.



■ 4 to 20 mA


When the resolution is 1/6,000, the hexadecimal values 0000 to 1770 (0 to 6000) correspond to an analog current range of 4 to 20 mA.

The entire output range is 3.2 to 20.8 mA.



When the resolution is 1/12,000, the hexadecimal values 0000 to 2EE0 (0 to 12000) correspond to an analog voltage range of 4 to 20 mA.

The entire output range is 3.2 to 20.8 mA.





Procedure

Connect and wire Units.


- Connect Analog Output Units.
- Wire to analog input devices.

Create a ladder program.

- Write set data to output words
CP1W-DA041/DA042: Words (n+1, n+2)
CP1W-DA021: Word (n+1)
 - Set use of outputs.
 - Select output signals using range codes.
- Write D/A conversion values to output words
CP1W-DA041/DA042: Words (n+1 to n+4)
CP1W-DA021: Words (n+1, n+2)

Writing Set Data and Writing D/A Conversion Data**■ CP1W-DA041/CP1W-DA042****■ CP1W-DA021****1. Connecting the Analog Output Unit**


Connect the Analog Output Unit to the CPU Unit.




2. Wiring Analog Outputs

Internal Circuits

The following diagram shows the internal circuit using CP1W-DA041/DA042 as an example, which wires analog outputs 1 to 4. In the case of CP1W-DA021, analog outputs 1 to 2 can be used.



■ Wiring for Analog Outputs




Note

- (1) Connect the shield to the FG terminal to prevent noise.
- (2) Separate wiring from power lines (AC power supply lines, high-voltage lines, etc.)
- (3) When there is noise in the power supply line, install a noise filter on the input section and the power supply.
- (4) When external power is supplied (when range codes are set), or when the power is interrupted, there may be a pulse status analog output of up to 1 ms. If this status is a problem, take the following measures.
 - Turn ON the power to the CP1H CPU Unit, check the operation status, and then turn ON the power at the load.
 - Turn OFF the power to the load and then turn OFF the power to the CP1H CPU Unit.

3. Creating the Ladder Program



Allocating Output Words

Four output words (n+1 to n+4) are allocated, beginning from the first word following the last I/O word allocated to the CPU Unit or already-connected Expansion I/O Unit or Expansion Unit. For CP1W-DA021, two output words (n+1, n+2) are allocated.



Writing Set Data

Write the output use and the range code to words $n+1$ and $n+2$. For CP1W-DA021, only word $n+1$ can be used. The D/A conversion will start when the set data is transferred from the CPU Unit to the Analog Output Unit.

**■ Set Data**

- The Analog Output Unit will not start converting analog output values until the set data has been written.
- Before the range code is written, 0 V or 0 mA will be output in the 0 to 10 V, -10 to +10 V, and 0 to 20 mA ranges, and 1 V or 4 mA will be output in the 1 to 5 V and 4 to 20 mA ranges.
- Once the range code has been set, it is not possible to be changed while power is being supplied to the CPU Unit. To change the range code, turn the CPU Unit OFF then ON again.

Writing Analog Output Conversion Values

The ladder program can be used to write conversion data to the output words. The output word starts from “ $n+1$ ” where “ n ” is the last output word allocated to the CPU Unit, or previous Expansion Unit or Expansion I/O Unit.


Startup Operation

After power is turned ON, it will require two cycle times plus approximately 50 ms before the first conversion data is output.

The following table shows the output status after the initial processing is completed.

Output type	Voltage output		Current output	
Output range	0 to 10 V, -10 to +10 V	1 to 5 V	0 to 20 mA	4 to 20 mA
Before range code is written	0 V		0 mA	
After range code is written	0 V	1 V	0 mA	4 mA

Therefore, create a program as shown below, so that when operation begins simultaneously with startup it will wait for valid set data.



TIM0005 is started when the power is turned ON. After 0.2 s (200 ms) elapses, the TIM0005 contact turns ON, and the data stored in D100 will be moved to 102 as the conversion data for analog output 1.


Handling Unit Errors

- When an error occurs at the Analog Output Unit, the analog output will be 0 V or 0 mA. If a CPU Unit fatal error occurs when analog outputs are set in the 1 to 5 V or 4 to 20 mA range, 0 V or 0 mA will be output for a CPU error I/O bus error, and 1 V or 4 mA will be output for all other errors.
- CP-series Expansion Unit errors are output to bits 0 to 6 of word A436. The bits are allocated from A436.00 in order starting with the Unit nearest the CPU Unit. Use these flags in the program when it is necessary to detect errors.

Program Example


■ CP1W-DA041/CP1W-DA042

Analog output	Output range	Range code	Set data	Destination word
Output 1	0 to 10 V	001	1001 (9 hex)	n+1
Output 2	4 to 20 mA	100	1100 (C hex)	n+1
Output 3	−10 to 10 V	000	1000 (8 hex)	n+2
Output 4	Not used.	−(000)	0000 (0 hex)	n+2



■ **Example:Scaling analog output values**


Convert a value between 200 and 500 in D300 into 2 to 5 V to output the voltage from the analog output word (CIO 102) of CP1W-DA042.



Data memory settings

Setting	Address	Data
Control word	D110	#0800
Unscaled minimum value (200)	D111	&200
Scaled minimum value (3,000)	D112	&3,000
Unscaled maximum value (500)	D113	&500
Scaled maximum value (12,000)	D114	&12,000

Ladder program



Refer to 7-2 *Example:Scaling analog input values* for the descriptions of APR instruction.

7-4 Analog I/O Units


7-4-1 CP1W-MAD11 Analog I/O Units

Each CP1W-MAD11 Analog I/O Unit provides 2 analog inputs and 1 analog output.


- The analog input range can be set to 0 to 5 VDC, 1 to 5 VDC, 0 to 10 VDC, –10 to 10 VDC, 0 to 20 mA, or 4 to 20 mA. The inputs have a resolution of 1/6000.
An open-circuit detection function is activated in the ranges of 1 to 5 VDC and 4 to 20 mA.
- The analog output range can be set to 1 to 5 VDC, 0 to 10 VDC, –10 to 10 VDC, 0 to 20 mA, or 4 to 20 mA. The outputs have a resolution of 1/6000.

Part Names

CP1W-MAD11



- (1) Analog I/O Terminals
Connected to analog I/O devices.



Note For current inputs, short V IN0 to I IN0 and V IN1 to I IN1.

V OUT	Voltage output
I OUT	Current output
COM	Output common
V IN0	Voltage input 0
I IN0	Current input 0
COM0	Input common 0
V IN1	Voltage input 1
I IN1	Current input 1
COM1	Input common 1

- (2) Expansion I/O Connecting Cable
Connected to the expansion connector of a CP1H CPU Unit or a CP-series Expansion Unit or Expansion I/O Unit. The cable is provided with the Analog I/O Unit and cannot be removed.

Caution Do not touch the cables during operation. Static electricity may cause operating errors.

- (3) Expansion Connector
Used for connecting CP-series Expansion Units or Expansion I/O Units.
- (4) DIP Switch
Used to enable or disable averaging.




Pin1: Average processing for analog input 0
(OFF: Average processing not performed; ON: Average processing performed)
Pin2: Average processing for analog input 1
(OFF: Average processing not performed; ON: Average processing performed)

Main Analog I/O Unit Specifications

A maximum of seven Units can be connected, including other Expansion Units and Expansion I/O Units.

But a maximum of three Analog I/O Units can be connected because each unit is allocated four words.



Item		Voltage I/O	Current I/O
Analog Input Section	Number of inputs	2 inputs (2 words allocated)	
	Input signal range	0 to 5 VDC, 1 to 5 VDC, 0 to 10 VDC, or -10 to 10 VDC	0 to 20 mA or 4 to 20 mA
	Max. rated input	±15 V	±30 mA
	External input impedance	1 MΩ min.	Approx. 250 Ω
	Resolution	1/6000 (full scale)	
	Overall accuracy	25°C	0.3% full scale
		0 to 55°C	0.4% full scale
	A/D conversion data		16-bit binary (4-digit hexadecimal) Full scale for -10 to 10 V: F448 to 0BB8 hex Full scale for other ranges: 0000 to 1770 hex
	Averaging function	Supported (Settable for individual inputs via DIP switch)	
	Open-circuit detection function	Supported	
Analog Output Section	Number of outputs	1 output (1 word allocated)	
	Output signal range	1 to 5 VDC, 0 to 10 VDC, or -10 to 10 VDC,	0 to 20 mA or 4 to 20 mA
	Allowable external output load resistance	1 kΩ min.	600 Ω max.
	External output impedance	0.5 Ω max.	
	Resolution	1/6000 (full scale)	
	Overall accuracy	25°C	0.4% full scale
		0 to 55°C	0.8% full scale
	Set data (D/A conversion)		16-bit binary (4-digit hexadecimal) Full scale for -10 to 10 V: F448 to 0BB8 hex Full scale for other ranges: 0000 to 1770 hex
Conversion time		2 ms/point (6 ms/all points)	
Isolation method		Photocoupler isolation between analog I/O terminals and internal circuits. No isolation between analog I/O signals.	
Current consumption		5 VDC: 83 mA max., 24 VDC: 110 mA max.	


Analog I/O Signal Ranges

Analog I/O data is digitally converted according to the analog I/O signal range as shown below.


Note When the input exceeds the specified range, the AD converted data will be fixed at either the lower limit or upper limit.

Analog Input Signal Ranges**-10 to 10 V**


The -10 to 10 V range corresponds to the hexadecimal values F448 to 0BB8 (-3000 to 3000). The entire data range is F31C to 0CE4 (-3300 to 3300). A negative voltage is expressed as a two's complement.

**0 to 10 V**

The 0 to 10 V range corresponds to the hexadecimal values 0000 to 1770 (0 to 6000). The entire data range is FED4 to 189C (-300 to 6300). A negative voltage is expressed as a two's complement.


**0 to 5 V**

The 0 to 5 V range corresponds to the hexadecimal values 0000 to 1770 (0 to 6000). The entire data range is FED4 to 189C (-300 to 6300). A negative voltage is expressed as a two's complement.




1 to 5 V


The 1 to 5 V range corresponds to the hexadecimal values 0000 to 1770 (0 to 6000). The entire data range is FED4 to 189C (–300 to 6300). Inputs between 0.8 and 1 V are expressed as two's complements. If the input falls below 0.8 V, open-circuit detection will activate and converted data will be 8000.

**0 to 20 mA**

The 0 to 20 mA range corresponds to the hexadecimal values 0000 to 1770 (0 to 6000). The entire data range is FED4 to 189C (–300 to 6300). A negative voltage is expressed as a two's complement.


**4 to 20 mA**

The 4 to 20 mA range corresponds to the hexadecimal values 0000 to 1770 (0 to 6000). The entire data range is FED4 to 189C (–300 to 6300). Inputs between 3.2 and 4 mA are expressed as two's complements. If the input falls below 3.2 mA, open-circuit detection will activate and converted data will be 8000.




Analog Output Signal Ranges**-10 to 10 V**


The hexadecimal values F448 to 0BB8 (-3000 to 3000) correspond to an analog voltage range of -10 to 10 V. The entire output range is -11 to 11 V. Specify a negative voltage as a two's complement.

**0 to 10 V**

The hexadecimal values 0000 to 1770 (0 to 6000) correspond to an analog voltage range of 0 to 10 V. The entire output range is -0.5 to 10.5 V. Specify a negative voltage as a two's complement.


**1 to 5 V**

The hexadecimal values 0000 to 1770 (0 to 6000) correspond to an analog voltage range of 1 to 5 V. The entire output range is 0.8 to 5.2 V.




0 to 20 mA

The hexadecimal values 0000 to 1770 (0 to 6000) correspond to an analog current range of 0 to 20 mA. The entire output range is 0 to 21 mA.

**4 to 20 mA**

The hexadecimal values 0000 to 1770 (0 to 6000) correspond to an analog current range of 4 to 20 mA. The entire output range is 3.2 to 20.8 mA.

**Averaging Function for Analog Inputs**


The averaging function can be enabled for inputs using the DIP switch. The averaging function stores the average (a moving average) of the last eight input values as the converted value. Use this function to smooth inputs that vary at a short interval.

Open-circuit Detection Function for Analog Inputs


The open-circuit detection function is activated when the input range is set to 1 to 5 V and the voltage drops below 0.8 V, or when the input range is set to 4 to 20 mA and the current drops below 3.2 mA. When the open-circuit detection function is activated, the converted data will be set to 8,000.

The time for enabling or clearing the open-circuit detection function is the same as the time for converting the data. If the input returns to the convertible range, the open-circuit detection is cleared automatically and the output returns to the normal range.


Using Analog I/O



Writing Set Data and Reading A/D Converted Values




Writing D/A Conversion Data



Note Word (n+1) can be used for either the set data or the analog output conversion value.

Connecting the Analog I/O Unit and Setting the DIP Switch

This section describes how to connect an Analog I/O Unit to the CPU Unit.



Setting the Averaging Function

DIP switch pins 1-1 and 1-2 are used to set the averaging function. When averaging is enabled, a moving average of the last eight input values is output as the converted value. The averaging function can be set separately for analog inputs 1 and 2.




DIP switch pin	Function	Setting	Default
1-1	Averaging	Analog input 0 OFF: Disabled; ON: Enabled	OFF
1-2		Analog input 1 OFF: Disabled; ON: Enabled	OFF


Wiring Analog I/O Devices

Internal Circuits


Analog Inputs



Analog Outputs





Terminal Arrangements





Note For current inputs, short V IN0 to I IN0 and V IN1 to I IN1.

V OUT	Voltage output
I OUT	Current output
COM	Output common
V IN0	Voltage input 0
I IN0	Current input 0
COM0	Input common 0
V IN1	Voltage input 1
I IN1	Current input 1
COM1	Input common 1

Wiring for Analog Inputs




Wiring for Analog Outputs



- Note**
- (1) Connect the shield to the FG terminal to prevent noise.
 - (2) When an input is not being used, short the + and – terminals.
 - (3) Separate wiring from power lines (AC power supply lines, high-voltage lines, etc.)
 - (4) When there is noise in the power supply line, install a noise filter on the input section and the power supply terminals.

- (5) Refer to the following diagram regarding wiring disconnections when voltage input is being used.



Example: If analog input device 2 is outputting 5 V and the same power supply is being used for both devices as shown above, approximately 1/3, or 1.6 V, will be applied to the input for input device 1.

If a wiring disconnection occurs when voltage input is being used, the situation described below will result. Either separate the power supplies for the connected devices, or use an isolator for each input.

If the same power supply is being used by the connected devices and a disconnection occurs at points A or B in the above diagram, an unwanted circuit path will occur as shown along the dotted line in the diagram. If that occurs, a voltage of approximately 1/3 to 1/2 of the output voltage of the other connected device will be generated. If that voltage is generated while the setting is for 1 to 5 V, open-circuit detection may not be possible. Also, if a disconnection occurs at point C in the diagram, the negative (-) side will be used in for both devices and open-circuit detection will not be possible.


This problem will not occur for current inputs even if the same power supply is used.

- (6) When external power is supplied (when setting the range code), or when there is a power interruption, pulse-form analog output of up to 1 ms may be generated. If this causes problems with operation, take countermeasures such as those suggested below.
- Turn ON the power supply for the CP1H CPU Unit first, and then turn ON the power supply for the load after confirming correct operation.
 - Turn OFF the power supply for the load before turning OFF the power supply for the CP1H CPU Unit.

Creating a Ladder Program

I/O Allocation


Two input words and one output word are allocated to the Analog I/O Unit starting from the next word following the last word allocated to the CPU Unit or previous Expansion Unit or Expansion I/O Unit.



Writing Set Data


Write the set data to word (n+1). A/D or D/A conversion begins when the set data is transferred from the CPU Unit to the Analog I/O Unit. There are five range codes, 000 to 100, that combine the analog input 1 and 2 and analog output signal ranges, as shown below.

Range code	Analog input 0 range	Analog input 1 range	Analog output range
000	-10 to 10 V	-10 to 10 V	-10 to 10 V
001	0 to 10 V	0 to 10 V	0 to 10 V
010	1 to 5 V/4 to 20 mA	1 to 5 V/4 to 20 mA	1 to 5 V
011	0 to 5 V/0 to 20 mA	0 to 5 V/0 to 20 mA	0 to 20 mA
100	---	---	4 to 20 mA



Example

The following instructions set analog input 0 to 4 to 20 mA, analog input 1 to 0 to 10 V, and the analog output to -10 to 10 V.



- The Analog I/O Unit will not start converting analog I/O values until the range code has been written. Until conversion starts, inputs will be 0000, and 0 V or 0 mA will be output.
- After the range code has been set, 0 V or 0 mA will be output for the 0 to 10 V, -10 to 10 V, or 0 to 20 mA ranges, and 1 V or 4 mA will be output for the 1 to 5 V and 4 to 20 mA ranges until a convertible value has been written to the output word.
- Once the range code has been set, it is not possible to change the setting while power is being supplied to the CPU Unit. To change the I/O range, turn the CPU Unit OFF then ON again.

Reading Analog Input Converted Values

The ladder program can be used to read the memory area words where the converted values are stored. Values are output to the next two words ($m + 1$, $m + 2$) following the last input word (m) allocated to the CPU Unit or previous Expansion Unit or Expansion I/O Unit.


Writing Analog Output Converted Values

The ladder program can be used to write data to the memory area where the set value is stored. The output word will be “ $n+1$,” where “ n ” is the last output word allocated to the CPU Unit or previous Expansion Unit or Expansion I/O Unit.

Startup Operation

After power is turned ON, it will require two cycle times plus approx. 50 ms before the first data is converted. The following instructions can be placed at the beginning of the program to delay reading converted data from analog inputs until conversion is actually possible.

Analog input data will be 0000 until initial processing has been completed. Analog output data will be 0 V or 0 mA until the range code has been written. After the range code has been written, the analog output data will be 0 V or 0 mA if the range is 0 to 10 V, –10 to 10 V, or 0 to 20 mA, or it will be 1 V or 4 mA if the range is 1 to 5 V or 4 to 20 mA.

**Handling Unit Errors**

- When an error occurs in the Analog I/O Unit, analog input data will be 0000 and 0 V or 0 mA will be output as the analog output.
If a CPU error or an I/O bus error (fatal errors) occurs at the CPU Unit and the analog output is set to 1 to 5 V or 4 to 20 mA, 0 V or 0 mA will be output. For any other fatal errors at the CPU Unit, 1 V or 4 mA will be output.
- CP-series Expansion Unit or Expansion I/O Unit errors are output to bits 0 to 6 of word A436. The bits are allocated from A436.00 in order starting with the Unit nearest the CPU Unit. Use these flags in the program when it is necessary to detect errors.


Program Example

This programming example uses these ranges:

Analog input 0: 0 to 10 V

Analog input 1: 4 to 20 mA

Analog output: 0 to 10 V



7-4-2 CP1W-MAD42/CP1W-MAD44 Analog I/O Units

Each CP1W-MAD42 Analog I/O Unit provides 4 analog inputs and 2 analog outputs.


Each CP1W-MAD44 Analog I/O Unit provides 4 analog inputs and 4 analog outputs.

- The analog input range can be set to 0 to 5 VDC, 1 to 5 VDC, 0 to 10 VDC, -10 to 10 VDC, 0 to 20 mA, or 4 to 20 mA. The inputs have a resolution of 1/12000.

An open-circuit detection function is activated in the ranges of 1 to 5 VDC and 4 to 20 mA.


- The analog output range can be set to 1 to 5 VDC, 0 to 10 VDC, -10 to 10 VDC, 0 to 20 mA, or 4 to 20 mA. The outputs have a resolution of 1/12000.

Part Names



- (1) Analog Input Terminals
Connected to analog output devices.

Input Terminal Arrangement for CP1W-MAD42/MAD44




V IN1	Voltage input 1
I IN1	Current input 1
COM1	Input common 1
V IN2	Voltage input 2
I IN2	Current input 2
COM2	Input common 2
V IN3	Voltage input 3
I IN3	Current input 3
COM3	Input common 3
V IN4	Voltage input 4
I IN4	Current input 4
COM4	Input common 4

Note When using current inputs, voltage input terminals must be short-circuited with current input terminals.


- (2) Analog Output Terminals
Connected to analog input devices.

Output Terminal Arrangement for CP1W-MAD42



V OUT1	Voltage output 1
I OUT1	Current output 1
COM1	Output common 1
V OUT2	Voltage output 2
I OUT2	Current output 2
COM2	Output common 2

Output Terminal Arrangement for CP1W-MAD44



(3) Expansion I/O Connecting Cable
Connected to the expansion connector of a CP1H CPU Unit or a CP-series Expansion Unit or Expansion I/O Unit. The cable is provided with the Analog I/O Unit and cannot be removed.

Caution Do not touch the cables during operation. Static electricity may cause operating errors.


(4) Expansion Connector
Used for connecting CP-series Expansion Units or Expansion I/O Units.

Main Analog I/O Unit Specifications

A maximum of seven Units can be connected, including other Expansion Units and Expansion I/O Units.

But a maximum of three Analog I/O Units can be connected because each unit is allocated four words.

A maximum of 7 Expansion Units or Expansion I/O Units can be connected.



Item			Voltage I/O	Current I/O
Analog Input Section	Number of inputs		4 inputs (4 words allocated)	
	Input signal range		0 to 5 VDC, 1 to 5 VDC, 0 to 10 VDC, or −10 to 10 VDC	0 to 20 mA or 4 to 20 mA
	Max. rated input		±15 V	±30 mA
	External input impedance		1 MΩ min.	Approx. 250 Ω
	Resolution		1/12000 (full scale)	
	Overall accuracy	25°C	0.2% full scale	0.3% full scale
		0 to 55°C	0.5% full scale	0.7% full scale
	A/D conversion data		16-bit binary (4-digit hexadecimal) Full scale for −10 to 10 V: E890 to 1770 hex Full scale for other ranges: 0000 to 2EE0 hex	
	Averaging function		Supported	
Open-circuit detection function		Supported		
Analog Output Section	Number of outputs		CP1W-MAD42: 2 outputs (2 words allocated) CP1W-MAD44: 4 outputs (4 words allocated)	
	Output signal range		1 to 5 VDC, 0 to 10 VDC, or −10 to 10 VDC,	0 to 20 mA or 4 to 20 mA
	Allowable external output load resistance		2 kΩ min.	350 Ω max.
	External output impedance		0.5 Ω max.	
	Resolution		1/12000 (full scale)	
	Overall accuracy	25°C	0.3% full scale	
		0 to 55°C	0.7% full scale	
	Set data (D/A conversion)		16-bit binary (4-digit hexadecimal) Full scale for −10 to 10 V: E890 to 1770 hex Full scale for other ranges: 0000 to 2EE0 hex	
Conversion time			CP1W-MAD42: 1 ms/point (6 ms/all points) CP1W-MAD44: 1 ms/point (8 ms/all points)	
Isolation method			Photocoupler isolation between analog I/O terminals and internal circuits. No isolation between analog I/O signals.	
Current consumption			CP1W-MAD42: 5 VDC: 120 mA max., 24 VDC: 120 mA max. CP1W-MAD44: 5 VDC: 120 mA max., 24 VDC: 170 mA max.	


Analog I/O Signal Ranges

Analog I/O data is digitally converted according to the analog I/O signal range as shown below.


Note When the input exceeds the specified range, the AD converted data will be fixed at either the lower limit or upper limit.

Analog Input Signal Ranges**-10 to 10 V**


The -10 to 10 V range corresponds to the hexadecimal values E890 to 1770 (-6000 to 6000). The entire data range is E638 to 19C8 (-6600 to 6600). A negative voltage is expressed as a two's complement.

**0 to 10 V**

The 0 to 10 V range corresponds to the hexadecimal values 0000 to 2EE0 (0 to 12000). The entire data range is FDA8 to 3138 (-600 to 12600). A negative voltage is expressed as a two's complement.


**0 to 5 V**

The 0 to 5 V range corresponds to the hexadecimal values 0000 to 2EE0 (0 to 12000). The entire data range is FDA8 to 3138 (-600 to 12600). A negative voltage is expressed as a two's complement.




1 to 5 V


The 1 to 5 V range corresponds to the hexadecimal values 0000 to 2EE0 (0 to 12000). The entire data range is FDA8 to 3138 (–600 to 12600). Inputs between 0.8 and 1 V are expressed as two's complements. If the input falls below 0.8 V, open-circuit detection will activate and converted data will be 8000.

**0 to 20 mA**

The 0 to 20 mA range corresponds to the hexadecimal values 0000 to 2EE0 (0 to 12000). The entire data range is FDA8 to 3138 (–600 to 12600). A negative current is expressed as a two's complement.

**4 to 20 mA**


The 4 to 20 mA range corresponds to the hexadecimal values 0000 to 2EE0 (0 to 12000). The entire data range is FDA8 to 3138 (–600 to 12600). Inputs between 3.2 and 4 mA are expressed as two's complements. If the input falls below 3.2 mA, open-circuit detection will activate and converted data will be 8000.



Analog Output Signal Ranges


-10 to 10 V

The hexadecimal values E890 to 1770 (-6000 to 6000) correspond to an analog voltage range of -10 to 10 V. The entire output range is -11 to 11 V. Specify a negative voltage as a two's complement.




0 to 10 V

The hexadecimal values 0000 to 2EE0 (0 to 12000) correspond to an analog voltage range of 0 to 10 V. The entire output range is -0.5 to 10.5 V. Specify a negative voltage as a two's complement.




1 to 5 V

The hexadecimal values 0000 to 2EE0 (0 to 12000) correspond to an analog voltage range of 1 to 5 V. The entire output range is 0.8 to 5.2 V.




0 to 20 mA

The hexadecimal values 0000 to 2EE0 (0 to 12000) correspond to an analog current range of 0 to 20 mA. The entire output range is 0 to 21 mA.

**4 to 20 mA**

The hexadecimal values 0000 to 2EE0 (0 to 12000) correspond to an analog current range of 4 to 20 mA. The entire output range is 3.2 to 20.8 mA.

**Averaging Function for Analog Inputs**

For analog inputs, the averaging function operates when the averaging bit is set to 1. The averaging function outputs the average (a moving average) of the last eight input values as the converted value. If there is only a slight variation in inputs, it is handled by the averaging function as a smooth input.

The averaging function stores the average (a moving average) of the last eight input values as the converted value. Use this function to smooth inputs that vary at a short interval.

Open-circuit Detection Function for Analog Inputs

The open-circuit detection function is activated when the input range is set to 1 to 5 V and the voltage drops below 0.8 V, or when the input range is set to 4 to 20 mA and the current drops below 3.2 mA. When the open-circuit detection function is activated, the converted data will be set to 8,000.

The time for enabling or clearing the open-circuit detection function is the same as the time for converting the data. If the input returns to the convertible range, the open-circuit detection is cleared automatically and the output returns to the normal range.

Using Analog I/O

Connect and wire the Unit.



- Connect the Analog I/O Unit.
- Wire to analog I/O devices.




Create a ladder program.

- Analog inputs: 0 to 5 VDC, 1 to 5 VDC, 0 to 10 VDC, -10 to 10 VDC, 0 to 20 mA, or 4 to 20 mA
- Analog outputs: 1 to 5 VDC, 0 to 10 VDC, -10 to 10 VDC, 0 to 20 mA, or 4 to 20 mA
- Set analog inputs as voltage or current inputs and set the averaging function.
- Write set data to output words.


Writing Set Data and Reading A/D Converted Values



Writing D/A Conversion Data




Note Words (n+1, n+2) can be used for either the set data or the analog output conversion value.




Note Words (n+1 to n+4) can be used for either the set data or the analog output conversion value.

Wiring Analog I/O Devices Internal Circuits


Analog Inputs





Analog Outputs (CP1W-MAD42)





Analog Outputs (CP1W-MAD44)



Wiring for Analog Inputs




Wiring for Analog Outputs



Note

- (1) Connect the shield to the FG terminal to prevent noise.
- (2) When an input is not being used, short the + and – terminals.
- (3) Separate wiring from power lines (AC power supply lines, high-voltage lines, etc.)
- (4) When there is noise in the power supply line, install a noise filter on the input section and the power supply terminals.
- (5) Refer to the following diagram regarding wiring disconnections when voltage input is being used.



For example, if analog input device 2 is outputting 5 V and the same power supply is being used as shown above, about 1/3, or 1.6 V, will be applied at the input for input device 1.

Consider the following information on open input circuits when using voltage inputs. Either use separate power supplies, or install an isolator at each input.

If the same power supply is used as shown in the following diagram and an open circuit occurs at point A or B, an unwanted current flow will occur as shown by the dotted lines in the diagram, creating a voltage at the other input of about 1/3 to 1/2. If the 1 to 5 V range is being used, the open-circuit detection function will not operate. Also, if there is an open circuit at C, the open-circuit detection function will not operate because the negative sides are the same.


- (6) When external power is supplied (when range codes are set), or when the power is interrupted, there may be a pulse status analog output of up to 1 ms. If this status is a problem, take the following measures.
 - Turn ON the power to the CP1H CPU Unit, check the operation status, and then turn ON the power at the load.
 - Turn OFF the power to the load and then turn OFF the power to the CP1H CPU Unit.

Creating a Ladder Program

I/O Allocation

Four input words and two output words are allocated to the CP1W-MAD42, starting from the next word following the last word allocated to the CPU Unit or previous Expansion Unit or Expansion I/O Unit.

Four input words and four output words are allocated to the CP1W-MAD44, starting from the next word following the last word allocated to the CPU Unit or previous Expansion Unit or Expansion I/O Unit.



Writing Set Data

CP1W-MAD42

Write the set data to words (n+1 to n+2). A/D or D/A conversion begins when the set data is transferred from the CPU Unit to the Analog I/O Unit. Setting contents are shown as the following table.

Word (n+1)	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Value	1	0	0	0	Analog output 1				Analog input 2				Analog input 1			
Word (n+2)	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Value	1	0	0	0	Analog output 2				Analog input 4				Analog input 3			

CP1W-MAD44

Write the set data to words (n+1 to n+4). A/D or D/A conversion begins when the set data is transferred from the CPU Unit to the Analog I/O Unit. Setting contents are shown as the following table.

Word (n+1)	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Value	1	0	0	0	0	0	0	0	Analog input 2				Analog input 1			
Word (n+2)	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Value	1	0	0	0	0	0	0	0	Analog input 4				Analog input 3			
Word (n+3)	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Value	1	0	0	0	0	0	0	0	Analog output 2				Analog output 1			
Word (n+4)	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Value	1	0	0	0	0	0	0	0	Analog output 4				Analog output 3			

Even if analog inputs are not used, bit 15 in word (n+1) and (n+2) must be set to 1.

Set Data of Analog Inputs

	7	6	5	4	3	2	1	0
Value	Enable	Average	AD Range Code		Enable	Average	AD Range Code	

Enable Bit

0 : Disable channel

1 : Enable channel

Average Bit

0 : Disable

1 : Enable

AD Range Code

00 : -10 to 10V

01 : 0 to 10V

10 : 1 to 5V (4 to 20mA)

11 : 0 to 5V (0 to 20mA)

Range Code	Analog input range
00	–10 to 10 V
01	0 to 10 V
10	1 to 5 V (4 to 20 mA)
11	0 to 5 V (0 to 20 mA)

Set Data of Analog Outputs

Value	7	6	5	4	3	2	1	0
	Enable	DA Range Code			Enable	DA Range Code		

Enable Bit
 0 : Disable channel
 1 : Enable channel

DA Range Code
 000 : –10 to 10V
 001 : 0 to 10V
 010 : 1 to 5V
 011 : 0 to 20mA
 100 : 4 to 20mA

Range Code	Analog output range
000	–10 to 10 V
001	0 to 10 V
010	1 to 5 V
011	0 to 20 mA
100	4 to 20 mA

- The Analog I/O Unit will not start converting analog I/O values until the set data has been written.
- Before range code is written, 0 V or 0 mA will be output in the 0 to 10 V, –10 to +10 V, and 0 to 20 mA ranges, and 1 V or 4 mA will be output in the 1 to 5 V and 4 to 20 mA ranges.
- Once the range code has been set, it is not possible to be changed while power is being supplied to the CPU Unit. To change the code range, turn the CPU Unit OFF then ON again.

Averaging

Set whether averaging is to be used for set data. When the averaging bit is set to 1, the average (moving average) for the past eight inputs is output as conversion data.

Reading Analog Input Converted Values

Read the conversion value storage area with the ladder program. With word m as the last input word allocated to the CPU Unit or an already-connected Expansion Unit, the A/D conversion data will be output to the following words m+1 to m+4.

Writing Analog Output Converted Values

The ladder program can be used to write conversion data to the output words. The output word start from “n+1” where “n” is the last output word allocated to the CPU Unit, or previous Expansion Unit or Expansion I/O Unit.

Startup Operation


After power is turned ON, it will require two cycle times plus approximately 50ms before the first conversion data is output.

Analog input data will be 0000 until the first conversion data is stored in the input words.

The following table shows the output status after the initial processing is completed.

Output type	Voltage output		Current output	
	Output range			
	0 to 10 V, -10 to +10 V	1 to 5 V	0 to 20 mA	4 to 20 mA
Before range code is written	0 V		0 mA	
After range code is written	0 V	1 V	0 mA	4 mA

Therefore, create a program as shown below, so that the ladder can start to operate with valid conversion data in input words.




TIM0005 is started when the power is turned ON. After 0.2 s (200 ms) elapses, the TIM0005 contact turns ON and the analog input 1 conversion data stored in word 2 is transferred to D0.

Handling Unit Errors

When an error occurs in the Analog I/O Unit, analog input data will be 0000 and 0 V or 0 mA will be output as the analog output.

If a CPU error or an I/O bus error (fatal errors) occurs at the CPU Unit and the analog output is set to 1 to 5 V or 4 to 20 mA, 0 V or 0 mA will be output. For any other errors at the CPU Unit, 1 V or 4 mA will be output.

Program Example




This programming example uses these ranges:


CP1W-MAD42

Analog input	Input range	Range code	Averaging	Set data	Destination word
Input 1	4 to 20 mA	10	Yes	1110 (E hex)	n+1
Input 2	0 to 10 V	01	Yes	1101 (D hex)	n+1
Input 3	0 to 5 V	11	Yes	1111 (F hex)	n+2
Input 4	-10 to 10 V	00	Yes	1100 (C hex)	n+2
Output 1	-10 to 10 V	000	---	1000 (8 hex)	n+1
Output 2	4 to 20 mA	100	---	1100 (C hex)	n+2

CP1W-MAD44

Analog input	Input range	Range code	Averaging	Set data	Destination word
Input 1	4 to 20 mA	10	Yes	1110 (E hex)	n+1
Input 2	0 to 10 V	01	No	1001 (9 hex)	n+1
Input 3	0 to 5 V	11	Yes	1111 (F hex)	n+2
Input 4	−10 to 10 V	00	Yes	1100 (C hex)	n+2
Output 1	−10 to 10 V	000	---	1000 (8 hex)	n+3
Output 2	4 to 20 mA	100	---	1100 (C hex)	n+3
Output 3	0 to 10 V	001	---	1001 (9 hex)	n+4
Output 4	Not use	---	---	0000 (0 hex)	n+4





7-5 Temperature Sensor Units


7-5-1 CP1W-TS□01/TS□02 Temperature Sensor Units

CP1W-TS002/TS102 Temperature Sensor Units each provide up to four input points, and CP1W-TS001/TS101 Temperature Sensor Units each provide up to two input points. The inputs can be from thermocouples or platinum resistance thermometers.

CP1W-TS002/TS102 Temperature Sensor Units are each allocated four input words, so no more than three Units can be connected. Up to 14 temperature sensor input points can be connected by using three CP1W-TS002/TS102 Temperature Sensor Units and one CP1W-TS001/TS101 Temperature Sensor Unit.

Part Names

Temperature Sensor Units: CP1W-TS001/002/101/102




- (1) Temperature Sensor Input Terminals
Used to connect temperature sensors such as thermocouples or platinum resistance thermometers.
 - (2) DIP Switch
Used to set the temperature unit (°C or °F) and the number of decimal places used.
 - (3) Rotary Switch
Used to set the temperature input range. Make the setting according to the specifications of the temperature sensors that are connected.
 - (4) Expansion I/O Connecting Cable
Connected to the expansion connector of a CP1H CPU Unit or a CP-series Expansion Unit or Expansion I/O Unit. The cable is included with the Temperature Sensor Unit and cannot be removed.
- Note** Do not touch the cables during operation. Static electricity may cause operating errors.
- (5) Expansion Connector
Used for connecting CP-series Expansion Units or Expansion I/O Units.

Main Specifications

Item	CP1W-TS001	CP1W-TS002	CP1W-TS101	CP1W-TS102
Temperature sensors	Thermocouples		Platinum resistance thermometer	
	Switchable between K and J, but same type must be used for all inputs.		Switchable between Pt100 and JPt100, but same type must be used for all inputs.	
Number of inputs	2	4	2	4
Allocated input words	2	4	2	4
Max. number of Units	7	3	7	3
Accuracy	(The larger of $\pm 0.5\%$ of converted value or $\pm 2^{\circ}\text{C}$) ± 1 digit max. (See note.)		(The larger of $\pm 0.5\%$ of converted value or $\pm 1^{\circ}\text{C}$) ± 1 digit max.	
Conversion time	250 ms for 2 or 4 input points			
Converted temperature data	16-bit binary data (4-digit hexadecimal)			
Isolation	Photocouplers between all temperature input signals			
Current consumption	5 VDC: 40 mA max., 24 VDC: 59 mA max.		5 VDC: 54 mA max., 24 VDC: 73 mA max.	


Note Accuracy for a K-type sensor at -100°C or less is $\pm 4^{\circ}\text{C} \pm 1$ digit max.

Using Temperature Sensor Units



Connecting Temperature Sensor Units


A maximum of three CP1W-TS002 and CP1W-TS102 Temperature Sensor Units can be connected, because each unit is allocated four words.




Setting Temperature Ranges

- Note**
- (1) Always turn OFF the power supply before setting the temperature range.
 - (2) Never touch the DIP switch or rotary switch during Temperature Sensor Unit operation. Static electricity may cause operating errors.

The Temperature Sensor Unit's DIP switch and rotary switch are used to set the temperature unit, to select 2-decimal-place Mode is to be used, and to set the temperature input range.

**DIP Switch Settings**

The DIP switch is used to set the temperature unit ($^{\circ}\text{C}$ or $^{\circ}\text{F}$) and the number of decimal places used.



SW1	Setting		
1	Temperature unit	OFF	$^{\circ}\text{C}$
		ON	$^{\circ}\text{F}$
2	Number of decimal places used (See note.) (0.01 expression)	OFF	Normal (0 or 1 digit after the decimal point, depending on the input range)
		ON	2-decimal-place Mode

- Note** For details on 2-decimal-place Mode, refer to *Two-decimal-place Mode* on page 455.

Rotary Switch Setting

Caution Set the temperature range according to the type of temperature sensor connected to the Unit. Temperature data will not be converted correctly if the temperature range does not match the sensor.

Caution Do not set the temperature range to any values other than those for which temperature ranges are given in the following table. An incorrect setting may cause operating errors.

The rotary switch is used to set the temperature range.




Setting	CP1W-TS001/002			CP1W-TS101/102		
	Input type	Range (°C)	Range (°F)	Input type	Range (°C)	Range (°F)
0	K	–200 to 1,300	–300 to 2,300	Pt100	–200.0 to 650.0	–300.0 to 1,200.0
1		0.0 to 500.0	0.0 to 900.0	JPt100	–200.0 to 650.0	–300.0 to 1,200.0
2	J	–100 to 850	–100 to 1,500	---	Cannot be set.	
3		0.0 to 400.0	0.0 to 750.0	---		
4 to F	---	Cannot be set.		---		

Connecting Temperature Sensors

Thermocouples


CP1W-TS001

Either K or J thermocouples can be connected, but both thermocouples must be the same type and the same input range.



CP1W-TS002

Either K or J thermocouples can be connected, but all four of the thermocouples must be of the same type and the same input range must be used for each.



Note When connecting a thermocouple input, observe the following precautions:


- Do not remove the cold junction compensator attached at the time of delivery. If the cold junction compensator is removed, the Unit will not be able to measure temperatures correctly.
- Each of the input circuits is calibrated with the cold junction compensator attached to the Unit. If the Unit is used with the cold junction compensator from other Units, the Unit will not be able to measure temperatures correctly.

- Do not touch the cold junction compensator. Doing so may result in incorrect temperature measurement.

Platinum Resistance Thermometers

CP1W-TS101


One or two Pt or JPt platinum resistance thermometers can be connected, but both of the thermometers must be of the same type and the same input range must be used for each.



Temperature input 0 Temperature input 1

CP1W-TS102

Up to four Pt100 or JPt100 platinum resistance thermometers can be connected, but all four of the thermometers must be of the same type and the same input range must be used for each.




Note Do not connect anything to terminals not used for inputs.

Creating a Ladder Program


Word Allocations

Temperature Sensor Units are allocated words in the same way as other CP-series Expansion Units or Expansion I/O Units, in order of connection. A Temperature Sensor Unit is allocated the next input words following the input words of the CPU Unit or previous Expansion Unit or Expansion I/O Unit. Four input words are allocated to the 2-input CP1W-TS001 or CP1W-TS101 and four input words are allocated to the 4-input CP1W-TS002 or CP1W-TS102. No output words are allocated.

Example 1



Example 2



Converted Temperature Data

The temperature data will be stored in the input words allocated to the Temperature Sensor Unit in 4-digit hexadecimal.

TS002/TS102

m+1	Converted temperature data from input 0
m+2	Converted temperature data from input 1
m+3	Converted temperature data from input 2
m+4	Converted temperature data from input 3

TS001/TS101

m+1	Converted temperature data from input 0
m+2	Converted temperature data from input 1

“m” is the last input word allocated to the CPU Unit, Expansion I/O Unit, or Expansion Unit connected immediately before the Temperature Sensor Unit.


- Negative values are stored as 2’s complements.
- Data for range codes that include one digit after the decimal point are stored without the decimal point, i.e., 10 times the actual value is stored.

Input		Data conversion examples
Unit: 1°C	K or J	850°C → 0352 hex -200°C → FF38 hex
Unit: 0.1°C	K, J, Pt100 or JPt100	×10 500.0°C → 5000 → 1388 hex -20.0°C → -200 → FF38 hex -200.0°C → -2000 → F830 hex

- If the input temperature exceeds the maximum or minimum value in the temperature input range that has been set by ±20°C or ±20°F, the displayed value will be held.
- If the circuit is disconnected, the open-circuit detection function will operate and the converted temperature data will be set to 7FFF.
- The open-circuit detection function will be automatically cleared and normal input temperature conversion will begin automatically when the input temperature returns to the convertible range.

Startup Operation

After power is turned ON, approximately 1 s is required for the first conversion data to be stored in the input word. During that period, the data will be 7FFE. Therefore, create a program as shown below, so that when operation begins simultaneously with startup it will wait for valid conversion data.


**Handling Unit Errors**


- CP-series Expansion Unit/Expansion I/O Unit errors are output to bits 0 to 6 of word A436. The bits are allocated from A436.00 in order starting from the Unit nearest the CPU Unit. CP1W-TS002 and CP1W-TS102 Temperature Sensor Units are allocated two bits each. Use these flags in the program when it is necessary to detect Expansion Unit/Expansion I/O Unit errors.
- When an error occurs, the Temperature Sensor Unit data becomes 7FFF hex (the same as for an open-circuit detection). With an open-circuit detection, it is not reflected in word A436.

Programming Example


1,2,3...

1. The following programming example shows how to convert the input data from 2 temperature sensor inputs to BCD and store the result in D0 and D1.








2. The following programming example shows how to convert the data for temperature input 0 to BCD and store the result in D0 and D1. "0001" is stored in D1 when the input data is a negative value. The following system configuration is used.



Temperature unit setting	0 (°C)
Two-decimal-place Mode	0 (normal)
Input range setting	1 (Pt100: -200.0 to 650.0°C)
Input 0	CIO 2

Programming with BCD(24) Instruction**Programming with SCL2(-) Instruction**

Operation




Two-decimal-place Mode

If pin 2 on the DIP switch is turned ON, values are stored to two decimal places. In this case, temperature data is stored as 6-digit signed hexadecimal (binary) data with 4 digits in the integer portion and 2 digits after the decimal point. The actual data stored in memory is 100 times the actual value, i.e., the decimal point is not indicated. Methods for handling this data are described in this section.

Note When set to store values to two decimal places, temperature data as far as two digits after the decimal point is converted to 6-digit binary data, but the actual resolution is not 0.01°C (°F). For this reason, there may be skipping and inaccuracies in the first digit after the decimal point (0.1). Treat any resolution above that specified for the normal data format as reference data.

Temperature Data Partitioning and Structure

Temperature Data (Actual Temperature x 100 Binary)



Leftmost/Rightmost Flag: Indicates whether the leftmost or rightmost 3 digits are provided.
Temperature Unit Flag: Indicates whether the temperature is in °C or °F.
Open-circuit Flag: Turns ON (1) when an open-circuit is detected. The temperature data will be 7FF FFF if this flag is ON.

Data Conversion Examples


Example 1

Temperature: 1,130.25°C
 ×100: 113025
 Temperature Data: 01B981 (hexadecimal for 113025)

Leftmost 3 Digits and Flags

	Flags				×16 ⁵	×16 ⁴	×16 ³
Bits	15	14	13	12	11 to 08	07 to 04	03 to 00
Data	0	0	0	0	0	1	B


Normal
 °C
 Leftmost



Rightmost 3 Digits and Flags

	Flags				×16 ²	×16 ¹	×16 ⁰
Bits	15	14	13	12	11 to 08	07 to 04	03 to 00
Data	1	0	0	0	9	8	1

Normal
 °C
 Rightmost




Example 2

Temperature: -100.12°C
 ×100: -10012
 Temperature Data: FFD8E4 (hexadecimal for -10012)

Leftmost 3 Digits and Flags

	Flags				×16 ⁵	×16 ⁴	×16 ³
Bits	15	14	13	12	11 to 08	07 to 04	03 to 00
Data	0	0	0	0	F	F	D


Normal
 °C
 Leftmost



Rightmost 3 Digits and Flags

	Flags				×16 ²	×16 ¹	×16 ⁰
Bits	15	14	13	12	11 to 08	07 to 04	03 to 00
Data	1	0	0	0	8	E	4

Normal
 °C
 Rightmost



Example 3

Temperature: -200.12°F


×100: -20012

Temperature Data: FFB1D4 (hexadecimal for -20012)

Leftmost 3 Digits and Flags


	Flags				×16 ⁵	×16 ⁴	×16 ³
Bits	15	14	13	12	11 to 08	107 to 04	03 to 00
Data	0	1	0	0	F	F	B

Leftmost
°F Normal

**Rightmost 3 Digits and Flags**

	Flags				×16 ²	×16 ¹	×16 ⁰
Bits	15	14	13	12	11 to 08	07 to 04	03 to 00
Data	1	1	0	0	1	D	4

Rightmost
°F Normal

**Example 4**


Temperature: Open circuit (°F)

Temperature Data: 7FFFFFFF

Leftmost 3 Digits and Flags


	Flags				×16 ⁵	×16 ⁴	×16 ³
Bits	15	14	13	12	11 to 08	07 to 04	03 to 00
Data	0	1	1	0	7	F	F

Leftmost
°F Error

**Rightmost 3 Digits and Flags**

	Flags				×16 ²	×16 ¹	×16 ⁰
Bits	15	14	13	12	11 to 08	07 to 04	03 to 00
Data	1	1	1	0	F	F	F


Rightmost
°F Error

**Note**



- (1) Leftmost digits are stored in the lower memory addresses. Treat the data in the lower memory address as the leftmost digits when programming.
- (2) Be sure that the data is read at least once every 125 ms to allow for the CPU Unit's cycle time and communications time. Correct data may not be obtained if the read cycle is greater than 125 ms.


Programming Example

The following programming example shows how to use 2-decimal-place Mode for the following PC configuration.




In this example, 100 times the temperature data for temperature input 0 is stored in binary form in D100 to D102.





Description of Operation




Main Specifications

Item		CP1W-TS003
Temperature sensors		Thermocouples or analog input (See note1.)
		Switchable between K and J, but same type must be used for all inputs.
Number of inputs		4
Allocated input words		4
Max. number of Units		3
Accuracy at 25°C	Thermocouple inputs	(The larger of $\pm 0.5\%$ of converted value or $\pm 2^\circ\text{C}$) ± 1 digit max. (See note2.)
	Analog voltage inputs	0.5% full scale
	Analog current inputs	0.6% full scale
Accuracy at 0 to 55 °C	Thermocouple inputs	(The larger of $\pm 1\%$ of converted value or $\pm 4^\circ\text{C}$) ± 1 digit max. (See note3.)
	Analog voltage inputs	1.0% full scale
	Analog current inputs	1.2% full scale
Input signal range	Thermocouple inputs	K: -200.0 to 1300.0°C or -300.0 to 2300.0°F J: -100.0 to 850.0°C or -100.0 to 1500.0°F
	Analog voltage inputs	0 to 10V/1 to 5V
	Analog current inputs	4 to 20mA
Resolution	Thermocouple inputs	0.1°C or 0.1°F
	Analog inputs	1/12000 (full scale)
Max. rated input	Analog voltage inputs	$\pm 15\text{V}$
	Analog current inputs	$\pm 30\text{mA}$
External input impedance	Analog voltage inputs	1M Ω min.
	Analog current inputs	250 Ω
Open-circuit detection function		Supported
Averaging function		Unsupported
Conversion time		250 ms for 4 input points
Converted temperature data		16-bit binary data (4-digit hexadecimal) 2-decimal-place mode is not supported
Converted AD data		16-bit binary data (4-digit hexadecimal)
Isolation		Photocouplers between any two input signals
Current consumption		5 VDC: 70 mA max., 24 VDC: 30 mA max.

Note


- (1) Only last two channels can be used as analog input.
 (2) Accuracy for a K-type sensor at -100°C or less is $\pm 4^\circ\text{C} \pm 1$ digit max.
 (3) Accuracy for a K-type sensor at -100°C or less is $\pm 10^\circ\text{C} \pm 1$ digit max.

Using Temperature Sensor Units



Connecting Temperature Sensor Units

A maximum of three CP1W-TS003 Temperature Sensor Units can be connected, because each unit is allocated four words.



Setting Temperature or Analog Ranges


- Note**
- (1) Always turn OFF the power supply before setting the temperature or analog range.
 - (2) Never touch the DIP switch during Temperature Sensor Unit operation. Static electricity may cause operating errors.

DIP Switch Settings

Caution Set the temperature range according to the type of temperature sensor connected to the Unit. Temperature data will not be converted correctly if the temperature range does not match the sensor.

Caution Do not set the temperature range to any values other than those for which temperature ranges are given in the following table. An incorrect setting may cause operating errors.

The DIP switch is used to set the input type (temperature or analog input), the input thermocouple type (K or J) and the temperature unit (°C or °F).



SW	Setting		
1	Thermocouple type of temperature sensor	ON	J
		OFF	K
2	Temperature unit	ON	°F
		OFF	°C
3	NC		
4	Input type selection for the third input (Input 2)	ON	Analog input
		OFF	Thermocouple
5	Input type selection for the fourth input (Input 3)	ON	Analog input
		OFF	Thermocouple
6	Analog input signal range	ON	1 to 5V/4 to 20mA
		OFF	0 to 10V

Temperature input			Analog input	
Input type	Range (°C)	Range (°F)	Input type	Range
K	-200.0 to 1300.0	-300.0 to 2300.0	Voltage	0 to 10V/1 to 5V
J	-100.0 to 850.0	-100.0 to 1500.0	Current	4 to 20mA


Note Fahrenheit temperature uses the following equation to convert the temperature unit from Celsius, but the temperature input range is different between Fahrenheit and Celsius.

$$\text{Fahrenheit temperature (°F)} = \text{Celsius temperature (°C)} \times 1.8 + 32$$

Connecting Temperature Sensors

Thermocouples

Either K or J thermocouples can be connected, but all four thermocouples must be the same type and the same input range. Only last two channels can be used as analog inputs.




Note When connecting a thermocouple input, observe the following precautions:

- Do not remove the cold junction compensator attached at the time of delivery. If the cold junction compensator is removed, the Unit will not be able to measure temperatures correctly.


- Each of the input circuits is calibrated with the cold junction compensator attached to the Unit. If the Unit is used with the cold junction compensator from other Units, the Unit will not be able to measure temperatures correctly.
- Do not touch the cold junction compensator. Doing so may result in incorrect temperature measurement.

Analog Inputs

Last two channels can be used as analog inputs, but two of the analog inputs must be the same range.



Wiring for Analog Inputs



Note


- (1) When an input is not being used, short the + and – terminals.
- (2) Separate wiring from power lines (AC power supply lines, high-voltage lines, etc.)
- (3) When there is noise in the power supply line, install a noise filter on the input section and the power supply.

Analog Input Signal Ranges


When the input exceeds the specified range, the AD converted data will be fixed at either the lower limit or upper limit.

0 to 10 V


The 0 to 10 V range corresponds to the hexadecimal values 0000 to 2EE0 (0 to 12000). The entire data range is FDA8 to 3138 (–600 to 12600). A negative voltage is expressed as a two's complement.

**1 to 5 V**

The 1 to 5 V range corresponds to the hexadecimal values 0000 to 2EE0 (0 to 12000). The entire data range is FDA8 to 3138 (–600 to 12600). Inputs between 0.8 and 1 V are expressed as two's complements. If the input falls below 0.8 V, open-circuit detection will activate and converted data will be 8000.

**4 to 20 mA**

The 4 to 20 mA range corresponds to the hexadecimal values 0000 to 2EE0 (0 to 12000). The entire data range is FDA8 to 3138 (–600 to 12600). Inputs between 3.2 and 4 mA are expressed as two's complements. If the input falls below 3.2 mA, open-circuit detection will activate and converted data will be 8000.



Open-circuit Detection Function for Temperature**Open-circuit Detection Function for Analog Inputs**


If the circuit is disconnected, the open-circuit detection function will operate and the converted temperature data will be set to 7FFF.

The open-circuit detection function is activated when the input range is set to 1 to 5 V and the voltage drops below 0.8 V, or when the input range is set to 4 to 20 mA and the current drops below 3.2 mA. When the open-circuit detection function is activated, the converted data will be set to 8,000.

The time for enabling or clearing the open-circuit detection function is the same as the time for converting the data. If the input returns to the convertible range, the open-circuit detection is cleared automatically and the output returns to the normal range.

Creating a Ladder Program**Word Allocations**

Temperature Sensor Units are allocated words in the same way as other CP-series Expansion Units or Expansion I/O Units, in order of connection. A Temperature Sensor Unit is allocated the next input words following the input words of the CPU Unit or previous Expansion Unit or Expansion I/O Unit. Four input words are allocated to CP1W-TS003.

Example**Converted Temperature Data**

The converted temperature value will be stored in the input words allocated to the Temperature Sensor Unit in 4-digit hexadecimal.

m+1	Converted temperature data from input 0
m+2	Converted temperature data from input 1
m+3	Converted temperature data from input 2
m+4	Converted temperature data from input 3

“m” is the last input word allocated to the CPU Unit, Expansion I/O Unit, or Expansion Unit connected immediately before the Temperature Sensor Unit.

- Negative values are stored as 2's complements.
- Data for range codes that include one digit after the decimal point are stored without the decimal point, i.e., 10 times the actual value is stored.

Input		Data conversion examples	
Unit: 0.1°C	K or J	×10	500.0°C → 5000 → 1388 hex -20.0°C → -200 → FF38 hex -200.0°C → -2000 → F830 hex

- If the input temperature exceeds the maximum or minimum value in the temperature input range that has been set by $\pm 20^{\circ}\text{C}$ or $\pm 20^{\circ}\text{F}$, the displayed value will be held.
- If the circuit is disconnected, the open-circuit detection function will operate and the converted temperature data will be set to 7FFF.
- The open-circuit detection function will be automatically cleared and normal input temperature conversion will begin automatically when the input temperature returns to the convertible range.


Converted Analog Data

m+3	Converted analog data from input 2
m+4	Converted analog data from input 3


“m” is the last input word allocated to the CPU Unit, Expansion I/O Unit, or Expansion Unit connected immediately before the Temperature Sensor Unit.

Startup Operation

After power is turned ON, approximately 1 s is required for the first conversion data to be stored in the input word. During that period, the data will be 7FFE. Therefore, create a program as shown below, so that the ladder can start to operate with valid conversion data in input words.



**Programming Example**

The following programming example shows how to store the input data of CP1W-TS003 (4 inputs) in D0 to D3, and W10.00~W10.13 turns ON at the time of open-circuit detection.

**DIP Switch Setting**

SW1	OFF	K
SW2	OFF	°C
SW3	NC	
SW4	OFF	Thermocouple
SW5	ON	Analog
SW6	ON	1 to 5V/4 to 20mA

Wiring Diagram




7-5-3 CP1W-TS004 Temperature Sensor Units

CP1W-TS004 Temperature Sensor Unit provide up to twelve input points.
The inputs can be from thermocouples.

CP1W-TS004 Temperature Sensor Unit is allocated two input words and one output word, so no more than seven Units can be connected.

Part Names

Temperature Sensor Units: CP1W-TS004




- (1) Temperature Sensor Input Terminals
Used to connect temperature sensors such as thermocouples.
 - (2) DIP Switch
Used to set the temperature unit (°C or °F) and the temperature input range. Make the setting according to the specifications of the temperature sensors that are connected.
 - (3) Expansion I/O Connecting Cable
Connected to the expansion connector of a CP1H CPU Unit or a CP-series Expansion Unit or Expansion I/O Unit. The cable is included with the Temperature Sensor Unit and cannot be removed.
- Note** Do not touch the cables during operation. Static electricity may cause operating errors.
- (4) Expansion Connector
Used for connecting CP-series Expansion Units or Expansion I/O Units.

Main Specifications

Item		CP1W-TS004
Temperature sensors		Thermocouples
		Switchable between K and J, but same type must be used for all inputs.
Number of inputs		12
Allocated input words		2
Allocated output words		1
Accuracy	25°C	(The larger of $\pm 0.5\%$ of converted value or $\pm 2^\circ\text{C}$) ± 1 digit max. (See note1.)
	0 to 55°C	(The larger of $\pm 1\%$ of converted value or $\pm 4^\circ\text{C}$) ± 1 digit max. (See note2.)
Conversion time		500 ms for 12 input points
Converted temperature data		16-bit binary data (4-digit hexadecimal) 2-decimal-place mode is not supported
Isolation		Photocouplers between any two input signals
Current consumption		5 VDC: 80 mA max., 24 VDC: 50 mA max.


- Note**
- (1) Accuracy for a K-type sensor at -100°C or less is $\pm 4^\circ\text{C} \pm 1$ digit max.
 - (2) Accuracy for a K-type sensor at -100°C or less is $\pm 10^\circ\text{C} \pm 1$ digit max.

Using Temperature Sensor Units



Connecting Temperature Sensor Units

A maximum of seven CP1W-TS004 Temperature Sensor Units can be connected, because each unit is allocated two input words and one output word.



Setting Temperature Ranges


- Note**
- (1) Always turn OFF the power supply before setting the temperature range.
 - (2) Never touch the DIP switch during Temperature Sensor Unit operation. Static electricity may cause operating errors.

DIP Switch Settings

Caution Set the temperature range according to the type of temperature sensor connected to the Unit. Temperature data will not be converted correctly if the temperature range does not match the sensor.

Caution Do not set the temperature range to any values other than those for which temperature ranges are given in the following table. An incorrect setting may cause operating errors.

The DIP switch is used to set the temperature unit and to set the temperature input range.



SW	Setting		
1	Input type	ON	J
		OFF	K
2	Temperature unit	ON	°F
		OFF	°C

Temperature input		
Input type	Range (°C)	Range (°F)
K	–200.0 to 1300.0	–300.0 to 2300.0
J	–100.0 to 850.0	–100.0 to 1500.0


Note Fahrenheit temperature uses the following equation to convert the temperature unit from Celsius, but the temperature input range is different between Fahrenheit and Celsius.

$$\text{Fahrenheit temperature (°F)} = \text{Celsius temperature (°C)} \times 1.8 + 32$$

Connecting Temperature Sensors

Thermocouples

Either K or J thermocouples can be connected, but all twelve of the thermocouples must be of the same type and the same input range must be used for each.



Note When connecting a thermocouple input, observe the following precautions:

- Do not remove the cold junction compensator attached at the time of delivery. If the cold junction compensator is removed, the Unit will not be able to measure temperatures correctly.
- Each of the input circuits is calibrated with the cold junction compensator attached to the Unit. If the Unit is used with the cold junction compensator from other Units, the Unit will not be able to measure temperatures correctly.
- Do not touch the cold junction compensator. Doing so may result in incorrect temperature measurement.
- Use the thermocouple with metallic shield and connect the shield to ground.

Open-circuit Detection Function for Temperature


If the circuit is disconnected, the open-circuit detection function will operate and the converted temperature data will be set to 7FFF.

Creating a Ladder Program

Word Allocations

Temperature Sensor Units are allocated words in the same way as other CP-series Expansion Units or Expansion I/O Units, in order of connection. A Temperature Sensor Unit is allocated the next input words following the input words of the CPU Unit or previous Expansion Unit or Expansion I/O Unit. Two input words and one output word are allocated to CP1W-TS004.

Example



Temperature Data Read Operation

There are 12 temperature input data to be read, but only two input words are allocated to CP1W-TS004. The operation is shown as the following.

Input Word

m+1	Response. Input words stored in CIO m+2
m+2	Temperature data of the specified input word

Output Word

n+1	Read command data (input word specified)
-----	--

Read/Response Command and Temperature Data

Command	Output Word	Input Word	
	n+1	m+1	m+2
	Read command	Response command	Temperature data (4-digit hexadecimal)
Read temperature data from input 0	#9901	9901	Input 0 temperature data
Read temperature data from input 1	#9902	9902	Input 1 temperature data
Read temperature data from input 2	#9903	9903	Input 2 temperature data
Read temperature data from input 3	#9904	9904	Input 3 temperature data
Read temperature data from input 4	#9905	9905	Input 4 temperature data
Read temperature data from input 5	#9906	9906	Input 5 temperature data
Read temperature data from input 6	#9907	9907	Input 6 temperature data
Read temperature data from input 7	#9908	9908	Input 7 temperature data
Read temperature data from input 8	#9909	9909	Input 8 temperature data
Read temperature data from input 9	#990A	990A	Input 9 temperature data
Read temperature data from input 10	#990B	990B	Input 10 temperature data
Read temperature data from input 11	#990C	990C	Input 11 temperature data
Others	Others	No response for other commands	


- Negative values are stored as 2's complements.
- The converted temperature data CIO m+2 is stored in 16-bit binary data (4-digit hexadecimal).
- Data for range codes that include one digit after the decimal point are stored without the decimal point, i.e., 10 times the actual value is stored.

Input		Data conversion examples	
Unit: 0.1°C	K or J	×10	500.0°C → 5000 → 1388 hex -20.0°C → -200 → FF38 hex -200.0°C → -2000 → F830 hex

- If the input temperature exceeds the maximum or minimum value in the temperature input range that has been set by $\pm 20^{\circ}\text{C}$ or $\pm 20^{\circ}\text{F}$, the displayed value will be held.
- If the circuit is disconnected, the open-circuit detection function will operate and the converted temperature data will be set to 7FFF.
- The open-circuit detection function will be automatically cleared and normal input temperature conversion will begin automatically when the input temperature returns to the convertible range.

Creating Ladder Program

- (1) Write temperature data command
Write temperature data command which read temperature data from input word to CIO n+1.
- (2) Response confirmation
After CP1W-TS004 receives CIO n+1 read command and CP1W-TS004's internally specified input temperature data is ready, the value which is the same as the read command will be stored in CIO m+1. The temperature data will be stored in CIO m+2 at the same time.
- (3) Read temperature data
Store the temperature data from CIO m+2 in DM area.




- Note**
- (1) It takes about 2ms maximum until it is reflected to CIO m+1 and m+2 from writing the read command to CIO n+1.
 - (2) It takes about 1s after the power is turned ON, till a read command initial processing of CP1W-TS004 is completed, so a response to the read command after power ON takes only about 1s. After the power is turned ON, create a ladder program 1s later due to its control by temperature data.
 - (3) When writing a command other than that specified in the temperature data read command, CIO m+1 and m+2 hold the previous value.


Programming Example


The temperature data of CP1W-TS004 (12 inputs, input type is J type and temperature unit is °C) is stored in D0 to D11.


When it occurs open-circuit alarm, W10.00~W10.11 is ON.


**Temperature Data Storage Address**

Input word	Read command CIO n+1	Temperature data storage address	Open-circuit alarm
Input 0	#9901	D0	W0.00
Input 1	#9902	D1	W0.01
Input 2	#9903	D2	W0.02
Input 3	#9904	D3	W0.03
Input 4	#9905	D4	W0.04
Input 5	#9906	D5	W0.05
Input 6	#9907	D6	W0.06
Input 7	#9908	D7	W0.07
Input 8	#9909	D8	W0.08
Input 9	#990A	D9	W0.09
Input 10	#990B	D10	W0.10
Input 11	#990C	D11	W0.11











7-6 CompoBus/S I/O Link Units

The CP1H can function as a slave to a CompoBus/S Master Unit (or SRM1 CompoBus/S Master Control Unit) when a CP1W-SRT21 CompoBus/S I/O Link Unit is connected. The CompoBus/S I/O Link Unit establishes an I/O link of 8 inputs and 8 outputs between the Master Unit and the PLC. Up to three CompoBus/S I/O Link Units, including other Expansion I/O Units, can be connected to a CP1H CPU Unit.



From the standpoint of the CP1H CPU Unit, the 8 input bits and 8 output bits allocated to the CompoBus/S I/O Link Unit are identical to input and output bits allocated to Expansion I/O Units even though the CompoBus/S I/O Link Unit does not control actual inputs and outputs. The input and output bits allocated to the CompoBus/S I/O Link Unit are one side of an I/O link between the slave CPU Unit and the CPU Unit to which the Master Unit is connected.




Specifications

Model number	CP1W-SRT21
Master/slave	CompoBus/S Slave
Number of I/O points	8 input points, 8 output points
Number of words allocated in CPU Unit I/O memory	1 input word, 1 output word (Allocated in the same way as Expansion Units and Expansion I/O Units.)
Node number setting	Set using the DIP switch (Set before turning on the CPU Unit's power supply.)


LED Indicators

Indicator	Name	Color	Meaning
COMM	Communications Indicator	Yellow	ON: Communications in progress. OFF: Communications stopped or error has occurred.
ERR	Error indicator	Red	ON: A communications error has occurred. OFF: Indicates normal communications or stand-by.

CP1W-SRT21 CompoBus/S I/O Link Unit



- (1) CompoBus/S Terminals
- The following CompoBus/S terminals are provided: CompoBus/S communications data high/low terminals, NC terminals for communications power supply plus (+) and minus (-), and an NC terminal. (Power is supplied internally for this Unit, so the NC terminals for communications power supply can be used as relay terminals.)
- (2) DIP Switch
- Used to specify the node number for the CompoBus/S I/O Link Unit. (Refer to the following table.)



Pin labels	Contents				
1	Node Number Setting	SW1			
2		8	4	2	1
4		0	0	0	0
8		1	0	0	1
		2	0	0	1
		3	0	0	1
		4	0	1	0
		5	0	1	0
		6	0	1	1
		7	0	1	1
		8	1	0	0
		9	1	0	1
		10	1	0	1
		11	1	0	1
		12	1	1	0
		13	1	1	0
		14	1	1	1
		15	1	1	1
	1 = ON, 0 = OFF				
DR	ON	Long-distance communications mode (See note.)			
	OFF	High-speed communications mode			
HOLD	ON	Retain inputs after a communications error.			
	OFF	Clear inputs after a communications error.			

Note: The long-distance communications mode can be used only when one of the following Master Units is connected: C200HW-SRM21-V1, CQM1-SRM21-V1, or SRM1-C0□-V2.

(3) LED Indicators

Used to show the CompoBus/S communications status.

Indicator	Name	Color	Meaning
COMM	Communications indicator	Yellow	ON: Communications in progress. OFF: Communications stopped or error has occurred.
ERR	Error indicator	Red	ON: A communications error has occurred. OFF: Indicates normal communications or stand-by.

(4) Expansion I/O Connecting Cable


Connected to the expansion connector of a CP1H CPU Unit or a CP-series Expansion Unit or Expansion I/O Unit. The cable is provided with the CompoBus/S I/O Link Unit and cannot be removed.

Note Do not touch the cables during operation. Static electricity may cause operating errors.

(5) Expansion Connector


Used to connect CP-series Expansion Units or Expansion I/O Units.

Operating Procedure



Connecting the CompoBus/S I/O Link Unit


CompoBus/S I/O Link Units are connected to the CP1H CPU Unit. Up to seven Units can be connected, including any other Expansion Units and Expansion I/O Units that are also connected. The Units can be connected in any order from the CPU Unit.




I/O Allocation

I/O words are allocated to the CompoBus/S I/O Link Unit in the same way as to other Expansion Units and Expansion I/O Units, i.e., the next available input and output words are allocated. As shown below, when “m” is the last allocated input word and “n” is the last allocated output word, the CompoBus/S I/O Link Unit is allocated “m+1” as its input word and “n+1” as its output word.


CompoBus/S I/O Link Unit




In the following example, a CompoBus/S I/O Link Unit is connected as the first Unit after the CP1H CPU Unit.



The input word (m+1) contains the 8 bits of data from the Master Unit and two CompoBus/S communications flags.



Write the data to be transmitted to the Master Unit in the output word (n+1).

**Note**

- (1) The 8 bits of I/O data are not always transmitted simultaneously. In other words, 8 bits of data transmitted from the Master CPU Unit at the same time will not always reach the Slave CPU Unit simultaneously, and 8 bits of data transmitted from the Slave CPU Unit at the same time will not always reach the Master CPU Unit simultaneously. When the 8 bits of input data must be read together, modify the ladder program in the CPU Unit receiving the data. For example, read the input data twice in succession and accept the data only when the two values match.
- (2) Unused bits in the CompoBus/S I/O Link Unit's output word can be used as work bits, but unused bits in the output slaves cannot be used as work bits.

(3) Unused bits in input word cannot be used as work bits.


Determining the Node Number and Making DIP Switch Settings

Node Number

- The CompoBus/S I/O Link Unit is a Slave Unit with 8 input bits and 8 output bits. The node number setting is made using the DIP switch; the inputs and outputs share the same node number.
- The range of possible node number settings is determined by the type of PC the Master Unit is mounted to and the settings on the Master Unit. For details refer to the *CompoBus/S Operation Manual*.

DIP Switch Settings

Use the DIP switch to set the CompoBus/S I/O Link Unit's node number, communications mode, and the status of output data when a communications error occurs.




Note: The long-distance communications mode can be used only when one of the following Master Units is connected: C200HW-SRM21-V1, CQM1-SRM21-V1, or SRM1-C0□-V2.

Pin labels	Contents				
1	Node Number Setting	SW1			
2		8	4	2	1
4		0	0	0	0
8		1	0	0	1
		2	0	0	1
		3	0	0	1
		4	0	1	0
		5	0	1	0
		6	0	1	1
		7	0	1	1
		8	1	0	0
		9	1	0	0
		10	1	0	1
		11	1	0	1
		12	1	1	0
		13	1	1	0
		14	1	1	1
		15	1	1	1
	1 = ON, 0 = OFF				
DR	ON	Long-distance communications mode (See note.)			
	OFF	High-speed communications mode			
HOLD	ON	Retain inputs after a communications error.			
	OFF	Clear inputs after a communications error.			

Note Always turn OFF the power supply before changing the DIP switch settings.

Wiring the CompoBus/S Communications Path

Wire the CompoBus/S communications path as shown in the following diagrams.



SECTION 8

LCD Option Board

This section gives an outline of the LCD Option Board, explains how to install and remove the LCD Option Board, and describes the functions including how to monitor and make settings for the PLC. It also lists the errors during operation and provides probable causes and countermeasures for troubleshooting.

8-1	Features	486
8-2	Specifications	487
8-3	Part Names	488
8-4	Installation and Removing	489
8-5	Basic Operation	490
8-5-1	Startup	490
8-5-2	Screen Transitions	491
8-5-3	Operation Examples	493
8-6	LCD Option Board Function	495
8-6-1	Function Overview	495
8-6-2	PLC Mode	498
8-6-3	I/O Memory Setting	499
8-6-4	PLC Setup	504
8-6-5	Analog	506
8-6-6	Error	507
8-6-7	Memory Cassette	510
8-6-8	User Monitor Screen	514
8-6-9	Message Screen	523
8-6-10	Timer Switch	528
8-6-11	Data Backup	534
8-6-12	Language Selection	537
8-6-13	PLC Cycle Time	538
8-6-14	PLC Clock Setting	539
8-6-15	PLC System Information	540
8-6-16	LCD Backlight Setting	541
8-6-17	LCD Contrast Setting	542
8-6-18	LCD Factory Setting	543
8-7	Trouble Shooting	544
8-7-1	Symptom at Power ON or during Operation	544
8-7-2	Communication Error Message during Operation	544
8-7-3	Deleting EEPROM Error	545

8-1 Features

LCD Option Board is small but has a wide range of functions and is easy to use.

Powerful Display and Setting Functions

Equipped for easy display and set up of user-specified messages, time or other data of the PLC.

User Monitor Screen

Preset the screen, including I/O memory and text string, which user will monitor frequently. So it is easy for user to acquire his necessary data. It is possible to register up to 16 screens.

Timer Switch

Preset the timer, including Day, Weekly and Calendar Timer. Each timer can execute a trans-day, trans-week or trans-year operation. So a 24-hours control will be effected by one-step setting. It is possible to register up to 16 timers for each kind.

Easier to Identify with Backlight

When PLC error occurs, the red backlight of LCD display screen will begin to blink, quickly altering you of the error.


Normally the backlight is green. The automatic cutout time for the backlight can be set to occur from 2 to 30 minutes, or even set permanently to OFF or ON position.

The contrast level can also be adjusted.






8-2 Specifications

Item	Specification
Model	CP1W-DAM01
Type	Built-in
Serial port	Only port 1
Communication protocol	Toolbus
DC consumption	5V : 40mA 24V : 0mA
Dimensions	43×36×23 mm (W×H×D)
Weight	20g max.
Screen size	2.6cm×1.45cm
Total characters on screen	4 lines×12 characters
Font size	5×7 dot
Backlight color	Green / Red
Display language	English / Japanese (Katakana)
Ambient operating temperature	0 to 55°C
Ambient operating humidity	10% to 90% (with no condensation)
Atmosphere	No corrosive gas.
Ambient storage condition	<p>(with no condensation)</p>

8-3 Part Names



Operation Button

No.	Button	Function
a	 ESC	Cancel the setting and return to the up-level menu.
b	 Forward	Move the column cursor. Press and hold the button, the column cursor will move forward continuously.
c	 Up	Move the line cursor up. Change numerals and parameters. Press and hold the button, the line cursor will move up continuously and the parameters will increase continuously.
d	 Down	Move the line cursor down. Change numerals and parameters. Press and hold the button, the line cursor will move down continuously and the parameters will decrease continuously.
e	 OK	Confirm the setting.

Backlight

Color	Meaning
Green	PLC is normal.
Red	PLC error has occurred.

8-4 Installation and Removing


Installation

The following processing explains how to install and remove a LCD Option Board.

Caution Always turn OFF the power supply to the CPU Unit and wait until all the operation indicators go out before installing or removing the LCD Option Board.


1,2,3...

1. Press the up/down lock levers on both sides of the Option Board slot cover 1 at the same time to unlock the cover, and then pull the cover out.
2. Check the alignment to make the corner cut of the LCD Option Board fit in the Option Board slot 1, and firmly press the LCD Option Board in until it snaps into place.




3. Switch DipSW4 of the CPU Unit to ON.

Note DipSW4 is OFF at shipment



Removing

Press the up/down lock levers on both sides of the LCD Option Board at the same time to unlock the Option Board, and then pull it out.



8-5 Basic Operation


8-5-1 Startup

According to the operation status of the LCD Option Board, it will display different screens when the CPU Unit power is turned ON.

Normal Startup

When the CPU Unit power is turned ON, the LCD Option Board will initialize hardware and check EEPROM, then check communication between the LCD Option Board and the CPU Unit. If startup is normal, LCD will display Clock Screen as shown below.

Clock Screen




No.	Description
a	Type of the CPU Unit
b	Date of the CPU Unit
c	Time of the CPU Unit
d	Week abbreviation of the CPU Unit

Startup Failure


- If EEPROM is faulty, LCD will display EEPROM Error Screen and the red backlight will blink. Refer to *8-7 Trouble Shooting*.

EEPROM Error Screen



- If the communication between the LCD Option Board and the CPU Unit has failed, LCD will display NG screen. Refer to *8-7 Trouble Shooting*.


NG Screen



Note If the LCD Option Board receives no response from the CPU Unit within 3 seconds during operation, it will also display NG screen.

8-5-2 Screen Transitions

The screen transition of the LCD Option Board as shown in the following diagram.




- Note**
1. The screen will be displayed after making settings in the Setup Mode.
 2. The Message Screen will disappeared automatically after control bit is OFF.
 3. In the Setup Mode, if there is no operation for 10 minutes, LCD will automatically switch to the Monitor Mode.


Screen Transition Example in the Monitor Mode

In this example, User Monitor Screen 1 and Message Screen 2, Message Screen 6 have been set.


Control bit is OFF




Control bit 1 is ON




Control bit 5 is ON during control bit 1 ON



Control bit 1 is OFF



Control bit 1 and bit 5 are ON at the same time



Note

1. When one control bit is ON, the Clock Screen or the User Monitor Screen will switch to the Message Screen automatically.
2. If another control bit is ON when the Clock Screen or the User Monitor Screen is displayed, the display will switch to another Message Screen.
3. If another control bit is ON when one Message Screen is displayed, the display will not change until one of the control bit is OFF.

4. If another control bit is bigger, the display will switch to another Message Screen after one of the control bit is OFF. If another control bit is smaller, the display will switch to the Clock Screen after one of the control bit is OFF.
5. When no less than one control bit are ON at the same time, the Message Screen whose Screen No. is smaller will be displayed.
6. If one control bit is ON during the period that PLC error occurs, the display remains the Error Screen. Even if the error is eliminated, the display will not switch to the Message Screen, but return to the Clock Screen.





8-5-3 Operation Examples

With actual operation examples, the main operation flow of the LCD Option Board as shown below.

Menu Selection

Display the Monitor Screen of I/O memory.

1,2,3...



1. Turn on the power to the CPU Unit. Clock Screen will be displayed.
2. Press the **OK + ESC** button simultaneously to switch to the main menu. The line cursor ">" is always displayed on the first line of menu items.
3. Press the **Down** or **Up** button to select the menu item. Move the line cursor to **IO Memory**.
4. Press the **OK** button to enter the submenu.
5. Press the **Down** or **Up** button to select the I/O memory type. Move the line cursor to **DM**.
6. Press the **OK** button to enter the Monitor Screen of I/O memory.

Displaying I/O Memory

Display any data of I/O memory. In this example, two word data on D10001 to D10002, D10003 to D10004 with unsigned decimal number will be displayed.

1,2,3...

```
D00000 # W
+0:#98F0
+1:#F5F5
+2:#1234
```

```
D10000 # W
+0:#98F0
+1:#F5F5
+2:#1234
```

```
D10001 & W
&1236547890
+2
&1236547890
```

1. Line 1 will display the default address D00000 in I/O memory, Line 2 to 4 will display one word data on D00000, D00001, D00002 with hex number when entering the Monitor Screen of I/O memory.
The first digit of memory address "0" will flash. The column cursor is at the flashing position.
The digit under the column cursor can be changed, otherwise it is read only.
2. Use the **Forward** button to move the column cursor to the digit to be set.
Use the **Down** or **Up** button to change the value of each digit.
The screen display will be updated immediately after the address is changed.
3. Use the **Forward** button to move the column cursor to another parameter to be set.
Use the **Down** or **Up** button to select the value of parameter.
The screen display will be updated immediately after the parameter is changed.

Changing I/O Memory


Change any data of I/O memory. In this example, the data of I/O memory on D10001 will be changed.

1,2,3...

```
D10001 # W
+0:#98F0
+1:#F5F5
+2:#1234
```

```
D10001 # W
#98F0 #98F0
```

1. Display I/O memory.
2. Press the **OK** button to enter the Change Screen of I/O memory.
The column cursor is at the "#" position.
Use the **Down** or **Up** button to select the value of parameter.



- Use the **Forward** button to move the column cursor to the data of I/O memory. Use the **Down** or **Up** button to change the value of each digit.

- Press the **OK** button to save the setting. Press the **ESC** button to return to the previous screen. The data displayed in the Monitor Screen will be changed.

Press the **ESC** button to cancel the setting and return to the previous screen.


8-6 LCD Option Board Function

This section describes the functions of the LCD Option Board including how to monitor and make settings for the PLC.

8-6-1 Function Overview


PLC Mode

Display the present PLC mode and change the PLC mode. Refer to *Page 498* for details.




I/O Memory Setting

Monitor and change the data of I/O Memory. Refer to *Page 499* for details.



PLC Setup

Monitor and change the PLC Setup, especially fast access the CPU Unit Operating Mode. Refer to *Page 504* for details.



Analog

Monitor the value from the analog adjuster and external analog setting input of the PLC.

Refer to *Page 506* for details.




```
[Analog] RUN
>AnalogVol
```

Error History

Display the list of error history and the details of each error. It is possible to display up to 20 screens. User can also monitor the occurring errors.

Refer to *Page 508* for details.



```
[Error]
>ErrorLog
ErrorMon
```

Memory Cassette

The LCD Option Board can execute any of the following operations.

- Load data from memory cassette to PLC.
- Save data from PLC to memory cassette.
- Compare data between PLC and memory cassette.
- Clear data in memory cassette.

Refer to *Page 510* for details.



```
[MC] PRG
>MC->PLC
PLC->MC
Compare
```

User Monitor Screen

Set or delete User Monitor Screen, which includes some elements such as I/O word memory, bit memory or text string. It is possible to register up to 16 screens. User can monitor his necessary data in the User Monitor Screen.

Refer to *Page 514* for details.




```
[UserMon]
>Setup
Delete
```

Message Screen

Set or delete Message Screen. It is possible to register up to 16 screens. User can monitor the text message in the Message Screen when control bit is ON.

Refer to *Page 523* for details.



```
[Message]
>Setup
Delete
```

Timer Switch

Set day, weekly and calendar timers. It is possible to register up to 16 timers for each kind. Each timer can execute a trans-day, trans-week or trans-year operation.

Refer to *Page 528* for details.

**Data Backup**

The LCD Option Board can execute any of the following operations.

- Load user settings from DM area.
- Save user settings to DM area.


So user can save the user settings to the DM area of the PLC from one LCD Option Board and load to other LCD Option Boards from the DM area.

Refer to *Page 534* for details.

**Language**


Change the language of the LCD display between English and Japanese.

Refer to *page 537* for details.

**Other**

- PLC Cycle Time
- PLC Clock Setting
- PLC System Information
- LCD Backlight Setting
- LCD Contrast Setting
- LCD Factory Setting

Refer to *Page 539 to 542* for details.



8-6-2 PLC Mode

This function can display the present PLC mode and change the PLC mode.

Example

Change the PLC Mode from RUN to PRG.

1,2,3...

```
[Menu]
>Mode
IO Memory
PLC Setup
▼
```

```
[Mode]    RUN
>RUN
MONITOR
PROGRAM
▼
```

```
[Mode]    RUN
RUN
MONITOR
>PROGRAM
▲
```

```
[Mode]    PRG
RUN
MONITOR
>PROGRAM
▲
```



1. Switch to the Setup Mode.
2. Press the **OK** button to enter the Mode Screen.
There is a choice of 3 PLC modes-RUN/MON/PRG.
The line cursor will point to the present PLC mode.
The present mode is ***RUN***.
3. Press the **Down** button to select ***PROGRAM***.
4. Press the **OK** button, then LCD will update the present mode to ***PRG***.

8-6-3 I/O Memory Setting

Displaying I/O Memory

Example Monitor two word data on D10001 to D10002, D10003 to D10004 with unsigned decimal number.

1,2,3...



1. Switch to the Setup Mode.
2. Press the **Down** button to select *IO Memory*.
3. Press the **OK** button to enter the I/O Memory menu.
4. Press the **Down** button to select *DM*.
5. Press the **OK** button to enter the Monitor Screen of I/O memory DM.
The following table shows the setting items.

No.	Description
a	Leading word address
b	Display format
c	Data length

The first digit of the leading word address will be flashing.
The present setting is the default address.
Line 2 to 4 will display one word data on D00000, D00001, D00002 with hex number.

6. Use the **Forward** button to move the column cursor to the digit to be set.
Use the **Up** button to change the leading word address to *10001*.

The following table shows the default address and the setting range for each I/O memory type.

I/O memory type	Default address	Range
TIM	0000	0000 to 4095
CNT	0000	0000 to 4095
DM	00000	00000 to 32767
AR	000	000 to 959
IO	0000	0000 to 6143
WR	000	000 to 511
HR	000	000 to 511
DR	00	00 to 15
IR	00	00 to 15
TK	00	00 to 31

Note LongWord has only five display types, DM, IO, WR, HR and AR.

7. Use the **Forward** button to move the column cursor to the display format position.

Press the **Down** or **Up** button to select the display format **&**.

Select the display format in the following table.

Display format	Meaning
#	Hex number
+	Signed decimal number
&	Unsigned decimal number

8. Use the **Forward** button to move the column cursor to the data length position.

Press the **Down** or **Up** button to select the data length **LW**.

Select the data length in the following table.

Data length	Meaning
W	One word data
LW	Two word data

Then it will display two word data on D10001 to D10002, D10003 to D10004 with unsigned decimal number.

Note The screen display will be updated immediately after the address, display format or data length is changed.

```
D10001  W
+0:832767
+1:832768
+2:832769
```

```
D10001  & LW
&1234567890
+2
&1234567890
```

Changing I/O Memory

Example

First change two word data on W000 to 12345678, then change one word data on W509 to 98F5 and set the control bit 509.05 to OFF.

1,2,3...

```
[Menu]
>Mode
  ID Memory
  PLC Setup
  ▾
```

```
[Menu]
  Mode
  >ID Memory
  PLC Setup
  ▲ ▾
```

```
[ID Mem]
>TIM
  CNT
  DM
  ▲ ▾
```

```
[ID Mem]
  AR
  IO
  >WR
  ▲ ▾
```

```
W000 # W
+0:#98F0
+1:#F5F5
+2:#1234
```




```
W000 # LW
#22221111
+2
#44443333
```

```

1 2 3
↓ ↓ ↓
W000 # LW
#22221111 ← 4
#22221111 ← 5
```

1. Switch to the Setup Mode.
2. Press the **Down** button to select **IO Memory**.
3. Press the **OK** button to enter the I/O Memory menu.
4. Press the **Down** button to select **WR**.
5. Press the **OK** button to enter the Monitor Screen of I/O memory WR.
6. Use the **Forward** button to move the column cursor to the data length position.
Press the **Down** or **Up** button to select the data length **LW**.
7. Press the **OK** button to enter the Change Screen of I/O memory W000.
The following table shows the setting items.

No.	Attributes
1	Head channel address (Read only)
2	Display format (Read only)
3	Data length (Read only)
4	Data of I/O memory before change (Read only)
5	Data of I/O memory after change



8. Press the **Forward** button to move the column cursor to the digit to be set.
Use the **Down** or **Up** button to change the data to **12345678**.


9. Press the **OK** button to save the setting.
Press the **ESC** button to return to the previous screen.
Then the data on W000 displayed in the Monitor Screen will be 12345678.

10. Change the leading word address to **509** to update the screen display.

11. Press the **OK** button to enter the Change Screen of I/O memory W509.
The following table shows the setting items.

No.	Description
a	Leading word address(Read only)
b	Display format(Read only)
c	Data length(Read only)
d	Data of I/O memory before change (Read only)
e	Data of I/O memory after change
f	Bit address
g	Bit flag
h	Bit state

Note If the display format is a decimal number (& or +), or the data length is a LongWord, user cannot make a setting for bit.



12. Move the column cursor to the digit to be set.
Use the **Up** button to change the data to **98F5**.

13. Use the **Forward** button to move the column cursor to the position of bit address.
The present setting is the default address. The range is 00~15.

```

W509      # W
#98F0 #98F5
W509.05   N
          ON

```

```

W509      # W
#98F0 #98F5
W509.05   █
          ON

```

```

W509      # W
#98F0 #98F5
W509.05   N
          █

```

```

W509      # W
#98F0 #98F5
W509.05   N
          OFF

```

```

W509      # W
+0: #98D5
+1: #F5F5
+2: #1234

```

14. Use the **Up** button to change the bit address to **05**.

15. Use the **Forward** button to move the column cursor to the bit flag position.
The present setting is the default setting.
Select the bit flag in the following table.

Bit flag	Meaning
N	Normal
S	Force to SET
R	Force to RESET

16. Use the **Forward** button to move the column cursor to the bit state position.
The present state is ON. The state ON or OFF is according to PLC.

17. Press the **Down** or **Up** button to select the bit state **OFF**.

Note If bit flag is S or R, the setting of bit state is invalid.

18. Press the **OK** button to save the setting.

Press the **ESC** button to return to the previous screen.

Then the data on W509 displayed in the Monitor Screen will be 98D5.

8-6-4 PLC Setup

This function can display and change the settings in the PLC Setup.

Example 1

Change the CPU Unit Operating Mode from PRG to RUN.

1,2,3...




1. Switch to the Setup Mode.



2. Press the **Down** button to select **PLC Setup**.



3. Press the **OK** button to enter the PLC Setup menu.



4. Press the **OK** button to enter the CPU Unit Operating Mode Screen. The following table shows the setting items.


No.	Attributes
a	Address of CPU Unit Operating Mode (Read only)
b	Present PLC mode (Read only)
c	CPU Unit Operating Mode after change (Read only when PLC mode is RUN or MON)
d	CPU Unit Operating Mode before change (Read only)

The address of CPU Unit Operating Mode is always 081, so there is no need to change the address.




5. Use the **Up** button to select **RUN**.

Note Before changing the CPU Unit Operating Mode, make sure that the present PLC mode is PRG. If PLC is in RUN or MON mode, the CPU Unit Operating Mode is unchangeable.





6. Press the **OK** button to save the setting.



7. Press the **ESC** or **OK** button to return to the previous menu.

Example 2 Display the value of PLC Setup on 080. Then change the value to 0195.



1,2,3...



1. Switch to the Setup Mode.
2. Press the **Down** button to select **PLC Setup**.
3. Press the **OK** button to enter the PLC Setup menu.
4. Press the **Down** button to select **PLC Setup**.
5. Press the **OK** button to enter the PLC Setup Screen
The following table shows the setting items.


No.	Description
a	Address of PLC Setup
b	PLC mode (Read only)
c	Value of PLC Setup after change (Read only when PLC mode is RUN or MON)
d	Value of PLC Setup before change (Read only)

The first digit of PLC Setup address will be flashing. The range of the address is 000 to 511.




6. Use the **Up** button to change the address to **080**.
After the address is changed, the value of PLC Setup will be updated immediately.
7. Use the **Forward** button to move the column cursor to the value of PLC Setup.
Use the **Up** button to change the value to **0195**.

Note Before changing the value of PLC Setup, make sure that the PLC mode is PRG. If PLC is in RUN or MON mode, the value is unchangeable.



8. Press the **OK** button to save the setting.



9. Press the **ESC** or **OK** button to return to the PLC Setup Screen.

8-6-5 Analog

Displaying Analog Settings

Example Monitor the external analog setting input with unsigned decimal number.


1,2,3...




1. Switch to the Setup Mode.




2. Press the **Down** button to select Analog.




3. Press the **OK** button to enter the Analog menu.



4. Press the **OK** button to enter the Monitor Screen of analog setting.
Line 2 will display the value from the analog adjuster.
Line 4 will display the external analog setting input value.
The display format on line 2 will be flashing.



5. Use the **Forward** button to move the column cursor to the display format position on line 4.



6. Press the **Down** or **Up** button to change the display format to **&**.


```
[Analog] RUN
>AnalogVol
```

7. Press the **ESC** button to return to the previous screen.

8-6-6 Error

This function can display the list of error history and the details of each error. It is possible to display up to 20 screens. User can also monitor the occurring errors in the Error Monitor Screen.

Displaying and Clearing Error History

Example Display the list of error history and then clear it.

1,2,3...

```
[Menu]
>Mode
  IO Memory
  PLC Setup
```

1. Switch to the Setup Mode.

```
[Menu]
>Analog
  Error
  MC
```

2. Press the **Down** button to select **Error**.

```
[Error]
>ErrorLog
  ErrorMon
```

3. Press the **OK** button to enter the Error menu.

```
[ErrorLog]
>MemoryErr
  Bus Unit
  FALS 024
```

4. Press the **OK** button to enter the Error History Screen. Error history will be displayed in this screen.

```
1. MemoryErr
2007/11/22
15:30:02
Code: 0002
```

5. Press the **OK** button to enter the Error Screen details. The following table shows the display items.

No.	Description
a	Error number(1 to 20)
b	Error type
c	The date error occurred
d	The time error occurred
e	Error code

```
11.MemoryErr
2007/11/28
13:26:35
Code:0002
```

6. If there is more than one error, press the **Down** button to scroll the screen and display the details of the next error.

```
[ErrorLog]
MemoryErr
>CLR ErrLog
```

7. Press the **ESC** button to return to the Error History Screen.
Press the **Down** button to select **CLR ErrLog** which is always below the last error.

```
[CLR ErrLog]
>Cancel
OK
```

8. Press the **OK** button to enter the Error Clear Screen.

```
[CLR ErrLog]
Cancel
>OK
```

9. Press the **Down** button to select **OK**.

Note Selecting **Cancel** will result in a return to the previous screen.

```
[CLR ErrLog]
Complete
```

10. Press the **OK** button to clear the error history.
When the clearing is finished, it will display a complete screen.

```
[ErrorLog]
```

11. Press the **ESC** button to return to the Error History Screen.
All the errors have been cleared.

Clearing Occurring Error List

Example Clear memory error in the list that occurs at the present time.

1,2,3...

```
[Menu]
>Mode
IO Memory
PLC Setup
```

1. Switch to the Setup Mode.

```
[Menu]
Analog
>Error
MC
```

2. Press the **Down** button to select **Error**.




```
[Error]
>ErrorLog
ErrorMon
  ▾
```

3. Press the **OK** button to enter the Error menu.




```
[Error]
ErrorLog
>ErrorMon
  ▲
```

4. Press the **Down** button to select **ErrorMon**.



```
[ErrMon] PRG
>MemoryErr
Bus Unit
CLR Err
  ▸
```

5. Press the **OK** button to enter the Error Monitor Screen.
Max. 2 errors that occur the earliest will be displayed.



```
[ErrMon] PRG
MemoryErr
Bus Unit
>CLR Err
  ▾
```

6. Press the **Down** button to select **CLR Err**.




```
[CLR Err]
>Cancel
OK
  ▾
```

7. Press the **OK** button to enter the Error Clear Screen.



```
[CLR Err]
Cancel
>OK
  ▲
```


8. Press the **Down** button to select **OK**.



```
[ErrMon] PRG
Bus Unit
>CLR Err
  ▾
```

9. Press the **OK** button to clear the memory error in the list.

Note Only one error that occurs the earliest in the list will be cleared one time.



```
[ErrMon] RUN
MemoryErr
Bus Unit
>CLR Err
  ▾
```

10. If the memory error itself has not been eliminated, when the Error Monitor Screen is updated, the error will be displayed again in the screen.

8-6-7 Memory Cassette

Before Operation

- Memory Cassette should be equipped into the PLC. Otherwise LCD cannot operate Memory Cassette.
- Make sure that the PLC mode is PRG. If the PLC is in RUN or MON mode, the operation of Memory Cassette cannot be executed.


Loading Data from Memory Cassette to PLC

Example Load data from Memory Cassette to the PLC.


1,2,3...



1. Switch to the Setup Mode.



2. Press the **Down** button to select **MC**.




3. Press the **OK** button to enter the Memory Cassette menu.
The following table shows the setting items.


No.	Description
a	PLC mode (Read only)
b	Operation mode

Select the operation mode in the following table.

Operation Mode	Meaning
MC->PLC	Load data from memory cassette to PLC
PLC->MC	Save data from PLC to memory cassette
Compare	Compare data between PLC and MC
Clear	Format memory cassette




4. Press the **OK** button to enter the "MC->PLC" Operation Screen.




5. Press the **Down** button to select **OK**.

Note Selecting **Cancel** will result in a return to the previous menu.



6. Press the **OK** button to start loading.
A rate of loading will be displayed in the screen.




7. When the rate comes up to 0%, the loading is finished. Then it will display a complete screen.


Saving Data from PLC to Memory Cassette

Example Save data from the PLC to Memory Cassette.

1,2,3...



1. Switch to the Setup Mode.




2. Press the **Down** button to select **MC**.



3. Press the **OK** button to enter the Memory Cassette menu.




4. Press the **Down** button to select **PLC->MC**.



5. Press the **[OK]** button to enter the "PLC->MC" menu.
Select the saving mode in the following table.

Saving Mode	Meaning
Autoboot PRG	If the power turns ON, the operation cannot be executed.
Autoboot RUN	Even if the power turns ON, the operation can be executed.




- Press the **OK** button to enter the "PLC->MC" Operation Screen.




- Press the **Down** button to select **OK**.

Note Selecting **Cancel** will result in a return to the previous menu.



- Press the **OK** button to start saving.
A rate of saving will be displayed in the screen.



- When the rate comes up to 0%, the saving is finished. Then it will display a complete screen.


Comparing Data between PLC and MC

Example Compare the data between the PLC and Memory Cassette.


1,2,3...




- Switch to the Setup Mode.



- Press the **Down** button to select **MC**.



- Press the **OK** button to enter the Memory Cassette Screen.



- Press the **Down** button to select **Compare**.



- Press the **OK** button to enter the Compare Operation Screen.




- Press the **Down** button to select **OK**.

Note Selecting **Cancel** will result in a return to the previous menu.



- Press the **OK** button to start comparing.
A rate of comparison will be displayed in the screen.




- When the rate comes up to 0%, the comparing is finished. Then it will display a result of comparison.


Clearing Memory Cassette

Example Clear the data in Memory Cassette.


1,2,3...




- Switch to the Setup Mode.




- Press the **Down** button to select **MC**.



- Press the **OK** button to enter the Memory Cassette menu.



- Press the **Down** button to select **Clear**.




5. Press the **OK** button to enter the Clear Operation Screen.




6. Press the **Down** button to select **OK**.

Note Selecting **Cancel** will result in a return to the previous menu.



7. Press the **OK** button to start clearing.
A rate of clearance will be displayed in the screen.



8. When the rate comes up to 0%, the clearing is finished. Then it will display a complete screen.


8-6-8 User Monitor Screen

This function can set or delete User Monitor Screen. It is possible to register up to 16 screens. User can monitor his necessary data in the User Monitor Screen. Each User Monitor Screen includes 4 lines of content. Each line has three kinds of display type including word memory, bit memory and text string.


Creating New User Monitor Screen

Example 1 Monitor one word data on the word address D09000 with unsigned decimal number through User Monitor Screen 2, displayed on Line 1.

1,2,3...




1. Switch to the Setup Mode.



2. Press the **Down** button to select **UserMonitor**.



3. Press the **OK** button to enter the User Monitor menu.








4. Press the **OK** button to enter the User Monitor Setup Screen.

The final digit of the Screen No. will be flashing.

The following table shows the setting items for each display type.

No.	Description	Display type		
		Word	Bit	Text string
a	Monitor flag	Yes	Yes	Yes
b	User Monitor Screen No. (01 to 16)	Yes	Yes	Yes
c	Line No. (1 to 4) of the User Monitor Screen	Yes	Yes	Yes
d	Display type	Yes	Yes	Yes
e	I/O memory address	Yes	Yes	No
f	Display format	Yes	No	No
g	Date length	Yes	No	No
h	I/O memory name	Yes	Yes	Yes

5. Use the **Up** button to change the Screen No. to **2**.



6. Use the **Forward** button to move the column cursor to the monitor flag position. Select the monitor flag in the following table.

Monitor flag	Meaning
Y	User Monitor Screen in use
N	User Monitor Screen not in use

7. Press the **Up** button to select the monitor flag **Y**. Then user can monitor this screen after the setting is complete.

8. Use the **Forward** button to move the column cursor to the Line No. position. The present setting is Line **1**.

9. Use the **Forward** button to move the column cursor to the display type position. The following table shows the display types which can be selected, including the default address and the setting range for each type.

Display type		Default address	Range
Word	IO	0000	0000 to 6143
	WR	000	000 to 511
	HR	000	000 to 511
	AR	000	000 to 959
	TIM	0000	0000 to 4095
	CNT	0000	0000 to 4095
	DM	00000	00000 to 32767
	DR	00	00 to 15
	IR	00	00 to 15
	TK	00	00 to 31
	TMF(Timer flag)	0000	0000 to 4095
	CTF(Timer flag)	0000	0000 to 4095
Bit	IOB	0000.00	0000.00 to 6143.15
	WRB	000.00	000.00 to 511.15
	HRB	000.00	000.00 to 511.15
	ARB	000.00	000.00 to 959.15
Text string	STR	-	-

```

Setup Y No02
Line1  DM
D00000 # W
Name:

```

10. Press the **Up** button to select **DM**.

```

Setup Y No02
Line1  DM
D00000 # W
Name:

```

11. Use the **Forward** button to move the column cursor to the memory address position.

The present setting is the default address.

```

Setup Y No02
Line1  DM
D00000 # W
Name:

```

12. Move the column cursor to the digit to be set.
Use the **Up** button to change the memory address to **09000**.

```

Setup Y No02
Line1  DM
D09000 # W
Name:

```

13. Use the **Forward** button to move the column cursor to the display format position.

Select the display format in the following table.

Display format	Meaning
#	Hex number
+	Signed decimal number
&	Unsigned decimal number

```

Setup Y No02
Line1  DM
D09000  W
Name:

```

```

Setup Y No02
Line1  DM
D09000  & W
Name:

```

```

Setup Y No02
Line1  DM
D09000  & W
Name:

```

```

Setup Y No02
Line1  DM
D09000  & W
Name:Counter

```

```

Set OK
[Esc]

```

```

Setup Y No02
Line1  DM
D09000  & W
Name:Counter

```

```

Counter
&12345

```

14. Press the **Down** or **Up** button to select the display format **&**.

15. Use the **Forward** button to move the column cursor to the data length position.
The present setting is **W**.
Select the data length in the following table.

Data length	Meaning
W	One word data
LW	Two word data

16. Use the **Forward** button to move the column cursor to the position of Name.

17. Use the **Down** or **Up** button to select the character of each digit.
Name the word to **Counter**.

Note

1. When selecting the character of the next digit, the leading character will be the character of the digit before.
2. The max length of word or bit name is 7 characters.

18. Press the **OK** button to save the setting.

19. Press the **ESC** or **OK** button to return to the User Monitor Setup Screen.

20. Press the **ESC** button three times to return to the Monitor Mode.
Switch to the User Monitor Screen 2 with the **Down** button.

Note

1. Setting of word or bit name is not necessary. The default name is NULL, and the memory address will be displayed at the name position in the User Monitor Screen.
2. One line setting will take 1 or 2 lines of space. If word or bit name length is more than 5 characters or data length is a LongWord, it will take 2 lines of space.
3. One screen only has 4 lines of space available. If one line setting has already taken 2 lines of space, the next line setting will be invalid. If the setting of line 4 takes 2 lines of space, its setting will be invalid.

Example 2 Display a text string "elevator" on the User Monitor Screen 2, Line 4, after the setting in example 1.

1,2,3...

```
[Menu]
>Mode
IO Memory
PLC Setup
▼
```

1. Switch to the Setup Mode.

```
[Menu]
>UserMonitor
Message
Timer
▲ ▼
```

2. Press the **Down** button to select **UserMonitor**.

```
[UserMon]
>Setup
Delete
▼
```

3. Press the **OK** button to enter the User Monitor menu.

```
Setup N No01
Line1 IO
0000 # U
Name:
```

4. Press the **OK** button to enter the User Monitor Setup Screen.

```
Setup Y No02
Line1 DM
D0900 & W
Name:Counter
```

5. Use the **Up** button to change the Screen No. to **2**.
The setting in example 1 will be displayed.

```
Setup Y No02
Line4 IO
0000 # U
Name:
```

6. Use the **Forward** button to move the column cursor to the Line No. position.
Use the **Up** button to change the Line No. to **4**.

```
Setup Y No02
Line4 STR
```

7. Use the **Forward** button to move the column cursor to the display type position.
Press the **Up** button to select **STR**.

```
Setup Y No02
Line4 STR
■
```

8. Use the **Forward** button to move the column cursor to the position of String Name.

```

Setup Y No02
Line4   STR
elevator

```

9. Use the **Down** or **Up** button to select the character of each digit.
Name the text string to **elevator**.

```

Set OK
[Esc]

```

10. Press the **OK** button to save the setting.

```

Setup Y No02
Line4   STR
elevator

```

11. Press the **ESC** or **OK** button to return to the User Monitor Setup Screen.

```

Counter:
      812345
elevator

```

12. Press the **ESC** button three times to return to the Monitor Mode.
Switch to the User Monitor Screen 2.

Note

1. The default text string is NULL.
2. The max length of text string is 12 characters.

Changing User Monitor Screen

User can not only change the date displayed in the User Monitor Screen in the Setup Mode, but also in the Monitor Mode.

Example 1

Change the average to 0100 and the minimum to -00123.

1,2,3...

```

Avg   #1000
Min   +00123
Max
800000009999

```

1. Display the User Monitor Screen.

```

Avg   ##1000
Min   +00123
Max
800000009999

```

2. Press the **Forward + OK** button simultaneously to enter the Data Change Screen.
The column cursor will be flashing on the digit before the value.

```

Avg   #11000
Min   +00123
Max
800000009999

```

3. Use the **Forward** button to move the column cursor to the digit to be set.

```

Avg   #0100
Min   +00123
Max
800000009999

```

```

Avg   ##0100
Min   +00123
Max
800000009999

```

```

Avg   #0100
Min   ■+00123
Max
800000009999

```

```

Avg   #0100
Min   ■00123
Max
800000009999

```

```

Avg   #0100
Min   ■-00123
Max
800000009999

```

```

Avg   #0100
Min   +00123
Max
800000009999

```

4. Use the **Up** button to change the value to **0100**.

5. Press the **OK** button to save the setting.
The column cursor will return to the digit before the value.

6. Use the **Down** button to move the cursor to line 2.

Note Only when the cursor is on the digit before the value, press the **Down** or **Up** button to move the cursor to other lines.


7. Use the **Forward** button to move the column cursor to the sign position.
Press the **Down** or **Up** button to change the sign to -.

8. Press the **OK** button to save the setting.
If the setting is invalid, the screen display will have no change.


9. Press the **ESC** button to return to the User Monitor Screen.
The average has been changed to 0100, but the minimum is still +00123.

Example 2 Change bit0 from OFF to ON.


1,2,3...




1. Press the **Forward + OK** button simultaneously to enter the Data Change Screen.




2. Use the **Down** button to move the cursor to line 2.



3. Use the **Forward** button to move the column cursor to the bit state position.



4. Press the **Down** or **Up** button to change the bit state to **ON**.




5. Press the **OK** button to save the setting.
Press the **ESC** button to return to the User Monitor Screen.


Deleting User Monitor Screen

Example Delete the User Monitor Screen 2.

1,2,3...



1. Switch to the Setup Mode.



2. Press the **Down** button to select **UserMonitor**.



3. Press the **OK** button to enter the User Monitor menu.



```
[UserMon]
Setup
>Delete
^
```

4. Press the **Down** button to select **Delete**.



```
[UserMon]
Delete No00
```


5. Press the **OK** button to enter the User Monitor Delete Screen.
The final digit of the Screen No. will be flashing.



```
[UserMon]
Delete No02
```

6. Use the **Up** button to change the Screen No. to **2**.

Note Press and hold the **UP** button until the Screen No. changes to **ALL**, all the User Monitor Screen will be deleted if the setting is confirmed.



```
Delete OK
[Esc]
```

7. Press the **OK** button to delete the screen.



```
[UserMon]
Setup
>Delete
^
```

8. Press the **ESC** or **OK** button to return to the previous menu.

8-6-9 Message Screen

This function can set or delete Message Screen. It is possible to register up to 16 screens. User can monitor the text message in the Message Screen when control bit is ON.

Creating New Message Screen

Example

When control bit W100.01 is ON, the Message Screen 2 will display the data on the word address D09040 to D09075.

1,2,3...

```
[Menu]
>Mode
IO Memory
PLC Setup
```

```
[Menu]
UserMonitor
>Message
Tiner
```

```
[Message]
>Setup
Delete
```

```
Message No00
HdCH: D09000
CtrlCH N
WR 000
```

a ←
b ←
c ←
d ↑

```
Message No02
HdCH: D09040
CtrlCH N
WR 000
```

1. Switch to the Setup Mode.
2. Press the **Down** button to select **Message**.
3. Press the OK button to enter the Message menu.
4. Press the **OK** button to enter the Message Setup Screen.
The final digit of the Screen No. will be flashing.
The following table shows the setting items.

No.	Description
a	Message Screen No. (01 to 16)
b	Leading word (Only DM) address
c	Message flag
d	Word (Only WR) address of control bit

5. Use the **Up** button to change the Screen No. to **2**.
The following table shows the relation between the Screen No. and the control bit when the word address is W000.

Screen No.	Control bit
01	W000.00
02	W000.01
03	W000.02
04	W000.03
...	...
16	W000.15

```

Message No02
HdCH: D09040
Ctr-ICH  N
WR 000

```

6. Use the **Forward** button to move the column cursor to the position of leading word address.

The present setting is the default address.

The following table shows the default address and the setting range for each screen when the leading word address is D09000.

Screen No.	Default address	Range
01	09000 to 09035	00000 to 32732
02	09040 to 09075	
03	09080 to 09115	
04	09120 to 09155	
...	...	
16	09600 to 09635	

7. Use the **Forward** button to move the column cursor to the message flag position. Select the message flag in the following table.

Message flag	Meaning
Y	Message Screen in use
N	Message Screen not in use

8. Press the **Up** button to select the message flag **Y**.

The setting is available for all the screens.

```

Message No02
HdCH: D09040
Ctr-ICH  Y
WR 000

```

```

Message No02
HdCH: D09040
Ctr-ICH  Y
WR 000

```

```

Message No02
HdCH: D09040
Ctr-ICH  Y
WR 000

```

9. Use the **Forward** button to move the column cursor to the position of word address.

The present setting is the default address. The range of the address is 000 to 511.

```

Message No02
HdCH: D09040
Ctr-ICH  Y
WR 100

```

10. Use the **Up** button to change the word address to **100**.

```

Set OK
[Esc]

```

11. Press the **OK** button to save the setting.

```

Message No02
HdCH: D09040
Ctr-ICH  Y
WR 100

```

12. Press the **ESC** or **OK** button to return to the Message Setup Screen.

```

Elevator
Stop at 1F

```

13. Press the **ESC** button three times to return to the Monitor Mode. Switch to the Message Screen 2 when control bit W100.01 is ON.

DM Area Settings

The text message is stored in the DM area. One character is 1 byte and one DM word is 2 bytes, so 24 DM words need to be used to store one screen message. But not all of the area can be used.

The following table shows the setting area for each screen when the leading word address is D09000..

Screen No.	Word	0		1		2		3		4		5		6	7	8	9
01	D09000	1	2	3	4	5	6	7	8	9	10	11	12				
	D09010	13	14	15	16	17	18	19	20	21	22	23	24				
	D09020	25	26	27	28	29	30	31	32	33	34	35	36				
	D09030	37	38	39	40	41	42	43	44	45	46	47	48				
02	D09040	1	2	3	4	5	6	7	8	9	10	11	12				
	D09050	13	14	15	16	17	18	19	20	21	22	23	24				
	D09060	25	26	27	28	29	30	31	32	33	34	35	36	Do not use.			
	D09070	37	38	39	40	41	42	43	44	45	46	47	48				
...																	
16	D09600	1	2	3	4	5	6	7	8	9	10	11	12				
	D09610	13	14	15	16	17	18	19	20	21	22	23	24				
	D09620	25	26	27	28	29	30	31	32	33	34	35	36				
	D09630	37	38	39	40	41	42	43	44	45	46	47	48				

In this example, "Elevator Stop at 1F" is displayed on the Message Screen 2.

The data can be set in the DM area with the CX-Programmer.
The settings show as below.

Line No.	Word	Setting	Character	
1	D09040	2020		
	D09041	2020		
	D09042	2020		
	D09043	2020		
	D09044	2020		
	D09045	2020		
2	D09050	456C	E	l
	D09051	6576	e	v
	D09052	6174	a	t
	D09053	6F72	o	r
	D09054	2020		
	D09055	2020		
3	D09060	2053		S
	D09061	746F	t	o
	D09062	7020	p	
	D09063	6174	a	t
	D09064	2031		1
	D09065	4620	F	
4	D09070	2020		
	D09071	2020		
	D09072	2020		
	D09073	2020		
	D09074	2020		
	D09075	2020		

Select the character codes in the following table.

Upper bits Lower bits	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0															
1															
2															
3															
4															
5															
6															
7															
8															
9															
A															
B															
C															
D															
E															
F															

Deleting Message Screen

Example Delete the Message Screen 1.

1,2,3...

```
[Menu]
>Mode
  IO Memory
  PLC Setup
  ▼
```

1. Switch to the Setup Mode.

```
[Menu]
  UserMonitor
  >Message
  Tiner
  ▲ ▼
```

2. Press the **Down** button to select **Message**.

```
[Message]
>Setup
Delete
  ▼
```

3. Press the **OK** button to enter the Message menu.

```
[Message]
  Setup
  >Delete
  ▲
```

4. Press the **Down** button to select **Delete**.

```
[Message]
Delete No.01
```

5. Press the **OK** button to enter the Message Delete Screen.
The present setting is Screen **01**.

Note Press and hold the **UP** button until the Screen No. changes to **ALL**, all the User Monitor Screen will be deleted if the setting is confirmed.

```
Delete OK
      [ESC]
```

6. Press the **OK** button to delete the screen.

```
[Message]
  Setup
  >Delete
  ▲
```

7. Press the **ESC** or **OK** button to return to the previous menu.

8-6-10 Timer Switch

There are 3 kinds of timer, including Day, Weekly and Calendar Timer. It is possible to register up to 16 timers for each kind.

Type	Description
Day timer	Sometime in a day, set the related control bit to ON.
Weekly timer	Sometime in a week, set the related control bit to ON.
Calendar timer	Sometime in a year, set the related control bit to ON.

Setting Day Timer

Example 8:30 to 17:15 from Monday to Friday, control bit W509.15 is ON.

1,2,3...

```
[Menu]
>Mode
  IO Memory
  PLC Setup
  ▼
```

```
[Menu]
  UserMonitor
  Message
  >Timer
  ▲ ▼
```

```
[Timer]
>Day Timer
  WeekTimer
  Cal Timer
  ▼
```

```
Day N No000
ON :00:00 Mo
OFF:00:00 Mo
IO 0100
  ▲       ▲
  e       f
```

a b c d

```
Day N No100
ON :00:00 Mo
OFF:00:00 Mo
IO 0100
```

1. Switch to the Setup Mode.

2. Press the **Down** button to select **Timer**.

3. Press the **OK** button to enter the Timer Switch menu.

4. Press the **OK** button to enter the Day Timer Screen. The final digit of the Timer No. will be flashing. The following table shows the setting items.

No.	Description
a	Timer flag
b	Timer No. (01 to 16)
c	ON time of PLC
d	OFF time of PLC
e	Word type
f	Word address

5. Use the **Up** button to change the Timer No. to **16**. The following table shows the relation between the Timer No. and the control bit when the word address is W001.

Timer No.	Control bit
01	W001.00
02	W001.01
03	W001.02
04	W001.03
...	...
16	W001.15

```

Day  [ ] No16
ON :00:00 Mo
OFF:00:00 Mo
IO  0100

```

```

Day  Y No16
ON :08:30 Mo
OFF:00:00 Mo
IO  0100

```

```

Day  Y No16
ON :08:30 M[ ]
OFF:00:00 Mo
IO  0100

```

```

Day  Y No16
ON :08:30 Mo
OFF:17:15 Mo
IO  0100

```

```

Day  Y No16
ON :08:30 Mo
OFF:17:15 F[ ]
IO  0100

```

```

Day  Y No16
ON :08:30 Mo
OFF:17:15 Fr
IO  0100

```

```

Day  Y No16
ON :08:30 Mo
OFF:17:15 Fr
WR  0000

```

6. Use the **Forward** button to move the column cursor to the timer flag position. Press the **Up** button to select the timer flag **Y**. Select the timer flag in the following table.

Timer flag	Meaning
Y	Timer in use
N	Timer not in use

7. Use the **Forward** button to move the column cursor to the ON time position. Use the **Up** button to change time to **08:30**.

8. Use the **Forward** button to move the column cursor to the ON week position. The present setting is **Monday**.

9. Use the **Forward** button to move the column cursor to the OFF time position. Use the **Up** button to change time to **17:15**.

10. Use the **Forward** button to move the column cursor to the OFF week position. Press the **Down** or **Up** button to select **Friday**.

11. Use the **Forward** button to move the column cursor to the position of control bit.

12. Press the **Up** button to select **WR**. The following table shows the word type which can be selected, including the default address and the setting range for each type.

Timer	Word	Default address	Range
All	IO	0100	0100 to 6143
Day timer	WR	001	001 to 511
Weekly timer	WR	002	002 to 511
Calender timer	WR	003	003 to 511
All	HR	000	000 to 511
All	AR	448	448 to 959

```

Day  Y  No16
ON  :08:30 Mo
OFF:17:15 Fr
WR   W000

```

13. Use the **Forward** button to move the column cursor to the position of word address.
The present setting is the default address.

```

Day  Y  No16
ON  :08:30 Mo
OFF:17:15 Fr
WR   W500

```

14. Move the column cursor to the digit to be set.
Use the **Up** button to change the word address to **509**.

```

Set OK
[Esc]

```

15. Press the **OK** button to save the setting.

```

Day  Y  No16
ON  :08:30 Mo
OFF:17:15 Fr
WR   W509

```

16. Press the **ESC** or **OK** button to return to the Day Timer Screen.

Setting Calendar Timer

Example

From 1st June to 1st October, control bit H209.05 is ON.

1,2,3...

```

[Menu]
>Mode
  IO Memory
  PLC Setup

```

1. Switch to the Setup Mode.

```

[Menu]
  UserMonitor
  Message
>Timer

```

2. Press the **Down** button to select **Timer**.

```

[Timer]
>Day Timer
  WeekTimer
  Cal Timer

```


3. Press the **OK** button to enter the Timer menu.

```

[Timer]
  Day Timer
  WeekTimer
>Cal Timer

```


4. Press the **Down** button to select **Cal Timer**.



5. Press the **OK** button to enter the Calendar Timer Screen.
The final digit of the Timer No. will be flashing.
The following table shows the setting items.


No.	Description
a	Timer flag
b	Timer No. (01 to 16)
c	ON date of PLC
d	OFF date of PLC
e	Word type
f	Word address

6. Use the **Up** button to change the Timer No. to **6**.




7. Use the **Forward** button to move the column cursor to the timer flag position.

Press the **Up** button to select the timer flag **Y**.




8. Use the **Forward** button to move the column cursor to the ON date position.
Use the **Up** button to change the date to **06/01**.




9. Use the **Forward** button to move the column cursor to the OFF date position.

Use the **Up** button to change the date to **10/01**.




10. Use the **Forward** button to move the column cursor to the position of control bit.

Press the **Up** button to select **HR**.




11. Use the **Forward** button to move the column cursor to the position of word address.

The present setting is default address.



12. Move the column cursor to the digit to be set.

Use the **Up** button to change the word address to **209**.





13. Press the **OK** button to save the setting.




14. Press the **ESC** or **OK** button to return to the Calander Timer Screen.

- Note**
1. If a timer is in use, when the timer switch turns ON, the LCD Option Board will send command to PLC one time every 1 second to make control bit ON, when the timer switch turns OFF, the LCD Option Board will send command to PLC one time every 1 second to make control bit OFF.
 2. Move the LCD Option Board from one PLC to another, the result of timer operation will be different if the time of two PLCs is not the same.

Timing Curve

Each timer can execute a trans-day, trans-week or trans-year operation. The operation period will be shown in the following curve.

Day Timer



		SUN	MON	TUE	WED	THU	FRI	SAT	
		8:00	17:00	8:00	17:00	8:00	17:00	8:00	17:00
8:00 ON	Mon								
17:00 OFF	Fri								
17:00 ON	Mon								
8:00 OFF	Fri								
8:00 ON	Fri								
17:00 OFF	Mon								
17:00 ON	Fri								
8:00 OFF	Mon								
8:00 ON	Mon								
8:01 OFF	Mon								
8:00 ON	Mon								
7:59 OFF	Mon								
8:00 ON	Mon								
8:00 OFF	Mon								

[illegible]

533

8-6-11 Data Backup

User can save the user settings to DM memory area from one LCD Option Board and load to other LCD Option Boards from the DM memory area.

Note Please do not take the DM area (D8000 to D8999) for other use.

User settings which can be backed up as shown below.

User setting		Quantity
User Monitor screen		16 screens
Message screen		16 screens
Timer Switch		16 × 3 timers
Other	Language	1
	Backlight	1
	Contrast	1

Loading User Setting

Example Load user settings from DM memory area.

1,2,3...

```
[Menu]
>Mode
  IO Memory
  PLC Setup
  ▾
```

1. Switch to the Setup Mode.

```
[Menu]
>DataBackup
  実行
  Other
  ▾
```

2. Press the **Down** button to select **DataBackup**.

```
[DataBackup]
>Load
  Save
  ▾
```

3. Press the **OK** button to enter the Data Backup menu.

```
[Load]
>Cancel
  OK (All)
  ▾
```


4. Press the **OK** button to enter the Load Operation Screen. Select the operation mode in the following table.

Operation Mode	Meaning
Load	Load user setting from DM area
Save	Save user setting into DM area


```
[Load]
  Cancel
>OK (All)
  ▴
```

5. Press the **Down** button to select **OK**.


Note Selecting **Cancel** will result in a return to the previous menu.




6. Press the **OK** button to display a load confirming screen.



7. Press the **OK** button to start loading.
A rate of loading will be displayed in the screen.



8. When the rate comes up to 100%, the loading is finished. Then it will display a complete screen.




9. Press the **ESC** or **OK** button to restart the LCD Option Board.


Saving User Setting

Example Save user settings to DM memory area.


1,2,3...




1. Switch to the Setup Mode.



2. Press the **Down** button to select **DataBackup**.



3. Press the **OK** button to enter the Data Backup menu.



4. Press the **Down** button to select **Save**.



```
[Save]
>Cancel
OK      (All)
```


5. Press the **OK** button to enter the Save Operation Screen.



```
[Save]
Cancel
>OK      (All)
```


6. Press the **Down** button to select **OK**.

Note Selecting **Cancel** will result in a return to the previous menu.



```
ConfirmSave?
DM 8000+8999
[OK/Esc]
```


7. Press the **OK** button to display a save confirming screen.



```
[Save]

02%
```

8. Press the **OK** button to start saving.
A rate of saving will be displayed in the screen.



```
[Save]

Complete
```

9. When the rate comes up to 100%, the saving is finished. Then it will display a complete screen.

8-6-12 Language Selection


Display for the LCD Option Board is available in 2 languages - English and Japanese.

Example Change the display language from English to Japanese.


1,2,3...




1. Switch to the Setup Mode.




2. Press the **Down** button to select ゲンゴ .




3. Press the **OK** button to enter the Language Setup Screen.
The present language is English.



4. Press the **Down** button to select ニホンゴ .



5. Press the **OK** button to save the setting.



6. Press the **ESC** or **OK** button return to the previous menu.
The display language will change to Japanese.

8-6-13 PLC Cycle Time


This function can display the cycle time of the CPU Unit. The operation method will be shown in the following example.

1,2,3...




```
[Menu]
>Mode
IO Memory
PLC Setup
  ▲ ▼
```

1. Switch to the Setup Mode.




```
[Menu]
DataBackup
>PLC
Other
  ▲
```

2. Press the **Down** button to select **Other**.




```
[Other]
>CycleTime
ClockSet
SystemInfo
  ▲
```

3. Press the **OK** button to enter the Other menu.




```
[CycleTime]
Avg:
    1.5ms
```

4. Press the **OK** button to enter the Cycle Time Screen.
The average cycle time of the CPU Unit will be displayed.



```
[CycleTime]
Max:
    22.3ms
```

5. Press the **Down** button to display the max. cycle time of the CPU Unit.



```
[CycleTime]
Min:
    0.5ms
```

6. Press the **Down** button to display the min. cycle time of the CPU Unit.

8-6-14 PLC Clock Setting

This function can change the setting of the built-in clock in the CPU Unit.

Example

Change PLC time to 12:00:00, PLC week to Saturday.

1,2,3...

```
[Menu]
>Mode
IO Memory
PLC Setup
```

1. Switch to the Setup Mode.

```
[Menu]
DataBackup
>PLC
Other
```

2. Press the **Down** button to select **Other**.

```
[Other]
>CycleTime
ClockSet
SystemInfo
```

3. Press the **OK** button to enter the Other menu.

```
[Other]
CycleTime
>ClockSet
SystemInfo
```

4. Press the **Down** button to select **ClockSet**.

```
[ClockSet]
2007/12/01
12:05:30
(Mon)
```

5. Press the **OK** button to enter the Clock Setup Screen.
The present date, time and week of the CPU Unit will be displayed.

```
[ClockSet]
2007/12/01
12:00:00
(Mon)
```

6. Use the **Forward** button to move the column cursor to the position of PLC time.
Use the **Down** or **Up** button to change the time to **12:00:00**.

```
[ClockSet]
2007/12/01
12:00:00
(Sat)
```

7. Use the **Forward** button to move the column cursor to the position of PLC week.
Use the **Down** or **Up** button to select **Sat**.

```
Set OK
[Esc]
```

8. Press the **OK** button to save the setting.

```
[Other]
CycleTime
>ClockSet
SystemInfo
```

9. Press the **ESC** or **OK** button to return to the previous menu.

10. Press the **ESC** button to return to the Monitor Mode.

```

CP1L
2007/12/01
12:00:00
(Sat)

```

8-6-15 PLC System Information

This function can display the system information of the CPU Unit. The operation method will be shown in the following example.

1,2,3...

1. Switch to the Setup Mode.

```

[Menu]
>Mode
IO Memory
PLC Setup

```

2. Press the **Down** button to select **Other**.

```

[Menu]
DataBackup
>PLC
Other

```

3. Press the **OK** button to enter the Other menu.

```

[Other]
>CycleTime
ClockSet
SystemInfo

```

4. Press the **Down** button to select **SystemInfo**.

```

[Other]
CycleTime
ClockSet
>SystemInfo

```

5. Press the **OK** button to enter the System Information Screen.
Line 1 to 3 will display the CPU Unit model, line 4 the lot No.

```

CP1H
-X40DR-A
LotNo. 29905

```

6. Press the **Down** button to display the CPU Unit version.

```

[SystemInfo]
UnitVer
1.2

```

8-6-16 LCD Backlight Setting







This function can make a setting for the LCD backlight.
The backlight turns off after LCD has not been used for 5 minutes.

Example
1,2,3...

- 1. Switch to the Setup Mode.
- 2. Press the **Down** button to select **Other**.
- 3. Press the **OK** button to enter the Other menu.
- 4. Press the **Down** button to select **BackLight**.
- 5. Press the **OK** button to enter the Backlight Screen.
The following table shows the setting items.

No.	Description		Meaning
a	Timer interval		The range is 02 to 30 minutes.
b	Backlight mode	Timer	Backlight will turn OFF if LCD has not been used for the timer interval.
		ON	Backlight is always ON.
		OFF	Backlight is always OFF.

- 6. Use the **Forward** button to move the column cursor to the position of timer interval.
Use the **Up** button to change the timer interval to **05**.
- 7. Press the **OK** button to save the setting.
- 8. Press the **ESC** or **OK** button to return to the previous menu.



8-6-17 LCD Contrast Setting

This function can make a setting for the LCD contrast.

Example

Change the contrast of LCD display to 8.

1,2,3...

```
[Menu]
>Mode
IO Memory
PLC Setup
▼
```

1. Switch to the Setup Mode.

```
[Menu]
DataBackup
>PLC
Other
▲
```

2. Press the **Down** button to select **Other**.

```
[Other]
>CycleTime
ClockSet
SystemInfo
▼
```

3. Press the **OK** button to enter the Other menu.

```
[Other]
BackLight
>Contrast
FactorySet
▲ ▼
```

4. Press the **Down** button to select **Contrast**.

```
[Contrast]
Level1:01
```

5. Press the **OK** button to enter the Contrast Screen.
The contrast level of LCD display is 1 to 16.

```
[Contrast]
Level1:08
```

6. Use the **Up** button to change the level to **08**.

```
Set OK
[Esc]
```

7. Press the **OK** button to save the setting.

```
[Other]
BackLight
>Contrast
FactorySet
▲ ▼
```

8. Press the **ESC** or **OK** button to return to the previous menu.

8-6-18 LCD Factory Setting

This function can initialize the factory setting of the LCD Option Board. The operation method will be shown in the following example.

1,2,3...

```
[Menu]
>Mode
  IO Memory
  PLC Setup
```

```
[Menu]
DataBackup
>Factory
Other
```

```
[Other]
>CycleTime
ClockSet
SystemInfo
```

```
[Other]
BackLight
Contrast
>FactorySet
```

```
[FactorySet]
>Cancel
OK
```

```
[FactorySet]
Cancel
>OK
```

```
Initializing
0640
```

```
Finish to
initialize
[Esc]
```

```
CP1L
2007/11/28
13:26:35
(Mon)
```

1. Switch to the Setup Mode.
2. Press the **Down** button to select **Other**.
3. Press the **OK** button to enter the Other menu.
4. Press the **Down** button to select **FactorySet**.
5. Press the **OK** button to enter the Factory Setting Screen.
6. Press the **Down** button to select **OK**.
Note Selecting **Cancel** will result in a return to the previous menu.
7. Press the **OK** button to start initializing.
8. When the initializing is finished, it will display a complete screen.
9. Press the **ESC** or **OK** button to restart the LCD Option Board.

8-7 Trouble Shooting

8-7-1 Symptom at Power ON or during Operation

Symptom	Probable cause	Possible solution
No LCD display	LCD connection error or no power supply from PLC.	Check if LCD is connected correctly and the PLC power supply is normal.
	Still in startup waiting time.	It's not error. Just wait a moment.
Display EEPROM Error Screen and blinking red backlight	EEPROM is damaged.	Replace the LCD Option Board.
	User settings in EEPROM are corrupted.	Press the ESC button to exit the screen. User settings backed up in EEPROM will be replaced by default settings. Then proceed to reset the screens. (See 8-7-3 for details.)
Display NG Screen	LCD connection error.	Check if LCD is connected correctly.
	Communication error between LCD and PLC.	Check the communication setting of PLC, switching DipSW4 to ON.
Display Error Screen and blinking red backlight	PLC error	Check PLC according to error code and eliminate the error.
Button unresponsive	Button is damaged.	Replace the LCD Option Board.
	User setting error.	Check the settings and change it.
	Noise disturbing.	Retry after the noise is reduced.
Display too faint	Backlight is damaged.	Replace the LCD Option Board.
	Contrast level is too low or too high.	Reset the contrast level.

Note Do not repair the LCD Option Board by yourself.

8-7-2 Communication Error Message during Operation

When communication error occurs, the error message will be displayed at the LCD Option Board and the red backlight will blink.

Error message	Probable cause	Possible solution
Parity Error or Framing Error or Overrun Error	Communication parameters or conditions of PLC are changed.	Check the communication setting of PLC.
	LCD connection error.	Check if LCD is still connected correctly.
	Noise disturbing.	<ul style="list-style-type: none"> Return to normal automatically when the noise is reduced. If the display cannot return to normal, press the ESC button to restart LCD.
FCS Error(Sum check)	Noise disturbing.	<ul style="list-style-type: none"> Return to normal automatically when the noise is reduced. If the display cannot return to normal, press the ESC button to restart LCD.
Buffer overflow	The length of receiving data is beyond the range of receiving memory.	Press the ESC button to restart LCD.
	Noise disturbing.	
Connecting Host...	LCD connection error.	Check if LCD is still connected correctly.
	The communication between PLC and LCD is out of service.	Check if PLC is running normally.
Response code Error	Operation mistake.	Refer to CJ/CS Communication Manual for solutions according to an end code.
	Noise disturbing.	<ul style="list-style-type: none"> Return to normal automatically if the noise is reduced. Press the ESC button to exit the screen.
	CX-Programmer and LCD execute some function at the same time.	Press the ESC button to exit the screen. Execute this function by either CX-Programmer or LCD.

8-7-3 Deleting EEPROM Error

1,2,3...

EEPROM ERR
User Screen
01 L.04
[Esc]

a

c

b

CF1L
2007/11/28
13:26:35
(Mon)

Setup No02
Line# IO
0000 # W
Name:

1. A flashing error screen will be displayed when an error occurs.
The following table shows the display items.

No.	Description	
a	Error type	User Monitor setting error
		Message setting error
		Timer Switch setting error
		Language setting error
		Backlight setting error
		Contrast setting error
b	Screen No.	
c	Line No.	

According to the error message, the setting of User Monitor Screen 2, line 4 is corrupted.

2. Press the **ESC** button to exit the screen. Once the EEPROM Error Screen has disappeared, the display will return to normal.

3. Enter the User Monitor Setup Screen 2, line 4.
User settings backed up in EEPROM are replaced by default settings.
Then reset the screen.

545

SECTION 9

Ethernet Option Board


This section gives an outline of the Ethernet Option Board, explains how to install and remove the Ethernet Option Board, and how to monitor and make settings required for operation. It also lists the errors during operation and provides countermeasures for troubleshooting.

9-1	Ethernet Option Board Function Guide	548
9-1-1	Overall system configuration example	548
9-1-2	Connecting the CX-Programmer to PLCs Online via Ethernet	549
9-1-3	Receiving Data from OMRON PLCs using Ethernet.	550
9-2	Features	551
9-3	System Configuration	552
9-3-1	System Configuration	552
9-3-2	Devices Required for Constructing a Network.	552
9-4	Specifications	553
9-5	FINS Communications	554
9-5-1	FINS Communications Service Specifications.	554
9-5-2	Overview of FINS Communication Service.	555
9-6	Part Names	556
9-7	Comparison with Previous Models	557
9-8	Installation and Initial Setup	559
9-8-1	Overview of Startup Procedure.	559
9-8-2	Installation and Removing	560
9-8-3	Network Installation	562
9-8-4	Web Browser Setting Function	564
9-9	Memory Allocations	567
9-9-1	CIO Area Allocation	567
9-9-2	DM Area Allocation	569
9-10	Web Browser Setup and Display	573
9-10-1	Multi-language Function	573
9-10-2	Overview of Web Browser Function	573
9-10-3	System	574
9-10-4	HTTP	576
9-10-5	IP Address Table	577
9-10-6	IP Router Table	578
9-10-7	FINS/TCP	579
9-10-8	Unit Information	580
9-10-9	Unit Status	581
9-10-10	FINS Status	582
9-10-11	Error Log	583
9-11	Trouble Shooting	584
9-11-1	Error Log	584
9-11-2	Trouble-shooting with Indicators and Error Code Display	587
9-11-3	Error Status	587
9-12	Sample Application	588
9-13	Buffer Configuration (CP1W-CIF41)	592

9-1 Ethernet Option Board Function Guide

9-1-1 Overall system configuration example

Ethernet Option Board provides receiving commands by OMRON standard protocol FINS for CP1L and CP1H programmable controllers. The Ethernet Network Interface allows you to easily connect CP1L and CP1H Programmable Controllers onto new or existing Ethernet network and upload/download programs, communicate between controllers (do not support real-time scanning I/O on Ethernet Option Board).



- Note**
1. Please use CX-Programmer version 8.1 or higher (CX-ONE version 3.1 or higher).
 2. Please use CX-Integrator version 2.33 or higher (CX-ONE version 3.1 or higher) to make the routing table. Except making the routing table for CP1W-CIF41, other functions, such as transferring the parameters and network structure, are not supported by CX-Integrator.
 3. Use the Web browser to set the CP1W-CIF41.
 4. NS-series HMI version 8.2 or higher can use CP1W-CIF41 through Ethernet.
 5. Expect for CX-Programmer and CX-Integrator (only set FINS routing table function), other tools do not support CP1W-CIF41.

9-1-2 Connecting the CX-Programmer to PLCs Online via Ethernet

Connecting within the Same Segment

Use the UDP/IP version of the FINS communications service (i.e., FINS/UDP). FINS/UDP is supported by many OMRON products and is compatible with earlier Ethernet Units (CS1W-ETN01/ETN11/ETN21 and CJ1W-ETN11/ETN21). The CX-Programmer can be connected and used with FINS/UDP.

Connecting through Multiple Segments

Use the TCP/IP version of the FINS communications service (i.e., FINS/TCP). It provides automatic recovery at the TCP/IP layer from communications errors (such as packet loss) that occur during multilevel routing. For CX-Programmer, FINS/TCP can be used to directly connect to the PLC online.

Using Media with Unreliable Connections, Such as a Wireless LAN


Use the TCP/IP version of the FINS communications service (i.e., FINS/TCP). It provides automatic recovery at the TCP/IP layer from communications errors (such as packet loss) resulting from unreliable connections. For CX-Programmer, FINS/TCP can be used to directly connect to the PLC online.

Connecting from a Personal Computer with a Dynamic Private IP Address

Depending on whether or not the connection will be within the same segment, either use an IP address conversion method for dynamic IP addresses in the UDP/IP version of the FINS communications service or use the TCP/IP version of the FINS communications service.

It is possible to connect online to a PLC using the CX-Programmer from a computer serving as a temporarily connected node or a permanent DHCP client.

For CX-Programmer, FINS/TCP can be used to directly connect to the PLC online.



9-1-3 Receiving Data from OMRON PLCs using Ethernet

The CP1W-CIF41 Ethernet Option Board can only support receiving FINS commands from OMRON PLCs using Ethernet.


Connecting within the Same Segment

Use the UDP/IP version of the FINS communications service (i.e., FINS/UDP), and construct applications using the SEND(090), RECV(098), and CMND(490) instructions in the ladder program. FINS/UDP is supported by many OMRON products, and is compatible with earlier Ethernet Units (CS1W-ETN01/ETN11/ETN21 and CJ1W-ETN11/ETN21). The protocol processing for FINS/UDP is simpler than for FINS/TCP, giving FINS/UDP certain advantages in terms of performance. Another feature of FINS/UDP is that it can be used for broadcasting.

On the other hand, with FINS/UDP it is necessary to provide measures, such as retries, for handling communications errors.

Connecting through Multiple Segments

Use the TCP/IP version of the FINS communications service (i.e., FINS/TCP), and construct applications using the SEND(090), RECV(098), and CMND(490) instructions in the ladder program. FINS/TCP is the initial function supported by this Ethernet Option Board (CP1W-CIF41). It provides automatic recovery at the TCP/IP layer from communications errors (such as packet loss) that occur during multilevel routing.



9-2 Features

Compatibility and Speed

The transmission medium of Ethernet side has been upgraded to 100Base-TX, while compatibility with some functions and application interfaces of the existing Ethernet Unit models for CS/CJ series has been maintained.

Limited by the Toolbus protocol used on the serial side, the processing speed is only 115.2kbps, slower than the existing Ethernet Unit. The FINS frame length is less than 1,004 bytes, so the system response performance for the same FINS message applications is longer than the existing Ethernet Unit.

Various Protocols Available on Ethernet

A variety of protocols make a wide range of applications for use on an Ethernet network. The protocols that can be selected include receiving commands by OMRON's standard protocol FINS and reading Ethernet Option Board settings and status by HTTP.

A communications service can be selected according to need, allowing the PLC to be flexibly integrated with the Ethernet information network.

Improved FINS Message Communications

The following functions have been maintained according to the existing Ethernet Unit models for CS/CJ series.

- The maximum number of nodes is 254.
- Communications are enabled even if the host computer's IP address is dynamic.
- An automatic client FINS node address allocation function makes it possible to connect online to the PLC even if no FINS node address has been set for the host computer.
- FINS message communications are enabled in both UDP/IP and TCP/IP, but it are only enabled in TCP/IP with up to 2 simultaneous connections .
→Previously it are enabled in TCP/IP with up to 16 simultaneous connections and all can be set to client.
- Multiple FINS applications, such as the CX-Programmer, on the same computer can be connected online to the PLC via Ethernet.

Use Web Function to Read Ethernet Option Board Settings and Status

A Web function is provided in Ethernet Option Board.

This enables use of a Web browser to read the Ethernet Option Board's system settings and statuses.


Full Range of Functions for Handling Troubles

A full range of functions is provided for promptly handling any troubles.

- Self-diagnostic function when power is turned ON.
- Error log for recording error information when an error occurs.

9-3 System Configuration

9-3-1 System Configuration



9-3-2 Devices Required for Constructing a Network

The basic configuration for a 100Base-TX Ethernet System consists of one hub to which nodes are attached in star form using twisted-pair cable. The devices shown in the following table are required to configure a network with 100Base-TX-type CP1W-CIF41, so prepared them in advance.

Network device	Contents
(1) Ethernet Option Board (CP1W-CIF41)	The Ethernet Option Board is a Communication Unit that connects a CP1H series or CP1L series PLC to 100Base-TX Ethernet networks. (They can also be used as 10Base-T.)
(2) Twisted-pair cable	This is twisted-pair cable for connecting 100Base-TX type Ethernet Option Board to the hub, with an RJ45 Modular Connector at each end. Use a category 3, 4, 5, or 5e UTP (unshielded twisted pair) or STP (shielded twisted-pair) cable.
(3) Hub	This is a relay device for connecting multiple nodes in a star LAN.

Recommended Hubs

For detail on recommended devices for constructing a network, refer to 9-8-3 *Network Installation*.

9-4 Specifications

Item		Specifications	
Model number		CP1W-CIF41	
Type		100/10Base-TX (Auto-MDIX)	
Applicable PLCs		CP1L and CP1H PLCs	
Unit classification		CP1 option port unit	
Mounting location		CP1L and CP1H micro PLC option port	
Max. number of Units that can be mounted		2 sets (See note.)	
Size of Buffers		8K bytes	
Transfer	Media access method	CSMA/CD	
	Modulation method	Baseband	
	Transmission paths	Star form	
	Baud rate	100 Mbit/s (100Base-TX)	10 Mbit/s (10Base-T)
		<ul style="list-style-type: none"> • Half/full auto-negotiation for each port • Link speed auto-sensing for each port 	
	Transmission media	<ul style="list-style-type: none"> • Unshielded twisted-pair (UDP) cable Categories: 5, 5e • Shielded twisted-pair (STP) cable Categories: 100Ω at 5, 5e 	<ul style="list-style-type: none"> • Unshielded twisted-pair (UDP) cable Categories: 3, 4, 5, 5e • Shielded twisted-pair (STP) cable Categories: 100Ω at 3, 4, 5, 5e
Transmission Distance		100 m (distance between hub and node)	
Current consumption (Unit)		130 mA max. at 5 V DC	
Vibration resistance		Conforms to JIS 0040. 10 to 57Hz: 0.075-mm amplitude, 57 to 150 Hz: acceleration 9.8 m/s ² in X, Y, and Z directions for 80 minutes each (sweep time: 8 minutes×10 sweeps = 80 minutes)	
Shock resistance		Conforms to JIS 0041. 147m/s ² , 3 times each in X, Y, and Z directions	
Ambient operating temperature		0 to 55°C	
Ambient humidity		10% to 90% (with no condensation)	
Atmosphere		Must be free of corrosive gas.	
Ambient storage temperature		-20 to 75°C	
Weight		23 g max.	
Dimensions		36.4×36.4×28.2 mm (W×H×D)	


- Note**
1. Two CP1W-CIF41(unit version 2.0) can be mounted in the CP1L/CP1H system.
 2. One CP1W-CIF41(unit version 2.0) and one CP1W-CIF41(unit version 1.0) can be mounted in the CP1L/CP1H system.
 3. Only one CP1W-CIF41(unit version 1.0) can be mounted in the CP1L/CP1H system. If two CP1W-CIF41 are mounted, the CP1W-CIF41 mounted on option board slot 1 will be abnormal and ERR indicator will be ON, the CP1W-CIF41 on option board slot 2 will work normally.
 4. CP1W-CIF41 only supports 32 bytes PING command. If PING command's length is larger than 32 bytes, there is no response.

9-5 FINS Communications

9-5-1 FINS Communications Service Specifications

Item	Specification	
Number of nodes	254	
Message Length	1016 bytes max.	
Date Length	1004 bytes max. (See note)	
Number of buffer	14 (1016 bytes×6+240 bytes×8)	
Protocol name	FINS/UDP method	FINS/TCP method
Protocol used	UDP/IP	TCP/IP
	The selection of UDP/IP or TCP/IP is made from the FINS/TCP Tab by Web browser function.	
Number of connections	---	2
Port number	9600 (default)	9600 (default)
	Can be changed.	Can be changed.
Protection	No	Yes (Specification of client IP addresses when unit is used as a server)
Other	Items set for each UDP port <ul style="list-style-type: none"> • Broadcast • Address conversion method 	Items set for each connection <ul style="list-style-type: none"> • Server specification • Remote IP address spec. Server: specify IP addresses of clients permitted to connect. • Automatic FINS node address allocation Specify automatic allocation of client FINS node addresses
Internal table	<p>This is a table of correspondences for remote FINS node addresses, remote IP addresses, TCP/UDP, and remote port numbers. It is created automatically when power is turned ON to the PLC or when the unit is restarted, and it is automatically changed when a connection is established by means of the FINS/TCP method or when a FINS command received.</p> <p>The following functions are enabled by using this table.</p> <ul style="list-style-type: none"> • IP address conversion using the FINS/UDP method • Automatic FINS node address conversion after a connection is established using the FINS/TCP method • Automatic client FINS node address allocation using the FINS/TCP method • Simultaneous connection of multiple FINS applications 	


Note Refer to the following diagram for the relation between message length and date length.



9-5-2 Overview of FINS Communication Service

Basic Functions

FINS commands can be received from other PLCs or computers on the same Ethernet network by executing SEND(090), RECV(098), or CMND(490) instructions in the ladder diagram program. This enables various control operations such as the reading and writing of I/O memory between PLCs, mode changes, and file memory operations.



Executing, from the host computer, FINS commands with UDP/IP or TCP/IP headers enables various control operations, such as the reading and writing of I/O memory between PLCs, mode changes, and file memory operations.

For example, it is possible to connect online via Ethernet from FINS communications applications such as the CX-Programmer, and to perform remote programming and monitoring.


Upgraded Functions

With the CP1W-CIF41, the following functions have been upgraded.

- The FINS communications service can be executed not only with UDP/IP but also with TCP/IP, and it is even possible to use FINS communications with both UDP/IP and TCP/IP together on the same network. Using TCP/IP makes FINS communications highly reliable.
- Even if the IP address and UDP port number of the host computer (a DHCP client computer) are changed, it is still possible for the host computer to send FINS commands to PLCs on the Ethernet network and to receive responses. When UDP is used, either the automatic generation (dynamic) method or the IP address table method must be selected for IP address conversion. When TCP is used, changes in IP address and TCP port numbers are handled automatically.
- Multiple FINS applications (CX-Programmer and user-created application programs) at the same computer can be connected online to a PLC via Ethernet (using either TCP/IP or UDP/IP).

Note The message service does not guarantee that a message will reach the destination node. A message may be lost during transmission due to factors such as noise. To prevent this from occurring when using message services, it is common to set up retry processing at the node from which instructions are issued. With the SEND(090), RECV(098), and CMND(490) instructions, retry processing is executed automatically by specifying the number of retries, so specify a number other than 0.

9-6 Part Names



LED Indicators

Indicator	Color	Status	Meaning
COMM	Yellow	Not lit	Not sending or receiving data.
		Flashing	Sending or receiving data.
ERR	Red	Not lit	Unit normal.
		Lit	An fatal error has occurred at the Unit.
		Flashing	An no-fatal error has occurred at the unit.

9-7 Comparison with Previous Models

Model		CP1L-EL/EM	CP1W-CIF41	CS1W-ETN21 CJ1W-ETN21
Local IP address		192.168.250.FINS node address	192.168.250.1	192.168.250.FINS node address
FINS node address		Set in PLC setup	Set in system settings	Set by rotary switch
Physical layer		100/10Base-TX (Auto-MDIX)	100/10Base-TX (Auto-MDIX)	100/10Base-TX
Number of nodes		254	254	254
Data length of FINS message		1004 bytes (Max)	1004 bytes (Max)	2012 bytes (Max)
FINS buffer size		16K bytes	8K bytes	392K bytes
Driver buffer number		Input: 55×592 bytes Output: 55×592 bytes	Input: 16×256 bytes Output: 8×256 bytes	Input: 50×1.5K bytes Output: 50×1.5K bytes
Process of driver buffer overflow		The last packet will be dropped.	Restart Ethernet function	The last packet will be dropped.
Connection number (FINS/TCP)		3 for user 1 for CX-Programmer auto connection	2 (only server)	16
PLC maintenance via the Internet		Not supported	Not supported	Not supported
Server specification		Specification by IP address or by host name (DNS Client Function)	Not supported	Specification by IP address or by host name (DNS Client Function)
FINS comm. service	Automatic IP address acquisition	A computer automatically acquiring IP addresses can send commands to the PLC and receive responses.	A computer automatically acquiring IP addresses can send commands to the PLC and receive responses.	A computer automatically acquiring IP addresses can send commands to the PLC and receive responses.
	FINS communication with computer without fixed node address	Possible (with automatic allocation) (Client FINS automatic node address allocation function, TCP/IP only)	Possible (with automatic allocation) (Client FINS automatic node address allocation function, TCP/IP only)	Possible (with automatic allocation) (Client FINS automatic node address allocation function, TCP/IP only)
	Handling TCP/IP	With FINS communications, both UDP/IP and TCP/IP (3 max.) possible.	With FINS communications, both UDP/IP and TCP/IP (2 max.) possible. (Only can be set to server)	With FINS communications, both UDP/IP and TCP/IP (16 max.) possible.
	Simultaneous connection of multiple applications in a computer	Possible (with both UDP/IP and TCP/IP)	Possible (with both UDP/IP and TCP/IP)	Possible (with both UDP/IP and TCP/IP)
Mail function		Not supported	Not supported	E-mail attachments with I/O memory data are possible for the mail send function. (SMTP, file attachment) With the mail receive function, commands can be received from the PLC. (POP3, mail receive)
FTP server function		Not supported	Not supported	Supported
Socket services function		Supported	Not supported	Supported
Automatic clock information adjustment		Supported	Not supported	Supported
IP conflict (GARP)		Supported	Not supported	Supported
TCP keep-alive function		Supported	Not supported	Supported
Multicast function		Not supported	Not supported	Not supported
Web function		Not supported	Supported	Supported

Improved FINS Message Communications from CP1W-CIF41


The following functions have been maintained according to the existing Ethernet Unit models for CP1W-CIF41.

- The maximum number of nodes is 254.
- Communications are enabled even if the host computer's IP address is dynamic.
- An automatic client FINS node address allocation function makes it possible to connect online to the PLC even if no FINS node address has been set for the host computer.
- FINS message communications are enabled in both UDP/IP and TCP/IP, and it is enabled in TCP/IP with up to 3 simultaneous connections.
→Previously CP1W-CIF41 is enabled in TCP/IP with up to 2 simultaneous connections and all can only be set to server.
- Multiple FINS applications, such as the CX-Programmer, on the same computer can be connected online to the PLC via Ethernet.

9-8 Installation and Initial Setup

9-8-1 Overview of Startup Procedure

The following procedure is the same for the CS Series and CJ Series.



- Note**
1. When using this method, always leave the local IP address of system setup in the Ethernet Option Board set to the value of 0.0.0.0. If this area contains any other value, any setting made in the allocated CIO words will be overwritten with it.
 2. The local IP address and other parameters can be set from the Web browser.
 3. It is not necessary step, and the CX-Integrator version 2.33 or higher (CX-ONE version 3.1 or higher) is required.

When the FINS communications service is used, routing tables must be created in advance. Routing tables are required in the following circumstances.

- When communicating with a PLC or computer on another network (e.g. remote programming or monitoring using FINS message or a CX-programmer)
- When multiple Communications Units are mounted to a single PLC (e.g. CPU unit)
- When routing tables are used for one or more other nodes on the same network

4. It is not necessary step, and the Web browser is required.


9-8-2 Installation and Removing

The following processing explains how to install and remove an Ethernet Option Board.

- Caution** Always turn OFF the power supply to the CPU unit and wait until all the operation indicators go out before installing or removing the Ethernet Option Board.

Installation


- 1,2,3...**
1. Press the up/down lock-levers on both sides of the Option Board slot cover at the same time to unlock the cover, and then pull the cover out.
 2. Check the alignment to make the corner cut of the Ethernet Option Board fit in the Option Board slot, and firmly press the Ethernet Option Board in until it snaps into place.



- Note** If two CP1W-CIF41 (unit version 1.0) Ethernet Option Boards are mounted on the CP1L/CP1H PLC, the CP1W-CIF41 mounted on Option Board slot1 (left side) will run in abnormal status and ERR indicator will be ON. If the ladder program operates the with CP1W-CIF41 fatal error, the PLC will generate the non-fatal error.

3. For CPU Units with 30, 40 or 60 I/O points, switch DipSW4 of the CPU unit to ON, if the Ethernet Option Board is mounted on the Option Board slot 1 (left side). Switch DipSW5 of the CPU unit to ON, if the Ethernet Option Board is mounted on the Option Board slot 2 (right side).
For CPU Units with 14 or 20 I/O points, switch DipSW4 of the CPU unit to ON.

Note DipSW4 and DipSW5 are OFF at shipment.




Caution In CP1H or CP1L system, option board setting should be set to Toolbus 115K to ensure the work normally.

There are two methods to set this setting. One is to turn DipSW4 or DipSW5 to ON, and another is to set option board setting to Toolbus 115K by CX-Programmer.

Removing

Press the up/down lock-levers on both sides of the Ethernet Option Board at the same time to unlock the Ethernet Option Board, and then pull it out.



9-8-3 Network Installation

Basic Installation Precautions

- Take the greatest care when installing the Ethernet System, being sure to follow ISO 802-3 specifications. You must obtain a copy of these specifications and be sure you understand them before attempting to install an Ethernet System. Unless you are already experienced in installing communications systems, we strongly recommend that you employ a professional to install your system.
- Do not install Ethernet equipment near sources of noise. If noise-prone environments are unavoidable, be sure to take adequate measures against noise interference, such as installing network components in grounded metal cases, using optical links in the system, etc.

Recommended products

The following products are recommended for use with the Ethernet Option Board.

Part	Maker	Model number	Specifications	Inquires
Hub	100BASE-TX			
	OMRON	W4S1-03B	10/100 Mbit/s 3-port hub	
	OMRON	W4S1-05B (C)	10/100 Mbit/s 5-port hub	
	PHOE-NIX CONTACT	SWITCH 5TX	10/100 Mbit/s 5-port hub	
	Allied Telesis	RH509E	9-port hub	Allied Telesis (0120) 86-0442 (in Japan only)
		MR820TLX	9-port hub with 10Base-5 backbone port	
	10BASE-T			
	Allied Telesis	RH509E	9-port hub	Allied Telesis (0120) 86-0442 (in Japan only)
		MR820TLX	9-port hub with 10Base-5 backbone port	
Twisted-pair cable	100BASE-TX			
	Fujikura	F-LINK-E 0.5mm x 4P	STP (shielded twisted-pair) cable: Category 5, 5e Note: Impedance is limited to 100 Ω.	---
	Fujikura	CTP-LAN5 0.5mm x 4P	UTP (unshielded twisted-pair) cable: Category 5, 5e	
	10BASE-T			
	Fujikura	F-LINK-E 0.5mm x 4P	STP (shielded twisted-pair) cable: Category 3, 4, 5, 5e Note: Impedance is limited to 100 Ω.	
	Fujikura	CTP-LAN5 0.5mm x 4P	UTP (unshielded twisted-pair) cable: Category 3, 4, 5, 5e	
	Connectors (Modular plug)	STP Plug		
Panduit Corp		MPS588	---	
UTP Plug				
Panduit Corp		MP588-C	---	

Precautions on Laying Twisted-pair Cable

Basic Precautions

- Press the cable connector in firmly until it locks into place at both the hub and the Ethernet Option Board.
- After laying the twisted-pair cable, check the connection with a 10Base-T cable tester.

Environment Precautions

- The UTP cable is not shielded, and the hub is designed for use in OA environments. In environments subject to noise, construct a system with shielded twisted-pair (STP) cable and hubs suitable for an FA environment.
- Do not lay the twisted-pair cable together with high-voltage lines.
- Do not lay the twisted-pair cable near devices that generate noise.
- Do not lay the twisted-pair cable in locations subject to high temperature or high humidity.
- Do not lay the twisted-pair cable in locations subject to excessive dirt and dust or to oil mist or other contaminants.

Hub Installation Environment Precautions

- Do not install the hub near devices that generate noise.
- Do not install the hub in locations subject to high temperature or high humidity.
- Do not install the hub in locations subject to excessive dirt and dust or to oil mist or other contaminants.


Hub Connection Methods

If more hub ports are required, they can be added by connecting more than one hub. There are two possible connection methods for hubs: Cascade and stacked.

Ethernet Connectors

The following standards and specifications apply to the connectors for the Ethernet twisted-pair cable.

- Electrical specifications: Conforming to IEEE802.3 standards
- Connector structure: RJ45 8-pin Modular Connector (conforming to ISO8877)



Connector Pin	Signal Name	Abbr.	Signal Direction
1	Transmission data +	TD+	Output
2	Transmission data -	TD-	Output
3	Reception data +	RD+	Input
4	Not used	---	---
5	Not used	---	---
6	Reception data -	RD-	Input
7	Not used	---	---
8	Not used	---	---
Hood	Frame ground	FG	---

Connecting the Cable

⚠ Caution Turn OFF the PLC's power supply before connection or disconnecting twisted-pair cable.

⚠ Caution Allow enough space for the bending radius of the twisted-pair cable.

- 1,2,3...**
1. Lay the twisted-pair cable.
 2. Connect the cable to the hub. Be sure to press in the cable until it locks into place.
Request cable installation from a qualified professional.
 3. Connect the cable to the connector on the Ethernet Option Board. Be sure to press in the cable until it locks into place.

9-8-4 Web Browser Setting Function

The Ethernet Option Board's system settings can be set using the Web browser of a personal computer or other device. The Ethernet Option Board's Web window is displayed by accessing the following URL from the Web browser.


English page: [http://\(Ethernet Option Board's IP address\)/E00.htm](http://(Ethernet Option Board's IP address)/E00.htm)

Japanese page: [http://\(Ethernet Option Board's IP address\)/J00.htm](http://(Ethernet Option Board's IP address)/J00.htm)


Chinese page: [http://\(Ethernet Option Board's IP address\)/C00.htm](http://(Ethernet Option Board's IP address)/C00.htm)

In this example, use the following procedure to set the IP address using Internet Explorer version 6.0 and the Ethernet Option Board's English Web pages.


- 1,2,3...**
1. Connect to the Ethernet Option Board from the Web browser using the Ethernet Option Board's default IP address.
<http://192.168.250.1/E00.htm>




- Input the default password “ETHERNET” and click the **Login** Button.



- Select **Settings** from the menu on the left side of the window to display the Settings Menu.



4. Select **1. IP address and Protocols - System** to display System menu.




5. Make the required settings (i.e., the IP address in this example).

System Format

Parameter	Value
IP Address	192 . 168 . 250 . 1
Subnet Mask	255 . 255 . 255 . 0
FINS Node Address	1 [0: default(1)]
FINS/UDP Port	0 <input type="checkbox"/> Use Input Port No [Default(9600)]
FINS/TCP Port	0 <input type="checkbox"/> Use Input Port No [Default(9600)]

6. After entering the correct values, click the Transfer Button to transfer the settings to the Ethernet Option Board.



7. To enable the new settings, turn the power to the Ethernet Option Board OFF and ON again, or click the Restart Button.

9-9 Memory Allocations

9-9-1 CIO Area Allocation

The memory allocation about communication services status in the CIO area of PLC is shown as the following diagram. The beginning CIO channel m is calculated by the following equation:

$$m = \text{CIO2980} + 10 \times (0\text{xFD} - \text{Unit Address})$$

Offset	D15	D0
m	Service Status	
$m+1$	Error Status	
$m+2$	FINS/TCP Connection Status	

The following table describes the unit address for each option port.

Option Port No.	I/O Capacity	Unit Address	Range of Status Area
Option port 1	14/20	0xFC	CIO2990 to CIO2992
	30/40/60	0xFD	CIO2980 to CIO2982
Option port 2	30/40/60	0xFC	CIO2990 to CIO2992

Service Status


	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
m	1		0	0	0	0	0	0	0	0	0	0	0	0	0	0

Bit	Name	Unit operation
0 to 13	Reserved	Always 0.
14	Link Status	0: The link between hubs is terminated. 1: A link is established between hubs.
15	Reserved	Always 1.

Caution Bit 15 is used for detect power condition of PLC, so do not change it at any time. Otherwise the CP1W-CIF41 Ethernet Option Board will generate error.

Error Status

The status of errors that occur at the Ethernet Option Board is reflected as shown in the following diagram.



Bit	Name	Correction
0 to 1	Reserved	Always 0.
2	IP address setting error	The following cannot be used as IP address settings. <ul style="list-style-type: none"> • Host IDs that are all 0 or all 1. • Network IDs that are all 0 or all 1. • Subnetwork IDs that are all 1. • Addresses beginning with 127 (7F hex). Reset the IP address.
3	IP address table error	Correct the IP address table. If the problem cannot be resolved, replace the CPU Unit.
4	IP router table error	Correct the IP router table. If the problem cannot be resolved, replace the CPU Unit.
5	Reserved	Always 0.
6	Routing table error	Correct the routing tables. If the problem cannot be resolved, replace the CPU Unit.
7 to 13	Reserved	Always 0.
14	Address disagreement	Make sure that the node number and the last byte of the IP address are the same and then set other host IDs to 0. Change the address conversion method.
15	EEPROM error	Restart the PC. If the problem cannot be resolved, replace the Ethernet Option Board.

FINS/TCP Connection Status

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
m+2	0	0	0	0	0	0	0	0	0	0	0	0	0	0		

Bit	Switch	Unit operation
0	FINS/TCP Connection No.1	0: The connection is terminated. 1: A connection is established.
1	FINS/TCP Connection No.2	0: The connection is terminated. 1: A connection is established.
2 to 15	Reserved	Always 0.

9-9-2 DM Area Allocation

The memory allocation about system setup is shown as the following diagram. These data will be allocated to the DM area of PLC. The beginning DM channel n is calculated by the following equation.


- Note**
1. DM area from n to $n+154$ can only display all of the settings stored in the unit. Modification in this area is invalid to the CP1W-CIF41 Ethernet Option Board.
 2. DM area $n+155$ and $n+156$ will display the IP address used by the CP1W-CIF41 when the power is turned ON.
 3. When the IP address is illegal, such as using CLASS D, CLASS E IP address, the values in words $n+3$ and $n+155$ will be different, and the CP1W-CIF41 will temporarily use the default IP address (192.168.250.1). Use this IP address to modify the IP address settings through Web browser.
 4. When the system settings are wrong, A525 can be used to reset CP1W-CIF41. Refer to *Appendix C* and *Appendix D* for details.

$$n = \text{DM32000} + 300 \times (\text{0xFD} - \text{Unit Address})$$

Offset	D15	D0
n	Mode setting (2 bytes)	
$n+1$	FINS/TCP port number (2 bytes)	
$n+2$	FINS/UDP port number (2 bytes)	
$n+3$	IP address (4 bytes)	
$n+5$	Subnet mask (4 bytes)	
$n+7$	Reserved (2 bytes)	
$n+8$	IP address table (194 bytes)	
$n+105$	IP router table (66 bytes)	
$n+138$	FINS/TCP connection setup (22 bytes)	
$n+149$	HTTP server setup (10 bytes)	
$n+154$	FINS node address (2 bytes)	
$n+155$	Using IP Address Display/Setting Area (4 bytes)	

The following table describes the unit address for each option port.

Option Port No.	I/O Capacity	Unit Address	Range of Status Area
Option port 1	14/20	0xFC	DM32300 to DM32456
	30/40/60	0xFD	DM32000 to DM32156
Option port 2	30/40/60	0xFC	DM32300 to DM32456

Mode Setting

Bit	Mode	Settings
0	Reserved	Always 0.
1	Broadcast address	0: 4.3BSD specifications 1: 4.2BSD specifications
2 to 3	IP address conversion method	00, 01: Automatic generation method 10: IP address table reference method 11: Combined method
4	FINS/UDP port number	0: Default (9600) 1: Unit setup value
5	FINS/TCP port number	0: Default (9600) 1: Unit setup value
6	FINS/UDP destination IP mode	0: Enable (Dynamically) 1: Disable (Static)
7	FINS/TCP protect function	0: Disable (Only FINS/TCP Server) 1: Enable (Only FINS/TCP Server)
8 to 15	Reserved	Always 0.

FINS/TCP and FINS/UDP Port Number

	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
n+1	FINS/TCP port number (hex)
n+2	FINS/UDP port number (hex)

When displaying 0000, the port number is 9600.

IP Address

	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
n+3	(1)(2) (3)(4)
n+4	(5)(6) (7)(8)


The IP address is (1)(2).(3)(4).(5)(6).(7)(8) (hex)

Subnet Mask

	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
n+5	(1)(2) (3)(4)
n+6	(5)(6) (7)(8)

The Subnet mask is (1)(2).(3)(4).(5)(6).(7)(8) (hex)

IP Address Table




Pointer of IP Address Table


Point to the last recorder in IP address table. For example, if the last recorder number in IP address table is 6, the value of this channel is 6.

IP Address Table Records

Each IP address table record has 6 bytes. The max number of records is 32. The configuration of the 6 bytes of data in each record is as shown in the following diagram.



IP Router Table




Pointer of IP Router Table

Point to the last recorder in IP router table. For example, if the last recorder number in IP router table is 6, the value of this channel is 6.

IP Router Table Records


Each IP router table record has 8 bytes. The max number of records is 8. The configuration of the 8 bytes of data in each record is as shown in the following diagram.



FINS/TCP Connection Setup

Offset	15	8	7	0
n+138	FINS/TCP Port Settings			
n+139	FINS/TCP connection No.1		FINS/TCP connection No.1	
n+140	FINS/TCP connection No.1		FINS/TCP connection No.1	
n+141	FINS/TCP connection No.1		FINS/TCP connection No.2	
n+142	FINS/TCP connection No.2		FINS/TCP connection No.2	
n+143	FINS/TCP connection No.2		FINS/TCP connection No.2	
n+144	Reserved (Always 0)			
:				
n+148				


FINS/TCP Port Settings




Bit	Settings	Unit operation
0	Reserved	Always 0.
1	Protect setting	0: The IP address of FINS/TCP connection No.1 is not under the protection. 1: The IP address of FINS/TCP connection No.1 is under the protection.
2 to 4	Reserved	Always 0.
5	Protect setting	0: The IP address of FINS/TCP connection No.2 is not under the protection. 1: The IP address of FINS/TCP connection No.2 is under the protection.
6 to 15	Reserved	Always 0.

FINS/TCP Connection No.1 to 2

Each FINS/TCP connection number has 5 bytes. The configuration of the 5 bytes of data in each number is as shown in the following diagram.




HTTP Server Setup




If the password for accessing the Ethernet Option Board's Web page is forgotten, find out it in this area. It is written in ASCII format.

FINS Node Address



The setting range is 0~ FE (hex).

Using IP Address Display/Setting Area



The IP address is (1)(2).(3)(4).(5)(6).(7)(8) (hex)

If the local IP address in the system setup is set to a value other than 0.0.0.0, this area will act as an IP address display area and the local IP address in the system setup will be read and stored here when the power is turned ON or the Ethernet Option Board restarted.

If the local IP address in the system setup is set to 0.0.0.0, this area will act as an IP address setting area. The value will be read by the Ethernet Option Board when the power is turned ON or the Ethernet Option Board restarted and is used as the local IP address.

If the IP address for accessing the Ethernet Option Board through Web browser is forgotten, find out it in this area.

Note When IP address in system setup area and DM area are all set to 0.0.0.0, the IP address will be 192.168.250.1 (FINS node address).

9-10 Web Browser Setup and Display

9-10-1 Multi-language Function

The WEB server supports the multi-language function. The supported languages are English, Chinese and Japanese.

Before setting, users should select the appropriate language in the following ULC.

English page: [http://\(Ethernet Option Board's IP address\)/E00.htm](http://(Ethernet Option Board's IP address)/E00.htm)

Japanese page: [http://\(Ethernet Option Board's IP address\)/J00.htm](http://(Ethernet Option Board's IP address)/J00.htm)

Chinese page: [http://\(Ethernet Option Board's IP address\)/C00.htm](http://(Ethernet Option Board's IP address)/C00.htm)

9-10-2 Overview of Web Browser Function

System setup for the Ethernet Option Board is as follows.

Setting Item		Reference Page
System	IP Address	574
	Subnet Mask	574
	FINS Node Address	574
	FINS/UDP Port	574
	FINS/TCP Port	574
	Address Conversion Mode	574
	FINS/UDP Option	574
	Broadcast Option	575
	FINS/TCP Protected	575
HTTP	WEB Password	576
	Port No.	576
IP Address Table	FINS Node Address	577
	IP Address	577
IP Router Table	IP Network Address	578
	Router IP Address	578
FINS/TCP	IP Address	579
	Auto-allocated FINS Node	579

Monitor status for the Ethernet Option Board is as follows.

Status	Reference Page
Unit information	580
Unit status	581
FINS status	582
Error log	583

9-10-3 System

OMRON Ethernet Option Board

[Settings]

[Menu](#)

1. IP Address and Protocols
 - [System](#)
 - [HTTP](#)
2. IP Address/Router Table
 - [IP Address Table](#)
 - [IP Router Table](#)
3. FINS/TCP
 - [Connection](#)

System Format

Parameter	Value
IP Address	192 . 168 . 250 . 1
Subnet Mask	255 . 255 . 255 . 0
FINS Node Address	1 [0: default(1)]
FINS/UDP Port	0 <input type="checkbox"/> Use Input Port No [Default(9600)]
FINS/TCP Port	0 <input type="checkbox"/> Use Input Port No [Default(9600)]
Address Conversion Mode	<input checked="" type="radio"/> Auto (Dynamic) <input type="radio"/> Auto (Static) <input type="radio"/> Manual <input type="radio"/> Auto & Manual
FINS/UDP Option	<input checked="" type="radio"/> Destination IP address is changed dynamically. <input type="radio"/> Destination IP address is Not changed dynamically.
Broadcast Option	<input checked="" type="radio"/> All '1' (4.3BSD) <input type="radio"/> All '0' (4.2BSD)
FINS/TCP Protected	<input type="checkbox"/> Use FINS/TCP Protection Function

System Format

Item	Contents	Default
IP Address	Set the local IP address for the Ethernet Option Board. • Setting range: 00.00.00.00 to 223.255.255.255	192.168.250.1
Subnet Mask	Set the subnet mask for the Ethernet Option Board. This is required if a method other than the IP address table method is used for address conversion.	255.255.255.0
FINS Node Address	Set the local FINS node address for the Ethernet Option Board. • Setting range: 1 to 254	1
FINS/UDP Port	Specify the local UDP port number to be used for the FINS communications service. The UDP port number is the number used for UDP identification of the application layer (i.e., FINS communications service). • Setting range: 1 to 65,535	9,600
FINS/TCP Port	Specify the local TCP port number to be used for the FINS communications service. The TCP port number is the number used for TCP identification of the application layer (i.e., the FINS communications service in this case). • Setting range: 1 to 65,535 Note Make the settings so that TCP port number 80 for HTTP does not overlap. The port number setting only has an effect on the FINS/TCP server function, not on the FINS/TCP client function. FINS/TCP client port will switch from 3000 to 65535 automatically for connection.	9,600
Use Input Port No.	Check this checkbox, if you want the user defined port number for UDP or TCP to be in effect.	Unchecked
Address Conversion Mode	Select any of the following as the method for finding and converting IP addresses from FINS node addresses. (Enabled for FINS/UDP only.) • Auto (dynamic): Automatic generation (dynamic) • Auto (static): Automatic generation (static) • Manual: IP address table method • Auto & Manual: Combined method	Auto (dynamic)
FINS/UDP Option	Select to dynamically change the remote (destination) IP address for FINS/UDP or not. To prohibit dynamic changes, check the second box.	Change dynamically

Item	Contents	Default
Broadcast Option	Set the method for specifying IP addresses for broadcasting in FINS/UDP. <ul style="list-style-type: none"> • All '1' (4.3BSD): Broadcast with host number set to all ones. • All '0' (4.2BSD): Broadcast with host number set to all zeros. Normally the default setting should be used.	All '1' (4.3BSD)
FINS/TCP Protected	When this option is selected, if the FINS/TCP connection is set to a server, and if an IP address other than 0.0.0.0 is set to destination IP address, any connection request from other than the setting IP address will be denied. Select this option to prevent faulty operation (by FINS commands) from specific nodes from affecting the PLC.	Unchecked

The functions of the buttons are as follows.

Button	Function
Transfer	Transfer the entered values from the personal computer to the Ethernet Option Board. (The new settings are invalid until the Ethernet Option Board has been reset.)
Cancel	Cancel the entered values.
Restart	Restart the Ethernet Option Board to enable the new settings after transfer. The Restart button is invalid to the PLC.

9-10-4 HTTP

OMRON Ethernet Option Board

[Settings]

[Menu](#)

1. IP Address and Protocols
 o [System](#)
 o [HTTP](#)
2. IP Address/Router Table
 o [IP Address Table](#)
 o [IP Router Table](#)
3. FINS/TCP
 o [Connection](#)

HTTP Server Setup

Parameter	Value
WEB Password	<input type="text"/>
Port Number	<input type="text" value="0"/> [0: default(80)]

HTTP Server Setup

Item	Contents	Default
WEB Password	Set the password for accessing the Ethernet Option Board's settings and status monitoring information.	ETHERNET
Port Number	Set the port No. used to connect to the Web browser.	80

The functions of the buttons are as follows.

Button	Function
Transfer	Transfer the entered values from the personal computer to the Ethernet Option Board. (The new settings are invalid until the Ethernet Option Board has been reset.)
Cancel	Cancel the entered values.
Restart	Restart the Ethernet Option Board to enable the new settings after transfer. The Restart button is invalid to the PLC.

9-10-5 IP Address Table

Set the IP address table that defines the relationship between FINS node addresses and IP addresses. With FINS/UDP, this is enabled only when the IP address table method is set to the IP address conversion method.

The screenshot shows the 'OMRON Ethernet Option Board' web interface. On the left is a navigation menu with 'Settings' selected, containing links for 'Menu', 'System', 'HTTP', 'IP Address/Router Table', 'IP Address Table', 'IP Router Table', 'FINS/TCP', and 'Connection'. The main area is titled 'IP Address Table' and contains a 'Setting Form' with two input fields: 'FINS Node Address' (with a range of 1 - 254) and 'IP Address' (with four separate boxes for octets). Below these are 'Transfer', 'Cancel', and 'Restart' buttons. A 'Setting List' table is also present, with columns for 'No', 'FINS Node Address', and 'IP Address'. The first row shows '01' in the 'No' column, and 'Show' and 'Delete' buttons are at the bottom.

Item	Contents	Default
FINS Node Address	Set the node address for the remote device.	None
IP Address	Set the related IP address for the remote device.	None

The functions of the buttons are as follows.

Button	Function
Transfer	Transfer the entered values from the personal computer to the Ethernet Option Board. (The new settings are invalid until the Ethernet Option Board has been reset.)
Cancel	Cancel the entered values.
Restart	Restart the Ethernet Option Board to enable the new settings after transfer. The Restart button is invalid to the PLC.
Show	Show the FINS node address and IP address of the selected No.
Delete	Delete the IP address table of the selected No.

9-10-6 IP Router Table

Set the IP router table when the Ethernet Option Board is to communicate through the IP router with nodes on another IP network segment.

The screenshot shows the OMRON Ethernet Option Board web interface. On the left is a sidebar with a menu. The main area is titled 'IP Router Table' and contains a 'Setting Form' and a 'Setting List'.

OMRON Ethernet Option Board

[Settings]

[Menu](#)

1. IP Address and Protocols
 - o [System](#)
 - o [HTTP](#)
2. IP Address/Router Table
 - o [IP Address Table](#)
 - o [IP Router Table](#)
3. FINS/TCP
 - o [Connection](#)

IP Router Table

Setting Form

Parameter	Value
IP Network Address	<input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/>
Router IP Address	<input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/>

Transfer Cancel Restart

Setting List

No	IP Network Address	Router IP Address
01		

Show Delete

Item	Contents	Default
IP Network Address	Set the network ID from the IP address.	None
Router IP Address	Set the related IP address of a router connected to a network.	None

The functions of the buttons are as follows.

Button	Function
Transfer	Transfer the entered values from the personal computer to the Ethernet Option Board. (The new settings are invalid until the Ethernet Option Board has been reset.)
Cancel	Cancel the entered values.
Restart	Restart the Ethernet Option Board to enable the new settings after transfer. The Restart button is invalid to the PLC.
Show	Show the IP network address and Router IP address of the selected No.
Delete	Delete the IP router table of the selected No.

9-10-7 FINS/TCP

OMRON Ethernet Option Board

[Settings]

[Menu](#)

1. IP Address and Protocols
 - o [System](#)
 - o [HTTP](#)
2. IP Address/Router Table
 - o [IP Address Table](#)
 - o [IP Router Table](#)
3. FINS/TCP
 - o [Connection](#)

FINS/TCP Connection Setup

No	Mode	Value
1	FINS/TCP Server	IP Address : 0 . 0 . 0 . 0 Auto-allocated FINS Node : 251
2	FINS/TCP Server	IP Address : 0 . 0 . 0 . 0 Auto-allocated FINS Node : 252

FINS/TCP Connection Setup

Item	Contents	Default
No.	Shows the connection number. This is a network API used when TCP is used for the FINS communications service. Up to 2 can be used at a time, and they are identified by connection numbers 1 to 2. The Ethernet Option Board can thus simultaneously execute the FINS communications service by TCP with up to 2 remote nodes.	---
IP Address	<ul style="list-style-type: none"> When the Ethernet Option Board is used as a server: If the option is selected to use IP addresses to protect, set the IP addresses as required at clients from which connection is permitted. If not set for those connections, the default setting can be used. When the Ethernet Option Board is used as a client: Set the IP address for the remote Ethernet Unit (i.e., the server) that is to be connected by FINS/TCP. It is required that an IP address be set for the remote Ethernet Unit. 	0.0.0.0
Auto-allocated FINS node	If the client (normally a personal computer) application supports FINS/TCP, and if FINS node addresses are not fixed, the client will take 0 as its node address. Then, when a FINS command arrives, the number set here (from 251 to 252) will automatically be allocated as the client's FINS node address.	From 251 to 252, for connection No. 1 to 2

The functions of the buttons are as follows.

Button	Function
Transfer	Transfer the entered values from the personal computer to the Ethernet Option Board. (The new settings are invalid until the Ethernet Option Board has been reset.)
Cancel	Cancel the entered values.
Restart	Restart the Ethernet Option Board to enable the new settings after transfer. The Restart button is invalid to the PLC.

9-10-8 Unit Information

OMRON Ethernet Option Board [Status View] Menu 1. Unit Information 2. Unit Status 3. FINS Status 4. Error Log	Unit Information	
	Parameter	Value
	Model	CP1W-CIF41
	Version	V1.05
	IP Address	192.168.250.1
	Subnet Mask	255.255.255.0
	FINS/UDP Port Number	9600
	Use Input Port Number	Unused
	Broadcast Setting	All '1' (4.3BSD)
	IP Address Conversion	Auto (Dynamic)
	Ethernet Address	00-00-0A-3A-C0-05

Parameter	Contents
Model	Show the model information of the Ethernet Option Board.
Version	Show the version information of the Ethernet Option Board.
IP Address	Show the IP address of the Ethernet Option Board.
Subnet Mask	Show the subnet mask of the Ethernet Option Board.
FINS/UDP Port Number	Show the FINS/UDP port number of the Ethernet Option Board.
Use Input Port Number	Show the effective port number setting mode.
Broadcast Setting	Show the broadcast setting of the Ethernet Option Board.
IP Address Conversion	Show the IP address conversion method of the Ethernet Option Board.
Ethernet Address	Show the MAC ID of the Ethernet Option Board.

9-10-9 Unit Status

OMRON Ethernet

Option Board

[Status View]

Menu

1. Unit Information

2. Unit Status

3. FINS Status

4. Error Log

Unit Status

Parameter		Value
Error Flags	IP Address Error	Normal
	IP Address Table Error	Normal
	IP Router Table Error	Normal
	Router Table Error	Normal
	Address Disagreement	Normal
	EEPROM Error	Normal
Total Number of Packets Received		0
Total Number of Receive Errors		0
Total Number of Packets Sent		0
Total Number of Errors Sent		0

Parameter	Contents
Error Flags	Indicate the operating status and errors that occurred when the Ethernet Option Board is turned ON.
Total Number of Packets Received	Show the total number of packets received by the Ethernet Option Board.
Total Number of Receive Errors	Show the total number of errors detected while the Ethernet Option Board was receiving. The types of errors detected are short packet errors, alignment errors, CRC errors, frame length errors and communication controller overflow errors.
Total Number of Packets Sent	Show the total number of packets sent by the Ethernet Option Board.
Total Number of Errors Sent	Show the total number of errors detected while the Ethernet Option Board was sending.

9-10-10 FINS Status

**OMRON Ethernet
Option Board**

[Status View]

[Menu](#)

1. [Unit Information](#)
2. [Unit Status](#)
3. [FINS Status](#)
4. [Error Log](#)

FINS Status

Node	Connection Type	Local Port No.	Remote IP	Remote Port No.	TCP Connection No.	TCP status
01						

Parameter	Contents
Node	Show the FINS node address.
Connection Type	Show the protocol used by connection with the related node address.
Local Port No.	Show the port number of the Ethernet Option Board for connection with the related node address.
Remote IP	Show the IP address of the related node address.
Remote Port No.	Show the remote port number of the related node address for connection.
TCP Connection No.	If the connection is the FINS/TCP, show the connection number (1 to 4).
TCP Status	If the connection is the FINS/TCP, show the current connection status.

The details of TCP status are listed as the following table.

Status	Meaning
CLOSED	Connection closed
LISTEN	Waiting for connection
SYN SENT	SYN sent in active status
SYN RECEIVED	SYN received and sent
ESTABLISHED	Already established
CLOSE WAIT	FIN received and waiting for completion
FIN WAIT1	Completed and FIN sent
CLOSING	Completed and exchanged FIN. Awaiting ACK.
LAST ACK	FIN sent and completed. Awaiting ACK.
FIN WAIT2	Completed and ACK received. Awaiting FIN.
TIME WAIT	After closing, pauses twice the maximum segment life (2MSL).

The function of the button is as follows.

Button	Function
Send	Show the FINS status of the selected No.

9-10-11 Error Log

**OMRON Ethernet
Option Board**

[Status View]

[Menu](#)

1. [Unit Information](#)
2. [Unit Status](#)
3. [FINS Status](#)
4. [Error Log](#)

Error Log

No.	Error Code	Detail Code	Date
01			

Parameter	Contents
No.	Show the error recorder number.
Error Code	Show the error code of the error recorder.
Detail Code	Show the detail error code of the error recorder.
Date	Show the date of the error recorder.

The functions of the buttons are as follows.

Button	Function
Send	Show the error log of the selected No.
Clear Error Log	Clear the error log table.

9-11 Trouble Shooting

9-11-1 Error Log

The Ethernet Option Board provides an error log that records errors occurred during Ethernet Option Board operation. The contents of the error log can be read or cleared from the Web Brower.

Logged Errors

The following errors are recorded in the error log.

- Errors in network operation
- Errors in data transfers
- Error in the CPU unit

Error Log Table

Each error is recorded as one record in an error log table. Up to 20 records can be saved. If more than 20 errors occur, the oldest errors will be deleted from the error log and the most recent error will be recorded.

The following information is recorded in the error log table.

- Main error code (see table later in this section)
- Detailed error code (see table later in this section)
- Time stamp (from the clock in the CPU unit)

Note During the initialization of the Ethernet Option Board, if an error occurs, the error log time stamp will record as 2000-00-00 00:00:00.

Error Log Location

When an error is detected, the error codes and time stamp are recorded in the error log in RAM inside the Ethernet Option Board. Serious errors are also recorded in EEPROM. The maximum number of errors that can be saved to EEPROM is 20 for the CP1L and CP1H. The errors recorded in EEPROM will be saved even if the unit is restarted or power is turned OFF.

Error Codes

Error code	ERR LED	Meaning	Detailed error code		Correction	EEPROM
			1st byte	2nd byte		
0002	LIT	CPU Unit service monitoring error	Monitor time (ms)		Check and correct the CPU Unit's operating environment. Note Recovery is possible for this error. When operation is restored, operations will return to normal.	Saved
0015	FLASH	CPU Unit fatal error			Eliminate the cause of the error in the CPU Unit.	---
010E	---	No routing table entry (send failed)	Commands Bit 15: OFF Bits 08 to 14: SNA Bits 00 to 07: SA1 Responses Bit 15: ON Bits 08 to 14: DNA Bits 00 to 07: DA1		Set the local node, remote node, and relay nodes in the routing tables.	---
010F	---	Routing table error (send failed)			Create the routing tables correctly.	---
0110	---	Too many relay points (send failed)			Reconstruct the network or correct the routing tables so that commands are sent to within a 3-level network range.	---
0111	---	Command too long (send failed)			Check the command format and set the correct command data.	---
0112	---	Header error (send failed)			Check the command format and set the correct command data.	---
0117	---	Internal buffers full; packet discarded			Change the network so that traffic is not concentrated.	---
0120	---	Unexpected routing error			Check the routing tables.	---
0123	---	Internal send buffers full; packet discarded			Change the network so that traffic is not concentrated.	---
0125	---	Time out error			Resend the command.	---
021A	FLASH	Logic error in setting table	00	02: Network parameters 03: Routing tables 04: Unit Setup 05: CPU Bus Unit Words (CIO/DM)	Recreate the data specified by the 2nd byte of the detailed error code.	Saved

Error code	ERR LED	Meaning	Detailed error code		Correction	EEPROM
			1st byte	2nd byte		
03C0	FLASH	FINS/TCP setting error	01 to 02: Connection No.	01: Automatically allocated FINS node address duplication 02: Destination IP address error 03: Destination port number error	Set the FINS/TCP settings correctly.	---
03C2	---	FINS/TCP packet discarded	01 to 02: Connection No.	03: Reception error	Resend the command.	---
				04: Transmission error	There is too much load (traffic) on the Ethernet Option Board. Correct the system so that traffic is not concentrated.	---
03C3	---	FINS/UDP Packet discarded	00	01 to FE Node address	The automatic generation (static) method was used as the IP address conversion method, so remote IP address information in internal memory could not be changed.	---
03C8	---	Socket Error	Arbitrary		Resend the packet or the destination node is not in the network.	---
03D0	FLASH	System setup sum value error			Reset the value of system setup area, Restart CPU Unit.	Saved
0601	LIT	Option Board error	Arbitrary		Restart the CPU Unit. If the problem persists, replace the Ethernet Option Board.	Saved
0602	LIT	Option Board memory error	01: Read error 02: Write error	06: Error log	Restart the CPU Unit. If the problem persists, replace the Ethernet Option Board.	Saved (except error log)

9-11-2 Trouble-shooting with Indicators and Error Code Display

ERR Indicator	Error	Probably Cause	Error code (hex)	Correction
Lit	CPU Unit service monitoring error	Service from the CPU Unit was not completed within the fixed interval. The monitoring time is normally 11s.	0002	Check and correct the CPU Unit's operating environment. Check whether the related DIP SW is on. Refer to 9-8-2 <i>Installation and Removing</i> . Note Recovery is possible for this error. When operation is restored, it will return to normal.
	Two option boards (unit version 1.0) installed	Two option boards have been installed on the CPU Unit.	---	Uninstall the Ethernet Option Board in one serial port of the CPU Unit and restart the CPU unit.
	Option board error	An error occurred in the Ethernet Option Board.	0601	Restart the CPU Unit. Replace the Ethernet Option Board if the error recurs.
	Option board memory error	An error occurred in the Unit's non-volatile memory itself. This error will occur while writing or reading the error log, system setup, identity data, MAC ID.	0602	Restart the CPU Unit. Replace the Ethernet Option Board if the error recurs.
Flashing	CPU Unit fatal error	A fatal error occurred in the CPU Unit.	0015	Eliminate the cause of the error in the CPU Unit.
	IP address setting error	The IP address is set incorrectly.	021A	Correct the IP address. Do not set any of the following IP addresses. • Host IDs that are all 0 or all 1. • Network IDs that are all 0 or all 1. • Subnetwork IDs that are all 1. • Addresses beginning with 127 (7F hex).
	IP address table error	The IP address table is set incorrectly.	021A	Correct the IP address table.
	IP Router table setting error	The IP Router table is set incorrectly.	021A	Correct the IP Router table.
	Address Disagreement	The node number set for the option board does not agree with the host ID in the IP address. This probably occurs when the address conversion method is set for automatic address generation.	021A	Make sure that the node number and the last byte of the IP address are the same and then set other host IDs to 0. Change the address conversion method.
	Logic error in setting table	There is a logic error in the setting table.	021A	Recreate the data specified by the 2nd byte of the detailed error code.
	System setup Sum check error	The Checksum of System setup is incorrect.	03D0	Reset the value of system setup area. Restart the CPU Unit.
	FINS/TCP setting error	The settings of FINS/TCP are incorrect.	03C0	Refer to operation manual and set the FINS/TCP setting correctly.

9-11-3 Error Status

The status of errors that occur at the Ethernet Option Board is reflected in CIO relation area, Refer to 9-9-1 *CIO Area Allocation, Error Status* for details.


9-12 Sample Application

The following examples show how to connect online from a CX-Programmer on an Ethernet network to a PLC on the Ethernet network.

Note Please use CX-Programmer version 8.1 or higher (CX-ONE version 3.1 or higher).

■ System Configuration Example 1: No Routing

In this example, an online connection is made by FINS/UDP to a PLC on an Ethernet network (PLC1 in the diagram below) from a CX-Programmer / CX-Integrator connected to the Ethernet network.



Web Browser Setting

Item	Setting
Broadcast	All ones (4.3BSD)
FINS/UDP port	Default (9600)
IP address	192.168.250.2
Subnet mask	255.255.255.0
FINS Node Address	2
IP address conversion	Automatic generation method (dynamic)
Baud rate	Automatic Detaction
IP router tabel	None

OMRON Ethernet Option Board
[Settings]
[Menu](#)
1. IP Address and Protocols
 o [System](#)
 o [HTTP](#)
2. IP Address/Router Table
 o [IP Address Table](#)
 o [IP Router Table](#)
3. FINS/TCP
 o [Connection](#)

System Format

Parameter	Value
IP Address	192 . 168 . 250 . 2
Subnet Mask	255 . 255 . 255 . 0
FINS Node Address	2 [0: default(1)]
FINS/UDP Port	0 <input type="checkbox"/> Use Input Port No [Default(9600)]
FINS/TCP Port	0 <input type="checkbox"/> Use Input Port No [Default(9600)]
Address Conversion Mode	<input checked="" type="radio"/> Auto (Dynamic) <input type="radio"/> Auto (Static) <input type="radio"/> Manual <input type="radio"/> Auto & Manual
FINS/UDP Option	<input checked="" type="radio"/> Destination IP address is changed dynamically. <input type="radio"/> Destination IP address is Not changed dynamically.
Broadcast Option	<input checked="" type="radio"/> All '1' (4.3BSD) <input type="radio"/> All '0' (4.2BSD)
FINS/TCP Protected	<input type="checkbox"/> Use FINS/TCP Protection Function

Transfer Cancel Restart

CX-Programmer's Change PLC Dialog Box


Item			Setting
PLC name			PLC1
Network classification			Ethernet
Network Tab	FINS transmission source address		0
	FINS destination	Network number	0
		Node address	2
	Frame length		1,004bytes
	Response monitor time		5 seconds
Driver Tab	Workstation node address		1
	Automatic generation method		Not selected
	Ethernet Option Board IP address		192.168.250.2
	Port number		9600

Note Limited by the CP1W-CIF41 inner bus protocol (Toolbus), the frame length and response monitor time are different from the existing Ethernet unit.

Inputs to the CX-Programmer's Setup Window**Change PLC Settings**

The screenshot shows the 'Change PLC' dialog box. The 'Device Name' field is set to 'NewPLC1'. The 'Device Type' dropdown is set to 'CP1L'. The 'Network Type' dropdown is set to 'Ethernet'. The 'Comment' field is empty. The 'Settings...' buttons are visible next to the 'Device Type' and 'Network Type' dropdowns. The 'OK', 'Cancel', and 'Help' buttons are at the bottom.

Network Settings (Network Tab)




The dialog box is titled "Network Settings [Ethernet]" and has a close button (X) in the top right corner. It features two tabs: "Network" (selected) and "Driver". The "Network" tab contains several settings:

- FINS Source Address:** A group box containing three spinners for "Network" (0), "Node" (0), and "Unit" (0).
- FINS Destination Address:** A group box containing three spinners for "Network" (0), "Node" (2), and "Unit" (0).
- Frame Length:** A spinner set to 1004.
- Response Timeout (s):** A spinner set to 5.
- Host Link Unit Number:** A spinner set to 0.
- Network Operating Level:** Two radio buttons, "#0" (selected) and "#1".

At the bottom of the dialog are three buttons: "OK", "Cancel", and "Help".

Network Settings (Driver Tab)




The dialog box is titled "Network Settings [Ethernet]" and has a close button (X) in the top right corner. It features two tabs: "Network" and "Driver" (selected). The "Driver" tab contains the following settings:

- Workstation Node Number:** A spinner set to 1, with an "Auto-detect" checkbox to its right.
- IP Address:** A text field containing "192 . 168 . 250 . 2".
- Port Number:** A text field containing "9600".

At the bottom of the dialog are three buttons: "OK", "Cancel", and "Help".

■ System Configuration Example 2: Using Routing Tables

In this example, an online connection is made via the Ethernet to a PLC on a Controller Link network (PLC3 in the diagram below) from a CX-Programmer / CX-Integrator connected to the Ethernet network.



Web Browser Setting

Same as for *System Configuration Example 1*.

CX-Programmer's Change PLC Dialog Box

Settings for target PLC (PLC1)'s Change PLC Dialog Box			Setting
PLC name			PLC2
Network classification			PLC1
Network Tab	FINS transmission source address		2
	FINS destination	Network number	1
		Node address	1
	Frame length		542bytes (default)
	Response monitor time		5 seconds

Routing Table Settings and Transfer to Each PLC

Set the routing tables with CX-Integrator, and transfer them.

- 1,2,3...**
- Using CX-Integrator, connect online, and select **Routing table - Settings**. Then create FINS local routing tables (a local network table and a relay network table).

Example: PLC 1 Routing Table Settings

• Local Network Table

Unit number	Local network number
0	1
1	2

• Relay Network Table (None)

Example: PLC 2 and PLC 3 Routing Table Settings

• Local Network Table


Option port No.	I/O capacity	Unit address	Local network number
Option port 1	14/20	252(0xFC hex)	1
	30/40/60	253(0xFD hex)	1
Option port 2	30/40/60	252(0xFC hex)	1

• Relay Network Table

In order to relay from PLC2/3 to the final network number 2, it is necessary to relay via node address 1 on relay network number 2.

Final network number	Relay network number	Relay node address
2	1	2

- Save the routing table file (File - Save local routing table file).
- Select **New** from the Project Menu, and save with a file name. Then select **Add Device** from the Project Menu. For each PLC, register a PLC with a direct serial connection (node address: 0), and select it.
- With CX-Integrator, select **Open** from the PLC Menu.
- Select **Routing table - Setup**, read the saved file, and select **Options - Transfer to PLC**. Click **Yes** to transfer the routing tables to the connected PLCs.

9-13 Buffer Configuration (CP1W-CIF41)

SECTION 10

Program Transfer, Trial Operation, and Debugging

This section describes the processes used to transfer the program to the CPU Unit and the functions that can be used to test and debug the program.

10-1	Program Transfer.	594
10-2	Trial Operation and Debugging.	594
10-2-1	Forced Set/Reset.	594
10-2-2	Differential Monitoring.	595
10-2-3	Online Editing.	596
10-2-4	Tracing Data	598

10-1 Program Transfer

The CX-Programmer is used to transfer the programs, PLC Setup, I/O memory data, and I/O comments to the CPU Unit with the CPU Unit in PROGRAM mode. The following procedure is used.

- 1,2,3...
1. Select **PLC - Transfer - To PLC**. The Download Options Dialog Box will be displayed.
 2. Specify the items to transfer.
 3. Click the **OK** Button.

Note The program data on a Memory Cassette can be automatic transferred when the power is turned ON.

10-2 Trial Operation and Debugging

10-2-1 Forced Set/Reset


The CX-Programmer can force-set (ON) or reset (OFF) specified bits in the CIO Area, Auxiliary Area, and HR Area, as well as timer/counter Completion Flags. Forced status will take priority over status output from the program or I/O refreshing. This status cannot be overwritten by instructions, and will be stored regardless of the status of the program or external inputs until it is cleared from the CX-Programmer.

Force-set/reset operations are used to force input and output during a trial operation or to force certain conditions during debugging.

Force-set/reset operations can be executed in either MONITOR or PROGRAM modes, but not in RUN mode.

Note Turn ON the Forced Status Hold Bit (A500.13) and the IOM Hold Bit (A500.12) at the same time to retain the status of bits that have been force-set or reset when switching the operating mode.

Turn ON the Forced Status Hold Bit (A500.13) and the IOM Hold Bit (A500.12), and set the Forced Status Hold Bit at Startup parameter in the PLC Setup to retain the status of the Forced Status Hold Bit hold to retain the status of bits that have been force-set or reset when turning OFF the power.




The following areas can be force-set and reset: CIO Area (I/O bits, data link bits, CPU Bus Unit bits, Special I/O Unit bits, and work bits), Work Area, Timer Completion Flags, HR Area, Counter Completion Flags.

CX-Programmer Operation

- Selecting bits for forced setting/resetting
- Selecting forced set or forced reset status
- Clearing forced status (also clearing all forced status at the same time)

10-2-2 Differential Monitoring

When the CPU Unit detects that a bit set by the CX-Programmer has changed from OFF to ON or from ON to OFF, the results are indicated in the Differentiate Monitor Completed Flag (A508.09). The Flag will turn ON when conditions set for the differential monitor have been met. The CX-Programmer can monitor and display these results on screen.



CX-Programmer Operation

- 1,2,3...
1. Right-click the bit for differential monitoring.
2. Click **Differential Monitor** from the PLC Menu. The Differential Monitor Dialog Box will be displayed.
3. Click **Rising** or **Falling**.
4. Click the **Start** Button. The buzzer will sound when the specified change is detected and the count will be incremented.
5. Click the **Stop** Button. Differential monitoring will stop.


Related Auxiliary Bits/Words

Name	Address	Description
Differentiate Monitor Completed Flag	A508.09	Turns ON when the differential monitoring condition has been met during differential monitoring. Note: The flag will be cleared when differential monitoring is started.

10-2-3 Online Editing

The Online Editing function is used to add to or change part of a program in a CPU Unit directly from the CX-Programmer when the CPU Unit is in MONITOR or PROGRAM mode. This function is designed for minor program changes without stopping the CPU Unit.

Online editing is possible simultaneously from more than one computer running the CX-Programmer as long as different tasks are edited.



The cycle time will be increased by from one to several cycle times if the program in the CPU Unit is edited online in MONITOR mode. The cycle time will also be increased to back up data in the flash memory after online editing. The BKUP indicator will be lit during this period and the progress of the backup will be displayed on the CX-Programmer. The increases per cycle are listed in the following table.

CPU Unit	Increase in cycle time	
	Online editing	Backup to flash memory
CP1H CPU Units	26 ms max.	4% of cycle time

There is a limit to the number of edits that can be made consecutively. The actual number depends on the type of editing that is performed, but 40 edits should be used as a guideline. A message will be displayed on the CX-Programmer if the limit is exceeded, and further editing will not be possible until the CPU Unit has completed backing up the data.

The length of time that the cycle time is extended due to online editing is almost unaffected by the size of the task program being edited.

Precautions


The cycle time will be longer than normal when a program is overwritten using Online Editing in MONITOR mode, so make sure that the amount of time that it is extended will not exceed the cycle monitoring time set in the PLC Setup. If it does exceed the monitoring time, then a Cycle Time Over error will occur, and the CPU Unit will stop. Restart the CPU Unit by selecting PROGRAM mode first before changing to RUN or MONITOR mode.

Note If the task being edited online contains a block program, then previous execution information, such as Standby (WAIT) or Pause status, will be cleared by online editing, and the next execution will be from the beginning.

Online Editing from the CX-Programmer

- 1,2,3... 1. Display the program section that will be edited.
2. Select the instructions to be edited.
3. Select **Program - Online Edit - Begin**.

4. Edit the instructions.
5. Select **Program - Online Edit - Send Changes** The instructions will be check and, if there are no errors, they will be transferred to the CPU Unit. The instructions in the CPU Unit will be overwritten and cycle time will be increased at this time.

 **Caution** Proceed with Online Editing only after verifying that the extended cycle time will not adversely affect operation. Input signals may not be read if the cycle time is too long.

Temporarily Disabling Online Editing

It is possible to disable online editing for specific cycles to ensure response characteristics for machine control in those cycles. Online editing from the CX-Programmer will be disabled for those cycles and any requests for online editing received during those cycles will be held online editing is enables.

Online editing is disabled by setting the Online Editing Disable Bit Validator (A527.00 to A527.07) to 5A and then turning ON the Online Editing Disable Bit (A527.09). When these settings have been made and a request for online editing is received, online editing will be put on standby and the Online Editing Wait Flag (A201.10) will be turned ON.

When the Online Editing Disable Bit (A527.09) is turned OFF, online editing will be performed, the Online Editing Processing Flag (A201.11) will turn ON, and the Online Editing Wait Flag (A201.10) will turn OFF. When online editing has been completed, the Online Editing Processing Flag (A201.11) will turn OFF.

Online editing can also be temporarily disabled by turning ON the Online Editing Disable Bit (A527.09) while online editing is being performed. Here too, the Online Editing Wait Flag (A201.10) will turn ON.

If a second request for online editing is received while the first request is on standby, the second request will not be recorded and an error will occur.

Online editing can also be disabled to prevent accidental online editing. As described above, disable online editing by setting the Online Editing Disable Bit Validator (A527.00 to A527.07) to 5A and turning ON the Online Editing Disable Bit (A527.09).

Enabling Online Editing from the CX-Programmer

When online editing cannot be enabled from the program, it can be enabled from the CX-Programmer. If operations continue with online editing in standby status, CX-Programmer may go offline. If this occurs, reconnect the computer to the CPU Unit and turn OFF the Online Edit Disable Bit (A527.09).

Related Auxiliary Bits/Words

Name	Address	Description
Online Edit Disable Bit Validator	A527.00 to A527.07	Enables using the Online Edit Disable Bit (A527.09). Not 5A: Online Edit Disable Bit disabled. 5A: Online Edit Disable Bit enabled.
Online Edit Disable Bit	A527.09	To disable online editing, set the Online Edit Disable Bit Validator (A527.00 to A527.07) to 5A and turn ON this bit ON.
Online Editing Wait Flag	A201.10	ON while an online editing process is on standby because online editing is disabled.
Online Editing Processing Flag	A201.11	ON while an online editing process is being executed.

10-2-4 Tracing Data

The Data Trace function samples specified I/O memory data using any one of the following timing methods. It stores the sampled data in Trace Memory, where they can be read and checked later from the CX-Programmer.

- Specified sampling time (10 to 2,550 ms in 10-ms units)
- One sample per cycle
- When the TRACE MEMORY SAMPLING instruction (TRSM(045)) is executed

Up to 31 bits and 6 words in I/O memory can be specified for sampling.

Basic Procedure

- 1,2,3...**
1. Sampling will start when the parameters have been set from the CX-Programmer and the command to start tracing has been executed.
 2. Sampled data (after step 1 above) will be traced when the trace trigger condition is met, and the data just after the delay (see note 1) will be stored in Trace Memory.
 3. Memory data will be sampled until the Trace Memory is full, and then the trace will be ended.

Note Delay value: Specifies how many sampling periods to offset the sampling in Trace Memory from when the trace condition is met. The setting ranges are shown in the following table.


No. of words sampled	Setting range
0	–1999 to 2000
1	–1332 to 1333
2	–999 to 1000
3	–799 to 800
4	–665 to 666
5	–570 to 571
6	–499 to 500

Positive delay: Store data delayed by the set delay.

Negative delay: Store previous data according go to the set delay.

Example: Sampling at 10 ms with a –30 ms delay time yields $-30 \times 10 = 300$ ms, so data 300 ms before the trigger will be stored.

Note Use the CX-Programmer to turn ON the Sampling Start Bit (A508.15). Never turn ON this bit from the user program.



The following traces can be executed.

Scheduled Data Trace

A scheduled data trace will sample data at fixed intervals. Specified sampling interval is 10 to 2,550 ms in 10-ms units. Do not use the TRSM(045) instruction in the user program and be sure to set the sampling period higher than 0.

One-cycle Data Trace

A one-cycle data trace will sample I/O refresh data after the end of all cyclic tasks. Do not use the TRSM(045) instruction in the user program and be sure to set the sampling period higher than 0.

Data Trace via TRSM(045)

A sample will be taken once each time the TRACE MEMORY SAMPLING instruction (TRSM(045)) instruction is executed. When more than one TRSM(045) instruction is used in the program, a sample will be taken each time TRSM(045) is executed after the trace trigger condition has been met until trace memory is full.

Data Trace Procedure

Use the following procedure to execute tracing.

- 1,2,3...** 1. Use the CX-Programmer to set trace parameters (select **PLC - Data Trace** and then select **Operation - Configure**):
Addresses of the sampled words/bits, sampling period, delay time, and trigger conditions.
2. Use the CX-Programmer to start sampling or turn ON the Sampling Start Bit (A508.15).
3. Put the trace trigger condition into effect.
4. End tracing.
5. Use CX-Programmer to read the trace data.
 - a) Select **Data Trace** from the PLC Menu.
 - b) Select **Select** from the Operation Menu.
 - c) Select **Execute** from the Operation Menu.
 - d) Select **Read** from the Operation Menu.

Related Auxiliary Bits/Words

Name	Address	Description
Sampling Start Bit	A508.15	Use the CX-Programmer to turn ON this bit to start sampling. This bit must be turned ON from the CX-Programmer. Do not turn this bit ON and OFF from the user program. Note: The bit will be turned OFF when the Data Trace has been completed.
Trace Start Bit	A508.14	When this bit is turned ON, the trace trigger will be monitored and sampled data will be stored in Trace Memory when the trigger condition is met. The following traces are enabled with this bit. 1) Scheduled trace (trace at fixed intervals of 10 to 2,550 ms) 2) TRSM(045) instruction trace (trace when the TRSM(045) is executed) 3) One-cycle trace (trace at the end of execution of all cyclic tasks)
Trace Trigger Monitor Flag	A508.11	This flag turns ON when the trace trigger condition has been met after the Trace Start Bit has turned ON. This flag will turn OFF when the sampling is started.
Trace Busy Flag	A508.13	This flag turns ON when sampling is started and turns OFF when the trace has been completed.
Trace Completed Flag	A508.12	This flag turns ON when Trace Memory becomes full after the trace trigger condition has been met during a trace operation and turns OFF when the next sampling operation is started.

SECTION 11

Troubleshooting

This section provides information on hardware and software errors that occur during CP1H operation.

11-1	Error Classification and Confirmation	602
11-2	Troubleshooting	607
11-2-1	Error Processing Flowchart	608
11-2-2	No Operation When Power Is Supplied	608
11-2-3	Fatal Errors	609
11-2-4	CPU Errors	614
11-2-5	Non-fatal Errors	614
11-2-6	Other Errors	618
11-3	Error Log	619
11-4	Troubleshooting Unit Errors	620

11-1 Error Classification and Confirmation

Error Categories

Errors in CP1H CPU Units can be broadly divided into the following four categories.

Category	Comments
CPU Error	A WDT (watchdog timer) error is generated in the CPU Unit, the CPU Unit will malfunction, and operation will stop.
CPU Standby	The CPU will go on standby because conditions for starting operation have not yet been met.
Fatal Error	Operation cannot continue. Operation will stop due to a serious problem.
Non-fatal Error	A minor problem has occurred. Operation will continue

Confirming Errors

There are three sources of information on errors that have occurred.

- CPU Unit indicators
- Seven-segment display
- Auxiliary Area

CPU Unit Indicators

<input type="checkbox"/> POWER	<input type="checkbox"/> RUN
<input type="checkbox"/> ERR/ALM	<input type="checkbox"/> INH
<input type="checkbox"/> BKUP	<input type="checkbox"/> PRPHL


These indicators show the operating status of the CPU Unit.

POWER (green)	Lit	Power is ON.
	Not lit	Power is OFF.
RUN (green)	Lit	The CPU Unit is executing a program in either RUN or MONITOR mode.
	Not lit	Operation is stopped in PROGRAM mode or due to a fatal error.
ERR/ALM (red)	Lit	A fatal error or CPU error (WDT error) has occurred. operation will stop and all outputs will be turned OFF.
	Flashing	A non-fatal error has occurred. Operation will continue.
	Not lit	Operation is normal.
INH (yellow)	Lit	The Output OFF Bit (A500.15) was turned ON. All outputs will be turned OFF.
	Not lit	Operation is normal.
BKUP (yellow) (See note.)	Lit	The built-in flash memory is being written to or the Memory Cassette is being accessed. The BKUP indicator also lights while the user program is being restored when the power supply is turned ON.
	Not lit	Other than the above.
PRPHL (yellow)	Flashing	Communications (either sending or receiving) are in progress through the peripheral port.
	Not lit	Other than the above.

Note Do not turn OFF the CPU Unit power supply when this indicator is lit.

CPU Unit Indicators and Error Meanings in RUN or MONITOR Mode


Indicator	CPU error	CPU standby	Fatal error	Non-fatal error	Peripheral port communications error	Output OFF Bit turned ON
POWER	Lit	Lit	Lit	Lit	Lit	Lit
RUN	Not lit	Not lit	Not lit	Lit	Lit	Lit
ERR/ALM	Lit	Not lit	Lit	Flashing	---	---
INH	Not lit	---	---	---	---	Lit
BKUP	---	---	---	---	---	---
PRPHL	---	---	---	---	Not lit	---

Seven-segment Display

Two-digit, 7-segment display

Error codes are shown on the 7-segment display if an error occurs. The 7-segment display has only two digits, so 4-digit error codes are displayed two digits at a time. If there are 4-digit error details in addition to the error code, they will be displayed after the error code two digits at a time.

- Display Example
Error code: 80F1 (memory error)
Error details: 0001 (user program)



The display switches at intervals of approximately 1 s.

- If two or more errors occur at the same time, the most serious error will be displayed first. When that error is cleared, the next most serious error will be displayed.
- The 7-segment display shows digits created by special instructions in the user program or by analog adjustment operations. Error code displays, however, are given priority whenever an error occurs.

Fatal Errors

8.0 → F.1 → → → Memory error

→ → Location of memory error

Example Displays for Locations of Memory Errors

→ 0.0 → 0.1 → User program

→ 0.0 → 1.0 → PLC setup

→ 0.0 → 8.0 → Routing tables

→ 0.1 → 0.0 → CPU Bus Unit setup

→ 0.1 → 9.0 → PLC system + routing tables + CPU Bus Unit setup

→ 0.2 → 0.0 → Memory Cassette transfer error at startup

8.0 → C.A → 0.A → 0.A → I/O bus error for CP-series Units

8.0 → C.F → 0.F → 0.F → I/O bus error for CJ-series Units,
error location unknown

8.0 → C.E → 0.E → 0.E → I/O bus error for CJ-series Units,
no End Cover

8.0 → C.0 → → → I/O bus error for CJ-series Units

→ → Location of I/O bus error

Example Displays for Locations of I/O Bus Errors

→ 0.0 → 0.0 → First CJ-series Unit

→ 0.0 → 0.1 → Second CJ-series Unit

8.0 → E.9 → → → Duplicate number error

→ → Duplicate unit number

Example Displays of Duplicate Unit Numbers

→ 0.0 → 0.1 → CPU Bus Unit, Unit No. 1

→ 8.0 → 0.1 → Special I/O Unit, Unit No. 1

8.0 → E.1 → → → Too many I/O points

→ → Error details

Example Displays of Details Errors for Too Many I/O Points

→ 4.0 → 0.0 → Too many CP-series Expansion I/O Unit words

→ 6.0 → 0.0 → Too many CP-series Expansion I/O Units

→ E.0 → 0.0 → Too many CJ-series Units

<div>80→E0→ I/O setting error</div>
<div><div>80→F0→<div></div>→<div></div>→ Program error</div><div>Program error details</div><div>Example Displays of Program Errors</div><div><div>→01→00→ Instruction processing error</div><div>→02→00→ Indirect DM addressing BCD error</div><div>→04→00→ Illegal area access area</div><div>→08→00→ No END error</div><div>→10→00→ Task error</div><div>→20→00→ Differentiation overflow error</div><div>→40→00→ Illegal instruction error</div><div>→80→00→ UM overflow error</div></div></div>
<div>80→9F→ Cycle time too long</div>
<div><div>11→01→ FALS instruction executed for FALS number 001</div><div>:</div><div>22→00→ FALS instruction executed for FALS number 256</div><div>:</div><div>22→FF→ FALS instruction executed for FALS number 511</div></div>

Non-fatal Errors

<div>4.1. → 0.1. → FAL instruction executed for FAL number 001</div> <div>:</div> <div>4.2. → 0.0. → FAL instruction executed for FAL number 256</div> <div>:</div> <div>4.2. → F.F. → FAL instruction executed for FAL number 511</div>
0.0. → F.1. → Flash memory error
<div>0.0. → 8.b. → <div>→ <div>→</div> →</div> → Interrupt task error</div> <div>Unit number of interrupt task error occurrence</div> <div>Example Displays of Unit Numbers for which an Interrupt Task Error Has Occurred</div> <div>→ 8.0. → 0.0. → Special I/O Unit with unit number 1</div> <div>→ 8.0. → 0.F. → Special I/O Unit with unit number 15</div> <div>→ 8.0. → 5.F. → Special I/O Unit with unit number 95</div>
<div>0.0. → 9.b. → <div>→ <div>→</div> →</div> → PLC Setup error</div> <div>Location of PLC Setup error</div> <div>Example Displays for Locations of PLC Setup Errors</div> <div>→ 0.0. → 0.0. → PLC Setup internal address: 0000 hex</div> <div>→ 0.1. → F.F. → PLC Setup internal address: 01FF hex</div>
0.0. → 8.8. → Built-in analog I/O error
<div>0.2. → 0.0. → CPU bus error for CPU Bus Unit with unit number 0</div> <div>:</div> <div>0.2. → 0.F. → CPU bus error for CPU Bus Unit with unit number F</div>
<div>0.3. → 0.0. → Error for Special I/O Unit with unit number 0</div> <div>:</div> <div>0.3. → 5.F. → Error for Special I/O Unit with unit number 95</div> <div>0.3. → F.F. → Error for Special I/O Unit with unknown unit number</div>
<div>0.0. → d.1. → Option Board error for option slot 1</div> <div>0.0. → d.2. → Option Board error for option slot 2</div>
0.0. → F.7. → Battery error

Auxiliary Area

■ **Error Code Storage Word**

The error code is stored in A400 when an error occurs. If two or more errors occur at the same time, the most serious error will be stored.

■ **Error Flags**

Flags that indicate the type of error are allocated in the Auxiliary Area.

■ **Error Information**

This area indicates specific information on the meaning of error flags and provides information on error location and error details.

■ Fatal Errors

Error	Error code (A400)	Error flag	Error information	
			Meaning	Address
Memory error	80F1	A401.15	Memory error location	A403
I/O bus error	80C0 to 80C7, 80CA, 80CE, 80CF	A401.14	I/O bus error details	A404
Duplicate number error	80E9	A401.13	Duplicate CPU Bus Unit unit number	A411 to A416
			Duplicate Special I/O Unit unit number	A411 to A416
Too many I/O error	80E1	A401.11	Details for too many I/O error	A407
I/O setting error	80E0	A401.10	---	---
Program error	80F0	A401.09	Program error details	A294 to A299
Cycle time too long error	809F	A401.08	---	---
FALS instruction executed	C101 to C2FF	A401.06	---	---

■ Non-fatal Errors


Error	Error code (A400)	Error flag	Error information	
			Meaning	Address
FAL instruction executed	4101 to 42FF	A402.15	Executed FAL number	A360 to A391
Flash memory error	00F1	A315.15	---	---
Interrupt task error	008B	A402.13	Interrupt task error unit number	A426
PLC Setup error	009B	A402.10		A406
Built-in analog error	008A	A315.14	---	---
CPU Bus Unit error	0200 to 020F	A402.07	Error unit number	A417
Special I/O Unit error	0300 to 035F, 00FF	A402.06	No display	A418 to A423
Option Board error	00D1, 00D2	A315.13	Error Option Board Flags	A424
Battery error	00F7	A402.04	---	---

11-2 Troubleshooting

Use the following procedure to check error details and remove the cause of the error if the CPU Unit does not operate when the power supply is ON, operation suddenly stops and the error indicator (ERR/ALM indicator) lights, or if the error indicator (ERR/ALM indicator) flashes during operating.

11-2-1 Error Processing Flowchart

Confirm the error category by referring to the status of the CPU Unit indicators and the 7-segment display, investigate the cause for the error in the error tables, and take corrective actions.



11-2-2 No Operation When Power Is Supplied

First confirm that the POWER indicator (green) is lit.

POWER Indicator Not Lit

The power supply may not match the Unit rating, wiring may not be correct, or the Unit may be faulty.

1,2,3...

1. Confirm the Unit rating (i.e., is it 24 VDC or 100 to 240 VAC?) and see if the supply power matches the rating.
2. Check the wiring to see if it is correct and that nothing is disconnected.
3. Check the voltage at the power supply terminals. If the voltage is normal and the POWER indicator is lit, the Unit may be faulty. In that case, replace the Unit.

POWER Indicator Turns OFF and ON

There may be fluctuations in the power supply voltage, disconnected wiring, or poor contacts. Check the power supply system and wiring.

POWER Indicator Lit but No Operation

Check the RUN indicator if the POWER indicator is lit but the CPU Unit does not operate. The CPU Unit may be on standby if the RUN indicator is not lit.


■ CPU Standby

Detection of Special I/O Units and CPU Bus Units has not been completed.

- If a CPU Bus Unit has not started normally, check the Unit Setup.
- If a Special I/O Unit is not detected, replace the Special I/O Unit.

11-2-3 Fatal Errors

■ CPU Unit Indicators



POWER	Lit
RUN	Not lit
ERR/ALM	Lit
INH	---
BKUP	---
PRPHL	---


There may be a CPU error or a fatal error if operation stops (i.e., the RUN indicator turns OFF) and the ERR/ALM indicator lights. Error code for fatal errors will be updated on the 7-segment display. If a CPU error occurs, the 7-segment display will remain unlit or the display will freeze.

Data on fatal errors is displayed on the Error Tab Page of the CX-Programmer's PLC Error Window.

Take corrective actions after checking error details based on the 7-segment display or the CX-Programmer display message together with the Auxiliary Area Error Flags and error information.

- Note**
1. Errors are listed in order with the most serious errors first.
 2. If two or more errors occur at the same time, the most serious error code will be stored in A400.
 3. I/O memory will be cleared if a fatal error occurs (except those created with FALS instructions).
 4. I/O memory will be held when the I/O Memory Hold Bit is ON, but outputs will be turned OFF.

Memory Errors




Seven-segment display	Probable cause and possible remedy
8.0. → F. I. →	→ 0.0. → 0. I. →
→ 0.0. → 0. I. →	A checksum error has occurred in the user program. Transfer the user program again.
→ 0.0. → 8.0. →	A checksum error has occurred in the PLC Setup. Transfer the PLC Setup again.
→ 0. I. → 0.0. →	A checksum error has occurred in the routing tables. Transfer the routing tables again.
→ 0. I. → 9.0. →	A checksum error has occurred in the CPU Bus Unit Setup. All settings for the CPU Bus Unit have returned to the default setting. Perform the settings again.
→ 0.2. → 0.0. →	A PLC Setup error, routing table setting error, and CPU Bus Unit Setup error have occurred at the same time. Take corrective actions for these three errors.
	Automatic transfer from the Memory Cassette at startup failed because the required data is not on the Memory Cassette or the Memory Cassette is not installed. Store the required data on the Memory Cassette and be sure that the Memory Cassette is installed.

■ Reference Information

Error flag	Memory Error Flag, A401.15
Error code (A400)	80F1
Error information	Memory Error Location, A403

I/O Bus Errors

An I/O bus error occurs in data transfer between the CPU Units and Units connected to the I/O bus. Cycle the power supply. If operation is not restored when the power supply has been cycled, turn OFF the power supply and check that connections are proper and that there is no damage.


Seven-segment display	Probable cause and possible remedy		
B.D. → C.R. → D.R. → D.R. →	I/O bus error for CP-series Units An error has occurred in data transfer with a CP-series Expansion Unit or Expansion I/O Unit. Check the condition of the connection cables.		
B.D. → C.F. → D.F. → D.F. →	I/O bus error for CJ-series Units, error location unknown An error has occurred in data transfer for CJ-series Units, but the error location is not known. Check the connections between the CPU Unit, CJ Unit Adapter, and CJ-series Units.		
B.D. → C.E. → D.E. → D.E. →	I/O bus error for CJ-series Units, no End Cover No End Cover has been installed for CJ-series Units. Properly install the End Cover.		
B.D. C.D. →  →			
B.D. → C.D. →	→ D.D. → D.D. →	First CJ-series Unit	An error has occurred in data transfer for CJ-series Units (first Unit or second Unit). Check that there is no damage to the relevant Unit. Replace the Unit if required.
	→ D.D. → D. I. →	Second CJ-series Unit	

■ Reference Information

Error flag	I/O Bus Error Flag, A401.14
Error code (A400)	80C0, 80CA, 80CE, 80CF
Error information	I/O bus error details, A404

Duplicate Number Error

A duplicate unit number error occurs for CJ-series Units. Turn OFF the power supply and make sure the same unit number is not set for more than one Unit.

B.D. → E.9. →  →

Seven-segment display	Probable cause and possible remedy	
B.D. → E.9. →	→ D.D. → D. I. →	The same number has been set for more than one CPU Bus Unit. Check the unit number settings and eliminate the duplication.
	→ B.D. → D. I. →	The same number has been set for more than one Special I/O Unit. Check the unit number settings and eliminate the duplication.

■ Reference Information

Error flag	Duplication Error Flag, A401.13
Error code (A400)	80E9
Error information	CPU Bus Unit Duplication Number Flags, A410 Special I/O Unit Duplicate Number Flags, A411 to A416

Too Many I/O Points

The number of CP-series Expansion Units, CP-series Expansion I/O Units, or CJ-series Units connected exceeds the restriction for the number of Units or words for the system configuration. Turn OFF the power supply and reconfigure the system within the restrictions.

8.8. → E. I. → 

Too many I/O points, details

Seven-segment display		Probable cause and possible remedy	
8.8. → E. I. →	→ 4.8. → 0.0. →	The total number of words for CP-series Expansion Units and Expansion I/O Units exceeds the restriction. Configure the system so that there are no more than 15 input words and 15 output words allocated to Expansion Units and Expansion I/O Units.	Refer to 1-2-4 <i>Restrictions on System Configuration</i> .
	→ 5.8. → 0.0. →	The number of CP-series Expansion Units and Expansion I/O Units exceeds the restriction. Connect a maximum of seven Units.	
	→ E.8. → 0.0. →	The number of CJ-series Units exceeds the restriction. Mount a maximum of two Units.	

■ Reference Information

Error flag	Too Many I/O Points Flag, A401.11
Error code (A400)	80E1
Error information	Too Many I/O Points Details, A407

I/O Setting Error

An I/O setting error indicates that a Unit is connected that cannot be used in the system configuration. Turn OFF the power supply and remove the Unit.


Seven-segment display	Probable cause and possible remedy
8.8. → E.8. →	A CJ-series Basic I/O Unit or an I/O Control Unit has been mounted. These Unit cannot be used. Remove any of these Units.

■ Reference Information

Error flag	I/O Setting Error Flag, A401.10
Error code (A400)	80E0
Error information	---

Program Error

A program error indicates a problem with the user program. Refer to the error information, check the program, and correct the mistakes. Clear the error once the problem has been corrected.



Seven-segment display	Probable cause and possible remedy
B.C. → F.C. → → 0.1. → 0.0. →	Instruction Processing Error If the PLC Setup has been set to stop operation for an instruction error, the Error Flag will be turned ON when an instruction cannot be executed due to a problem in the operand data. Refer to A298 and A299 (instruction program address when the program fails), check the specifications for the relevant instruction, and set the correct operand data. Alternatively, set the PLC Setup to not stop operation for an instruction error.
B.C. → F.C. → → 0.2. → 0.0. →	Indirect DM Addressing BCD Error If the PLC Setup has been set to stop operation for an indirect DM BCD error, the Access Error Flag will turn ON when the content of an indirectly addressed DM operand is not BCD although BCD mode has been selected. Refer to A298 and A299 (instruction program address when the program fails), and correctly set the content for the indirectly addressed DM operand (BCD mode) to BCD or change the specified destination. Alternatively, change the indirect addressing to binary mode or set the PLC Setup to not stop operation for an indirect DM addressing BCD error.
→ 0.4. → 0.0. →	Illegal Area Access Error If the PLC Setup has been set to stop operation for an illegal access error, the Access Error Flag will turn ON when an illegal access error has occurred. The following operations are considered illegal access: <ul style="list-style-type: none"> • Reading/writing the parameter area • Writing to an area without memory installed • Writing to a write-protected area • Indirect DM addressing BCD error Refer to A298 and A299 (instruction program address when the program fails) and take corrective actions so that illegal area access errors will not occur.
→ 0.8. → 0.0. →	No END Error This error occurs when there is not an END(001) instruction in the program within a task. Insert an END(001) instruction at the end of the program allocated to the task stored in A294 (task number when the program fails).
→ 1.0. → 0.0. →	Task Error This error is generated by any of the following conditions. <ul style="list-style-type: none"> • There is not an executable cyclic task (active). Check the properties of the executable cyclic task and set at least one task to start when operation starts. • There is no specified interrupt task when an interrupt is generated (input interrupt, high-speed counter interrupt, scheduled interrupt, or external interrupt). Create a task for the number stored in A294 (task number when the program fails).
→ 0.2. → 0.0. →	Differentiation Overflow Error Differentiation instructions were repeatedly inserted or deleted using the online editor and the system restriction was exceeded. Change the operating mode to PROGRAM mode and then return to MONITOR mode.
→ 0.4. → 0.0. →	Illegal Instruction Error Execution of an unexecutable instruction was attempted. Check the program, correct the problem, and transfer the program to the CPU Unit again.
→ 0.8. → 0.0. →	UM Overflow Error An attempt was made to execute a program that exceeds the user program capacity. Transfer the program again using the CX-Programmer.

■ **Reference Information**

Error flag	Program Error Flag, A401.09
Error code (A400)	80F0
Error information	Program error details, A294 to A299

Cycle Time Too Long

Seven-segment display	Probable cause and possible remedy
8.0.→9.F.→	<p>This error occurs when the cycle time PV exceeds the maximum cycle time set in the PLC Setup. Review the program to decrease the cycle time or change the maximum cycle time set in the PLC Setup.</p> <p>Refer to the Maximum Interrupt Task Processing Time (A440) and study the maximum cycle time.</p> <p>The cycle time can be decreased using the following methods.</p> <ul style="list-style-type: none"> • Separate instructions not being executed into different tasks. • Consider using jump instructions for areas in the task that are not executed. • Prohibit cycle refreshing with Special I/O Units that do not require exchange of cycle data.

■ **Reference Information**

Error flag	Cycle Time Too Long Error, A401.08
Error code (A400)	809F
Error information	---

Errors Created with FALS Instructions


Seven-segment display	Probable cause and possible remedy
C.1.→0.1.→	<p>FALS instruction executed (FALS number 001)</p> <p>A FALS instruction was executed in the program to create a fatal error.</p>
C.2.→0.0.→	<p>FALS instruction executed (FALS number 256)</p> <p>C100 hex will be added to the FALS number (001 to 1FF hex) and the result will be stored in A400 as error codes C101 to C2FF hex.</p>
C.2.→F.F.→	<p>FALS instruction executed (FALS number 511)</p> <p>Check the conditions for executing FALS instructions and remove any causes for the user-defined error.</p>

■ **Reference Information**

Error flag	FALS Error Flag, A401.06
Error code (A400)	C101 to C2FF
Error information	---

11-2-4 CPU Errors

■ CPU Unit Indicators



POWER	Lit
RUN	Not lit
ERR/ALM	Lit
INH	---
BKUP	---
PRPHL	---

A CPU error or fatal error may have occurred if the ERR/ALM indicator lights during operation (RUN mode or MONITOR mode), the RUN indicator turns OFF, and operation stops. A CPU error may have occurred if nothing is shown on the 7-segment display or the same message remains on the display.

CPU Errors

Seven-segment display	Probable cause and possible remedy
The display is not lit or it is frozen.	A WDT (watchdog) error occurred in the CPU Unit. (This does not occur in normal use.) Cycle the power supply. The Unit may be faulty. Consult your OMRON representative.

■ Reference Information


Error flag	None
Error code (A400)	None
Error information	None

Note Just as when a CPU error occurs, the RUN indicator will turn OFF and the ERR/ALM indicator will light when a fatal error occurs. Connecting the CX-Programmer, however, is possible for fatal errors but not for CPU errors. If the CX-Programmer cannot be connected (online), a CPU error has probably occurred.

11-2-5 Non-fatal Errors

A non-fatal error has occurred if both the RUN indicator and the ERR/ALM indicator are lit during operation (i.e., in RUN or MONITOR mode).

■ CPU Unit Indicators



POWER	Lit
RUN	Lit
ERR/ALM	Flashing
INH	---
BKUP	---
PRPHL	---

Information on the non-fatal error can be obtained from the error code on the 7-segment display and from the Error Tab Page of the CX-Programmer's PLC Error Window. Take corrective actions after checking error details using the display messages and the Auxiliary Area Error Flags and error information.

- Errors are listed in the following table in order, with the most serious ones first.
- If two or more errors occur at the same time, the most serious error code will be stored in A400.

Errors Created with for FAL Instructions

A FAL instruction was executed in the program to create a non-fatal error.

Seven-segment display		Probable cause and possible remedy
4.1.→0.1.→	FAL instruction executed (FAL number 001)	The executed FAL number 001 to 511 will be stored in A360 to A391. The number 4 will be added to the front of 101 to 2FF (which correspond to executed FAL numbers 001 to 511) and the result will be stored in A400 as error code 4101 to 42FF.
4.2.→0.0.→	FAL instruction executed (FAL number 256)	
4.2.→F.F.→	FAL instruction executed (FAL number 511)	Check the conditions for executing FAL instructions and remove any causes of the user-defined error.

■ Reference Information

Error flag	FAL Error Flag, A402.15
Error code (A400)	4101 to 42FF
Error information	None


Flash Memory Errors

Seven-segment display	Probable cause and possible remedy
0.0.→F.1.→	A315.15 will turn ON when writing to the internal flash memory fails. Replace the CPU Unit when the internal flash memory has been written to more than 100,000 times.

■ Reference Information

Error flag	Flash Memory Error Flag, A315.15 Other non-fatal flags, A402.00
Error code (A400)	None
Error information	None

Interrupt Task Errors




Seven-segment display		Probable cause and possible remedy	
0.0.→8.b.→	→8.0.→0.0.→	Special I/O Unit unit number 0	An interrupt task error occurs when the <i>Detect Interrupt task errors setting</i> in the PLC Setup is set to <i>Detect</i> and an attempt is made to refresh a Special I/O Unit from an interrupt task with IORF(097) while the Unit's I/O is being refreshed by cyclic refreshing (duplicate refreshing).
	→8.0.→0.F.→	Special I/O Unit unit number 15	
	→8.0.→5.F..→	Special I/O Unit unit number 95	Review the program to see whether detecting interrupt task errors can be disabled or avoided.

■ Reference Information

Error flag	Interrupt Task Error Flag, A402.13
Error code (A400)	008B
Error information	Interrupt Task Error, A426

PLC Setup Errors



Seven-segment display		Probable cause and possible remedy	
0.0. → 9.b. →	→ 0.0. → 0.0. →	PLC Setup Internal address: 0000 hex	A set value error occurred in the PLC Setup. The address of the error is stored in A406 in 16-bit binary. Correct the PLC Setup with correct values.
	→ 0. 1. → F.F. →	PLC Setup Internal address: 01FF hex	

■ Reference Information

Error flag	PLC Setup Error Flag, A402.10
Error code (A400)	009B
Error information	PLC Setup error location, A406

Built-in Analog I/O Errors

Seven-segment display	Probable cause and possible remedy
0.0. → 8.8. →	A315.14 will turn ON when a built-in analog I/O error occurs and stops the operation of built-in analog I/O. Replace the CPU Unit if the error is not cleared when the power supply is cycled.

■ Reference Information

Error flags	Built-in Analog I/O Error Flag, A315.14 Other Non-fatal Error Flag, A402.00
Error code (A400)	008A
Error information	---

CPU Bus Unit Errors

Seven-segment display		Probable cause and possible remedy
0.2. → 0.0. →	CPU Bus Unit error, unit number 0	A data exchange error has occurred between the CPU Unit and one of the CPU Bus Units. Note Information on where the data exchange error occurred (i.e., between the CPU Unit and what unit number) is stored in A417. Check the Unit given in A417. Refer to the manual for the relevant Unit and remove the cause of the error. Then turn ON the Restart Bit or cycle the power supply. Replace the Unit if operation is not restored when the Unit is restarted.
0.2. → 0.F. →	CPU Bus Unit error, unit number F	

■ Reference Information

Error flag	CPU Bus Unit Error Flag, A402.07
Error code (A400)	0200 to 020F
Error information	CPU Bus Unit Error Unit Number Error Flags, A417

Special I/O Unit Errors

Seven-segment display		Probable cause and possible remedy
0.3.→0.0.→	Special I/O Unit error, unit number 0	A data exchange error has occurred between the CPU Unit and one of the Special I/O Units. Note Information on where the data exchange error occurred (i.e., between the CPU Unit and what Unit number) is stored in A418 to A423. Check the Unit given in A418 to A423.
0.3.→5.F.→	Special I/O Unit error, unit number 95	
0.3.→F.F.→	Special I/O Unit error, unit number unknown	Refer to the manual for the relevant Unit and remove the cause of the error. Then turn ON the Restart Bit or cycle the power supply. Replace the Unit if operation is not restored when the Unit is restarted.

■ Reference Information

Error flag	Special I/O Unit Error Flag, A402.06
Error code (A400)	0300 to 035F, 03FF
Error information	Special I/O Unit Error Unit Number Flags, A418 to A423

Option Board Errors

Seven-segment display		Probable cause and possible remedy
0.0.→d.1.→	Option Board error (option slot 1)	A315.13 will turn ON if the Option Board is removed while the power is being supplied. Turn OFF the power supply and then install the Option Board again.
0.0.→d.2.→	Option Board error (option slot 2)	

■ Reference Information

Error flags	Option Board Error Flag, A315.13 Other Non-fatal Error Flag, A402.00
Error code (A400)	---
Error information	---

Battery Error

Seven-segment display	Probable cause and possible remedy
0.0.→F.7.→	If the PLC Setup is set to detect battery errors, this error will occur when there is an error in the battery in the CPU Unit (i.e., the voltage is low or a battery is not mounted). Check the battery connections. When using battery-free operation, disable connecting battery errors in the PLC Setup.







■ Reference Information

Error flag	Battery Error Flag, A402.04
Error code (A400)	00F7
Error information	---

11-2-6 Other Errors

Communications Errors

■ CPU Unit Indicators

 POWER	 RUN
 ERR/ALM	 INH
 BKUP	 PRPHL

POWER	Lit
RUN	Lit
ERR/ALM	---
INH	---
BKUP	Not lit
PRPHL	---

Seven-segment display	Probable cause and possible remedy
None	An error has occurred in the communications between the peripheral port and connected device. Confirm that the peripheral port settings in the PLC Setup are correct.
	An error has occurred in the communications between the RS-232C port and connected device. Confirm that the RS-232C port settings in the PLC Setup are correct. Check the cable wiring. If a host computer is connected, check the serial port settings and program in the host computer.
	An error will be occurred if the cycle time is too long. Modify the CX-Programmer's response monitoring time longer according to the following method. Start the CX-Programmer. Select Change Model from the PLC Menu . The Change PLC Dialog Box will be displayed. Click the Settings Button on the right side of Network Type . The Network Settings [USB] Dialog Box will be displayed. Click the Network Tab and increase the value in Response Timeout(s) .


11-3 Error Log

Each time an error occurs, the error code is shown on the 7-segment display and the CPU Unit stores error information in the Error Log Area of the Auxiliary Area (A100 to A199). The error information includes the error code (stored in A400), error contents, and time that the error occurred. Up to 20 records can be stored in the Error Log.

In addition to system-generated errors, the CPU Unit records user-defined errors, making it easier to track the operating status of the system.

When more than 20 errors occur, the oldest error data (stored in A100 to A104) is deleted, the 19 errors stored in A105 to A199 shift one record, and the newest record is stored in A195 to A199.

The number of records stored in the error log is stored in the Error Log Pointer (A300). The Error Log Pointer is not incremented after 20 records have been stored.



11-4 Troubleshooting Unit Errors

CPU Unit

Symptom	Cause	Remedy
POWER indicator is not lit.	PCB short-circuited or damaged.	Replace Unit.
		Correct program.
		Replace Unit.
RUN indicator is not lit.	(1) Error in program (fatal error) (2) Power line is faulty.	Replace Unit.
RUN indicator on the CPU Unit is lit.	Internal circuitry in the Unit is faulty.	Replace Unit.
Special I/O Unit or CPU Bus Unit does not operate or malfunctions.	(1) The I/O Connecting Cable is faulty. (2) The I/O bus is faulty.	Replace Unit.
Bits do not operate past a certain point.		
Error occurs in units of 8 or 16 points.		
I/O bit turns ON.		
All bits in one Unit do not turn ON.		

Special I/O Units

Refer to the operation manual for the Special I/O Unit to troubleshoot any other errors.

Symptom	Cause	Remedy
The ERH and RUN indicators on the Special I/O Unit are lit.	I/O refreshing is not being performed for the Unit from the CPU Unit (CPU Unit monitoring error).	Enable cyclic refreshing for the Unit in the PLC Setup, or make sure that the Unit is refreshed from the program using IORF at least once every 11 s.

Inputs

Symptom	Cause	Remedy
Not all inputs turn ON or indicators are not lit.	(1) External power is not supplied for the input.	Supply power
	(2) Supply voltage is low.	Adjust supply voltage to within rated range.
	(3) Terminal block mounting screws are loose.	Tighten screws.
	(4) Faulty contact of terminal block connector.	Replace terminal block connector.
Not all inputs turn ON even though the indicator is lit.	Input circuit is faulty. (There is a short at the load or something else that caused an over-current to flow.)	Replace Unit.
Not all inputs turn OFF.	Input circuit is faulty.	Replace Unit.
Specific bit does not turn ON.	(1) Input device is faulty.	Replace input devices.
	(2) Input wiring disconnected.	Check input wiring
	(3) Terminal block screws are loose.	Tighten screws
	(4) Faulty terminal block connector contact.	Replace terminal block connector.
	(5) Too short ON time of external input.	Adjust input device
	(6) Faulty input circuit	Replace Unit.
	(7) Input bit number is used for output instruction.	Correct program.
Specific bit does not turn OFF.	(1) Input circuit is faulty.	Replace Unit.
	(2) Input bit number is used for output instruction.	Correct program.

Symptom	Cause	Remedy
Input irregularly turns ON/OFF.	(1) External input voltage is low or unstable.	Adjust external input voltage to within rated range.
	(2) Malfunction due to noise.	Take protective measures against noise, such as: <ul style="list-style-type: none"> • Install surge suppressor. • Install insulation transformer. Install shielded cables between the Input Unit and the loads.
	(3) Terminal block screws are loose.	Tighten screws
	(4) Faulty terminal block connector contact.	Replace terminal block connector.
Error occurs in units of 8 points or 16 points, i.e., for the same common.	(1) Common terminal screws are loose.	Tighten screws
	(2) Faulty terminal block connector contact.	Replace terminal block connector.
	(3) Faulty data bus	Replace Unit.
	(4) Faulty CPU	Replace CPU Unit.
Input indicator is not lit in normal operation.	Faulty indicator or indicator circuit.	Replace Unit.

Outputs

Symptom	Cause	Remedy
Not all outputs turn ON	(1) Load is not supplied with power.	Supply power
	(2) Load voltage is low.	Adjust voltage to within rated range.
	(3) Terminal block screws are loose.	Tighten screws
	(4) Faulty terminal block connector contact.	Replace terminal block connector.
	(5) An overcurrent (possibly caused by a short at the load) resulted in a blown fuse for the output or the Unit is faulty.	Replace fuse or Unit.
	(6) Faulty I/O bus connector contact.	Replace Unit.
	(7) Output circuit is faulty.	Replace Unit.
	(8) If the INH indicator is lit, the Output OFF Bit (A500.15) is ON.	Turn A500.15 OFF.
Not all outputs turn OFF	Output circuit is faulty.	Replace Unit.
Output of a specific bit number does not turn ON or indicator is not lit	(1) Output ON time too short because of a mistake in programming.	Correct program to increase the time that the output is ON.
	(2) Bit status controlled by multiple instructions.	Correct program so that each output bit is controlled by only one instruction.
	(3) Faulty output circuit.	Replace Unit.
Output of a specific bit number does not turn ON (indicator lit).	(1) Faulty output device.	Replace output device.
	(2) Break in output wiring.	Check output wiring.
	(3) Loose terminal block screws.	Tighten screws.
	(4) Faulty terminal block connector faulty.	Replace terminal block connector.
	(5) Faulty output bit (relay output only).	Replace Unit.
	(6) Faulty output circuit (relay output only).	Replace Unit.
Output of a specific bit number does not turn OFF (indicator is not lit).	(1) Faulty output bit.	Replace Unit.
	(2) Bit does not turn OFF due to leakage current or residual voltage.	Replace external load or add dummy resistor.
Output of a specific bit number does not turn OFF (indicator lit).	(1) Bit status controlled by multiple instructions.	Correct program.
	(2) Faulty output circuit.	Replace Unit.
Output irregularly turns ON/OFF.	(1) Low or unstable load voltage.	Adjust load voltage to within rated range
	(2) Bit status controlled by multiple instructions.	Correct program so that each output bit is controlled by only one instruction.
	(3) Malfunction due to noise.	Protective measures against noise: • Install surge suppressor. • Install insulation transformer. • Use shielded cables between the output terminal and the load.
	(4) Terminal block screws are loose.	Tighten screws.
	(5) Faulty terminal block connector contact.	Replace terminal block connector.
Error occurs in units of 8 points or 16 points, i.e., for the same common.	(1) Loose common terminal screw.	Tighten screws.
	(2) Faulty terminal block connector contact.	Replace terminal block connector.
	(3) An overcurrent (possibly caused by a short at the load) resulted in a blown fuse for the output or the Unit is faulty.	Replace fuse or Unit.
	(4) Faulty data bus.	Replace Unit.
	(5) Faulty CPU.	Replace CPU Unit.
Output indicator is not lit (operation is normal).	Faulty indicator.	Replace Unit.

SECTION 12

Inspection and Maintenance

This section provides inspection and maintenance information.

12-1	Inspections	624
12-1-1	Inspection Points.....	624
12-1-2	Unit Replacement Precautions	625
12-2	Replacing User-serviceable Parts	626

12-1 Inspections

Daily or periodic inspections are required in order to maintain the PLC's functions in peak operating condition.

12-1-1 Inspection Points

Although the major components in CP-series PLCs have an extremely long life time, they can deteriorate under improper environmental conditions. Periodic inspections are thus required to ensure that the required conditions are being kept.

Inspection is recommended at least once every six months to a year, but more frequent inspections will be necessary in adverse environments.

Take immediate steps to correct the situation if any of the conditions in the following table are not met.

No.	Item	Inspection	Criteria	Action
1	Source Power Supply	Check for voltage fluctuations at the power supply terminals.	The voltage must be within the allowable voltage fluctuation range. (See note.)	Use a voltage tester to check the power supply at the terminals. Take necessary steps to bring voltage fluctuations within limits.
2	I/O Power Supply	Check for voltage fluctuations at the I/O terminals.	Voltages must be within specifications for each Unit.	Use a voltage tester to check the power supply at the terminals. Take necessary steps to bring voltage fluctuations within limits.
3	Ambient environment	Check the ambient temperature (inside the control panel if the PLC is in a control panel).	0 to 55°C	Use a thermometer to check the temperature and ensure that the ambient temperature remains within the allowed range of 0 to 55°C.
		Check the ambient humidity (inside the control panel if the PLC is in a control panel).	Relative humidity must be 10% to 90% with no condensation.	Use a hygrometer to check the humidity and ensure that the ambient humidity remains within the allowed range.
		Check that the PLC is not in direct sunlight.	Not in direct sunlight	Protect the PLC if necessary.
		Check for accumulation of dirt, dust, salt, metal filings, etc.	No accumulation	Clean and protect the PLC if necessary.
		Check for water, oil, or chemical sprays hitting the PLC.	No spray on the PLC	Clean and protect the PLC if necessary.
		Check for corrosive or flammable gases in the area of the PLC.	No corrosive or flammable gases	Check by smell or use a sensor.
		Check the level of vibration or shock.	Vibration and shock must be within specifications.	Install cushioning or shock absorbing equipment if necessary.
		Check for noise sources near the PLC.	No significant noise sources	Either separate the PLC and noise source or protect the PLC.

No.	Item	Inspection	Criteria	Action
4	Installation and wiring	Check that each Unit is connected securely and locked in place.	No looseness	Press the connectors together completely and lock them with the sliders.
		Check that the Option Boards and cable connectors are fully inserted and locked.	No looseness	Correct any improperly installed connectors.
		Check for loose screws in external wiring.	No looseness	Tighten loose screws with a Phillips screwdriver.
		Check crimp connectors in external wiring.	Adequate spacing between connectors	Check visually and adjust if necessary.
		Check for damaged external wiring cables.	No damage	Check visually and replace cables if necessary.
5	User-serviceable parts	Check whether the battery has reached its service life. CJ1W-BAT01 Battery	Service life expectancy is 5 years at 25°C, less at higher temperatures. (From 0.75 to 5 years depending on model, power supply rate, and ambient temperature.)	Replace the battery when its service life has passed even if a battery error has not occurred.

Note The following table shows the allowable voltage fluctuation ranges for source power supplies.

CPU Unit	Supply voltage	Allowable voltage range
CP1H-X40DR-A CP1H-XA40DR-A	100 to 240 V AC	85 to 264 V AC (+10%/–15%)
CP1H-X40DT-D CP1H-X40DT1-D CP1H-XA40DT-D CP1H-XA40DT1-D CP1H-Y20DT-D	24 V DC	20.4 to 26.4 V DC (+10%/–15%)

Tools Required for Inspections

Required Tools

- Phillips screwdrivers
- Voltage tester or digital voltmeter
- Industrial alcohol and clean cotton cloth

Tools Required Occasionally

- Synchroscope
- Oscilloscope with pen plotter
- Thermometer and hygrometer

12-1-2 Unit Replacement Precautions

Check the following when replacing any faulty Unit.

- Do not replace a Unit until the power is turned OFF.
- Check the new Unit to make sure that there are no errors.
- If a faulty Unit is being returned for repair, describe the problem in as much detail as possible, enclose this description with the Unit, and return the Unit to your OMRON representative.
- For poor contact, take a clean cotton cloth, soak the cloth in industrial alcohol, and carefully wipe the contacts clean. Be sure to remove any lint prior to remounting the Unit.

- Note**
1. When replacing a CPU Unit, be sure that not only the user program but also all other data required for operation is transferred to or set in the new CPU Unit before starting operation, including DM Area and HR Area settings. If data area and other data are not correct for the user program, unexpected accidents may occur.
 2. Be sure to include the routing tables, Controller Link Unit data link tables, network parameters, and other CPU Bus Unit data, which are stored as parameters in the CPU Unit. Refer to the CPU Bus Unit and Special I/O Unit operation manuals for details on the data required by each Unit.

12-2 Replacing User-serviceable Parts

The following parts should be replaced periodically as preventative maintenance. The procedures for replacing these parts are described later in this section.

- Battery (backup for the CPU Unit's internal clock and RAM)

Battery Functions

The battery maintains the internal clock and the following data in the retained regions of I/O memory while the main power supply is OFF.

If the battery is not installed or battery voltage drops too low, the internal clock will stop and the data in RAM will be lost when the main power supply goes OFF.


Battery Service Life and Replacement Period

At 25°C, the maximum service life for batteries is five years whether or not power is supplied to the CPU Unit while the battery is installed. The battery's lifetime will be shorter when it is used at higher temperatures.

The following table shows the approximate minimum lifetimes and typical lifetimes for the backup battery (total time with power not supplied).

Model	Approx. maximum lifetime	Approx. minimum lifetime (See note.)	Typical lifetime (See note.)
CP1H-X/XA40DR-A CP1H-X/XA40DT(1)-D CP1H-Y20DR-D	5 years	13,000 hours (approx. 1.5 years)	43,000 hours (approx. 5 years)


- Note** The minimum lifetime is the memory backup time at an ambient temperature of 55°C. The typical lifetime is the memory backup time at an ambient temperature of 25°C.



This graphic is for reference only.

Low Battery Indications

The ERR/ALM indicator on the front of the CPU Unit will flash when the battery is nearly discharged.



When the ERR/ALM indicator flashes, connect the CX-Programmer to the peripheral port and read the error messages. If a low battery message appears on the CX-Programmer (see note 1) and the Battery Error Flag (A402.04) is ON (see note 1), first check whether the battery is properly connected to the CPU Unit. If the battery is properly connected, replace the battery as soon as possible.

Once a low-battery error has been detected, it will take 5 days before the battery fails assuming that power has been supplied at least once a day (see note 2). Battery failure and the resulting loss of data in RAM can be delayed by ensuring that the CPU Unit power is not turned OFF until the battery has been replaced.

Note

1. The PLC Setup must be set to detect a low-battery error (Detect Low Battery). If this setting has not been made, the BATT LOW error message will not appear on the CX-Programmer and the Battery Error Flag (A402.04) will not go ON when the battery fails.
2. The battery will discharge faster at higher temperatures, e.g., 4 days at 40°C and 2 days at 55°C.

Replacement Battery

Use the CJ1W-BAT01 Battery Set. Be sure to install a replacement battery within two years of the production date shown on the battery's label.

Production Date



Manufactured in July 2005.

Replacement Procedure

Use the following procedure to replace the battery when the previous battery has become completely discharged. You must complete this procedure within five minutes after turning OFF the power to the CPU Unit to ensure memory backup.

Note


1. We recommend replacing the battery with the power OFF to prevent the CPU Unit's sensitive internal components from being damaged by static electricity. The battery can be replaced without turning OFF the power supply. To do so, always touch a grounded piece of metal to discharge static electricity from your body before starting the procedure.
2. After replacing the battery, connect the CX-Programmer and clear the battery error.

Procedure**1,2,3...**

1. Turn OFF the power to the CPU Unit.
- or If the CPU Unit has not been ON, turn it ON for at least five minutes and then turn it OFF.

Note If power is not turned ON for at least five minutes before replacing the battery, the capacitor that backs up memory when the battery is removed will not be fully charged and memory may be lost before the new battery is inserted.

2. Open the compartment on the CPU Unit and carefully draw out the battery.
3. Remove the battery connector.
4. Connect the new battery, place it into the compartment, and close the cover.



! WARNING Never short-circuit the battery terminals; never charge the battery; never disassemble the battery; and never heat or incinerate the battery. Doing any of these may cause the battery to leak, burn, or rupturing resulting in injury, fire, and possible loss of life or property. Also, never use a battery that has been dropped on the floor or otherwise subject to shock. It may leak.

! Caution You must complete this procedure within five minutes after turning OFF the power to the CPU Unit to ensure memory backup. If the procedure is not completed within 5 minutes, data may be lost.

! Caution UL standards require that batteries be replaced by experienced technicians. Always place an experienced technician in charge of battery replacement.




! Caution Turn ON the power after replacing the battery for a CPU Unit that has been unused for a long time. Leaving the CPU Unit unused again without turning ON the power even once after the battery is replaced may result in a shorter battery life.

Note The battery error will automatically be cleared when a new battery is inserted.


Appendix A

Standard Models








CPU Units

Name and appearance	Model	Specifications			Remarks
		Power supply	Outputs	Inputs	
	CP1H-X40DR-A	100 to 240 VAC	16 relay outputs	24 VDC 24 inputs	Memory capacity: 20 Ksteps High-speed counters: 100 kHz, 4 counters Pulse outputs: 2 outputs at 100 kHz, 2 outputs at 30 kHz
	CP1H-X40DT-D	24 VDC	16 transistor outputs, sinking		
	CP1H-X40DT1-D		16 transistor outputs, sourcing		
	CP1H-XA40DR-A	100 to 240 VAC	16 relay outputs	24 VDC 24 inputs	Memory capacity: 20 Ksteps High-speed counters: 100 kHz, 4 counters Pulse outputs: 2 outputs at 100 kHz, 2 outputs at 30 kHz Analog inputs: 4 Analog outputs: 4
	CP1H-XA40DT-D	24 VDC	16 transistor outputs, sinking		
	CP1H-XA40DT1-D		16 transistor outputs, sourcing		
	CP1H-Y20DT-D	24 VDC	8 transistor outputs, sinking	24 VDC 12 inputs	Memory capacity: 20 Ksteps High-speed counters: 2 counters at 1 MHz, 2 counters at 100 kHz Pulse outputs: 2 outputs at 1 MHz, 2 outputs at 30 kHz







Programming Devices

Name and appearance	Model	Application	Remarks
CX-Programmer Ver. 6.1 	WS02-CXPC1-E-V61	Programming and monitoring from a Windows environment	<ul style="list-style-type: none"> The CP1H is supported by CX-Programmer version 6.1 or higher. Use an off-the-shelf USB cable to connect the computer running the CX-Programmer to the USB port on the CP1H CPU Unit.







Optional Products



Name and appearance	Model	Application	Remarks
RS-232C Option Board 	CP1W-CIF01	Mounted in option slot 1 or 2 on the CPU Unit to function as an RS-232C port.	---
RS-422A/485 Option Board 	CP1W-CIF11/ CIF12	Mounted in option slot 1 or 2 on the CPU Unit to function as an RS-422A/485 port.	
LCD Option Board 	CP1W-DAM01	Used to monitor and change user-specified messages, time or other data of the CPU Unit.	---
Ethernet Option Board 	CP1W-CIF41	Can be used to communicate with these units supported OMRON FINS/TCP, FINS/UDP protocol.	---
Memory Cassette 	CP1W-ME05M	Used to save CPU Unit user programming, parameters, and data or to copy these to another CPU Unit.	---
CJ Unit Adapter 	CP1W-EXT01	Required to connect CJ-series Special I/O Units and CJ-series CPU Bus Units.	The CP1W-TER01 End Cover is provided with the CJ Unit Adapter.
End Cover (See <i>Remarks.</i>) 	CJ1W-TER01		

CP-series Expansion I/O Units





Name and appearance	Model	Specifications		Remarks
		Inputs	Outputs	
40-point I/O Units 	CP1W-40EDR	24 VDC 24 inputs	16 relay outputs	---
	CP1W-40EDT		16 transistor outputs, sinking	
	CP1W-40EDT1		16 transistor outputs, sourcing	
32-point Output Units 	CP1W-32ER	None	32 relay outputs	---
	CP1W-32ET		32 transistor outputs, sinking	
	CP1W-32ET1		32 transistor outputs, sourcing	
20-point I/O Units 	CP1W-20EDR1	24 VDC 12 inputs	8 relay outputs	---
	CP1W-20EDT		8 transistor outputs, sinking	
	CP1W-20EDT1		8 transistor outputs, sourcing	
16-point Output Units 	CP1W-16ER	None	16 relay outputs	---
	CP1W-16ET		16 transistor outputs, sinking	
	CP1W-16ET1		16 transistor outputs, sourcing	
8-point Input Units 	CP1W-8ED	24 VDC 8 inputs	None	---
8-point Output Units 	CP1W-8ER	None	8 relay outputs	---
	CP1W-8ET		8 transistor outputs, sinking	
	CP1W-8ET1		8 transistor outputs, sourcing	






Expansion Units

Name and appearance	Model	Specifications	Remarks
Analog I/O Unit 	CP1W-MAD11	2 analog inputs 0 to 5 V, 1 to 5 V, 0 to 10 V, -10 to +10 V, 0 to 20 mA, 4 to 20 mA 1 analog output 1 to 5 V, 0 to 10 V, -10 to +10 V, 0 to 20 mA, 4 to 20 mA Resolution: 1/6,000	---
Analog I/O Unit 	CP1W-MAD42	4 analog inputs 0 to 5 V, 1 to 5 V, 0 to 10 V, -10 to +10 V, 0 to 20 mA, 4 to 20 mA 2 analog outputs 1 to 5 V, 0 to 10 V, -10 to +10 V, 0 to 20 mA, 4 to 20 mA Resolution: 1/12,000	---
Analog I/O Unit 	CP1W-MAD44	4 analog inputs 0 to 5 V, 1 to 5 V, 0 to 10 V, -10 to +10 V, 0 to 20 mA, 4 to 20 mA 4 analog outputs 1 to 5 V, 0 to 10 V, -10 to +10 V, 0 to 20 mA, 4 to 20 mA Resolution: 1/12,000	---
Analog Input Unit 	CP1W-AD041	4 analog inputs 0 to 5 V, 1 to 5 V, 0 to 10 V, -10 to +10 V, 0 to 20 mA, 4 to 20 mA Resolution: 1/6,000	---
	CP1W-AD042	4 analog inputs 0 to 5 V, 1 to 5 V, 0 to 10 V, -10 to +10 V, 0 to 20 mA, 4 to 20 mA Resolution: 1/12,000	---
Analog Output Unit 	CP1W-DA021	2 analog outputs 1 to 5 V, 0 to 10 V, -10 to +10 V, 0 to 20 mA, 4 to 20 mA Resolution: 1/6,000	---
	CP1W-DA041	4 analog outputs 1 to 5 V, 0 to 10 V, -10 to +10 V, 0 to 20 mA, 4 to 20 mA Resolution: 1/6,000	---
	CP1W-DA042	4 analog outputs 1 to 5 V, 0 to 10 V, -10 to +10 V, 0 to 20 mA, 4 to 20 mA Resolution: 1/12,000	---
Temperature Sensor Units 	CP1W-TS001	Thermocouple inputs K or J, 2 inputs	---
	CP1W-TS002	Thermocouple inputs K or J, 4 inputs	---
	CP1W-TS003	Thermocouple inputs K or J, 4 inputs or 2 analog inputs 0 to 10V, 1 to 5V, 4 to 20mA AD Resolution: 1/12,000 TS Resolution: 0.1°C or 0.1°F	---
	CP1W-TS101	Platinum resistance thermometer inputs Pt100 or JPt100, 2 inputs	---
	CP1W-TS102	Platinum resistance thermometer inputs Pt100 or JPt100, 4 inputs	---




Name and appearance	Model	Specifications	Remarks
Temperature Sensor Units 	CP1W-TS004	Thermocouple inputs K or J, 12 inputs	---
CompoBus/S I/O Link Unit 	CP1W-SRT21	As a CompoBus/S slave, 8 inputs and 8 outputs are allocated.	





CJ-series Special I/O Units

Name and appearance		Model	Specifications		Remarks
<div>Analog Input Units</div> <div></div>		CJ1W-AD081-V1	8 analog inputs	0 to 5 V, 1 to 5 V, 0 to 10 V, -10 to +10 V, 4 to 20 mA Resolution: 1/8000	Resolution can be set to 1/4000.
		CJ1W-AD041-V1	4 analog inputs		
<div>Analog Output Units</div> <div></div>		CJ1W-DA08V	8 analog outputs	0 to 5 V, 1 to 5 V, 0 to 10 V, -10 to +10 V Resolution: 1/8000	Resolution can be set to 1/4000.
		CJ1W-DA08C	8 analog outputs	4 to 20 mA Resolution: 1/8000	
		CJ1W-DA041	4 analog outputs	0 to 5 V, 1 to 5 V, 0 to 10 V, -10 to +10 V Resolution: 1/8000	
		CJ1W-DA021	2 analog outputs		
<div>Analog I/O Unit</div> <div></div>		CJ1W-MAD42	4 analog inputs and 2 analog outputs: 0 to 5 V, 1 to 5 V, 0 to 10 V, -10 to +10 V, 4 to 20 mA Resolution: 1/4000		Resolution can be set to 1/8000.
<div>Process I/O Units</div> <div></div>	Temperature Sensor Units	CJ1W-PTS51	Thermocouple inputs R, S, K, J, T, L, or B; 2 inputs		---
		CJ1W-PTS52	Platinum resistance thermometer inputs Pt100 or JPt100, 4 inputs		
		CJ1W-PTS15	Thermocouple inputs B, E, J, K, L, N, R, S, T, U, WRe5-26, PLII, or DC voltage (±100 mV); 2 inputs		
		CJ1W-PTS16	Platinum resistance thermometer inputs Pt100 or JPt100, JPt50, or Ni508.4; 2 inputs		
	Isolated-type DC Input Unit	CJ1W-PDC15	DC voltage: 0 to 125 V, -125 to +125 V, 0 to 5 V, 1 to 5 V, -5 to 5 V, 1 to 5 V, 0 to 10 V, -10 to +10 V, or user-set range between -10 to +10 V DC current: 0 to 20 mA or 4 to 20 mA 2 inputs		


Name and appearance	Model	Specifications			Remarks
<div>Temperature Control Units</div> <div></div>	CJ1W-TC001	Thermo-couple inputs B, S, K, J, T, or L	4 control loops	Open-collector NPN outputs	---
	CJ1W-TC002			Open-collector PNP outputs	
	CJ1W-TC003		2 control loops	Open-collector NPN outputs	
	CJ1W-TC004			Open-collector PNP outputs	
	CJ1W-TC101	Platinum resistance thermometer inputs Pt100 or JPt100	4 control loops	Open-collector NPN outputs	
	CJ1W-TC102			Open-collector PNP outputs	
	CJ1W-TC103		2 control loops	Open-collector NPN outputs	
	CJ1W-TC104			Open-collector PNP outputs	
<div>Position Control Units</div> <div></div>	CJ1W-NC113	1 control axis		Open-collector outputs	---
	CJ1W-NC133			Line-driver outputs	
	CJ1W-NC213	2 control axes		Open-collector outputs	
	CJ1W-NC233			Line-driver outputs	
	CJ1W-NC413	4 control axes		Open-collector outputs	
	CJ1W-NC433			Line-driver outputs	
<div>High-speed Counter Unit</div> <div></div>	CJ1W-CT021	Two counter channels, 10 kHz, 50 kHz, or 500 kHz			---
<div>ID Sensor Units</div> <div></div>	CJ1W-V600C11	Connects to one Read/Write Head.			---
	CJ1W-V600C12	Connects to two Read/Write Heads.			
<div>CompoBus/S Master Unit</div> <div></div>	CJ1W-SRM21	256 points (128 inputs and 128 outputs)			---

CJ-series CPU Bus Units




Name and appearance	Model	Specifications	Remarks
Position Control Unit 	CJ1W-NCF71	MECHATROLINK II-compliant 16 control axes	---
Motion Control Unit 	CJ1W-MCH71	MECHATROLINK II-compliant	
Serial Communications Units 	CJ1W-SCU41-V1	One RS-232C port One RS-422A/485 port	---
	CJ1W-SCU21-V1	Two RS-232C ports	

Name and appearance	Model	Specifications	Remarks
Ethernet Unit 	CJ1W-ETN21	100Base-TX or 10Base-T	---
Controller Link Unit 	CJ1W-CLK21	Data exchange: 20,000 words maximum	---
FL-net Unit 	CJ1W-FLN22	100Base-TX	---
DeviceNet Unit 	CJ1W-DRM21	Control points: 3,200 maximum (2,000 words)	---

Maintenance Products

Name and appearance	Model	Specifications	Remarks
Battery 	CJ1W-BAT01	---	Installed in the CPU Unit.


Installation and Wiring Products

Name and appearance	Model	Specifications	Remarks
DIN Track 	PFP-50N	---	---
	PFP-100N	---	
	PFP-100N2	---	
End Plate 	PFP-M	---	
I/O Connecting Cable 	CP1W-CN811	Used to install CP-series Expansion Units and Expansion I/O Units in a second row. Only one I/O Connecting Cable can be used in each PLC. This I/O Connecting Cable is required to connect both CJ-series and CP-series Units.	---

Appendix B


Dimensions Diagrams

X, XA, and Y CPU Units




Optional Products


CP1W-CIF01 Option Board




CP1W-CIF11/CP1W-CIF12-V1 Option Board




CP1W-CIF12 Option Board (Not include CP1W-CIF12-V1)




CP1W-DAM01 LCD Option Board



CP1W-CIF41 Ethernet Option Board




CP1W-ME05M Memory Cassette




Expansion I/O Units


40-point I/O Units (CP1W-40EDR/40EDT/40EDT1)




32-point Output Units (CP1W-32ER/32ET/32ET1)




20-point I/O Units (CP1W-20EDR1/20EDT/20EDT1)



16-point Output Unit (CP1W-16ER/16ET/16ET1)



8-point I/O Units (CP1W-8ER/8ET/8ET1)




Expansion Units


CP1W-AD041/CP1W-AD042 Analog Input Units

CP1W-DA041/CP1W-DA042 Analog Output Units


CP1W-MAD11/CP1W-MAD42/CP1W-MAD44 Analog I/O Units




CP1W-TS001/101/002/102/003 Temperature Sensor Units



CP1W-TS004 Temperature Sensor Units




CP1W-SRT21 CompoBus/S I/O Link Unit




Products Related to Using CJ-series Units


CP1W-EXT01 CJ Unit Adapter




CJ1W-TER01 End Cover



CJ-series Special I/O Units and CPU Bus Units



CJ1W-MCH71



Appendix C

Auxiliary Area Allocations by Function

Initial Settings

Name	Address	Description	Access	Updated
IOM Hold Bit	A500.12	Turn this bit ON to retain the status of the I/O Memory when shifting from PROGRAM to RUN or MONITOR mode or vice versa or when turning ON the power supply. ON: I/O memory retained OFF: I/O memory not retained	Read/write	
Forced Status Hold Bit	A500.13	Turn this bit ON to preserve the status of bits that have been force-set or force-reset when shifting from PROGRAM to MONITOR mode or vice versa or when turning ON the power supply.	Read/write	

CPU Unit Settings

Name	Address	Description	Access	Updated
Status of DIP Switch Pin 6	A395.12	The status of pin 6 on the DIP switch on the front of the CPU Unit is written to this flag every cycle.	Read-only	
Manufacturing Lot Number	A310 and A311	The manufacturing lot number is stored in 5 digits hexadecimal. X, Y, and Z in the lot number are converted to 10, 11, and 12, respectively. Examples: Lot number 23805 A310 = 0823, A311 = 0005 Lot number 15X05 A310 = 1015, A311 = 0005	Read-only	

DM Initial Value Settings

Name	Address	Description	Access	Updated
DM Initial Values Flag	A345.04	ON when DM initial values are stored in the flash memory.	Read-only	
DM Initial Values Read Error Flag	A751.11	ON when an error occurred in transferring DM initial values from the DM initial value area in flash memory to the DM Area.	Read-only	
DM Initial Values Save Execution Error Flag	A751.12	ON when the DM Initial Values Transfer Password (A752) is incorrect or when the DM Initial values area was not specified when starting to transfer DM initial values from the DM Area to the DM initial value area in flash memory.	Read-only	
DM Initial Values Save Error Flag	A751.13	ON when an error occurred in transferring DM initial values from the DM Area to the DM initial value area in flash memory.	Read-only	
DM Initial Values Save Flag	A751.14	ON while DM initial values are being transferred from the DM Area to the DM initial value area in flash memory. OFF when the transfer has been completed.	Read-only	
DM Initial Values Save Start Bit	A751.15	Turn ON this bit to start transferring DM initial values. This bit is valid only when a correct password is stored in A752 and the DM Area Initial Value Area is specified (i.e., when A753.00 is ON). The system will turn this bit OFF automatically when the transfer has been completed.	Read/Write	
DM Initial Values Transfer Password	A752	Set the passwords here to transfer DM initial values between the DM area and the DM initial value area in flash memory. The transfer will not be started unless the correct password is set. The transfer is started when A751.15 is turned ON. The password will be cleared by the system when the transfer has been completed. A5A5 hex: Save initial values from DM to flash	Read/Write	
DM Initial Values Save Area Specifications	A753.00	Specifies the area to be transferred to flash memory.	Read/Write	

Built-in Inputs

Analog Adjustment and External Analog Setting Input

Name	Address	Description	Access	Updated
Analog Adjustment PV	A642	Stores the value set on the analog adjuster as a hexadecimal value (resolution: 1/256). 0000 to 00FF hex	Read-only	When analog adjustment is turned
External Analog Setting Input PV	A643	Stores the value set from the external analog setting input as a hexadecimal value (resolution: 1/256). 0000 to 00FF hex	Read-only	

Input Interrupts, Interrupt Counters 0 to 7

Interrupt counter	Counter SV	Counter PV
Interrupt counter 0	A532	A536
Interrupt counter 1	A533	A537
Interrupt counter 2	A534	A538
Interrupt counter 3	A535	A539
Interrupt counter 4	A544	A548
Interrupt counter 5	A545	A549
Interrupt counter 6	A546	A550
Interrupt counter 7	A547	A551

Name	Description	Access	Updated
Interrupt Counter Counter SV	Used for an interrupt input in counter mode. Sets the count value at which the interrupt task will start. The corresponding interrupt task will start when the interrupt counter has counted this number of pulses.	Read/Write	<ul style="list-style-type: none"> Retained when power is turned ON. Retained when operation starts.
Interrupt Counter Counter PV	These words contain the interrupt counter PVs for interrupt inputs operating in counter mode. In increment mode, the counter PV starts incrementing from 0. When the counter PV reaches the counter SV, the PV is automatically reset to 0. In decrement mode, the counter PV starts decrementing from the counter SV. When the counter PV reaches the 0, the PV is automatically reset to the SV.	Read/Write	<ul style="list-style-type: none"> Retained when power is turned ON. Cleared when operation starts. Updated when interrupt is generated.

High-speed Counters 0 to 3

Item		High-speed counter 0	High-speed counter 1	High-speed counter 2	High-speed counter 3
High-speed Counter PV	Leftmost 4 digits	A271	A273	A317	A319
	Rightmost 4 digits	A270	A272	A316	A318
High-speed Counter Range Comparison Condition Met Flag	Range 1	A274.00	A275.00	A320.00	A321.00
	Range 2	A274.01	A275.01	A320.01	A321.01
	Range 3	A274.02	A275.02	A320.02	A321.02
	Range 4	A274.03	A275.03	A320.03	A321.03
	Range 5	A274.04	A275.04	A320.04	A321.04
	Range 6	A274.05	A275.05	A320.05	A321.05
	Range 7	A274.06	A275.06	A320.06	A321.06
	Range 8	A274.07	A275.07	A320.07	A321.07
High-speed Counter Comparison In-progress Flag		A274.08	A275.08	A320.08	A321.08
High-speed Counter Overflow/Underflow Flag		A274.09	A275.09	A320.09	A321.09
High-speed Counter Count Direction		A274.10	A275.10	A320.10	A321.10
High-speed Counter Count Reset Bit		A531.00	A531.01	A531.02	A531.03
High-speed Counter Gate Flag		A531.08	A531.09	A531.10	A531.11

Name		Description	Read/Write	Updated
High-speed Counter PV		Contains the PV of the high-speed counter.	Read-only	<ul style="list-style-type: none"> • Cleared when power is turned ON. • Cleared when operation starts. • Updated each cycle during overseeing process. • Updated when PRV(881) instruction is executed for the corresponding counter.
High-speed Counter Range Comparison Condition Met Flags	Range 1	These flags indicate whether the PV is within the specified ranges when the high-speed counter is being operated in range-comparison mode.	Read-only	<ul style="list-style-type: none"> • Cleared when power is turned ON. • Cleared when operation starts. • Cleared when range comparison table is registered. • Updated each cycle during overseeing process. • Updated when PRV(881) instruction is executed to read range comparison results.
	Range 2			
	Range 3	OFF: PV not in range		
	Range 4	ON: PV in range		
	Range 5			
	Range 6			
	Range 7			
	Range 8			
High-speed Counter Comparison In-progress Flag		<p>This flag indicates whether a comparison operation is being executed for the high-speed counter.</p> <p>OFF: Stopped.</p> <p>ON: Being executed.</p>	Read-only	<ul style="list-style-type: none"> • Cleared when power is turned ON. • Cleared when operation starts. • Updated when comparison operation starts or stops.
High-speed Counter Overflow/Underflow Flag		<p>This flag indicates when an overflow or underflow has occurred in the high-speed counter PV. (Used with the linear mode counting range only.)</p> <p>OFF: Normal</p> <p>ON: Overflow or underflow</p>	Read-only	<ul style="list-style-type: none"> • Cleared when power is turned ON. • Cleared when operation starts. • Cleared when the PV is changed. • Updated when an overflow or underflow occurs.
High-speed Counter Count Direction		<p>This flag indicates whether the high-speed counter is currently being incremented or decremented. The counter PV for the current cycle is compared with the PLC in last cycle to determine the direction.</p> <p>OFF: Decrementing</p> <p>ON: Incrementing</p>	Read-only	<ul style="list-style-type: none"> • Setting used for high-speed counter, valid during counter operation.
High-speed Counter Reset Bit		<p>When the reset method is set to Phase-Z signal + Software reset, the corresponding high-speed counter's PV will be reset if the phase-Z signal is received while this bit is ON.</p> <p>When the reset method is set to a software reset, the corresponding high-speed counter's PV will be reset in the cycle when this bit goes ON.</p>	Read/Write	<ul style="list-style-type: none"> • Cleared when power is turned ON.
High-speed Counter Gate Bit		<p>When a counter's Gate Bit is ON, the counter's PV will not be changed even if pulse inputs are received for the counter.</p> <p>When the bit is turned OFF again, counting will restart and the high-speed counter's PV will be updated.</p> <p>When the reset method is set to Phase-Z signal + Software reset, the Gate Bit is disabled while the corresponding Reset Bit is ON.</p>	Read/Write	<ul style="list-style-type: none"> • Cleared when power is turned ON.

Built-in Analog Inputs (XA CPU Units)

Name	Address	Description	Read/Write	Updated
Built-in Analog Input Open-circuit Error Flag	A434.00 to A434.03	<p>ON when an open-circuit occurs in a built-in analog input.</p> <p>A434.00: Analog Input 0 Open-circuit Error Flag</p> <p>A434.01: Analog Input 1 Open-circuit Error Flag</p> <p>A434.02: Analog Input 2 Open-circuit Error Flag</p> <p>A434.03: Analog Input 3 Open-circuit Error Flag</p>	Read-only	When open-circuit is detected
Analog Initialization Completed Flag	A434.04	ON while the built-in analog I/O is being initialized.	Read-only	When initialization is completed

Built-in Outputs

Pulse Outputs 0 to 3

Item		Pulse output 0	Pulse output 1	Pulse output 2	Pulse output 3
Pulse Output PV	Leftmost 4 digits	A277	A279	A323	A325
	Rightmost 4 digits	A276	A278	A322	A324
Pulse Output Accel/Decel Flag		A280.00	A281.00	A326.00	A327.00
Pulse Output Overflow/Underflow Flag		A280.01	A281.01	A326.01	A327.01
Pulse Output, Output Amount Set Flag		A280.02	A281.02	A326.02	A327.02
Pulse Output, Output Completed Flag		A280.03	A281.03	A326.03	A327.03
Pulse Output, Output In-progress Flag		A280.04	A281.04	A326.04	A327.04
Pulse Output No-origin Flag		A280.05	A281.05	A326.05	A327.05
Pulse Output At-origin Flag		A280.06	A281.06	A326.06	A327.06
Pulse Output, Output Stopped Error Flag		A280.07	A281.07	A326.07	A327.07
PWM Output, Output In-progress Flag		A283.00	A283.08	A326.08	A327.08
Pulse Output Stop Error Code		A444	A445	A438	A439
Pulse Output Reset Bit		A540.00	A541.00	A542.00	A543.00
Pulse Output CW Limit Input Signal Flag		A540.08	A541.08	A542.08	A543.08
Pulse Output CCW Limit Input Signal Flag		A540.09	A541.09	A542.09	A543.09
Pulse Output Positioning Completed Signal		A540.10	A541.10	A542.10	A543.10

Name	Description	Read/Write	Updated
Pulse Output PV	Contain the number of pulses output from the corresponding pulse output port. PV range: 80000000 to 7FFFFFFF hex (-2,147,483,648 to 2,147,483,647) When pulses are being output in the CW direction, the PV is incremented by 1 for each pulse. When pulses are being output in the CCW direction, the PV is decremented by 1 for each pulse. PV after overflow: 7FFFFFFF hex PV after underflow: 80000000 hex Note If the coordinate system uses relative coordinates (undefined origin), the PV will be cleared to 0 when a pulse output starts, i.e. when a pulse output instruction (SPED(885), ACC(888), or PLS2(887)) is executed.	Read-only	<ul style="list-style-type: none"> • Cleared when power is turned ON. • Cleared when operation starts. • Updated each cycle during over-see process. • Updated when the PV is changed by the INI(880) instruction.
Pulse Output Accel/Decel Flag	This flag will be ON when pulses are being output according to an ACC(888) or PLS2(887) instruction and the output frequency is being changed in steps (accelerating or decelerating). OFF: Constant speed ON: Accelerating or decelerating	Read-only	<ul style="list-style-type: none"> • Cleared when power is turned ON. • Cleared when operation starts or stops. • Updated each cycle during over-see process.
Pulse Output Overflow/Underflow Flag	This flag indicates when an overflow or underflow has occurred in the pulse output PV. OFF: Normal ON: Overflow or underflow	Read-only	<ul style="list-style-type: none"> • Cleared when power is turned ON. • Cleared when operation starts. • Cleared when the PV is changed by the INI(880) instruction. • Updated when an overflow or underflow occurs.
Pulse Output, Output Amount Set Flag	ON when the number of output pulses has been set with the PULS(886) instruction. OFF: No setting ON: Setting made	Read-only	<ul style="list-style-type: none"> • Cleared when power is turned ON. • Cleared when operation starts or stops. • Updated when the PULS(886) instruction is executed. • Updated when pulse output stops.
Pulse Output, Output Completed Flag	ON when the number of output pulses set with the PULS(886) or PLS2(887) instruction has been output. OFF: Output not completed. ON: Output completed.	Read-only	<ul style="list-style-type: none"> • Cleared when power is turned ON. • Cleared when operation starts or stops. • Updated at the start or completion of pulse output in independent mode.

Name	Description	Read/Write	Updated
Pulse Output, Output In-progress Flag	ON when pulses are being output. OFF: Stopped ON: Outputting pulses.	Read-only	<ul style="list-style-type: none"> • Cleared when power is turned ON. • Cleared when operation starts or stops. • Updated when pulse output starts or stops.
Pulse Output No-origin Flag	ON when the origin has not been determined and goes OFF when the origin has been determined. OFF: Origin established. ON: Origin not established.	Read-only	<ul style="list-style-type: none"> • Cleared when power is turned ON. • Cleared when operation starts. • Updated when pulse output starts or stops. • Updated each cycle during the overseeing processes.
Pulse Output At-origin Flag	ON when the pulse output PV matches the origin (0). OFF: Not stopped at origin. ON: Stopped at origin.	Read-only	<ul style="list-style-type: none"> • Cleared when power is turned ON. • Updated each cycle during the overseeing processes.
Pulse Output, Output Stopped Error Flag	ON when an error occurred while outputting pulses in the pulse output 0 origin search function. OFF: No error ON: Stop error occurred.	Read-only	<ul style="list-style-type: none"> • Cleared when power is turned ON. • Updated when origin search starts. • Updated when a pulse output stop error occurs.
PWM Output, Output In-progress Flag	ON when pulses are being output from the PWM output. OFF: Stopped ON: Outputting pulses.	Read-only	<ul style="list-style-type: none"> • Cleared when power is turned ON. • Cleared when operation starts or stops. • Updated when pulse output starts or stops.
Pulse Output Stop Error Code	If a Pulse Output Stop Error occurs, the error code is written to this word.	Read-only	<ul style="list-style-type: none"> • Cleared when power is turned ON. • Updated when origin search starts. • Updated when a pulse output stop error occurs.
Pulse Output Reset Bit	The pulse output PV will be cleared when this bit is turned ON.	Read/Write	Cleared when power is turned ON.
Pulse Output CW Limit Input Signal Flag	This is the CW limit input signal for the pulse output, which is used in the origin search. To use this signal, write the input from the actual sensor as an input condition in the ladder program and output the result to this flag.	Read/Write	Cleared when power is turned ON.
Pulse Output CCW Limit Input Signal Flag	This is the CCW limit input signal for the pulse output, which is used in the origin search. To use this signal, write the input from the actual sensor as an input condition in the ladder program and output the result to this flag.	Read/Write	Cleared when power is turned ON.
Pulse Output Positioning Completed Signal	This is the positioning completed input signal used in the origin search for the pulse output. The input signal from the servo driver is output to this bit from the ladder program to enable using the signal.	Read/Write	Cleared when power is turned ON.

Built-in Analog Outputs (XA CPU Units Only)

Name	Address	Description	Read/Write	Updated
Analog Initialization Completed Flag	A434.04	ON while the built-in analog I/O is being initialized.	Read-only	When initialization is completed

CPU Bus Unit Flags/Bits

Name	Address	Description	Access	Updated
CPU Bus Unit Initialization Flags	A302.00 to A302.15	These flags are ON while the corresponding CPU Bus Unit is initializing after its CPU Bus Unit Restart Bit (A501.00 to A501.15) is turned ON or the power is turned ON. Bits 00 to 15 correspond to unit numbers 0 to 15. Use these flags in the program to prevent the CPU Bus Unit's refresh data from being used while the Unit is initializing. IORF(097) cannot be executed while an CPU Bus Unit is initializing.	Read-only	
CPU Bus Unit Restart Bits	A501.00 to A501.15	Turn the corresponding bit ON to restart (initialize) the CPU Bus Unit with the corresponding unit number. Bits 00 to 15 correspond to unit numbers 0 to F.	Read/write	

Special I/O Unit Flags/Bits

Name	Address	Description	Access	Updated
Special I/O Unit Initialization Flags	A330.00 to A335.15	These flags are ON while the corresponding Special I/O Unit is initializing after its Special I/O Unit Restart Bit (A502.00 to A507.15) is turned ON or the power is turned ON. The bits in these words correspond to unit numbers 0 to 95 as follows: A330.00 to A330.15: Units 0 to 15 A331.00 to A331.15: Units 16 to 31 ---- A335.00 to A335.15: Units 80 to 95	Read-only	
Special I/O Unit Restart Bits	A502.00 to A507.15	Turn the corresponding bit ON to restart (initialize) the Special I/O Unit with the corresponding unit number. Bits A502.00 to A507.15 correspond to unit numbers 0 to 95.	Read/write	

System Flags

Name	Address	Description	Access	Updated
First Cycle Flag	A200.11	ON for one cycle after PLC operation begins (after the mode is switched from PROGRAM to RUN or MONITOR, for example).	Read-only	
Initial Task Execution Flag	A200.15	ON when a task is executed for the first time, i.e., when it changes from INI to RUN status.	Read-only	
Task Started Flag	A200.14	When a task switches from WAIT or INI to RUN status, this flag will be turned ON within the task for one cycle only. Note The only difference between this flag and A200.15 is that this flag also turns ON when the task switches from WAIT to RUN status.	Read-only	
Maximum Cycle Time	A262 to A263	These words contain the maximum cycle time since the start of PLC operation. The cycle time is recorded in 8-digit hexadecimal with the leftmost 4 digits in A263 and the rightmost 4 digits in A262. 0 to FFFFFFFF: 0 to 429,496,729.5 ms (0.1-ms units)	Read-only	
Present Cycle Time	A264 to A265	These words contain the present cycle time in 8-digit hexadecimal with the leftmost 4 digits in A265 and the rightmost 4 digits in A264. 0 to FFFFFFFF: 0 to 429,496,729.5 ms (0.1-ms units)	Read-only	
10-ms Incrementing Free Running Timer	A0	This word contains the system timer used after the power is turned ON. A value of 0000 hex is set when the power is turned ON and this value is automatically incremented by 1 every 10 ms. The value returns to 0000 hex after reaching FFFF hex (655,350 ms), and then continues to be automatically incremented by 1 every 10 ms. Note: The timer will continue to be incremented when the operating mode is switched to RUN mode. Example: The interval can be counted between processing A and processing B without requiring timer instructions. This is achieved by calculating the difference between the value in A0 for processing A and the value in A0 for processing B. The interval is counted in 10 ms units.	Read-only	
100-ms Incrementing Free Running Timer	A1	This word contains the system timer used after the power is turned ON. A value of 0000 hex is set when the power is turned ON and this value is automatically incremented by 1 every 100 ms. The value returns to 0000 hex after reaching FFFF hex (6,553,500 ms), and then continues to be automatically incremented by 1 every 100 ms. Note: The timer will continue to be incremented when the operating mode is switched to RUN mode. Example: The interval can be counted between processing A and processing B without requiring timer instructions. This is achieved by calculating the difference between the value in A0 for processing A and the value in A0 for processing B. The interval is counted in 100 ms units.	Read-only	

Task Information

Name	Address	Description	Access	Updated
Task Number when Program Stopped	A294	This word contains the task number of the task that was being executed when program execution was stopped because of a program error.	Read-only	
Maximum Interrupt Task Processing Time	A440	Contains the Maximum Interrupt Task Processing Time in units of 0.1 ms as hexadecimal data.	Read-only	
Interrupt Task with Max. Processing Time	A441	Contains the task number of the interrupt task with the maximum processing time. Hexadecimal values 8000 to 80FF correspond to task numbers 00 to FF. Bit 15 is turned ON when an interrupt has occurred.	Read-only	
IR/DR Operation between Tasks	A99.14	ON when index and data registers are shared between all tasks. OFF: Independent ON: Shared (default)	Read-only	

Debugging Information

Online Editing

Name	Address	Description	Access	Updated
Online Editing Wait Flag	A201.10	ON when an online editing process is waiting.	Read-only	
Online Editing Processing Flag	A201.11	ON when an online editing process is being executed.	Read-only	
Online Editing Disable Bit Validator	A527.00 to A527.07	The Online Editing Disable Bit (A527.09) is valid only when this byte contains 5A.	Read/write	
Online Editing Disable Bit	A527.09	Turn this bit ON to disable online editing. The setting of this bit is valid only when A527.00 to A527.07 have been set to 5A.	Read/write	

Output Control

Name	Address	Description	Access	Updated
Output OFF Bit	A500.15	Turn this bit ON to turn OFF all outputs from the CPU Unit, CP-series Units, and Special I/O Units.	Read/write	

Differentiate Monitor

Name	Address	Description	Access	Updated
Differentiate Monitor Completed Flag	A508.09	ON when the differentiate monitor condition has been established during execution of differentiation monitoring.	Read/write	

Data Tracing

Name	Address	Description	Access	Updated
Sampling Start Bit	A508.15	When a data trace is started by turning this bit ON from the CX-Programmer, the PLC will begin storing data in Trace Memory by one of the three following methods: Data is sampled at regular intervals (10 to 2,550 ms). Data is sampled when TRSM(045) is executed in the program. Data is sampled at the end of every cycle.	Read/write	
Trace Start Bit	A508.14	Turn this bit ON to establish the trigger condition. The offset indicated by the delay value (positive or negative) determines which data samples are valid.	Read/write	
Trace Busy Flag	A508.13	ON when the Sampling Start Bit (A508.15) is turned ON. OFF when the trace is completed.	Read/write	
Trace Completed Flag	A508.12	ON when sampling of a region of trace memory has been completed during execution of a trace.	Read/write	
Trace Trigger Monitor Flag	A508.11	ON when a trigger condition is established by the Trace Start Bit (A508.14). OFF when the next data trace is started by the Sampling Start Bit (A508.15).	Read/write	

Comment Memory

Name	Address	Description	Access	Updated
Program Index File Flag	A345.01	Turns ON when the comment memory contains a program index file. OFF: No file ON: File present	Read-only	
Comment File Flag	A345.02	Turns ON when the comment memory contains a comment file. OFF: No file ON: File present	Read-only	
Symbol Table File Flag	A345.03	Turns ON when the comment memory contains a symbol table file. OFF: No file ON: File present	Read-only	

Error Information

Error Log, Error Code

Name	Address	Description	Access	Updated
Error Log Area	A100 to A199	When an error has occurred, the error code, error contents, and error's time and date are stored in the Error Log Area.	Read-only	
Error Log Pointer	A300	When an error occurs, the Error Log Pointer is incremented by 1 to indicate the location where the next error record will be recorded as a hexadecimal offset from the beginning of the Error Log Area (A100 to A199).	Read-only	
Error Log Pointer Reset Bit	A500.14	Turn this bit ON to reset the Error Log Pointer (A300) to 00.	Read/write	
Error Code	A400	When a non-fatal error (user-defined FALS(006) or system error) or a fatal error (user-defined FALS(007) or system error) occurs, the 4-digit hexadecimal error code is written to this word.	Read-only	

Memory Error Information

Name	Address	Description	Access	Updated
Memory Error Flag (fatal error)	A401.15	ON when an error occurred in memory or there was an error in automatic transfer from the Memory Cassette when the power was turned ON. CPU Unit operation will stop and the ERR/ALM indicator on the front of the CPU Unit will light. Note A403.09 will be turned ON if there was an error during automatic transfer at startup. The automatic transfer at startup error cannot be cleared without turning OFF the PLC.	Read-only	
Memory Error Location	A403.00 to A403.08	When a memory error occurs, the Memory Error Flag (A401.15) is turned ON and one of the following flags is turned ON to indicate the memory area where the error occurred A403.00: User program A403.04: PLC Setup A403.07: Routing Table A403.08: CPU Bus Unit Settings	Read-only	
Startup Memory Card Transfer Error Flag	A403.09	ON when automatic transfer at startup has been selected and an error occurs during automatic transfer. An error will occur if there is a transfer error, the specified file does not exist, or the Memory Cassette is not installed. (This flag will be turned OFF when the error is cleared by turning the power OFF. The error cannot be cleared without turning the power OFF.)	Read-only	
Flash Memory Error	A403.10	ON when the flash memory fails.	Read-only	

Program Error Information

Name	Address	Description	Access	Updated
Other Fatal Error Flag	A401.00	ON when a fatal error that is not defined for A401.01 to A401.15 occurs. Detailed information is output to the bits of A314. OFF: No other fatal error ON: Other fatal error		
Program Error Flag (fatal error)	A401.09	ON when program contents are incorrect. CPU Unit operation will stop.	Read-only	When error occurs
Program Error Task	A294	This word contains the task number of the task that was being executed when program execution was stopped because of a program error.	Read-only	
Instruction Processing Error Flag	A295.08	This flag and the Error Flag (ER) will be turned ON when an instruction processing error has occurred and the PLC Setup has been set to stop operation for an instruction error.	Read-only	
Indirect DM/EM BCD Error Flag	A295.09	This flag and the Access Error Flag (AER) will be turned ON when an indirect DM BCD error has occurred and the PLC Setup has been set to stop operation an indirect DM BCD error. (This error occurs when the content of an indirectly addressed DM word is not BCD although BCD mode has been selected.)	Read-only	
Illegal Access Error Flag	A295.10	This flag and the Access Error Flag (AER) will be turned ON when an illegal access error has occurred and the PLC Setup has been set to stop operation an illegal access error. (This error occurs when a region of memory is accessed illegally.)	Read-only	
No END Error Flag	A295.11	ON when there isn't an END(001) instruction in each program within a task	Read-only	
Task Error Flag	A295.12	ON when a task error has occurred. The following conditions generate a task error. There isn't even one regular task that is executable (started). There isn't a program allocated to the task.	Read-only	
Differentiation Overflow Error Flag	A295.13	ON when the allowed value for Differentiation Flags which correspond to differentiation instructions has been exceeded.	Read-only	
Illegal Instruction Error Flag	A295.14	ON when a program that cannot be executed has been stored.	Read-only	
UM Overflow Error Flag	A295.15	ON when the last address in UM (User Memory) has been exceeded	Read-only	
Program Address Where Program Stopped	A298 and A299	These words contain the 8-digit binary program address of the instruction where program execution was stopped due to a program error. A298: Rightmost 4 digits, A299: Leftmost 4 digits	Read-only	

FAL/FALS Error Information

Name	Address	Description	Access	Updated
FAL Error Flag (non-fatal error)	A402.15	ON when a non-fatal error is generated by executing FAL(006). The CPU Unit will continue operating.	Read-only	
Executed FAL Number Flags	A360 to A391	The flag corresponding to the specified FAL number will be turned ON when FAL(006) is executed. Bits A360.01 to A391.15 correspond to FAL numbers 001 to 511.	Read-only	
FALS Error Flag (fatal error)	A401.06	ON when a fatal error is generated by the FALS(006) instruction. The CPU Unit will stop operating.	Read-only	
FAL/FALS Number for System Error Simulation	A529	Set a dummy FAL/FALS number to use to simulate the system error using FAL(006) or FALS(007). Set the FAL/FALS number. 0001 to 01FF hex: FAL/FALS numbers 1 to 511 0000 or 0200 to FFFF hex: No FAL/FALS number for system error simulation. (No error will be generated.)	Read/write	

PLC Setup Error Information

Name	Address	Description	Access	Updated
PLC Setup Error Flag (non-fatal error)	A402.10	ON when there is a setting error in the PLC Setup.	Read-only	
PLC Setup Error Location	A406	When there is a setting error in the PLC Setup, the location of that error is written to A406 in 4-digit hexadecimal.	Read-only	

Interrupt Task Error Information

Name	Address	Description	Access	Updated
Interrupt Task Error Flag (non-fatal error)	A402.13	ON when the Detect Interrupt Task Errors setting in the PLC Setup is set to "Detect" and an interrupt task is executed for more than 10 ms during I/O refreshing of a Special I/O Unit. This flag will also be turned ON if an attempt is made to refresh a Special I/O Unit's I/O from an interrupt task with IORF(097) while the Unit's I/O is being updated by cyclic I/O refreshing (duplicate refreshing).	Read-only	
Interrupt Task Error Cause Flag	A426.15	When A402.13 (the Interrupt Task Error Flag) is ON, this flag indicates the cause of the error.	Read-only	
Interrupt Task Error, Task Number	A426.00 to A426.11	When A402.13 (the Interrupt Task Error Flag) is ON, contains the unit number of the Special I/O Unit for which duplicate refreshing was executed.	Read-only	

I/O Information

Name	Address	Description	Access	Updated
Too Many I/O Points Flag (fatal error)	A401.11	ON when the number of CP-series Expansion Units and Expansion I/O Units exceeds the limit, when the number of words allocated to these Units exceeds the limit, or when too many CJ-series Units are mounted.	Read-only	
Too Many I/O Points, Details	A407.00 to A407.12	Always 0000 hex.	Read-only	
Too Many I/O Points, Cause	A407.13 to A407.15	The 3-digit binary value of these bits indicates the cause of the Too Many I/O Points Error. 010: Too many CP-series words 011: Too many CP-series Units 111: Too many CJ-series Units	Read-only	
I/O Bus Error Flag (fatal error)	A401.14	ON in the following cases: <ul style="list-style-type: none"> When an error occurs in a data transfer between the CPU Unit and a CP-series Expansion Unit or Expansion I/O Unit. If this happens, 0A0A hex will be output to A404. When an error occurs in a data transfer between the CPU Unit and a CJ-series Unit. If this happens, 0000 hex will be output to A404 to indicate the first Unit, 0001 hex to indicate the second Unit, and 0F0F hex to indicate an undetermined Unit. When the End Cover is not attached to the last CJ-series Unit. If this happens, 0E0E hex will be output to A404. CPU Unit operation will stop and the ERR/ALM indicator on the front of the CPU Unit will light. (This flag will be turned OFF when the error is cleared.)	Read-only	
I/O Bus Error Slot Number	A404	Contains information on I/O bus errors. The CPU Unit will stop operating and the ERR/ALM indicator on the front of the CPU Unit will light. (A401.04 (I/O Bus Error Flag) will turn ON.) (This information will be cleared when the error is cleared.) 0A0A hex: CP-series Unit error 0000 hex: CJ-series Unit error, 1st Unit 0001 hex: CJ-series Unit error, 2nd Unit 0F0F hex: CJ-series Unit error, unknown Unit 0E0E hex: CJ-series Unit error, no End cover	Read-only	

Name	Address	Description	Access	Updated
Duplication Error Flag (fatal error)	A401.13	ON in the following cases: <ul style="list-style-type: none"> Two CPU Bus Units have been assigned the same unit number. Two Special I/O Units have been assigned the same unit number. 	Read-only	
CP-series Unit Error Flags	A436.00 to A436.06	ON when an error occurs in a CP-series Expansion Unit or Expansion I/O Unit. A436.00: 1st Unit A436.10: 2nd Unit A436.02: 3rd Unit A436.03: 4th Unit A436.04: 5th Unit A436.05: 6th Unit A436.06: 7th Unit Note CP1W-TS002 and CP1W-TS102 are each counted as two Units.	Read-only	
Number of Connected CP-series Units	A437	Stores the number of CP-series Expansion Units and Expansion I/O Units connected as a hexadecimal number. Note This information is valid only when a Too Many I/O Points error has occurred. CP1W-TS002 and CP1W-TS102 are each counted as two Units.	Read-only	

CPU Bus Unit Information

Name	Address	Description	Access	Updated
CPU Bus Unit Number Duplication Flags	A410.00 to A410.15	The Duplication Error Flag (A401.13) and the corresponding flag in A410 will be turned ON when a CPU Bus Unit's unit number has been duplicated. Bits 00 to 15 correspond to unit numbers 0 to F.	Read-only	
CPU Bus Unit Error, Unit Number Flags	A417.00 to A417.15	When an error occurs in a data exchange between the CPU Unit and a CPU Bus Unit, the CPU Bus Unit Error Flag (A402.07) is turned ON and the bit in A417 corresponding to the unit number of the Unit where the error occurred is turned ON. Bits 00 to 15 correspond to unit numbers 0 to F.	Read-only	
CPU Bus Unit Error Flag (non-fatal error)	A402.07	ON when an error occurs in a data exchange between the CPU Unit and a CPU Bus Unit (including an error in the CPU Bus Unit itself).	Read-only	

Special I/O Unit Information

Name	Address	Description	Access	Updated
Special I/O Unit Number Duplication Flags	A411.00 to A416.15	The Duplication Error Flag (A401.13) and the corresponding flag in A411 through A416 will be turned ON when a Special I/O Unit's unit number has been duplicated. Bits A411.00 to A416.15 correspond to unit numbers 000 to 05F (0 to 95).	Read-only	
Special I/O Unit Setting Error Flag (non-fatal error)	A402.06	ON when an error occurs in a data exchange between the CPU Unit and a Special I/O Unit (including an error in the Special I/O Unit itself).	Read-only	
Special I/O Unit Error, Unit Number Flags	A418.00 to A423.15	When an error occurs in a data exchange between the CPU Unit and a Special I/O Unit, the Special I/O Unit Error Flag (A402.06) will be turned ON.	Read-only	

Other PLC Operating Information

Name	Address	Description	Access	Updated
Battery Error Flag (non-fatal error)	A402.04	ON if the CPU Unit's battery is disconnected or its voltage is low and the Detect Battery Error setting has been set in the PLC Setup.	Read-only	
Cycle Time Too Long Flag (fatal error)	A401.08	ON if the cycle time exceeds the maximum cycle time set in the PLC Setup (the cycle time monitoring time).	Read-only	
FPD Teaching Bit	A598.00	Turn this bit ON to set the monitoring time automatically with the teaching function.	Read/write	
Memory Corruption Detected Flag	A395.11	ON when memory corruption is detected when the power supply is turned ON.	Read-only	

Name	Address	Description	Access	Updated
Option Board Error Flag	A315.13	ON when the Option Board is removed while the power is being supplied. CPU Unit operation will continue and the ERR/ALM indicator will flash. OFF when the error has been cleared.	Read-only	When an error occurs
Built-in Analog I/O Error Flag	A315.14	ON when a built-in analog I/O error occurs and stops the operation of built-in analog I/O. CPU Unit operation will continue and the ERR/ALM indicator will flash. OFF when the error has been cleared.	Read-only	When an error occurs
Flash Memory Error Flag	A315.15	ON when writing to the internal flash memory fails. CPU Unit operation will continue and the ERR/ALM indicator will flash. OFF when the error has been cleared.	Read-only	When an error occurs
Other Fatal Error Flag	A402.00	ON when a non-fatal error that is not defined for A402.01 to A402.15 occurs. Detailed information is output to the bits of A314. OFF: No other fatal error ON: Other fatal error	Read-only	When an error occurs

Clock

Clock Information

Name	Address	Description	Access	Updated
Clock Data	The clock data from the clock built into the CPU Unit is stored here in BCD.		Read-only	
	A351.00 to A351.07	Seconds: 00 to 59 (BCD)		
	A351.08 to A351.15	Minutes: 00 to 59 (BCD)		
	A352.00 to A352.07	Hour: 00 to 23 (BCD)		
	A352.08 to A352.15	Day of the month: 01 to 31 (BCD)		
	A353.00 to A353.07	Month: 01 to 12 (BCD)		
	A353.08 to A353.15	Year: 00 to 99 (BCD)		
	A354.00 to A354.07	Day of the week: 00: Sunday, 01: Monday, 02: Tuesday, 03: Wednesday, 04: Thursday, 05: Friday, 06: Saturday		

Note The clock data is stored in the CPU Unit as BCD.

Operation Start and End Times

Name	Address	Description	Access	Updated
Operation Start Time	A515 to A517	The time that operation started as a result of changing the operating mode to RUN or MONITOR mode is stored here in BCD. A515.00 to A515.07: Seconds (00 to 59) A515.08 to A515.15: Minutes (00 to 59) A516.00 to A516.07: Hour (00 to 23) A516.08 to A516.15: Day of month (01 to 31) A517.00 to A517.07: Month (01 to 12) A517.08 to A517.15: Year (00 to 99) Note The previous start time is stored after turning ON the power supply until operation is started.	Read/write	
Operation End Time	A518 to A520	The time that operation stopped as a result of changing the operating mode to PROGRAM mode is stored here in BCD. A518.00 to A518.07: Seconds (00 to 59) A518.08 to A518.15: Minutes (01 to 59) A519.00 to A519.07: Hour (00 to 23) A519.08 to A519.15: Day of month (01 to 31) A520.00 to A520.07: Month (01 to 12) A520.08 to A520.15: Year (00 to 99) Note If an error occurs in operation, the time of the error will be stored. If the operating mode is then changed to PROGRAM mode, the time that PROGRAM mode was entered will be stored.	Read/write	

Power Supply Information

Name	Address	Description	Access	Updated
Startup Time	A510 and A511	These words contain the time at which the power was turned ON. The contents are updated every time that the power is turned ON. The data is stored in BCD. A510.00 to A510.07: Second (00 to 59) A510.08 to A510.15: Minute (00 to 59) A511.00 to A511.07: Hour (00 to 23) A511.08 to A511.15: Day of month (01 to 31)	Read/write	
Power Interruption Time	A512 and A513	These words contain the time at which the power was interrupted. The contents are updated every time that the power is interrupted. The data is stored in BCD. A512.00 to A512.07: Second (00 to 59) A512.08 to A512.15: Minute (00 to 59) A513.00 to A513.07: Hour (00 to 23) A513.08 to A513.15: Day of month (01 to 31) (These words are not cleared at startup.)	Read/write	
Number of Power Interruptions	A514	Contains the number of times that power has been interrupted since the power was first turned ON. The data is stored in binary. To reset this value, overwrite the current value with 0000.	Read/write	
Total Power ON Time	A523	Contains the total time that the PLC has been ON in 10-hour units. The data is stored in binary and it is updated every 10 hours. To reset this value, overwrite the current value with 0000.	Read/write	

Flash Memory Backup Information

Name	Address	Description	Access	Updated
User Program Date	A90 to A93	These words contain in BCD the date and time that the user program was last overwritten. A90.00 to A90.07: Seconds (00 to 59) A90.08 to A90.15: Minutes (00 to 59) A91.00 to A91.07: Hour (00 to 23) A91.08 to A91.15: Day of month (01 to 31) A92.00 to A92.07: Month (01 to 12) A92.08 to A92.15: Year (00 to 99) A93.00 to A93.07: Day of the week (00 to 06) (00: Sunday, 01: Monday, 02: Tuesday, 03: Wednesday, 04: Thursday, 05: Friday, 06: Saturday)	Read-only	
Parameter Date	A94 to A97	These words contain in BCD the date and time that the parameters were last overwritten. A94.00 to A94.07: Seconds (00 to 59) A94.08 to A94.15: Minutes (00 to 59) A95.00 to A95.07: Hour (00 to 23) A95.08 to A95.15: Day of month (01 to 31) A96.00 to A96.07: Month (01 to 12) A96.08 to A96.15: Year (00 to 99) A97.00 to A97.07: Day of the week (00 to 06) (00: Sunday, 01: Monday, 02: Tuesday, 03: Wednesday, 04: Thursday, 05: Friday, 06: Saturday)	Read-only	

Memory Cassette Information

Name	Address	Description	Access	Updated
Memory Cassette Access Status	A342	<p>A342.03: ON when data is being written to the Memory Cassette or the Memory Cassette is being initialized. OFF when processing has been completed.</p> <p>A342.04: ON when data is being read from the Memory Cassette. OFF when processing has been completed.</p> <p>A342.05: ON when data is being compared with data on the Memory Cassette. OFF when processing has been completed.</p> <p>A342.07: ON when an error occurs in initializing the Memory Cassette. OFF the next time the Memory Cassette is accessed normally (initialized, written, read, or compared).</p> <p>A342.08: ON when an error occurs in writing the Memory Cassette. OFF the next time the Memory Cassette is accessed normally (initialized, written, read, or compared).</p> <p>A342.10: ON when an error occurs in reading or comparing the Memory Cassette. OFF the next time the Memory Cassette is accessed normally (initialized, written, read, or compared).</p> <p>A342.12: ON when the data in the CPU Unit is not the same as the data in the Memory Cassette when a verification operation is performed. OFF the next time the Memory Cassette is accessed normally (initialized, written, read, or compared).</p> <p>A342.13: ON when the Memory Cassette is being accessed. OFF when processing has been completed.</p> <p>A342.15: ON when a Memory Cassette is mounted. OFF when a Memory Cassette is not mounted.</p>	Read-only	
Memory Cassette Verification Results	A494	<p>Stores the results of comparing data in the Memory Cassette and CPU Unit. Each bit turns ON to indicate status.</p> <p>A494.00: User program is different.</p> <p>A494.01: Function block sources are different.</p> <p>A494.02: Parameter area is different.</p> <p>A494.03: Symbol table is different.</p> <p>A494.04: Comments are different.</p> <p>A494.05: Program indices are different.</p> <p>A494.06: Data memory is different.</p> <p>A494.07: DM initial values are different.</p>	Read-only	

Information on Read Protection Using a Password

Name	Address	Description	Access	Updated
UM Read Protection Flag	A99.00	<p>Indicates whether the entire user program in the PLC is read-protected.</p> <p>OFF: UM not read-protected.</p> <p>ON: UM read-protected.</p>	Read-only	
Task Read Protection Flag	A99.01	<p>Indicates whether read protection is set for individual tasks.</p> <p>OFF: Tasks not read-protected.</p> <p>ON: Tasks read-protected.</p>	Read-only	
Program Write Protection for Read Protection	A99.02	<p>Indicates whether the program is write-protected.</p> <p>OFF: Write-enabled.</p> <p>ON: Write-protected.</p>	Read-only	
Enable/Disable Bit for Program Backup	A99.03	<p>Indicates whether creating a backup program file (.OBJ) is enabled or disabled.</p> <p>OFF: Enabled.</p> <p>ON: Disabled.</p>	Read-only	

Communications

Networks

Network Communications Information

Name	Address	Description	Access	Updated
Communications Port Enabled Flags	A202.00 to A202.07	ON when a network instruction or background execution can be executed with the corresponding port number. Bits 00 to 07 correspond to communications ports 0 to 7.	Read-only	
Communications Port Completion Codes	A203 to A210	These words contain the completion codes for the corresponding port numbers when network instructions have been executed. The corresponding word will be cleared when background execution has been completed. Words A203 to A210 correspond to communications ports 0 to 7.	Read-only	
Communications Port Error Flags	A219.00 to A219.07	ON when an error occurred during execution of a network instruction. OFF when a normal response is returned. Bits 00 to 07 correspond to communications ports 0 to 7.	Read-only	

Information When Automatically Allocating Communications Ports

Name	Address	Description	Access	Updated
Network Communications Port Allocation Enabled Flag	A202.15	ON when there is a communications port available for automatic allocation. Note Use this flag to confirm whether a communications port is available for automatic allocation before executing communications instructions when using 9 or more communications instructions simultaneously.	Read-only	
First Cycle Flags after Network Communications Finished	A214.00 to A214.07	Each flag will turn ON for just one cycle after communications have been completed. Bits 00 to 07 correspond to ports 0 to 7. Use the Used Communications Port Number stored in A218 to determine which flag to access. Note These flags are not effective until the next cycle after the communications instruction is executed. Delay accessing them for at least one cycle.	Read-only	
First Cycle Flags after Network Communications Error	A215.00 to A215.07	Each flag will turn ON for just one cycle after a communications error occurs. Bits 00 to 07 correspond to ports 0 to 7. Use the Used Communications Port Number stored in A218 to determine which flag to access. Determine the cause of the error according to the Communications Port Completion Codes stored in A203 to A210. Note These flags are not effective until the next cycle after the communications instruction is executed. Delay accessing them for at least one cycle.	Read-only	
Network Communications Completion Code Storage Address	A216 to A217	The completion code for a communications instruction is automatically stored at the address with the I/O memory address given in these words. Place this address into an index register and use indirect addressing through the index register to read the communications completion code.	Read-only	
Used Communications Port Numbers	A218	Stores the communications port numbers used when a communications instruction is executed using automatic communication port allocations. 0000 to 0007 hex: Communications port 0 to 7	Read-only	

Information on Explicit Message Instructions

Name	Address	Description	Access	Updated
Explicit Communications Error Flag	A213.00 to A213.07	Turn ON when an error occurs in executing an Explicit Message Instruction (EXPLT, EGATR, ESATR, ECHRD, or ECHWR). Bits 00 to 07 correspond to communications ports 0 to 7. The corresponding bit will turn ON both when the explicit message cannot be sent and when an error response is returned for the explicit message. The status will be maintained until the next explicit message communication is executed. The bit will always turn OFF when the next Explicit Message Instruction is executed.	Read-only	
Network Communications Error Flag	A219.00 to A219.07	ON when an error occurred during execution of a network instruction (SEND, RECV, CMND, or PMCR). Bits 00 to 07 correspond to communications ports 0 to 7. The ON status is retained until the next network instruction is executed.	Read-only	
Network Communications Response Code	A203 to A210	These words contain the completion codes for the corresponding port numbers when network instructions (SEND, RECV, CMND, or PMCR) have been executed. (The corresponding word will be cleared when background execution has been completed.) Words A203 to A210 correspond to communications ports 0 to 7. If the Explicit Communications Error Flag turns OFF, 0000 hex is stored. If the Explicit Communications Error Flag is ON and the Network Communications Error Flag is ON, the FINS end code is stored. If the Explicit Communications Error Flag is ON and the Network Communications Error Flag is OFF, the explicit message end code is stored. During communications, 0000 hex will be stored and the suitable code will be stored when execution has been completed. The code will be cleared when operation is started.	Read-only	

Serial Port 1 Information

Name	Address	Description	Access	Updated
Peripheral Port Communications Error Flag	A392.12	ON when a communications error has occurred at the serial port 1.	Read-only	
Peripheral Port Restart Bit	A526.01	Turn this bit ON to restart the serial port 1.	Read/write	
Peripheral Port Settings Change Bit	A619.01	ON while the serial port 1's communications settings are being changed.	Read/write	
Peripheral Port Error Flags	A528.08 to A528.15	These flags indicate what kind of error has occurred at the serial port 1.	Read/write	
Serial Port 1 Send Ready Flag (No-protocol Mode)	A392.13	ON when the serial port 1 is able to send data in no-protocol mode.	Read-only	
Serial Port 1 Reception Completed Flag (No-protocol Mode)	A392.14	ON when the serial port 1 has completed the reception in no-protocol mode.	Read-only	
Serial Port 1 Reception Overflow Flag (No-protocol Mode)	A392.15	ON when a data overflow occurred during reception through the serial port 1 in no-protocol mode.	Read-only	
Peripheral Port PT Communications Flags	A394.00 to A394.07	The corresponding bit will be ON when the serial port 1 is communicating with a PT in NT link mode. Bits 0 to 7 correspond to units 0 to 7.	Read-only	
Peripheral Port PT Priority Registered Flags	A394.08 to A394.15	The corresponding bit will be ON for the PT that has priority when the serial port 1 is communicating in NT link mode.	Read-only	
Serial Port 1 Reception Counter (No-protocol Mode)	A394.00 to A394.15	Indicates (in binary) the number of bytes of data received when serial port 1 is in no-protocol mode.	Read-only	

Serial Port 2 Information

Name	Address	Description	Access	Updated
RS-232C Port Communications Error Flag	A392.04	ON when a communications error has occurred at the serial port 2.	Read-only	
RS-232C Port Restart Bit	A526.00	Turn this bit ON to restart the serial port 2.	Read/write	
RS-232C Port Settings Change Bit	A619.02	ON while the serial port 2's communications settings are being changed.	Read/write	
RS-232C Port Error Flags	A528.00 to A528.07	These flags indicate what kind of error has occurred at the serial port 2.	Read/write	
RS-232C Port Send Ready Flag (No-protocol mode)	A392.05	ON when the serial port 2 is able to send data in no-protocol mode.	Read-only	
RS-232C Port Reception Completed Flag (No-protocol Mode)	A392.06	ON when the serial port 2 has completed the reception in no-protocol mode.	Read-only	
RS-232C Port Reception Overflow Flag (No-protocol mode)	A392.07	ON when a data overflow occurred during reception through the serial port 2 in no-protocol mode.	Read-only	
RS-232C Port PT Communications Flags	A393.00 to A393.07	The corresponding bit will be ON when the serial port 2 is communicating with a PT in NT link mode. Bits 0 to 7 correspond to units 0 to 7.	Read-only	
RS-232C Port PT Priority Registered Flags	A393.08 to A393.15	The corresponding bit will be ON for the PT that has priority when the serial port 2 is communicating in NT link mode.	Read-only	
RS-232C Port Reception Counter (No-protocol Mode)	A393.00 to A393.15	Indicates (in binary) the number of bytes of data received when serial port 2 is in no-protocol mode.	Read-only	

Serial Device Information

Name	Address	Description	Access	Updated
Communications Unit, Port Settings Changing Flags (Units 0 to 15, ports 1 to 4)	A620.01 to A635.04	The corresponding flag will be ON when the settings for that port are being changed.	Read/write	

Modbus-RTU Easy Master Information

Name	Address	Description	Access	Updated
Serial Port 1 Modbus-RTU Master Execution Bit	A641.00	Turn ON this bit to send a command and receive a response for serial port 1 using the Modbus-RTU easy master function. This bit will be turned OFF automatically by the system when communications have been completed. Turned ON: Execution started ON: Execution in progress. OFF: Not executed or execution completed.	Read-only	
Serial Port 1 Modbus-RTU Master Execution Normal Flag	A641.01	ON when one command has been sent and the response received for serial port 1 using the Modbus-RTU easy master function. ON: Execution normal. OFF: Execution error or still in progress.	Read-only	
Serial Port 1 Modbus-RTU Master Execution Error Flag	A641.02	ON when an error has occurred in communications for serial port 1 using the Modbus-RTU easy master function. The error code is output to D32352 in the DM fixed allocation words for Modbus-RTU Easy Master. ON: Execution error. OFF: Execution normal or still in progress.	Read-only	
Serial Port 2 Modbus-RTU Master Execution Bit	A640.00	Turn ON this bit to send a command and receive a response for serial port 2 using the Modbus-RTU easy master function. This bit will be turned OFF automatically by the system when communications have been completed. Turned ON: Execution started ON: Execution in progress. OFF: Not executed or execution completed.	Read-only	
Serial Port 2 Modbus-RTU Master Execution Normal Flag	A640.01	ON when one command has been sent and the response received for serial port 2 using the Modbus-RTU easy master function. ON: Execution normal. OFF: Execution error or still in progress.	Read-only	
Serial Port 2 Modbus-RTU Master Execution Error Flag	A640.02	ON when an error has occurred in communications for serial port 2 using the Modbus-RTU easy master function. The error code is output to D32252 in the DM fixed allocation words for Modbus-RTU Easy Master. ON: Execution error. OFF: Execution normal or still in progress.	Read-only	

Note DM fixed allocation words for Modbus-RTU Easy Master for serial port 1: D32200 to D32299
DM fixed allocation words for Modbus-RTU Easy Master for serial port 2: D32300 to D32399

Instruction-related Information

Name	Address	Description	Access	Updated
Step Flag	A200.12	ON for one cycle when step execution is started with STEP(008).	Read-only	
Macro Area Input Words	A600 to A603	Before the subroutine specified in MCRO(099) is executed, the source words for the subroutine are transferred to A600 through A603 (input parameter words).	Read/write	
Macro Area Output Words	A604 to A607	After the subroutine specified in MCRO(099) has been executed, the results of the subroutine are transferred from A604 through A607 to the specified destination words (output parameter words).	Read/write	

Background Execution Information

Name	Address	Description	Access	Updated
DR00 Output for Background Execution	A597	When a data register is specified as the output for an instruction processed in the background, A597 receives the output instead of DR00. 0000 to FFFF hex	Read-only	
IR00 Output for Background Execution	A595 and A596	When an index register is specified as the output for an instruction processed in the background, A595 and A596 receive the output instead of IR00. 0000 0000 to FFFF FFFF hex (A595: Rightmost digits, A596: Leftmost digits)	Read-only	

Name	Address	Description	Access	Updated
Equals Flag for Background Execution	A598.01	Turns ON if matching data is found for an SRCH(181) instruction executed in the background.	Read-only	
ER/AER Flag for Background Execution	A395.10	ON when an instruction processing error or an illegal area access error occurs during background processing. OFF (0) when background processing starts or power is turned ON.	Read-only	

Function Block Information

Function Block Memory Information

Name	Address	Description	Access	Updated
FB Program Data Flag	A345.00	Turns ON if the FB program memory contains FB program data. OFF: No data ON: Data present	Read-only	

OMRON FB Library Information

Name	Address	Description	Access	Updated
FB Communications Instruction Response Required	A580.15	0: Not required 1: Required	Read-only	
FB Communications Instruction Port No.	A580.08 to A580.11	0 to 7 hex: Communications port No. 0 to 7 F hex: Automatic allocation	Read-only	
FB Communications Instruction Retries	A580.00 to A580.03	Automatically stores the number of retries in the FB communications instruction settings specified in the PLC Setup.	Read-only	
FB Communications Instruction Response Monitoring Time	A581	Automatically stores the FB communications instruction response monitoring time set in the PLC Setup. 0001 to FFFF hex (Unit: 0.1 s; Range: 0.1 to 6553.5) 0000 hex: 2 s	Read-only	
FB DeviceNet Communications Instruction Response Monitoring Time	A582	Automatically stores the FB DeviceNet communications instruction response monitoring time set in the PLC Setup. 0001 to FFFF hex (Unit: 0.1 s; Range: 0.1 to 6553.5) 0000 hex: 2 s	Read-only	

Note These Auxiliary Area bits/words are not to be written by the user. The number of resends and response monitoring time must be set by the user in the FB communications instructions settings in the PLC Setup, particularly when using function blocks from the OMRON FB Library to execute FINS messages or DeviceNet explicit messages communications. The values set in the Settings for OMRON FB Library in the PLC Setup will be automatically stored in the related Auxiliary Area words A580 to A582 and used by the function blocks from the OMRON FB Library.

Ethernet Option Board Flag

System Settings Reset

Name	Address	Description	Access	Updated
Ethernet Option Board Reset Flag	A525.00 to A525.01	If the flag turns ON, the Ethernet Option Board mounted on the corresponding option board slot will reset the system settings to default values.	Read/write	

Unit Restart

Name	Address	Description	Access	Updated
Ethernet Option Board Restart Flag	A525.08 to A525.09	If the flag turns ON, the Ethernet Option Board mounted on the corresponding option board slot will be restarted.	Read/write	

Appendix D

Auxiliary Area Allocations by Address

Read-only Area (Set by System)

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A0	---	10-ms Incrementing Free Running Timer	<p>This word contains the system timer used after the power is turned ON.</p> <p>A value of 0000 hex is set when the power is turned ON and this value is automatically incremented by 1 every 10 ms. The value returns to 0000 hex after reaching FFFF hex (655,350 ms), and then continues to be automatically incremented by 1 every 10 ms.</p> <p>Note: The timer will continue to be incremented when the operating mode is switched to RUN mode.</p> <p>Example: The interval can be counted between processing A and processing B without requiring timer instructions. This is achieved by calculating the difference between the value in A0 for processing A and the value in A0 for processing B. The interval is counted in 10 ms units.</p>	---	Retained	Cleared	Every 10 ms after power is turned ON	---
A1	---	100-ms Incrementing Free Running Timer	<p>This word contains the system timer used after the power is turned ON.</p> <p>A value of 0000 hex is set when the power is turned ON and this value is automatically incremented by 1 every 100 ms. The value returns to 0000 hex after reaching FFFF hex (6,553,500 ms), and then continues to be automatically incremented by 1 every 100 ms.</p> <p>Note: The timer will continue to be incremented when the operating mode is switched to RUN mode.</p> <p>Example: The interval can be counted between processing A and processing B without requiring timer instructions. This is achieved by calculating the difference between the value in A0 for processing A and the value in A0 for processing B. The interval is counted in 100 ms units.</p>	---	Retained	Cleared	Every 100 ms after power is turned ON	---
A90 to A93	All	User Program Date	<p>These words contain in BCD the date and time that the user program was last overwritten.</p> <p>A90.00 to A90.07: Seconds (00 to 59)</p> <p>A90.08 to A90.15: Minutes (00 to 59)</p> <p>A91.00 to A91.07: Hour (00 to 23)</p> <p>A91.08 to A91.15: Day of month (01 to 31)</p> <p>A92.00 to A92.07: Month (01 to 12)</p> <p>A92.08 to A92.15: Year (00 to 99)</p> <p>A93.00 to A93.07: Day of the week (00: Sunday, 01: Monday, 02: Tuesday, 03: Wednesday, 04: Thursday, 05: Friday, 06: Saturday)</p>	---	Retained	Retained	---	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A94 to A97	All	Parameter Date	These words contain in BCD the date and time that the parameters were last overwritten. The format is the same as above.	---	Retained	Retained	---	---
A99	A99.00	UM Read Protection Status	Indicates whether the entire user program in the PLC is read-protected.	OFF: UM not read-protected. ON: UM read-protected.	Retained	Retained	When protection is set or cleared	---
	A99.01	Task Read Protection Status	Indicates whether read protection is set for individual tasks.	OFF: Tasks not read-protected. ON: Tasks read-protected.	Retained	Retained	When protection is set or cleared	---
	A99.02	Program Write Protection Status when Read Protection Is Set	Indicates whether the program is write-protected.	OFF: Write-enabled. ON: Write-protected.	Retained	Retained	When protection is set or cleared	---
	A99.03	Enable/Disable Status for Backing Up the Program to a Memory Cassette	Indicates whether creating a backup program file (.OBJ) is enabled or disabled.	OFF: Enabled. ON: Disabled.	Retained	Retained	When protection is set or cleared	---
	A99.14	IR/DR Operation between Tasks Retained	ON when index and data registers are shared between all tasks. OFF when separate index and data registers are being used in each task.	OFF: Independent ON: Shared (default)	Retained	Retained		---
	A99.15	Timer/Counter PV Refresh Mode Flag	Indicates whether the CPU Unit is operating in BCD mode or binary mode.	OFF: BCD mode ON: Binary mode	Retained	Retained		---
A100 to A199	All	Error Log Area	When an error has occurred, the error code, error contents, and error's time and date are stored in the Error Log Area. Information on the 20 most recent errors can be stored. Each error record occupies 5 words; the function of these 5 words is as follows: 1) Error code (bits 0 to 15) 2) Error contents (bits 0 to 15) 3) Minutes (bits 8 to 15), Seconds (bits 0 to 7) 4) Day of month (bits 8 to 15), Hours (bits 0 to 7) 5) Year (bits 8 to 15), Month (bits 0 to 7) Errors generated by FAL(006) and FALS(007) will also be stored in this Error Log. The Error Log Area can be reset from the CX-Programmer. If the Error Log Area is full (20 records) and another error occurs, the oldest record in A100 to A104 will be cleared, the other 19 records are shifted down, and the new record is stored in A195 to A199.	Error code Error contents: Address of Aux. Area word with details or 0000. Seconds: 00 to 59, BCD Minutes: 00 to 59, BCD Hours: 00 to 23, BCD Day of month: 01 to 31, BCD Year: 00 to 99, BCD	Retained	Retained	Refreshed when error occurs.	A500.14 A300 A400

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A200	A200.11	First Cycle Flag	ON for one cycle after PLC operation begins (after the mode is switched from PROGRAM to RUN or MONITOR, for example).	ON for the first cycle	---	---	---	---
	A200.12	Step Flag	ON for one cycle when step execution is started with STEP(008). This flag can be used for initialization processing at the beginning of a step.	ON for the first cycle after execution of STEP(008).	Cleared	---	---	---
	A200.14	Task Started Flag	When a task switches from WAIT or INI to RUN status, this flag will be turned ON within the task for one cycle only. The only difference between this flag and A200.15 is that this flag also turns ON when the task switches from WAIT to RUN status.	ON: ON for first cycle (including transitions from WAIT and IN) OFF: Other	Cleared	Cleared	---	---
	A200.15	First Task Startup Flag	ON when a task is executed for the first time. This flag can be used to check whether the current task is being executed for the first time so that initialization processing can be performed if necessary.	ON: First execution OFF: Not executable for the first time or not being executed.	Cleared	---	---	---
A201	A201.10	Online Editing Wait Flag	ON when an online editing process is waiting. (If another online editing command is received while waiting, the other command won't be recorded and an error will occur.)	ON: Waiting for online editing OFF: Not waiting for online editing	Cleared	Cleared	---	A527
	A201.11	Online Editing Flag	ON when an online editing process is being executed.	ON: Online editing in progress OFF: Online editing not in progress	Cleared	Cleared	---	A527
A202	A202.00 to A202.07	Communications Port Enabled Flags	ON when a network instruction (SEND, RECV, CMND, or PMCR) or background execution can be executed with the corresponding port number. Bits 00 to 07 correspond to communications ports 0 to 7. When two or more network instructions are programmed with the same port number, use the corresponding flag as an execution condition to prevent the instructions from being executed simultaneously. (The flag for a given port is turned OFF while a network instruction with that port number is being executed.)	ON: Network instruction is not being executed OFF: Network instruction is being executed (port busy)	Cleared	---	---	---
	A202.15	Network Communications Port Allocation Enabled Flag	ON when there is a communications port available for automatic allocation. Note Use this flag to confirm whether a communications port is available for automatic allocation before executing communications instructions when using 9 or more communications instructions simultaneously.	ON: Port available OFF: Port not available	Cleared	---	---	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A203 to A210	All	Communications Port Completion Codes	<p>These words contain the completion codes for the corresponding port numbers when network instructions (SEND, RECV, CMND, or PMCR) have been executed. (The corresponding word will be cleared when background execution has been completed.)</p> <p>Words A203 to A210 correspond to communications ports 0 to 7.</p> <p>The following codes will be stored when an Explicit Message Instruction (EXPLT, EGATR, ESATR, ECHRD, or ECHWR) has been executed.</p> <p>If the Explicit Communications Error Flag turns OFF, 0000 hex is stored.</p> <p>If the Explicit Communications Error Flag is ON and the Network Communications Error Flag is ON, the FINS end code is stored.</p> <p>If the Explicit Communications Error Flag is ON and the Network Communications Error Flag is OFF, the explicit message end code is stored.</p> <p>During communications, 0000 hex will be stored and the suitable code will be stored when execution has been completed. The code will be cleared when operation is started. (The completion code for a given port is cleared to 0000 when a network instruction with that port number is executed.)</p>	Non-zero: Error code 0000: Normal condition	Retained	---	---	---
A213	A213.00 to A213.07	Explicit Communications Error Flag	<p>Turn ON when an error occurs in executing an Explicit Message Instruction (EXPLT, EGATR, ESATR, ECHRD, or ECHWR). Bits 00 to 07 correspond to communications ports 0 to 7.</p> <p>The corresponding bit will turn ON both when the explicit message cannot be sent and when an error response is returned for the explicit message.</p> <p>The status will be maintained until the next explicit message communication is executed. The bit will always turn OFF when the next Explicit Message Instruction is executed.</p>	ON: Error end OFF: Normal end	Retained	---	---	A219.00 to A219.07 A203 to A210
A214	A214.00 to A214.07	First Cycle Flags after Network Communications Finished	<p>Each flag will turn ON for just one cycle after communications have been completed. Bits 00 to 07 correspond to ports 0 to 7. Use the Used Communications Port Number stored in A218 to determine which flag to access.</p> <p>Note These flags are not effective until the next cycle after the communications instruction is executed. Delay accessing them for at least one cycle.</p>	ON: First cycle after communications finish only OFF: Other status			---	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A215	A215.00 to A215.07	First Cycle Flags after Network Communications Error	Each flag will turn ON for just one cycle after a communications error occurs. Bits 00 to 07 correspond to ports 0 to 7. Use the Used Communications Port Number stored in A218 to determine which flag to access. Determine the cause of the error according to the Communications Port Completion Codes stored in A203 to A210. Note These flags are not effective until the next cycle after the communications instruction is executed. Delay accessing them for at least one cycle.	ON: First cycle after communications error only OFF: Other status			---	---
A216 to A217	All	Network Communications Completion Code Storage Address	The completion code for a communications instruction is automatically stored at the address with the I/O memory address given in these words. Place this address into an index register and use indirect addressing through the index register to read the communications completion code.	I/O memory address for the network communications completion code storage			---	---
A218	All	Used Communications Port Numbers	Stores the communications port numbers used when a communications instruction is executed using automatic communication port allocations.	0000 to 0007 hex: Communications port 0 to 7			---	---
A219	A219.00 to A219.07	Communications Port Error Flags	ON when an error occurred during execution of a network instruction (SEND, RECV, CMND, or PMCR). Bits 00 to 07 correspond to communications ports 0 to 7.	ON: Error occurred OFF: Normal condition	Retained	---	---	---
A262 and A263	All	Maximum Cycle Time	These words contain the maximum cycle time since the start of PLC operation. The cycle time is recorded in 8-digit hexadecimal with the leftmost 4 digits in A263 and the rightmost 4 digits in A262.	0 to FFFFFFFF: 0 to 429,496,729.5 ms (0.1-ms units)	---	---	---	---
A264 and A265	All	Present Cycle Time	These words contain the present cycle time in 8-digit hexadecimal with the leftmost 4 digits in A265 and the rightmost 4 digits in A264.	0 to FFFFFFFF: 0 to 429,496,729.5 ms	---	---	---	---
A270 to A271	All	High-speed Counter 0 PV	Contains the PV of high-speed counter 0. A271 contains the leftmost 4 digits and A270 contains the rightmost 4 digits. The PV is cleared when operation starts.	---	---	Cleared	Refreshed each cycle during oversee process. Refreshed when PRV(881) instruction is executed.	---
A272 to A273	All	High-speed Counter 1 PV	Contains the PV of high-speed counter 1. A273 contains the leftmost 4 digits and A272 contains the rightmost 4 digits. The PV is cleared when operation starts.	---	---	Cleared	Refreshed each cycle during oversee process. Refreshed when PRV(881) instruction is executed.	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A274	A274.00	High-speed Counter 0 Range 1 Comparison Condition Met Flag	These flags indicate whether the PV is within the specified ranges when high-speed counter 0 is being operated in range-comparison mode. Cleared at beginning of operation. Cleared when range comparison table is registered. OFF: PV not in range ON: PV in range	---	---	Cleared	Refreshed each cycle during oversee process. Refreshed when PRV(881) instruction is executed.	---
	A274.01	High-speed Counter 0 Range 2 Comparison Condition Met Flag						
	A274.02	High-speed Counter 0 Range 3 Comparison Condition Met Flag						
	A274.03	High-speed Counter 0 Range 4 Comparison Condition Met Flag						
	A274.04	High-speed Counter 0 Range 5 Comparison Condition Met Flag						
	A274.05	High-speed Counter 0 Range 6 Comparison Condition Met Flag						
	A274.06	High-speed Counter 0 Range 7 Comparison Condition Met Flag						
	A274.07	High-speed Counter 0 Range 8 Comparison Condition Met Flag						
A274	A274.08	High-speed Counter 0 Comparison In-progress Flag	This flag indicates whether a comparison operation is being executed for high-speed counter 0. Cleared at beginning of operation. OFF: Stopped. ON: Being executed.	---	---	Cleared	Refreshed when comparison operation starts or stops.	---
	A274.09	High-speed Counter 0 Overflow/Underflow Flag	This flag indicates when an overflow or underflow has occurred in the high-speed counter 0 PV. (Used with the linear mode counting range only.) Cleared when operation starts. Cleared when PV is changed. OFF: Normal ON: Overflow or underflow	---	---	Cleared	Refreshed when an overflow or underflow occurs.	---
	A274.10	High-speed Counter 0 Count Direction	This flag indicates whether the high-speed counter is currently being incremented or decremented. The counter PV for the current cycle is compared with the PLC in last cycle to determine the direction. OFF: Decrementing ON: Incrementing	---	---	Cleared	Setting used for high-speed counter, valid during counter operation.	Read only

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A275	A275.00	High-speed Counter 1 Range 1 Comparison Condition Met Flag	These flags indicate whether the PV is within the specified ranges when high-speed counter 1 is being operated in range-comparison mode. Cleared when operation starts. Cleared when range comparison table is registered. OFF: PV not in range ON: PV in range	---	---	Cleared	Refreshed each cycle during overseeing process. Refreshed when PRV(881) instruction is executed for the corresponding counter.	---
	A275.01	High-speed Counter 1 Range 2 Comparison Condition Met Flag						
	A275.02	High-speed Counter 1 Range 3 Comparison Condition Met Flag						
	A275.03	High-speed Counter 1 Range 4 Comparison Condition Met Flag						
	A275.04	High-speed Counter 1 Range 5 Comparison Condition Met Flag						
	A275.05	High-speed Counter 1 Range 6 Comparison Condition Met Flag						
	A275.06	High-speed Counter 1 Range 7 Comparison Condition Met Flag						
	A275.07	High-speed Counter 1 Range 8 Comparison Condition Met Flag						
	A275.08	High-speed Counter 1 Comparison In-progress Flag	This flag indicates whether a comparison operation is being executed for high-speed counter 1. Cleared when operation starts. OFF: Stopped. ON: Being executed	---	---	Cleared	Refreshed when comparison operation starts or stops.	---
A275	A275.09	High-speed Counter 1 Overflow/Underflow Flag	This flag indicates when an overflow or underflow has occurred in the high-speed counter 1 PV. (Used with the linear mode counting range only.) Cleared when operation starts. Cleared when the PV is changed. OFF: Normal ON: Overflow or underflow	---	---	Cleared	Refreshed when an overflow or underflow occurs.	---
	A275.10	High-speed Counter 1 Count Direction	This flag indicates whether the high-speed counter is currently being incremented or decremented. The counter PV for the current cycle is compared with the PC in last cycle to determine the direction. OFF: Decrementing ON: Incrementing	---	---	Cleared	Setting used for high-speed counter, valid during counter operation.	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A276 and A277	All	Pulse Output 0 PV	Contain the number of pulses output from the corresponding pulse output port.	---	---	Cleared	Refreshed each cycle during oversee process.	---
A278 and A279	All	Pulse Output 1 PV	PV range: 80000000 to 7FFFFFFF hex (-2,147,483,648 to 2,147,483,647) When pulses are being output in the CW direction, the PV is incremented by 1 for each pulse. When pulses are being output in the CCW direction, the PV is decremented by 1 for each pulse. PV after overflow: 7FFFFFFF hex PV after underflow: 80000000 hex A277 contains the leftmost 4 digits and A276 contains the rightmost 4 digits of the pulse output 0 PV. A279 contains the leftmost 4 digits and A278 contains the rightmost 4 digits of the pulse output 1 PV. Cleared when operation starts. Note If the coordinate system is relative coordinates (undefined origin), the PV will be cleared to 0 when a pulse output starts, i.e. when a pulse output instruction (SPED(885), ACC(888), or PLS2(887)) is executed.			Cleared	Refreshed when the INI(880) instruction is executed (PV change).	---
A280	A280.00	Pulse Output 0 Accel/Decel Flag	This flag will be ON when pulses are being output from pulse output 0 according to an ACC(888) or PLS2(887) instruction and the output frequency is being changed in steps (accelerating or decelerating). Cleared when operation starts or stops. OFF: Constant speed ON: Accelerating or decelerating	---	---	Cleared	Refreshed each cycle during oversee process.	---
	A280.01	Pulse Output 0 Overflow/Underflow Flag	This flag indicates when an overflow or underflow has occurred in the pulse output 0 PV. Cleared when operation starts. OFF: Normal ON: Overflow or underflow			Cleared	Cleared when the PV is changed by the INI(880) instruction. Refreshed when an overflow or underflow occurs.	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A280	A280.02	Pulse Output 0 Output Amount Set Flag	ON when the number of output pulses for pulse output 0 has been set with the PULS(886) instruction. Cleared when operation starts or stops. OFF: No setting ON: Setting made	---	---	Cleared	Refreshed when the PULS(886) instruction is executed. Refreshed when pulse output stops.	---
	A280.03	Pulse Output 0 Output Completed Flag	ON when the number of output pulses set with the PULS(886) or PLS2(887) instruction has been output through pulse output 0. Cleared when operation starts or stops. OFF: Output not completed. ON: Output completed.	---	---	Cleared	Refreshed at the start or completion of pulse output in independent mode.	---
	A280.04	Pulse Output 0 Output In-progress Flag	ON when pulses are being output from pulse output 0. Cleared when operation starts or stops. OFF: Stopped ON: Outputting pulses.	---	---	Cleared	Refreshed when pulse output starts or stops.	---
	A280.05	Pulse Output 0 No-origin Flag	ON when the origin has not been determined for pulse output 0 and goes OFF when the origin has been determined. Turned ON when power is turned ON. Turned ON when operation starts. OFF: Origin established. ON: Origin not established.	---	---	Cleared	Refreshed each cycle during the overseeing processes.	---
	A280.06	Pulse Output 0 At-origin Flag	ON when the pulse output PV matches the origin (0). OFF: Not stopped at origin. ON: Stopped at origin.	---	---	Cleared	Refreshed each cycle during the overseeing processes.	---
	A280.07	Pulse Output 0 Output Stopped Error Flag	ON when an error occurred while outputting pulses in the pulse output 0 origin search function. The Pulse Output 0 Output Stop Error code will be written to A444. OFF: No error ON: Stop error occurred.	---	---	Cleared	Refreshed when origin search starts. Refreshed when a pulse output stop error occurs.	---
A281	A281.00	Pulse Output 1 Accel/Decel Flag	This flag will be ON when pulses are being output from pulse output 1 according to an ACC(888) or PLS2(887) instruction and the output frequency is being changed in steps (accelerating or decelerating). Cleared when operation starts or stops. OFF: Constant speed ON: Accelerating or decelerating	---	---	Cleared	Refreshed each cycle during oversee process.	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A281	A281.01	Pulse Output 1 Overflow/Underflow Flag	This flag indicates when an overflow or underflow has occurred in the pulse output 1 PV. Cleared when operation starts. OFF: Normal ON: Overflow or underflow	---	---	Cleared	Refreshed when the PV is changed by the INI(880) instruction. Refreshed when an overflow or underflow occurs.	---
	A281.02	Pulse Output 1 Output Amount Set Flag	ON when the number of output pulses for pulse output 1 has been set with the PULS(886) instruction. Cleared when operation starts or stops. OFF: No setting ON: Setting made	---	---	Cleared	Refreshed when the PULS(886) instruction is executed.	---
	A281.03	Pulse Output 1 Output Completed Flag	ON when the number of output pulses set with the PULS(886) or PLS2(887) instruction has been output through pulse output 1. Cleared when operation starts or stops. OFF: Output not completed. ON: Output completed.	---	---	Cleared	Refreshed when PULS(886) (886) instruction is executed. Refreshed at the start or completion of pulse output.	---
	A281.04	Pulse Output 1 Output In-progress Flag	ON when pulses are being output from pulse output 1. Cleared when operation starts or stops. OFF: Stopped ON: Outputting pulses.	---	---	Cleared	Refreshed when pulse output starts or stops.	---
	A281.05	Pulse Output 1 No-origin Flag	ON when the origin has not been determined for pulse output 1 and goes OFF when the origin has been determined. Turned ON when power is turned ON. Turned ON when operation starts. OFF: Origin established. ON: Origin not established.	---	---	Cleared	Refreshed each cycle during overseeing processes.	---
	A281.06	Pulse Output 1 At-origin Flag	ON when the pulse output PV matches the origin (0). OFF: Not stopped at origin. ON: Stopped at origin.	---	---	Cleared	Refreshed each cycle during overseeing processes.	---
	A281.07	Pulse Output 1 Output Stopped Error Flag	ON when an error occurred while outputting pulses in the pulse output 1 origin search function. The Pulse Output 1 Output Stop Error code will be written to A445. OFF: No error ON: Stop error occurred.	---	---	Cleared	Refreshed when origin search starts. Refreshed when pulse output stop error occurs.	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A283	A283.00	PWM Output 0 Output In-progress Flag	ON when pulses are being output from PWM output 0. Cleared when operation starts or stops. OFF: Stopped ON: Outputting pulses.	---	---	Cleared	Refreshed when pulse output starts or stops.	---
	A283.08	PWM Output 1 Output In-progress Flag	ON when pulses are being output from PWM output 1. OFF: Stopped ON: Outputting pulses.	---	---	Cleared		---
A294	All	Task Number when Program Stopped	This word contains the task number of the task that was being executed when program execution was stopped because of a program error. (A298 and A299 contain the program address where program execution was stopped.)	Normal tasks: 0000 to 001F (task 0 to 31) Interrupt tasks: 8000 to 80FF (task 0 to 255)	Cleared	Cleared	When program error occurs.	A298/A299
A295	A295.08	Instruction Processing Error Flag	This flag and the Error Flag (ER) will be turned ON when an instruction processing error has occurred and the PLC Setup has been set to stop operation for an instruction error. CPU Unit operation will stop and the ERR/ALM indicator will light when this flag goes ON. (The task number where the error occurred will be stored in A294 and the program address will be stored in A298 and A299.)	ON: Error Flag ON OFF: Error Flag OFF	Cleared	Cleared	When program error occurs.	A294, A298/A299 PLC Setup (Operation when instruction error has occurred)
	A295.09	Indirect DM BCD Error Flag	This flag and the Access Error Flag (AER) will be turned ON when an indirect DM BCD error has occurred and the PLC Setup has been set to stop operation an indirect DM BCD error. (This error occurs when the content of an indirectly addressed DM word is not BCD although BCD mode has been selected.) CPU Unit operation will stop and the ERR/ALM indicator will light when this flag goes ON. (The task number where the error occurred will be stored in A294 and the program address will be stored in A298 and A299.)	ON: Not BCD OFF: Normal	Cleared	Cleared	When program error occurs.	A294, A298/A299 PLC Setup (Operation when instruction error has occurred)
	A295.10	Illegal Access Error Flag	This flag and the Access Error Flag (AER) will be turned ON when an illegal access error has occurred and the PLC Setup has been set to stop operation an illegal access error. (This error occurs when a region of memory is accessed illegally.) CPU Unit operation will stop and the ERR/ALM indicator will light when this flag goes ON. The following operations are considered illegal access: 1) Reading/writing the system area 2) Indirect DM BCD error (in BCD mode) (The task number where the error occurred will be stored in A294 and the program address will be stored in A298 and A299.)	ON: Illegal access occurred OFF: Normal condition	Cleared	Cleared	When program error occurs.	A294, A298/A299 PLC Setup (Operation when instruction error has occurred)

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A295	A295.11	No END Error Flag	ON when there isn't an END(001) instruction in each program within a task. CPU Unit operation will stop and the ERR/ALM indicator will light when this flag goes ON. (The task number where the error occurred will be stored in A294 and the program address will be stored in A298 and A299.)	ON: No END OFF: Normal condition	Cleared	Cleared	---	A294, A298/A299
	A295.12	Task Error Flag	ON when a task error has occurred. The following conditions generate a task error. There isn't even one regular task that is executable (started). There isn't a program allocated to the task. (The task number where the error occurred will be stored in A294 and the program address will be stored in A298 and A299.)	ON: Error OFF: Normal	Cleared	Cleared	---	A294, A298/A299
	A295.13	Differentiation Overflow Error Flag	The allowed value for Differentiation Flags which correspond to differentiation instructions has been exceeded. CPU Unit operation will stop and the ERR/ALM indicator will light when this flag goes ON. (The task number where the error occurred will be stored in A294 and the program address will be stored in A298 and A299.)	ON: Error OFF: Normal	Cleared	Cleared	---	A294, A298/A299
	A295.14	Illegal Instruction Error Flag	ON when a program that cannot be executed has been stored. CPU Unit operation will stop and the ERR/ALM indicator will light when this flag goes ON.	ON: Error OFF: Normal	Cleared	Cleared	---	A294, A298/A299
	A295.15	UM Overflow Error Flag	ON when the last address in UM (User Memory) has been exceeded. CPU Unit operation will stop and the ERR/ALM indicator will light when this flag goes ON.	ON: Error OFF: Normal	Cleared	Cleared	---	A294, A298/A299
A298	All	Program Address Where Program Stopped (Rightmost 4 digits)	These words contain the 8-digit binary program address of the instruction where program execution was stopped due to a program error. (A294 contains the task number of the task where program execution was stopped.)	Right 4 digits of the program address	Cleared	Cleared	---	A294
A299	All	Program Address Where Program Stopped (Leftmost 4 digits)		Left 4 digits of the program address	Cleared	Cleared	---	
A300	All	Error Log Pointer	When an error occurs, the Error Log Pointer is incremented by 1 to indicate the location where the next error record will be recorded as an offset from the beginning of the Error Log Area (A100 to A199). The Error Log Pointer can be cleared to 00 by turning A500.14 (the Error Log Reset Bit) ON. When the Error Log Pointer has reached 14 hex (20 decimal), the next record is stored in A195 to A199 when the next error occurs.	00 to 14 hexadecimal	Retained	Retained	Refreshed when error occurs.	A500.14

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A302	A302.00 to A302.15	CPU Bus Unit Initializing Flags	These flags are ON while the corresponding CPU Bus Unit is initializing after its CPU Bus Unit Restart Bit (A501.00 to A501.15) is turned ON or the power is turned ON. Bits 00 to 15 correspond to unit numbers 0 to 15. Use these flags in the program to prevent the CPU Bus Unit's refresh data from being used while the Unit is initializing. IORF(097) cannot be executed while an CPU Bus Unit is initializing. These bits are turned OFF automatically when initialization is completed.	OFF: Not initializing ON: Initializing (Reset to 0 automatically after initialization.)	Retained	Cleared	Written during initialization	A501.00 to A501.15
A310	All	Manufacturing Lot Number, Lower Digits	The manufacturing lot number is stored in 6 digits hexadecimal. X, Y, and Z in the lot number are converted to 10, 11, and 12, respectively. Examples: Lot number 01805 A310 = 0801, A311 = 0005 Lot number 30Y05 A310 = 1130, A311 = 0005	---	Retained	Retained	When the power supply is turned ON	---
A311	All	Manufacturing Lot Number, Upper Digits						
A315	A315.13	Option Board Error Flag	ON when the Option Board is removed while the power is being supplied. CPU Unit operation will continue and the ERR/ALM indicator will flash. OFF when the error has been cleared.	---	Cleared	Cleared	Refreshed when error occurs.	A402.00, A424
	A315.14	Built-in Analog I/O Error Flag	ON when a built-in analog I/O error occurs and stops the operation of built-in analog I/O. CPU Unit operation will continue and the ERR/ALM indicator will flash. OFF when the error has been cleared.	---	Cleared	Cleared	Refreshed when error occurs.	A402.00
	A315.15	Flash Memory Error Flag	ON when writing to the internal flash memory fails. CPU Unit operation will continue and the ERR/ALM indicator will flash. OFF when the error has been cleared.	---	Cleared	Cleared	Refreshed when error occurs.	A402.00
A316 to A317	All	High-speed Counter 2 PV	Contains the PV of high-speed counter 2. A317 contains the leftmost 4 digits and A316 contains the rightmost 4 digits. The PV is cleared when operation starts.	---	---	Cleared	Refreshed each cycle during oversee process.	---
A318 to A319	All	High-speed Counter 3 PV	Contains the PV of high-speed counter 3. A319 contains the leftmost 4 digits and A318 contains the rightmost 4 digits. The PV is cleared when operation starts.	---	---	Cleared	Refreshed when PRV(881) instruction is executed.	---
A320	A320.00	High-speed Counter 2 Range 1 Comparison Condition Met Flag	These flags indicate whether the PV is within the specified ranges when high-speed counter 2 is being operated in range-comparison mode. Cleared at beginning of operation. Cleared when range comparison table is registered. OFF: PV not in range ON: PV in range	---	---	Cleared	Refreshed each cycle during oversee process. Refreshed when PRV(881) instruction is executed.	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A320	A320.01	High-speed Counter 2 Range 2 Comparison Condition Met Flag	These flags indicate whether the PV is within the specified ranges when high-speed counter 2 is being operated in range-comparison mode. Cleared at beginning of operation. Cleared when range comparison table is registered. OFF: PV not in range ON: PV in range	---	---	Cleared	Refreshed each cycle during oversee process. Refreshed when PRV(881) instruction is executed.	---
	A320.02	High-speed Counter 2 Range 3 Comparison Condition Met Flag						
	A320.03	High-speed Counter 2 Range 4 Comparison Condition Met Flag						
	A320.04	High-speed Counter 2 Range 5 Comparison Condition Met Flag						
	A320.05	High-speed Counter 2 Range 6 Comparison Condition Met Flag						
	A320.06	High-speed Counter 2 Range 7 Comparison Condition Met Flag						
	A320.07	High-speed Counter 2 Range 8 Comparison Condition Met Flag						
	A320.08	High-speed Counter 2 Comparison In-progress Flag	This flag indicates whether a comparison operation is being executed for high-speed counter 2. Cleared at beginning of operation. OFF: Stopped. ON: Being executed.	---	---	Cleared	Refreshed when comparison operation starts or stops.	---
	A320.09	High-speed Counter 2 Overflow/Underflow Flag	This flag indicates when an overflow or underflow has occurred in the high-speed counter 2 PV. (Used with the linear mode counting range only.) Cleared when operation starts. Cleared when PV is changed. OFF: Normal ON: Overflow or underflow	---	---	Cleared	Refreshed when an overflow or underflow occurs.	---
	A320.10	High-speed Counter 2 Count Direction	This flag indicates whether the high-speed counter is currently being incremented or decremented. The counter PV for the current cycle is compared with the PLC in last cycle to determine the direction. OFF: Decrementing ON: Incrementing	---	---	Cleared	Setting used for high-speed counter, valid during counter operation.	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A321	A321.00	High-speed Counter 3 Range 1 Comparison Condition Met Flag	These flags indicate whether the PV is within the specified ranges when high-speed counter 3 is being operated in range-comparison mode. Cleared when operation starts. Cleared when range comparison table is registered. OFF: PV not in range ON: PV in range	---	---	Cleared	Refreshed each cycle during overseeing process. Refreshed when PRV(881) instruction is executed for the corresponding counter.	---
	A321.01	High-speed Counter 3 Range 2 Comparison Condition Met Flag						
	A321.02	High-speed Counter 3 Range 3 Comparison Condition Met Flag						
	A321.03	High-speed Counter 3 Range 4 Comparison Condition Met Flag						
	A321.04	High-speed Counter 3 Range 5 Comparison Condition Met Flag						
	A321.05	High-speed Counter 3 Range 6 Comparison Condition Met Flag						
	A321.06	High-speed Counter 3 Range 7 Comparison Condition Met Flag						
	A321.07	High-speed Counter 3 Range 8 Comparison Condition Met Flag						
	A321.08	High-speed Counter 3 Comparison In-progress Flag	This flag indicates whether a comparison operation is being executed for high-speed counter 3. Cleared when operation starts. OFF: Stopped. ON: Being executed	---	---	Cleared	Refreshed when comparison operation starts or stops.	---
	A321.09	High-speed Counter 3 Overflow/Underflow Flag	This flag indicates when an overflow or underflow has occurred in the high-speed counter 3 PV. (Used with the linear mode counting range only.) Cleared when operation starts. Cleared when the PV is changed. OFF: Normal ON: Overflow or underflow	---	---	Cleared	Refreshed when an overflow or underflow occurs.	---
	A321.10	High-speed Counter 3 Count Direction	This flag indicates whether the high-speed counter is currently being incremented or decremented. The counter PV for the current cycle is compared with the PC in last cycle to determine the direction. OFF: Decrementing ON: Incrementing	---	---	Cleared	Setting used for high-speed counter, valid during counter operation.	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A322 and A323	All	Pulse Output 2 PV	Contain the number of pulses output from the corresponding pulse output port.	---	---	Cleared	Refreshed each cycle during oversee process.	---
A324 and A325	All	Pulse Output 3 PV	PV range: 80000000 to 7FFFFFFF hex (-2,147,483,648 to 2,147,483,647) When pulses are being output in the CW direction, the PV is incremented by 1 for each pulse. When pulses are being output in the CCW direction, the PV is decremented by 1 for each pulse. PV after overflow: 7FFFFFFF hex PV after underflow: 80000000 hex A323 contains the leftmost 4 digits and A322 contains the rightmost 4 digits of the pulse output 2 PV. A325 contains the leftmost 4 digits and A324 contains the rightmost 4 digits of the pulse output 3 PV. Cleared when operation starts. Note If the coordinate system is relative coordinates (undefined origin), the PV will be cleared to 0 when a pulse output starts, i.e. when a pulse output instruction (SPED(885), ACC(888), or PLS2(887)) is executed.	---	---	Cleared	Refreshed when the INI(880) instruction is executed (PV change).	---
A326	A326.00	Pulse Output 2 Accel/Decel Flag	This flag will be ON when pulses are being output from pulse output 2 according to an ACC(888) or PLS2(887) instruction and the output frequency is being changed in steps (accelerating or decelerating). Cleared when operation starts or stops. OFF: Constant speed ON: Accelerating or decelerating	---	---	Cleared	Refreshed each cycle during oversee process.	---
	A326.01	Pulse Output 2 Overflow/Underflow Flag	This flag indicates when an overflow or underflow has occurred in the pulse output 2 PV. Cleared when operation starts. OFF: Normal ON: Overflow or underflow	---	---	Cleared	Cleared when the PV is changed by the INI(880) instruction. Refreshed when an overflow or underflow occurs.	---
	A326.02	Pulse Output 2 Output Amount Set Flag	ON when the number of output pulses for pulse output 2 has been set with the PULS(886) instruction. Cleared when operation starts or stops. OFF: No setting ON: Setting made	---	---	Cleared	Refreshed when the PULS(886) instruction is executed. Refreshed when pulse output stops.	---
	A326.03	Pulse Output 2 Output Completed Flag	ON when the number of output pulses set with the PULS(886) or PLS2(887) instruction has been output through pulse output 2. Cleared when operation starts or stops. OFF: Output not completed. ON: Output completed.	---	---	Cleared	Refreshed at the start or completion of pulse output in independent mode.	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A326	A326.04	Pulse Output 2 Output In-progress Flag	ON when pulses are being output from pulse output 2. Cleared when operation starts or stops. OFF: Stopped ON: Outputting pulses.	---	---	Cleared	Refreshed when pulse output starts or stops.	---
	A326.05	Pulse Output 2 No-origin Flag	ON when the origin has not been determined for pulse output 2 and goes OFF when the origin has been determined. Turned ON when power is turned ON. Turned ON when operation starts. OFF: Origin established. ON: Origin not established.	---	---	Cleared	Refreshed each cycle during the overseeing processes.	---
	A326.06	Pulse Output 2 At-origin Flag	ON when the pulse output PV matches the origin (0). OFF: Not stopped at origin. ON: Stopped at origin.	---	---	Cleared	Refreshed each cycle during the overseeing processes.	---
	A326.07	Pulse Output 2 Output Stopped Error Flag	ON when an error occurred while outputting pulses in the pulse output 2 origin search function. The Pulse Output 2 Output Stop Error code will be written to A444. OFF: No error ON: Stop error occurred.	---	---	Cleared	Refreshed when origin search starts. Refreshed when a pulse output stop error occurs.	---
A327	A327.00	Pulse Output 3 Accel/Decel Flag	This flag will be ON when pulses are being output from pulse output 3 according to an ACC(888) or PLS2(887) instruction and the output frequency is being changed in steps (accelerating or decelerating). Cleared when operation starts or stops. OFF: Constant speed ON: Accelerating or decelerating	---	---	Cleared	Refreshed each cycle during oversee process.	---
	A327.01	Pulse Output 3 Overflow/Underflow Flag	This flag indicates when an overflow or underflow has occurred in the pulse output 3 PV. Cleared when operation starts. OFF: Normal ON: Overflow or underflow	---	---	Cleared	Refreshed when the PV is changed by the INI(880) instruction. Refreshed when an overflow or underflow occurs.	---
	A327.02	Pulse Output 3 Output Amount Set Flag	ON when the number of output pulses for pulse output 3 has been set with the PULS(886) instruction. Cleared when operation starts or stops. OFF: No setting ON: Setting made	---	---	Cleared	Refreshed when the PULS(886) instruction is executed.	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A327	A327.03	Pulse Output 3 Output Completed Flag	ON when the number of output pulses set with the PULS(886) or PLS2(887) instruction has been output through pulse output 3. Cleared when operation starts or stops. OFF: Output not completed. ON: Output completed.	---	---	Cleared	Refreshed when PULS(886) (886) instruction is executed. Refreshed at the start or completion of pulse output.	---
	A327.04	Pulse Output 3 Output In-progress Flag	ON when pulses are being output from pulse output 3. Cleared when operation starts or stops. OFF: Stopped ON: Outputting pulses.	---	---	Cleared	Refreshed when pulse output starts or stops.	---
	A327.05	Pulse Output 3 No-origin Flag	ON when the origin has not been determined for pulse output 3 and goes OFF when the origin has been determined. Turned ON when power is turned ON. Turned ON when operation starts. OFF: Origin established. ON: Origin not established.	---	---	Cleared	Refreshed each cycle during over-seeing processes.	---
	A327.06	Pulse Output 3 At-origin Flag	ON when the pulse output PV matches the origin (0). OFF: Not stopped at origin. ON: Stopped at origin.	---	---	Cleared	Refreshed each cycle during over-seeing processes.	---
	A327.07	Pulse Output 3 Output Stopped Error Flag	ON when an error occurred while outputting pulses in the pulse output 3 origin search function. The Pulse Output 3 Output Stop Error code will be written to A445. OFF: No error ON: Stop error occurred.	---	---	Cleared	Refreshed when origin search starts. Refreshed when pulse output stop error occurs.	---
A330 to A335	A330.00 to A335.15	Special I/O Unit Initializing Flags	These flags are ON while the corresponding Special I/O Unit is initializing after its Special I/O Unit Restart Bit (A502.00 to A507.15) is turned ON or the power is turned ON. The bits in these words correspond to unit numbers 0 to 95 as follows: A330.00 to A330.15: Units 0 to 15 A331.00 to A331.15: Units 16 to 31 ---- A335.00 to A335.15: Units 80 to 95 Use these flags in the program to prevent the Special I/O Unit's refresh data from being used while the Unit is initializing. Also, IORF(097) cannot be executed while a Special I/O Unit is initializing. These bits are turned OFF automatically when initialization is completed.	OFF: Not initializing ON: Initializing (Reset to 0 automatically after initialization.)	Retained	Cleared	---	A502.00 to A507.15
A339 and A340	All	Maximum Differentiation Flag Number	These words contain the maximum value of the differentiation flag numbers being used by differentiation instructions.	---	See Function column.	Cleared	Written at the start of operation	A295.13

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A342	A342.03	Memory Cassette Write Flag	ON when data is being written to the Memory Cassette.	OFF: Not writing ON: Writing	Retained	Cleared	---	---
	A342.04	Memory Cassette Read Flag	ON when data is being read from the Memory Cassette.	OFF: Not reading ON: Reading	Retained	Cleared	---	---
	A342.05	Memory Cassette Verify Flag	ON when data is being compared with data on the Memory Cassette.	OFF: Not verifying ON: Verifying	Retained	Cleared	---	---
	A342.07	Memory Cassette Initialization Error Flag	ON when an error occurs in initializing the Memory Cassette. OFF the next time the Memory Cassette is accessed normally (initialized, written, read, or compared).	OFF: No error ON: Error	Retained	Cleared	---	---
	A342.08	Memory Cassette Write Error Flag	ON when an error occurs in writing the Memory Cassette. OFF the next time the Memory Cassette is accessed normally (initialized, written, read, or compared).	OFF: No error ON: Error	Retained	Cleared	---	---
	A342.10	Memory Cassette Read Error Flag	ON when an error occurs in reading the Memory Cassette. OFF the next time the Memory Cassette is accessed normally (initialized, written, read, or compared).	OFF: No error ON: Error	Retained	Cleared	---	---
	A342.12	Memory Cassette Mismatch Flag	ON the data in the CPU Unit is not the same as the data in the Memory Cassette when a verification operation is performed. OFF the next time the Memory Cassette is accessed normally (initialized, written, read, or compared).	OFF: Match ON: Mismatch	Retained	Cleared	---	---
	A342.13	Memory Cassette Access Flag	ON when the Memory Cassette is being accessed. OFF when access is completed.	OFF: Not being accessed ON: Being accessed		Cleared	---	---
	A342.15	Memory Cassette Flag	ON when a Memory Cassette is mounted. OFF when a Memory Cassette is not mounted.	OFF: No Memory Cassette ON: Memory Cassette mounted	Retained	Cleared	---	---
A345	A345.00	FB Program Data Flag	Turns ON if the FB program memory contains FB program data.	OFF: No data ON: Data present	Retained	Cleared	Downloading programs from CX-Programmer or Memory Cassette or clearing VM	---
	A345.01	Program Index File Flag	Turns ON when the comment memory contains a program index file.	OFF: No file ON: File present			Downloading programs from CX-Programmer or Memory Cassette	
	A345.02	Comment File Flag	Turns ON when the comment memory contains a comment file.	OFF: No file ON: File present				
	A345.03	Symbol Table File Flag	Turns ON when the comment memory contains a symbol table file.	OFF: No file ON: File present				
	A345.04	DM Initial Values Flag	ON when DM initial values are stored in the flash memory.	OFF: No values stored ON: Values stored	---	---	---	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A351 to A354	All	Calendar/ Clock Area	These words contain the CPU Unit's internal clock data in BCD. The clock can be set from the CX-Programmer such as a Programming Console, with the DATE(735) instruction, or with a FINS command (CLOCK WRITE, 0702).	---	Retained	Retained	Written every cycle	---
	A351.00 to A351.07		Seconds (00 to 59) (BCD)					
	A351.08 to A351.15		Minutes (00 to 59) (BCD)					
	A352.00 to A352.07		Hours (00 to 23) (BCD)					
	A352.08 to A352.15		Day of the month (01 to 31) (BCD)					
	A353.00 to A353.07		Month (01 to 12) (BCD)					
	A353.08 to A353.15		Year (00 to 99) (BCD)					
	A354.00 to A354.07		Day of the week (00 to 06) (BCD) 00: Sunday, 01: Monday, 02: Tuesday, 03: Wednesday, 04: Thursday, 05: Friday, 06: Saturday					
A360 to A391	A360.01 to A391.15	Executed FAL Number Flags	The flag corresponding to the specified FAL number will be turned ON when FAL(006) is executed. Bits A360.01 to A391.15 correspond to FAL numbers 001 to 511. The flag will be turned OFF when the error is cleared.	ON: That FAL was executed OFF: That FAL wasn't executed	Retained	Cleared	Refreshed when error occurs.	A402.15
A392	A392.04	Serial Port 2 Error Flag	ON when an error has occurred at the serial port 2. (Not valid in Peripheral Bus Mode or NT Link mode.)	ON: Error OFF: No error	Retained	Cleared	Refreshed when error occurs.	---
	A392.05	Serial Port 2 Send Ready Flag (No-protocol mode)	ON when the serial port 2 is able to send data in no-protocol mode.	ON: Able-to-send OFF: Unable-to-send	Retained	Cleared	Written after transmission	---
	A392.06	Serial Port 2 Reception Completed Flag (No-protocol mode)	ON when the serial port 2 has completed the reception in no-protocol mode. <ul style="list-style-type: none"> When the number of bytes was specified: ON when the specified number of bytes is received. When the end code was specified: ON when the end code is received or 256 bytes are received. 	ON: Reception completed OFF: Reception not completed	Retained	Cleared	Written after reception	---
	A392.07	Serial Port 2 Reception Overflow Flag (No-protocol mode)	ON when a data overflow occurred during reception through the serial port 2 in no-protocol mode. <ul style="list-style-type: none"> When the number of bytes was specified: ON when more data is received after the reception was completed but before RXD(235) was executed. When the end code was specified: ON when more data is received after the end code was received but before RXD(235) was executed. ON when 257 bytes are received before the end code.	ON: Overflow OFF: No overflow	Retained	Cleared	---	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A392	A392.12	Serial Port 1 Communications Error Flag	<ul style="list-style-type: none"> ON when a communications error has occurred at the serial port 1. (Not valid in Peripheral Bus Mode or NT Link mode.) ON when a timeout error, overrun error, framing error, parity error, or BCC error occurs in Serial Gateway mode. 	ON: Error OFF: No error	Retained	Cleared	---	---
	A392.13	Serial Port 1 Send Ready Flag (No-protocol Mode)	ON when the serial port 1 is able to send data in no-protocol mode.	ON: Able-to-send OFF: Unable-to-send	Retained	Cleared	Written after transmission	---
	A392.14	Serial Port 1 Reception Completed Flag (No-protocol Mode)	ON when the serial port 1 has completed the reception in no-protocol mode. <ul style="list-style-type: none"> When the number of bytes was specified: ON when the specified number of bytes is received. When the end code was specified: ON when the end code is received or 256 bytes are received. 	ON: Reception completed OFF: Reception not completed	Retained	Cleared	Written after reception	---
	A392.15	Serial Port 1 Reception Overflow Flag (No-protocol Mode)	ON when a data overflow occurred during reception through the serial port 1 in no-protocol mode. <ul style="list-style-type: none"> When the number of bytes was specified: ON when more data is received after the reception was completed but before RXD(235) was executed. When the end code was specified: ON when more data is received after the end code was received but before RXD(235) was executed. ON when 257 bytes are received before the end code. 	ON: Overflow OFF: No overflow	Retained	Cleared	---	---
A393	A393.00 to A393.07	Serial Port 2 PT Communications Flags	The corresponding bit will be ON when the serial port 2 is communicating with a PT in NT Link or Serial PLC Link mode. Bits 0 to 7 correspond to units 0 to 7.	ON: Communicating OFF: Not communicating	Retained	Cleared	Refreshed when there is a normal response to the token.	---
	A393.08 to A393.15	Serial Port 2 PT Priority Registered Flags	The corresponding bit will be ON for the PT that has priority when the serial port 2 is communicating in NT link mode. Bits 0 to 7 correspond to units 0 to 7. These flags are written when the priority registration command is received.	ON: Priority registered OFF: Priority not registered	Retained	Cleared	See <i>Function</i> column.	---
	A393.00 to A393.15	Serial Port 2 Reception Counter (No-protocol Mode)	Indicates (in binary) the number of bytes of data received when the serial port 2 is in no-protocol mode.	---	Retained	Cleared	Refreshed when data is received.	---
A394	A394.00 to A394.07	Serial Port 1 PT Communications Flags	The corresponding bit will be ON when the serial port 1 is communicating with a PT in NT link mode. Bits 0 to 7 correspond to units 0 to 7.	ON: Communicating OFF: Not communicating	Retained	Cleared	Refreshed when there is a normal response to the token.	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A394	A394.08 to A394.15	Serial Port 1 PT Priority Registered Flags	The corresponding bit will be ON for the PT that has priority when the serial port 1 is communicating in NT link mode. Bits 0 to 7 correspond to units 0 to 7. These flags are written when the priority registration command is received.	ON: Priority registered OFF: Priority not registered	Retained	Cleared	See <i>Function</i> column.	---
	A394.00 to A394.15	Serial Port 1 Reception Counter (No-protocol Mode)	Indicates (in binary) the number of bytes of data received when serial port 1 is in no-protocol mode.	---	Retained	Cleared	Refreshed when data is received.	---
A395	A395.10	ER/AER Flag for Background Execution	ON when an instruction processing error or an illegal area access error occurs during background processing.	ON: Error. OFF (0) when power is turned ON. OFF (0) when operation starts. OFF: No errors. OFF (0) when background processing starts.	Cleared	Cleared	---	---
	A395.11	Memory Corruption Detected Flag	ON when memory corruption is detected when the power supply is turned ON.	ON: Memory corruption OFF: Normal operation	Retained	See <i>Function</i> column.	Refreshed when power is turned ON.	---
	A395.12	DIP Switch Pin 6 Status Flag	The status of pin 6 on the DIP switch on the front of the CPU Unit is written to this flag every cycle.	ON: Pin 6 ON OFF: Pin 6 OFF	Retained	See <i>Function</i> column.	Written every cycle.	---
A400	All	Error code	When a non-fatal error (user-defined FALS(006) or system error) or a fatal error (user-defined FALS(007) or system error) occurs, the 4-digit hexadecimal error code is written to this word. When two or more errors occur simultaneously, the highest error code will be recorded.	---	Cleared	Cleared	Refreshed when error occurs.	---
A401	A401.00	Other Fatal Error Flag	ON when a fatal error that is not defined for A401.01 to A401.15 occurs. Detailed information is output to the bits of A314. There are no errors that affect this flag at this time. This flag is reserved by the system.	OFF: No other fatal error ON: Other fatal error	Cleared	Cleared	Refreshed when error occurs.	A314
	A401.06	FALS Error Flag (fatal error)	ON when a fatal error is generated by the FALS(006) instruction. The CPU Unit will stop operating and the ERR/ALM indicator will light. The corresponding error code will be written to A400. Error codes C101 to C2FF correspond to FALS numbers 001 to 511. This flag will be turned OFF when the FALS errors are cleared.	ON: FALS(006) executed OFF: FALS(006) not executed	Cleared	Cleared	Refreshed when error occurs.	A400
	A401.08	Cycle Time Too Long Flag (fatal error)	ON if the cycle time exceeds the maximum cycle time set in the PLC Setup (the cycle time monitoring time). CPU Unit operation will stop and the ERR/ALM indicator on the front of the CPU Unit will light. This flag will be turned OFF when the error is cleared.	OFF: Cycle time under max. ON: Cycle time over max.	Cleared	Cleared	Refreshed when the cycle time exceeds maximum.	PLC Setup (Cycle time monitoring time)

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A401	A401.09	Program Error Flag (fatal error)	ON when program contents are incorrect. CPU Unit operation will stop and the ERR/ALM indicator on the front of the CPU Unit will light. The task number where the error occurred will be stored in A294 and the program address will be stored in A298 and A299. The type of program error that occurred will be stored in A295.08 to A295.15. Refer to the description of A295 for more details on program errors. This flag will be turned OFF when the error is cleared.	ON: Error OFF: No error	Cleared	Cleared	Refreshed when error occurs.	A294, A295, A298 and A299
	A401.10	I/O Setting Error Flag (fatal error)	ON when a Basic I/O Unit or I/O Control Unit is mounted. (These Units cannot be used.) CPU Unit operation will stop and the ERR/ALM indicator on the front of the CPU Unit will light. This flag will be turned OFF when the error is cleared.	ON: Error OFF: No error	Cleared	Cleared	Refreshed when error occurs.	A405.08
	A401.11	Too Many I/O Points Flag (fatal error)	ON when the number of CP-series Expansion Units and Expansion I/O Units exceeds the limit, when the number of words allocated to these Units exceeds the limit, or when too many CJ-series Units are mounted. CPU Unit operation will stop and the ERR/ALM indicator on the front of the CPU Unit will light. This flag will be turned OFF when the error is cleared.	ON: Error OFF: No error	Cleared	Cleared	Refreshed when error occurs.	A407
	A401.13	Duplication Error Flag (fatal error)	ON in the following cases: <ul style="list-style-type: none"> Two CPU Bus Units have been assigned the same unit number. Two Special I/O Units have been assigned the same unit number. CPU Unit operation will stop and the ERR/ALM indicator on the front of the CPU Unit will light. The duplicated unit number is indicated in A409 to A416. (This flag will be turned OFF when the error is cleared.)	ON: Duplication error OFF: No duplication	Cleared	Cleared	Refreshed when error occurs.	A410 to A416

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A401	A401.14	I/O Bus Error Flag (fatal error)	<p>ON in the following cases:</p> <ul style="list-style-type: none"> When an error occurs in a data transfer between the CPU Unit and a CP-series Expansion Unit or Expansion I/O Unit. If this happens, 0A0A hex will be output to A404. When an error occurs in a data transfer between the CPU Unit and a CJ-series Unit. If this happens, 0000 hex will be output to A404 to indicate the first Unit, 0001 hex to indicate the second Unit, and 0F0F hex to indicate an undetermined Unit. When the End Cover is not attached to the last CJ-series Unit. If this happens, 0E0E hex will be output to A404. <p>CPU Unit operation will stop and the ERR/ALM indicator on the front of the CPU Unit will light. (This flag will be turned OFF when the error is cleared.)</p>	ON: Error OFF: No error	Cleared	Cleared	Refreshed when error occurs.	A404
	A401.15	Memory Error Flag (fatal error)	<p>ON when an error occurred in memory or there was an error in automatic transfer from the Memory Cassette when the power was turned ON.</p> <p>CPU Unit operation will stop and the ERR/ALM indicator on the front of the CPU Unit will light.</p> <p>The location where the error occurred is indicated in A403.00 to A403.08, and A403.09 will be turned ON if there was an error during automatic transfer at startup.</p> <p>This flag will be turned OFF when the error is cleared. (The automatic transfer at startup error cannot be cleared without turning OFF the PLC.)</p>	ON: Error OFF: No error	Cleared	Cleared	Refreshed when error occurs.	A403.00 to A403.08, A403.09
A402	A402.00	Other Fatal Error Flag	<p>ON when a non-fatal error that is not defined for A402.01 to A402.15 occurs. Detailed information is output to the bits of A314.</p> <p>There are no errors that affect this flag at this time. This flag is reserved by the system.</p>	OFF: No other fatal error ON: Other fatal error	Cleared	Cleared	Refreshed when error occurs.	A315
	A402.04	Battery Error Flag (non-fatal error)	<p>ON if the CPU Unit's battery is disconnected or its voltage is low and the Detect Battery Error setting has been set in the PLC Setup.</p> <p>The CPU Unit will continue operating and the ERR/ALM indicator on the front of the CPU Unit will flash.</p> <p>This flag can be used to control an external warning light or other indicator to indicate that the battery needs to be replaced.</p> <p>(This flag will be turned OFF when the error is cleared.)</p>	ON: Error OFF: No error	Cleared	Cleared	Refreshed when error occurs.	PLC Setup (Detect Battery Error)

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A402	A402.06	Special I/O Unit Error Flag (non-fatal error)	ON when an error occurs in a data exchange between the CPU Unit and a Special I/O Unit (including an error in the Special I/O Unit itself). The CPU Unit will continue operating and the ERR/ALM indicator on the front of the CPU Unit will flash. The Special I/O Unit where the error occurred will stop operating and the unit number of the Unit where the data exchange error occurred is indicated in A418 through A423. (This flag will be turned OFF when the error is cleared.)	ON: Error in one or more Units OFF: No errors in any Unit	Cleared	Cleared	Refreshed when error occurs.	A418 to A423
	A402.07	CPU Bus Unit Error Flag (non-fatal error)	ON when an error occurs in a data exchange between the CPU Unit and an CPU Bus Unit (including an error in the CPU Bus Unit itself). The CPU Unit will continue operating and the ERR/ALM indicator on the front of the CPU Unit will flash. The CPU Bus Unit where the error occurred will stop operating and the unit number of the Unit where the data exchange error occurred is indicated in A417. (This flag will be turned OFF when the error is cleared.)	ON: Error in one or more Units OFF: No error in any Unit	Cleared	Cleared	Refreshed when error occurs.	A417
	A402.10	PLC Setup Error Flag (non-fatal error)	ON when there is a setting error in the PLC Setup. The CPU Unit will continue operating and the ERR/ALM indicator on the front of the CPU Unit will flash. The location of the error will be written to A406. (This flag will be turned OFF when the error is cleared.)	ON: Error OFF: No error	Cleared	Cleared	Refreshed when error occurs.	A406
	A402.13	Interrupt Task Error Flag (non-fatal error)	ON when the Detect Interrupt Task Errors setting in the PLC Setup is set to "Detect" and an interrupt task is executed for more than 10 ms during I/O refreshing of a Special I/O Unit. This flag will also be turned ON if an attempt is made to refresh a Special I/O Unit's I/O from an interrupt task with IORF(097) while the Unit's I/O is being refreshed by cyclic I/O refreshing (duplicate refreshing). The CPU Unit will continue operating and the ERR/ALM indicator on the front of the CPU Unit will flash. (This flag will be turned OFF when the error is cleared.)	ON: Interrupt task error OFF: No error	Cleared	Cleared	Refreshed when error occurs.	A426, PLC Setup (Detect Interrupt Task Errors setting)
	A402.15	FAL Error Flag (non-fatal error)	ON when a non-fatal error is generated by executing FAL(006). The CPU Unit will continue operating and the ERR/ALM indicator on the front of the CPU Unit will flash. The bit in A360 to A391 that corresponds to the FAL number specified in FALS(006) will be turned ON and the corresponding error code will be written to A400. Error codes 4101 to 42FF correspond to FAL numbers 001 to 2FF (0 to 511). (This flag will be turned OFF when the error is cleared.)	ON: FALS(006) error occurred OFF: FALS(006) not executed	Cleared	Cleared	Refreshed when error occurs.	A360 to A391, A400

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A403	A403.00 to A403.08	Memory Error Location	<p>When a memory error occurs, the Memory Error Flag (A401.15) is turned ON and one of the following flags is turned ON to indicate the memory area where the error occurred</p> <p>A403.00: User program A403.04: PLC Setup A403.07: Routing Table A403.08: CPU Bus Unit Settings</p> <p>When a memory error occurs, the CPU Unit will continue operating and the ERR/ALM indicator on the front of the CPU Unit will flash.</p> <p>(The corresponding flag will be turned OFF when the error is cleared.)</p>	ON: Error OFF: No error	Cleared	Cleared	Refreshed when error occurs.	A401.15
	A403.09	Memory Cassette startup Transfer Error Flag	<p>ON when automatic transfer at start-up has been selected and an error occurs during automatic transfer. An error will occur if there is a transfer error, the specified file does not exist, or the Memory Cassette is not installed.</p> <p>(This flag will be turned OFF when the error is cleared by turning the power OFF. The error cannot be cleared without turning the power OFF.)</p>	ON: Error OFF: No error	Cleared	Cleared	Refreshed when power is turned ON.	---
	A403.10	Flash Memory Error Flag	ON when the flash memory is physically destroyed.	ON: Error OFF: No error	Cleared	Cleared	Refreshed when error is detected.	---
A404	All	I/O Bus Error Details	<p>Contains information on I/O bus errors.</p> <p>The CPU Unit will stop operating and the ERR/ALM indicator on the front of the CPU Unit will light.</p> <p>(A401.04 (I/O Bus Error Flag) will turn ON.)</p> <p>(This information will be cleared when the error is cleared.)</p>	<p>0A0A hex: CP-series Unit error 0000 hex: CJ-series Unit error, 1st Unit 0001 hex: CJ-series Unit error, 2nd Unit 0F0F hex: CJ-series Unit error, unknown Unit 0E0E hex: CJ-series Unit error, no End cover</p>	Cleared	Cleared	Refreshed when error is detected.	A401.14
A406	All	PLC Setup Error Location	<p>When there is a setting error in the PLC Setup, the location of that error is written to A406 in 4-digit hexadecimal.</p> <p>The CPU Unit will continue operating and the ERR/ALM indicator on the front of the CPU Unit will flash.</p> <p>(A406 will be cleared when the cause of the error is eliminated.)</p>	0000 to 01FF hexadecimal	Cleared	Cleared	Refreshed when error occurs.	A402.10
A407	A407.00 to A407.12	Too Many I/O Points, Details	Always 0000 hex.	0000 hex	Cleared	Cleared	---	A401.11, A407.13 to A407.15

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A407	A407.13 to A407.15	Too Many I/O Points, Cause	The 3-digit binary value of these bits indicates the cause of the Too Many I/O Points Error. (These bits will be cleared when the error is cleared.)	010: Too many CP-series words 011: Too many CP-series Units 111: Too many CJ-series Units	Cleared	Cleared	Refreshed when error occurs.	---
A410	A410.00 to A410.15	CPU Bus Unit Number Duplication Flags	The Duplication Error Flag (A401.13) and the corresponding flag in A410 will be turned ON when an CPU Bus Unit's unit number has been duplicated. Bits 00 to 15 correspond to unit numbers 0 to F. CPU Unit operation will stop and the ERR/ALM indicator on the front of the CPU Unit will light.	ON: Duplication detected OFF: No duplication	Cleared	Cleared	---	A401.13
A411 to A416	A411.00 to A416.15	Special I/O Unit Number Duplication Flags	The Duplication Error Flag (A401.13) and the corresponding flag in A411 through A416 will be turned ON when a Special I/O Unit's unit number has been duplicated. Bits A411.00 to A416.15 correspond to unit numbers 000 to 05F (0 to 95). CPU Unit operation will stop and the ERR/ALM indicator on the front of the CPU Unit will light.	ON: Duplication detected OFF: No duplication	Cleared	Cleared	---	A401.13
A417	A417.00 to A417.15	CPU Bus Unit Error, Unit Number Flags	When an error occurs in a data exchange between the CPU Unit and an CPU Bus Unit, the CPU Bus Unit Error Flag (A402.07) is turned ON and the bit in A417 corresponding to the unit number of the Unit where the error occurred is turned ON. Bits 00 to 15 correspond to unit numbers 0 to F. The CPU Unit will continue operating and the ERR/ALM indicator on the front of the CPU Unit will flash.	ON: Error OFF: No error	Cleared	Cleared	---	A402.07
A418 to A423	A418.00 to A423.15	Special I/O Unit Error, Unit Number Flags	When an error occurs in a data exchange between the CPU Unit and a Special I/O Unit, the Special I/O Unit Error Flag (A402.06) will be turned ON. Each bit corresponds to a unit number. Bits A418.00 to A423.15 correspond to unit numbers 000 to 05F (0 to 95). The CPU Unit will continue operating and the ERR/ALM indicator on the front of the CPU Unit will flash. The unit number of the Unit where the error occurred is indicated in A417. If the unit number of the Unit is uncertain, none of the flags will be turned ON. (The flag will be turned OFF when the error is cleared.)	ON: Error OFF: No error	Cleared	Cleared	---	A402.06
A424	A424.00 to A424.15	Error Option Board Flags	The bit corresponding to the option slot turns ON when an error occurs in an Option Board (A315.13 will be ON). Bit 00: Option slot 1 Bit 01: Option slot 2	ON: Error OFF: No error	Cleared	Cleared	---	A353.13

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A426	A426.00 to A426.11	Interrupt Task Error, Unit Number	An attempt was made to refresh a Special I/O Unit's I/O from an interrupt task with IORF(097) while the Unit's I/O is being refreshed by cyclic I/O refreshing (duplicate refreshing). A426.00 to A426.11 contain the Special I/O Unit's unit number. These bits will be cleared when the error is cleared.	Unit number: 000 to 05F (0 to 95)	Cleared	Cleared	---	A402.13 A426.15
	A426.15	Interrupt Task Error Cause Flag	When A402.13 (the Interrupt Task Error Flag) is ON, this flag indicates the cause of the error. The CPU Unit will continue operating and the ERR/ALM indicator on the front of the CPU Unit will flash. This flag turns ON when an attempt is made to refresh a Special I/O Unit during an interrupt task while the Unit is being refreshed in cyclic processing.	ON: Duplicated refreshing	Cleared	Cleared	---	A402.13, A426.00 to A426.11
A434	A434.00 to A434.03	Built-in Analog Input Open-circuit Error Flag	ON when an open-circuit occurs in a built-in analog input. A434.00: Analog Input 0 Open-circuit Error Flag A434.01: Analog Input 1 Open-circuit Error Flag A434.02: Analog Input 2 Open-circuit Error Flag A434.03: Analog Input 3 Open-circuit Error Flag	OFF: No error ON: Error	Retained	Cleared	When open-circuit is detected.	---
	A434.04	Analog Initialization Completed Flag	ON while the built-in analog I/O is being initialized.	OFF: Initializing ON: Initialization completed	Retained	Cleared	When Initialization is completed	---
A436	A436.00 to A436.06	CP-series Unit Error Flags	ON when an error occurs in a CP-series Expansion Unit or Expansion I/O Unit. A436.00: 1st Unit A436.10: 2nd Unit A436.02: 3rd Unit A436.03: 4th Unit A436.04: 5th Unit A436.05: 6th Unit A436.06: 7th Unit	OFF: No error ON: Error	Retained	Cleared	---	---
A437	All	Number of Connected CP-series Units	Stores the number of CP-series Expansion Units and Expansion I/O Units connected as a hexadecimal number. Note This information is valid only when a Too Many I/O Points error has occurred. CP1W-TS002 and CP1W-TS102 are each counted as two Units.	0000 to 0007 hex	Retained	Cleared	---	---
A438	All	Pulse Output 2 Stop Error Code	If a Pulse Output Stop Error occurs for pulse output 2, the error code is stored.	---	Retained	Cleared	Refreshed when origin search starts. Refreshed when a pulse output stop error occurs.	---

Address		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related flags, settings
Words	Bits							
A439	All	Pulse Output 3 Stop Error Code	If a Pulse Output Stop Error occurs for pulse output 3, the error code is stored.	---	Retained	Cleared	Refreshed when origin search starts. Refreshed when a pulse output stop error occurs.	---
A440	All	Max. Interrupt Task Processing Time	Contains the Maximum Interrupt Task Processing Time in units of 0.1 ms. (This value is written after the interrupt task with the max. processing time is executed and cleared when PLC operation begins.)	0000 to FFFF hexadecimal	Cleared	Cleared	See Function column.	---
A441	All	Interrupt Task With Max. Processing Time	Contains the task number of the interrupt task with the maximum processing time. Hexadecimal values 8000 to 80FF correspond to task numbers 00 to FF. Bit 15 is turned ON when an interrupt has occurred. (This value is written after the interrupt task with the max. processing time is executed and cleared when PLC operation begins.)	8000 to 80FF hexadecimal	Cleared	Cleared	See Function column.	---
A444	All	Pulse Output 0 Stop Error Code	If a Pulse Output Stop Error occurs for pulse output 0, the error code is written to this word.	---	---	Cleared	Refreshed when origin search starts. Refreshed when a pulse output stop error occurs.	---
A445		Pulse Output 1 Stop Error Code	If a Pulse Output Stop Error occurs for pulse output 1, the error code is written to this word.	---	---			---
A494	A494.00 to A494.07	Memory Cassette Verification Results	Stores the results of comparing data in the Memory Cassette and CPU Unit. This information is cleared the next time the Memory Cassette is accessed normally (initialized, written, read, or compared). A494.00: User program is different. A494.01: Function block sources are different. A494.02: Parameter area is different. A494.03: Symbol table is different. A494.04: Comments are different. A494.05: Program indices are different. A494.06: Data memory is different. A494.07: DM initial values are different.	OFF: Match ON: Mismatch			When Memory Cassette is compared.	

Read/Write Area (Set by User)

Addresses		Name	Function	Settings	Status after mode change	Status at startup	Write timing	Related Flags, Settings
Word	Bits							
A500	A500.12	IOM Hold Bit	Turn this bit ON to preserve the status of the I/O Memory when shifting from PROGRAM to RUN or MONITOR mode or vice versa. The I/O Memory includes the CIO Area, Transition Flags, Timer Flags and PVs, Index Registers, and Data Registers. (If the status of the IOM Hold Bit itself is preserved in the PLC Setup (IOM Hold Bit Status), the status of the I/O Memory Area will be retained when the PLC is turned ON or power is interrupted.)	ON: Retained OFF: Not retained	Retained	See Function column.	See Function column.	PLC Setup (IOM Hold Bit Status setting)
	A500.13	Forced Status Hold Bit	Turn this bit ON to preserve the status of bits that have been force-set or force-reset when shifting from PROGRAM to MONITOR mode or vice versa. Bits that have been force-set or force-reset will always return to their default status when shifting to RUN mode. (If the status of the Forced Status Hold Bit itself is preserved in the PLC Setup (Forced Status Hold Bit Status), the status of force-set and force-reset bits will be retained when the PLC is turned ON or power is interrupted.)	ON: Retained OFF: Not retained	Retained	See Function column.	See Function column.	PLC Setup (Forced Status Hold Bit Status setting)
	A500.14	Error Log Reset Bit	Turn this bit ON to reset the Error Log Pointer (A300) to 00. The contents of the Error Log Area itself (A100 to A199) are not cleared. (This bit is automatically reset to 0 after the Error Log Pointer is reset.)	OFF to ON: Clear	Retained	Cleared	---	A100 to A199, A300
	A500.15	Output OFF Bit	Turn this bit ON to turn OFF all outputs from the CPU Unit, CP-series Units, and Special I/O Units. The INH indicator on the front of the CPU Unit will light while this bit is ON. (The status of the Output OFF Bit is retained through power interruptions.)	---	Retained	Retained	---	---
A501	A501.00 to A501.15	CPU Bus Unit Restart Bits	Turn the corresponding bit ON to restart (initialize) the CPU Bus Unit with the corresponding unit number. Bits 00 to 15 correspond to unit numbers 0 to F. When a restart bit is turned ON, the corresponding CPU Bus Unit Initializing Flag (A302.00 to A302.15) will be turned ON. Both the restart bit and initializing flag will be turned OFF automatically when initialization is completed.	OFF to ON: Restart ON to OFF: Restart completed Turned OFF by the system when the Unit has been restarted.	Retained	Cleared	---	A302.00 to A302.15
A502 to A507	A502.00 to A507.15	Special I/O Unit Restart Bits	Turn the corresponding bit ON to restart (initialize) the Special I/O Unit with the corresponding unit number. Bits A502.00 to A507.15 correspond to unit numbers 0 to 95. When a restart bit is turned ON, the corresponding Special I/O Unit Initializing Flag (A330.00 to A335.15) will be turned ON. Both the restart bit and initializing flag will be turned OFF automatically when initialization is completed.	OFF to ON: Restart ON to OFF: Restart completed Turned OFF by the system when the Unit has been restarted.	Retained	Cleared	---	A330.00 to A335.15

Addresses		Name	Function	Settings	Status after mode change	Status at startup	Write timing	Related Flags, Settings
Word	Bits							
A508	A508.09	Differentiate Monitor Completed Flag	ON when the differentiate monitor condition has been established during execution of differentiation monitoring. (This flag will be cleared to 0 when differentiation monitoring starts.)	ON: Monitor condition established OFF: Not yet established	Retained	Cleared	---	---
	A508.11	Trace Trigger Monitor Flag	ON when a trigger condition is established by the Trace Start Bit (A508.14). OFF when the next Data Trace is started by the Sampling Start bit (A508.15).	ON: Trigger condition established OFF: Not yet established or not tracing	Retained	Cleared	---	---
	A508.12	Trace Completed Flag	ON when sampling of a region of trace memory has been completed during execution of a Trace. OFF when the next time the Sampling Start Bit (A508.15) is turned ON.	ON: Trace completed OFF: Not tracing or trace in progress	Retained	Cleared	---	---
	A508.13	Trace Busy Flag	ON when the Sampling Start Bit (A508.15) is turned ON. OFF when the trace is completed.	ON: Trace in progress OFF: Not tracing (not sampling)	---	---	---	---
	A508.14	Trace Start Bit	Turn this bit ON to establish the trigger condition. The offset indicated by the delay value (positive or negative) determines which data samples are valid.	ON: Trace trigger condition established OFF: Not established	---	---	---	---
	A508.15	Sampling Start Bit	When a data trace is started by turning this bit ON from the CX-Programmer, the PLC will begin storing data in Trace Memory by one of the three following methods: 1) Data is sampled at regular intervals (10 to 2,550 ms). 2) Data is sampled when TRSM(045) is executed in the program. 3) Data is sampled at the end of every cycle. The operation of A508.15 can be controlled only from the CX-Programmer.	OFF to ON: Starts data trace (sampling) Turned ON from Programming Device.	---	---	---	---
A510 to A511	All	startup Time	These words contain the time at which the power was turned ON. The contents are updated every time that the power is turned ON. The data is stored in BCD. A510.00 to A510.07: Second (00 to 59) A510.08 to A510.15: Minute (00 to 59) A511.00 to A511.07: Hour (00 to 23) A511.08 to A511.15: Day of month (01 to 31)	See Function column.	Retained	See Function column.	Refreshed when power is turned ON.	---
A512 to A513	All	Power Interruption Time	These words contain the time at which the power was interrupted. The contents are updated every time that the power is interrupted. The data is stored in BCD. A512.00 to A512.07: Second (00 to 59) A512.08 to A512.15: Minute (00 to 59) A513.00 to A513.07: Hour (00 to 23) A513.08 to A513.15: Day of month (01 to 31) (These words are not cleared at startup.)	See Function column.	Retained	Retained	Written at power interruption	---

Addresses		Name	Function	Settings	Status after mode change	Status at startup	Write timing	Related Flags, Settings
Word	Bits							
A514	All	Number of Power Interruptions	Contains the number of times that power has been interrupted since the power was first turned ON. The data is stored in binary. To reset this value, overwrite the current value with 0000. (This word is not cleared at startup, but it is cleared when the Memory Corruption Detected Flag (A395.11) goes ON.)	0000 to FFFF hexadecimal	Retained	Retained	Refreshed when power is turned ON.	A395.11
A515 to A517	All	Operation Start Time	The time that operation started as a result of changing the operating mode to RUN or MONITOR mode is stored here in BCD. A515.00 to A515.07: Seconds (00 to 59) A515.08 to A515.15: Minutes (00 to 59) A516.00 to A516.07: Hour (00 to 23) A516.08 to A516.15: Day of month (01 to 31) A517.00 to A517.07: Month (01 to 12) A517.08 to A517.15: Year (00 to 99) Note The previous start time is stored after turning ON the power supply until operation is started.	See at left.	Retained	Retained	See at left.	---
A518 to A520	All	Operation End Time	The time that operation stopped as a result of changing the operating mode to PROGRAM mode is stored here in BCD. A518.00 to A518.07: Seconds (00 to 59) A518.08 to A518.15: Minutes (01 to 59) A519.00 to A519.07: Hour (00 to 23) A519.08 to A519.15: Day of month (01 to 31) A520.00 to A520.07: Month (01 to 12) A520.08 to A520.15: Year (00 to 99) Note If an error occurs in operation, the time of the error will be stored. If the operating mode is then changed to PROGRAM mode, the time that PROGRAM mode was entered will be stored.	See at left.	Retained	Retained	See at left.	---
A523	All	Total Power ON Time	Contains the total time that the PLC has been ON in 10-hour units. The data is stored in binary and it is updated every 10 hours. To reset this value, overwrite the current value with 0000. (This word is not cleared at startup, but it is cleared to 0000 when the Memory Corruption Detected Flag (A395.11) goes ON.)	0000 to FFFF hexadecimal	Retained	Retained	---	---

Addresses		Name	Function	Settings	Status after mode change	Status at startup	Write timing	Related Flags, Settings
Word	Bits							
A525	A525.00	Ethernet Option Board Reset Flag (Serial Port 2)	Turn this bit ON to reset the Ethernet Option Board mounted on the serial port 2.	OFF to ON: Reset	Retained	Cleared	---	---
	A525.01	Ethernet Option Board Reset Flag (Serial Port 1)	Turn this bit ON to reset the Ethernet Option Board mounted on the serial port 1.	OFF to ON: Reset	Retained	Cleared	---	---
	A525.08	Ethernet Option Board Restart Flag (Serial Port 2)	Turn this bit ON to restart the Ethernet Option Board mounted on the serial port 2.	OFF to ON: Restart	Retained	Cleared	---	---
	A525.09	Ethernet Option Board Restart Flag (Serial Port 1)	Turn this bit ON to restart Ethernet Option Board mounted on the serial port 1.	OFF to ON: Restart	Retained	Cleared	---	---
A526	A526.00	Serial Port 2 Restart Bit	Turn this bit ON to restart the serial port 2. (Do not use this bit when the port is operating in Peripheral Bus Mode.) This bit is turned OFF automatically when the restart processing is completed.	OFF to ON: Restart	Retained	Cleared	---	---
	A526.01	Serial Port 1 Restart Bit	Turn this bit ON to restart the serial port 1. This bit is turned OFF automatically when the restart processing is completed.	0 to ON: Restart	Retained	Cleared	---	---
A527	A527.00 to A527.07	Online Editing Disable Bit Validator	The Online Editing Disable Bit (A527.09) is valid only when this byte contains 5A. To disable online editing from the CX-Programmer, set this byte to 5A and turn ON A527.09. (Online editing refers to changing or adding to the program while the PLC is operating in MONITOR mode.)	5A: A527.09 enabled Other value: A527.09 disabled	Retained	Cleared	---	A527.09
	A527.09	Online Editing Disable Bit	Turn this bit ON to disable online editing. The setting of this bit is valid only when A527.00 to A527.07 have been set to 5A.	ON: Disabled OFF: Not disabled	Retained	Cleared	---	A527.00 to A527.07

Addresses		Name	Function	Settings	Status after mode change	Status at startup	Write timing	Related Flags, Settings
Word	Bits							
A528	A528.00 to A528.07	Serial Port 2 Error Flags	These flags indicate what kind of error has occurred at the serial port 2; they are automatically turned OFF when the serial port 2 is restarted. (These flags are not valid in peripheral bus mode and only bit 5 is valid in NT Link mode.) PLC Link Polling Unit: Bit 05: ON for timeout error. PLC Link Polled Unit: Bit 03: ON for framing error. Bit 04: ON for overrun error. Bit 05: ON for timeout error. These bits can be cleared by the CX-Programmer.	Bits 00 and 01: Not used. Bit 02: ON for parity error. Bit 03: ON for framing error. Bit 04: ON for overrun error. Bit 05: ON for timeout error. Bits 06 and 07: Not used.	---	---	---	---
	A528.08 to A528.15	Serial Port 1 Error Code	These flags indicate what kind of error has occurred at the serial port 1; they are automatically turned OFF when the serial port 1 is restarted. (These flags are not valid in peripheral bus mode and only bit 5 is valid in NT Link mode.) PLC Link Polling Unit: Bit 13: ON for timeout error. PLC Link Polled Unit: Bit 11: ON for framing error. Bit 12: ON for overrun error. Bit 13: ON for timeout error. These bits can be cleared by the CX-Programmer.	Bits 08 and 09: Not used. Bit 10: ON for parity error. Bit 11: ON for framing error. Bit 12: ON for overrun error. Bit 13: ON for timeout error. Bits 14 and 15: Not used.	---	---	---	---
A529	All	FAL/FALS Number for System Error Simulation	Set a dummy FAL/FALS number to use to simulate the system error using FAL(006) or FALS(007). When FAL(006) or FALS(007) is executed and the number in A529 is the same as the one specified in the operand of the instruction, the system error given in the operand of the instruction will be generated instead of a user-defined error.	0001 to 01FF hex: FAL/FALS numbers 1 to 511 0000 or 0200 to FFFF hex: No FAL/FALS number for system error simulation. (No error will be generated.)	Retained	Cleared	---	---
A531	A531.00	High-speed Counter 0 Reset Bit	When the reset method is set to Phase-Z signal + Software reset, the corresponding high-speed counter's PV will be reset if the phase-Z signal is received while this bit is ON. When the reset method is set to Software reset, the corresponding high-speed counter's PV will be reset in the cycle when this bit turns ON.	---	Retained	Cleared	---	---
	A531.01	High-speed Counter 1 Reset Bit		---	Retained	Cleared	---	---
	A531.02	High-speed Counter 2 Reset Bit		---	Retained	Cleared	---	---
	A531.03	High-speed Counter 3 Reset Bit		---	Retained	Cleared	---	---
A531	A531.08	High-speed Counter 0 Gate Bit	When a counter's Gate Bit is ON, the counter's PV will not be changed even if pulse inputs are received for the counter.	---	Retained	Cleared	---	---
	A531.09	High-speed Counter 1 Gate Bit	When the bit is turned OFF again, counting will restart and the high-speed counter's PV will be refreshed.	---	Retained	Cleared	---	---
	A531.10	High-speed Counter 2 Gate Bit	When the reset method is set to Phase-Z signal + Software reset, the Gate Bit is disabled while the corresponding Reset Bit (A531.00 or A531.01) is ON.	---	Retained	Cleared	---	---
	A531.11	High-speed Counter 3 Gate Bit		---	Retained	Cleared	---	---

Addresses		Name	Function	Settings	Status after mode change	Status at startup	Write timing	Related Flags, Settings
Word	Bits							
A532	All	Interrupt Counter 0 Counter SV	Used for interrupt input 0 in counter mode. Sets the count value at which the interrupt task will start. Interrupt task 140 will start when interrupt counter 0 has counted this number of pulses. Retained when operation starts.	---	Retained	Retained	---	---
A533	All	Interrupt Counter 1 Counter SV	Used for interrupt input 1 in counter mode. Sets the count value at which the interrupt task will start. Interrupt task 141 will start when interrupt counter 1 has counted this number of pulses.	---	Retained	Retained	---	---
A534	All	Interrupt Counter 2 Counter SV	Used for interrupt input 2 in counter mode. Sets the count value at which the interrupt task will start. Interrupt task 142 will start when interrupt counter 2 has counted this number of pulses.	---	Retained	Retained	---	---
A535	All	Interrupt Counter 3 Counter SV	Used for interrupt input 3 in counter mode. Sets the count value at which the interrupt task will start. Interrupt task 143 will start when interrupt counter 3 has counted this number of pulses.	---	Retained	Retained	---	---
A536	All	Interrupt Counter 0 Counter PV	These words contain the interrupt counter PVs for interrupt inputs operating in counter mode.	---	---	Retained	Refreshed when interrupt is generated. Refreshed when INI(880) instruction is executed.	---
A537	All	Interrupt Counter 1 Counter PV	In increment mode, the counter PV starts incrementing from 0. When the counter PV reaches the counter SV, the PV is automatically reset to 0.	---	---			---
A538	All	Interrupt Counter 2 Counter PV	In decrement mode, the counter PV starts decrementing from the counter SV. When the counter PV reaches the 0, the PV is automatically reset to the SV.	---	---			---
A539	All	Interrupt Counter 3 Counter PV	Cleared when operation starts.	---	---			---
A540	A540.00	Pulse Output 0 Reset Bit	The pulse output 0 PV (contained in A276 and A277) will be cleared when this bit is turned ON.	---	---	Cleared	---	A276 and A277
	A540.08	Pulse Output 0 CW Limit Input Signal Flag	This is the CW limit input signal for pulse output 0, which is used in the origin search. To use this signal, write the input from the actual sensor as an input condition in the ladder program and output the result to this flag.	---	---	Cleared	---	---
	A540.09	Pulse Output 0 CCW Limit Input Signal Flag	This is the CCW limit input signal for pulse output 0, which is used in the origin search. To use this signal, write the input from the actual sensor as an input condition in the ladder program and output the result to this flag.	---	---	Cleared	---	---
A540	A540.10	Pulse Output 0 Positioning Completed Signal	This is the positioning completed input signal used in the origin search for pulse output 0. The input signal from the servo driver is output to this bit from the ladder program to enable using the signal.	---	---	Cleared	---	---

Addresses		Name	Function	Settings	Status after mode change	Status at startup	Write timing	Related Flags, Settings
Word	Bits							
A541	A541.00	Pulse Output 1 Reset Bit	The pulse output 1 PV (contained in A278 and A279) will be cleared when this bit is turned ON.	---	---	Cleared	---	A278 and A279
	A541.08	Pulse Output 1 CW Limit Input Signal Flag	This is the CW limit input signal for pulse output 1, which is used in the origin search. To use this signal, write the input from the actual sensor as an input condition in the ladder program and output the result to this flag.	---	---	Cleared	---	---
	A541.09	Pulse Output 1 CCW Limit Input Signal Flag	This is the CCW limit input signal for pulse output 1, which is used in the origin search. To use this signal, write the input from the actual sensor as an input condition in the ladder program and output the result to this flag.	---	---	Cleared	---	---
	A541.10	Pulse Output 1 Positioning Completed Signal	This is the positioning completed input signal used in the origin search for pulse output 1. The input signal from the servo driver is output to this bit from the ladder program to enable using the signal.	---	---	Cleared	---	---
A542	A542.00	Pulse Output 2 Reset Bit	The pulse output 2 PV (contained in A322 and A323) will be cleared when this bit is turned ON.	---	---	Cleared	---	A322 and A323
	A542.08	Pulse Output 2 CW Limit Input Signal Flag	This is the CW limit input signal for pulse output 2, which is used in the origin search. To use this signal, write the input from the actual sensor as an input condition in the ladder program and output the result to this flag.	---	---	Cleared	---	---
	A542.09	Pulse Output 2 CCW Limit Input Signal Flag	This is the CCW limit input signal for pulse output 2, which is used in the origin search. To use this signal, write the input from the actual sensor as an input condition in the ladder program and output the result to this flag.	---	---	Cleared	---	---
	A542.10	Pulse Output 2 Positioning Completed Signal	This is the positioning completed input signal used in the origin search for pulse output 2. The input signal from the servo driver is output to this bit from the ladder program to enable using the signal.	---	---	Cleared	---	---
A543	A543.00	Pulse Output 3 Reset Bit	The pulse output 3 PV (contained in A324 and A325) will be cleared when this bit is turned ON.	---	---	---	---	A324 and A325
	A543.08	Pulse Output 3 CW Limit Input Signal Flag	This is the CW limit input signal for pulse output 3, which is used in the origin search. To use this signal, write the input from the actual sensor as an input condition in the ladder program and output the result to this flag.	---	---	---	---	---
	A543.09	Pulse Output 3 CCW Limit Input Signal Flag	This is the CCW limit input signal for pulse output 3, which is used in the origin search. To use this signal, write the input from the actual sensor as an input condition in the ladder program and output the result to this flag.	---	---	---	---	---
A543	A543.10	Pulse Output 3 Positioning Completed Signal	This is the positioning completed input signal used in the origin search for pulse output 3. The input signal from the servo driver is output to this bit from the ladder program to enable using the signal.	---	---	---	---	---

Addresses		Name	Function	Settings	Status after mode change	Status at startup	Write timing	Related Flags, Settings
Word	Bits							
A544	All	Interrupt Counter 4 Counter SV	Used for an input interrupt in Counter Mode. Set the value to count before starting the interrupt task. When interrupt counter 4 has counted the set number of pulses, interrupt task 144 will be started.	---	---	Retained	---	---
A545	All	Interrupt Counter 5 Counter SV	Used for an input interrupt in Counter Mode. Set the value to count before starting the interrupt task. When interrupt counter 5 has counted the set number of pulses, interrupt task 145 will be started.	---	---	Retained	---	---
A546	All	Interrupt Counter 7 Counter SV	Used for an input interrupt in Counter Mode. Set the value to count before starting the interrupt task. When interrupt counter 6 has counted the set number of pulses, interrupt task 146 will be started.	---	---	Retained	---	---
A547	All	Interrupt Counter 7 Counter SV	Used for an input interrupt in Counter Mode. Set the value to count before starting the interrupt task. When interrupt counter 7 has counted the set number of pulses, interrupt task 147 will be started.	---	---	Retained	---	---
A548	All	Interrupt Counter 4 Counter PV	Stores the present value of the interrupt counter for an input interrupt in Counter Mode.	---	---	Cleared	Cleared	---
A549	All	Interrupt Counter 5 Counter PV	For an incrementing counter, the value is incremented by 1 from 0. The value returns to 0 after the SV has been reached.	---	---	Cleared	Cleared	---
A550	All	Interrupt Counter 7 Counter PV	For a decrementing counter, the value is decremented by 1 from the ST. The value returns to the SV after 0 has been reached.	---	---	Cleared	Cleared	---
A551	All	Interrupt Counter 7 Counter PV		---	---	Cleared	Cleared	---
A580 (See note.)	A580.00 to A580.03	FB Communications Instruction Retries	Automatically stores the number of retries in the FB communications instruction settings specified in the PLC Setup.	0 to F hex	---	Cleared	Written at start of operation	
A581 (See note.)	All	FB Communications Instruction Response Monitoring Time	Automatically stores the FB communications instruction response monitoring time set in the PLC Setup.	0001 to FFFF hex (Unit: 0.1 s; Range: 0.1 to 6553.5) 0000 hex: 2 s	---	Cleared	Written at start of operation	---
A582 (See note.)	All	FB DeviceNet Communications Instruction Response Monitoring Time	Automatically stores the FB DeviceNet communications instruction response monitoring time set in the PLC Setup.	0001 to FFFF hex (Unit: 0.1 s; Range: 0.1 to 6553.5) 0000 hex: 2 s	---	Cleared	Written at start of operation	---

Note These Auxiliary Area bits/words are not to be written by the user. The number of resends and response monitoring time must be set by the user in the FB communications instructions settings in the PLC Setup, particularly when using function blocks from the OMRON FB Library to execute FINS messages or DeviceNet explicit messages communications. The values set in the Settings for OMRON FB Library in the PLC Setup will be automatically stored in the related Auxiliary Area words A580 to A582 and used by the function blocks from the OMRON FB Library.

Addresses		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related Flags, Settings
Word	Bits							
A595 and A596	All	IR00 Output for Background Execution	When an index register is specified as the output for an instruction processed in the background, A595 and A596 receive the output instead of IR00.	0000 0000 to FFFF FFFF hex (A596 contains the leftmost digits.)	Cleared	Cleared	---	---
A597	All	DR00 Output for Background Execution	When a data register is specified as the output for an instruction processed in the background, A597 receives the output instead of DR00.	0000 to FFFF hex	Cleared	Cleared	---	---
A598	A598.00	FPD Teaching Bit	Turn this bit ON to set the monitoring time automatically with the teaching function. While A598.00 is ON, FPD(269) measures how long it takes for the diagnostic output to go ON after the execution condition goes ON. If the measured time exceeds the monitoring time, the measured time is multiplied by 1.5 and that value is stored as the new monitoring time. (The teaching function can be used only when a word address has been specified for the monitoring time operand.)	ON: Teach monitoring time OFF: Teaching function OFF	Cleared	Cleared	---	---
	A598.01	Equals Flag for Background Execution	Turns ON if matching data is found for an SRCH(181) instruction executed in the background.	ON: Search data found in table OFF: Search data not found	Cleared	Cleared	---	---
A600 to A603	All	Macro Area Input Words	Before the subroutine specified in MCRO(099) is executed, the source words for the subroutine are transferred to A600 through A603 (input parameter words).	Input data: 4 words	Cleared	Cleared	---	---
A604 to A607	All	Macro Area Output Words	After the subroutine specified in MCRO(099) has been executed, the results of the subroutine are transferred from A604 through A607 to the specified destination words (output parameter words).	Output data: 4 words	Cleared	Cleared	---	---
A619	A619.01	Serial Port 1 Settings Changing Flag	ON while the serial port 1's communications settings are being changed. This flag will be turned ON when STUP(237) is executed and it will be turned OFF after the settings have been changed.	ON: Changing OFF: Not changing	Retained	Cleared	---	---
	A619.02	Serial Port 2 Settings Changing Flag	ON while the serial port 2's communications settings are being changed. This flag will be turned ON when STUP(237) is executed and it will be turned OFF after the settings have been changed.	ON: Changing OFF: Not changing	Retained	Cleared	---	---
A620	A620.01	Communications Unit 0, Port 1 Settings Changing Flag	The corresponding flag will be ON when the settings for that port are being changed. The flag will be turned ON when STUP(237) is executed and it will be turned OFF by an event issued from the Serial Communications Unit after the settings have been changed.	ON: Changing OFF: Not changing	Retained	Cleared	---	---
	A620.02	Communications Unit 0, Port 2 Settings Changing Flag	It is also possible for the user to indicate a change in serial port settings by turning these flags ON.	ON: Changing OFF: Not changing	Retained	Cleared	---	---
	A620.03	Communications Unit 0, Port 3 Settings Changing Flag		ON: Changing OFF: Not changing	Retained	Cleared	---	---
	A620.04	Communications Unit 0, Port 4 Settings Changing Flag		ON: Changing OFF: Not changing	Retained	Cleared	---	---

Addresses		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related Flags, Settings
Word	Bits							
A621 to A635	A621.00 to A635.04	Communications Units 0 to 15, Ports 1 to 4 Settings Changing Flag	Same as above.	ON: Changing OFF: Not changing	Retained	Cleared	---	---
A640	A640.00	Serial Port 2 Modbus-RTU Easy Master Execution Bit	Turn ON this bit to send a command and receive a response for serial port 2 using the Modbus-RTU easy master function. This bit will be turned OFF automatically by the system when communications have been completed.	Turned ON: Execution started ON: Execution in progress. OFF: Not executed or execution completed.	Retained	Cleared	---	DM fixed allocation words for Modbus-RTU Easy Master: D32300 to D32399
	A640.01	Serial Port 2 Modbus-RTU Easy Master Normal End Flag	ON when one command has been sent and the response received for serial port 2 using the Modbus-RTU easy master function.	ON: Execution normal. OFF: Execution error or still in progress.	Retained	Cleared	---	
	A640.02	Serial Port 2 Modbus-RTU Easy Master Error End Flag	ON when an error has occurred in communications for serial port 2 using the Modbus-RTU easy master function. The error code is output to D32252 in the DM fixed allocation words for Modbus-RTU Easy Master.	ON: Execution error. OFF: Execution normal or still in progress.	Retained	Cleared	---	
A641	A641.00	Serial Port 1 Modbus-RTU Master Execution Bit	Turn ON this bit to send a command and receive a response for serial port 1 using the Modbus-RTU easy master function. This bit will be turned OFF automatically by the system when communications have been completed.	Turned ON: Execution started ON: Execution in progress. OFF: Not executed or execution completed.	Retained	Cleared	---	DM fixed allocation words for Modbus-RTU Easy Master: D32200 to D32299
	A641.01	Serial Port 1 Modbus-RTU Master Execution Normal Flag	ON when one command has been sent and the response received for serial port 1 using the Modbus-RTU easy master function.	ON: Execution normal. OFF: Execution error or still in progress.	Retained	Cleared	---	
	A641.02	Serial Port 1 Modbus-RTU Master Execution Error Flag	ON when an error has occurred in communications for serial port 1 using the Modbus-RTU easy master function. The error code is output to D32352 in the DM fixed allocation words for Modbus-RTU Easy Master.	ON: Execution error. OFF: Execution normal or still in progress.	Retained	Cleared	---	
A642	All	Analog Adjustment PV	Stores the value set on the analog adjuster as a hexadecimal value (resolution: 1/256).	0000 to 00FF hex	Retained	Cleared	---	---
A643	All	External Analog Setting Input PV	Stores the value set from the external analog setting input as a hexadecimal value (resolution: 1/256).	0000 to 00FF hex	Retained	Cleared	---	---
A651	All	Program Password	Type in the password to replace a program. A5A5 hex: Replacement Start Bit (A65015) is enabled. Any other value: Replacement Start Bit (A65015) is disabled. When the power is turned ON or program replacement is completed, the Replacement Start Bit will be turned OFF, regardless of whether replacement was completed normally or in error.	---	Retained	Cleared	---	---

Addresses		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related Flags, Settings
Word	Bits							
A720 to A722	All	Power ON Clock Data 1	These words contain the time at which the power was turned ON one time before the startup time stored in words A510 to A511. A720.00 to A720.07: Seconds (00 to 59) A720.08 to A720.15: Minutes (00 to 59) A721.00 to A721.07: Hour (00 to 23) A721.08 to A721.15: Day of month (00 to 31) A722.00 to A722.07: Month (01 to 12) A722.08 to A722.15: Year (00 to 99)	See at left.	Retained	Retained	Written when power is turned ON.	
A723 to A725	All	Power ON Clock Data 2	These words contain the time at which the power was turned ON two times before the startup time stored in words A510 to A511. A723.00 to A723.07: Seconds (00 to 59) A723.08 to A723.15: Minutes (00 to 59) A724.00 to A724.07: Hour (00 to 23) A724.08 to A724.15: Day of month (00 to 31) A725.00 to A725.07: Month (01 to 12) A725.08 to A725.15: Year (00 to 99)	See at left.	Retained	Retained	Written when power is turned ON.	
A726 to A728	All	Power ON Clock Data 3	These words contain the time at which the power was turned ON three times before the startup time stored in words A510 to A511. A726.00 to A726.07: Seconds (00 to 59) A726.08 to A726.15: Minutes (00 to 59) A727.00 to A727.07: Hour (00 to 23) A727.08 to A727.15: Day of month (00 to 31) A728.00 to A728.07: Month (01 to 12) A728.08 to A728.15: Year (00 to 99)	See at left.	Retained	Retained	Written when power is turned ON.	
A729 to A731	All	Power ON Clock Data 4	These words contain the time at which the power was turned ON four times before the startup time stored in words A510 to A511. A729.00 to A729.07: Seconds (00 to 59) A729.08 to A729.15: Minutes (00 to 59) A730.00 to A730.07: Hour (00 to 23) A730.08 to A730.15: Day of month (00 to 31) A731.00 to A731.07: Month (01 to 12) A731.08 to A731.15: Year (00 to 99)	See at left.	Retained	Retained	Written when power is turned ON.	
A732 to A734	All	Power ON Clock Data 5	These words contain the time at which the power was turned ON five times before the startup time stored in words A510 to A511. A732.00 to A732.07: Seconds (00 to 59) A732.08 to A732.15: Minutes (00 to 59) A733.00 to A733.07: Hour (00 to 23) A733.08 to A733.15: Day of month (00 to 31) A734.00 to A734.07: Month (01 to 12) A734.08 to A734.15: Year (00 to 99)	See at left.	Retained	Retained	Written when power is turned ON.	
A735 to A737	All	Power ON Clock Data 6	These words contain the time at which the power was turned ON six times before the startup time stored in words A510 to A511. A735.00 to A735.07: Seconds (00 to 59) A735.08 to A735.15: Minutes (00 to 59) A736.00 to A736.07: Hour (00 to 23) A736.08 to A736.15: Day of month (00 to 31) A737.00 to A737.07: Month (01 to 12) A737.08 to A737.15: Year (00 to 99)	See at left.	Retained	Retained	Written when power is turned ON.	

Addresses		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related Flags, Settings
Word	Bits							
A738 to A740	All	Power ON Clock Data 7	These words contain the time at which the power was turned ON seven times before the startup time stored in words A510 to A511. A738.00 to A738.07: Seconds (00 to 59) A738.08 to A738.15: Minutes (00 to 59) A739.00 to A739.07: Hour (00 to 23) A739.08 to A739.15: Day of month (00 to 31) A740.00 to A740.07: Month (01 to 12) A740.08 to A740.15: Year (00 to 99)	See at left.	Retained	Retained	Written when power is turned ON.	
A741 to A743	All	Power ON Clock Data 8	These words contain the time at which the power was turned ON eight times before the startup time stored in words A510 to A511. A741.00 to A741.07: Seconds (00 to 59) A741.08 to A741.15: Minutes (00 to 59) A742.00 to A742.07: Hour (00 to 23) A742.08 to A742.15: Day of month (00 to 31) A743.00 to A743.07: Month (01 to 12) A743.08 to A743.15: Year (00 to 99)	See at left.	Retained	Retained	Written when power is turned ON.	
A744 to A746	All	Power ON Clock Data 9	These words contain the time at which the power was turned ON nine times before the startup time stored in words A510 to A511. A744.00 to A744.07: Seconds (00 to 59) A744.08 to A744.15: Minutes (00 to 59) A745.00 to A745.07: Hour (00 to 23) A745.08 to A745.15: Day of month (00 to 31) A746.00 to A746.07: Month (01 to 12) A746.08 to A746.15: Year (00 to 99)	See at left.	Retained	Retained	Written when power is turned ON.	
A747 to A749	All	Power ON Clock Data 10	These words contain the time at which the power was turned ON ten times before the startup time stored in words A510 to A511. A747.00 to A747.07: Seconds (00 to 59) A747.08 to A747.15: Minutes (00 to 59) A748.00 to A748.07: Hour (00 to 23) A748.08 to A748.15: Day of month (00 to 31) A749.00 to A749.07: Month (01 to 12) A749.08 to A749.15: Year (00 to 99)	See at left.	Retained	Retained	Written when power is turned ON.	
A751	A751.11	DM Initial Values Read Error Flag	ON when an error occurred in transferring DM initial values from the DM initial value area in flash memory to the DM Area.	OFF: Normal ON: Error (failed to load)	Retained	Cleared	---	---
	A751.12	DM Initial Values Save Execution Error Flag	ON when the DM Initial Values Transfer Password (A752) is incorrect or when the DM Initial values area was not specified when starting to transfer DM initial values from the DM Area to the DM initial value area in flash memory.	OFF: Normal ON: Error (failed to save)	Retained	Cleared	---	---
	A751.13	DM Initial Values Save Error Flag	ON when an error occurred in transferring DM initial values from the DM Area to the DM initial value area in flash memory.	OFF: Normal ON: Error (failed to save)	Retained	Cleared	---	---
	A751.14	DM Initial Values Save Flag	ON while DM initial values are being transferred from the DM Area to the DM initial value area in flash memory. OFF when the transfer has been completed.	OFF: Not being saved ON: Being saved	Retained	Cleared	---	---
	A751.15	DM Initial Values Save Start Bit	Turn ON this bit to start transferring DM initial values. This bit is valid only when a correct password is stored in A752 and the DM Area Initial Value Area is specified (i.e., when A753.00 is ON). The system will turn this bit OFF automatically when the transfer has been completed.	Turned ON: Transfer started OFF: Not transferring ON: Transferring	Retained	Cleared	---	---

Addresses		Name	Function	Settings	Status after mode change	Status at start-up	Write timing	Related Flags, Settings
Word	Bits							
A752	All	DM Initial Values Save Password	Set the passwords here to transfer DM initial values between the DM area and the DM initial value area in flash memory. The transfer will not be started unless the correct password is set. The transfer is started when A751.15 is turned ON. The password will be cleared by the system when the transfer has been completed.	A5A5 hex: Save initial values from DM to flash	Retained	Cleared	---	---
A753	All	DM Initial Values Save Area Specification	Specifies the area to be transferred to flash memory.	0001 hex: DM Area specified	Retained	Cleared	---	---

Note The following flags are provided in a special read-only area and can be specified with the labels given in the table. These flags are not contained in the Auxiliary Area. Refer to 4-18 *Condition Flags* and 4-19 *Clock Pulses* for details.

Flag area	Name	Label	Meaning
Condition Code Area	Error Flag	ER	Turns ON when an error occurs in processing an instructions, indicating an error end to the instruction.
	Access Error Flag	AER	Turns ON when an attempt is made to access an illegal area. The status of this flag is maintain only during the current cycle and only in the task in which it occurred.
	Carry Flag	CY	Turns ON when there is a carry or borrow in a math operation, when a bit is shifted into the Carry Flag, etc.
	Greater Than Flag	>	Turns ON when the result of comparing two values is “greater than,” when a value exceeds a specified range, etc.
	Equals Flag	=	Turns ON when the result of comparing two values is “equals,” when the result of a math operation is 0, etc.
	Less Than Flag	<	Turns ON when the result of comparing two values is “less than,” when a value is below a specified range, etc.
	Negative Flag	N	Turns ON when the MSB in the result of a math operation is 1.
	Overflow Flag	OF	Turns ON when the result of a math operation overflows.
	Underflow Flag	UF	Turns ON when the result of a math operation underflows.
	Greater Than or Equals Flag	>=	Turns ON when the result of comparing two values is “greater than or equals.”
	Not Equal Flag	<>	Turns ON when the result of comparing two values is “not equal.”
	Less than or Equals Flag	<=	Turns ON when the result of comparing two values is “less than or equals.”
	Always ON Flag	A1	This flag is always ON.
	Always OFF Flag	A0	This flag is always OFF.
Clock Pulse Area	0.02-s clock pulse	0.02s	Repeatedly turns ON for 0.02 s and OFF for 0.02 s.
	0.1-s clock pulse	0.1s	Repeatedly turns ON for 0.1 s and OFF for 0.1 s.
	0.2-s clock pulse	0.2s	Repeatedly turns ON for 0.2 s and OFF for 0.2 s.
	1-s clock pulse	1s	Repeatedly turns ON for 1 s and OFF for 1 s.
	1-min clock pulse	1min	Repeatedly turns ON for 1 min and OFF for 1 min.

Details on Auxiliary Area Operation

A100 to A199: Error Log Area

A100	Error code		} Error record
A101	Error flag contents		
A102	min	s	
A103	day	hr	
A104	yr	mo	
			} Error record
A195	Error code		
A196	Error flag contents		
A197	min	s	
A198	day	hr	
A199	yr	mo	

The following data would be generated in an error record if a memory error (error code 80F1) occurred on 1 April 1998 at 17:10:30 with the error located in the PLC Setup (04 hex).

80	F1
00	04
10	30
01	17
98	04

The following data would be generated in an error record if an FALS error with FALS number 001 occurred on 2 May 1997 at 8:30:15.


C1	01
00	00
30	15
02	08
97	05

Error Codes and Error Flags

Classification	Error code	Meaning	Error flags
System-defined fatal errors	80F1	Memory error	A403
	80C0 to 80C7 80CE, 80CF	I/O bus error	A404
	80E9	Duplicate number error	A410, A411 to 416 (See note 3.)
	80E1	Too many I/O error	A407
	80E0	I/O setting error	---
	80F0	Program error	A295 to A299 (See note 4.)
	809F	Cycle time too long error	---
	80EA	Duplicate Expansion Rack number error	A409.00 to A409.07
User-defined fatal errors	C101 to C2FF	FALS instruction executed (See note 1.)	---
User-defined non-fatal errors	4101 to 42FF	FAL instruction executed (See note 2.)	---
System-defined non-fatal errors	008B	Interrupt task error	A426
	009A	Basic I/O error	A408
	009B	PLC Setup setting error	A406
	0200 to 020F	CPU Bus Unit error	A417
	0300 to 035F	Special I/O Unit error	A418 to A423 (See note 5.)
	00F7	Battery error	---
	0400 to 040F	CPU Bus Unit setup error	A427
	0500 to 055F	Special I/O Unit setup error	A428 to A433 (See note 5.)


- Note**
1. C101 to C2FF will be stored for FALS numbers 001 to 511.
 2. 4101 to 42FF will be stored for FAL numbers 001 to 511.
 3. The contents of the error flags for a duplicate number error are as follows:
 Bits 00 to 07: Unit number (binary), 00 to 5F hex for Special I/O Units, 00 to 0F hex for CPU Bus Units
 Bits 08 to 14: All zeros.
 Bit 15: Unit type, 0 for CPU Bus Units and 1 for Special I/O Units.
 4. Only the contents of A295 is stored as the error flag contents for program errors.
 5. A value of 0000 hex will be stored as the error flag contents.

A200.11: First Cycle Flag




A200.15: Initial Task Flag



A200.15 will turn ON during the first time a task is executed after it has reached executable status. It will be ON only while the task is being executed and will not turn ON if following cycles.





A201.10: Online Editing Wait Flag



A202.00 to A202.07: Communications Port Enabled Flags




The program is designed so that CMND(490) will be executed only when A202.00 is ON.

A300: Error Record Pointer
**A501.00 to A501.15: CPU Bus Unit Restart Bits and
 A302.00 to A302.15: CPU Bus Unit Initialization Flags**


A401.09: Program Error Flag

	Error	Address
Program Error Flag (A401.09): ON	UM Overflow Error Flag	A295.15
	Illegal Instruction Flag	A295.14
	Distribution Overflow Error Flag	A295.13
	Task Error Flag	A259.12
	No END(001) Error Flag	A295.11
	Illegal Area Access Error Flag	A295.10
	Indirect DM Addressing Error Flag	A295.09
	Instruction Processing Error Flag (ER Flag goes ON)	A295.08

A426.15: Interrupt Task Error Cause Flag



Appendix E

Memory Map

PLC Memory Addresses

PLC memory addresses are set in Index Registers (IR00 to IR15) to indirectly address I/O memory. Normally, use the MOVE TO REGISTER (MOVW(560)) and MOVE TIMER/COUNTER PV TO REGISTER (MOVW(561)) instructions to set PLC memory addresses into the Index Registers.

Some instructions, such as DATA SEARCH (SRCH(181)), FIND MAXIMUM (MAX(182)), and FIND MINIMUM (MIN(183)), output the results of processing to an Index Register to indicate an PLC memory address.

There are also instructions for which Index Registers can be directly designated to use the PLC memory addresses stored in them by other instructions. These instructions include DOUBLE MOVE (MOVL(498)), some symbol comparison instructions (=L, <>L, <L, >L, <=L, and >=L), DOUBLE COMPARE (CMPL(060)), DOUBLE DATA EXCHANGE (XCGL(562)), DOUBLE INCREMENT BINARY (++L(591)), DOUBLE DECREMENT BINARY (--L(593)), DOUBLE SIGNED BINARY ADD WITHOUT CARRY (+L(401)), DOUBLE SIGNED BINARY SUBTRACT WITHOUT CARRY (-L(411)), SET RECORD LOCATION (SETR(635)), and GET RECORD LOCATION (GETR(636)).

The PLC memory addresses all are continuous and the user must be aware of the order and boundaries of the memory areas. As reference, the PLC memory addresses are provided in a table at the end of this appendix.

Note Directly setting PLC memory addresses in the program should be avoided whenever possible. If PLC memory addresses are set in the program, the program will be less compatible with new CPU Unit models or CPU Units for which changes have been made to the layout of the memory.

Memory Configuration

There are two classifications of the RAM memory (with battery backup) in a CP-series CPU Unit.

Parameter Areas: These areas contain CPU Unit system setting data, such as the PLC Setup, CPU Bus Unit Setups, etc. An illegal access error will occur if an attempt is made to access any of the parameter areas from an instruction in the user program.

I/O Memory Areas: These are the areas that can be specified as operands in the instructions in user programs.

Memory Map

Note Do not access the areas indicated *Reserved for system*.

Classification	PLC memory addresses (hex)	User addresses	Area
Parameter areas	00000 to 0B0FFF	---	PLC Setup Area Routing Table Area CPU Bus Unit Setup Area
I/O memory areas	0B100 to 0B1FFF	---	Reserved for system.
	0B200 to 0B7FFF	---	Reserved for system.
	0B800 to 0B801	TK00 to TK31	Task Flag Area
	0B802 to 0B83F	---	Reserved for system.
	0B840 to 0B9FFF	A0 to A447	Read-only Auxiliary Area
	0BA00 to 0BBFFF	A448 to A959	Read/Write Auxiliary Area
	0BC00 to 0BDFFF	---	Reserved for system.
	0BE00 to 0BEFFF	T0000 to T4095	Timer Completion Flags
	0BF00 to 0BFFFF	C0000 to C4095	Counter Completion Flags
	0C000 to 0D7FFF	CIO 0 to CIO 6143	CIO Area
	0D800 to 0D9FFF	H0 to H511	Holding Area
	0DA00 to 0DDFFF	---	Reserved for system.
	0DE00 to 0DFFFF	W0 to W511	Work Area
	0E000 to 0EFFF	T0000 to T4095	Timer PVs
	0F000 to 0FFFF	C0000 to C4095	Counter PVs
	10000 to 17FFF	D0 to D32767	DM Area
	18000 to 1FFFF	---	Reserved for system.
	20000 to 27FFF	---	Reserved for system.
	Etc.	Etc.	Etc.
	48000 to 4FFFF	---	Reserved for system.
	Etc.	Etc.	Etc.
	F8000 to FFFFF	---	Reserved for system.

Appendix F

Connections to Serial Communications Option Boards

Connection Methods

Communications Modes and Ports

The following table shows the relationship between the communications ports and the communications modes for the Serial Communications Option Boards.

Communications mode	RS-232C CP1W-CIF01		RS-422A/485 CP1W-CIF11/CIF12			
	1:1	1:N (See note 1.)	1:1 4-wire	1:N 4-wire	1:1 2-wire	1:N 2-wire
Host Link	YES	YES (See note 2.)	YES	YES	No	No
Serial PLC Links	YES	YES	YES	YES	YES	YES
Serial Gateway	YES	YES	YES	YES	YES	YES
No-protocol	YES	YES	YES	YES	YES	YES
1:N NT Link	YES	YES	YES	YES	YES	YES

Note (1) The NT-AL001 Link Adapter can be used to convert between RS-232C and RS-422A/485 to enable 1:N communications.

(2) Use 4-wire connections between Link Adapters.

Models of Serial Communications Option Board


Model	Port	Maximum transmission distance	Connection method
CP1W-CIF01	One RS-232C port	15 m	Connector (D-sub, 9-pin female)
CP1W-CIF11	One RS-422A/485 port	50 m (See note.)	Terminal block (using ferrules)
CP1W-CIF12	One RS-422A/485 port	500 m	Terminal block (using ferrules)

Note The CP1W-CIF11 is a non-isolated board, so the maximum transmission distance is 50 m. For distances over 50 m, use the RS-232C port on the CP1W-CIF01 and then connect through the NT-AL001 Link Adapter, which is isolated. Doing so will enable a maximum transmission distance of 500 m.


Reducing Electrical Noise for External Wiring

Observe the following precautions when wiring communications cables, PLC power lines, and high-power lines. When multi-conductor signal cable is being used, avoid using I/O wires and other control wires in the same cable.

- If wiring racks are running in parallel, allow at least 300 mm between the racks.




- If the I/O wiring and power cables must be placed in the same duct, they must be shielded from each other using grounded steel sheet metal.



2-Wire and 4-Wire Connections

The transmission circuits for 2-wire and 4-wire connections are different, as shown in the following diagram.



- Note**
- (1) Use the same transmission circuit (2-wire or 4-wire) for all nodes.
 - (2) Do not use 4-wire connections when the 2/4-wire switch on the Board is set to 2-wire.

NT-AL001 Link Adapter Settings

The NT-AL001 Link Adapter has a DIP switch for setting RS-422A/485 communications conditions. When connecting the Serial Communications Option Board, refer to the DIP switch settings shown in the following table.

Pin	Function	Factory setting
1	Not used. Always set this pin to ON.	ON
2	Built-in terminating resistance setting ON: Connects terminating resistance. OFF: Disconnects terminating resistance.	ON
3	2/4-wire setting	OFF
4	2-wire: Set both pins to ON. 4-wire: Set both pins to OFF.	OFF
5	Transmission mode (See note.) Constant transmission: Set both pins to OFF.	ON
6	Transmission performed when CTS signal in RS-232C interface is at high level: Set pin 5 to OFF and pin 6 to ON. Transmission performed when CTS signal in RS-232C interface is at low level: Set pin 5 to ON and pin 6 to OFF.	OFF

Note When connecting to a CP-series CPU Unit, turn OFF pin 5 and turn ON pin 6.

Connections for Host Link Communications

Port connections for Host Link communications are shown in the following table. Up to 32 nodes can be connected for 1:N connections.

Port	Configuration	Schematic diagram, RS-232C ports	Schematic diagram, RS-422A/485 ports
Computer to PLC: C-mode or FINS commands PLC to computer: FINS commands	1:1		
Computer to PLC: C-mode or FINS commands	1:N		

- Note**
- (1) Four-wire connections must be used for RS-422A/485 connections with Host Link communications.
 - (2) “Resistance ON” indicates the terminating resistance must be turned ON.
 - (3) “5-V power” indicates that a 5-V power supply is required for the Link Adapter. Refer to the Link Adapter manual for details. A 5-V power supply is not required for a Link Adapter connected to an RS-232C Option Board mounted on the CPU Unit because power is supplied from pin 6 of the connector.
 - (4) The maximum cable length for RS-232C is 15 m. The RS-232C standard, however, does not cover baud rates above 19.2 Kbps. Refer to the manual for the device being connected to confirm support.


Connection Examples

The connection examples in the remainder of this section show only the basic connection diagrams. We recommend that appropriate noise countermeasures be taken in actual applications, including the use of shielded twisted-pair cables. Refer to *Recommended RS-422A/485 Wiring Examples* on page 735 for actual wiring methods.


Host Computer Connections

1:1 Connections Using RS-232C Ports

- IBM PC/AT or Compatible Computers



- Using NT-AL001 Converting Link Adapters




Note We recommend using the following NT-AL001 Link Adapter Connecting Cables to connect to NT-AL001 Link Adapters.

XW2Z-070T-1: 0.7 m

XW2Z-200T-1: 2 m


Caution Do not use the 5-V power from pin 6 of the RS-232C Option Board for anything but the NT-AL001 Link Adapter. Using this power supply for any other external device may damage the RS-232C Option Board or the external device.

1:N Connections Using RS-232C Ports


Note We recommend using the following NT-AL001 Link Adapter Connecting Cables to connect to NT-AL001 Link Adapters.


XW2Z-070T-1: 0.7 m

XW2Z-200T-1: 2 m

1:1 Connections Using RS-422A/485 Port


DIP Switch Settings
 Pin 1: ON
 Pin 2: ON
 (terminating resistance)
 Pin 3: OFF
 Pin 4: OFF
 Pin 5: OFF
 Pin 6: OFF

1:N Connections Using RS-422A/485 Ports




Programmable Terminal (PT) Connections

Direct Connections from RS-232C to RS-232C Ports



- Communications Mode: Host Link (unit number 0 only for Host Link)
NT Link (1:N, N = 1 Unit only)
- OMRON Cables with Connectors:
XW2Z-200T-1: 2 m
XW2Z-500T-1: 5 m

1:1 Connections from RS-422A/485 to RS-422A/485 Ports




- Communications Mode: Host Link (unit number 0 only for Host Link)
NT Link (1:N, N = 1 Unit only)

Note (1) RS-422A/485 Option Board settings:

Terminating resistance ON, 4-wire.

- (2) The terminating resistant setting shown above is an example for the NT631/NT631C. The setting method varies with the PT. Refer to the manual for you PT for details.


1:N, 4-wire Connections from RS-422A/485 to RS-422A/485 Ports

- Communications Mode: 1:N NT Link

Note (1) RS-422A/485 Option Board settings:

Terminating resistance ON, 4-wire.

- (2) The terminating resistant setting shown above is an example for the NT631/NT631C. The setting method varies with the PT. Refer to the manual for you PT for details.

1:N, 2-wire Connections from RS-422A/485 to RS-422A/485 Ports

- Communications Mode: 1:N NT Link

Note (1) RS-422A/485 Option Board settings:

Terminating resistance ON, 2-wire.

- (2) The terminating resistant setting shown above is an example for the NT631/NT631C. The setting method varies with the PT. Refer to the manual for you PT for details.

Connections for Serial Gateway and No-protocol Communications

This section describes the connections for Serial Gateway, and no-protocol communications. Up to 32 nodes can be used for 1:N connections.

Port	Configuration	Schematic diagram
RS-232C	1:1	
RS-232C	1:N	

- Note**
- (1) The maximum cable length for RS-232C is 15 m. The RS-232C standard, however, does not cover baud rates above 19.2 Kbps. Refer to the manual for the device being connected to confirm support.
 - (2) The combined cable length for RS-422A/485 is 500 m including branch lines.
 - (3) The maximum cable length is limited to 2 m when an NT-AL001 Link Adapter is connected.
 - (4) Branch lines must be a maximum of 10 m long.

Port	Configuration	Schematic diagram
RS-422A/485	1:1	
RS-422A/485	1:N	


- Note**
- (1) The maximum cable length for RS-232C is 15 m. The RS-232C standard, however, does not cover baud rates above 19.2 Kbps. Refer to the manual for the device being connected to confirm support.
 - (2) The CP1W-CIF11 is a non-isolated board, so the maximum transmission distance is 50 m. The CP1W-CIF12 is an isolated board, so the maximum transmission distance is 500m. For distances over 50 m, use the RS-422A/485 port on the CP1W-CIF12 directly, or the RS-232C port on the CP1W-CIF01 and then connect through the NT-AL001 Link Adapter, which is isolated. Doing so will enable a maximum transmission distance of 500 m.
 - (3) The maximum cable length is limited to 2 m when an NT-AL001 Link Adapter is connected.
 - (4) Branch lines must be a maximum of 10 m long.

Connection Examples


The connection examples in the remainder of this section show only the basic connection diagrams. We recommend that appropriate noise countermeasures be taken in actual applications, including the use of shielded twisted-pair cables. Refer to *RS-232C and RS-422A/485 Wiring* for actual wiring methods.

Connecting RS-232C Ports 1:1


Connections to E5CK Controller




Connections to a Host Computer



Connections to a Personal Computer with RTS-CTS Flow Control



Connecting a Host Computer with NT-AL001 Converting Link Adapters




Note We recommend using the following NT-AL001 Link Adapter Connecting Cables to connect to NT-AL001 Link Adapters.



XW2Z-200T-1: 2 m

XW2Z-500T-1: 5 m

Connections to a Modem



1:N Connections Using RS-232C Ports




Note We recommend using the following NT-AL001 Link Adapter Connecting Cables to connect to NT-AL001 Link Adapters.


XW2Z-070T-1: 0.7 m


XW2Z-200T-1: 2 m

1:1 Connections Using RS-422A/485 Ports




1:N Connections Using RS-422A/485 Ports






1:N NT Link Connections with Programmable Terminals

Direct Connections from RS-232C to RS-232C Ports



- Communications Mode: Host Link (unit number 0 only for Host Link)
NT Link (1:N, N = 1 Unit only)
- OMRON Cables with Connectors:
XW2Z-070T-1: 0.7 m
XW2Z-200T-1: 2 m


1:N, 4-wire Connections from RS-422A/485 to RS-422A/485 Ports

- Communications Mode: 1:N NT Link

Note (1) RS-422A/485 Option Board settings:

Terminating resistance ON, 4-wire.

- (2) The terminating resistant setting shown above is an example for the NT631/NT631C. The setting method varies with the PT. Refer to the manual for you PT for details.

1:N, 2-wire Connections from RS-422A/485 to RS-422A/485 Ports

- Communications Mode: 1:N NT Link

Note (1) RS-422A/485 Option Board settings:


Terminating resistance ON, 2-wire.

- (2) The terminating resistant setting shown above is an example for the NT631/NT631C. The setting method varies with the PT. Refer to the manual for you PT for details.

Serial PLC Link Connection Examples

This section provides connection examples for using Serial PLC Link. The communications mode used here is Serial PLC Link.


Connecting an RS-422A Converter




Note The CP1W-CIF11 is not insulated, so the total transmission distance for the whole transmission path is 50 m max. If the total transmission distance is greater than 50 m, use the RS-422A/485 port on the CP1W-CIF12 directly, or the insulated NT-AL001, and do not use the CP1W-CIF11. If the CP1W-CIF12 or NT-AL001 is used, the total transmission distance for the whole transmission path is 500 m max.

Connection with an RS-232C Port

RS-232C connection is also possible when using a Serial PLC Link to connect two CP1H CPU Units.




Connection Examples



Connections in Loopback Test

Connect the communications ports as shown below.



RS-232C and RS-422A/485 Wiring

Recommended RS-232C Wiring Examples

It is recommended that RS-232C cables be connected as described below especially when the Option Board is used in an environment where it is likely to be subject to electrical noise.



1. Always use shielded twisted-pair cables as communications cables.

Model	Manufacturer
UL2464 AWG28x5P IFS-RVV-SB (UL product) AWG28x5P IFVV-SB (non-UL product)	Fujikura Ltd.
UL2464-SB (MA) 5Px28AWG (7/0.127) (UL product) CO-MA-VV-SB 5Px28AWG (7/0.127) (non-UL product)	Hitachi Cable, Ltd.


2. Combine signal wires and SG (signal ground) wires in a twisted-pair cable. At the same time, bundle the SG wires to the connectors on Option Board and the remote device.
3. Connect the shield of the communications cable to the Hood (FG) terminal of the RS-232C connector on the Option Board. At the same time, ground the ground (GR) terminal of the CPU Unit to 100 Ω or less.
4. A connection example is shown below.

Example: Twisted-pair Cable Connecting SD-SG, RD-SG, RTS-SG, and CTS-SG Terminals in Toolbus Mode

Actual Wiring Example



Note The Hood (FG) is internally connected to the ground terminal (GR) on the CPU Unit. Therefore, FG is grounded by grounding the ground terminal (GR) on the power supply terminal block. Although there is conductivity between the Hood (FG) and pin 1 (FG), connect the Hood (FG) to the shield because the Hood (FG) has smaller contact resistance with the shield than pin 1 (FG), and thus provides better noise resistance.



Recommended RS-422A/485 Wiring Examples

Use the following wiring methods for RS-422A/485 to maintain transmission quality.

1. Always use shielded twisted-pair cables as communications cables.


Model	Manufacturer
CO-HC-ESV-3Px7/0.2	Hirakawa Hewtech Corp.

2. Connect the shield of the communications cable to the FG terminal on the RS-422A/485 Option Board. At the same time, ground the ground (GR) terminal of the CPU Unit to 100 Ω or less.


Note Always ground the shield only at the RS-422A/485 Option Board end. Grounding both ends of the shield may damage the device due to the potential difference between the ground terminals.

Connection examples are shown below.


• 2-Wire Connections




• 4-Wire Connections



• Using a B500-AL001-E Link Adapter



- With NT-AL001 RS-232C/RS-422 Link Adapter




Note (1) The following cables are available for this connection.

Length	Model
70 cm	XW2Z-070T-1
2 m	XW2Z-200T-1

It is recommended that one of these cables be used to connect the RS-232C port on the Option Board to the NT-AL001 RS-232C/RS-422 Link Adapter. The recommended wiring for these cables is shown below.

- Wiring for the Recommended Cables (XW2Z-070T-1 and XW2Z-200T-1, 10-conductor Cables)



- (2) The XW2Z-070T-1 and XW2Z-200T-1 Connecting Cables for the NT-AL001 Link Adapter uses special wiring for the DTS and RTS signals. Do not use these signals with other devices; they may be damaged.
- (3) The Hood (FG) is internally connected to the ground terminal (GR) on the CPU Unit. Therefore, FG is grounded by grounding the ground terminal (GR) on the power supply terminal block.


Wiring Connectors

Use the following steps to wire connectors.


See the following diagrams for the length of the cable portion to be cut in each step.

Shield Connected to Hood (FG)


1. Cut the cable to the required length.
2. Remove the specified length of the sheath from the cable using a knife. Be careful not to scratch the braided shield.



3. Trim off the braided shield using scissors so that the remaining shield length is 10 mm.




4. Remove the insulation from each conductor using a stripper so that the exposed conductor length is 5 mm.



5. Fold back the braided shield.




6. Wrap aluminum foil tape around the folded shield.



Shield Not Connected to Hood (FG)

1. Cut the cable to the required length.
2. Remove the specified length of the sheath from the cable using a knife. Be careful not to scratch the braided shield.



3. Trim off all the braided shield using scissors.



4. Remove the insulation from each conductor using a stripper so that the exposed conductor length is 5 mm.




5. Wrap adhesive tape around the conductor from which the braided shield was removed.




Soldering

1. Thread a heat-shrinking tube through each conductor.
2. Temporarily solder each conductor to the corresponding connector terminals.
3. Completely solder each conductor.




4. Return the heat-shrinking tube to the soldered portion, then heat the tube to shrink it in place.




Assembling Connector Hood

Assemble the connector hood as shown below.



Connecting to Unit



Appendix G

PLC Setup

Startup Settings

Startup Hold Settings

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Force Status Hold Bit	Not held.	Not held.	When power is turned ON	80	14	0
			Held.				1
2	IOM Hold Bit	Not held.	Not held.	When power is turned ON	80	15	0
			Held.				1

Startup Data Read Setting

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Read DM from flash memory	Do not read.	Do not read.	When power is turned ON	82	15	0
			Read.				1

Mode: CPU Unit Operating Mode

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Use programming console (RUN mode)	Use programming console (RUN mode) (See note.)	Use programming console: RUN mode	When power is turned ON	81	00 to 15	0000 hex
			Program: PROGRAM mode				8000 hex
			Monitor: MONITOR mode				8001 hex
			Run: RUN mode				8002 hex

Note A Programming Console cannot be connected to the CP1H. If the default setting, "Use programming console," is set, the CPU Unit will start in RUN mode.

Settings: CPU Unit Settings

Execute Process Settings

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Do not detect Low Battery (run without battery)	Detect.	Detect	Every cycle	128	15	0
			Do not detect.				1
2	Detect Interrupt Task Error	Detect.	Detect	Every cycle	128	14	0
			Do not detect.				1
3	Stop CPU on Instruction Error	Do not stop.	Do not stop.	At start of operation	197	15	0
			Stop				1
4	Don't register FAL to error log	Register.	Register.	Every cycle	129	15	0
			Do not register.				1

Background Execution Settings

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Table data process instructions	Do not execute in background.	Do not execute in background. Execute in background.	At start of operation	198	15	0 1
2	String data process instructions	Do not execute in background.	Do not execute in background. Execute in background.	At start of operation	198	14	0 1
3	Data shift process instructions	Do not execute in background.	Do not execute in background. Execute in background.	At start of operation	198	13	0 1
4	Com Port number (logical number)	Port 00	0: Port 0 : 7: Port 7	At start of operation	198	00 to 03	0 hex : 7 hex

Comms Instructions Settings in FB:

Settings for Communications Instructions in Function Blocks

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Retry Counts: Number of retries	0	0 to 15	At start of operation	200	00 to 03	0 hex : F hex
2	Response Timeout (default 2s), Comms Instructions in FB	2 s	2 s	At start of operation	201	00 to 15	0000 hex
			1: 1 × 0.1 s				0001 hex
			:				:
			65535: 65,535 × 0.1 s				FFFF hex
3	Response Timeout (default 2s), DeviceNet Comms Instruction in FB	2 s	2 s	At start of operation	202	00 to 15	0000 hex
			1: 1 × 0.1 s				0001 hex
			:				:
			65535: 65,535 × 0.1 s				FFFF hex

Timings: Time and Interrupt Settings

Cycle Time Settings

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Watch Cycle Time (default 1000 ms)		Use default.	Use default. (Default: 1 s)	At start of operation	209	15	0
				Use user setting.				1
	1-1	Watch Cycle Time (default 1000 ms)	1,000 ms	1: 1 × 10 ms	At start of operation	209	00 to 14	001 hex
				:				:
				40,000: 40,000 × 10 ms				FA0 hex
2	Cycle Time (No Setting)		No minimum cycle time	No minimum cycle time	At start of operation	208	00 to 15	0000 hex
				1 ms				0001 hex
				:				:
				32,000 ms				7D00 hex

Interrupt Setting

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Scheduled Interrupt Interval		10 ms	10 ms	At start of operation	195	00 to 03	0 hex
				1 ms				1 hex
				0.1 ms				2 hex

Input Constant Settings

Input Constant (0-17CH): Input Constant Settings for CIO 0 to CIO 17

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	0CH: CIO 0	8 ms Default (8ms)	No filter (0 ms) 0.5 ms 1 ms 2 ms 4 ms 8 ms 16 ms 32 ms	When power is turned ON	10	00 to 07	10 hex 11 hex 12 hex 13 hex 14 hex 15 hex 16 hex 17 hex
2	1CH: CIO 1	Same as above.	Same as above.	Same as above.	10	08 to 15	Same as above.
3	2CH: CIO 2				11	00 to 07	
4	3CH: CIO 3				11	08 to 15	
5	4CH: CIO 4				12	00 to 07	
6	5CH: CIO 5				12	08 to 15	
7	6CH: CIO 6				13	00 to 07	
8	7CH: CIO 7				13	08 to 15	
9	8CH: CIO 8				14	00 to 07	
10	9CH: CIO 9				14	08 to 15	
11	10CH: CIO 10				15	00 to 07	
12	11CH: CIO 11				15	08 to 15	
13	12CH: CIO 12				16	00 to 07	
14	13CH: CIO 13				16	08 to 15	
15	14CH: CIO 14				17	00 to 07	
16	15CH: CIO 15				17	08 to 15	
17	16CH: CIO 16				18	00 to 07	
18	17CH: CIO 17				18	08 to 15	

Serial Port 1 Settings

Serial Communications Settings

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Communications Settings		Standard (9600; 1,7,2,E)	Standard (9600; 1,7,2,E) (The standard settings are as follows: 9,600 baud, 1 start bit, 7-bit data, even parity, and 2 stop bits.)	Every cycle	144	15	0
				Custom				1
2	Mode		Host Link	Host Link	Every cycle	144	08 to 11	0 hex
				NT Link (1:N)				5 hex
				RS-232C				2 hex
				ToolBus (peripheral bus)				3 hex
				Serial Gateway				4 hex
				PC Link (Slave)				9 hex
				PC Link (Master)				7 hex
								8 hex
2-1	Host Link							
	2-1-1	Baud	9,600 bps	300 bps	Every cycle	145	00 to 07	01 hex
				600 bps				02 hex
				1,200 bps				03 hex
				2,400 bps				04 hex
				4,800 bps				05 hex
				9,600 bps				00 or 06 hex
				19,200 bps				07 hex
				38,400 bps				08 hex
				57,600 bps				09 hex
				115,200 bps				0A hex
	2-1-2	Format (data length, stop bits, parity)	7,2,E: 7-bit data, 2 stop bits, even parity	7,2,E: 7-bit data, 2 stop bits, even parity	Every cycle	144	00 to 03	0 hex
				7,2,O: 7-bit data, 2 stop bits, odd parity				1 hex
				7,2,N: 7-bit data, 2 stop bits, no parity				2 hex
				7,1,E: 7-bit data, 2 stop bits, even parity				4 hex
				7,1,O: 7-bit data, 1 stop bit, odd parity				5 hex
				7,1,N: 7-bit data, 1 stop bit, no parity				6 hex
				8,2,E: 8-bit data, 2 stop bits, even parity				8 hex
				8,2,O: 8-bit data, 2 stop bits, odd parity				9 hex
				8,2,N: 8-bit data, 2 stop bits, no parity				A hex
				8,1,E: 8-bit data, 1 stop bit, even parity				C hex
				8,1,O: 8-bit data, 1 stop bit, odd parity				D hex
				8,1,N: 8-bit data, 1 stop bit, no parity				E hex
	2-1-3	Unit Number	0	0	Every cycle	147	00 to 07	00 hex
				:				:
				31				1F hex

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings		
2	2-2	NT Link (1:N): 1:N NT Links								
		2-2-1	Baud	9,600 (disabled)	38,400 (standard)	Every cycle	145	00 to 07	00 hex	
					115,200 (high speed)				0A hex	
		2-2-2	NT/PC Link Max: Highest unit num- ber	0	0	Every cycle	150	00 to 03	0 hex	
					:				:	
					7				7 hex	
		2-3	RS-232C							
			2-3-1	Baud	9600 bps	300 bps	Every cycle	145	00 to 07	01 hex
						600 bps				02 hex
	1,200 bps					03 hex				
	2,400 bps					04 hex				
	4,800 bps					05 hex				
	9,600 bps					00 or 06 hex				
	19,200 bps					07 hex				
	38,400 bps					08 hex				
	57,600 bps					09 hex				
	115,200 bps					0A hex				
	2-3-2		Format (data length, stop bits, parity)	7,2,E: 7-bit data, 2 stop bits, even parity	7,2,E: 7-bit data, 2 stop bits, even parity	Every cycle	144	00 to 03	0 hex	
					7,2,O: 7-bit data, 2 stop bits, odd parity				1 hex	
					7,2,N: 7-bit data, 2 stop bits, no parity				2 hex	
					7,1,E: 7-bit data, 2 stop bits, even parity				4 hex	
					7,1,O: 7-bit data, 1 stop bit, odd parity				5 hex	
					7,1,N: 7-bit data, 1 stop bit, no parity				6 hex	
					8,2,E: 8-bit data, 2 stop bits, even parity				8 hex	
					8,2,O: 8-bit data, 2 stop bits, odd parity				9 hex	
					8,2,N: 8-bit data, 2 stop bits, no parity				A hex	
					8,1,E: 8-bit data, 1 stop bit, even parity				C hex	
					8,1,O: 8-bit data, 1 stop bit, odd parity				D hex	
					8,1,N: 8-bit data, 1 stop bit, no parity				E hex	
	2-3-3		Start Code	Disable.	Disable.	Every cycle	149	12	0	
					Set.				1	
	2-3-4		Start Code	00 hex0x0000	0x0000	Every cycle	148	08 to 15	00 hex	
					:				:	
					0x00FF				FF hex	
	2-3-5		End Code	Received Bytes: Receive specified num- ber of bytes.	Received Bytes: Receive specified number of bytes.	Every cycle	149	08 and 09	00	
					CR,LF				10	
					Set End Code				01	
	2-3-6		Received Bytes	256 bytes	256 bytes	Every cycle	149	00 to 07	00 hex	
					1 byte				01 hex	
					:				:	
					255 bytes				FF hex	

	Name			Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings				
2	2-3	2-3-7	Set End Code	0x0000	1 byte	Every cycle	148	00 to 07	00 hex				
					:				:				
					255 bytes				FF hex				
		2-3-8	Delay	0 ms	0: 0 × 10 ms	Every cycle	146	00 to 15	0000 hex				
					:				:				
					9999: 9999 × 10 ms				270F hex				
	2-4	ToolBus (peripheral bus)											
		2-4-1	Baud	9,600 bps	9,600 bps	Every cycle	145	00 to 07	00 or 06 hex				
					19,200 bps				07 hex				
					38,400 bps				08 hex				
					57,600 bps				09 hex				
					115,200 bps				0A hex				
	2-5 Serial Gateway												
2-5-1	Baud	9,600 bps	300 bps	Every cycle	145	00 to 07	01 hex						
			600 bps				02 hex						
			1,200 bps				03 hex						
			2,400 bps				04 hex						
			4,800 bps				05 hex						
			9,600 bps				00 or 06 hex						
			19,200 bps				07 hex						
			38,400 bps				08 hex						
			57,600 bps				09 hex						
			115,200 bps				0A hex						
			2-5-2				Format (data length, stop bits, parity)	7,2,E: 7-bit data, 2 stop bits, even parity	7,2,E: 7-bit data, 2 stop bits, even parity	Every cycle	144	00 to 03	0 hex
									7,2,O: 7-bit data, 2 stop bits, odd parity				1 hex
									7,2,N: 7-bit data, 2 stop bits, no parity				2 hex
									7,1,E: 7-bit data, 2 stop bits, even parity				4 hex
									7,1,O: 7-bit data, 1 stop bit, odd parity				5 hex
									7,1,N: 7-bit data, 1 stop bit, no parity				6 hex
									8,2,E: 8-bit data, 2 stop bits, even parity				8 hex
									8,2,O: 8-bit data, 2 stop bits, odd parity				9 hex
									8,2,N: 8-bit data, 2 stop bits, no parity				A hex
8,1,E: 8-bit data, 1 stop bit, even parity	C hex												
8,1,O: 8-bit data, 1 stop bit, odd parity	D hex												
8,1,N: 8-bit data, 1 stop bit, no parity	E hex												
2-5-3	Response Timeout	50: 50 × 100 ms = 5 s	50: 50 × 100 ms = 5 s	Every cycle	151	08 to 15	00 hex						
			1: 1 × 100 ms				01 hex						
			:				:						
			255: 255 × 100 ms				FF hex						

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings	
2	2-6	PC Link (Slave)							
		2-6-1	Baud	9,600 bps (disabled)	38,400 (standard)	Every cycle	145	00 to 07	00 hex
					115,200 (high speed)				0A hex
		2-6-2	PC Link Unit No.	0	0	Every cycle	151	00 to 03	0 hex
					:				:
					7				7 hex
	2-7	PC Link (Master)							
		2-7-1	Baud	9,600 bps (disabled)	38,400 (standard)	Every cycle	145	00 to 07	00 hex
					115,200 (high speed)				0A hex
		2-7-2	Link Words	10 (default)	1 : 10 (default)	Every cycle	150	04 to 07	1 hex : 0 or A hex
		2-7-3	PC Link Mode	ALL	ALL	Every cycle	150	15	0
					Masters				1

Serial Port 2 Settings

Serial Communications Settings

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Communications Settings		Standard (9600 ; 1,7,2,E)	Standard (9600; 1,7,2,E) (The standard settings are as follows: 9,600 baud, 1 start bit, 7-bit data, even parity, and 2 stop bits.)	Every cycle	160	15	0
				Custom				1
2	Mode		Host Link	Host Link	Every cycle	160	08 to 11	0 hex
				NT Link (1:N): 1:N NT Links				5 hex
				RS-232C				2 hex
				ToolBus (peripheral bus)				3 hex
				Serial Gateway				4 hex
				PC Link (Slave)				9 hex
				PC Link (Master)				7 hex
								8 hex
2-1	Host Link							
	2-1-1	Baud	9,600 bps	300 bps	Every cycle	161	00 to 07	01 hex
				600 bps				02 hex
				1,200 bps				03 hex
				2,400 bps				04 hex
				4,800 bps				05 hex
				9,600 bps				00 or 06 hex
				19,200 bps				07 hex
				38,400 bps				08 hex
				57,600 bps				09 hex
				115,200 bps				0A hex
	2-1-2	Format (data length, stop bits, parity)	7,2,E: 7-bit data, 2 stop bits, even parity	7,2,E: 7-bit data, 2 stop bits, even parity	Every cycle	160	00 to 03	0 hex
				7,2,O: 7-bit data, 2 stop bits, odd parity				1 hex
				7,2,N: 7-bit data, 2 stop bits, no parity				2 hex
				7,1,E: 7-bit data, 2 stop bits, even parity				4 hex
				7,1,O: 7-bit data, 1 stop bit, odd parity				5 hex
				7,1,N: 7-bit data, 1 stop bit, no parity				6 hex
				8,2,E: 8-bit data, 2 stop bits, even parity				8 hex
				8,2,O: 8-bit data, 2 stop bits, odd parity				9 hex
				8,2,N: 8-bit data, 2 stop bits, no parity				A hex
				8,1,E: 8-bit data, 1 stop bit, even parity				C hex
				8,1,O: 8-bit data, 1 stop bit, odd parity				D hex
				8,1,N: 8-bit data, 1 stop bit, no parity				E hex
	2-1-3	Unit Number	0	0	Every cycle	161	00 to 07	00 hex
				:				:
				31				1F hex

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings							
2	2-2	NT Link (1:N)													
		2-2-1	Baud	9,600 (disabled)	38,400 (standard)	Every cycle	161	00 to 07	00 hex						
					115,200 (high speed)				0A hex						
		2-2-2	NT/PC Link Max: Highest unit number	0	0	Every cycle	166	00 to 03	0 hex						
					:				:						
					7				7 hex						
		2-3	RS-232C												
			2-3-1	Baud	9600 bps	300 bps	Every cycle	161	00 to 07	01 hex					
						600 bps				02 hex					
	1,200 bps					03 hex									
	2,400 bps					04 hex									
	4,800 bps					05 hex									
	9,600 bps					00 or 06 hex									
	19,200 bps					07 hex									
	38,400 bps					08 hex									
	57,600 bps					09 hex									
	115,200 bps					0A hex									
	2-3-2					Format (data length, stop bits, parity)				7,2,E: 7-bit data, 2 stop bits, even parity	7,2,E: 7-bit data, 2 stop bits, even parity	Every cycle	160	00 to 03	0 hex
			7,2,O: 7-bit data, 2 stop bits, odd parity	1 hex											
			7,2,N: 7-bit data, 2 stop bits, no parity	2 hex											
			7,1,E: 7-bit data, 2 stop bits, even parity	4 hex											
			7,1,O: 7-bit data, 1 stop bit, odd parity	5 hex											
			7,1,N: 7-bit data, 1 stop bit, no parity	6 hex											
			8,2,E: 8-bit data, 2 stop bits, even parity	8 hex											
			8,2,O: 8-bit data, 2 stop bits, odd parity	9 hex											
			8,2,N: 8-bit data, 2 stop bits, no parity	A hex											
			8,1,E: 8-bit data, 1 stop bit, even parity	C hex											
			8,1,O: 8-bit data, 1 stop bit, odd parity	D hex											
			8,1,N: 8-bit data, 1 stop bit, no parity	E hex											
			2-3-3	Start Code	Disable.		Disable.	Every cycle	165		12				0
							Set.								1
	2-3-4		Start Code	00 hex0x0000	0x0000	Every cycle	164	08 to 15	00 hex						
					:				:						
					0x00FF				FF hex						
	2-3-5		End Code	Received Bytes: Receive specified number of bytes.	Received Bytes: Receive specified number of bytes.	Every cycle	165	08 and 09	00						
					CR,LF				10						
					Set End Code				01						
	2-3-6		Received Bytes	256 bytes	256 bytes	Every cycle	165	00 to 07	00 hex						
					1 byte				01 hex						
					:				:						
					255 bytes				FF hex						

	Name			Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings				
2	2-3	2-3-7	Set End Code	0x0000	0x0000	Every cycle	164	00 to 07	00 hex				
					:				:				
					0x00FF				FF hex				
		2-3-8	Delay	0: 0 × 10 ms	0: 0 × 10 ms	Every cycle	162	00 to 15	0000 hex				
					:				:				
					9999: 9999 × 10 ms				270F hex				
	2-4	ToolBus (peripheral bus)											
		2-4-1	Baud	9,600 bps	9,600 bps	Every cycle	161	00 to 07	00 or 06 hex				
					19,200 bps				07 hex				
					38,400 bps				08 hex				
					57,600 bps				09 hex				
					115,200 bps				0A hex				
	2-5 Serial Gateway												
	2-5-1	Baud	9,600 bps	300 bps	Every cycle	161	00 to 07	01 hex					
600 bps				02 hex									
1,200 bps				03 hex									
2,400 bps				04 hex									
4,800 bps				05 hex									
9,600 bps				00 or 06 hex									
19,200 bps				07 hex									
38,400 bps				08 hex									
57,600 bps				09 hex									
115,200 bps				0A hex									
2-5-2				Format (data length, stop bits, parity)				7,2,E: 7-bit data, 2 stop bits, even parity	7,2,E: 7-bit data, 2 stop bits, even parity	Every cycle	160	00 to 03	0 hex
									7,2,O: 7-bit data, 2 stop bits, odd parity				1 hex
									7,2,N: 7-bit data, 2 stop bits, no parity				2 hex
	7,1,E: 7-bit data, 2 stop bits, even parity	4 hex											
	7,1,O: 7-bit data, 1 stop bit, odd parity	5 hex											
	7,1,N: 7-bit data, 1 stop bit, no parity	6 hex											
	8,2,E: 8-bit data, 2 stop bits, even parity	8 hex											
	8,2,O: 8-bit data, 2 stop bits, odd parity	9 hex											
	8,2,N: 8-bit data, 2 stop bits, no parity	A hex											
	8,1,E: 8-bit data, 1 stop bit, even parity	C hex											
8,1,O: 8-bit data, 1 stop bit, odd parity	D hex												
8,1,N: 8-bit data, 1 stop bit, no parity	E hex												
2-5-3	Response Timeout	50: 50 × 100 ms = 5 s	50: 50 × 100 ms = 5 s	Every cycle	167	08 to 15	00 hex						
			1: 1 × 100 ms				01 hex						
			:				:						
			255: 255 × 100 ms				FF hex						

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings	
2	2-6	PC Link (Slave)							
		2-6-1	Baud	9,600 bps (disabled)	38,400 (standard)	Every cycle	161	00 to 07	00 hex
					115,200 (high speed)				0A hex
		2-6-2	PC Link Unit No.	0	0	Every cycle	167	00 to 03	0 hex
					:				:
					7				7 hex
		2-7	PC Link (Master)						
			2-7-1	Baud	9,600 bps (disabled)	38,400 (standard)	Every cycle	161	00 to 07
	115,200 (high speed)					0A hex			
	2-7-2		Link Words	10 (default)	1 : 10 (default)	Every cycle	166	04 to 07	1 hex : 0 or A hex
	2-7-3		PC Link Mode	ALL	ALL	Every cycle	166	15	0
					Masters				1

Peripheral Service Settings

Set Time to All Events: Time Setting for Services

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Set time to all events		Default	Default (4% of cycle time)	At start of operation	218	15	0
				Use user setting.				1
	1-1	Time allocated to services	0: 0 × 0.1 ms = 0 ms	0: 0 × 0.1 ms = 0 ms	At start of operation	218	00 to 07	00 hex
				:				:
				255: 255 × 0.1 ms				FF hex

Built-in Input Settings

High Speed Counter Settings

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings	
1	Use high speed counter 0		Do not use.	Do not use.	When power is turned ON	50	12 to 15	0 hex	
				Use.				1 hex	
	1-1	Counting mode		Linear mode	Linear mode	At start of operation	50	08 to 11	0 hex
					Circular mode				1 hex
		1-1-1	Circular Max. Count	0	0	At start of operation	52 and 51	00 to 15	0000
					:				0000 hex
	4,294,967,295				FFFF				
								FFFF hex	
	1-2	Reset		Z phase, software reset	Z phase, software reset	When power is turned ON	50	04 to 07	0 hex
					Software reset				1 hex
					Z phase, software reset (comparing)				2 hex
					Software reset (comparing)				3 hex
	1-3	Input Setting		Differential phase input	Differential phase input	When power is turned ON	50	00 to 03	0 hex
					Pulse + direction input				1 hex
					Up/Down input				2 hex
					Increment pulse input				3 hex
2	Use high speed counter 1		Do not use.	Do not use.	When power is turned ON	53	12 to 15	0 hex	
				Use.				1 hex	
	2-1	Counting mode		Linear mode	Linear mode	At start of operation	53	08 to 11	0 hex
					Circular mode				1 hex
		2-1-1	Circular Max. Count	0	0	At start of operation	55 and 54	00 to 15	0000
					:				0000 hex
	4,294,967,295				FFFF				
								FFFF hex	
	2-2	Reset		Z phase, software reset	Z phase, software reset	When power is turned ON	53	04 to 07	0 hex
					Software reset				1 hex
					Z phase, software reset (comparing)				2 hex
					Software reset (comparing)				3 hex
	2-3	Input Setting		Differential phase input	Differential phase input	When power is turned ON	53	00 to 03	0 hex
					Pulse + direction input				1 hex
					Up/Down input				2 hex
					Increment pulse input				3 hex

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings	
3	Use high speed counter 2		Do not use.	Do not use.	When power is turned ON	95	12 to 15	0 hex	
				Use.				1 hex	
	3-1	Counting mode		Linear mode	Linear mode	At start of operation	95	08 to 11	0 hex
									Circular mode
		3-1-1	Circular Max. Count	0	0	At start of operation	97 and 96	00 to 15	0000 0000 hex
					:				:
					4,294,967,295				FFFF FFFF hex
	3-2	Reset		Z phase, software reset	Z phase, software reset	When power is turned ON	95	04 to 07	0 hex
					Software reset				1 hex
					Z phase, software reset (comparing)				2 hex
					Software reset (comparing)				3 hex
	3-3	Input Setting		Differential phase input	Differential phase input	When power is turned ON	95	00 to 03	0 hex
					Pulse + direction input				1 hex
					Up/Down input				2 hex
					Increment pulse input				3 hex
4	Use high speed counter 3		Do not use.	Do not use.	When power is turned ON	98	12 to 15	0 hex	
				Use.				1 hex	
	4-1	Counting mode		Linear mode	Linear mode	At start of operation	98	08 to 11	0 hex
									Circular mode
		4-1-1	Circular Max. Count	0	0	At start of operation	100 and 99	00 to 15	0000 0000 hex
					:				:
					4,294,967,295				FFFF FFFF hex
	4-2	Reset		Z phase, software reset	Z phase, software reset	When power is turned ON	98	04 to 07	0 hex
					Software reset				1 hex
					Z phase, software reset (comparing)				2 hex
					Software reset (comparing)				3 hex
	4-3	Input Setting		Differential phase input	Differential phase input	When power is turned ON	98	00 to 03	0 hex
					Pulse + direction input				1 hex
					Up/Down input				2 hex
					Increment pulse input				3 hex

Interrupt Input Settings

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	IN0 (CIO 0.00)	Normal	Normal	When power is turned ON	60	00 to 03	0 hex
			Interrupt				1 hex
			Quick				2 hex
2	IN1 (CIO 0.01)	Normal	Normal	When power is turned ON	60	04 to 07	0 hex
			Interrupt				1 hex
			Quick				2 hex
3	IN2 (CIO 0.02) (Y CPU Units: CIO 1.00)	Normal	Normal	When power is turned ON	60	08 to 11	0 hex
			Interrupt				1 hex
			Quick				2 hex
4	IN3 (CIO 0.03) (Y CPU Units: CIO 1.01)	Normal	Normal	When power is turned ON	60	12 to 15	0 hex
			Interrupt				1 hex
			Quick				2 hex
5	IN4 (CIO 1.00) (Y CPU Units: CIO 1.02)	Normal	Normal	When power is turned ON	59	00 to 03	0 hex
			Interrupt				1 hex
			Quick				2 hex
6	IN5 (CIO 1.01) (Y CPU Units: CIO 1.03)	Normal	Normal	When power is turned ON	59	04 to 07	0 hex
			Interrupt				1 hex
			Quick				2 hex
7	IN6 (CIO 1.02)	Normal	Normal	When power is turned ON	59	08 to 11	0 hex
			Interrupt				1 hex
			Quick				2 hex
8	IN7 (CIO 1.03)	Normal	Normal	When power is turned ON	59	12 to 15	0 hex
			Interrupt				1 hex
			Quick				2 hex

Pulse Output 0 Settings

Base Settings

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Undefined Origin (operation for limit signal turning ON)	Hold	Hold	At start of operation	268	12 to 15	0 hex
			Undefined				1 hex
2	Limited Input Signal Operation	Search Only	Search Only	When power is turned ON	256	04 to 07	0 hex
			Always				1 hex
3	Limit Input Signal	NC	NC	At start of operation	268	00 to 03	0 hex
			NO				1 hex
4	Search/Return Initial Speed	0 pps	0 pps	At start of operation	259 and 258	00 to 15	0000 0000 hex
			:				:
			100,000 pps (maximum for X/XA CPU Unit) 1,000,000 pps (maximum for Y CPU Unit)				0001 86A0 hex 000F 4240 hex
5	Speed Curve	Trapezium	Trapezium	When power is turned ON	256	12 to 15	0 hex
			S-shaped				1 hex

Define Origin Operation Settings: Origin Search Settings

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Use define origin operation		Do not use.	Do not use.	When power is turned ON	256	00 to 03	0 hex
				Use.				1 hex
	1-1	Search Direction	CW	CW	At start of operation	257	12 to 15	0 hex
				CCW				1 hex
	1-2	Detection Method	Method 0	Method 0	At start of operation	257	08 to 11	0 hex
				Method 1				1 hex
				Method 2				2 hex
	1-3	Search Operation	Inverse 1	Inverse 1	At start of operation	257	04 to 07	0 hex
				Inverse 2				1 hex
	1-4	Operation Mode	Mode 0	Mode 0	At start of operation	257	00 to 03	0 hex
				Mode 1				1 hex
				Mode 2				2 hex
	1-5	Origin Input Signal (X/XA CPU Units)	NC	NC	Unit version 1.0 and earlier: At start of operation Unit version 1.1 and later: When power is turned ON	268	08 to 11	0 hex
				NO				1 hex
		Origin Input Signal (Y CPU Units)		NC (line driver)	At start of operation			2 hex
				NO (line driver)				3 hex
	1-6	Proximity Input Signal	NC	NC	At start of operation	268	04 to 07	0 hex
				NO				1 hex
	1-7	Search High Speed	0 pps (disabled)	1 pps	At start of operation	261 and 260	00 to 15	0000 0001 hex
				:				:
				100,000 pps (maximum for X/XA CPU Unit) 1,000,000 pps (maximum for Y CPU Unit)				0001 86A0 hex 000F 4240 hex
	1-8	Search Proximity Speed	0 pps (disabled)	1 pps	At start of operation	263 and 262	00 to 15	0000 0001 hex
				:				:
				100,000 pps (maximum for X/XA CPU Unit) 1,000,000 pps (maximum for Y CPU Unit)				0001 86A0 hex 000F 4240 hex
	1-9	Search Compensation Value	0 pps	−2,147,483,648	At start of operation	265 and 264	00 to 15	8000 0000 hex
				:				:
				0				0000 0000 hex
				:				:
				+2,147,483,647				7FFF FFFF hex
	1-10	Search Acceleration Ratio	0 (disabled)	1 (pulses/4 ms)	At start of operation	266	00 to 15	0001 hex
				:				:
				65,535 (pulses/4 ms)				FFFF hex
	1-11	Search Deceleration Ratio	0 (disabled)	1 (pulses/4 ms)	At start of operation	267	00 to 15	0001 hex
				:				:
				65,535 (pulses/4 ms)				FFFF hex
	1-12	Positioning Monitor Time	0 ms	0 ms	At start of operation	269	00 to 15	0000 hex
				:				:
9,999 ms				270F hex				

Origin Return Settings

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Speed	0 pps (disabled)	1 pps	At start of operation	271 and 270	00 to 15	0000 0001 hex
			:				:
			100,000 pps (maximum for X/XA CPU Unit) 1,000,000 pps (maximum for Y CPU Unit)				0001 86A0 hex 000F 4240 hex
2	Acceleration Ratio	0 (disabled)	1 (pulses/4 ms)	At start of operation	272	00 to 15	0001Hex
			:				:
			65535 (pulses/4 ms)				FFFF hex
3	Deceleration Ratio	0 (disabled)	1 (pulses/4 ms)	At start of operation	273	00 to 15	0001 hex
			:				:
			65535 (pulses/4 ms)				FFFF hex

Pulse Output 1 Settings

Base Settings

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Undefined Origin (operation for limit signal turning ON)	Hold	Hold	At start of operation	286	12 to 15	0 hex
			Undefined				1 hex
2	Limited Input Signal Operation	Search Only	Search Only	When power is turned ON	274	04 to 07	0 hex
			Always				1 hex
3	Limit Input Signal	NC	NC	At start of operation	286	00 to 03	0 hex
			NO				1 hex
4	Search/Return Initial Speed	0 pps	0 pps	At start of operation	277 and 276	00 to 15	0000 0000 hex
			:				:
			100,000 pps (maximum for X/XA CPU Unit) 1,000,000 pps (maximum for Y CPU Unit)				0001 86A0 hex 000F 4240 hex
5	Speed Curve	Trapezium	Trapezium	When power is turned ON	274	12 to 15	0 hex
			S-shaped				1 hex

Define Origin Operation Settings: Origin Search Settings

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Use define origin operation		Do not use.	Do not use.	When power is turned ON	274	00 to 03	0 hex
				Use.				1 hex
	1-1	Search Direction	CW	CW	At start of operation	275	12 to 15	0 hex
				CCW				1 hex
	1-2	Detection Method	Method 0	Method 0	At start of operation	275	08 to 11	0 hex
				Method 1				1 hex
				Method 2				2 hex
	1-3	Search Operation	Inverse 1	Inverse 1	At start of operation	275	04 to 07	0 hex
				Inverse 2				1 hex
	1-4	Operation Mode	Mode 0	Mode 0	At start of operation	275	00 to 03	0 hex
				Mode 1				1 hex
				Mode 2				2 hex
	1-5	Origin Input Signal (X/XA CPU Units)	NC	NC	Unit version 1.0 and earlier: At start of operation Unit version 1.1 and later: When power is turned ON	286	08 to 11	0 hex
				NO				1 hex
		Origin Input Signal (Y CPU Units)		NC (line driver)	At start of operation			2 hex
				NO (line driver)				3 hex
	1-6	Proximity Input Signal	NC	NC	At start of operation	286	04 to 07	0 hex
				NO				1 hex
	1-7	Search High Speed	0 pps (disabled)	1 pps	At start of operation	279 and 278	00 to 15	0000 0001 hex
				:				:
				100,000 pps (maximum for X/XA CPU Unit) 1,000,000 pps (maximum for Y CPU Unit)				0001 86A0 hex 000F 4240 hex
	1-8	Search Proximity Speed	0 pps (disabled)	1 pps	At start of operation	281 and 280	00 to 15	0000 0001 hex
				:				:
				100,000 pps (maximum for X/XA CPU Unit) 1,000,000 pps (maximum for Y CPU Unit)				0001 86A0 hex 000F 4240 hex
	1-9	Search Compensation Value	0 pps	-2,147,483,648	At start of operation	283 and 282	00 to 15	8000 0000 hex
				:				:
				0				0000 0000 hex
				:				:
:				:				
+2,147,483,647				7FFF FFFF hex				
1-10	Search Acceleration Ratio	0 (disabled)	1 (pulses/4 ms)	At start of operation	284	00 to 15	0001 hex	
			:				:	
			65,535 (pulses/4 ms)				FFFF hex	
1-11	Search Deceleration Ratio	0 (disabled)	1 (pulses/4 ms)	At start of operation	285	00 to 15	0001 hex	
			:				:	
			65,535 (pulses/4 ms)				FFFF hex	
1-12	Positioning Monitor Time	0 ms	0 ms	At start of operation	287	00 to 15	0000 hex	
			:				:	
			9,999 ms				270F hex	

Origin Return Settings

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Speed	0 pps (disabled)	1 pps	At start of operation	289 and 288	00 to 15	0000 0001 hex
			:				:
			100,000 pps (maximum for X/XA CPU Unit) 1,000,000 pps (maximum for Y CPU Unit)				0001 86A0 hex 000F 4240 hex
2	Acceleration Ratio	0 (disabled)	1 (pulses/4 ms)	At start of operation	290	00 to 15	0001Hex
			:				:
			65535 (pulses/4 ms)				FFFF hex
3	Deceleration Ratio	0 (disabled)	1 (pulses/4 ms)	At start of operation	291	00 to 15	0001 hex
			:				:
			65535 (pulses/4 ms)				FFFF hex

Pulse Output 2 Settings

Base Settings

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Undefined Origin (operation for limit signal turning ON)	Hold	Hold	At start of operation	392	12 to 15	0 hex
			Undefined				1 hex
2	Limited Input Signal Operation	Search Only	Search Only	When power is turned ON	380	04 to 07	0 hex
			Always				1 hex
3	Limit Input Signal	NC	NC	At start of operation	392	00 to 03	0 hex
			NO				1 hex
4	Search/Return Initial Speed	0 pps	0 pps	At start of operation	383 and 382	00 to 15	0000 0000 hex
			:				:
			30,000 pps				0000 7530 hex
5	Speed Curve	Trapezium	Trapezium	When power is turned ON	380	12 to 15	0 hex
			S-shaped				1 hex

Define Origin Operation Settings: Origin Search Settings

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Use define origin operation		Do not use.	Do not use.	When power is turned ON	380	00 to 03	0 hex
				Use.				1 hex
	1-1	Search Direction	CW	CW	At start of operation	381	12 to 15	0 hex
				CCW				1 hex
	1-2	Detection Method	Method 0	Method 0	At start of operation	381	08 to 11	0 hex
				Method 1				1 hex
				Method 2				2 hex
	1-3	Search Operation	Inverse 1	Inverse 1	At start of operation	381	04 to 07	0 hex
				Inverse 2				1 hex
	1-4	Operation Mode	Mode 0	Mode 0	At start of operation	381	00 to 03	0 hex
				Mode 1				1 hex
				Mode 2				2 hex
	1-5	Origin Input Signal	NC	NC	At start of operation	392	08 to 11	0 hex
				NO				1 hex
	1-6	Proximity Input Signal	NC	NC	At start of operation	392	04 to 07	0 hex
				NO				1 hex
	1-7	Search High Speed	0 pps (disabled)	1 pps	At start of operation	385 and 384	00 to 15	0000 0001 hex
				:				:
				30,000 pps				0000 7530 hex
	1-8	Search Proximity Speed	0 pps (disabled)	1 pps	At start of operation	387 and 386	00 to 15	0000 0001 hex
				:				:
				30,000 pps				0000 7530 hex
	1-9	Search Compensation Value	0 pps	-2,147,483,648	At start of operation	389 and 388	00 to 15	8000 0000 hex
				:				:
				0				0000 0000 hex
				:				:
				+2,147,483,647				7FFF FFFF hex
	1-10	Search Acceleration Ratio	0 (disabled)	1 (pulses/4 ms)	At start of operation	390	00 to 15	0001 hex
				:				:
				65,535 (pulses/4 ms)				FFFF hex
	1-11	Search Deceleration Ratio	0 (disabled)	1 (pulses/4 ms)	At start of operation	391	00 to 15	0001 hex
				:				:
				65,535 (pulses/4 ms)				FFFF hex
	1-12	Positioning Monitor Time	0 ms	0 ms	At start of operation	393	00 to 15	0000 hex
				:				:
				9,999 ms				270F hex

Origin Return Settings

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Speed	0 pps (disabled)	1 pps	At start of operation	395 and 394	00 to 15	0000 0001 hex
			:				:
			30,000 pps				0000 7530 hex
2	Acceleration Ratio	0 (disabled)	1 (pulses/4 ms)	At start of operation	396	00 to 15	0001Hex
			:				:
			65535 (pulses/4 ms)				FFFF hex
3	Deceleration Ratio	0 (disabled)	1 (pulses/4 ms)	At start of operation	397	00 to 15	0001 hex
			:				:
			65535 (pulses/4 ms)				FFFF hex

Pulse Output 3 Settings

Base Settings

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Undefined Origin (operation for limit signal turning ON)	Hold	Hold	At start of operation	410	12 to 15	0 hex
			Undefined				1 hex
2	Limited Input Signal Operation	Search Only	Search Only	When power is turned ON	398	04 to 07	0 hex
			Always				1 hex
3	Limit Input Signal	NC	NC	At start of operation	410	00 to 03	0 hex
			NO				1 hex
4	Search/Return Initial Speed	0 pps	0 pps	At start of operation	401 and 400	00 to 15	0000 0000 hex
			:				:
			30,000 pps				0000 7530 hex
5	Speed Curve	Trapezium	Trapezium	When power is turned ON	398	12 to 15	0 hex
			S-shaped				1 hex

Define Origin Operation Settings: Origin Search Settings

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Use define origin operation		Do not use.	Do not use.	When power is turned ON	398	00 to 03	0 hex
				Use.				1 hex
	1-1	Search Direction	CW	CW	At start of operation	399	12 to 15	0 hex
				CCW				1 hex
	1-2	Detection Method	Method 0	Method 0	At start of operation	399	08 to 11	0 hex
				Method 1				1 hex
				Method 2				2 hex
	1-3	Search Operation	Inverse 1	Inverse 1	At start of operation	399	04 to 07	0 hex
				Inverse 2				1 hex
	1-4	Operation Mode	Mode 0	Mode 0	At start of operation	399	00 to 03	0 hex
				Mode 1				1 hex
				Mode 2				2 hex
	1-5	Origin Input Signal	NC	NC	At start of operation	410	08 to 11	0 hex
				NO				1 hex
	1-6	Proximity Input Signal	NC	NC	At start of operation	410	04 to 07	0 hex
				NO				1 hex
	1-7	Search High Speed	0 pps (disabled)	1 pps	At start of operation	403 and 402	00 to 15	0000 0001 hex
				:				:
				30,000 pps				0000 7530 hex
	1-8	Search Proximity Speed	0 pps (disabled)	1 pps	At start of operation	405 and 404	00 to 15	0000 0001 hex
				:				:
				100,000 pps (maximum for X/XA CPU Unit) 1,000,000 pps (maximum for Y CPU Unit)				0000 7530 hex
	1-9	Search Compensation Value	0 pps	-2,147,483,648	At start of operation	407 and 406	00 to 15	8000 0000 hex
				:				:
				0				0000 0000 hex
				:				:
				+2,147,483,647				7FFF FFFF hex
	1-10	Search Acceleration Ratio	0 (disabled)	1 (pulses/4 ms)	At start of operation	408	00 to 15	0001 hex
				:				:
				65,535 (pulses/4 ms)				FFFF hex
	1-11	Search Deceleration Ratio	0 (disabled)	1 (pulses/4 ms)	At start of operation	409	00 to 15	0001 hex
				:				:
				65,535 (pulses/4 ms)				FFFF hex
	1-12	Positioning Monitor Time	0 ms	0 ms	At start of operation	411	00 to 15	0000 hex
				:				:
				9,999 ms				270F hex

Origin Return Settings

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Speed	0 pps (disabled)	1 pps	At start of operation	413 and 412	00 to 15	0000 0001 hex
			:				:
			100,000 pps (maximum for X/XA CPU Unit) 1,000,000 pps (maximum for Y CPU Unit)				0000 7530 hex
2	Acceleration Ratio	0 (disabled)	1 (pulses/4 ms)	At start of operation	414	00 to 15	0001Hex
			:				:
			65535 (pulses/4 ms)				FFFF hex
3	Deceleration Ratio	0 (disabled)	1 (pulses/4 ms)	At start of operation	415	00 to 15	0001 hex
			:				:
			65535 (pulses/4 ms)				FFFF hex

Built-in AD/DA: Built-in Analog I/O Settings

Base Settings

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Built-in analog resolution (for all analog I/O)	6,000 (Resolution)	6,000 (Resolution)	When power is turned ON	75	15	0
			12,000 (Resolution)				1

AD 0CH/AD 1CH/AD 2CH/AD 3CH: Analog Input Settings

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Analog Input 0: Use	Do not use.	Do not use.	When power is turned ON	76	7	0
			Use.				1
	1-1 Range	-10 to 10 V	-10 to 10 V	When power is turned ON	76	00 to 02	0 hex
			0 to 10 V				1 hex
			1 to 5 V				2 hex
			0 to 5 V				3 hex
			0 to 20 mA				4 hex
			4 to 20 mA				5 hex
	1-2 Use averaging	Do not use.	Do not use.	When power is turned ON	76	6	0
			Use.				1
2	Analog input 1: Use	Do not use.	Do not use.	When power is turned ON	76	15	0
			Use.				1
	2-1 Range	-10 to 10 V	-10 to 10 V	When power is turned ON	76	08 to 10	0 hex
			0 to 10 V				1 hex
			1 to 5 V				2 hex
			0 to 5 V				3 hex
			0 to 20 mA				4 hex
			4 to 20 mA				5 hex
	2-2 Use averaging	Do not use.	Do not use.	When power is turned ON	76	14	0
			Use.				1

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
3	Analog Input 2: Use		Do not use.	Do not use.	When power is turned ON	77	7	0
				Use.				1
	3-1	Range	−10 to 10 V	−10 to 10 V	When power is turned ON	77	00 to 02	0 hex
				0 to 10 V				1 hex
				1 to 5 V				2 hex
				0 to 5 V				3 hex
				0 to 20 mA				4 hex
				4 to 20 mA				5 hex
	3-2	Use averaging	Do not use.	Do not use.	When power is turned ON	77	6	0
				Use.				1
4	Analog Input 3: Use		Do not use.	Do not use.	When power is turned ON	77	15	0
				Use.				1
	4-1	Range	−10 to 10 V	−10 to 10 V	When power is turned ON	77	08 to 10	0 hex
				0 to 10 V				1 hex
				1 to 5 V				2 hex
				0 to 5 V				3 hex
				0 to 20 mA				4 hex
				4 to 20 mA				5 hex
	4-2	Use averaging	Do not use.	Do not use.	When power is turned ON	77	14	0
				Use.				1

DA 0CH/DA 1CH: Analog Output Settings

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	Analog Input 0: Use		Do not use.	Do not use.	When power is turned ON	78	7	0
				Use.				1
	1-1	Range	−10 to 10 V	−10 to 10 V	When power is turned ON	78	00 to 02	0 hex
				0 to 10 V				1 hex
				1 to 5 V				2 hex
				0 to 5 V				3 hex
				0 to 20 mA				4 hex
				4 to 20 mA				5 hex
2	Analog input 1: Use		Do not use.	Do not use.	When power is turned ON	78	15	0
				Use.				1
	2-1	Range	−10 to 10 V	−10 to 10 V	When power is turned ON	78	08 to 10	0 hex
				0 to 10 V				1 hex
				1 to 5 V				2 hex
				0 to 5 V				3 hex
				0 to 20 mA				4 hex
				4 to 20 mA				5 hex

SIOU Refresh: Special I/O Unit Refresh Settings

Disable SIOU Cyclic Refresh: Special I/O Unit Refresh Disable Settings

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
1	SIOU 0	Disable.	Disable.	At start of operation	226	0	0
			Enable.				1
2	SIOU 1	Disable.	Disable.	At start of operation	226	1	0
			Enable.				1
:	:	:	:	:	:	:	:

	Name	Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings
16	SIOU 15	Disable.	Disable.	At start of operation	226	15	0
			Enable.				1
17	SIOU 16	Disable.	Disable.		227	0	0
			Enable.				1
:	:	:	:	:	:	:	:
32	SIOU 31	Disable.	Disable.	At start of operation	227	15	0
			Enable.				1
:	:	:	:	:	:	:	:
48	SIOU 47	Disable.	Disable.	At start of operation	228	15	0
			Enable.				1
:	:	:	:	:	:	:	:
64	SIOU 63	Disable.	Disable.	At start of operation	229	15	0
			Enable.				1
:	:	:	:	:	:	:	:
80	SIOU 79	Disable.	Disable.	At start of operation	230	15	0
			Enable.				1
:	:	:	:	:	:	:	:
96	SIOU 95	Disable.	Disable.	At start of operation	231	15	0
			Enable.				1

FINS Protection Settings

Settings for FINS Write Protection via Network

	Name		Default	Settings	When setting is read by CPU Unit	Internal address	Bits	Settings		
1	Validate FINS write protection via network		Disable.	Disable.	Every cycle	448	15	0		
				Enable.				1		
	1-1	Nodes excluded from protection targets		---	---	---	---	---	---	
		1-1-1	Network Address	0	0	Every cycle	449	08 to 15	00 hex	
					:				:	
					127				7F hex	
		1-1-2	Node Address	1	1	Every cycle	449	00 to 07	01 hex	
					:				:	
					254				FE hex	
					All nodes				FF hex	
		1-2	Nodes excluded from protection targets		---	---	---	---	---	---
			1-2-1	Network Address	0	0	Every cycle	450	08 to 15	00 hex
						:				:
						127				7F hex
	1-2-2		Node Address	1	1	Every cycle	450	00 to 07	01 hex	
					:				:	
					254				FE hex	
					All nodes				FF hex	
	---		---	---	---	---	---	---	---	---
	1-32		Nodes excluded from protection targets		---	---	---	---	---	---
			1-32-1	Network Address	0	0	Every cycle	480	08 to 15	00 hex
						:				:
		127				7F hex				
		1-32-2	Node Address	1	1	Every cycle	480	00 to 07	01 hex	
					:				:	
					254				FE hex	
					All nodes				FF hex	

Appendix H

Specifications for External Power Supply Expansion

When using the external power supply for AC-power-supply CPU Units, the following limitations apply:

The external power supply for AC-power-supply CP1H CPU Units manufactured since July 2008 (Model CP1H-X□□□DR-A) can be used beyond 300mA within the capacity range of the power supply built in the CPU Units.

Please calculate the usable capacity of external power supply according to the following example.

• **Calculation example of the capacity limit of external power supply**

Example 1

	CPU Units	Expansion (I/O) Units			Total	Limit
		1 st unit	2 nd unit	3 rd unit		
	Model CP1H-XA40DR-A	Model CP1W-DA041 x3 units	Model CP1W-40EDR x1 unit	None		
5V	0.42A	0.24A	0.08A	0.0A	0.47A	≤2.0A
24V	0.07A	0.372A	0.09A	0.0A	0.532A	≤1.0A
Power consumption	5V×0.74A=3.7W 24V×0.532A=12.768W				Total 16.468W	≤30W
Usable capacity of external power supply	30W (Total of usable power consumption)–16.468W=13.532W 13.532W/24V=564A				0.564A	≤1.0A

Example 2

	CPU Units	Expansion (I/O) Units			Total	Limit
		1 st unit	2 nd unit	3 rd unit		
	Model CP1H-XA40DR-A	None	None	None		
5V	0.42A	0.0A	0.0A	0.0A	0.42A	≤2.0A
24V	0.07A	0.0A	0.0A	0.0A	0.07A	≤1.0A
Power consumption	5V×0.42A=2.1W 24V×0.07A= 1.68W				Total 3.78W	≤30W
Usable capacity of external power supply	30W (Total of usable power consumption)–3.78W=26.22W 26.22W/24V=1.09A Note: use the external power supply under 1.0A even if the calculation result exceeds 1.0A				1.0A	≤1.0A

For AC-power-supply CPU Units manufactured before July 2008, the specifications are as written in 2-2-1 *General Specifications* for CP1H CPU Units.

Index

A

- absolute coordinates
 - selecting, 248
- absolute pulse outputs, 248
- Access Error Flag, 181
- addresses
 - memory map, 713
- Always OFF Flag, 182
- Always ON Flag, 182
- applications
 - precautions, xxvii
- Auxiliary Area, 166
 - read/write section, 694, 706
 - read-only section, 665

B

- background execution
 - special flags, 662
- backup
 - precautions, xxvi
- Basic I/O Units
 - error information, 654
- battery
 - error flag, 655, 688
 - precautions, xxix
 - service life, 626
- Battery Error Flag, xxvi, 688
- bit allocations
 - PWM(891) outputs, 290

C

- Carry Flag, 182
- CIO Area, 146
- clock
 - clock data, 656, 684
- clock pulses
 - flags, 183
- communications
 - Communications Port Enabled Flags, 709
 - flags, 659
 - messages, 362
 - no-protocol, 342
- Communications Port Enabled Flags, 709
- complete link method, 350

- Condition Flag
 - saving and loading status, 183
- Condition Flags, 181
- connectors
 - recommended models, 562
- coordinate systems (absolute or relative), 249
- Counter Area, 169
- countermeasures
 - noise, xxxi
- CPU Bus Unit Area, 161
- CPU Bus Units
 - error information, 655
 - I/O allocations, 161, 172
 - Initialization Flags, 649, 677
 - memory area, 161
 - related flags/bits, 710
 - Restart Bits, 649, 694
- CPU Unit
 - initialization, 88
- cycle time
 - flags, 650
 - maximum cycle time, 97, 650, 669
 - present cycle time, 97, 650, 669
 - setting, 96
- Cycle Time Too Long Flag, 655, 686

D

- data areas
 - overview, 146
- Data Link Area, 160
- data links, 160, 163
- Data Registers, 179
- data registers
 - sharing, 149
- data tracing, 598
 - related flags/bits, 651
- dates
 - program and parameters, 381
- debugging, 594
 - flags, 651
- DeviceNet Area, 163
- differential phase mode
 - details, 213
- DIP switch
 - pin 6 status, 645

direction
 automatic direction selection, 251
DM Area, 170
DR00 Output for Background Execution, 662

E

EC Directives, xxx
electromagnetic fields, xxvii
EMC Directives, xxx
Equals Flag, 182
Equals Flag for Background Execution, 663
ER/AER Flag for Background Execution, 663
error codes, 708
 pulse output stop error codes, 271
Error Flag, 181
error log, 707
Error Log Area, 619, 652, 666, 707
errors
 basic I/O errors, 662
 communications error flags, 659
 CPU Bus Units, 655
 CPU Rack, 620
 error codes, 708
 error log, 652, 707
 Expansion I/O Rack, 620
 failure point detection, 385
 FAL/FALS flags, 653
 flags, 181
 flash memory, 652
 Input Units, 620
 memory error flags, 652
 Output Units, 622
 PLC Setup errors, 662
 programming error flags, 662
 Special I/O Units, 662
 troubleshooting, 601
Expansion I/O Racks
 troubleshooting, 620
external interrupts
 response time, 103

F

failure point detection, 385
FAL Error Flag, 653
FAL errors
 flag, 689

FAL/FALS Number for System Error Simulation, 653
FALS Error Flag, 653
FALS errors
 flag, 653, 656, 686, 688
FALS instruction, xxv, xxx
FINS commands
 list, 361
First Cycle Flag, 650, 667, 708
flash memory
 data dates, 657
 errors, 652
Flash Memory Error, 652
flowchart
 overall CPU operation, 84
Forced Status Hold Bit, 645, 694
force-resetting bits
 debugging, 594
force-setting bits
 debugging, 594
frequency
 frequency measurement, 228

G

Gate Bit
 high-speed counters, 228
Greater Than Flag, 182
Greater Than or Equals Flag, 182

H

High-speed Counter Gate Bit, 228
high-speed counter inputs
 reset methods, 215
 restrictions, 225
Holding Area, 165
Host Link
 ports, 715
Host Link commands, 359
Host Link communications, 358
hot starting, 150
hot stopping, 150

I

I/O Hold Bit, xxx
I/O interrupts
 response time, 101

- I/O memory
 - addresses, 713
 - areas, 714
 - effects of operating mode changes, 90
- I/O response time
 - calculating, 100
- immediate refreshing
 - input bits and words, 87
- increment mode
 - details, 214
- index register
 - sharing, 178
- index registers, 172
 - sharing, 149
- indirect addressing
 - DM Area, 171
 - index registers, 172
- Initial Task Execution Flag, 650
- Initial Task Flag, 708
- Initial Task Startup Flag, 667
- initialization
 - CPU Bus Units, 677
 - CPU Unit, 88
- Input Units
 - troubleshooting, 620
- inspection
 - procedures, 624
- installation
 - location, xxvi
- interrupt feeding
 - ladder program, 321
- Interrupt Input Units
 - response time, 101
- Interrupt Task Error Cause Flag, 711
- interrupt tasks
 - error flag, 711
 - error information, 654
- interrupts
 - processing times, 651
- IOM Hold Bit, 151, 645, 694
- IORF(097) refreshing
 - input bits and words, 87
- IR/DR Operation between Tasks, 651
- IR00 Output for Background Execution, 662

L

- Less Than Flag, 182

- Less Than or Equals Flag, 182
- Limit Input Signal Type, 269
- linear mode counting
 - details, 214
- Link Area, 160
- Low Voltage Directive, xxx

M

- maintenance
 - procedures, 626
- memory
 - memory map, 714
 - See also* data areas
- Memory Error Flag, 652, 688
- messages, 362
- momentary power interruption, 91
- MONITOR mode, 89
- monitoring
 - differential monitoring, 595
- multiple progressive positioning
 - ladder program, 306
 - wiring example, 303

N

- Negative Flag, 182
- networks
 - related flags/bits, 659, 660
- noise, xxvii
 - reducing, xxxi
- no-protocol communications, 342
- Not Equal Flag, 182
- NT Link
 - ports, 715

O

- online editing, 596
 - effect on cycle time, 99
- Online Editing Flags, 667
- Online Editing Wait Flag, 709
 - related flags/bits, 651
- operating environment, xxvii
 - precautions, xxvi
- operating modes
 - description, 89

- effects of mode changes on counters, 169
- operation
 - debugging, 594
 - trial operation, 594
- Origin Compensation, 269
- Origin Detection Method, 263
- Origin Input Signal Type, 269
- Origin Proximity Input Signal Type, 269
- origin return function
 - details, 255
 - examples, 275
- Origin Return Parameters, 276
- origin search
 - executing, 269
- Origin Search Acceleration Rate, 268
- Origin Search Deceleration Rate, 268
- Origin Search Direction
 - specifying, 268
- origin search function
 - details, 255
- Origin Search High Speed, 268
- Origin Search Operation Setting, 263
- Origin Search Parameters, 260
- Origin Search Proximity Speed, 268
- Origin Search/Return Initial Speed, 268
- origin status
 - operations affecting, 250
- Output, 252
- Output OFF Bit, 651, 694
- Output Units
 - troubleshooting, 622
- outputs
 - precautions, xxv, xxx
- Overflow Flag, 182

P

- Parameter Area, 714
- Parameter Date, 382, 389, 657
- parts
 - replacing parts, 626
- peripheral port
 - related flags/bits, 685
- PLC Setup
 - error information, 654
- Polled Units
 - settings, 354

- Polling Unit
 - setting, 354
- Polling Unit link method, 350
- positioning
 - vertically conveying PCBs, 301
- Positioning Monitor Time, 269
- power interruptions
 - information, 657, 695
 - momentary interruptions, 91
- power OFF processing, 91
- power supply, xxvii
 - precautions, xxx
- precautions, xxiii
 - applications, xxvii
 - general, xxiv
 - handling precautions, 625
 - operating environment, xxvi
 - periodic inspections, 624
 - safety, xxiv
- Program Error Flag, 687
- program errors, 711
- PROGRAM mode, 89
- program transfer, 594
- programming
 - error flag, 687
 - program error information, 653
 - program errors, 711
 - program protection, 381
 - protecting the program, 381
 - transferring the program, 594
- pulse + direction mode
 - details, 213
- pulse frequency conversion, 229
- pulse input modes
 - details, 213
- Pulse Output 0 settings
 - speed curve, 253
- pulse output modes, 233
- pulse output stop error codes, 271
- pulse outputs, 231
- PWM(891) outputs
 - bit allocations, 290
 - details, 290
 - restrictions, 290

Q

quick-response inputs
 details, 322

R

radioactivity, xxvii
read/write-protection, 382
refreshing
 immediate refreshing, 87
 IORF(097), 87
refreshing data, 350
relative coordinates
 selecting, 248
reset methods, 215
Restart Bits
 CPU Bus Units, 649
 peripheral port, 660
 RS-232C port, 661
 Special I/O Units, 650
ring mode counting
 details, 215
RS-232C port
 related flags/bits, 660, 661, 684, 685
RUN mode, 89

S

safety precautions, xxiv
scheduled interrupts
 response time, 102
S-curve acceleration/deceleration
 output pattern, 252
 restrictions, 253
self-maintaining bits, 165
serial communications
 communications information, 661
 functions, 340
Serial PLC Link Area, 163
Serial PLC Links, 350
 allocated words, 353
 PLC Setup, 354
 related flags, 355, 356
simulating system errors, 653
software reset, 216
Special I/O Unit Area, 162

Special I/O Units
 error information, 662
 Initialization Flags, 650, 682
 Restart Bits, 650, 694
 words allocated to Special I/O Units, 162, 171
specifications
 PWM(891) output, 290
startup
 hot starting and stopping, 150
static electricity, xxvii
Step Flag, 667
stocker, 301

T

target value comparison
 for interrupt tasks, 226
Task Error Flag, 676
Task Flags, 181
Task Started Flag, 650
tasks
 related flags/bits, 651
 See also interrupt tasks
 Task Flags, 181
Timer Area, 167
TR Area, 166
tracing
 See also data tracing
trial operation, 594
troubleshooting, 601
twisted-pair cables
 recommended models, 562
two-axis multipoint positioning
 ladder program, 314
 wiring example, 309

U

Underflow Flag, 182
up/down mode
 details, 214
User Program Date, 382, 389, 657

V

variable duty ratio pulse outputs
 details, 290
vertical conveyor, 301

W

Work Area, 165
work bits, 165
work words, 165
write-protection, 381

Revision History

A manual revision code appears as a suffix to the catalog number on the front cover of the manual.

Cat. No. W450-E1-10



Revision code

The following table outlines the changes made to the manual during each revision. Page numbers refer to the previous version.

Revision code	Date	Revised content
01	October 2005	Original production
02	May 2006	Unit version 1.1 added for CP1H CPU Units. Specifications for unit version 1.1 added throughout the manual. Pages 61 and 62: Information added on signals. Page 64: Information added on high-speed counter inputs. Page 176: Information added on power OFF interrupts. Page 219: Information added on high-speed counter frequency measurements. Page 221: Information added on controlling pulse outputs. Page 222: Information added on output frequency. Pages 228 and 229: Information changed in input functions table. Pages 247 and 248: Information added on origin search parameters. Page 264: Information added on origin search parameters. Pages 266 and 267: Information added on pulse output method. Page 270: Information added on first pulse frequency word. Pages 271 and 273: Information added on first settings table word. Pages 375 to 384: Information added on Analog Input Units. Pages 385 to 392: Information added on Analog Output Units. Page 467: Information added on Analog Input Units and Analog Output Units. Page 587: Information added on interrupt input settings. Pages 588 and 591: Information added on origin input signals.
03	April 2008	Information added on CP1W Expansion I/O Units and Expansion Units. Information added on LCD Option Board. Errors were corrected.
04	June 2008	Errors were corrected.
05	August 2008	CP1W-CIF12 added for Serial Communications Option Board.
06	March 2009	Information added on Ethernet Option Board.
07	May 2010	CP1W-DA021 added for CP-series Expansion Units. Unit version 2.0 added for CP1W-CIF41 Ethernet Option Board. Errors were corrected.
08	October 2014	CP1W-AD042 Analog Input Units, CP1W-DA042 Analog Output Units, CP1W-MAD42/MAD44 Analog I/O Units and CP1W-TS003/TS004 Temperature Sensor Units added for CP-series Expansion Units. Errors were corrected.
09	October 2015	Unit version 1.3 added for CP1H CPU Units. Errors were corrected.
10	July 2017	CP1W-CIF12-V1 added for Serial Communications Option Board.

Revision History

OMRON Corporation Industrial Automation Company
Kyoto, JAPAN

Contact: www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V.

Wegalaan 67-69, 2132 JD Hoofddorp
The Netherlands

Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ASIA PACIFIC PTE. LTD.

No. 438A Alexandra Road # 05-05/08 (Lobby 2),
Alexandra Technopark,
Singapore 119967

Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200
Hoffman Estates, IL 60169 U.S.A.

Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD.

Room 2211, Bank of China Tower,
200 Yin Cheng Zhong Road,
PuDong New Area, Shanghai, 200120, China

Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

Authorized Distributor:

© OMRON Corporation 2005 All Rights Reserved.
In the interest of product improvement,
specifications are subject to change without notice.

Cat. No. W450-E1-10

0717