



**© 2000 OMRON ASIA PACIFIC PTE LTD**

All rights reserved. No part of this material may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without prior written permission of Omron Asia Pacific Pte Ltd

No patent liability is assumed with respect to the use of the information contained herein. Every precaution has been taken in the preparation of this booklet; however OMRON assumes no responsibility for errors or omissions.

**CX - Motion**

# Table of Content

## Section 1 Introduction of CX-Motion

<b>1-1</b>	<b>Introduction .....</b>	<b>2</b>
<b>1-2</b>	<b>Features .....</b>	<b>2</b>
<b>1-3</b>	<b>Functions .....</b>	<b>2</b>
<b>1-4</b>	<b>System Configuration.....</b>	<b>3</b>
<b>1-5</b>	<b>Creating Project with CX-Motion.....</b>	<b>4</b>
1-5-1	Startup CX-Motion.....	4
1-4-1	Setting Up a new Project. ....	5
1-5-2	Introduction to CX-Motion workspace.....	8
1-5-3	Inserting MC unit for project.....	9
1-5-4	Setting Parameter for MC unit .....	13
<b>1-6</b>	<b>Downloading and Upload of Parameters.....</b>	<b>33</b>
1-6-1	Downloading of Parameters .....	33
1-6-2	Uploading of Parameters .....	34
1-6-3	Verify Parameters Settings .....	36

## Section 2 Position Data

<b>2-1</b>	<b>Position Data .....</b>	<b>2</b>
2-1-1	Creating Position Data file .....	2
2-1-2	Inserting Position Data file to Project.....	4
<b>2-2</b>	<b>Downloading and Upload of Position data file .....</b>	<b>5</b>
2-2-1	Downloading of Position Data .....	5
2-2-2	Uploading of Position Data .....	6
2-2-3	Verifying of Position Data.....	8
<b>2-3</b>	<b>Changing Position Data via Programming.....</b>	<b>10</b>
2-3-1	CS1W-MC421/221.....	10
2-3-2	CV500-MC421/MC221.....	12
2-3-3	C200H-MC221 .....	13

## Section 3 G - Code Programming

<b>3-1</b>	<b>Program.....</b>	<b>2</b>
3-1-1	Creating New program .....	2
3-1-2	Programming .....	2
3-1-3	Compilation of Program .....	6
3-1-4	Saving of program .....	6
3-1-5	Inserting a file to project.....	7
<b>3-2</b>	<b>Downloading and uploading of Program Files.....</b>	<b>8</b>
3-2-1	Downloading of Programs.....	8
3-2-2	Uploading of Programs.....	10
3-2-3	Verifying of Program .....	11

## Table of Content

### Section 4 Automatic Downloading Function

<b>4-1</b>	<b>Script.....</b>	<b>2</b>
4-1-1	Creating of Script file .....	3
4-1-2	Autodownload .....	6
<b>4-2</b>	<b>Executing Automatic Loading.....</b>	<b>8</b>
4-2-1	Parameter to access .....	8
4-2-2	Related Bits in the PC Interface Area.....	9

### Section 5 Monitoring Function

<b>5-1</b>	<b>Monitoring Function .....</b>	<b>2</b>
5-1-1	Monitor Coordinates.....	3
5-1-2	Monitor MC Task .....	4
5-1-3	Monitor I/O status .....	6
5-1-4	MC FAL Status .....	7
5-1-5	View MC Error Log .....	8
<b>5-2</b>	<b>The Servo Graph .....</b>	<b>9</b>
5-2-1	Immediate.....	9
5-2-2	Axis Run.....	11
5-2-3	Saving File.....	12
5-2-4	Reading a save file .....	12
5-2-5	Retrieving file in Microsoft Excel .....	14

### Section 6 Startup Guide

<b>6-1</b>	<b>Getting started .....</b>	<b>2</b>
6-1-1	Overview .....	2
6-1-2	Procedure.....	3
<b>6-2</b>	<b>System Configuration and Wiring .....</b>	<b>4</b>
6-2-1	System Configuration.....	4
6-2-2	Checking Operation from the Teaching Box.....	15
<b>6-3</b>	<b>Considerations When Starting Up the MC Unit.....</b>	<b>15</b>
6-3-1	Setting the System Parameters .....	15
6-3-2	Considerations When Starting Up or Making Adjustments .....	15
6-3-3	Changing the Teaching Box Mode for Trial Operation.....	15

# Section 1

## Introduction to CX-Motion

This section will guide user on the creation of project and setting up of parameter.

- 1-1 Introduction ..... 2
- 1-2 Features ..... 2
- 1-3 Functions ..... 2
- 1-4 System Configuration ..... 3
- 1-5 Creating Project with CX-Motion ..... 4
  - 1-5-1 Startup CX-Motion..... 4
  - 1-4-1 Setting Up a new Project. .... 5
  - 1-5-2 Introduction to CX-Motion workspace..... 8
  - 1-5-3 Inserting MC unit for project..... 9
  - 1-5-4 Setting Parameter for MC unit..... 13
- 1-6 Downloading and Upload of Parameters ..... 33
  - 1-6-1 Downloading of Parameters ..... 33
  - 1-6-2 Uploading of Parameters ..... 34
  - 1-6-3 Verify Parameters Settings ..... 36

## 1-1 Introduction

### System Requirements

To install the CX-Motion, the basic configuration of the System is as shown:

CX-Motion :

OS: Windows 95/98, Window NT 4.0  
RAM: 32MB or more  
Harddisk: 10MB or more.  
Resolution: SVGA (800x600) or larger

The CX-Motion can support the following MC units.

MC Unit	PLC Type
CS1-MC421/221	CS1 Series
CV500-MC421/221	CV Series
C200H-MC221	C Series

### Product Type

Product Description	Specification	Model
Cx-Motion	CD-ROM	WS02-MCTC1-E

## 1-2 Features

### Single-port Multi-access Function

A Windows-based Support Software package called CX-Motion can be used on the same computer and through the same port as the CX-Programmer, enabling multiple programming environments on a single computer.

### Servo Information Trace Function

Speed reference values, the present speed, and the error counter can be traced with specified starting conditions and a specified sampling period using the MC Support Software. Up to 500 items can be traced, making it easy to adjust the servo system.

### Automatic Loading Function

When it is necessary to use more programs or position data than can be stored in the MC Unit, programs or position data stored in an external memory device at the computer where the MC Support Software is installed can be automatically downloaded to the MC Unit's internal memory.


## 1-3 Functions

Function	Description
Program Editing	Creating, changing, and clearing MC programs.
Position data editing	Creating, changing, and clearing MC programs.
Parameter editing	Creating and changing system parameters, and clearing to defaults.
Transfer and Comparison	Transferring and verifying MC programs, system parameters, and position data contents between MC unit and personal computer.
Printing	Printing MC programs, system parameters and position data contents.

Function	Description
Monitoring	Monitoring MC programs that are being run. Monitoring present values: <ul style="list-style-type: none"> <li>Reference coordinate system PV (user settings and pulse)</li> <li>Workpiece coordinate system PV</li> <li>Workpiece origin shift amount</li> <li>Error counter value</li> </ul> MC unit FAL status MC unit I/O status MC unit error log ( CS1W-MC421/MC221 only )
File Management	File display, loading, saving and changing
Use-defined mnemonics	Setting G code by mnemonics
Servo trace	Displaying servo trace data with the MC unit (CS1W-MC421/MC221 only.)
Automatic loading	Automatic downloading of programs to the MC unit (CS1W-MC421/MC221 only)
File conversion	Converting parameters created by MC Support Software for use by the CS1W-MC421/MC221.

## 1-4 System Configuration

The following system configuration is applicable to CS1W-MC421 (4 axes). CS1W-MC221 will be used for 2 axes system configuration.




- Note**
1. A special Driver Connection Cable is available for OMRON U-, H-, and M-series Servo Drivers. A cable can also be prepared by the user.
  2. A special cable is available for connecting to a Terminal Block. The cable can also be prepared by the user.
  3. A data backup is required when using an absolute encoder.

## 1-5 Creating Project with CX-Motion


### 1-5-1 Startup CX-Motion

To start CX-Motion, please perform the following step.


*Start - Program - Omron - CX-Motion - Cx-Motion.*




The CX-Motion application window will appear.



At the following window, click on **Continue** to continue.




From the **File** Menu , select New. At the pop-up menu, select **Project**. ( To create a new project.)



#### 1-4-1 Setting Up a new Project.

Upon the selection, the following dialog box will appear on the screen.




Enter the necessary information of the project to be created. Then click on the **OK** button. The following dialog box will appear.



Enter a label for the PLC, and provide the necessary information of the PLC. (That is select the PLC type and the communication type.)




When communicating with C200H-MC221, please do the following setting.



Select **Sysmac Way**, then at the **Driver** tab configure the communication settings as followed:

- Communication rate : 9,600 bps
- Parity : None
- Data Length : 8 bits
- Stop bits : 2 bits
- Response monitor time : 10 s




(The connect for C200H-MC221 will be made via the tool port on the unit, the switch must be slide to HOST.)


As user are able to access to the MC unit on the backplane of CS1W and CV via the I/O bus, uploading and downloading of parameters, position data, programs and etc. can done via the SYSMAC way. That is, connect to the RS232C of the CPU unit.

The configuration are as followed:

- Communication rate : 9,600 bps
- Parity : Even
- Data Length : 7 bits
- Stop bits : 2 bits
- Response monitor time : 2 s



If **Toolbus** is selected as the Network type for communication, the setting of the driver are as followed.




- Note**
1. The Baud Rate Auto-Detect is only available when using CS series.
  2. For detail information on wiring, please refer to the Appendix.


## 1-5-2 Introduction to CX-Motion workspace

Upon configure the **ADD PLC** dialogue box, the window as shown will appear on screen.

### Introduction to CX-Motion window



### Introduction to Project Workspace




The project workspace consist of two tab, **Project Tab** and **File Tab**. The figure as shown on the left is the **Project Tab**.

Each file types are represented by different icon. In a project file, more than one type of PLC can be configured.

The project tree can be expanded or shrink by click on the "+" with the left mouse click.

PLC-Label	→	PLC_CS1W
MC unit Type	→	MC_CS1W-MC421
MC unit Parameters	→	CS1W MC421 Default parameters
Positions Data	→	New Positions
G-code Program	→	P530 Circular Interpolation
	→	P010 familiarization


Each branch from the PLC-Label will represent the files created for that PLC.




The figure on the left shows the **File Tab** of the project workspace. In the **File Tab**, the filename of the Project file, MC unit parameter, position data file and the G-code program file will be displayed. Hence, the path of the project file will also be displayed in the window.

### 1-5-3 Inserting MC unit for project

At the **Project Tab**, use the right mouse button to click on the **PLC Type**. The following pop-up dialogue box will appear.




Select **New MC**. The following dialogue box will be shown.




Parameter	Description
MC Name	The label for the MC Unit.
MC Type	<p>For CS1 Series , the following type of MC unit can be mounted on the backplane:</p> <ul style="list-style-type: none"> <li>• CS1W-MC421</li> <li>• CS1W-MC221</li> <li>• C200H-MC221</li> </ul> <p>For CV Series, the following type of MC unit can be mounted on the backplane.</p> <ul style="list-style-type: none"> <li>• CV500-MC421</li> <li>• CV500-MC221</li> </ul> <p>For C-Series, only C200H-MC221 is available.</p>
Communications settings:	
Network	The network number of the remote PLC. (See note.)
Node	The node number of the PLC in the remote network. (See note.)
Unit	The MACHINE No. of the MC Unit to communicate to.
Response Time	The timeout response time. ( Default 2 seconds.)

**Note:** CS1 Series and CV Series support remote programming via OMRON Network, example: Ethernet, Controller Link and Sysmac Link . The following are the steps to configure the Network Number and the Node Number.


- 1,2,3... 1. At the **ADD PLC** or **Change PLC** dialogue box, select **Settings**, as shown.




2. At the **Network Tab**, enter the information of the PLC in the remote network.




3. Upon configuring, click **OK**. Then use the right mouse button to click on the **PLC type**.




4. Select **New MC**, the information of the network will be shown.




Upon completion of entering the parameter in the **Motion Controller** window, click on **OK**. The following dialogue box will be shown.




If **Yes** is selected. At the window shown, select a file.




If **No** is selected, at the window as shown, create a new file.



After selecting **Yes** or **No**, the **Parameter Icon** will be shown in the **Project Workspace**.



Double click on the Parameter set, at the **Display window**, the parameter setting dialogue box will be shown.



### 1-5-4 Setting Parameter for MC unit

#### Unit and Memory Parameter

#### Parameter Setting for CS1W-MC421

If CS1W-MC421 is selected for the MC unit in the project, the following parameter window will be shown.

#### Description of the Parameter setting of the Unit and Memory Window.

Parameter	Description
Number of axis	CS1W-MC421: Max. number of axis 4 CS1W-MC221: Max. number of axis 2 CV500-MC421: Max. number of axis 4 C200H-MC221: Max. number of axis 2
Task Allocated per axis	CS1W-MC421: Max. number of task 4 Max. number of block 2000 Max. number of program 100 CS1W-MC221: Max. number of task 2 Max. number of block 2000 Max. number of program 100 <b>Note:</b> Max. no. of block per program 800, including subroutine. Same program number cannot be used for difference tasks. CV500-MC421: Max. number of task 4 Max. number of block 800 Max. number of program 100 CV500-MC221: Max. number of task 2 Max. number of block 800 Max. number of program 100 <b>Note:</b> Max. no. of block per program 800, including subroutine. Same program number cannot be used for difference tasks. C200H-MC221: Max. number of task 2 Max. number of block 800 Max. number of program 100



Parameter	Description
Task memory Range	Indication of the block range assign for each task.
Digital Output	Selection of Brake output or general output.
MPG/Synchronous Encoder	Select Line driver output-type, MPG/Sync encode :1
Pass Mode	To specify whether the Pass mode is use at acceleration time or deceleration time.
Teaching Box Language	The type of language display at the teaching box: English or Japanese.
Synchronous Encoder Ratio	Pulse Ratio Selection
Acceleration Mode	To enable or disable the constant acceleration mode.
Autoload Timeout	Max. Time range 0 ~ 180. The parameter is used when batch downloading programs, position data and system parameter to the MC units from external memory device of a personal computer with CX-Motion

### Parameter Setting for CS1W-MC221

If CS1W-MC221 is selected for the MC unit in the project, the following parameter window will be shown.

The parameter setting of CS1W-MC221 is similar to CS1W-MC421, except that the maximum number of axis available is 2 axis.


### Parameter Setting for C200H-MC22 and CV500-MC221

If C200H-MC221 is selected for the MC unit in the project, the following parameter window will be shown.

Specify the number of axis used, and the block range assign to each task.

### Parameter Setting for CV500-MC421

If CV500-MC421 is selected for the MC unit in the project, the following parameter window will be shown.



Specify the number of axis used, and the block range assigned for each task.

After configuring the Unit and Memory Parameter setting, it is necessary to set the following parameters for individual axis:

- Machine Parameter
- Coordinate Parameter
- Feed Rate Parameter
- Zone Parameter
- Servo Parameter

To start with, click on at the toolbar for Machine Parameter setting

**Note:** When any of the parameter setting icon is selected from the toolbar, the following selection icon will also appear.




The icon indicates the axis parameters setting. ( For example, the figure shown above is X-axis. Hence, all parameters setting, which is being set for X-axis. To set the parameter for Y,Z or U, click on the respective alphabet.) For \*\*\*-MC221, only X and Y are selectable.

### Machine Parameter

#### Setting Parameter for CS1W-MC421 and CS1W-MC221

If CS1W-MC421 or CS1W-MC221 is selected for the MC unit in the project, the following parameter window will be shown.



A total of six tabs of forms to be filled up:

- Motor Setting
- Motor Limits
- Encoder
- Limits
- Origin
- Wiring

### Motor Setting

Parameter	Description
Minimum setting Unit	1/0.1/0.01/0.001/0,0001 (Default 1)
Display Unit	The following type of display units are available; <ul style="list-style-type: none"> <li>• mm</li> <li>• inch</li> <li>• deg</li> <li>• pulse</li> </ul>
Rotate Direction on +V	The rotating direction when the voltage is positive.
Emergency Stop Method	The parameter will determine how the servomotor will stopped when an emergency stop input signal or CW/CCW limit signal is received. <ul style="list-style-type: none"> <li>• By dropping the output to 0 v</li> <li>• Accumulated pulses in error counter.</li> </ul>

### Motor Limits

Parameter Set 1 Machine Parameters

Motor Settings **Motor Limits** Encoder Limits Origin Wiring


Maximum Motor Speed: 3000 rpm

Pulse Rate:


Numerator: 1 pulse /Pulse

Denominator: 1


Parameter	Description
Maximum Motor Speed	Specification of the Motor used. (Speed) Range 1 ~ 32767

Parameter	Description
Pulse Rate	<p>The parameter determine the amount that the work-piece is moved per feedback pulse. The pulse rate are given by the following equation.</p> <p>The pulse rate <math>\leq 1</math>.</p> $\text{Pulse rate} = \frac{X \text{ (mm)}}{Y \text{ (pulses)} \times 4} \quad \leftarrow \text{With an encoder ratio of 4}$ 
Numerator	The value is determine by X (range 1~100000) (X the reading of the ball screw.)
Denominator	The value is determine by Y*4 (range 1~100000) (Y the Encoder Resolution.)

## Encoder




Parameter	Description
Type	Type of encoder used : Absolute Encoder or Incremental Encoder
Resolution	Setting the encoder resolution. (Range 1~ 65,535) (The number of pulse that can be output per encoder revolution )
Encoder Polarity	The parameter specified whether the motor will turn forward or reverse when the feedback pulses from the encoder increase.
Encoder Pulse Ratio	Specifies the ratio of the encoder.

**Limits**

Parameter	Description
Software Limit	The limit monitor by the software. ( The range of the software limit is determined by the positive and negative limit.)
Negative Limit	Minimum setting ( -39,999,999)
Position Limit	Maximum setting (39,999,999)
Axis Mode	Two selection are available: <ul style="list-style-type: none"> <li>• Normal Enables positioning within the software limits after the origin has been established.</li> <li>• Infinite When the Infinite is chosen, the Unlimited Feed Mode is enable, that is the software limits will not operate regardless of whether or not the origin has been determined. Thus, the present position is set by the ring counter method at the value determined by the positive and negative software limits.</li> </ul>


## Origin



Parameter	Description
Search Method	<p>Origin Search Method.</p> <p>The method available are as followed :</p> <ul style="list-style-type: none"> <li>Set origin at Power On. The position of the motor when power is turned ON is automatically defined as the origin.</li> <li>Reverse Mode The motor search direction is reversed. The origin will be establish when the Z-phase signal goes ON after the origin proximity signal goes from ON to OFF.</li> <li>Direction search Mode The origin search is performed in the direction set by the origin search direction parameter. An error will occur if a limit input signal goes ON before the origin proximity input signal is received.</li> </ul>
Z-phase Detection Direction	Specifies whether to move in the CW or CCW direction to detect Z-phase.
Deceleration Method	<p>Two method are available:</p> <p>Proximity Specifies whether to use origin proximity signal input or limit signal input for deceleration near the origin. Use limit for proximity input. Specifies the limit signal input for deceleration.</p>
Proximity Logic	Specifies whether the origin proximity is normally open or normally closed.
Deceleration Method on CW/CCW input	<p>Two selection:</p> <p>Stop on error counter Uses pulse accumulated in the error counter to stop. Deceleration stop Decelerate to a stop.</p>

Parameter	Description
Origin Search Start Direction	Two selection. As origin search Specifies to start search as in the same direction of phase Z-detection. Reverse Specifies to start search as in the opposite direction of phase Z-detection.

### Wiring



Parameter	Description
Wiring Check	To enable or disable wiring check function. The wiring check function is designed to check for reverse wiring and disconnected wiring when power supply is turn on in order to prevent motor runaway. The function will output a specified number of pulses in the specified direction and to check whether correct feedback pulses are read.
Check Time	Wiring checking time, the parameter check the feedback pulses if the check pulses are not returned with in the time set, it is consider as failed.(Range 0 to 99 )(x10ms)
Check Pulse	Wiring Check Pulse, the parameter specifies the number of pulses output in a wiring check. (Range 0 to 999)
Absolute Position Setting Value	The parameter specifies the correction value for the absolute encoder used when the absolute origin setting is used. (Not available in Teaching Box.)

### Setting Parameter for CV500-MC421/MC221 and C200H-MC221

The parameter setting of CV500-MC421, CV500-MC221 and C200H-MC221 is about the same except that only two axes are available in CV500-MC221 and C200H-MC221.

As similar to the CS1-MC421/221, CV500-MC421/221 and C200H-MC221 had the following tabs for parameters setting :

- Motor Setting
- Motor Limits
- Encoder
- Limits
- Origin
- Wiring

The parameter setting in the Motor Setting Tab and Motor Limits is the same as in CS1W-MC421/221. Thus, the differences will be as shown.

- **Encoder Tab:** The encoder pulse ratio is not available.
- **Limit Tab:** The Axis Mode is not available.
- **Origin Tab:** The Deceleration Method on CW/CCW input and Origin Search Start Direction are not available.
- **Wiring Tab:** For the ABS Encoder, Initial Set Value and Soft Reset is available.


When completion in configuring the Motor Parameter, click on  to configure the Coordinate Parameter.

### Coordinate Parameter


In the Coordinate Parameter window, the Reference Origin Offset and Workpiece Origin offset is configured.

### Reference Origin Offset

A reference origin offset is an offset from the Mechanical origin. It is used in origin searches as shown in the figure.




The setting range will vary with the minimum setting unit and pulse rate in the machine parameters.






### Workpiece Origin Offset Values

A workpiece origin offset is an offset from the reference origin.





It is useful when carrying out operations such as drilling holes in the position as shown above.

Coordinate Parameter window for 4 axes



Coordinate Parameter window for 2 axis.



In completion of the Coordinate Parameter, click on  to configure FeedRate parameter.


**FeedRate Parameter**

In the FeedRate Parameter Window, it consist of three tabs,

- Feed Rates
- Acceleration
- Electronics Gears

**Feed Rate**

CS1W-MC421/221



The following equation provides possible ranges for high-speed feed rates as well as high and low speed feed rates for origin searches.

$$1 \leq SV \leq V_m \times E_p \times E_t \times \frac{Pr}{60}$$

$V_m$ : Max. motor frequency  
 $E_p$ : Encoder Resolution  
 $E_t$ : Encoder Ratio  
 $Pr$ : Pulse rate

For example,

$V_m$ :	1000
$E_p$ :	300
$Pr$ :	0.01
$E_t$ :	ratio of 4


Therefore, the equation yield : 200[mm/s]. Hence the setting range would be 1 to 200. When the minimum setting units is 0.01, the possible setting range would be 0.01 to 200.00. ( Units maybe display in terms of the pulse or mm.)

**Feed Rate Relationships**

The following condition must be met, else error will occur when transferred from CX-Motion.


Max. Feed rate  $\geq$  Maximum interpolation feed rate  
 Max. Feed rate  $\geq$  Maximum jog feed rate  
 Max. Feed rate  $\geq$  Origin search high-speed feed rate  
 Max. Feed rate  $\geq$  Origin search low-speed feed rate  
 Origin search high-speed feed rate  $\geq$  Origin search low-speed feed rate



Parameter	Description
Maximum Feedrate	Setting of feed rate for different operation: <ul style="list-style-type: none"> <li>• High Speed (Point to Point)</li> <li>• Interpolation (Linear, Circular, Helical circular)</li> <li>• Jog (Jogging rate)</li> </ul>

Parameter	Description
Origin Search	<p>The high-speed and the low-speed rates for origin search. The high-speed feed rate is the feed rate at which the axis is moved until the origin proximity input signal is detected during an origin search.</p> <p>The origin search low-speed rate is used after the origin proximity input signal is received until phase Z is detected.</p> 

All the parameters in the Feed Rate Tab must be set between 0.0001 to 39,999,999.

## Acceleration




Parameter	Description
Acceleration/Deceleration Curve	<p>A trapezoidal curve or a S-curve can be selected. The default setting is for a trapezoidal curve.</p> <p><b>Trapezoidal Curve</b></p>  <p><b>S-Curve</b></p> 

Parameter	Description
Acceleration Times (ms) and Interpolation Times (ms)	Acceleration is the time required to reach the maximum feed rate. Deceleration is the time required to decelerate to from maximum speed to zero. The range is from 0 to 10,000 in 2-ms units.

All the parameters in the Acceleration Tab must be set between 0 to 100,000

### Electronic Gear




Parameter	Description
MPG Ratio	The parameter set the ratio per pulse when using an MPG or Sync encoder. The ratio setting is extremely accurate because the numerator and denominator can be set separately. A maximum of four ratios can set for each axis.  Ranges Numerator : -10,000 to 10,000 Denominator : 1 to 10,000 $0.0001 \leq \text{numerator/denominator} \leq 10,000$

**Feed Rate****CV500-MC421/221 & C200H-MC221**

The feed rate setting of CV500-MC421/221 and C200H-MC221 is similar as in CS1W-MC421/221.

For CV500-MC421/221 and C200H-MC221, the Electronic Gear Tab is not available. Instead, the MPG Ratio is included in the second tab, which is as followed.




The Acceleration Times and Interpolation Times must be set between 0 to 9999. As for the MPG Ratio, the parameters must be set between 1 to 1000. (Please note, the numerator and denominator is not used.)

To set the Zone Parameter, click on .

**Zone Parameter**


In the Zone Parameter window, the ranges of positions or values will be defined, and the flags corresponding to the zone will be turned on whenever the present position is within the range.

**Zone parameter window for CS1W-MC421/221**

Parameter	Description
Zone Availability	The validation of when the Zone Setting: On Origin Establish - valid when the origin is establish. Independent of Origin Establish - always valid.
Set	Validation of the zone setting
Negative SV	Setting of the lower range
Positive SV	Setting of the upper range

Positive and Negative SV.

When the present value is within the range set in Positive and Negative SV, the corresponding flags will turn on.




The following table shows the zone flag allocations.

Word		Axis	Bits	Bit names
MC221	MC421			
n+22	n+38	X axis	08 to 15	Zone 1 Flag (bit 08) to Zone 8 Flag (Bit 15)
n+25	n+41	Y axis		
	n+44	Z axis		
	n+47	U axis		

The zone ranges that can be set depend on the machine parameter minimum setting unit and pulse rate.

#### Zone Parameter for CV500-MC421/221 and C200H-MC221



The parameter setting is the same as in CS1W-MC421/221, except that the Zone availability option is not included.

The following table shows the zone flag area for CV500-MC421/221.

Word		Axis	Bits	Bit names
MC221	MC421			
n+17	n+17	X axis	08 to 15	Zone 1 Flag (bit 08) to Zone 8 Flag (Bit 15)
n+19	n+19	Y axis		
	n+21	Z axis		
	n+23	U axis		


The following table shows the zone flag area for C200H-MC221



Word	Axis	Bits	Bit names
MC221			
n+16	X axis	08 to 15	Zone 1 Flag (bit 08) to Zone 8 Flag (Bit 15)
n+19	Y axis		

To setting the Servo Parameter, click on .


### Servo Parameter CS1W-MC421/221

Setting the Servo Parameter, when the parameter is changed, the changed value will become valid in real time.




Parameter	Description
Error Counter Warning	The parameter set the number of pulse used to monitor accumulated pulse in the error counter. (See Note 1.) The range of set value is 0 ~ 65000
In Position	The range within which the system is determined to be at the target position. (See Note 2.) The range of set value is 0~10000
Position Loop Gain	<p>The loop gain can be determined by the following equation:</p> $\text{Position loop gain [1/s]} = \frac{\text{Feed rate [pulses/sec]}}{\text{Accumulated pulses [pulses]}}$ <p>If the position loop gain is too low, the motor responsivity will deteriorate because there will be too many accumulated pulses. If the position loop gain is too high, oscillation and noise might occur. In general, the setting should be :</p> <p>50 to 70 (1/s) for NC Machine tools  30 to 50 (1/s) for Multi-purpose machines  10 to 30 (1/s) for industrial robots  Setting range is 1 to 250.</p>
Position Loop FF Gain	<p>The position loop FF gain process the speed reference pulses and reduces the positioning time by adding directly to the command voltage.</p>  <p>The following diagram shows the relationship between the position loop FF gain and the speed reference pulses</p> 



Parameter	Description
Backlash Correction	<p>The parameter sets backlash correction for the mechanical system. It is a function for pre-registering the backlash space within a range of 0 to 10,000 pulse to minimise the positioning error of the machines moving forward or reverse direction to the same position.</p> <p>A backlash is a sudden backward movement of a driving axis that may be caused due to mechanical looseness as shown.</p>  <p>The positioning of the machine can be precisely if there is backlash.</p>
Brake Off Time	The delay time before the Positioning Completed Flag turns ON. Setting Range 0 to 10,000ms. (Used when performing Servo Lock.)
Brake On Time	The delay time before the Positioning Completed Flag turns off. Setting Range 0 to 10,000ms. (Used when performing Servo Unlock.)

- Note** 1. The Error Counter Function Selection (bit 07 to word n) can be used to set either error counter error detection (default setting) or and error counter warnings. If the error detection is set and the number of pulses in the error counter exceeds the warning value, an error counter overflow error will occur and the servo will be turned off. IF the alarm function is set, the Error Counter Warning Flag will be turned on instead.


Generally set the error warning counter about 20% above the level of pulses that accumulate during normal operation and adjust to proper setting for the mechanical system. When a problem occurs in the mechanical system or motor, the accumulated pulses in the error counter will exceed the set value so the error can be detected.



The following table shows the Error Counter warning flag and Error Counter function selection allocation for CS1W-MC421/221.

Word		Axis	Bits	Bit names
MC221	MC421			
N+22	n+38	X axis	06	Error Counter Warning Flag
N+25	n+41	Y axis		
	n+44	Z axis		
	n+47	U axis		
n		All	07	Error Counter function selection

2. When positioning an axis, the Position Completed Flag in the PC interface area is turned ON when the pulse distribution is completed and the axis is in position.




The following table shows the Axis Start bit and Positioning Completed Flag allocation.

Word		Axis	Bit names
MC221	MC421		
n+22	n+38	X axis	Axis Start Bit (bit 04) Positioning Completed Flag (bit 05)
n+25	n+41	Y axis	
	n+44	Z axis	
	n+47	U axis	

#### Servo Parameter

CV500-MC421/221 and C200H-MC221



The configuration of the parameter is similar as in CS1W-MC421/221.

Parameter	Setting Range
Error Counter Warning	0 ~ 65000 ( See Note 1)
In position	0 ~ 999 (See Note 2)
Position Loop Gain	5 ~ 150 (Model CV500-MC421/221) 5 ~ 250 (Model C200H-MC221)
Position Loop FF Gain	0 ~ 100
Backlash	0 ~ 999

**Note** 1. The following table shows the Error Counter Alarm allocation for CV500-MC421/221.

Word		Axis	Bits	Bit names
MC221	MC421			
n+18	n+18	X axis	07	Error Counter Alarm Flag
n+20	n+20	Y axis		
	n+22	Z axis		
	n+24	U axis		

The following table shows the Error Counter Alarm Flag allocation for C200H-MC221.

Word	Axis	Bits	Bit names
MC221			
n+16	X axis	06	Error Counter Alarm Flag
n+19	Y axis		

2. The following table shows the Axis Operating Bit and the Positioning Completed Flag for CV500-MC421/221.



Word		Axis	Bit names
MC221	MC421		
n+18	n+18	X axis	Axis Operating Bit (bit 02) Positioning Completed Flag (bit 03)
n+20	n+20	Y axis	
	n+22	Z axis	
	n+24	U axis	

The following table shows the Axis Operating Bit and the Positioning Completed Flag for C200H-MC221.

Word	Axis	Bit names
MC221		
n+16	X axis	Axis Operating Bit (bit 04) Positioning Completed Flag (bit 05)
n+19	Y axis	

Upon configuring the following parameters for an axis:



- Machine Parameter
- Coordinate Parameter
- Feed Rate Parameter
- Zone Parameter
- Servo Parameter

If  is shown at the toolbar, this show that the parameter setting is out of range. Click on the icon and the error will be shown. The error will be shown in red, tips will be shown on the bottom of the parameter window. If  is shown, that means that the parameter setting is all right.

Users are able to copy the parameter settings from one axis to another by the steps are as shown.

To copy the parameter setting from X axis to the other axis(Y, Z or U). Select X (as shown)



Then click on the **Copy Axis** icon . Select the destination, example Y (as shown), then click on the **Paste Axis** icon .





## 1-6 Downloading and Upload of Parameters


### 1-6-1 Downloading of Parameters

To download the parameter setting to the MC units, please follow the steps as shown:


Select the MC unit, then click on , the following window will appear.




Select **Parameters** to download the parameters Setting only; or at the project tree, select the Parameters setting file, and click . Then, **Download** Dialogue box will appear.




**Note:** Only the **Parameters** is selected.



To proceed, click on **Transfer**, to download the Parameters. At the lower portion of the dialogue box, the status of the file transfer will be shown.




To download the Parameters Settings to the Flash Memory, tick the checkbox of **Flash Memory Write**.




## 1-6-2 Uploading of Parameters

To upload the parameters setting from the MC unit, please proceed as followed.


Select the MC unit to upload, click on , the following window will appear.



Click on **Parameters**.



Then click on **Transfer**. At the lower portion of the Upload window, the file transfer status will be shown.




Upon completion, click on cancel to proceed. The parameters settings will be shown on screen.


### 1-6-3 Verify Parameters Settings

To verify the parameters settings of the MC unit, please proceed with the following steps.


Select the MC unit, and click on . At the **MC Verify** window, select **Verify Parameters**.




Click on **Upload** to proceed, at the **Result** Section , the file transfer status will be shown.



Upon uploading of the parameters, the following window will appear, select the file to verify with, and click **Open**.



Then at the **MC Verify** window, the compare result will be shown.



To verify with multiple files, check the checkbox at **Verify against a further file**. Then click on **OK**.

The **Open** dialogue box will appear. Select the file to compare will and click **Open**.  
The result will be shown.



## Section 2

### Position Data

In this chapter, the different method of editing the position data will be described.

2-1	Position Data .....	2
2-1-1	Creating Position Data file.....	2
2-1-2	Inserting Position Data file to Project.....	4
2-2	Downloading and Upload of Position data file.....	5
2-2-1	Downloading of Position Data.....	5
2-2-2	Uploading of Position Data .....	6
2-2-3	Verifying of Position Data.....	8
2-3	Changing Position Data via Programming .....	10
2-3-1	CS1W-MC421/221 .....	10
2-3-2	CV500-MC421/MC221 .....	12
2-3-3	C200H-MC221 .....	13


## 2-1 Position Data

The motion of the machine controlled by an OMRON PLC and MC unit combination is defined using one or more G Code programs. These programs contain sequences of movements and delays which combine across the two or four axes of the controller to perform the job required. The G Code programs work in conjunction with the parameter settings and position data of the project.

### 2-1-1 Creating Position Data file

To create position data, please perform the following steps:

#### *File - New - Positions*



The Position Window as shown will appear.

Positions1		
Addr	Value	Label
0	0.	
1	0.	
2	0.	
3	0.	
4	0.	
5	0.	
6	0.	
7	0.	
8	0.	
9	0.	
10	0.	
11	0.	
12	0.	
13	0.	
14	0.	
15	0.	
16	0.	

As the MC unit are able to store up to 2000 position data, the position data are addressed using addresses A0000 to A1999 in G-Code programs.

The position data will be stored in the following format.

Example:

For 2-axis system: (XY)

A50	First X-position
A51	First Y-position
A52	Second X-position
A53	Second Y-position

For 4-axes system (XYZU)

A50	First X-position
A51	First Y-position
A52	First Z-position
A53	First U-position
A54	Second X-position
A55	Second Y-position
A56	Second Z-position
A57	Second U-position

Example of G-Code program using the position data.

```
N010 G01 XA1000 MA1001
```

Explanation:

The content of A1000 (Address 1000 for position data) will be used for X-axis, and the content of A1001 will be used for M code.

Example of G-Code program using the position data

```
N009 G90                                Absolute specification.
N010 G00 XA1000 YA1001 M001
```


Explanation:

The content of A1000 (Address 1000 for position data) will be used for X-axis, and the content of A1001 will be used for Y-axis.


In completion of creating the position data, save the file with an extension ".mca".

The steps are as followed:

File- Save File as



The following dialog box will appear.




Enter the desire filename and click on **Save**.


### 2-1-2 Inserting Position Data file to Project

To insert the position data to a project, please followed the steps as shown.


At the Project Tree, use the right mouse to click on the desire MC card, the following pop-up window will appear.




Select **Add File**, from the file selection dialog box, select the Position Tab.



Then select the desire file to insert, then click on **Add**.




At the project tree, the position file icon will be shown. Please note that only one position data file are allowed.




## 2-2 Downloading and Upload of Position data file


Downloading and Uploading of the Position data are supported by CX-Motion, to execute these functions provided, please follow the steps as shown.

### 2-2-1 Downloading of Position Data

Select a MC unit to download, click on . (Download Icon.) The Download Dialog box will appear, check the Positions checkbox, or;




At the project tree, click on Position data file, and click on




**Note:** Only **Positions** is highlighted


Then select **Transfer**. The downloading status of files will be shown.





To download the position data to the Flash Memory, check the checkbox at **Flash Memory Write**.




### 2-2-2 Uploading of Position Data


To upload position data, select the desire MC unit, then click on ; check the checkbox or the Position; or



At the project tree window, click on the Position data file and click .




Then click on **Transfer** to upload the Position data. The status of file transfer will be shown.




**Note:** The MC unit allows only one Position data file.

### 2-2-3 Verifying of Position Data


To verify the Position data, click on , then select **Verify Position Data**.



Then, click on **Upload**. The status of file transfer will be shown at the bottom left corner of the **MC Verify** window.




When completion, the **Open** dialogue box will appear, thus prompting user to select a file to verify with.






Then the selected file is being compare and the result will be shown at the result portion.




To verify against a further file, check the checkbox as shown.



Then click on **OK**. At the **Open** dialogue box, select the file to verify against.



After verification, the result will be shown.



## 2-3 Changing Position Data via Programming

Position Data can be change via Ladder Programming. In the G code Program, users are able use AXXXX as a variable. Hence, with the help of the Ladder Program, users are able to change the value as required by the application.

### 2-3-1 CS1W-MC421/221

The procedure of changing the position data are as shown.

#### 1,2,3... 1. Position Data Addressing

The addresses of the positions data are specified in hexadecimal when using IOWR/IORD commands.

Data	Address Range
Position data	0000 to 07CF (decimal: 0000 to 1999)

The preceding addresses 0000 to 1999 are specified using A0000 to A1999 in G language.

#### 2. Position Data Configuration

Each position is comprised of three words.

	15	12 11	08 07	04 03	00
j+0	0	0	0	A (Decimal point position)	
j+1	Position data (32-bit signed: Rightmost 16 bits)				
j+2	Position data (32-bit signed: Leftmost 16 bits)				

A: Decimal Point Position      0: x 1  
    1: x 0.1  
    2: x 0.01  
    3: x 0.001  
    4: x 0.0001

For example, the position data is 1234.567 (123456 = 1E240)

j+0 :        0003  
 j+1 :        E240  
 j+2 :        0001

Another example, the position data is -387654.32 (-38765432 = FDB07C88)

j+0 :        0002  
 j+1 :        7C88  
 j+2 :        FDB0


#### 3. Using Ladder Programming.

In these examples, the IOWR operands and transfer data are all assumed to be correct. When debugging, write ladder code that will check the status of the Error Flag and bit 14 of word n + 10/n + 18.

**Example 1** Transferring Four Positions to A0456 to A0459 from D0100 to D0111  
Position data      Position data address

A0456	345678.90
A0457	123456.78
A0458	-387654.32
A0459	123.456

**Ladder Program**




**Settings**  
**DM Area**

D00100	0002	}	345678.90
D00101	76D2		
D00102	020F		
D00103	0002	}	123456.78
D00104	614E		
D00105	00BC		
D00106	0002	}	-387654.32
D00107	7C88		
D00108	FDB0		
D00109	0003	}	123.456
D00110	E240		
D00111	0001		


## 2-3-2 CV500-MC421/MC221

To send new position data to the MC unit, the procedure are as shown.

The following diagram shows how to transmit the value 1234.567 to position data address A0100.



## Ladder Program




2-3-3 C200H-MC221

The process of sending new position data to C200H-MC221 is similar to CS1, that is , the IOWR instruction is used.

Instead of expressing the data in terms of hexadecimal, the values of the data is express in terms of BCD.

Ladder Diagram



Settings  
DM Area

D00100	0002	}	345678.90
D00101	7890		
D00102	3456		
D00103	0002	}	123456.78
D00104	5678		
D00105	1234		
D00106	0002	}	-387654.32
D00107	5432		
D00108	B876		
D00109	0003	}	123.456
D00110	3456		
D00111	0012		

## Section 3

# G-Code Programming

This section will describe how G-Code program can be created in CX-Motion. The detail of individual G-Code description can be found in the Appendix A.

3-1	Program .....	2
3-1-1	Creating New program .....	2
3-1-2	Programming .....	2
3-1-3	Compilation of Program .....	6
3-1-4	Saving of program .....	6
3-1-5	Inserting a file to project .....	7
3-2	Downloading and uploading of Program Files .....	8
3-2-1	Downloading of Programs .....	8
3-2-2	Uploading of Programs .....	10
3-2-3	Verifying of Program .....	11


## 3-1 Program

The motion of the machine controlled by an OMRON PLC and MC unit combination is defined using one or more G Code programs. These programs contain sequences of movements and delays, which combine across the two or four axes of the controller, to perform the job required. The G Code program or programs work in conjunction with the parameter settings and position data of the project. Up to 100 programs can program into the MC unit. Hence, CX-Motion provides the utilities for programmer to write G-code programming for MC unit.


### 3-1-1 Creating New program

To create a new program file, please follow the steps as shown.

#### *File - New - Program*




The programming window will appear.



### 3-1-2 Programming

To start programming, click on the workspace provided.

Online help will appear in a yellow box from time to time, guiding programmer on the programming structure.



Guides on G-code will also be shown.

```

N000 P000 XY
n001 G90
n002 G00 XA0100 M001
n003 G01 XA0102

```

G00 or MOV:  
 \_[<Axis movement command>]\_[M<M code>]\_[#<optional number>]

In the program, each command line will be identified by a NXXX (representing the block/line number).

In the first line of a program, it is normal started with a declaration of program number, which is represented by PXXX, and a notification on the usage of the axes (XYZU).

**Example:**

```

N000 P000 XY
:
:
N003 G90
:
:

```

**Note:** The block number varies from 000 to 800 (maximum per program), and the program number varies from 0 to 100 (which depend on the number of task used.)

In every carriage return at the end of command line, the subsequent line number will automatically appear.

```

N000 P000 XY
n001

```

In the case of inserting a command in between written line, the line number will be jumble up.

```

N000 P000 XY
n001 G90
n002 G00 XA0100 M001
n003 G01 XA0104 YA105 M003
n003 G91
n004 G01 XA0102 YA0103 M002
n005 G79


```

Or during compilation of the program, the following error will be shown.

```

Line number out of sequence: 003
n003 G91

```

Click on  to rearrange the line number.


```

N000 P000 XY
n001 G90
n002 G00 XA0100 M001
n003 G01 XA0104 YA105 M003
n004 G91
n005 G01 XA0102 YA0103 M002
n006 G79


```



To acquire details on the G-code, click on . The G-code reference card dialog box will appear.




The **Codes** tab will display the G-code available for the particular MC unit, selected by **Current**. To change the MC Model, click on the down-arrow.



Choose the model of your choice, the G-code reference Card will display the applicable G-code.


To display the description of the G-code, check on the corresponding checkbox and click on the **Details** tab. The details of the selected G-code will appear.



The descriptions includes:


- Format
- Description
- Parameters
- Note
- Caution
- Example Program


To view the address and register available in the MC units, select the desire MC unit and click in the **Addr/Regs** tab.



### 3-1-3 Compilation of Program

In completion, users are able to compile the written G-code.

Click on the project workspace, then click on . The program will be compiled. The result of compilation will be shown at the bottom of the program window.




If error occurs, the description will be in red, else "No errors reported" will be displayed.



### 3-1-4 Saving of program


To save the written program, select **File - Save as**. Then, labelled the file.




The G-code program file will have an extension ".mcp".

### 3-1-5 Inserting a file to project.


To insert a program file to a project, use the right mouse click to select a MC unit. From the pop-up menu, select **Add File**.



From the dialog box, select the file to include, and click on **Add**.



At the project tree the filename will be displayed.




## 3-2 Downloading and uploading of Program Files


### 3-2-1 Downloading of Programs

Programs can be downloaded by two method, single program download or batch program download.


The steps are as shown.

#### Single Program download


To download a single program, at the project tree, highlight the filename, and click on .



Then at the **Download** Window, click on **Transfer**. The file transfer status will be shown at the lower portion of the **Download** Window.




To download the program to the Flash Memory, check the checkbox at the Flash Memory Write.




### Multiple Programs download


To download all programs in one shot, at the project tree, select the MC unit and click on the download icon.



At the **Download** window, select Programs, and click on **Transfer** to proceed.





To download the program to the Flash Memory, check the checkbox at the Flash Memory Write.




### 3-2-2 Uploading of Programs

To upload the program from the MC unit, please proceed with the steps as shown.

At the project window, click on the MC unit to upload, then click on . At the **Uploading** Window, select **Programs**, and click **Transfer**.



The CX-Motion will upload program files until all files have been uploaded.



Indicating the filename uploading at the moment.

Show the number of program files available in the MC unit


Hence, the **Transferring** box will constantly update the user by displaying the present uploading file.

In completion, all program files will be displayed on the screen.


### 3-2-3 Verifying of Program

To verify the program, please follow the steps as shown.


Select the MC unit for verification, then click on . Then at the **MC Verify** Window, select **Verify Program**.



Then click on **Upload**. "Checking MC, please wait" will be shown at the **Result** portion. (The CX-Motion will check for the number of program available in the MC unit.)




Upon checking, the following window will be shown.




Select the program to verify and click on **Upload**.




The status of the file transfer will be shown.




Upon completion, the **Open** Window will prompt user to select the file to compare with. Select the appropriate file and click **OK**.




The file will be verify, and the result will be shown at the result portion.



To verify against a further file, check the checkbox at the **Verify against further file**, and click **OK**



The **Open** window will appear for the user to select the file to verify against. Then click OK to continue, the result of the verification will be shown.



## Section 4

# Automatic Downloading Function

This section will contain description of writing a script for Automatic Downloading of program files or position data. The activation of the Automatic Downloading Function will also be described.


4-1	Script .....	2
4-1-1	Creating of Script file .....	3
4-1-2	Autodownload .....	6
4-2	Executing Automatic Loading .....	8
4-2-1	Parameter to access .....	8
4-2-2	Related Bits in the PC Interface Area .....	9

## 4-1 Script

CS1 MC Unit has an auto-download features that allow a ladder control program running on the CPU to request new G code programs and position data for MC unit. This function allows more programs or program blocks to be executed by treating external memory devices connected to a personal computer running CX-Motion as MC Unit memory.

The automatic loading function is executed by the IOWR instruction for the Command Area. Either Automatic Mode or Manual Mode can be used.

Any number from 1 to 10,000 can be specified as the job number. CX-Motion must be used to create MC programs and position data in advance for job numbers that are to be used.



### How does auto-downloading work?

- 1,2,3... 1. The MC unit's job number is always monitored by CX-Motion.
2. Using the IOWR instruction, a new job number is written to the job number currently in the MC unit.
3. When CX-Motion detects the specified job number, the program and position data are downloaded to the MC unit from the file for that the job number created by CX-Motion.
4. Before downloading the program and position data, CX-Motion deletes from the MC unit all of the programs for all tasks. Then it downloads the program and position data for the specified job number.
5. When the downloading has been completed, the CPU unit is notified from the MC unit. While the program and position are being downloaded, the Auto-loading it in the PC Interface Area turns from OFF to ON, and when the downloading is completed normally it turns from ON to OFF.


To enable the auto-downloading features, user must create a script file. This script file contains three sections:

- A project file
- A poll interval
- The jobs to process


### 4-1-1 Creating of Script file

To create the script file, follow the steps as shown.

At the **File** menu, select **New - Script**.




The script window will appear in the workspace.




### Adding Project File


To set the project file (i.e., information of the MC Unit.), click on the right mouse button, and select **Set Project**.



At the following window, select the project to add in, and click on **Set**.




At the Script window, the filename and the path will be shown.



### Setting Time Interval

The time interval determines the polling time for the CX-Motion to poll the MC units for the job number. For example, if the script specifies a poll interval of two seconds, and two MC units, each unit will be polled once every four seconds. If a job number is specified, the programs and position data corresponding to the job number will be downloaded to the MC unit. (The CX-Motion will delete all programs for all tasks before downloading.)


To change the interval time setting, highlight the **Interval (s)**, and click on it, when the blinking cursor appeared, key-in the desire time. The range is between 1 to 60 seconds.



### Define Jobs

At the **Jobs**, the job functions will be defined. The job number and the files to download will be set in the section.


To start with, at the script window, click on the right mouse button, and select **Add Job**.




Then, an icon with a job number will appear under the **Jobs** branches.




At the Jobs number, set the files to download. Click on the right mouse key, and select **Add File**.



From the **Add File** window, select the desire file.




Then, click on **Add**. The path of the file will be shown.



To add Jobs and files to each the Jobs task, repeat the steps as shown above.

**Note:** Only one position data file can be set per task.




### 4-1-2 Autodownload

After the creation of the script file, connect the computer with CX-Motion with the MC unit, then RUN the script. It is only possible to run one script at a time, although the script can process many MC units.


While the script is running, it is still possible to use the main editing and monitoring features of CX-Motion. However, that some online functions may perform slower than normal as the communications connection is now processing and passing more information, thus causing the polling rate between CX-Motion and the MC units to be slower than expected. (Example: System is being used to monitor an MC unit.)

To run the script, followed the steps as shown.


Select **OnLine - AutoDownload - Start Script**



The process can be monitor by the status bar at the **Script** Window.



At an interval of 1second, the CX-Motion will poll the specified MC unit.






After the specified timeout time, CX-Motion will poll for the next MC unit.




To stop the Script, please proceed with the steps as shown.

Select **OnLine - AutoDownload - Stop Script**.





The **Status** bar at the Script window will display **Stopped**.



## 4-2 Executing Automatic Loading

To execute automatic downloading, set one of the following addresses for the control code (C) of the IOWR instruction and then transfer the job number to the MC Unit.

### 4-2-1 Parameter to access


Address		R/W	Name	Configuration
MC221	MC421			
17D8 (6104)	17D8 (6104)	R/W	Specifying automatic loading	 <p>This parameter is used when batch downloading programs and position data to an MC unit from the external memory device of a personal computer with CX-Motion.</p> <p>X (Job No.) Specifies a job number within a range from 0001 to 2710 Hex (1 to 10,000). The following contents can be read from this address using an IORD instruction. X= 0000: Power supply ON, automatic loading completed normally X= 0001 to 2710 Hex (1 to 10,000): Specified jib number or executing job number.</p>
0FA9 (4009)	0FA9 (4009)	R	Teaching Box language/autoload timeout	 <p>Autoload timeout _____ T.Box language _____ T.Box language _____</p> <p>Specifies whether the T.Box message is displayed in English or Japanese. (Only bit 0 is valid) X=0: English, X=1: Japanese</p> <p>Autoload Timeout Specifies whether the time up time is displayed when the automatic loading function is used. Range: 00 to B4 Hex ( 0 to 180s) Time up will not be monitored if 00 is set.</p>

**Note** Programs and position data will not be properly downloaded to the MC Unit if the personal computer cable is disconnected or CX-Motion downloading is interrupted during execution of the automatic downloading function. If that occurs, perform the operation again.

#### Ladder Programming example

In this example, job number 100 is specified. The MC Unit is mounted to a CS1 PC and assigned unit number 0, and the job number to be transferred (job number 100) is stored in words D00100 and D00101. Both the IOWR operands and the data to be transferred are assumed to be normal.

When debugging, check the Error Flags from the ladder program.



### Transfer Data


D00100	0064	← Job Number: 100
D00101	0000	

## 4-2-2 Related Bits in the PC Interface Area

Bit Name	Model	Words	Bit	Decription
Autoloading Error Reset Bit	MC421 MC221	n n	05	↑: Error reset for automatic loading
Autoloading Flag	MC421 MC221	n+10 n+18	04	↑:Automatic loading begun ↓:Automatic loading finished
Autoloading Error Flag	MC421 MC221	n+10 n+18	05	↑:Error occurred during automatic loading ↓:Automatic loading error reset turned ON.

### Autoloading Flag


This flag turns ON when the data for the specified job number begins to be downloaded as the result of executing the IOWR instruction. It turns OFF when all of the data for that job number has been downloaded.



### Autoloading Error Flag and Error Reset Bit

The Autoloading Error Flag turns ON when an error occurs during automatic loading. When the Autoloading Error Reset Bit is turned ON, the Autoloading Error Bit will turn OFF. Unless the cause of the error has been cleared, however, the Autoloading Error Flag will turn back ON again the next time the automatic loading is executed.

If communications are not restarted by the time the Autoloading Time Up set in the unit parameters has elapsed, an error will occur and the Autoloading Error Flag will turn ON. If that occurs, the data transferred up to that point will be discarded.



**Note:** The MC Unit does not monitor the time from when it receives the automatic loading command until the Autoloading Flag turns ON. There may be cases where the power to the personal computer is turned OFF or a cable is disconnected, so monitor this time from the ladder program.

## Section 5

# Monitoring Function

This section describes the monitoring utilities provided by the CX-Motion.

5-1	Monitoring Function.....	2
5-1-1	Monitor Coordinates.....	3
5-1-2	Monitor MC Task.....	4
5-1-3	Monitor I/O status.....	6
5-1-4	MC FAL Status.....	7
5-1-5	View MC Error Log .....	8
5-2	The Servo Graph.....	9
5-2-1	Immediate .....	9
5-2-2	Axis Run.....	11
5-2-3	Saving File.....	12
5-2-4	Reading a save file.....	12
5-2-5	Retrieving file in Microsoft Excel .....	14


## 5-1 Monitoring Function


The following Monitoring Functions are provided by the CX-Motion.

Window Name	Description		
MC Coordinates Displays	<p>The following information will be shown:</p> <ul style="list-style-type: none"> <li>▪ Reference Coordinate (In pulse)</li> <li>▪ Reference Coordinate ( As selected in the Machine Parameter - Motor Setting - Display Unit.)</li> <li>▪ WorkPiece Coordinate</li> <li>▪ WorkPiece Origin Shift</li> <li>▪ Error Counter</li> <li>▪ Error Messages</li> </ul>		
Monitor MC Tasks	<p>The following information will be shown:</p> <ul style="list-style-type: none"> <li>▪ Executing Program</li> <li>▪ Task Status</li> <li>▪ Error Messages</li> <li>▪ Axis Monitoring</li> </ul>		
I/O status Display	<p>ON/OFF status of Input and Output</p> <table> <tr> <td> <p>Input</p> <ul style="list-style-type: none"> <li>▪ General Input</li> <li>▪ Origin Proximity</li> <li>▪ CW / CCW Limit</li> <li>▪ Emergency Stop Input</li> <li>▪ Alarm Input</li> </ul> </td><td> <p>Output</p> <ul style="list-style-type: none"> <li>▪ General Output/Break Signal Output</li> <li>▪ Memory Run</li> <li>▪ Memory Run Stopped</li> <li>▪ Run Command Output</li> <li>▪ Alarm Reset Output</li> <li>▪ Sensor ON Output</li> </ul> </td></tr> </table>	<p>Input</p> <ul style="list-style-type: none"> <li>▪ General Input</li> <li>▪ Origin Proximity</li> <li>▪ CW / CCW Limit</li> <li>▪ Emergency Stop Input</li> <li>▪ Alarm Input</li> </ul>	<p>Output</p> <ul style="list-style-type: none"> <li>▪ General Output/Break Signal Output</li> <li>▪ Memory Run</li> <li>▪ Memory Run Stopped</li> <li>▪ Run Command Output</li> <li>▪ Alarm Reset Output</li> <li>▪ Sensor ON Output</li> </ul>
<p>Input</p> <ul style="list-style-type: none"> <li>▪ General Input</li> <li>▪ Origin Proximity</li> <li>▪ CW / CCW Limit</li> <li>▪ Emergency Stop Input</li> <li>▪ Alarm Input</li> </ul>	<p>Output</p> <ul style="list-style-type: none"> <li>▪ General Output/Break Signal Output</li> <li>▪ Memory Run</li> <li>▪ Memory Run Stopped</li> <li>▪ Run Command Output</li> <li>▪ Alarm Reset Output</li> <li>▪ Sensor ON Output</li> </ul>		
MC FAL Status Display	<p>MC unit Error Display</p> <ul style="list-style-type: none"> <li>▪ MC FAL</li> <li>▪ Task FAL</li> <li>▪ Axis FAL</li> </ul>		
MC Error Log	The 20 error that occur most recently will be displayed. (If more that 20 error had occur the old error will be deleted.)		
Servo Graph Input	Data Trace and General input trace.		

### 5-1-1 Monitor Coordinates

To monitor the present values of coordinates, please proceed with the steps as shown.

Click on , the following window will appear.



The dialog box titled "Monitor MC Coordinates" contains several sections for monitoring coordinate data:

- Reference Coordinate (mm):**

X Axis	0	mm
Y Axis	0	mm
Z Axis	0	mm
U Axis	0	mm
- WorkPiece Coordinate (mm):**

X Axis	0	mm
Y Axis	0	mm
Z Axis	0	mm
U Axis	0	mm
- Reference Coordinate (pulse):**

X Axis	0	pulse
Y Axis	0	pulse
Z Axis	0	pulse
U Axis	0	pulse
- Error Counter (pulse):**


X Axis	0	pulse
Y Axis	0	pulse
Z Axis	0	pulse
U Axis	0	pulse
- WorkPiece Origin Shift (mm):**

X Axis	0	mm
Y Axis	0	mm
Z Axis	0	mm
U Axis	0	mm
- Error Messages:** A text area for displaying error messages.

Buttons: Close, Help, Start, Next.


The coordinates displayed represent the respective titled at the boxes.

To start monitoring, click on **Start**. When the icon is click, the CX-Motion will tried to go ONLINE. If communication error occurs, the following dialog box will appear.



The dialog box titled "CX-Motion" displays a yellow warning triangle icon and the message: "Communications Error - (FINS Code0202) No Response". An "OK" button is present at the bottom.

Else the status of the coordinates will be shown.



The dialog box titled "Monitor MC Coordinates" shows updated coordinate values after monitoring has started:

- Reference Coordinate (mm):**

X Axis	-00121582	mm
Y Axis	00069549	mm
Z Axis	00000000	pulse
U Axis	00000000	pulse
- WorkPiece Coordinate (mm):**

X Axis	-00121582	mm
Y Axis	00069549	mm
Z Axis	00000000	pulse
U Axis	00000000	pulse
- Reference Coordinate (pulse):**


X Axis	-00121579	pulse
Y Axis	00069507	pulse
Z Axis	00000000	pulse
U Axis	00000000	pulse
- Error Counter (pulse):**

X Axis	00000054	pulse
Y Axis	-00000503	pulse
Z Axis	00000000	pulse
U Axis	00000000	pulse
- WorkPiece Origin Shift (mm):**

X Axis	00000000	mm
Y Axis	00000000	mm
Z Axis	00000000	pulse
U Axis	00000000	pulse

Buttons: Close, Help, Start, Next.

To monitor individual box, click on the next button. Only the highlighted box will have its coordinates updated. To select the other boxes, click on **Next**.





The **Monitor MC Coordinates** dialog box displays coordinate data for four different boxes. Each box has a title bar and a list of axes with their values and units.

Box	X Axis	Y Axis	Z Axis	U Axis
Reference Coordinate (Box 1)	-00108463 mm	-00003943 mm	00000000 pulse	00000000 pulse
WorkPiece Coordinate (Box 2)	-00125538 mm	00060159 mm	00000000 pulse	00000000 pulse
Reference Coordinate (Box 3)	-00125533 pulse	00060200 pulse	00000000 pulse	00000000 pulse
WorkPiece Origin Shift (Box 4)	00000000 mm	00000000 mm	00000000 pulse	00000000 pulse

Buttons: **Close**, **Help**, **Start**, **Next** (highlighted).

### 5-1-2 Monitor MC Task

To monitor the present status of the task, click on . The following window will appear on screen.



The **Monitor MC Tasks** dialog box shows the status of four tasks. The main area is a large empty box labeled 'Task/Program'. On the right, there is a 'Task Status' section with a list of tasks and their status.

Task	Status
1	OFF
2	OFF
3	OFF
4	OFF


Buttons: **Close**, **Help**, **Start**.

Task/Program: [Empty box]

Axis monitoring: X-Axis, Y-Axis, Z-Axis, U-Axis.

Task 1 Task 2 Task 3 Task 4


When the icon is click, the CX-Motion will try to connect to the PLC, if communication error occur, the following dialog window will appear.



The **CX-Motion** error dialog box displays a yellow warning triangle icon and the message: **Communications Error - (FINS Code0202) No Response**. An **OK** button is at the bottom.




To start monitoring, click on the Start button at lower right hand corner of the Monitor MC Task window.




At the bottom of the window, select the desire task to view (if more than one task is in used). At the **Tasks Status** section, the status of the task will be shown in correspond to ON/OFF. At the **Task/Program** section, the execution steps of the program will be shown, when the particular block number is being highlighted, it implies that the MC unit is executing that G code command.

To see more information, click on the Next button.


When the Next button is being click, users are able to view others information.




If error occurred while the task is processing, the error number will be shown at Error Messages.




### 5-1-3 Monitor I/O status


To monitor the I/O status of the MC unit, click on . The following window will appear.




When the icon is clicked, CX-Motion will try to communicate with the MC unit, however if communication error occur, the following window will appear.




Else, status of the Input will be display in terms of ON/OFF (which is GREEN/RED)




To view the Output status, click on the Output tab.




#### 5-1-4 MC FAL Status

To view the present fault that occur on the MC unit, click on . The following window will appear. The CX-motion will try to go ONLINE with the MC unit when the icon is being click. If communication error occur, the following window will be shown.





Else the present fault status will be display.




### 5-1-5 View MC Error Log

The CX-Motion provide error log viewer for user, The Error Log are able to display up to 20 error that had occurred. If more than 20 errors were accumulated, the old error will be discard.


To view the error log, click on . The CX-Motion will try to go ONLINE, hence if communication error occurs, the following window will appear.



Else the error log will be displayed.



To clear the error log, click on the clear button.




## 5-2 The Servo Graph

The servo graph monitoring functions are only provided in CS1W-MC421/221. With these functions, users are able to monitor servo data as shown:

For each axis:

Feedback: Current, measured, velocity  
 Demand: Demanded velocity  
 Error: Error count

To start, click on , the **Servo Graph Input Window** will appear.



To start monitoring, there are two possible methods to trigger:


- Immediate  
That is, once the **Start** button has been clicked, the data trace will start.
- Axis Run  
Only when the selected axis or general input goes high, then the data trace will start.


It is also possible to specify the sampling interval in milliseconds (between 2 and 100ms).

After configuring the trigger type, click on **Start**.


### 5-2-1 Immediate

If immediate is selected, the following window will be shown.






When completed, the Status box will shown the process status.




Upon configuration, click on **OK**. The graph will be display as configured.



The legends of the graph are described as above.


If the scroll navigation tools are selected, the scroll bar will appear under the arrow button.




To scroll, click on the selector and move it <-> or <+>. To display continuous data, click on the arrow button, if ⇐ is selected, the graph will display data which go towards the <-> direction. If the ⇒ is selected, the graph will display data which go toward the <+> direction. With scroll navigation tools, a maximum of total of 500 trace data can be displayed. To stop continuous data display, click on **Step**.

### 5-2-2 Axis Run


When Axis Run is selected as trigger method, select the trigger source, and click on **Start**.




At the **Status** Bar the following information will be shown.



When the axis start running, the Status will show



Upon completion, the **Trace Complete** will be display at the status bar.




To display the graph, the steps are the same as **Immediate** method.

### 5-2-3 Saving File

The trace file can be save for further analysis. To save the file followed the steps below.


At the Servo Graph window, click on the **Close** button. At the **Servo Graph Input**, click on **Save File as**. The following will appear.



The Servo files will be save as \*.mcv.


### 5-2-4 Reading a save file

To retrieve the file for analysis, at the **Servo Graph Input** , click on the **File Read** button.







Select the appropriate file to read.



Then, the data will be display in the **Servo Graph Window**.




The filename of the read file will be display at the **Status Bar**.




### 5-2-5 Retrieving file in Microsoft Excel

Servo Data can also be read in Microsoft Excel, the steps are as shown.


At the Microsoft Excel, perform a file open operation. At the Open File Window, select **All Files** at the **File of type**.




Select the desired file and click **Open**. The **Text Import Wizard - Step 1 of 3** window will appear.



Click on **Next >** to continue. At the **Text Import Wizard - Step 2 of 3** window, select **Comma & Tab** as Delimiters and **"** as Text Qualifier.



Click **Next >** to proceed. At **Text Import Wizard - Step 3 of 3** window, click on **Finish** to complete. The servo data will be shown as below.



	A	B	C	D	E	F	G	H	I	J	K
1	IdntMCV										
2	21/12/1999	2:59:45 PM									
3	2										
4	8001										
5	0										
6	X Target	X P Velocity	X Error	Y Target	Y P Velocity	Y Error	Z Target	Z P Velocity	Z Error	U Target	U P Velocity
7	4	0	4	4	0	4	0	0	0	0	0
8	9	0	13	9	0	13	0	0	0	0	0
9	14	1	26	14	0	27	0	0	0	0	0
10	19	0	45	19	0	46	0	0	0	0	0
11	23	0	68	23	0	69	0	0	0	0	0
12	27	0	95	27	0	96	0	0	0	0	0
13	33	0	128	33	0	129	0	0	0	0	0
14	36	0	164	36	0	165	0	0	0	0	0
15	42	0	206	42	0	207	0	0	0	0	0
16	41	0	247	41	1	247	0	0	0	0	0
17	42	0	289	42	0	289	0	0	0	0	0
18	41	0	330	41	0	330	0	0	0	0	0
19	42	0	372	42	2	370	0	0	0	0	0
20	41	1	412	41	15	396	0	0	0	0	0
21	42	0	454	42	23	415	0	0	0	0	0
22	41	3	492	41	25	431	0	0	0	0	0
23	42	11	523	42	28	445	0	0	0	0	0
24	41	18	546	41	29	457	0	0	0	0	0

## Section 6

### Startup Guide

This section will give a basic guide of setting up a servo system, by using CX-Motion to configure the system parameter of the MC unit.

6-1	Getting started .....	2
6-1-1	Overview .....	2
6-1-2	Procedure .....	3
6-2	System Configuration and Wiring .....	4
6-2-1	System Configuration .....	4
6-2-2	Checking Operation from the Teaching Box .....	16
6-3	Considerations When Starting Up the MC Unit .....	21
6-3-1	Setting the System Parameters.....	21
6-3-2	Considerations When Starting Up or Making Adjustments.....	22
6-3-3	Changing the Teaching Box Mode for Trial Operation .....	22


## 6-1 Getting started

This section explains the MC Unit startup procedures, taking the CS1W-MC221 as an example.

### 6-1-1 Overview


In this operation, a 2-axis mechanical system using the X and Y axes is used for positioning according to an MC program in the G-language executed in Automatic Mode, and for performing servo-lock, origin search, and jogging operations in Manual Mode.

#### Mechanical System



#### Automatic Mode Operation

The MC Unit executes the following positioning according to the MC program.



- 1, 2, 3...
1. Each axis waits at its reference origin (0, 0).
  2. The X and Y axes are started to move the drill to a position where the first hole (400, 200) is to be drilled.
  3. The robot moves to the next position (100, 200).
  4. The robot moves to the last position (200, 400).
  5. The robot returns to the reference origin (0, 0).

#### Manual Mode Operation

##### Servo-lock

If no other manual command is being executed and if the axes are not already servolocked, the X and Y axes will be servolocked.

##### Origin Search

If no other manual command is being executed and if the origin has not been defined yet, an origin search will be executed for the X and Y axes.

##### Jogging

If no other manual command is being executed and if the axes are servolocked, jogging will be executed along the X and Y axes.

### 6-1-2 Procedure

The procedure for performing these operations is as follows:


1, 2, 3...

1. Mount the MC Unit.
2. Set the MC Unit's unit number
3. Connect and wire all Units and devices.  
Connect the Programming Devices to the CPU Unit and a personal computer with CX-Programmer and CX-Motion installed. Connect the Teaching Box. Wire the MC Unit external inputs. Wire the Input Unit (for the switchbox), and wire the Servo Driver.
4. Power up the PC and use CX-Programmer or the Programming Console to create I/O tables.
5. Create a new project and add PC (CPU Unit) using CX-Motion.
6. Add MC Unit to the project and set/save the system parameters using CX-Motion.
7. Create, compile, and save MC programs (G language), register in the project, and save the project using CX-Motion.
8. Transfer the system parameters and MC programs (G language) to the MC Unit and save in the flash memory using the CX-Motion.
9. Create a ladder program, transfer it to the CPU Unit, and save it.
10. Conduct trial operation. (Refer to 8)  
Using either CX-Motion or the Teaching Box, check the MC program in Automatic Mode and the servo-lock, origin search, and jogging operations in Manual Mode. Use CX-Motion for to monitor operation.  
When setting the system parameters and conducting the trial operation.

## 6-2 System Configuration and Wiring

### 6-2-1 System Configuration

Perform the operations using the following system configuration. Mount the MC Unit to the CPU Backplane and set it to unit number 0.



The model numbers for the Units and devices used in this configuration are provided in the following tables.

**Control System**

Name	Model
CPU Unit (Sysmac CS1-Series)	CS1H-CPU6_-E/CS1G-CPU4_-E
MC unit	CS1W-MC221
Input	C200H-ID212
Power Supply Unit	C200HW-PA204
CPU Backplane	CS1W-BC103
Power supply for input signals	DC power supply (+24 V)
Teaching Boc	CVM1-PRO01 + CVM1-MP702

**Programming Devices**

Name	Model
Personal Computer for Programming Devices	IBM PC/AT or compatible
Operating System	Windows 95/98/NT 4.0
CX-Programmer	WS02-CXPC1-E
CX-Motion	WS02-MCTC1-E

**Servo Control System**

Name	Model
Servo Drivers (two)	R88D-UA03L (for 100 VAC, 30 W) _ 2
Servomotors (two)	R88M-U03030L (for 100 VAC, 30 W) _ 2
Power Cables	R88A-CAU___S (for U Series)
Encoder Cable	R88A-CRU___C (for U Series)
Control Cable	R88A-CPU00_M1 (for U Series)

**Note** In this example operation, U series Servo Drives and Servomotors are used for the X and Y axes. To use H-series, M-series, or other Servo Drives and Servomotors, refer to the applicable manuals.

**Special I/O cable and Terminals**

Name	Model
Special MC Unit Cable	XW2Z-100J-F1
Special MC Unit Terminal Block	XW2B-20J6-6

**1) Mounting the MC Unit**

Mount the MC Unit to the CPU Backplane.

**2) Setting the Unit Number**


Set the unit number to 0 (MACHINE No. 00) with the rotary switch on the front panel of the MC Unit.





### 3) Connecting and Wiring Units and Devices

**Connecting Programming Devices** Connect the CPU Unit with connecting cable to a personal computer running the CX-Programmer and CX-Motion.



Unit	Port at CPU Unit	Personal Computer	Port at personal Computer	Network Type (serial communication s mode)	Cable model	Cable Length	Remarks	
CPU unit	Internal peripheral port	IBM PC/AT or compatible	D-sub 9-pin male	Peripheral bus or host link (SYSMAC WAY)	CS1W-CN226	2 meters	Use a connector with protection against static electric discharge	
					CS1W-CN626	6 meters		
	Built-In RS-232C port D-sub 9 pin female				XW2Z-200S-V	2 meters		
					XW2Z-500S-V	5 meters		
Serial Communications Board/Unit	RS-232C port D-sub 9 pin female			Host Link (SYSMAC WAY)	XW2Z-200S-CV	2 meters		
					XW2Z-500S-CV	5 meters		


#### Connecting the Teaching Box

Using the following connecting cable to the teaching box to the MC unit.


Model	Cable Length
CV500-CN224	2 meters
CV500-CN424	4 meters
CV500-CN634	6 meters

### Connecting MC unit External Inputs

The cable and terminal block shown in this example are for the CS1W-MC221.




### Connection Diagram



## Connecting the Servo Drivers

Connect the MC Unit and Servo Drivers using special Control Cable, and connect a +24-V power supply. Then connect the Servo Drivers to the Servomotors using special Power Cable and Encoder Cable. (The Control Cable, Power Cable, and Encoder Cable are all purchased separately.)


### Connecting Control Cables



The following table shows that available Control Cables.

Series	Model Number	Length
R88D-U	R88A-CPU001M1 (for two axes)	1.0 meters
	R88A-CPU002M2(for two axes)	2.0 meters

### Connecting Power Cables and Encoder Cables



The following table shows the available Power Cables and Encoder Cables.

#### Power Cables

Series	Specification	Model	Length
R88D-U	Without brake	R88A-CA003S	3 meters
		R88A-CA005S	5 meters
		R88A-CA010S	10 meters
		R88A-CA015S	15 meters
		R88A-CA020S	20 meters
	With brake	R88A-CAU003B	3 meters
		R88A-CAU005B	5 meters
		R88A-CAU010B	10 meters
		R88A-CAU015B	15 meters
		R88A-CAU020B	20 meters

#### Encoder Cables

Series	Model	Length
R88D-U	R88A-CRU003C	3 meters
	R88A-CRU005C	5 meters
	R88A-CRU010C	10 meters
	R88A-CRU015C	15 meters
	R88A-CRU020C	20 meters

#### Power Supply Wiring

Wire the power supply according to the instructions in the applicable Servo Driver manual.


#### 4) Creating I/O Tables

Turn ON the PC and create I/O tables according to the Units mounted to the Backplane. For details on creating I/O tables, refer to the CX-Programmer operation manual.

**Note** It is necessary to create an I/O table after mounting the MC Unit.

#### 5) Creating Projects/Adding PCs (CPU Units)

- Note** A simple explanation of the operation procedure is given below. For details, refer to Section 1.
- 1, 2, 3...**
1. Turn ON the power supply for the personal computer, start the CX-Motion and select **File/New/Project**.
  2. The Project Properties Dialog Box will be displayed. The title can be changed and explanation can be omitted.
  3. Click **OK**. The Add PC Dialog Box will be displayed.



4. Input the desired PC name.
5. Click the Down Arrow at the right of the PC Model Field, and select the PC model from the menu. For example, if the CPU Unit is the CS1H-CPU67, select **CS1H**.
6. Click the **Set** button on the right of the PC Model Field. Click the Down Arrow at the right of the CPU type field, and select the type of CPU Unit from the menu. In this example, **CPU 67** is selected.
7. Click the **OK** button. The Add PC Dialog Box will return.
8. Set the Network type. In this example, SYSMAC WAY is selected.
9. Click the **Set** button on the right of the Network Type Field, and click the Driver Tab.
10. In Port Name under Connections, select the port of the personal computer to which the cable is connected (COM1/COM2).
11. Click **OK**. The Add PC Dialog Box will return.
12. Click **OK**. The PC will be added to the project.

#### 6) Adding MC Units/Setting and Saving System Parameters

**Note** A simple explanation of the operation procedure is given below. For details, refer Section 1

- 1, 2, 3...**
1. In the project workspace, click the icon of the PC that was added in 5) Creating Projects/Adding PCs (CPU Units), and then select **Edit/Add MC**. The MC Unit Dialog Box will be displayed.
  2. Input the desired MC Unit name.
  3. Click the Down Arrow at the right of the MC Type Field and select **CS1W-MC221** from the menu.
  4. Set the unit number under Communications Environment Settings to 0 (unit number 0).
  5. Click **OK**.
  6. In this operation, new parameters are to be created, so click **No**. The Parameter File Save Type Dialog Box will be displayed.
  7. Input the file name and click **Save**. The system parameters will be saved, and registered in the project.

### System Parameter Settings

- 1, 2, 3... 1. Double-click the system parameters in the project workspace. The Unit and memory parameters will be displayed.

Set the system parameters that are required for controlling the MC Unit. Some of the defaults set by CX-Motion will be changed. Once the system parameters have been set, transfer them to the MC Unit and save them in the flash memory. For the task axis declaration, use the X and Y axes for task 1.

For detail, please refer to Section 1.

The following parameters require setting. Use default settings for other parameters.

Type of Parameter	Name	Set Value
Machine parameters	Minimum unit	0.01
	Display Unit	Mm
	Pulse Rate	1/100
	Positive/negative software limit	X-axis – direction: –50.00
		X-axis + direction: 600.00
		Y-axis – direction: –50.00
		Y-axis + direction: 600.00
Feed Rate parameters	Maximum feed rate	4000.00
	Maximum interpolation feed rate	4000.00
	High-speed origin search feed rate	400.00
	Low-speed origin search feed rate	40.00
	Maximum jog feed rate	400.00

When no axes are specified, set the same values for the X and Y axes.

## 7) Creating/Compiling/Saving MC Programs, Registering in Projects, and Saving Projects

### Creating Program

Using CX-Motion, create the following MC program. For details on creating programs, refer to Section 3..

### MC Program

```

N000 P001 XY
*001 SAMPLE PROGRAM
N002 G04 5
N003 G26 XY
N004 G11
N005 G01 X400 Y300 F30
N006 G01 X100 Y200 F10
N007 G01 X200 Y400 F30
N008 G026 XY
N009 G79
    
```

### Program Contents

```

N000 Declares program number P001 and use of the X and Y axes.
*001 This is a comment.
N002 Waits five seconds.
N003 Returns the X and Y axes to their reference origins.
N004 Selects the stop mode for positioning.
N005 Moves to X400 Y300 at speed 30.
N006 Moves to X100 Y200 at speed 10.
N007 Moves to X200 Y400 at speed 30.
N008 Returns the X and Y axes to their reference origins.
N009 Ends the program.
    
```

## Saving and Compiling the MC program

### Compiling

After creating the program and before transferring it to the MC unit, compile it and check that no errors are generated. For details, please refer to Section 3.

- 1, 2, 3... 1. Select **File/Properties**.  
2. Select **CS1W-MC221** for the MC type, and click **OK**.  
3. Select **Tool/Compile**.

### Saving

- 1, 2, 3... 1. Select **File/Save as....**  
2. After inputting a file name, click **Save**.

### Registering in the Project

- 1, 2, 3... 1. Click on the MC Unit that was added in 5) Creating Projects/Adding PCs (CPU Units, and select **Edit/Add File**).  
2. Click on **Program**, and click on the file that was saved in Saving above. The MC program will be registered in the project.

**Saving the Project** Save the project before transferring system parameters and the MC program to the MC Unit.

- 1, 2, 3... 1. Click on the project in the project workspace, and then select **File/Save project as....**  
2. Input a file name, and then select **Save**.

## 8)Transferring System Parameters and MC Programs to the MC Unit and Saving to Flash Memory

**Note** A simple explanation of the operation procedure is given below. For details, refer Section 3.

- 1, 2, 3... 1. Click on the MC Unit in the project workspace, select **Online/Transfer to MC**. The Download Dialog Box will be displayed.  
2. Turn ON the **All MC files** and **Write to flash Memory** settings and click **Transfer**.

## 9) Creating Ladder Programs/Transferring and Saving to the CPU Unit

### Creating Ladder Programs

Create ladder programs using CX-Programmer. The programs required to execute servo-lock, origin search and jogging in Manual Mode and to execute the MC program in Automatic Mode are given below. For details about creating, ladder programs refer to the CX-Programmer Startup guide. After creating a ladder program, be sure to transfer it to the CPU Unit.


### Notation Used in Ladder Program Diagrams

Bit/flag names in the < > symbols indicate outputs in allocated words. Bit/flag names in the ( ) symbols indicate inputs in allocated words.

In the following examples, the MC Unit is the CS1W-MC221 and the unit number is 00. Therefore, 30 words will be allocated to the MC Unit starting from CIO 2000. Word Area words are from W00000 to W00008. The Input Unit corresponds to CIO 0000.

Ladder Program


Input the ladder program shown below.




Continued on next page



Continued from previous page



**Note** A task error reset is required for when an error occurs during trial operation. Add an error reset like the on shown below to the program.



### Transferring the Program

After the ladder program has been created, transfer it to the CPU Unit. (Perform the procedure using CX-Programmer. Refer to CX-Programmer Startup Guide.)

### Saving the Program

Save the ladder program to a data disk. (Perform the procedure using CX-Programmer. Refer to CX-Programmer Startup Guide.)

## 10) Trial Operation (Operation Check)

**Note** A simple explanation of the operation procedure is given below. For details, refer to 9-2 Monitoring Operations in the CX-Motion Operation Manual.

Use the following procedures to confirm correct operation of the MC program in Automatic Mode and servo-lock, origin search and jogging operations in Manual Mode.

### Manual Mode

#### Power ON

If power is supplied to the MC Unit when the Servo Driver alarm input is already ON, an error will not be generated. An error will occur, however, if the alarm turns OFF and then ON again, or if an instruction that includes axis operation is performed with the alarm still ON. This feature allows greater flexibility with the sequence in which power is supplied to the MC Unit and the Servo Drive.

When operating the MC Unit online from a personal computer, the power supply for the personal computer must be ON first. Otherwise an error will occur.

#### MC Coordinate Displays

Display the MC coordinates in order to check the present position of each axis.

- 1, 2, 3... 1. Select **Online/MC coordinate display**. (For more detail, please refer to Section 5.)
2. Click **Start**.

#### Servo-lock



Set the Automatic/Manual switch to Manual. Servo-lock the X and Y axes by pressing the Operation Buttons. By performing servo-lock, power will be supplied to each axis. While the servo is locked, the CW and CCW indicators will flash. On the MC coordinates display screen, the present position values and the error counter pulse numbers will constantly change in a neighborhood of 0.

#### Origin Search

Set the Automatic/Manual switch to Manual. Execute an origin search for the X and Y axes by pressing the Origin Buttons. The axes will move to the origin. When origin search has been completed, the reference coordinate system present position values in the MC coordinates display screen will change to values near 0.

### Jogging

Check that jogging is performed correctly for each axis. Set the Automatic/Manual Switch to Manual. Press and hold down the X+ button to move the X axis in the + direction. The present position value for the X axis on the MC monitoring screen will increase. Press and hold down the X- button to move the X axis in the – direction. The present position value for the X axis on the MC monitoring screen will decrease. Use the same procedure to confirm correct operation for the Y axis. Be sure that the present position value does not exceed the set software limit. A CW software limit or CCW software limit error will occur.

### MC Program

Set the Automatic/Manual switch to Automatic. Press the Start Button to execute the MC program. From the MC task display screen, use the following procedure to display and check the MC program.

1, 2, 3...

1. Set the Automatic/Manual switch to Automatic.
2. Press the Start Button.
3. Select **Online/MC task display**. (For more detail, please refer to Section 5.)
4. Click **Start**. The MC program will be displayed on the screen. The part of the program currently being executed will be displayed in reverse video.
5. Check that the axes have moved to the coordinates indicated in the lower right-hand area of the screen under **Axis monitoring**.

## 6-2-2 Checking Operation from the Teaching Box

This section explains how to use the Teaching Box to execute the MC program and the jog operation. It explains cyclic execution, in which the specified program is executed from the beginning, and single-block execution, in which the specified program is executed one block at a time.

If servo-lock and origin search have not been executed using the switch box, execute the origin search from the Teaching Box after setting locking the servos before executing the MC program and jog operation.

### Changing the Mode to T. BOX RESERVED

1, 2, 3...

1. Press the EXT Key.

EXT		1/2
1.		CHANGE MODE
2.		SERVO LOCK
3.		SERVO FREE

2. Press 1.

EXT		-CHG MODE-
		T.BOX
		LIMITED
		SWITCH: ↑, ↓

3. Press the Down Key. (Pressing the UP and Down Keys switches among the three modes.)

## Executing Servo-Lock

- 1,2,3... 1. Select 2. SERVO LOCK from the Extension Mode Menu.

EXT		-SERVO LOCK-
		0. ALL AXES
		1. X      3. Z
		2. Y      4. U

2. Select all the axes.

EXT		-SERVO LOCK-
		OK?
ALL		YES / NO

The specified axis/axes are shown here.

3. Press the YES Key. The Servos will be locked, and the following screen will be displayed.

EXT		-SERVO LOCK-
ALL		COMPLETE!

## Executing Origin Search for All Axes

- 1, 2, 3... 1. Press the ORIG SRCH Key.

ORG		0. ALL AXES
		1. X      3. Z
		2. Y      4. U

2. Select 0. ALL AXES. Press 1 or 2 when selecting individual axis.

ORG		OK?
ALL		YES / NO

The specified axis/axes are shown here.

3. Press the YES Key. An origin search will be started and the present position monitoring screen will be displayed.

ORG	X*	12.00
	Y*	12.32
ALL	Z*	0.00
	U*	0.00

The present position will be refreshed for moving axes.

The origin search operations will be performed and the axes will stop at the reference coordinate system origins. The asterisks will disappear at that point, and the present position is shown as 0.

When the origin search operation has been completed for the specified axes, the following screen will be displayed.

EXT	
ALL	COMPLETE !

4. Press the CLR Key. The axis selection screen in step one of this procedure will return.

When an error occurs in the MC Unit or the Servo Driver, clear it by means of the following procedures.

### Resetting MC Unit Errors

- 1, 2, 3... 1. Press the ERR CLR Key.

[RT]
1.MC UNIT
2.DRIVER

2. Press 1.

[RT]	MC UNIT
RESET ERROR ?	
YES / NO	

3. Press the YES Key. The error will be reset for the task in which the error occurred.

[RT]	MC UNIT
ERROR RESET !	

## Resetting Servo Driver Errors

- 1, 2, 3... 1. Select 2.DRIVER from the MC Unit's Error Reset Procedure 1 Menu.

[RT]	DRIVER
	0. ALL AXES
	1. X    3. Z
	2. Y    4. U

2. Press a number from 0 to 2 to select the number of axes to be reset.

[RT]	DRIVER
	<ALL AXES>
	RESET ERROR ?
	YES / NO

The specified axis/axes are displayed here.

0: All axes 1: X axis 2: Y axis

3. Press the YES Key. The error will be reset for the selected axes.

[RT]	DRIVER
	ERROR RESET !

## Jogging

- 1, 2, 3... 1. Press the JOG Key. The Unit will go into Jog Mode and the following screen will be displayed.

JOG	X*	0.00
	Y*	0.00
	Z*	0.00
050	U*	0.00

The override values are displayed here. The default value is 50 %. Press the Up and Down Keys to set the values from 10% to 100% in increments of 10%.

2. To execute jogging along the X or Y axes, press any of the following four jog keys: +X, +Y, -X, -Y. The specified axis will move in the specified direction, and the present position will be refreshed on the screen.

## Executing Cyclic Execution

- 1, 2, 3... 1. Press the PROG EXEC Key.

RUN	1.CYCLE RUN
	2. SINGLE RUN

2. Select 1. CYCLE RUN from the menu.

RUN		-CYCLE RUN-	
CYC		PROGRAM	P000
TK1		BLOCK	N000
		RUN:	START

Task 1 is displayed.

3. Specify the program number. In this case, the program number is 001, so just input 1.

RUN		-CYCLE RUN-	
CYC		PROGRAM	P000
TK1		BLOCK	N000
		RUN:	START

If the program is changed from CX-Motion, the program number must be entered again even if it is the same. If it is not entered again, an error will be generated. In this case program execution will begin from the first block.

4. Press the START Key.

RUN		STATUS RUN	
CYC		PROGRAM	P001
TK1		BLOCK	N010

Each status has the following meaning .

RUN: Under memory operation  
 END: Memory operation ended.  
 ERR: Error occurring  
 PAUSE: Temporary suspension

When the PAUSE Key is pressed, program execution will be paused and the previous screen will be restored. Program execution is resumed by pressing the START Key. The program cannot be executed while an error is in effect. If the program number is entered again, program execution will begin from the first block.

5. Press the CLR Key after the program has been completed. The menu for selecting the operation mode will be restored. ( The CLR Key is not effective during program execution.)

If the status is either END or ERR, pressing the CLR Key will return to the restart screen.

### Executing Single-block Execution

- 1, 2, 3... 1. Select 2.SINGLE RUN from the menu.

RUN		-SINGLE RUN-	
SIN		PROGRAM	P000
TK1		BLOCK	N000
		RUN:	START

Task 1 is displayed.

2. Specify the program number. In this case, the program number is 001, so just input 1. If the program number is already set to 001 after cyclic execution, there is no need to enter anything here.
3. Press the START Key. The first block of program number 001 will be executed. In this case, block N002 will be executed because the first block is a comment.

RUN	STATUS	RUN
SIN	PROGRAM	P001
TK1	BLOCK	N002

To halt the operation in progress, press the PAUSE Key.

3. When the execution of the first block has been completed, PAUSE status will go into effect and program execution will be stopped. The number of the next block to be executed will be displayed.

RUN	STATUS	PAUSE
SIN	PROGRAM	P050
TK1	BLOCK	N002
	RUN:	START

Press the PROG EXEC Key to execute the next block. Press the CLR Key to return to the program number input screen. Then press to CLR Key again to return to the operating mode menu.

## 6-3 Considerations When Starting Up the MC Unit

### 6-3-1 Setting the System Parameters

The main considerations when setting the machine parameters are explained below, taking U-series Servo Drivers as an example.

An OMRON Servomotor connected to the MC Unit will operate if the default values (forward for positive voltage, and forward for encoder increase) are set.

If the system is set for a right-hand ball screw connection, the default settings will produce a decrease in the present value as the table (workpiece) moves away from the Servomotor. To have the present value increase as the table (work-piece) moves away from the Servomotor with a right-hand ball screw connection, use either of the following two methods.

- Set the MC Unit parameter (rotation direction) so that the motor will reverse for a positive voltage and reverse for an encoder increase.
- Set the Servomotor's mode to Reverse Mode. For U-series Servomotors, turn ON bit 0 of Cn-02.

**Encoder Resolution** The encoder resolution parameter sets the number of pulses (encoder frequency dividing ratio) that can be output from the Servo Driver per Servomotor revolution. For U-series Servomotors, set the encoder resolution according to the encoder frequency dividing ratio (Cn-0A), and not the number of encoder pulses parameter.

**Note** When a U-series Servo Driver with a capacity of 1 kW or more is used, a speed of up to 614.4 kpps is possible (when the encoder resolution is 8,192 and the maximum speed is 4,500 r/m). The maximum control speed of the MC Unit, however, is 500 kpps, so adjust the encoder resolution and the encoder frequency dividing ratio so that the speed will stay within this range.



**Pulse Rate**

With a ball screw connection, set the ball screw pitch (the distance advanced for one turn of the ball screw) for the numerator. Set the value derived by multiplying the encoder resolution by the ratio for the denominator. This number is a ratio of the number of millimeters advanced per pulse.

**Maximum Number of Motor Revolutions**

Set the rated number of revolutions for the motor (generally the catalog value).

- Note**
1. There is a difference between the acceleration/deceleration times set in the MC Unit and the Servo Driver. The MC Unit acceleration/deceleration time defines the time for accelerating and decelerating until the MC Unit's maximum feed rate or interpolation speed reference. The Servo Driver acceleration/deceleration time, in contrast, sets the delay time for accelerating to the speed reference that is given. When the Servo Driver acceleration/deceleration time is set, it lowers the gain for the system, so do not make this setting when using a Servo Driver in combination with an MC Unit.
  2. When an S-curve is set in the MC Unit and a software start is set in the Servo Driver, it puts the MC outputs through a filter and the gain is extremely decreased. Set both the S-curve and software start may produce faulty operation.

**Transferring and Saving Data**

When using CX-Motion to transfer data to the MC Unit, select Save/Transfer (Computer "MC"). Parameters, position data, programs, and so on, are transferred between a file (on a floppy or hard disk) and the MC Unit, so they must be saved or the MC Unit will operate using the old data. After transferring the data, be sure to save it to flash memory before turning OFF the power.

If the machine parameters or Unit parameters are changed and transferred, a system setup error will occur. It can be cleared by turning OFF the power and restarting the Unit. The error will appear to be cleared by just executing an error reset, but internally the old system parameters will remain in effect. The program cannot be correctly transferred while this condition persists, so whenever a system setup error occurs, be sure to turn OFF the power and use the Restart Bit in the CPU Unit to restart the Unit. Then transfer the program after the restart.

**Backing Up Data to Flash Memory**

With the CS1W-MC421 and CS1W-MC221, memory is backed up to flash memory following the transfer of system parameters and other data. The data in flash memory is always reloaded when the MC Unit is started. If data is not written to flash memory, it will be valid only until the power is turned OFF, so be sure to save it to flash memory after transferring it if it is required.

**6-3-2 Considerations When Starting Up or Making Adjustments**

An error may occur if the wiring check parameters are left at their default settings. These settings are made assuming a suitable load, but the load in the actual system may be different and a wiring error may be incorrectly detected. If a wiring error does occur, refer to CS1W-MC421/221 Motion Control Units Operation Manual Section 2-5 Wiring Check Troubleshooting and adjust the wiring check parameters.

**6-3-3 Changing the Teaching Box Mode for Trial Operation**

When the Teaching Box is connected to the MC Unit, it first goes into T. BOX LIMITED mode, in which only monitoring is possible. To execute the program or jog, the mode must be switched to either T. BOX RESERVED or T. BOX ENABLED. The operating mode can be changed only from the Teaching Box itself.

For the procedure for changing the Teaching Box mode to either T. BOX RESERVED or T. BOX ENABLED, refer to Changing the Mode to T. BOX RESERVED in 6-2-2 Checking Operation From the Teaching Box.

To change position data from the Teaching Box, press the EXT Key, select 4. Memory Protect, and use the Up Key or Down Key to clear the memory protection. Operations from the CPU Unit are not possible when the Teaching Box is in any mode other than T. BOX LIMITED. While operations are being executed from the Teaching Box in T. BOX RE-SERVED or T. BOX ENABLED Mode, other operations will not be carried out even if commands are given from the CPU Unit.

For details on Teaching Box operations, refer to the Teaching Box Operation Manual.

# Appendix A

## G-language Programming

This section describes using the G-language to program motion control in the MC Unit.

Programs and Tasks.....	2
1 Overview .....	2
G Language Overview.....	3
1 List of G-language Commands.....	3
2 G-language Formats .....	4
3 List of G Symbols.....	6
4 Declaring Program Numbers and Axes .....	8
5 Default Mode and Coordinate System.....	9
G-language Commands .....	9
1 G00: POSITIONING.....	10
2 G01: Linear Interpolation .....	11
3 G02 and G03: Circular Interpolation.....	14
4 G04: Dwell Timer .....	21
5 G10: Pass Mode.....	21
6 G11: Stop Mode .....	23
7 G13: In-position Check Off Mode.....	24
8 G17 to G22: Circular Plane Specification .....	26
9 G26: Reference Origin Return.....	27
10 G27: Workpiece Origin Return .....	28
11 G28: Origin Search.....	29
12 G29: Origin Undefined.....	30
13 G30: Speed Control Axis Feeding.....	30
14 G31: Interrupt Feeding .....	32
15 G32: Traverse.....	38
16 G50: Select Reference Coordinate System.....	41
17 G51: Select Workpiece Coordinate System .....	42
18 G53: Change Workpiece Origin Offset .....	43
19 G54: Change Reference Coordinate System PV .....	44
20 G60: Arithmetic Operations .....	45
21 G63: Substitution.....	45
22 G69: Change Parameter.....	46
23 G70: Unconditional Jump.....	47
24 G71: Conditional Jump.....	48
25 G72: Subroutine Jump.....	49
26 G73: Subroutine End.....	50
27 G74: Optional End.....	50
28 G75: Optional Skip.....	51
29 G76: Optional Program Pause .....	52
30 G79: Program End.....	54
31 G90: Absolute Specification.....	54
32 G91: Incremental Specification .....	55
M Code outputs .....	56
1 Introduction .....	56
2 M Code Data .....	57
3 M Code Examples .....	58
4 Effect of Mode Changes on M Code Resets.....	58
5 Clearing M000 to M499 with Forced Block End or G74 .....	58
6 Clearing M500 to M999 with Forced Block End or G74 .....	60
7 M Code Outputs in Pass Mode.....	61
8 Stopover function and Resetting M Codes .....	62
9 D Code Outputs .....	63
10 Stopover Function .....	65
11 Precautions on the Stopover Function .....	67

# Programs and Tasks

## 1 Overview

The CS1W-MC421 MC Unit can execute up to four tasks (tasks 1 to 4), and the CS1W-MC221 can execute one or two (tasks 1 to 2). (A task is a unit of execution for a program.)

By executing two or four tasks at the same time, the MC Unit can perform the same functions as two or four controllers.

The number of tasks and axes to be used are set in advance using CX-Motion for the unit parameters.

### Number of Tasks and Axes

The X and Y axes can be used with the CS1W-MC221, and the X, Y, Z, and U axes can be used with the CS1W-MC421. Each axis can be used for only one task, i.e., any axis assigned to one task cannot be used in another task.

#### Example 1: 4 Tasks and 4 Axes

Task1: X axis	Task: 2 Y axis	Task 3: Z axis	Task 4: U axis
------------------	-------------------	-------------------	-------------------

#### Example 2: 2 Tasks and 3 Axes

Task1: X,Y axis	Task: 2 Z axis
--------------------	-------------------

Task 1: Y,Z axis	Task 2: Y,U axis
---------------------	---------------------

#### Example 3: 2 Tasks and 4 Axes

Task1: X,Y,Z axis	Task: 2 U axis
----------------------	-------------------

Task 1: X,Y,Z axis	Task 2: X,Y,U axis
--------------------------	--------------------------

#### Example 4: 1 Task and 2 Axes

Task1: X,Y axis
--------------------

### Tasks and Blocks

The MC Unit is capable of storing a total of 2,000 blocks of program. The maximum number of blocks that can be executed in each task depends on the number of tasks as shown in the following table. These figures include subroutines.

Number of tasks	Maximum number of blocks (CS1W-MC421)	Maximum number of blocks (CS1W-MC221)
1	2,000 blocks	2,000 blocks
2	1,000 blocks/task	1,000 blocks/task
3	666 blocks/task	---
4	500 blocks/task	---

**Note** A maximum of 800 blocks can be used in one program, including subroutines.

**Tasks and Programs**

A maximum of 100 programs can be managed by the MC Unit. The number of programs that can be managed per task depends on the number of tasks as shown in the following table. These figures include subroutines.

Number of tasks	Maximum number of blocks (CS1W-MC421)	Maximum number of blocks (CS1W-MC221)
1	100 programs	100 programs
2	50 programs/task	50 programs/tasks
3	33 programs/task	---
4	25 programs/task	---

**Note** The same program number cannot be used for different tasks.

**G Language Overview****1 List of G-language Commands**

Code	Name	Function
G00	POSITIONING	Positions up to two or four axes simultaneously with PTP control at the maximum feed rate.
G01	LINEAR INTERPOLATION	Performs linear interpolation on up to two or four axes simultaneously at the specified interpolation feed rate.
G02	CIRCULAR INTERPOLATION (CLOCKWISE)	Performs 2-axis circular interpolation in the clockwise direction at the specified interpolation feed rate.
G03	CIRCULAR INTERPOLATION (COUNTERCLOCKWISE)	Performs 2-axis circular interpolation in the counterclockwise direction at the specified interpolation feed rate.
G04	DWELL TIMER	Waits for the specified period of time.
G10	PASS MODE	Performs operations one-by-one in sequence without deceleration to stop.
G11	STOP MODE	Performs the next operation after completing positioning.
G13	IN-POSITION CHECK OFF MODE	Starts the next operation without waiting for positioning to be completed.
G17	CIRCULAR PLANE SPECIFICATION (X-Y)	Sets the X-Y plane as the plane for circular interpolation.
G18 (See note)	CIRCULAR PLANE SPECIFICATION (X-Z)	Sets the X-Z plane as the plane for circular interpolation.
G19 (See note)	CIRCULAR PLANE SPECIFICATION (Y-Z)	Sets the Y-Z plane as the plane for circular interpolation.
G20 (See note)	CIRCULAR PLANE SPECIFICATION (X-U)	Sets the X-U plane as the plane for circular interpolation.
G21 (See note)	CIRCULAR PLANE SPECIFICATION (Y-U)	Sets the Y-U plane as the plane for circular interpolation.
G22 (See note)	CIRCULAR PLANE SPECIFICATION (Z-U)	Sets the Z-U plane as the plane for circular interpolation.
G26	REFERENCE ORIGIN RETURN	Moves to the reference origin.
G27	WORKPIECE ORIGIN RETURN	Moves to the workpiece origin.
G28	ORIGIN SEARCH	Performs an origin search in the specified axis.
G29	ORIGIN UNDEFINED	Makes the origin undefined.

Code	Name	Function
G30	SPEED CONTROL	Feeds up to two or four axes simultaneously at a controlled speed.
G31	INTERRUPT FEEDING	Performs interrupt feeding operations.
G32	TRAVERSE	Executes traverse operations.
G50	SELECT REFERENCE COORDINATE SYSTEM	Specifies the reference coordinate system.
G51	SELECT WORKPIECE COORDINATE SYSTEM	Specifies the workpiece coordinate system.
G53	CHANGE WORKPIECE ORIGIN OFFSET	Changes the origin of the workpiece coordinate system.
G54	CHANGE REFERENCE COORDINATE SYSTEM PV	Changes the present value in the reference coordinate system.
G60	ARITHMETIC OPERATIONS	Performs arithmetic operations on numerical values, position data, and registers.
G63	SUBSTITUTION	Substitutes numerical values, position data, or registers into other position data or registers.
G69	CHANGE PARAMETER	Changes the specified parameter.
G70	UNCONDITIONAL JUMP	Unconditionally jumps to the specified block.
G71	CONDITIONAL JUMP	Jumps to the specified block when the condition is met.
G72	SUBROUTINE JUMP	Calls the specified subroutine.
G73	SUBROUTINE END	Ends the subroutine.
G74	OPTIONAL END	Ends the block currently being executed when the specified optional input is ON.
G75	OPTIONAL SKIP	Skips the block after this command when the specified optional input is ON.
G76	OPTIONAL PROGRAM PAUSE	Pauses the program when the specified optional input is ON.
G79	PROGRAM END	Ends the main program.
G90	ABSOLUTE SPECIFICATION	Specifies the use of absolute coordinates in axis operations.
G91	INCREMENTAL SPECIFICATION	Specifies the use of relative coordinates in axis operations.

**Note** Not supported by the CS1W-MC221.

## 2 G-language Formats

The following notion is used for the operands.

- < >      Name of an operand to be specified
- [ ]      Optional operand
- ...      An operand that can be specified more than once
- A required space
- \_      Optional space

Name	Code	Operands
POSITIONING	G00	<Axis movement command ...> [ <sub>_</sub> M<M code>[/Stopover (Note 2.)]] [ <sub>_</sub> D<D code>[/Stopover (Note 2.)]] [ #<optional number>]
LINEAR INTERPOLATION	G01	<Axis movement command ... > [ <sub>_</sub> F<speed reference>[/Stopover (Note 2.)]] [ <sub>_</sub> M<M code>[/Stopover (Note 2.)]] [ <sub>_</sub> D<D code>[/Stopover (Note 2.)]] [ #<optional number>]

Name	Code	Operands
CIRCULAR INTERPOLATION (CLOCKWISE)T	G02	[<Axis movement command ... >]_<I to H center coordinate ...> [_F<speed reference>] [_M<M code>[/Stopover (Note 2.)]] [_D<D code>[/Stopover (Note 2.)]] [_L<number of turns>] [_#<optional number>]  [<Axis movement command ... >]_<R radius> [_F<speed reference>] [_M<M code>[/Stopover (Note 2.)]] [_D<D code>[/Stopover (Note 2.)]] [_L<number of turns>] [_#<optional number>]
CIRCULAR INTERPOLATION (COUNTERCLOCKWISE)	G03	[<Axis movement command ... >]_<I to H center coordinate ...> [_F<speed reference>] [_M<M code>[/Stopover (Note 2.)]] [_D<D code>[/Stopover (Note 2.)]] [_L<number of turns>] [_#<optional number>]  [<Axis movement command ... >]_<R radius> [_F<speed reference>] [_M<M code>[/Stopover (Note 2.)]] [_D<D code>[/Stopover (Note 2.)]] [_L<number of turns>] [_#<optional number>]
DWELL TIMER	G04	• <wait time>
PASS MODE	G10	---
STOP MODE	G11	---
IN-POSITION CHECK OFF MODE	G13	---
CIRCULAR PLANE SPECIFICATION (X-Y)	G17	---
CIRCULAR PLANE SPECIFICATION (X-Z) (See note.)	G18	---
CIRCULAR PLANE SPECIFICATION (Y-Z) (See note.)	G19	---
CIRCULAR PLANE SPECIFICATION (X-U) (See note.)	G20	---
CIRCULAR PLANE SPECIFICATION (Y-U) (See note.)	G21	---
CIRCULAR PLANE SPECIFICATION (Z-U) (See note.)	G22	---
REFERENCE ORIGIN RETURN	G26	<Axis name ... >    [_M<M code>[/Stopover (Note 2.)]] [_D<D code>[/Stopover (Note 2.)]]
WORKPIECE ORIGIN RETURN	G27	<Axis name ... >    [_M<M code>[/Stopover (Note 2.)]] [_D<D code>[/Stopover (Note 2.)]]
ORIGIN SEARCH	G28	<Axis name ... >    [_M<M code>[/Stopover (Note 2.)]] [_D<D code>[/Stopover (Note 2.)]]
ORIGIN UNDEFINED	G29	<Axis name ...>
SPEED CONTROL	G30	<Axis movement command>

Name	Code	Operands
INTERRUPT FEEDING	G31	<Axis movement command> _F <Speed Reference 1> <Axis name> <Coordinate 1>[/<Coordinate 2>] [_F <Speed Reference 2>] [_M<M code>[/Stopover (Note 2.)]] [_D<D code>[/Stopover (Note 2.)]] [_S]
SELECT REFERENCE COORDINATE SYSTEM	G50	---
SELECT WORKPIECE COORDINATE SYSTEM	G51	---
CHANGE WORKPIECE ORIGIN OFFSET	G53	<Offset value ... >
CHANGE REFERENCE COORDINATE SYSTEM PV	G54	<Present value ... >
ARITHMETIC OPERATIONS	G60	<First term = Second term Operator Third term>
SUBSTITUTION	G63	<First term = Second term>
CHANGE PARAMETER	G69	<#System parameter type>/<New setting ... >
UNCONDITIONAL JUMP	G70	<Jump destination block number> [/L<Number of loops>]
CONDITIONAL JUMP	G71	<Jump destination block number>/<condition equation>
SUBROUTINE JUMP	G72	<subroutine number>
SUBROUTINE END	G73	---
OPTIONAL END	G74	• <Optional number>
OPTIONAL SKIP	G75	• <Optional number>
OPTIONAL PROGRAM STOP	G76	• <Optional number>
PROGRAM END	G79	---
ABSOLUTE SPECIFICATION	G90	---
INCREMENTAL SPECIFICATION	G91	---

**Note** 1. Not supported by the CS1W-MC221.

2. The stopover function can be used with either an M code or a D code, but not with both.

### 3 List of G Symbols

The following table lists the symbols used in G-language programming.

Symbol	Meaning
A	Indicates a position data address. There are 2000 addresses ranging from A0000 to A1999.
D	D code
E	Indicates a register. There are 32 registers ranging from E00 to E31.
F	Indicates the speed when performing interpolation operations.
G	G command
H (See note.)	Arc center coordinate for the U-axis.
I	Arc center coordinate for the X-axis.
J	Arc center coordinate for the Y-axis.
K (See note.)	Arc center coordinate for the Z-axis.
L	Number of loops
M	M Code
N	Block number
O	Specifies the end processing method for G32 winding.
P	Program number
R	Circle radius




Symbol	Meaning
S	Specifies no error when there is no G31 interrupt input.
U (See note.)	U-axis
X	X-axis
Y	Y-axis
Z (See note.)	Z-axis
/	Separator
()	Indirect specification
#	Optional number, system parameter type
*	Comment

**Note** Not supported by the CS1W-MC221.

#### Specifying Position Data Addresses (A0000 to A1999)

It is possible to use the contents of a position data address for position data or an M code by specifying that address in an operand in an axis movement command or M code. For example, when the following program is executed, the contents of A1000 (123.45) will be used for the X-axis data and the contents of A1001 (50) will be used for the M code.



#### Specifying Registers (E00) to (E31)

Position data can be specified indirectly by specifying a register (E00) to (E31) in an axis movement command or M code. The relationship between the register and position data contents is shown below.

Register		Position data	
E00	1000	A1000:	123.35
E01	1001	A1001:	50


Registers and position data are not assigned together to each task; they can be used independently for different tasks.

The contents of registers are all cleared to zero only when power is turned ON or when a restart is executed. Initialize register contents at the beginning of the program by executing a command such as the SUBSTITUTION command (G63). Registers can contain values from 0 through 1999. An error will occur if a value greater than 1999 is input in a register. The possible range of values for position data is -39,999,999 through 39,999,999.

#### **Indirect Addressing of Position Data**

If the register name is in parentheses, i.e. (E00), the content of register will be treated as a position data address.


For example, when the following program is executed, the contents of A1000 (123.45) will be used for the X-axis data and the contents of A1001 (50) will be used for the M code.



#### Direct Addressing of Registers

If the register name is not in parentheses, i.e. E00, the command will operate directly on the content that register. In the following example, the content of E00 and E01 are added and the result is placed in E02.

Program block  
N010 G60 E02=E00+E01



## 4 Declaring Program Numbers and Axes

The program number and axes being used must be declared at the beginning of the program.

**Format** <program number\_axes...>

**Operands** The following table shows the program numbers and axes that can be declared for main programs and subroutines.

Programs	Program number	Axes
Main programs	P000 through P499	X,Y,Z,U
Subroutines	P500 through P999	

**Usage** There are two kinds of MC Unit programs, main programs and subroutines. Main programs are assigned program numbers P000 through P499 and subroutines are assigned program numbers P500 through P999.

Every program must begin with a declaration of the program number and the axes being used. Main programs end with a PROGRAM END command (G79) and subroutines end with a SUBROUTINE END command (G73). This declaration is made at the beginning of the program (block number N000); an error (determined by CX-Motion) will occur if the declaration is made in a later block.

The MC Unit can contain up to 100 programs.

#### Programming Examples

Use the following format for main programs.

```

N000  P100  XY
      :      :
      :      :
N100  G79                                PROGRAM END command

```

Use the following format for subroutines.

```

N000   P510   XY
        :       :
        :       :
N100   G73                                SUBROUTINE END command

```

When executing the main program from the first block, make initial settings such as the following.

- 1,2,3... 1. Restore the acceleration/deceleration time, interpolation acceleration/deceleration time, and workpiece origin offset value to the system parameter values.
2. Set the operating mode to Pass Mode.
3. Set the coordinate system to the reference coordinate system.
4. Set the command method to absolute.

## 5 Default Mode and Coordinate System

Various modes and coordinate systems can be used when a G-language program is executed. The following table shows the default settings for these.

The following defaults will always be set before executing the first block of a G-language main program.

Coordinate system or mode		General description
Coordinate system	Reference coordinate system (Default setting)	Axis positions on the reference coordinate system are used.
	Workpiece coordinate system	Axis positions on the workpiece coordinate system are used.
Command Mode	Absolute specification (Default setting)	Absolute coordinates are used in axis operations.
	Incremental specification	Relative coordinates are used in axis operations.
Operating Mode	Stop Mode	For interpolation operations, the next operation is performed <b>only after positioning is completed</b> .
	Pass Mode (Default setting)	For interpolation operations, operations are performed sequentially without decelerating to a stop between them.
	In-position Check OFF Mode	For interpolation operations, the next operation is performed without waiting for positioning to be completed.

## G-language Commands

This section provides detailed descriptions of the G-language commands. Command formats, operands, and application are described and programming examples are provided. The command format shows the operands that can be used and shows the correct syntax using the following notation.

- < >      Name of an operand to be specified
- [ ]        Optional operand
- ...        An operand that can be specified more than once
- A required space
- Optional space

The descriptions provided in this section are for the CS1W-MC421. The CS1W-MC221 supports only the X and Y axes.

## 1 G00: POSITIONING

Positions up to four axes simultaneously with PTP control at the high-speed feed rate.

**Format** G00\_<Axis movement command ...>[\_M<M code>[/Stopover (Note.)]]  
 [\_D<D code>[/Stopover (Note.)]]  
 [\_#<optional number>]

**Note** The stopover function can be used with either an M code or a D code, but not with both.

**Operands** The following table shows the possible settings for the operands.

Operand		Possible settings
Axis movement command	Axes	X,Y,Z,U
	Coordinate data	-39,999,999 to +39,999,999 (E00) to (E31) A0000 to A1999 + or -
M code		000 to 999 (E00) to (E31) A0000 to A1999
D code		000(0) to 255 (E00) to (E31) A0000 to A1999
Stopover	Axes	X,Y,Z,U
	Position data	0 to 39999999 (E00) to (E31) A0000 to A1999
Optional number		00 to 19

**Note** Refer to 7-4 M Code Outputs for details on M codes, and to 7-4-9 D Code Out-puts for details on D codes. Refer to 7-4-10 Stopover Function for details on the stopover function.

**Description** Positions up to four axes simultaneously with PTP control according to the maximum feed rate, acceleration/deceleration time, and acceleration/deceleration curve settings in the system parameters. The override is valid.

When “+” or “-” is specified for the coordinate data, positioning will be performed to the software limit in the specified direction.

Control is passed on to the next block after all of the specified axes reach their in-position ranges.

When an optional number is specified, the axis movement command will be carried out when that optional input goes ON. The operation will not be performed until the optional input goes ON. The source of the optional input depends on the optional number specified, as shown below.

0 through 15: Inputs from the PC Interface Area

16 through 19: Inputs from general inputs 1 to 4


## Programming Examples

Use the following format for subroutines.

```

:      :
N010  G90      Absolute specification
N011  G00      X100  Y50  M001
:      :

```




The following program is for incremental operation.

```

:      :
N010  G91      Incremental specification
N011  G00      X100  Y50  M001
:      :

```



**Note** The X and Y axes are operated at the same speed in the above examples.

## 2 G01: Linear Interpolation

Performs linear interpolation on up to 4 axes simultaneously at the specified interpolation feed rate.

**Format**     G01\_<Axis movement command ...>    [\_F<speed reference>]  
    [\_M<M code>[/Stopover (Note.)]]  
    [\_D<D code>[/Stopover (Note.)]]  
    [\_#<optional number>]

**Note** The stopover function can be used with either an M code or a D code, but not with both.

**Operands** The following table shows the possible settings for the operands.

Operand		Possible settings
Axis movement command	Axes	X,Y,Z,U
	Coordinate data	-39,999,999 to +39,999,999 (E00) to (E31) A0000 to A1999
Speed reference		0.0001 to 39,999,999 (E00) to (E31) A0000 to A1999
M code		000 to 999 (E00) to (E31) A0000 to A1999
D code		000(0) to 255 (E00) to (E31) A0000 to A1999
Stopover	Axes	X,Y,Z,U
	Coordinate data	0 to 39999999 (E00) to (E31) A0000 to A1999
Optional number		00 to 19

**Note** Refer to 7-4 M Code Outputs for details on M codes, and to 7-4-9 D Code Outputs for details on D codes. Refer to 7-4-10 Stopover Function for details on the stopover function.

**Description** Performs linear interpolation on up to four axes simultaneously at the specified interpolation feed rate.

The interpolation feed rate is calculated with the equations shown below. Four axes are shown, but the same calculations apply when three or fewer axes are being used.

$$F_x = F \times dL_x / L$$

$$F_y = F \times dL_y / L$$

$$F_z = F \times dL_z / L$$

$$F_u = F \times dL_u / L$$

$F_x$  to  $F_u$ : Interpolation feed rates for axes X to U

$dL_x$  to  $dL_u$ : Movement distance for axes X to U

L: Total distance between start and end of linear interpolation

$$\left( L = \sqrt{dL_x^2 + dL_y^2 + dL_z^2 + dL_u^2} \right)$$

If the interpolation feed rate is not specified, the interpolation will be performed at the last feed rate used in a G01, G02, or G03 command. An error will occur if the interpolation feed rate is not specified and the G01, G02, or G03 command has not been executed before.

**⚠ Caution** When linear interpolation is performed in Pass Mode and an M code from 0 through 499 or an optional number is specified, the interpolation will be performed in Stop Mode, not Pass Mode. For details on the Pass Mode, refer to 7-3-5 Pass Mode.

If the same interpolation acceleration/deceleration times and override values are not set for all of the axes used in a task, the settings for the axis with the highest priority will be used. Axis X has the highest priority, followed by Y, Z, and U.

The override value can be specified from the Teaching Box or PC Interface Area.

Declared axis configuration for task	Interpolation deceleration time and override value
XYZU	X-axis time and value
YZU	Y-axis time and value
ZU	Z-axis time and value
U	U-axis time and value
XU	X-axis time and value

Refer to 6-8 Operating Modes for details on interpolation acceleration and deceleration times in Pass Mode.

The override value is read only for the first G01 command in Pass Mode or In-Position Check OFF Mode.

When the product of the specified interpolation feed rate and override exceeds the maximum interpolation feed rate specified in system parameters for the axis being moved by linear interpolation, linear interpolation will be performed at the lowest maximum interpolation feed rate among the axes being moved.

Consider the following situation.

G01 X1000 Y1000 Z-1000 F3000

X-axis override value: 100.0 [%]

X-axis maximum interpolation feed rate: 4000 [mm/s]

Y-axis maximum interpolation feed rate: 3000 [mm/s]

Z-axis maximum interpolation feed rate: 2000 [mm/s]

Interpolation feed rate after override calculation =

$$3000 \times 100.0/100.0 = 3000 \text{ [mm/s]}$$

This exceeds the maximum interpolation feed rate for the Z axis. The feed rate in this case would be 2000 [mm/s].

When an optional number is specified, the axis movement command will be carried out when that optional input goes ON. The operation will not be performed until the optional input goes ON. The source of the optional input depends on the optional number specified, as shown below.

0 through 15: Inputs from the PC Interface Area

16 through 19: Inputs from general inputs 1 to 4


### Programming Examples

The following example shows absolute positioning.

```

:      :
N010  G90      Absolute specification
N011  G01  X100  Y50  F300
:      :

```




The following program is for incremental operation.

```

:      :
N010  G91      Incremental specification
N011  G01      X100  Y50  F300
:      :

```



### 3 G02 and G03: Circular Interpolation

Performs two-axis circular interpolation in the clockwise (G02) or counterclockwise (G03) direction at the specified interpolation feed rate. With the CS1W-MC421, it is also possible to perform 2-axis circular interpolation + 1-axis linear interpolation (helical circular interpolation) and 2-axis circular interpolation + 2-axis linear interpolation. In addition, the multiturn function can be added to either circular interpolation or helical circular interpolation for winding machine operations.

**Format** G02 (G03)\_[<Axis movement command ...>]\_<center coordinate ...>  
 [\_F<speed reference>]  
 [\_M<M code>[/Stopover (Note.)]]  
 [\_D<D code>[/Stopover (Note.)]]  
 [\_L<number of turns>]  
 [\_#<optional number>]

G02 (G03)\_<Axis movement command ...>\_<R radius>  
 [\_F<speed reference>]  
 [\_M<M code>[/Stopover (Note.)]]  
 [\_D<D code>[/Stopover (Note.)]]  
 [\_L<number of turns>]  
 [\_#<optional number>]

**Note** The X and Y axes are operated at the same speed in the above examples.

**Examples** Example 1) G02 X100 Y90 I0 J40 F300 (Center specification)  
 Example 2) G02 X100 Y90 R120 F300 (Radius specification)  
 Example 3) G02 X200 Y200 Z200 I0 J0 F200 L10 (Helical circular)



**Operands** The following table shows the possible settings for the operands.

Operand		Possible settings
Axis movement command	Axes	X,Y,Z,U
	Coordinate data	-39,999,999 to +39,999,999 (E00) to (E31) A0000 to A1999
Center coordinate	Axes	I, J, K, H
	Radius	R
	Coordinate and radius data	-39,999,999 to +39,999,999 (E00) to (E31) A0000 to A1999
Speed reference		0.0001 to 39,999,999 (E00) to (E31) A0000 to A1999
M code		000(0) to 999 (E00) to (E31) A0000 to A1999
D code		000(0) to 255 (E00) to (E31) A0000 to A1999
Stopover	Axes	X,Y,Z,U
	Coordinate data	0 to 39,999,999 (E00) to (E31) A0000 to A1999
Number of truns		0 to 39,999,999 A0000 to A1999 (E00) to (E31)
Optional number		00 to 19

I, J, K, and H are the center coordinates (relative position) for the X, Y, Z, and U axes respectively.

**Note** Refer to 7-4 M Code Outputs for details on M codes, and to 7-4-9 D Code Outputs for details on D codes. Refer to 7-4-10 Stopover Function for details on the stopover function.

**Operation** This command is used to position two axes by circular interpolation, two axes by circular interpolation and one axis by linear interpolation, or two axes by circular interpolation and two axes by linear interpolation at the specified feed rate. Positioning two axes by circular interpolation and one axis by linear interpolation is referred to as helical circular interpolation. Axes that are not being moved by circular interpolation are called supplemental axes.


Axes that are being moved by circular interpolation are determined by CIRCULAR PLANE SPECIFICATION commands (G17 to G22). With axes specified as the circular plane, the present position of an axis with no axis run command will be treated as the target position. Other axes will not be moved unless axis movements are specified for them.

If the interpolation feed rate is not specified, circulation interpolation will be per-formed at the last interpolation feed rate specified for G01, G02 and G03. An error will occur if an interpolation feed rate is not specified when G02 or G03 is first executed.

An error will occur if circular plane is not specified prior to executing circular interpolation.

The axis with the highest priority must be the horizontal axis. The following diagrams show the order of priority.

High ← X Y Z U → Low



If an axis that is not defined as the circular plane is specified, that axis will move by linear interpolation, and the speed of the supplemental axis will be as follows:

$$F_i = F \times dLi/Lc$$

$F_i$ : Supplemental axis interpolation feed rate  
 $F$ : Speed reference  
 $dLi$ : Supplemental axis travel distance  
 $Lc$ : Circumferential length

An error will occur if the interpolation feed rate of the supplemental axis exceeds the maximum interpolation feed rate set for the axis.

When specifying the circle's center coordinate, specify the relative distance from the present position (the circle's starting point) and specify one or two axes. An error will occur if nothing is specified or if three or more axes are specified.

When specifying the radius, circular interpolation smaller than a semicircle will be executed for a positive value and circular interpolation greater than a semi-circle will be executed for a negative value. Either a negative or positive value can be specified for a semicircle.

When specifying a complete circle (360°), the system will operate when either of the following conditions is met in the center coordinate specifications.


- When the axis movement command and present position are the same
- When the axis movement command is omitted

A complete circle cannot be drawn using the radius specification.

**⚠ Caution** When circular interpolation is performed in Pass Mode and an M code from 0 through 499 or an optional number is specified, the interpolation will be per-formed in Stop Mode, not Pass Mode. For details on the Pass Mode, refer to 7-3-5 Pass Mode.

The override value can be set from either the Teaching Box or the PC Interface Area.

The order of priority is as follows:



Declared axis configuration for task	Interpolation deceleration time and override value
XYZU	X-axis time and value
YZU	Y-axis time and value
ZU	Z-axis time and value
U	U-axis time and value
XU	X-axis time and value

In Pass Mode or In-Position Check OFF Mode, the override value is read only for the first G02/G03 command.

When the product of the specified interpolation feed rate and override value exceeds the maximum interpolation feed rate for the axis being moved by circular interpolation (set in the system parameters), circular interpolation will be performed at the lowest maximum feed rate among the axes being moved. For example, consider the following situation.

```
G02  X100  Y90  I0  J40  F3000
X-axis override value:      100.0 [%]
X-axis max. interpolation feed rate:  4000 [mm/s]
Y-axis max. interpolation feed rate:  2000 [mm/s]
Interpolation feed rate after override calculation = 3000 × 100.0/100.0
                                                    = 3000 [mm/s]
```

The interpolation feed rate of 3000 [mm/s] exceeds the maximum interpolation feed rate for the Y-axis (2000 [mm/s]), so the interpolation feed rate is set to 2000 [mm/s].

**Note** Internal radius calculations are accurate to seven digits. When the radius exceeds 9,999,999 pulses, circular interpolation will be performed within the specified circle. Keep the radius under 9,999,999 pulses when specifying the radius in 1-pulse units.

If the plane where circular interpolation will be performed is changed while consecutive circular interpolations are being executed, pause the positioning before going on to the next circular interpolation when Pass Mode is specified.


When an optional number is specified, the axis movement command will be carried out when that optional input goes ON. The operation will not be performed until the optional input goes ON. The source of the optional input depends on the optional number specified, as shown below.

0 through 15: Inputs from the PC Interface Area

16 through 19: Inputs from general inputs 1 to 4

### Multiturn Function

The multiturn function was added to conventional circular and helical circular interpolations for the purpose of wiring machine operations.



**Note** If the multiturn function is specified for a complete circle, the axis will move the number of turns plus one revolution.


**Programming Examples**

The following programming example shows circular interpolation with center coordinate specification.

```

:      :
N010  G90      Absolute specification
N011  G17      Makes X-Y the circular plane
N010  G02      X100  Y90  I0   J40   F300
:      :

```




The following program shows circular interpolation with radius specification ( $R<0$ ). An arc greater than a semicircle will be drawn when  $R<0$ .

```

:      :
N010  G90      Absolute specification
N011  G17      Makes X-Y the circular plane
N012  G02      X140  Y50  R-40  F300
:      :

```




The following program shows circular interpolation with radius specification ( $R>0$ ). An arc smaller than a semicircle will be drawn when  $R>0$ .

```

:      :
N010  G91      Incremental specification
N011  G17      Makes X-Y the circular plane
N012  G02      X40   Y40   R40   F300
:      :

```




The following program shows circular interpolation of a complete circle.

```

:      :
N010  G90      Absolute specification
N011  G17      Makes X-Y the circular plane
N012  G02      X100  Y10   I0   J40   F500
:      :

```




## Helical Movement

```

:      :
N010  G90      Absolute specification
N011  G17      X-Y the circular plane specification
N012  G02      X50  Y100  Z20  I-30  J0  F500
:      :

```




## Helical Bundling Operation

```

N010 G90 ..... Absolute specification
N011 G17 ..... X-Y circular plane specification
N012 G02 X100 Y0 Z20 I0 J0 F200 L4

```

↑ Specifies the number of revolutions (4 revolutions in this case)  
 ↑ Feed pitch for the first revolution in the Z-axis direction (always relative movement)  
 ↑ Stop position after 10 revolutions



## 4 G04: Dwell Timer

Waits for a specified length of time.

**Format** G04• <wait time>

**Operands** The following table shows the possible settings for the wait time operand.

Operand	Possible settings
Wait time	0.001 to 39,999.994 (E00) to (E31) A0000 to A1999

**Description** This command waits for a specified wait time.

The wait time can be specified by a register or a position data address. If the memory contents have four or more digits below the decimal point, the fourth digit is rounded off. An error will occur if the resulting number is outside of the acceptable range (0.001 to 39,999.994). Values from 0.001 to 39,999.999 [s] can be input for the wait time, but settings of 39,999.995 to 39,999.999 will cause an error. The accuracy of the timer is approximately 0.02 s. For example, setting “1” [s] will result in an actual wait of 1.00 to 1.02 seconds.

**⚠ Caution** If this command is executed just after a G01, G02, G03, or G32 command, the interpolation will be performed in Stop Mode, not Pass Mode, even if Pass Mode has been selected.


### Programming Example

In this example, the dwell timer waits 10 seconds between linear interpolation operations.

```

:      :
N009  G10
N010  G01   X100   Y100
N011  G04    10
N012  G01   X200   Y200
:      :

```



**Note** Program blocks N010 and N012 are not pass operations.

## 5 G10: Pass Mode

Switches the operating mode to Pass Mode.

**Format** G10

**Operands** None

**Description** This command switches the operating mode to Pass Mode. When this command is executed, any subsequent interpolation (linear or circular) operation will move on to the next positioning operation without decelerating to a stop. The Pass Mode remains in effect until the STOP MODE command (G11) or IN-POSITION CHECK OFF MODE command (G13) is executed.

The pass operation may not be executed if a G01, G02, G03, or G32 command is executed with an extremely short travel time.

In Pass Mode, the next G-code command is executed (pre-read execution) without waiting for the completion of a G01, G02, G03, or G32 command that is currently being executed, so the execution block number output to the interface might be different from the actual block number being executed. The subsequent commands will be executed until the next block with a G01, G02, G03, or G32 command.


In the following programming example, blocks N003 to N006 are executed (pre-read execution) while the axis is moving according to the command in block N002. Although the axis is moving according to program block N002, the execution block number will be refreshed with block numbers N003 to N006. Program execution will then wait on standby at block N006.

When command processing for N002 is completed, pre-read execution will start again.

```

N000  P000  XY
N001  G10
N002  G01   X100  F1000
N003  G63   A0000  = 1
N004  G63   A0001  = 2
N005  G63   A0002  = 3
N006  G01   X200
      :      :

```

 **Caution** The following commands will pause pre-reading and switch any axis that is moving to Stop Mode. (The axis will decelerate to a stop when positioning is completed, and an in-position check will be performed).

- G00 (PTP)
- G01, G02 and G03 commands with #optional numbers
- CIRCULAR INTERPOLATION commands (G02, G03) with different circular plane specifications than those for CIRCULAR PLANE SPECIFICATION commands (G17 to G22)
- Pass Mode operation between CIRCULAR INTERPOLATION commands (G02, G03) and TRAVERSE (G32) (which is not possible)
- G04 (DWELL TIMER)
- G26 (WORKPIECE ORIGIN RETURN)
- G27 (REFERENCE ORIGIN RETURN)
- G28 (ORIGIN SEARCH)
- G29 (ORIGIN UNDEFINED)
- G30 (SPEED CONTROL)
- G31 (INTERRUPT FEEDING)
- G54 (CHANGE REFERENCE COORDINATE SYSTEM PV)
- G79 (PROGRAM END)
- M000 to M499 independent commands
- D000 to D256

The following commands must be executed in Stop Mode. Pre-reading will be paused.

- G01, G02, G03, G32 commands with an M code from M000 to M499.




**Programming Example**

In this example, linear interpolation is executed with a pass operation.

```

:      :
N010  G00   X30   Y30
N011  G10
N012  G01   X70
N013  G01   Y90
N014  G01   X120
N015  G00   Y30
N016  G00   X150
:      :

```



## 6 G11: Stop Mode

Switches the operating mode to Stop Mode.

**Format** G11

**Operands** None

**Description** This command switches the operating mode to Stop Mode. If this command is executed, subsequent interpolation (linear or circular) commands will be decelerated to a stop at the end point, an in-position check will be performed, and then the next positioning operation will be performed after completion of the positioning is verified.

The Stop Mode will remain in effect until one of the following commands is executed:

- 1,2,3...**
1. PASS MODE (G10)
  2. IN-POSITION CHECK OFF MODE (G13)
  3. REFERENCE ORIGIN RETURN (G26)
  4. WORKPIECE ORIGIN RETURN (G27)
  5. ORIGIN SEARCH (G28)

**Note** A reset will be performed and the operating mode will be switched to Pass Mode when a REFERENCE ORIGIN RETURN (G26), WORKPIECE ORIGIN RETURN (G27), or ORIGIN SEARCH (G28) command is executed.


**Programming Example**

The following programming example demonstrates positioning in Stop Mode. The mode is changed to Stop Mode after linear interpolation in Pass Mode. The Unit moves to the next operation after completion of the previous operation is confirmed.

```

:      :
N009  G10
N010  G01   X200   F200
N011  G11
N012  G01   X300   F100
N013  G01   X400   F100
:      :

```



In Stop Mode, the Unit moves to the next operation after completion of the previous operation is verified.

**7****G13: In-position Check Off Mode**

Starts the next positioning operation without waiting for the current one to be completed.

**Format** G13

**Operands** None

**Description** In Stop Mode, the next positioning operation will start only after positioning is completed, but with the In-position Check OFF Mode, the next positioning operation will start without waiting for positioning to be completed.

The following G codes can be used in In-position Check OFF Mode.

- G01 (LINEAR INTERPOLATION)
- G02/G03 (CIRCULAR INTERPOLATION)
- G32 (TRAVERSE)

The In-position Check OFF Mode remains in effect until one of the following is executed.

- PASS MODE (G10)
- STOP MODE (G11)
- REFERENCE ORIGIN RETURN (G26)
- WORKPIECE ORIGIN RETURN (G27)
- ORIGIN SEARCH (G28)

The following commands will pause pre-reading and shift any axis that is moving to Stop Mode. (The axis will decelerate to a stop when positioning is completed, and an in-position check will be performed).

- G00 (PTP)
- G01, G02 and G03 commands with #optional numbers
- CIRCULAR INTERPOLATION commands (G02, G03) with different circular plane specifications than those for CIRCULAR PLANE SPECIFICATION commands (G17 to G22)
- TRAVERSE (G32) after CIRCULAR INTERPOLATION commands (G02, G03)

- G04 (DWELL TIMER)
- G26 (WORKPIECE ORIGIN RETURN)
- G27 (REFERENCE ORIGIN RETURN)
- G28 (ORIGIN SEARCH)
- G29 (ORIGIN UNDEFINED)
- G30 (SPEED CONTROL)
- G31 (INTERRUPT FEEDING)
- G54 (CHANGE REFERENCE COORDINATE SYSTEM PV)
- G79 (PROGRAM END)
- M000 to M499 as independent commands
- D000 to D256

The following commands must be executed in Stop Mode. Pre-reading will be paused.

- G01, G02, G03, G32 commands with an M code from M000 to M499 (including stopover)


### Programming Examples

In this programming example, positioning is executed in Stop Mode.

```

:      :
N010  G11      Switch to Stop Mode
N020  G01  X200  F200
N030  G01  X400  F200
:      :

```




In this programming example, the In-position Check OFF Mode is enabled.

```

:      :
N010  G13      Switch to In-position check OFF Mode
N020  G01  X200  F200
N030  G01  X400  F200
:      :

```



## 8 G17 to G22: Circular Plane Specification

Specifies the plane in which circular interpolation is to be performed.

**Format** G17  
G18 (See note.)  
G19 (See note.)  
G20 (See note.)  
G21 (See note.)  
G22 (See note.)

**Note** G18 to G22 are not available with the CS1W-MC221.

**Operands** None

**Description** This command specifies the plane in which circular interpolation is performed, as shown in the following table.

Code	Plane
G17	Specifies the X-Y plane.
G18	Specifies the X-Z plane.
G19	Specifies the Y-Z plane.
G20	Specifies the X-U plane.
G21	Specifies the Y-U plane.
G22	Specifies the Z-U plane.

The setting remains in effect until a new plane is specified.

The initial setting is for the X-Y plane.


### Programming Examples 1

The following programming example performs circular interpolation in the X-Y plane.

```

:      :
N010  G90
N011  G17
N012  G00    X0    Y50    Z0
N013  G03    X0    Y150  R50    F300

```



The following example performs circular interpolation in the Y-Z plane.

Moves to the reference origin

**Note** The stopover function can be used with either an M code or a D code, but not with both.

Operand		Possible settings
Axis names		X,Y,Z,U
M code		000 to 999 (E00) to (E31) A0000 to A1999
D code		000(0) to 255 (E00) to (E31) A0000 to A1999
Stopover	Axes	X,Y,Z,U
	Coordinate data	0 to 39999999 (E00) to (E31) A0000 to A1999

***1,2,3...***

1. The coordinate system will be set to the reference coordinate system.
2. The command mode will be set to absolute specification.
3. The operating mode will be set to Pass Mode.

The settings will not be switched to the ones above if the G26 command is terminated while in progress by the OPTIONAL END command (G74), FORCED BLOCK END, or other command. The command is also considered to be in progress while waiting for the M code reset.

The following example moves the X and Y axes to the reference origin.

The M code (M500)  
is output here.

Reference origin

Reference coordinate system

X

Y

Moves to the workpiece origin.

**Note** The stopover function can be used with either an M code or D code, but not with both.

Operand		Possible settings
Axis names		X,Y,Z,U
M code		000 to 999 (E00) to (E31) A0000 to A1999
D code		000(0) to 255 (E00) to (E31) A0000 to A1999
Stopover	Axes	X,Y,Z,U
	Coordinate data	0 to 39999999 (E00) to (E31) A0000 to A1999

**Description** This command moves the specified axes to the workpiece origin by PTP control. The coordinate system and mode settings will be as follows after the return to the workpiece origin:

- A-28

The following example moves the X and Y axes to the workpiece origin.

The M code (M500) is output here.

Workpiece coordinate system

Workpiece origin (offset from the reference origin, set using a parameter or by G53.)

Reference coordinate system

Performs an origin search in the specified axes.

**Note** The stopover function can be used with either an M code or D code, but not with both.

Operand		Possible settings
Axis names		X,Y,Z,U
M code		000 to 999 (E00) to (E31) A0000 to A1999
D code		000(0) to 255 (E00) to (E31) A0000 to A1999
Stopover	Axes	X,Y,Z,U
	Coordinate data	0 to 39999999 (E00) to (E31) A0000 to A1999

**Description** This command performs an origin search in the specified axes.

As an upgrade to previous models, it is now possible to perform an origin search using an absolute encoder just as with an incremental encoder.

- The mode will be as follows after the origin search has been completed.
- 1,2,3... 1. The coordinate system will be set to the reference coordinate system.
  2. The command mode will be set to absolute specification.
  3. The operating mode will be set to Pass Mode.
- The settings will not be switched to the ones above if the G28 command is terminated while in progress by the OPTIONAL END command (G74), FORCED BLOCK END, or other command. The command is also considered to be in progress while waiting for the M code reset.

**Programming Example**

The following example performs an origin search for the X, Y, and Z axes.

```

      :      :
N010  G28   XYZ
      :      :

```

## 12 G29: Origin Undefined

Forcibly sets the origin to an undefined state for the specified axes.

**Format** G29\_<Axis name ...>

**Operands** X,Y,Z, and U axes

**Description** This command forcibly sets the origin to an undefined state for the specified axes.

- The No Origin Flag will turn ON in the PC Interface Area.
- An asterisk (\*) will be displayed for axes with undefined origins on the present value display on the Teaching Box.

The present position will not change with this command, but the present position of the machine will be updated continually. The following will occur if the origin is not defined.

- The software limits will be disabled.
- Zones will be disabled depending on the settings of the system parameters (i.e., they will be disabled when the zones depend on the origin being established).
- Positioning will not be allowed using G00, G01, G02, G03, G26 and G27 commands (when the axis mode is Normal Feed Mode).

Perform one of the following operations to re-establish the origin.

- Execute ORIGIN SEARCH (G28).
- Execute CHANGE REFERENCE COORDINATE SYSTEM PV (G54).

**Programming Example**

The following example sets the X and Y axes to an undefined state.

```

N000  P000  XY
N001  G00   X0    Y0    (Moves the axis to the system origin.)
N002  G29   XY      (Makes the origin undefined.)
N003  G30   X+    Y+    (Sets unlimited feeding.)
      :      :

```

## 13 G30: Speed Control Axis Feeding

Performs the feed rate control of a maximum of four axes.

**Format** G30\_<axis movement command ...>

**Operands** The following shows the possible settings for the operands.

Axis movement command	
Axis	Coordinate data
X,Y,Z,U	+,-



**Description** The axis is fed in the positive direction if the coordinate data is set to positive.  
 The axis is fed in the negative direction if the coordinate data is set to negative.  
 The feed rate of each axis can be set individually.  
 $\text{X-axis feed rate} = \text{X-axis maximum feed rate} \times \text{X-axis override value} / 100$   
 $\text{Y-axis feed rate} = \text{Y-axis maximum feed rate} \times \text{Y-axis override value} / 100$   
 $\text{Z-axis feed rate} = \text{Z-axis maximum feed rate} \times \text{Z-axis override value} / 100$   
 $\text{U-axis feed rate} = \text{U-axis maximum feed rate} \times \text{U-axis override value} / 100$

The feed rate is set with the system parameters.

Override value: Set with in PC Interface Area or Teaching Box within a range of 0.1% to 100.0%.

Example: The following X-axis feed rate will be obtained if the X-axis maximum feed rate is 10,000 mm/s and the X-axis override value is 50.0%.

$\text{X-axis feed rate} = 10,000 \times 50.0 / 100 = 5,000 \text{ mm/s.}$

The acceleration time or deceleration time varies with the override value, as follows:

$\text{X-axis acceleration time} = \text{X-axis acceleration time}^* \times \text{override value} / 100.$

$\text{X-axis deceleration time} = \text{X-axis deceleration time}^* \times \text{override value} / 100$

$\text{Y-axis acceleration time} = \text{Y-axis acceleration time}^* \times \text{override value} / 100.$

$\text{Y-axis deceleration time} = \text{Y-axis deceleration time}^* \times \text{override value} / 100$

$\text{Z-axis acceleration time} = \text{Z-axis acceleration time}^* \times \text{override value} / 100$

$\text{Z-axis deceleration time} = \text{Z-axis deceleration time}^* \times \text{override value} / 100$

$\text{U-axis acceleration time} = \text{U-axis acceleration time}^* \times \text{override value} / 100$

$\text{U-axis deceleration time} = \text{U-axis deceleration time}^* \times \text{override value} / 100$

\*These values are set with the system parameters.

The feed rate can be changed in real time by changing the override value. The operation will vary as follows depending on whether or not the origin is established:

Origin established: The software limit will be enabled and the present position will be always refreshed.

Origin not established: The software limit will be disabled. The present position will be set to 0 at the start of operation if the axis mode is Normal Feed Mode, and always refreshed if the axis mode is Unlimited Feed Mode.


### Programming Example

The following example shows executing speed control, adjusting the speed with an override, and stopping with an optional number.

```

:      :
N010  G74  16
      G30  X+
:      :

```



**Note** The preceding G01, G02, G03, and G32 commands will operate in Stop Mode instead of Pass Mode when this command is executed.

## 14 G31: Interrupt Feeding

Feeds a specified axis for a specified travel distance when a general input turns ON.

**Format** G31\_<Axis name> <Coordinate 1>[/<Coordinate 2>  
[\_F <Speed Reference 1>] [\_F <Speed Reference 2>]  
[\_M<M code>[/Stopover (Note.)]]  
[\_D<D code>[/Stopover (Note.)]]  
[\_S]

**Note** The stopover function can be used with either an M code or a D code, but not with both.

Example 1: G31 X100 F200

Example 2: G31 X100 F200 F100

Example 3: G31 X100/200 F200

**Operands** The following table shows the possible settings for the operands.

Operand		Possible settings
Axis movement command	Axis names	X,Y,Z,U
	Coordinate Data 1 Coordinate Data 2	–39,999,999 to +39,999,999 (E00) to (E31) A0000 to A1999
Speed Reference 1 Speed Reference 2		0.0001 to +39,999,999 (E00) to (E31) A0000 to A1999
M code		000(0) to 999 (E00) to (E31) A0000 to A1999
D code		000(0) to 255 (E00) to (E31) A0000 to A1999
Stopover	Axes	X,Y,Z,U
	Coordinate data	0 to 39999999 (E00) to (E31) A0000 to A1999

Coordinate Data 1 is the travel distance after the interrupt, and Coordinate Data 2 is the maximum travel distance before the input is received.  
Set Speed Reference 1 to a higher value than Speed Reference 2.


**Note** Refer to 7-4 M Code Outputs for details on M codes, and to 7-4-9 D Code Outputs for details on D codes. Refer to 7-4-10 Stopover Function for details on the stopover function.

**Description** The specified axis will be moved for the specified distance for positioning after the general input (1 to 4) is turned ON. It is also possible to specify a travel distance for when no general input is received to stop with an error (program execution interrupted) after positioning. An S option can also be used to execute the next block without an error occurring.

Refer to the following examples.

**Example 1: Speed Reference 2 Not Specified**


G31 X100 F200 (mm)



The X axis moves at 200 mm/s (speed control) until General Input 1 is turned ON. The X axis then moves for another 100 mm (position control) from the position where General Input 1 was turned ON.

**Example 2: Speed Reference 2 Specified**

G31 X100 F200 F100 (mm)



The X axis moves at 200 mm/s (speed control) until General Input 1 is turned ON. The speed of the X axis will decelerate to the speed specified by Speed Reference 2 (i.e., 100 mm/s) and the X axis will move for another 100 mm (position control) from the position where General Input 1 was turned ON.

There is no difference in acceleration/deceleration time between the G31 and G00 commands. It is generally set automatically according to the ratio of the speed reference to the maximum feed rate. There are exceptions, however. Refer to the following Operation Examples. Refer to the following table for the correspondence between interrupt feeding axes and general inputs.

Axis	General input
X	Turning ON of General Input 1
Y	Turning ON of General Input 2
Z	Turning ON of General Input 3
U	Turning ON of General Input 4

The operation will vary as follows depending on whether or not the origin is established.

- Origin established: The software limit will be enabled and the present position will be always refreshed.
- Origin not established: The software limit will be disabled. The present position will be set to 0 at the start of operation if the axis mode is Normal Feed Mode, and always refreshed if the axis mode is Unlimited Feed Mode.

**Note** 1. The preceding G01, G02, G03, or G32 command will operate in Stop Mode instead of Pass Mode if this command is executed.


2. An error will result if the G31 command is executed if the value of Speed Reference 2 is the same as or larger than that of Speed Reference 1. Make sure that the value of the Speed Reference 1 is larger than of Speed Reference 2.
3. The value of a speed reference must be the same as or less than the maximum feed rate. If the value is larger than the maximum feed rate, the axis will move at maximum feed rate and the override will be enabled for the speed control but disabled for the position control.

### Positioning Curve Examples


The following positioning curves are obtained according to the speed and movement of the axis if a general input is turned ON.

#### Speed Reference 2 Omitted


- 1,2,3... 1. A general input is turned ON while the axis is moving at constant speed, but the deceleration time is extremely short because the speed is high and the movement is small.




2. A general input is turned ON while the axis is being accelerated. (1)



3. A general input is turned ON while the axis is being accelerated. (2)




4. A general input is turned ON while the axis is being accelerated. (3)




### Speed Reference 2 Specified


- 1,2,3... 1. A general input is turned ON while the axis is moving at constant speed, but the deceleration time is extremely short and the speed is not decelerated to what was specified with Speed Reference 2 because the speed of the axis is high and the movement of the axis is small.




2. A general input is turned ON while the axis is being accelerated. (1)




3. A general input is turned ON while the axis is being accelerated. (2)




4. A general input is turned ON while the axis is being accelerated. (3)



5. A general input is turned ON when the axis is being accelerated. (4)



**Example 3: Specifying the Travel Distance for When No Interrupt is Input**  
G31 X100/200 F200




If no interrupt signal is input after positioning is completed, an error will occur and operation will stop (program execution interrupt). If an S option is attached, however, the condition is not judged to be an error and the next block can still be executed.

**Example** G31 X 100/200 F200 S


An interrupt input signal can be received at any time. The axis will be fed the reference amount at the going speed if an interrupt is input during deceleration.

Operation when an interrupt signal is input during deceleration



**Note** When positioning using interrupt feeding, positions that are determined after external sensor are enabled will vary depending on various conditions, such as the ambient temperature. This variation occurs due to detection delays by external sensors and the general input circuitry of the MC Unit.

The following illustration shows the MC Unit detection delay, and the resulting variation, assuming that there is no detection delay due to external sensors.



- The external sensor changes from disabled to enabled.
- The status of this external sensor is taken as the general input. There is a maximum delay of 1 ms in this general input circuit, so the MC Unit starts positioning control at no more than 1 ms after the external sensor is enabled.
- Accordingly, the actual position to be determined by the MC Unit after the external sensor is enabled can be obtained according to the following formula.

$$\text{Actual travel distance [pulse]} = \text{Specified travel distance [pulse]} + \text{Feed rate [pps]} \times \text{Detection delay [s]}$$

- Actual travel distance refers to the distance from the point where the external sensor is enabled to the point where the machine actually stops moving.
- Specified travel distance refers to the distance specified by G31.
- Feed rate refers to the rate specified by G31.
- The detection delay is 0.001 (s) max.

This command is provided for traverse, winding machine operations and it can be used in either Pass Mode or In-position Check OFF Mode.

**Format** G32\_<Axis movement command>\_<Speed reference>  
 [\_M<M code>[/Stopover (Note 1)]]  
 [\_D<D code>[/Stopover (Note 1)]]  
 [\_O<Trailing end specification>](Note 2)  
 \_L<Number of layers>

- Note**
1. The stopover function can be used with either an M code or a D code, but not with both.
  2. When winding at the end, specify the number of layers. Winding will not be performed at the end if the number of layers is not specified.

**Operands** The following table shows the possible settings for the operands.


Operand		Possible settings	
Rotating axis		X	Z
Coordinate data		±39999999 (E00) to (E31) A0 to A1999	±39999999 (E00) to (E31) A0 to A1999
Traverse axis		Y	U
Coordinate data		±39999999 (E00) to (E31) A0000 to A1999	
Speed reference		0.0001 to 39999999 (E00) to (E31) A0000 to A1999	
M code		000(0) to 999 (E00) to (E31) A0000 to A1999	
D code		000(0) to 255 (E00) to (E31) A0000 to A1999	
Stopover	Axes	X, Y, Z, U	
	Coordinate data	0 to 39999999 (E00) to (E31) A0000 to A1999	
End specification		0 to 39999999 (E00) to (E31) A0000 to A1999	
Number of layers		1 to 111111 (E00) to (E31) A0 to A1999	

**Note** Refer to 7-4 M Code Outputs for details on M codes, and to 7-4-9 D Code Outputs for details on D codes. Refer to 7-4-10 Stopover Function for details on the stopover function.

Values for all commands are relative to the present value.




**Operation** In the following application, the rotating axis of the spool is the X axis and the traverse axis is the Y axis.



### G Command Example

The M and D codes are omitted here. Specify the command units in the parameters using [deg.] for the X axis and [mm] for the Y axis.



### Number of Windings per Layer

Setting range: -39,999,999 to +39,999,999

Sets the number of windings per layer in [deg.] units. For 100 revolutions, set 36,000 because  $360 \text{ [deg.]} \times 100 = 36,000 \text{ [deg.]}$ .

The windings run clockwise if a positive number is set and counterclockwise if a negative number is set. The minimum setting unit is 0.0001 [deg.].

Only the X and Z axes can be specified as the rotating axis and the rotating axis must be set to Unlimited Feed Mode. Refer to 6-20 Unlimited Feeding for details on this function.

### Winding Width

Specifies the traverse width in [mm] units.

### Axis Rotation Speed

Specifies X- or Z-axis rotation speed in [deg./s] units.

### End Specification

Specifies the number of windings at the trailing end in [deg.] units. To set five windings at the end for example, then specify "01800" because  $360 \text{ (deg.)} \times 5 = 1,800 \text{ [deg.]}$ . No winding at the end will be set if the O option is omitted.

No windings at the end (O option omitted)



Windings at the end (for only one layer)



### Number of Winding Layers

Specifies the number of winding layers.

**Restrictions**

- Number of X-axis or Z-axis Rotations

The maximum distance that the X or Z axis can travel in one revolution without stopping must fall within the following equation:

$$|\text{Number of windings per layer} \times \text{Total no. of windings} + \text{Number of end windings}| \leq 39,999,999 \text{ (deg.)}$$

Numbers in the preceding range as well as the feed rate (in pulse units) after the pulse rate is changed must not exceed 7FFFFFFF.

- Y-axis or U-axis Travel Distance

The maximum distance that the Y axis or the U axis can travel in one revolution without stopping must fall within the following equation:

$$|\text{Traverse width}| \leq 39,999,999 \text{ (deg.)}$$



Numbers in the preceding range as well as the feed rate (in pulse units) after the pulse rate is changed must not exceed 7FFFFFFF.

- Number of Winding Layers

The maximum number of windings is 111111 (39,999,999 [deg.]/360 [deg.]).


**Programming Examples****Example 1**

In this example, a traverse operation is executed using aligned windings, a traverse width of 100 mm, 100 windings per layer and a total of 10 layers.


**Movement of each axis**

**Example 2** In this example, just once winding is executed each time at the end. This is an example of Pass Mode operation combined with G32.

N110 G10						..... Specifies Pass Mode
N120 G32	X36000	Y100	F1000	O360	L1	..... Winds one revolution at the end (0 designation)
N130 G32	X36000	Y-100	F1000	O360	L1	..... Moves back to the start



### Movement of each axis



## 16 G50: Select Reference Coordinate System

Specifies the reference coordinate system as the coordinate system.

**Format** G50

**Operands** None

**Description** This command specifies the reference coordinate system as the coordinate system. The coordinate data for subsequent axis operations will be processed as reference coordinate data.

The default setting at the start of program execution will be the reference coordinate system.

After WORKPIECE ORIGIN RETURN (G27) is executed, the workpiece coordinate system will be used.


**Programming Example**

The following example shows setting the reference coordinate system as the coordinate system and performing linear interpolation.

```

:      :
N009  G90
N010  G50
N011  G01  X100  Y200
:      :

```



17

**G51: Select Workpiece Coordinate System**

Set the workpiece coordinate system as the coordinate system.

**Format** G51

**Operands** None

**Description** This command sets the workpiece coordinate system as the coordinate system. After this command is executed, the coordinate data in all subsequent axis operations is processed as workpiece coordinate data.

The origin for the workpiece coordinate system can be set with the system parameters or with G53. The reference coordinate system will be used after REF-ERENCE ORIGIN RETURN (G26)) or ORIGIN SEARCH (G28) is executed.


**Programming Example**

The following example shows setting the workpiece coordinate system as the coordinate system and performing linear interpolation.

```

:      :
N009  G90
N010  G51
N011  G01  X100  Y200
:      :

```



**18 G53: Change Workpiece Origin Offset**

Changes the origin of the workpiece coordinate system.

**Format** G53\_<offset value...>

**Operands** The following table shows the possible settings for the operands.

Operand		Possible settings
Offset value	Axis names	X,Y,Z,U
	Data	±39,999,999 (E00) to (E31) A0000 to A1999

**Description** This command changes the offset between the reference coordinate system origin and the workpiece coordinate system origin to a specified value. The workpiece coordinate system will not be selected by executing this command. Specify using the workpiece coordinate system with G51.

The default setting for the workpiece coordinate system origin is the workpiece origin offset set in the system parameters when the main program is executed from the beginning.

The workpiece origin offset that is set in system parameters will not be updated by executing this command.

A software limit exceeded error will occur if a specified value exceeds the software limits set in the system parameters.

**Programming Example 1**

The following example shows changing the origin of the workpiece coordinate system.

```

:      :
N020  G10                Sets Pass Mode.
N021  G01  X100  Y100  F100
N022  G01  X200
N023  G53  X100
N024  G01  X300
:      :

```


**Programming Example 2**

The following example shows changing the origin of the workpiece coordinate system.

```

:      :
N010  G53  X100  Y50
:      :

```



## 19

**G54: Change Reference Coordinate System PV**

Changes the present value in the reference coordinate system.

**Format** G54\_<present value...>

**Operands** The following table shows the possible settings for the operands.

Operand		Possible settings
Present value	Axis name	X,Y,Z,U
	Data	±39,999,999 (E00) to (E31) A0000 to A1999

**Description** This command changes the present value of the specified axis reference coordinate system to a specified value.

**⚠ Caution** The absolute value stored in the absolute encoder will not be changed by this command. Unlock the servo, lock it again and read values to use the present position in the absolute encoder.

A software limit exceeded error will occur if a specified value exceeds the software limits set in the system parameters.

**⚠ Caution** If this command is executed just after a G01, G02, G03, or G32 command, the interpolation will be performed in Stop Mode, not Pass Mode, even if Pass Mode has been selected. The following example shows this effect.


**Programming Example**

In this programming example, the present value of the reference coordinate system is changed from (300, 400) to (200, 200).

```

:      :
N010  G54  X200  Y200
:      :

```



## 20

**G60: Arithmetic Operations**

Performs arithmetic operations on position data and registers.

**Format** G60\_<first term = second term operator third term>

**Operands** The following table shows the possible settings for the operands.

Operand	Possible settings
First term	A0000 to A1999 E00 to E31
Second term	A0000 to A1999 E00 to E31 $\pm 39,999,999$
Operator	+, -, *, or / (addition, subtraction, multiplication, or division)
Third term	A0000 to A1999 E00 to E31 $\pm 39,999,999$

**Description** This command performs arithmetic operations on numerical values, position data, or the contents of registers. When the first term is a register, the second and third terms will be integers. (Non-integer values are rounded to the nearest integer.)

**Example**

If G60: E00 = 0.4 + 0.4 is executed, then zero will be substituted at E00.

When the first term is a position data address, the second and third terms will be real numbers and values below the fifth decimal place will be rounded off.

**Example**

If G60: A0000 = 1.2345 x 1.01 is executed, then zero will be substituted at A0000.

The possible values for the result are as follows:

$-39,999,999$  to  $-0.0001$

0

$0.0001$  to  $39,999,999$

An error will occur if the first term's data is not within the acceptable range. The possible values for the first terms are as follows:

When the first term is position data:  $-39,999,999$  to  $+39,999,999$

When the first term is a register: 0000 to 1999

Registers are cleared to zero if the power is turned ON or the system is restarted.

Substitute values when registers are used.

**Programming Example**

The following example shows subtracting 500 from the value at A1000 and substituting the result at A0000.

```

:      :
N010  G60  A0000=A1000-500
:      :
```

## 21

**G63: Substitution**

Substitutes position data and registers

**Format** G63\_<first term = second term>

**Operands** The following table shows the possible settings for the operands.

Operand	Possible settings
First term	A0000 to A1999 E00 to E31
Second term	A0000 to A1999 E00 to E31 $\pm 39,999,999$ X, Y, Z, U

**Description** This command copies position data, register contents, present values, or numerical values into position data addresses or registers.

When the second term is an axis name, the present position of that axis in the reference coordinate system is copied to the first term. That present position is copied according to the pulse rate and minimum unit setting for that axis specified in the system parameters. However, if the origin has not been fixed, the ORI-GIN UNDEFINED error will occur.

When the first term is a register, the value in the second term will be treated as an integer.

Non-integer values are rounded to the nearest integer.

An error will occur if the first term's data is not within the acceptable range. The possible values for the first term are as follows:

When the first term is position data: -39,999,999 to +39,999,999

When the first term is a register: 0000 to 1999

Registers are cleared to zero only when the power is turned on, so be sure to initialize the register contents when the program is started.

### Programming Example

The following example shows **substituting 123.45 for A1000**.

```

:      :
N010  G63  A1000=123.45
:      :
```

## 22

### G69: Change Parameter

Changes the setting of the specified parameter.

**Format** G69\_<#parameter type>/<new setting ...>

**Operands** The following table shows the possible settings for the operands.

Operand		Possible settings
Parameter type		1 to 8
New setting	Axis names	X, Y, Z, U
	New setting	Refer to the ranges below for each parameter. (E00) to (E31) A0000 to A1999

**Description** This command changes the setting of the specified parameter. The following table shows the parameters that can be changed and the parameter type values used to identify them. Parameters #1 to #4 are feed rate parameters, and #5 to #8 are servo parameters.

Parameter type	Parameter	Setting range
#1	Acceleration time	0 to 100,000 (ms)
#2	Deceleration time	0 to 100,000 (ms)
#3	Interpolation acceleration time	0 to 100,000 (ms)
#4	Interpolation deceleration time	0 to 100,000 (ms)
#5	Position loop gain	1 to 250 (rad/s)
#6	Position loop feed forward gain	0 to 100 (%)
#7	In-position	0 to 10,000 (pulses)
#8	Error counter warning	0 to 65,000 (pulses)

The actual settings in the system parameters are not changed by G69.

System parameters will be initialized when the main program is executed starting from the beginning. If a position data address or register is specified and the specified data is not an integer, then the value will be rounded off to the nearest integer. A number range over error will occur if the specified data is not within the allowable range.

The following is supplemental information for each of the parameters.

<Acceleration time, deceleration time, interpolation acceleration time, interpolation deceleration time>



When the operating mode is Stop Mode or In-position Check OFF Mode, the new acceleration/deceleration time will be reflected in the next operation. When the operating mode is Pass Mode and the interpolation acceleration/deceleration time is changed during linear or circular interpolation, the new interpolation acceleration/deceleration time will go into effect between G01, G02, G03, and G32 commands following the G69 command.

<Position loop gain, position loop feed forward gain, in-position, error counter warning>

In Stop Mode or In-position Check OFF Mode, these values will go into effect when parameters are changed. In Pass Mode, they will go into effect with the next G69 operation command.


### Programming Example

In this programming example, the interpolation acceleration time is changed during interpolation.

```

:      :
N009  G01  X200  Y300
N010  G69  #3/X100
N011  G01  X300  Y500
N012  G01  X500  Y800
:      :

```



## 23

### G70: Unconditional Jump

Unconditionally jumps to the specified block.

**Format** G70\_<jump destination block number>[/L<number of loops>]

**Operands** The following table shows the possible settings for the operands.


Operand	Possible settings
Destination block number	N000 to N999
Number of loops	1 to 39,999,999 (E00) to (E31) A0000 to A1999

**Description** This command unconditionally jumps to the specified block. A fixed number of jumps (a loop) can be created by specifying a number of loops.

When a number of loops is specified, the destination block number must be before the current block number.

If an UNCONDITIONAL JUMP (G70) or a CONDITIONAL JUMP (G71) command is used to exit a loop before the number of loops has counted down to zero and the jump is to a program location after the loop, the number of loops will be cleared when another loop is started.

A second loop cannot be executed while a loop is in progress. The following diagram demonstrates this programming error.



Loops cannot be nested as shown above, but up to six loops can be nested by calling subroutines containing loops. The number of loops in each subroutine is cleared when the subroutine ends. Refer to 7-3-25 G72: SUBROUTINE JUMP for details.

When the number of loops is set indirectly from position data with register specification or position data number specification, the number of loops will be 0 if the value of the position data is 0. Non-integer position data values will be rounded off to the nearest integer value. An error will also occur if the position data is negative.

### Programming Example

The following example shows executing another loop when a given condition occurs in the first loop.

```

      :
N020 G00 X100
N030 G71 N090/A1000=1
N040 G70 N020/L100 .....●
      :
      :
      :
N090 G00 X3200
N100 G70 N090/L50 .....●
      :
      :
  
```

In loop ●, the program will jump to N020 up to 100 times while A1000p1, so blocks N020 and N030 will be executed up to 101 times.

In loop ●, the program will jump to N090 up to 50 times, so block N090 will be executed up to 51 times.

If A1000=1 on the 20th execution in loop ●, the program would jump to block N100. The remaining value of 80 jumps in the number of loops would be cleared and the number of loops would be set to the new value of 50 for block N100.

## 24

### G71: Conditional Jump

Jumps to the specified block when the condition is met.

**Format** G71\_<jump destination block number>/<condition equation>

**Operands** The following table shows the possible settings for the operands.

Operand		Possible settings
Destination block number		N000 to N999
Condition equation	First term	A0000 to A1999 E00 to E31
	Operator	=, <, >, or !
	Second term	A0000 to A1999 E00 to E31 ±39,999,999

**Description** This command jumps to the specified block when the given condition is met. The “!” operator is the inequality operator (not equal to). The first and second terms will be compared as real numbers, even if registers are specified.

**Programming Example**

The following example shows repeating until A1000=10

```

      :      :
N008  G91
N009  G63    A1000=0
N010  G00    X500
N011  G60    A1000=A1000+1
N012  G71    N010/A1000 ! 10
      :      :

```

In this programming example, 0 is substituted for A1000 in block N009 and then incremented by 1 in block N011 after the positioning operation in block N010. At N012, the program jumps back to N010 and repeats blocks N010 to N012 while A1000 ≠ 10. The program proceeds when A1000=10.

## 25

**G72: Subroutine Jump**

Calls the specified subroutine.

**Format** G72\_<subroutine number>

**Operands** The following table shows the possible settings for the operands.

Operand	Possible settings
Subroutine number	P500 to P999
	A0000 to A1999

**Description** This command calls and executes the specified subroutine. Subroutines can be nested five times. An error will occur if a sixth subroutine is called.  
 If the position data number is specified for the subroutine number, the subroutine stored in the position data will be called and executed (indirect calling).  
 A no program error will result if the position data does not satisfy the following condition.

$$500 \leq \text{Position data} \leq 999$$

**Programming Example**


The following example shows calling a subroutine.

```

      :      :
N010  G72    P500
      :      :

```

Up to six loops can be created by calling subroutines, as shown in the following diagram.



**26 G73: Subroutine End**

Ends the subroutine.

**Format** G73

**Operands** None

**Description** This command ends the subroutine and returns control to the block after the one that called the subroutine. This command must be programmed at the end of every subroutine.

**Programming Example**

```

N000 P510 XY
      :   :
      :   :
      :   :
N100 G73

```

**27 G74: Optional End**

Ends the block currently being executed when the specified optional input goes ON.

**Format** G74• <optional number>

**Operands** The following table shows the possible settings for the operands.

Operand	Possible settings
Optional number	00 to 19

**Description** If the specified input is received while the block after the one with this command is being executed, execution of that block will be interrupted and the program will proceed to execute the following block.

If an axis operation is being executed, the operation will be decelerated to a stop before proceeding to the next block. If a DWELL TIMER (G04) command is being executed, the command will be interrupted and the remaining time cancelled.

The source of the optional input depends on the optional number specified, as shown below.

0 through 15: Inputs from the PC Interface Area  
 16 through 19: Inputs from general inputs 1 to 4

This command is ineffective if the following block contains a SUBROUTINE END (G73) or PROGRAM END (G79) command. If the specified optional input is ON already, this command will operate just like the OPTIONAL SKIP (G75) command.


**Programming Example**

The following example shows stopping linear interpolation in progress by turning ON an optional input.

```

:      :
N008  G11
N009  G91
N010  G74    3
N011  G01    X100
N012  G01    X100
:      :

```



## 28

**G75: Optional Skip**

Skips the next block when the specified optional input is ON.

**Format** G75• <optional number>

**Operands** The following tables shows the possible settings for the operands.

Operand	Possible settings
Optional number	00 to 19

**Description** If the specified input is ON when this command is executed, the next block will be skipped. The source of the optional input depends on the optional number specified, as shown below.

0 through 15: Inputs from the PC Interface Area  
 16 through 19: Inputs from general inputs 1 to 4

Program execution will continue normally even if the optional input comes ON while the next block is being executed. The OPTIONAL SKIP (G75) command will be disabled if the following block contains a SUBROUTINE END command (G73) or PROGRAM END command (G79).



**Programming Example**

The following example shows disabling a linear interpolation operation by turning ON an optional input.

```



:
N008 G11
N009 G91
N010 G01 X50
N011 G75 3
N012 G01 X50
N013 G01 X50
:

```



When block N008 contains the Pass Mode (G10) command, blocks N011 and N012 are pre-executed while N010 is being executed, so block N012 will not be skipped if Optional Input 3 is turned ON after execution of block N010.

To ensure that block N012 will be skipped, make sure that Optional Input 3 is ON before block N010 is executed.

**29****G76: Optional Program Pause**

Pauses the program when the specified optional input is ON.

**Format** G76• <optional number>

**Operands** The following table shows the possible settings for the operands.

Operand	Possible settings
Optional number	00 to 19

**Description** If the specified input is ON when this command is executed, program execution will be paused. Program execution will continue from the next block when the optional input is reset. The source of the optional input depends on the optional number specified, as shown below.

0 through 15: Inputs from the PC Interface Area  
 16 through 19: Inputs from general inputs 1 to 4



Program execution will continue normally if the optional input comes ON while the next block is being executed.

### Programming Example

The following example shows pausing a linear interpolation operation by turning ON an optional input.


```

:
:
N008 G11
N009 G91
N010 G01 X100
N011 G76 3
N012 G01 X100
:
:
```




When block N008 contains the PASS MODE command (G10), blocks N011 and N012 are pre-executed while N010 is being executed, so the program will not be paused if Optional Input 3 is turned ON after execution of block N010.

To ensure that the program will be paused, make sure that Optional Input 3 is ON before block N010 is executed.



The program is not paused because Optional Input 3 is not ON when block N011 is pre-executed.



In this case, the program is paused because Optional Input 3 is ON when block N011 is pre-executed.

**30 G79: Program End**

Ends the main program.

**Format** G79

**Operands** None


**Description** This command ends the main program and must be included at the end of the main program.

When G79 is executed and an axis is in operation, the Unit will wait for the axis to be positioned before executing G79. M codes M500 to M999 will be forcibly cleared if they are being output when G79 is executed.

**Programming Example**

The following example shows how G79 is executed after axis operation is completed in Pass Mode.

	:	:	
N020	G10		Sets Pass Mode.
N021	G01	X100 Y100	F100
N022	G01	X200 F200	
N023	G79		Executed after N022 is completed.
	:	:	

**31 G90: Absolute Specification**

Specifies the use of the absolute coordinates in axis operations.

**Format** G90

**Operands** None

**Description** This command specifies that the absolute coordinate system for each axis is to be used when for axis positioning. After this command is executed, the coordinate data in axis movement commands is treated as absolute coordinate data.

In addition to G90, the absolute coordinate system is put into effect when a REFERENCE ORIGIN RETURN (G26), WORKPIECE ORIGIN RETURN (G27), or ORIGIN SEARCH (G28) command is executed.




**Programming Example**

The following example shows positioning with absolute coordinate data.

```

:      :
N010  G90
N011  G01    X50    Y50
N012  G01    X100   Y20
:      :

```



32

**G91: Incremental Specification**

Specifies the use of relative coordinates in axis operations.

**Format**     G91

**Operands**   None

**Description** This command specifies that positioning axis operations are performed relative to the present position. After this command is executed, the coordinate data in axis movement commands is treated as the distance to be moved from the present position.

In addition to G91, the incremental coordinate system is put into effect when a REFERENCE ORIGIN RETURN (G26), WORKPIECE ORIGIN RETURN (G27), or ORIGIN SEARCH (G28) command is executed.


**Programming Example**

The following example shows positioning with incremental coordinate data.



```

:      :
N010  G91
N011  G01    X50    Y50    F100
N012  G01    X100   Y20
:      :

```



If positioning with incremental specification is interrupted by a pause command, the axes will be moved to the original end position after the operation is restarted. Also, if the axes have been moved or an origin search was performed after the operation was interrupted, the axes will still be moved to the original end position.

**Example 1****Example 2**

## M Code outputs

### 1 Introduction

M codes consist of information used to interlock with external devices in positioning operation processes. External devices are devices directly connected to the general outputs of the CPU Unit and MC Unit.

**Format** M<M code>

Example 1: M500

Example 2: G01 X100 MA000

Example 3: G01 X200 Y100 M(E00)

**Operands** The following table shows the possible settings for the operands.

Operand	Possible settings
M code	00 to 999 (E00) to (E32) A0000 to A1999

**Programming Example**


The following program shows an example of M code usage.

```

N000 P100 X ..... Declares the program number.
N001 G01 X100 F100..... Moves to 100 mm on the X-axis by linear interpolation.
N002 M100 ..... Outputs M code 100 to the CPU Unit and waits for OK to
                    perform the next operation. Proceeds to next block when
                    the M code reset is received from the CPU Unit.
N003 G01 X0 ..... Moves to 0 mm on the X-axis by linear interpolation.
N004 G79..... Declares the end of the program
  
```

**Timing Chart**

The following diagram shows the timing of the programming example execution. The Axis Operating, M Strobe, M Code, and M Code Reset Bits are provided in the PC Interface Area.



**Description** The following list provides a running description of the program execution.

1. In block N001, the X-axis is moved to 100 mm by linear interpolation.
2. In block N002, M code 100 is output after the X-axis positioning is completed; the M strobe is turned ON at the same time to indicate that the M code has been set.
3. In the CPU Unit, the processes corresponding to M code 100 are performed when the M strobe goes ON. The CPU Unit turns ON the M Code Reset Bit when these processes are completed.
4. In the MC Unit, the M code is cleared to 0 and the M strobe is turned OFF when the CPU Unit turns ON the M Code Reset Bit.
5. When the M Code Reset Bit from the CPU Unit goes OFF, block N003 is executed, moving the X-axis to 0 mm.
6. The program ends in block N004.

**2****M Code Data**

There are some M codes that interlock as explained on the previous page, and others that do not interlock. These differences are explained below.

When an M code is specified in a register or position data address, the specified value will be rounded to the nearest integer value. An error will occur if the result is not an acceptable M code value (0 to 999).

**M Codes 0 to 499**

M codes 0 to 499 are used to interlock with external devices. Execution of the program is paused when there is not an M code reset input.

**M Codes 500 to 999**

Use M codes 500 to 999 when it is not necessary to interlock. These M codes are just output and the program is executed without waiting for an M code reset input.

These M codes are cleared when the PROGRAM END command (G79) is executed.

**3 M Code Examples**


M codes can be used independently or with G codes, such as G00 and G01, that execute axis operations.

**Example** The following program just outputs M code 600. (M codes over 499 do not interlock.)

```

N000 P000 X
N001 G01 X100 F100 M600
N002 G01 X200 F100
N003 G79

```


**4 Effect of Mode Changes on M Code Resets**

The status of M codes is not affected by switching from manual to automatic mode or vice versa.


**5 Clearing M000 to M499 with Forced Block End or G74**

The M strobe and M code outputs for M codes 000 to 499 will be cleared if the program block that outputs the M code is cleared with the Forced Block End Bit (PC Interface Area) or the OPTIONAL END (G74) command.


**Example 1** The M strobe and M code will not be output if a Forced Block End signal is received before they are output.



**Example 2** The M strobe and M code will not be output if the OPTIONAL END command's optional input is received before they are output.




**Example 3** When the output has been completed and the system is set to wait for the M code reset, the M strobe will be turned OFF and the M code will be cleared to release the M code reset.



**Example 4** The M strobe and M code will be cleared if the OPTIONAL END command's optional input is received while they are being output.

```
G74    3
G00    X500  M100
G01    X1000
```




## 6 Clearing M500 to M999 with Forced Block End or G74

The M strobe and M code outputs for M codes 500 to 999 will not be output cleared if the program block that outputs the M code is cleared with the Forced Block End Bit (PC Interface Area) or the OPTIONAL END (G74) command, but previous M codes will not be cleared.

**Example 5** The M strobe and M code will not be output if a Forced Block End signal is received before they are output, but a previous M code and M strobe will not be cleared.

```
M700
G00    X500  M600
```




**Example 6** The M strobe and M code will not be output if the Optional End command's optional input is received before they are output, but a previous M code and M strobe will not be cleared.

```

M700
G74 3
G00 X500 M600
G01 X1000

```



## 7 M Code Outputs in Pass Mode

M codes M500 to M999 can be output in Pass Mode while axes are being operated. In this case, M codes will be output at the following positions according to the system parameter settings.

### Constant Acceleration Mode OFF

The M code will be output just before the demand position. The output position can be calculated using the following equation.

$$\text{Demand position} - \text{reference speed} \times \text{pass time} / 2$$

The pass time is determined by the Pass Time Mode Selection settings in the system parameters as follows:

The pass time is the interpolation acceleration time when interpolation acceleration time is selected.

The pass time is the interpolation deceleration time when interpolation deceleration time is selected.

### Constant Acceleration Mode ON


The M code will be output at the demand position.

Refer to 6-8 Operating Modes for details on the Constant Acceleration Mode.

**Example 1 Constant Acceleration Mode OFF**


The following program will output an M code during pass operation. The M code is reset from the CPU Unit.

```
N000 P000 X
N001 G01 X100 F100 M500
N002 G01 X200 F200 M501
B003 G01 X300 F100
N004 G79
```

**Example 2 Constant Acceleration Mode ON**

The following program will output an M code during pass operation. The M code is reset from the CPU Unit.

```
N000 P000 X
N001 G01 X100 F100 M500
N002 G01 X200 F200 M501
B003 G01 X300 F100
N004 G79
```



## 8 Stopover function and Resetting M Codes

This section describes the reset timing for M codes when the Stopover function is used. Refer to 7-4-3 for details on the Stopover function.


**M000 to M499**

When an M code between M000 and M499 is output, the next positioning operation will be performed after positioning to the demand position has been completed in either Pass Mode or In-position Check OFF Mode.




**Example 1** The following program outputs M code 100 during linear interpolation (N001). The CPU Unit turns the M Code Reset Flag ON and OFF to reset the M code while N001 is executing. When that happens, the next positioning operation (in N002) is performed after the axis has moved 100 mm on the X axis.

N000 P000 X  
 N001 G01 X100 F100 M100/X30      Outputs M code 100 after the axis has moved 30 mm from the present position.  
 N002 G01 X200 F200  
 B003 G79



**Example 2** The following program outputs M code 100 during linear interpolation (N001). The Unit will wait for the M Code Reset Bit to turn ON after positioning has been completed because the Bit was not input while N001 was executing. The CPU Unit turns the M Code Reset Bit ON and OFF to reset the M code. When that happens, the next positioning operation (N002) is performed.

N000 P000 X  
 N001 G01 X100 F100 M100/X30      Outputs M code 100 after the axis has moved 30 mm from the present position.  
 N002 G01 X200 F200  
 B003 G79



**M500 to M999** The M code is reset with the same timing used to output M code in Pass Mode.

**Note** Refer to 7-4-7 M-code Outputs in Pass Mode for more details.

## 9

### D Code Outputs

**D Codes** A D code is a preset code that is output after positioning has been completed. The D code (0 to 255) is output to the CPU Unit as an interrupt task number to executed the interrupt task in the CPU Unit. It can also be output during operation without stopping operation by using the Stopover Function. Refer to 6-10 or Stopover Function for details on the function.



**Caution** D code outputs can only be used when an MC Unit is mounted on the CPU Back-plane. They cannot be used if the Unit is mounted on an Expansion Backplane.


<b>Format</b>	D <D code>					
	Case 1: N010	D100				
	Case 2: N010	G01	X100	F200	D100	
	Case 3: N010	G01	X100	F200	M50	D100

**Operands**

D Code
0 to 255
(E00) to (E32)
A0000 to A1999


**Description**

- The D code must be between 0 and 255.
- The following can be written after the D.
  - A number: 0 to 255 (integer)
  - (E00) to (E31)
  - A0000 to A1999
- The output timing for D codes is the same as that for M codes.
- D codes, like M codes, can be used with G codes. Only one or the other can be used at a time with a G code.
- When a D code is output, the CPU Unit determines whether it can receive an interrupt. If it cannot receive an interrupt, then it will monitor status for 10 ms. If reception is still not possible, the CPU Unit will output a D code timeout error and stop.
- If a D code is output from more than one task at the same time, then outputting the D code for each task will be offset in 2 to 10-ms increments.




## Operating Patterns


Case 1: Notification after Positioning Is Completed




Case 2: Pass Mode Operation



Case 3: CPU Unit Cannot Receive Interrupts during Pass Mode



Case 4: Continuous Interrupt Tasks Initiated



## 10

## Stopover Function

The Stopover function outputs M code or D code without stopping operation when the axis is moved a preset amount (judged from the present position) in axis operation. It is used to control peripheral devices prior to completing a move and to improve tact time. The function can be used with G codes for all operations and with either a D code or a M code, but not both at the same time.

**Format** M <M code>/<Stopover> or D <D code>/<Stopover>

Case 1: N010 G01 X200 F200 D100/X100 Outputs D code 100 after moving the axis 100 mm on the X axis.

Case 2: N010 G01 X200 F200 M600/X100 Outputs D code 600 after moving the axis 100 mm on the X axis.


## Operands

Stopover	
Axis	Coordinate data (travel distance)
X	0 to 39999999
Y	(E00) to (E32)
Z	A0000 to A1999
U	

**Description** The Stopover function outputs a M code or D code when the axis moves a certain amount (judged from the present position) after the axis starts to move from the present position to the demand position. The travel distance (relative movement) is always specified in as a positive value. The Stopover function is used with the following G codes for positioning.

G00	POSITIONING
G01	LINEAR INTERPOLATION
G02	CLOCKWISE CIRCULAR INTERPOLATION
G03	COUNTERCLOCKWISE CIRCULAR INTERPOLATION
G26	REFERENCE ORIGIN RETURN
G27	WORKPIECE ORIGIN RETURN
G28	ORIGIN SEARCH
G31 (See note.)	INTERRUPT FEEDING
G32	TRAVERSE


**Note** With the G31 code, the Stopover function becomes valid after the general input turns ON.



For G codes in which more than one axis moves, such as in multi-turn circular interpolation and traverse operations, the Stopover function is executed only once during execution of the G code.

**Example** The following program outputs M code 500 after the axis has moved 50 mm in the Y-axis direction when the traverse operation shown below (traverse width:100 mm, number of windings per layer: 10, number of winding layers: 10) is performed. No D code will not be output beyond that point.

```
G32 X36000 Y100 F1000 L10 M500/Y50
```



The following program outputs a M code or D code when the axis has moved the specified amount from the preceding demand position when the Stopover function is used in Pass Mode or In-position Check OFF Mode.


Example: (X, Y) = (30, 30)

```

:      :
N110  G10                                Pass Mode specified
N120  G01   X130   Y30   F100           Move to (X, Y) = (130, 30)
N130  G01   X130   Y130   M600/Y50

```

N130 is pre-read during execution of N120 because the system is in Pass Mode. M code 600 is thus output after moving 50 mm from Y30 (the demand position for N120) to 80 mm (determined from the present position).




The following occurs with circular interpolation. The D code is output when the axis has moved -70 mm on the X axis during circular interpolation as shown in the following figure.

```

N010  G02   X100   Y0    I0    J100   F100   D100/X70

```



## 11 Precautions on the Stopover Function

Heed the following precautions when using the Stopover function.

- Normally, the Stopover function is not valid if the specified distance moved is the same as the next demand position.


**Example** N0100 G00 X100  
N0110 G00 X200 M500/X100

If the specified distance is 100 mm which is the same as the distance from X100 to X200, then the Stopover function will not be valid after the axis has moved to demand position X200. M code 500 will be output if the travel distance exceeds 100 mm (large X-axis overshoot) before the demand position X200 is obtained.


- The Stopover function may not be valid in operations where the axis moves back and forth between two points in Pass Mode.

**Example** N000 P000 X  
N010 G01 X1000F<High-speed feed rate> D100/X900  
N020 G01 X0

#### High-speed feed Rate



#### Slow Feed Rate



## Appendix B

### G-language Programming Examples

This section provides examples of G-language programming for the CS1W-MC421/221.

Programming Examples .....	2
1 Positioning with PTP Control.....	2
2 Positioning with Linear Interpolation.....	3
3 Positioning with Linear and Circular Interpolation .....	4
4 Indirect Addressing with Registers.....	5
5 Using the Workpiece Origin Offset.....	6
6 Changing the Interpolation Acceleration Time .....	7
7 Positioning while Calculating Position Data .....	8
8 Stopping a Program with a General Input .....	10
9 Stopping the Program and Substituting Position Data.....	11
10 Positioning a Turntable.....	12
11 Positioning with Improved Locus Accuracy in Circular Interpolation .....	14
12 Starting Peripheral Devices during Operation .....	15
13 Positioning at High Speed .....	16
14 Shifting from Aligned to Rough Winding .....	17
Executing MC Programs from the Ladder Program .....	18

## Programming Examples

### 1 Positioning with PTP Control

**Operation** Three positioning operations are performed and then the reference origin is returned to. An M code is output when positioning is completed.

- 1,2,3...*
1. X100 Y50 (Output M code 20.)
  2. X250 Y150
  3. X300 Y200 (Output M code 700.)
  4. Return to reference origin.

#### Programming Example

The following programming example performs the positioning operations listed above.

```

N000 P001 XY
N001 G00 X100 Y50 M20
N002 G00 X250 Y150
N003 G04 2
N004 G00 X300 Y200 M700
N005 G26 XY
N006 G79

```

#### Explanation

Block N000 declares the program number and axes being used.

##### N001

Positions the axes to (X100, Y50) by PTP control. Absolute positioning (default) is used, because nothing is specified.

When positioning is completed, M code 20 is output and the Unit waits for a reset (M code reset standby).

##### N002

When the M code reset is received, block N002 positions the axes to (X250, Y150) by PTP control.

##### N003

Waits for 2 seconds.

##### N004

Positions the axes to (X300, Y200) by PTP control. When positioning is completed, M code 700 is output and the next block is executed without waiting for the reset.


##### N005

Returns the X and Y axes to the reference origin.

##### N006

Ends the program. When M code 700 is being output, it is forcibly cleared by the PROGRAM END command.


#### Timing Chart





## 2 Positioning with Linear Interpolation

**Operation** When the optional input turns ON, this program uses linear interpolation to move the X-axis by 300 and the Y-axis by 400 from the present position. This positioning operation will be repeated (up to 21 times) until position data address A1000 contains 1.



### Programming Example

```

N000 P002 XY
N001 G91
N002 G01 X300 Y400 F50 #16
N003 G71 N005/A1000=1
N004 G70 N002/L20
N005 G79

```

### Explanation

Block N000 declares the program number and axes being used.

#### N001

Specifies incremental positioning.

#### N002

Waits until optional input 16 (general input 1) turns ON. When it turns ON, the X-axis is moved by 300 and the Y-axis by 400 with linear interpolation at a speed of 50.


#### N003

Checks the content of A1000 and ends the program if it is 1.


#### N004

Jumps to block N002. Block N004 will jump to N002 20 times (performing 21 positioning operations).

**Note** The operations above are performed in Stop Mode, and not Pass Mode, because an option is specified.

**Timing Chart****3 Positioning with Linear and Circular Interpolation**

**Operation** This program combines linear and circular interpolation to move the X and Y axes in the pattern shown in the following diagram.

**Programming Example**

```

N000 P003 XY
N001 G17
N002 G01 X200 Y100 F50
N003 G03 X300 Y200 R100
N004 G01 Y300
N005 G02 X400 Y400 R-100
N006 G79

```

**Explanation****N001**

Sets the X-Y plane as the plane for circular interpolation.

**N002**

Moves the axes to (X200, Y100) by linear interpolation.

**N003**

Moves the axes to (X300, Y200) by circular interpolation in the counter-clock-wise direction with a radius of 100. A positive value is specified for the radius, so an arc smaller than a semicircle (1/4 circle) is drawn.

**N004**

Moves the axes to (X300, Y300) by linear interpolation.

**N005**

Moves the axes to (X400, Y400) by circular interpolation in the clockwise direction with a radius of 100. A negative value is specified for the radius, so an arc greater than a semicircle (3/4 circle) is drawn.

## 4 Indirect Addressing with Registers

**Operation** This program uses registers to indirectly specify position data stored in position data addresses and uses this data in positioning operations.

### Programming Example

```

N000  P005  XY
N001  G11
N002  G63   E1=100
N003  G63   E2=101
N004  G01   X(E1) Y(E2) F100
N005  G60   E1=E1+2
N006  G60   E2=E2+2
N007  G75   3
N008  G70   N004/L3
N009  G79

```

### Explanation

**N001**

Specifies Stop Mode.

**N002 through N003**

Set the initial position data addresses in the registers.

**N004**

Reads the position data from the addresses specified in the registers and moves the axes to this point by linear interpolation.

**N005 through N006**


Updates the contents of the registers.

**N007**

If optional input 3 is ON, the next block will be skipped and the program will end.


**N008**

Jumps to block N004 and repeats the positioning operation 3 times.



## 5 Using the Workpiece Origin Offset

**Operation** Positioning for the same pattern can be performed any number of times by repeatedly changing the workpiece origin offset and calling the subroutine. Using the workpiece coordinate system is useful particularly for absolute positioning



### Programming Example

```

N000 P006 XY
N001 G53 X100 Y100
N002 G72 P800
N003 G53 X200
N004 G72 P800
N005 G53 Y200
N006 G72 P800
N007 G79

```

### Subroutine

```

N000 P800 XY
N001 G27 XY M10
N002 G01 X10 Y10 F10
N003 G01 X20
N004 G01 Y20
N005 G01 X10
N006 G01 Y10
N007 G27 XY M20
N008 G26 XY M30
N009 G73

```

**Explanation****P006: N001**

Sets the workpiece origin offset to (X100, Y100).

**P006: N002**

Calls subroutine P800.

**P800: N001**

Returns to the workpiece origin. The workpiece coordinate system is selected at this time. M code M10 is output and the Unit waits for the M code reset.

**P800: N002 through N006**

The subroutine's series of absolute positioning operations is performed by linear interpolation in Pass Mode.

**P800: N007**

Returns to the workpiece origin. M code M20 is output and the Unit waits for the M code reset.

**P800: N008**

When the reset is received, block N008 returns to the reference origin. M code M30 is output and the Unit waits for the M code reset.

**P800: N009**

When the reset is received, block N009 returns to main program P006.

**P006: N003**

Changes the workpiece origin offset to X200.

**P006: N004**

Calls subroutine P800 and repeats the same series of operations.

## 6

**Changing the Interpolation Acceleration Time**

**Operation** This program changes the setting of the interpolation acceleration time parameter and performs linear interpolation.

**Programming Example**

```

N000  P007  XY
N001  G69   #3/X500
N002  G01   X1000 Y500 F300
N003  G01   X2000 Y-1000
N004  M20
N005  G69   #3/X100
N006  G01   X3000 Y1000
N007  G01   X4000 Y1500
N008  G79

```

**Explanation****N001**

Changes the setting of the X-axis' interpolation acceleration time parameter to 500 ms, which becomes the X-axis acceleration time used for interpolation in this task.

**N002**

Moves to (X1000, Y500) by linear interpolation with an acceleration time of 500 ms and speed of 300.

**N003**

Moves to (X2000, Y-1000) in Pass Mode with an acceleration time of 500 ms.

**N004**

Once the pass operation is completed, N004 outputs M code M20 and waits for the M code reset.

**N005**

Changes the setting of the interpolation acceleration time to 100 ms.


**N006**

Moves to (X3000, Y1000) by linear interpolation with an acceleration time of 100 ms.

**N007**


Moves to (X4000, Y1500) in Pass Mode with an acceleration time of 100 ms.

## Timing Charts



## 7 Positioning while Calculating Position Data

**Operation** After initializing the position data, this program moves the axes 10 times while incrementing the X-axis' position data by 20. Next, the Y-axis position data is incremented by 30 and the positioning operation is repeated five times. The positioning will be in grid as shown in the following diagram.



**Programming Example 1**

```

N000 P008 XY
N001 G11
N002 G63 E00=0
N003 G63 A1000=100
N004 G63 A1001=100
N005 G01 XA1000 YA1001 F20 M10
N006 G01 X0 Y0 F50
N007 G60 A1000=A1000+20
N008 G70 N005/L9
N009 G63 A1000=100
N010 G60 A1001=A1001+30
N011 G60 E00=E00+1
N012 G71 N005/E0 ! 5
N013 G79

```

**Explanation****N001**

Specifies Stop Mode.

**N002**

Initializes register E0 to 0.

**N003**

Substitutes the X-axis' initial position data into address A1000.

**N004**

Substitutes the Y-axis' initial position data into address A1001.

**N005**

Moves the axes by linear interpolation to the X position indicated in A1000 and the Y position indicated in A1001.

**N006**

Returns to the origin.

**N007**

Increments the X-axis' position data by 20.

**N008**

Jumps to block N004 and repeats the above process 9 times.

**N009**

Initializes the X-axis' position data to its original value.

**N010**

Increments the Y-axis' position data by 30.


**N011**

Uses register E0 as a loop counter with an initial value of 0. The content of E0 is incremented by 1.

**N012**

Jumps to N004 as long as the content of E0 is not 5. When E0=5, N012 proceeds to the next block and ends the program.

**Note** Register E0 is used as a loop counter in block N012 because loops cannot be nested as shown below.



The loops in the example above will not operate properly. A subroutine can also be used for nesting, as shown in the following programming example.

**Programming Example 2**

```

N000 P008 XY
N001 G11
N002 G63 A1000=100
N003 G63 A1001=100
N004 G72 P700
N005 G63 A1000=100
N006 G60 A1001=A1001+30
N007 G70 N004/L4
N008 G79

```

**Subroutine**

```

N000 P700 XY
N001 G01 XA1000 YA1001 F20 M10
N002 G01 X0 Y0 F50
N003 G60 A1000=A1000+20
N004 G70 N001/L9
N005 G73


```

**Explanation**

Blocks N005 through N008 in programming example 1 have been converted to subroutine format in subroutine P700, which is called from step N004 in main program P008. SUBROUTINE END (G73) is required at the end of the P700.

**8 Stopping a Program with a General Input**

**Operation** This program shows how to stop MC program execution when general input1 turns ON.

**Programming Example**

```

N000 P009 X
N001 G11
N002 G76 16
N003 G54 X0
N004 G01 X200 F100
N005 G70 N001
N006 G79

```

**Explanation****N001**

Specifies Stop Mode.

**N002**

Stops execution when general input 1 turns ON. (Proceeds to the next block when general input 1 is OFF.)

**N003**

Presets the X-axis' present value to 0.

**N004**

Absolute positioning of the X axis.

**N005**

Unconditionally jumps to block N001, repeating blocks N001 through N004. The process can be repeated indefinitely without an overflow because the present value is preset to 0 each time.

**N006**


Ends the program.



## 9

## Stopping the Program and Substituting Position Data

**Operation** This program moves the X axis to X1000 at a speed of 100 by linear interpolation. The movement will be decelerated to a stop by the G74 (OPTIONAL END) command if the target position is reached before the positioning operation is completed. The X position when the movement was stopped will be stored in address A500 and that position data will be used for later positioning operations. This process is useful for applications in which the position where the operation was stopped will be used for positioning rather than the original target position.



## Programming Example

```

N000 P010 X
N001 G11
N002 G74 17
N003 G01 X1000 F100
N004 G63 A500=X
N005 G01 X0
N006 G01 XA500
N007 G70 N005
N008 G79

```

## Explanation

**N001**

Specifies Stop Mode.

**N002**

Execution of the next block is stopped when general input 2 turns ON.

**N003**

Moves the X axis with a maximum target position of X1000. The positioning operation will be decelerated to a stop if general input 2 turns ON before positioning is completed.

**N004**

The stopping position is stored in address A500.

**N005**

Returns to the origin.

**N006**

Positions the X axis using the position data stored in address A500 in block N004.

**N007**


Jumps to N005 and repeats the positioning operation.

## 10 Positioning a Turntable

**Operation** This operation positions a turntable using the unlimited feed mode and various arithmetic commands. Positioning is performed while judging whether to move clockwise or counterclockwise to arrive at the target position. Target positions are specified between 0° and 360° and the present position will return to zero if a target position is specified outside that range.

Use the following procedure to specify positioning from the PC.

- 1,2,3... 1. Use the IOWR instruction to write the target position into address A0000 between 0° and 360°.
2. After the target position is specified, turn ON optional input zero and the turntable will be positioned at the target position.
3. M code 0001 will be output after positioning is completed. Check the M code, turn OFF optional input zero and turn the M code reset ON and OFF.
4. Repeat steps 1 to 3.



**Programming Example**

```

N000  P000  X
*001
*002  Target position=A0000, reference position (program setting)=A0001
*003  Present position (used internally)=A0100, work memory=A0101,A0102
*004
*005  Set the target position into A0000 by IOWR instruction.
*006  Waits until optional number zero turns ON.
*007
N008  G75   00
N009  G70   N008
*010
*011  Positions approximately.
*012
N013  G63   A0100=X
N014  G60   A0102=A0000-A0100
N015  G71   N020/A0102<-180
N016  G71   N022/A0102<180
N017  G71   N024/A0102<360
N018  G60   A0102=A0102-360
N019  G70   N015
N020  G60   A0001=A0000+360
N021  G70   N025
N022  G63   A0001=A0000
N023  G70   N025
N024  G60   A0001-A0000-360
N025  G00   XA0001      M001
N026  G70   N008
N027  G79

```

**Explanation**

Block N000 declares the program number and axis being used.

**\*001 to \*007**

Comments.

**N008 and N009**

Waits until optional input zero turns ON. When the input turns ON, unconditional jump N009 is disabled and the next block is executed (\*010).

**\*010 to \*012**

Comments.

**N013**

Substitutes the X-axis position into A0100.

**N014 to N017**

Determines whether to perform positioning in the clockwise or counterclockwise direction based on the target position (A0000) and the present position (A0100), and then jumps to individual processes.

**N018 and N019**

Corrects to a target position within one revolution if a target position of more than one revolution is specified, and restarts positioning from N014.

**N020 to N024**

Turns the turntable clockwise or counterclockwise and calculates target position A0001 where the turntable will be positioned.

**N025**

Positions the turntable at the target position and then outputs M code 0001 and turns ON the M strobe, and then waits for M code reset from the PC.

**N026**

After the M code reset from the PC has turned ON and OFF, jumps to the process for waiting for optional input zero to turn ON.

**System Parameter Settings**

The following system parameter settings must be made.

- Minimum setting unit                      Set for the user's system.
- Axis mode                                      Set to Unlimited Feed Mode.
- Software limits                              Set between 0° and 360°. If the minimum setting unit is 0.1, then the present position will be updated between 0.0° and 359.9°.


**Note** In the above application, set the encoder resolution and pulse rate so that a revolution (360°) is an integer when it is converted to pulses.

If positioning that passes through 0°, such as passing through 0° to shift the position from 350° to 10° or passing through 0° to shift the position from 10° to 350°, is performed repeatedly in a system that generates a remainder when a revolution (360°) is converted to pulses, an error of less than one pulse will occur per revolution.

Work within the allowable range for accuracy and execute ORIGIN SEARCH for each operation in systems like that described above.

## 11 Positioning with Improved Locus Accuracy in Circular Interpolation

**Operation** This operation is essentially the same as described in 8-1-3 Positioning with Linear and Circular Interpolation except that locus accuracy in the circle will be improved. When performing circular interpolation, the axes will follow the inner side of the expected circle as the feed rate increases. Locus accuracy will be improved by increasing the feed forward gain of the X and Y axes using G69 (change parameter). Normally overshooting will occur when the axes stop or when the target position is inverted if the feed forward gain in the servo system is increased too much. Therefore, set the feed forward gain to 20% for linear interpolation only operation and 60% for circular interpolation-only operation.



**Programming Example**

```

N000 P003 XY
N001 G17
N002 G69 #6/X20 Y20
N003 G01 X200 Y100 F50
N004 G69 #6/X60 Y60
N005 G02 X300 Y200 R100
N006 G69 #6/X20 Y20
N007 G01 Y300
N008 G69 #6/X60 Y60
N009 G02 X400 Y400 R-100
N010 G79

```

**Explanation**

**N002, N006:** Sets feed forward gain for the X and Y axes to 20% for linear interpolation operation.


**N004, N008:** Sets feed forward gain for the X and Y axes to 60% only for circular interpolation operation.

See 8-1-3 Positioning With Linear and Circular Interpolation for details on other settings.

## 12 Starting Peripheral Devices during Operation

**Operation** Peripheral devices can be started at high speed from the MC Unit using the MC Unit stopover function or interrupt notification function (D code) as well as a CPU interrupt task. This program allows high-speed synchronous applications to be created, because it is able to control peripheral devices without pausing operation.

The following program turns ON three valves (1, 2 and 3) during two-axis linear interpolation when the present positions on the X axis are 250, 500 and 750 mm.



## Programming Example

```

N000  P001  XY
*001  *****
*002  Executes interrupt notification.
*003  *****
N004  G01   X0    Y0    F100
N005  G75   N005
N007  G01   X250  Y250  F1000
N008  G01   X500  Y500  D100/X0
N009  G01   X750  Y750  D101/X0
N010  G01   X1000 Y1000 D102/X0
N011  G79

```

## Explanation

This operation creates a ladder program for the following interrupt tasks in the CPU Unit.

**Interrupt Task Number 100:**

Turns ON the output on the Output Unit that controls valve 1.

**Interrupt Task Number 101:**

Turns ON the output on the Output Unit that controls valve 2.

**Interrupt task number 102:**

Turns ON the output on the Output Unit that controls valve 3.

Positioning will start when optional input zero turns ON.

**N004**

Moves the axis to the start position.

**N005 and N006**

Waits until optional input zero turns ON. When the input turns ON, unconditional jump N0006 is disabled and the next block will be executed.

**N007**

Moves by linear interpolation to (X, Y) = (250, 250) in Pass Mode.

**N008**

Moves by linear interpolation to (X, Y) = (500, 500) in Pass Mode. This specifies the point where interrupt task number 100 (D100) will start up if the travel distance is zero when the Stopover function is used. The following shows where interrupt task number 100 (D100) will start up since Pass Mode operation is being used in this case.

Present position = preceding X-axis target position (N007) + stopover travel distance  
= 250 + 0  
= 250

In other words, interrupt task number 100 will start up when the present position is 250 mm.

**N009 and N010**

Similarly, interrupt task numbers 101 and 102 will start up at present positions 500 mm and 750 mm respectively.

## 13 Positioning at High Speed

This program reads the present position of the workpiece with a visual sensor, calculates correction and writes the correction value to the MC Unit. After the MC Unit receives the correction, it positions the axis accordingly. The CPU Unit sends two position data items to addresses A0000 and A0001 using the IOWR instruction and the MC Unit moves the axis immediately. Data can be sent to the MC Unit and positioning commands can be executed in a single scan.

**Programming Example**

```

N000 P000 XY
*001 *****
*002 Waits for M code reset.
*003 *****
N004 G01 X0 Y0 M500
N005 G75 00
N006 G70 N005
N007 G01 XA0000 YA0001 F1000 M001
N008 G70 N004
N009 G79

```

**Explanation****N004**

Waits at the reference coordinate system origin and outputs M code 500.

**N005 and N006**


Waits for optional number zero to turn ON. Writes position data from the CPU Unit by IOWR instruction and turns ON optional number zero.

**N007**


The MC Unit positions the axis at the position specified in A0000 and A0001, outputs M code 0001, and waits for M code reset. When the reset is received from the CPU Unit, the MC Unit moves the axis to the standby position.

**14 Shifting from Aligned to Rough Winding**

The following example shows what happens when 10 layers are created with wire at the rate of 20 windings per layer, and then 10 windings are applied just on the 11th layer.



10 windings just on the final layer (11th layer)

**Programming Example**

```

N000 P000 XY
N010 G32 X7200.0 Y50.0 F2000 L10
N020 G32 X3600.0 Y50.0 F2000 L1
N030 G79

```

**Explanation****N010**

Specifies  $360.0^\circ \times 20$  revolutions =  $7200.0^\circ$  on the X axis in order to get 20 windings per layer. It also specifies L10 in order to get 10 winding layers and because operation is in Pass Mode (default value for interpolated operation) it executes N020 without a break.

**N020**

Specifies  $360.0^\circ \times 10$  revolutions =  $3600.0^\circ$  on the X axis in order to get 10 windings per layer.

## Executing MC Programs from the Ladder Program

This section describes ladder programs that will execute G-language MC programs. Use the following procedure to execute MC programs.


- 1,2,3... 1. Set the MC Unit to Automatic Mode. (Turn ON bit 01 of word n+3.)
2. Set the program number of the desired MC program. (Word n+2)
3. Read the program number from word n+2 to the MC Unit. (Turn ON bit 07 of word n+3.)
4. Turn ON the Cycle Start Bit to execute the MC program specified in word n+2. (Turn ON bit 02 of word n+3.)

In this example procedure, task 1 is executed. The following table shows the equivalent IR Area control bits and IR Area words for tasks 2 to 4.

Task	Automatic Mode Bit	Program number	Program Number Read Bit	Cycle Start Bit
2	n+5: bit 01	n+4	n+5: bit 07	n+5: bit 02
3	n+7: bit 01	n+6	n+7: bit 07	n+7: bit 02
4	n+9: bit 01	n+8	n+9: bit 07	n+9: bit 02

### Ladder Programming Example


The following ladder program executes Task 1 in the MC Unit.





**Note** When executing a positioning operation in the MC program, all of the axes being used must be servo-locked (Servo-lock ON Flags must be turned ON), so be sure to add a condition like R4 in the programming example above.

**Timing Chart**



# Appendix C

## Basic Position Operations

This section explains the basic positioning operations executed by the MC Unit.

Overview .....	2
1 Summary of Operations.....	2
PTP Control.....	3
Linear Interpolation .....	5
Circular Interpolation .....	8
Helical Circular Interpolation .....	9
Interrupt Feeding .....	10
Traverse Function.....	12
Operating Modes .....	13
1 Stop Mode .....	14
2 Pass Mode .....	15
3 In-position Check OFF Mode.....	18
Changing Parameters.....	21
Stopover Function .....	21
CPU Unit Interrupt Processing .....	22
Override Function.....	23
Resetting the Error Counter.....	24
Servo Lock and Unlock .....	27
1 Timing Charts.....	27
2 Related System Parameters .....	28
Backlash Correction .....	29
1 Setting Backlash Correction .....	30
Automatic Loading .....	32
1 Executing Automatic Loading.....	33
2 Related Bits in the PC Interface Area.....	34
Present Position Preset .....	35
1 Executing Present Position Preset .....	36
Electronic Gear Function.....	37
1 Setting the System Parameters .....	37
2 Related Bits .....	39
Acceleration and Deceleration Curves .....	39
Unlimited Feeding .....	41
1 Setting System Parameters .....	41
2 Stopping .....	42

## Overview

This section describes the operations required for basic positioning with an MC Unit, and explains how to use them. It also explains the functions that have been newly added or changed from those of the earlier C200H-MC221 MC Unit.

There are four ways to execute operations, as follows:

- Running a G-language program.
- Executing operations with the PC Interface Area in the CPU Unit.
- Executing operations with the Command Area.
- Setting system parameters

### Notation

The bit status is indicated as follows in the explanations of positioning operations:

↑: A transition in the bit from 0 (OFF) to 1 (ON) (See note.)

↓: A transition in the bit from 1 (ON) to 0 (OFF) (See note.)

1: ON

0: OFF

**Note** Transitions in bits are determined in the MC Unit and are not always detectable when using the DIFU and DIFD instructions in the program in the CPU Unit.

## 1 Summary of Operations

Operation name	Basic function	Mode	Execution method
PTP control	Positions each axis independently	Automatic	G language (G00)
Linear interpolation	Performs linear interpolation on 1, 2, 3, or 4 axes (1 or 2 axes for MC221). The specified axes move simultaneously. The feed rate can be specified.	Automatic	G language (G01)
Circular interpolation	Positions using two axes, following an arc from the specified starting point to the specified end point.	Automatic	G language (G02/G03)
Helical circular interpolation	Adds another axis in parallel to circular interpolation.	Automatic	G language (G02/G03)
Interrupt feeding	Feeds along an axis for a fixed distance when an external interrupt is input. Feeding is also possible by specifying a given travel distance even when no interrupt is input.	Automatic	G language (G31)
Traverse	Used for winding machine operations	Automatic	G language (G32)
Operating mode	Any of the following modes can be specified for positioning operations: Stop Mode, Pass Mode, or In-position Check OFF Mode.	Automatic	G language (G10, G11, G13), system setup
Change parameter	Changes servo system parameters using G language.	Automatic	G language (G69)
Stopover	Outputs an M code or D code at a specified position during axis operation.	Automatic	G language (G00, G01)
CPU Unit interrupt processing	Executes an interrupt program with the D code (output with the stopover operation) as the interrupt program number.	Automatic	G language (D code output)
Override	Changes the speed by applying a specified factor.	Automatic, manual	Bit designation


Operation name	Basic function	Mode	Execution method
Error counter reset	Forcibly resets the error counter to zero, and stops axis operation.	Automatic, manual	Bit designation
Servo-lock	Creates a position loop at the MC Unit.	Manual	Bit designation
Servo-unlock	Releases the position loop at the MC Unit.	Automatic, manual	Bit designation
Backlash correction	Compensates for backlash in the mechanical system.	Automatic, manual	Command Area designation, CX-Motion
Automatic loading	Downloads G-language programs, position data, and system parameters to the MC Unit from an external memory device connected to a personal computer running CX-Motion.	Automatic, manual	Command Area designation, CX-Motion
Present position preset	Presets the present position to any specified value.	Manual	Command Area designation
Electronic gear	Sets the per/pulse ratio for an MPG or sync encoder.	Manual	System parameter setting (by IOWR or CX-Motion)
Acceleration/deceleration curve	Specifies the acceleration and deceleration method for how each axis is started or stopped.	Automatic, manual	System parameter setting (by CX-Motion only)
Unlimited feeding	Specifies control for an axis to be fed continuously, such as for a conveyer, for example.	Automatic, manual	System parameter setting (by CX-Motion only)
Stop	Describes how to stop the axis operation.	Automatic, manual	Bit designation, software limit (system parameter), external input (emergency stop, limit input), etc.

## PTP Control

### Overview

**Mode:** Automatic; **Method:** G language (G00) Positioning each axis independently from the other axes is called PTP control. Each axis moves at the preset feed rates: at the acceleration for the preset acceleration time, the maximum feed rate, and the deceleration for the preset deceleration time.

For example, suppose a control program is executed for moving from the origin to the X-axis coordinate of 100 and Y-axis coordinate of 50. If the feed rates, the acceleration times, and the deceleration times are the same for both axes, X-axis and Y-axis movements will be as illustrated below.



The illustration shows movements when the high-speed feed rate for the X axis is set to the same feed rate as the Y axis.

Both the X-axis and Y-axis move to a coordinate of 50 over the same duration of time. At this point, the Y-axis stops and the X-axis moves to a coordinate of 100.

Jogging in the Manual Mode is also performed using PTP control using the maximum jogging feed rate.


### Acceleration Time and Deceleration Time

Acceleration and deceleration times under the PTP control are as follows:

Acceleration time: Time required until the single axis speed reaches the maximum feed rate

Deceleration time: Time required until the speed control voltage drops to zero from the maximum feed rate of the single axis.


The acceleration time and deceleration time (feed rate parameters) are set either from the CX-Motion or by using IOWR in the ladder program.



Overrides can be set to alter the acceleration time and deceleration time. The acceleration speed, however, will remain constant.

### Triangular Control

If the travel time is shorter than the sum of acceleration time and deceleration time, triangular control will occur as shown below.



The ratio of acceleration time and deceleration time in the triangular control will be the same as the ratio of acceleration time and deceleration time set in the feed rate parameters.


# Linear Interpolation

## Overview

**Mode:** Automatic; **Method:** G language (G01)

Positioning with linear interpolation produces a straight line that connects a preset starting point to a preset end point using all specified axes (X to U).

Linear interpolation from the point A to the point B will be as shown below when using the X and Y axes.



F: Designated interpolation feed rate

Fx: Interpolation feed rate of the X axis based on F

Fy: Interpolation feed rate of the Y axis based on F

Ta: Interpolation acceleration time

Td: Interpolation deceleration time

Fx and Fy can be expressed as follows:

$$F_x = L_x / L \times F$$

$$F_y = L_y / L \times F$$

Where, L is the travel distance in the specified locus, Lx is the travel distance along the X-axis, and Ly is the travel distance along the Y-axis.

## Interpolation Acceleration and Deceleration Times

Interpolation acceleration and deceleration times for linear interpolation are defined as follows:

Interpolation acceleration time: Time required to reach the specified interpolation feed rate on the composite axial locus.


Interpolation deceleration time: Time required until the speed control voltage drops to zero from the specified interpolation feed rate on the composite axial locus.

The acceleration time and deceleration time (feed rate parameters) are set either from the CX-Motion or by using IOWR in the ladder program.

Unlike PTP control, linear interpolation acceleration and deceleration times are not affected by the speed. Acceleration changes according to the movement to satisfy the preset interpolation acceleration and deceleration times.


### Constant Acceleration Mode

When positioning is executed using linear interpolation, the normal operation (i.e., the CX-Motion default setting) is for positioning to accelerate at the interpolation acceleration time until the specified interpolation feed rate is reached, and for positioning to decelerate at the interpolation deceleration time. Unlike PTP control, the acceleration or deceleration time is not shortened according to the speed (except for triangular control).



The Constant Acceleration Mode is provided to shorten the positioning time when only one axis is used for linear interpolation. This mode is normally set to OFF (i.e., it is turned OFF in the CX-Motion default settings). When it is turned ON (enabled), positioning will be executed at acceleration and deceleration times according to the interpolation feed rate, as shown in the following diagram. When linear interpolation is executed for two or more axes, positioning will accelerate and decelerate at the interpolation acceleration and deceleration times (as shown in the above diagram) regardless of the interpolation feed rate and even if the Constant Acceleration Mode is turned ON (enabled).

In the following diagram, linear interpolation is executed for one axis only with the Constant Acceleration Mode turned ON.



Acceleration time  $T_a = \text{Specified interpolation feed rate} \times \text{interpolation acceleration time} / \text{maximum interpolation feed rate}$

Deceleration time  $T_d = \text{Specified interpolation feed rate} \times \text{interpolation deceleration time} / \text{maximum interpolation feed rate}$


**Note** 1. The interpolation acceleration time and the interpolation deceleration time use the acceleration and deceleration times set in the system parameters or the times that are changed in the G-language program. (The times can be changed by G69.)

2. The maximum interpolation feed rate uses the value set in the system parameters.

### Triangular Control

When the mode is set to the Stop Mode and if the travel time is shorter than the sum of the interpolation acceleration time and the deceleration time, triangular control will be performed, just as it is for PTP control.

When the mode is set to the Pass Mode, the travel time will not become shorter than the preset interpolation acceleration and deceleration times, but the speed will become slower than the designated feed rate.





The ratio between the interpolation acceleration time and the deceleration time for triangular control is equal to the ratio between the preset interpolation acceleration time ( $T_a$ ) and the deceleration time ( $T_d$ ).  $T_d'/T_a' = T_d/T_a$

## Circular Interpolation


### Overview

**Mode:** Automatic; **Method:** G language (G02, G03)

Positioning for circular interpolation is performed using two axes from a starting point to an ending point and traveling through a circular arc.

### Basic Concept


Circular interpolation is achieved by repeating successive linear interpolation along straight lines drawn by dividing a circular arc (in the shape of a polygon). The actual locus of circular interpolation is as shown below. The radius of the locus of actual movements is smaller than the radius of the arc due to accumulated pulses.



The interpolation acceleration time, the interpolation deceleration time, and triangular control are the same as for linear interpolation.

Refer to Linear Interpolation for details on interpolation acceleration time, interpolation deceleration time, and triangular control.

**Note** If positioning for circular interpolation is performed at high speed, the radius of the locus of actual movements will be reduced. This can also be improved by setting feed forward gain in the servo system. For details, refer to Changing Parameters.



# Helical Circular Interpolation

## Overview


**Mode:** Automatic; **Method:** G language (G02, G03)

Helical circular interpolation adds another axis to circular interpolation. It cannot be used with CS1W-MC221 MC Units.

With earlier MC Unit models, helical circular interpolation was limited to a single turn, but the CS1W-MC421's multiturn capability makes helical operations easier.

## Basic Concept

Similar to circular interpolation, helical circular interpolation performs control operations by dividing a 3-dimensional circular arc in the shape of a polygon. The helical circular interpolation locus is as shown below for circular interpolation executed for the X and Y axes and the Z-axis added as a supplemental axis.



The Z-axis feed rate is obtained by the following equation:

$$\text{Feed rate} = (\text{Specified interpolation feed rate} \times \text{Z-axis length}) / (\text{Arc length})$$

The interpolation acceleration time, the interpolation deceleration time, and triangular control are the same as for linear interpolation.

With helical circular interpolation, the travel time is calculated giving priority to the feed rate along the arc. For that reason, the feed rate of the supplemental axis may exceed the maximum interpolation feed rate set in the system parameters. If this occurs, a SUP AXIS SP OVER (supplemental axis speed overflow) error will be generated and operation will be stopped. Lower the feed rate if this error occurs.


# Helical Operation

```

N010 G90. . . . . Absolute specification
N011 G17. . . . . XY circular plane specification
N012 G02 X100 Y200 Z20 I0 J0 F200 L4

```

↑ Number of turns (4 in this case)  
 ↑ Feed pitch for one turn in Z-axis direction  
 ↑ Stop position for 5th turn



## Interrupt Feeding

### Overview

**Mode:** Automatic; **Method:** G language (G31)


Interrupt feeding is a control operation that feeds an axis for a fixed distance, using speed control until an external signal is input and then switching to position control at that point.

Interrupt feeding can be performed either at constant speed or two-stage speed.

It is also possible to specify a travel distance at which to stop when there is no interrupt input. Operation will normally stop with an error (program execution interrupted) after positioning, but an S option can be used to execute the next block without an error occurring.


### Constant Speed

In this example, only speed reference 1 is specified. The X axis is moved by 100 mm at 200 mm/s (speed reference 1) with speed control.




### Two-stage Speed

In this example, speed reference 2 is specified. The X axis is moved by 100mm while the speed of the X axis is decelerated to 100mm/s from 200 mm/s.



### Specifying an Amount of Travel for When No Interrupt Is Input



If no interrupt signal is received, operation will stop with an error (program execution interrupted) after positioning. If the S option is specified, however, the next block will be executed without an error occurring.

Example: G31 x 100/200 F200 S

- Notes**
1. Interrupt feeding can be used to move only one axis.
  2. An external signal for interrupt feeding can be input via general inputs1 to 4 of the MC Unit.

Input number	MC221	MC421
General input 1	For X-axis interrupt feeding	For X-axis interrupt feeding
General input 2	For Y-axis interrupt feeding	For Y-axis interrupt feeding
General input 3	---	For Z-axis interrupt feeding
General input 4	---	For U-axis interrupt feeding


## Traverse Function

### Overview

**Mode:** Automatic; **Method:** G language (G32)

The traverse function is a special G-language command (G32) that is provided for winding machine operations.


### G Code Specifications




The setting for 100 windings per layer is 36000 because one winding is equivalent to 360°.

### Example Application

In this example, the wire is wound around a spool on a winding machine. The spool is turned in a fixed direction and the traverse axis is operated according to the settings for the traverse function.



## Speeds for Each Axis during Traverse Operation



## Operating Modes

## Overview

**Mode:** Automatic; **Method:** G language (G10, G11, G13), system parameters

There are three operating modes for positioning: Stop Mode (G11), Pass Mode (G10), and In-position Check OFF Mode (G13).

Operating mode	Function
Stop Mode	When continuous operations are specified, the Stop Mode determines when positioning has been completed and then starts the next operation.
Pass Mode	When continuous operations are specified, the Pass Mode proceeds smoothly to the next operation without determining whether the present positioning has been completed.
In-position Check OFF Mode	When positioning is executed, the In-position Check OFF Mode starts the next operation without determining whether positioning has been completed. This is the only difference between this mode and the Stop Mode.

The operating mode can be changed by the operations and G codes shown in the following table. Once the operating mode has been changed, the new mode will remain in effect until it is again changed by one of these methods.

## Methods for Changing the Operating Mode

Name	G code	Operation mode
Power supply reset or restarting the MC Unit as a Special I/O Unit	None	Pass Mode
Executing the main program from the beginning	None	Pass Mode
ORIGIN SEARCH	G28	Pass Mode
REFERENCE ORIGIN RETURN	G26	Pass Mode
WORKPIECE ORIGIN RETURN	G27	Pass Mode
PASS MODE	G10	Pass Mode
STOP MODE	G11	Stop Mode
IN-POSITION CHECK OFF MODE	G13	In-position Check OFF Mode

Among those G codes that execute positioning actions, there are some for which any of the three operating modes can be selected and some for which positioning is always executed in Stop Mode. These G code operations are shown in the following table

G code	Name	Operating mode		
		Stop Mode	Pass Mode	In-position Check OFF Mode
G00	POSITIONING	●	---	---
G01	LINEAR INTERPOLATION	●	●	●
G02	CIRCULAR INTERPOLATION (CLOCKWISE)	●	●	●
G03	CIRCULAR INTERPOLATION (COUNTERCLOCKWISE)	●	●	●
G26	REFERENCE ORIGIN RETURN	●	---	---
G27	WORKPIECE ORIGIN RETURN	●	---	---
G28	ORIGIN SEARCH	●	---	---
G30	SPEED CONTROL	●	---	---
G31	INTERRUPT INCHING	●	---	---
G32	TRAVERSE	●	●	●

●: Modes that can be specified.

---: Positioning is always executed in Stop Mode regardless of which operating mode is specified.

## 1 Stop Mode

If the Stop Mode is specified for continuous positioning operations, one operation is followed by the subsequent operation after the first positioning operation has been completed.

The following illustration shows changes in the time, speed, and pulses when the axis is controlled as shown below.

### Example:


N010 G00 X100

Moves X axis to 100-mm point by PTP control

N011 G00 X200

Moves X axis to 200-mm point by PTP control

Speed/error counter pulses



P: In-position width

T: Time required for determining whether positioning is completed or not

Positioning is completed when the error counter pulse falls within the in-position zone. By using the In-position Check OFF function, it is also possible to start the next operation without waiting for positioning to be completed. In this case, the operation is executed within 4ms.

## 2 Pass Mode

If the Pass Mode is specified for continuous positioning operations, one operation is followed by the subsequent operation without any pause in motion, i.e., without stopping to determine whether positioning is completed or not. When the power is turned ON, this mode is automatically selected.

The following illustrations show changes in the speed in the Stop Mode and the Pass Mode when the continuous operation commands are given as shown be-low.

The Pass Time Mode Selection in the Unit parameters can be used to select, when Pass Mode is used, whether positioning will move to the next operation in the interpolation acceleration time or the interpolation deceleration time of the immediately preceding operation. Only in case of linear interpolation for one axis, acceleration during acceleration or pass operation may be set to a constant speed by selecting the Constant Acceleration Mode.


When the Constant Acceleration Mode is enabled, this mode will be given priority for single-axis pass operations regardless of the setting for the Pass Time Mode Selection.

The settings for the Pass Time Mode Selection and the Constant Acceleration Mode are made using CX-Motion. The contents of these settings can only be read from the ladder program using the IORD instruction.

### Example:

```
N010 G01 X100 F10
      Moves X axis to 100-mm point at 10 mm/s via linear interpolation
N011 G01 X300 F20
      Moves X axis to 300-mm point at 20 mm/s via linear interpolation
      ⋮
```


### In Stop Mode





### In Pass Mode with Acceleration Time

In this example, the Pass Time Mode Selection is set for interpolation acceleration time. Positioning moves to the next operation in the interpolation acceleration time of the immediately preceding operation.




**Note:** The acceleration/deceleration curve will be trapezoidal even if an S-curve is specified.

When the Pass Mode is specified as the operating mode, the time required for movements is reduced because there is no need to determine whether positioning has been completed.

### In Pass Mode with Deceleration Time

In this example, the Pass Time Mode Selection is set for interpolation deceleration time. Positioning moves to the next operation in the interpolation deceleration time of the immediately preceding operation.




**Note:** The acceleration/deceleration curve will be trapezoidal even if an S-curve is specified.

When the Pass Mode is selected, the time required for movements is reduced because there is no need to determine whether positioning has been completed.

### In Constant Acceleration Mode

The Constant Acceleration Mode is enabled when linear interpolation is executed for one axis only. To use this mode, turn ON the Constant Acceleration Mode setting in the Unit parameters.

If a pass operation is executed in the Constant Acceleration Mode, the acceleration and deceleration times will always be constant as shown in the following diagram.



Acceleration  $\alpha$  = Max. interpolation feed rate / interpolation acceleration time

Deceleration  $\beta$  = Max. interpolation feed rate / interpolation deceleration time

- Note:** 1. The interpolation acceleration time and the interpolation deceleration time use the acceleration and deceleration times set in the system parameters or the times that are changed in the G-language program. (The times can be changed by G69.)
2. The acceleration and deceleration times when pass operations are executed increase or decrease according to the amount of change in the interpolation feed rate. The times can be determined by the following equations:

Acceleration time =  $\frac{\text{Change in interpolation feed rate} \times \text{Interpolation acceleration time}}{\text{Maximum interpolation feed rate}}$


Deceleration time =  $\frac{\text{Change in interpolation feed rate} \times \text{Interpolation deceleration time}}{\text{Maximum interpolation feed rate}}$

### Block Ends in Pass Mode

In Pass Mode, the ends of G-language blocks are treated as shown below.


### When Constant Acceleration Mode Is OFF

Pass operations are executed as shown in the following diagram when the Constant Acceleration Mode is OFF.



### When Constant Acceleration Mode Is ON

Linear interpolation pass operations are executed as shown in the following diagram when the Constant Acceleration Mode is ON. The next block is executed after the demand position is created.



**Note:** Execution of the next block is started as soon as the demand position has been created.

## 3 In-position Check OFF Mode


By specifying the G13 code (IN-POSITION CHECK OFF MODE), the next positioning operation can be started without waiting for the present one to be completed. This allows high-speed pick-and-place operations to be performed.

This function contrasts with the Stop Mode, in which the next positioning operation is not started until the present one has been completed.

To have positioning wait until the present operation is completed before the next one is started, execute G11 (STOP MODE).

### When In-position Check OFF Mode Is Enabled

```
N010 G13 ..... In-position Check OFF statement
N020 G01 X200 F200
N030 G01 X400 F200
```




### Constant Acceleration Mode Limitations


The Constant Acceleration Mode can be used only for single-axis linear interpolation. When two or more axes are operated following a linear interpolation operation in the Constant Acceleration Mode, the next operation will be executed after positioning has been completed regardless of the operating mode set-ting.

The following diagrams provide four examples of operations in the Constant Acceleration Mode.


**Example 1: Operation with One Axis Only**




**Example 2: Pass Operation with One Axis Only**



**Example 3: Operating from One Axis to Two Axes**



**Example 4: Operating from One Axis to Two Axes**



### Pass Mode Limitations with Linear Interpolation, Circular Interpolation, and Traverse Operations

Linear interpolation, circular interpolation, and traverse operations are interpolation commands that can be specified for three operating modes. When these interpolation commands are continuously executed in Pass Mode, there are cases where pass operations cannot be performed (depending on the combination of the immediately preceding operation and the present operation). These cases are shown in the following table.

The preceding and present operations for the table shown below are as follows:

Preceding operation: N010 G01 X1000 Y100 F200

Present operation: N020 G01 Y2000 Y-100 F300

Pass: Indicates normal Pass Mode operations. Positioning is executed with pass operations from the preceding operation to the present operation.

Stop: Indicates normal Stop Mode operations. The present operation is executed after the positioning is completed for the preceding operation.

Preceding operation	Present operation				
	Linear interpolation	Circular interpolation		Traverse	
		Same plane	Different planes	Same axis	Different axes <sup>1</sup>
Linear interpolation	Pass	Pass	Pass	Pass	Pass
Circular interpolation	Pass	Pass	Stop <sup>2</sup>	Stop <sup>3</sup>	Stop <sup>3</sup>
Traverse	Pass	Stop <sup>3</sup>	Stop <sup>3</sup>	Stop or Pass <sup>4</sup>	Stop <sup>5</sup>

- Note**
1. “Different axes” indicates that the axes that are operated are changed, as when four axes are used for one task and linear interpolation is executed for the X and Y axes followed by traverse operation for the Z and U axes.
  2. This indicates cases such as executing ZU-plane circular interpolation after XY-plane circular interpolation.
  3. This indicates cases such as executing traverse operations after circular interpolation, or circular interpolation after traverse operations.
  4. The operating mode for the traverse operation will differ according to the following circumstances.  
If the rotating axes are operated in opposite directions, the preceding traverse operation will be performed in Stop Mode.  
If the rotating axes are operated in the same direction, positioning will be executed in Pass Mode.
  5. When four axes are used for one task, the traverse operation is executed first for the X and Y axes and then for the Z and U axes.

#### Other Limitation

In Pass Mode and In-position Check OFF Mode, the G-language program is read in advance. In addition, the pre-reading stops in the following situations, so the operations are always executed as if in Stop Mode, regardless of the actual operating mode.

Commands where operation stops following command	Commands where previous interpolation operation stops (G01, G02, G03, G32)
G01, G02, G03, including M000 to M499	G00 (PTP)
	G01, G02, G03, including # option number specification
	G04 (DWELL TIMER)
	G29 (ORIGIN UNDEFINED)
	G30 (SPEED CONTROL)
	G31 (INTERRUPT FEEDING)
	G54 (CHANGE REFERENCE COORDINATE SYSTEM PV)
	G79 (PROGRAM END)
	Independent commands M000 to M999
	Independent commands D000 to D255

## Changing Parameters

### Overview

**Mode:** Automatic; **Method:** G language (G69)

The servo system gain can be changed by using CHANGE PARAMETER (G69).

This function can be used, for example, to increase the accuracy of circular interpolation when position loop feed forward gain is enabled during circular interpolation.

The following parameters can be changed using this function:

#### Changeable Servo Parameters


- #5 Position loop gain
- #6 Position loop feed forward gain
- #7 In-position
- #8 Accumulated pulse warning value

#### Changeable Feed Rate Parameters

- #1 Acceleration time
- #2 Deceleration time
- #3 Interpolation acceleration time
- #4 Interpolation deceleration time

The changed servo parameters and feed rate parameters go into effect immediately after G69 is executed.

N010	G01	X0	Y100	F100			
N020	G69	#6/50	..... Sets the position loop feed forward gain to 50%.				
N030	G02	X100	Y100	I50	J0	F200	} Increases locus accuracy by enabling position loop feed forward gain when circular interpolation is executed.
N040	G02	X200	Y100	I50	J0	F300	
N050	G69	#5/X0	..... Returns the position loop feed forward gain to 0%.				
N060	G01	X-100	Y-200	F100			



## Stopover Function

### Overview

**Mode:** Automatic; **Method:** G language (G00, G01, etc.)

The stopover function outputs an M code or D code, without stopping axis operation, when the axis has traveled for a specified distance (determined by encoder feedback present position). Before the operation is completed, tact time can be improved by using this function to control peripheral devices.

This function can be applied to G codes for all operations. Either D codes or M codes can be used, but not both.

Case 1: N010 G01 X100 F200 D100/X50

In this case, D code 100 is output when the X-axis is moved by 50 mm in the direction of the specified position.

Case 2: N010 G01 X200 F200 M600/X100


In this case, M code 600 is output when the X-axis is moved by 100 mm in the direction of the specified position.

Case 3: N010 G01 X100 F200 M700 D30

In this case, D30 and M700 are output when block N010 is completed (i.e., when the X axis is moved by 200 mm).

Wrong: N010 G01 X100 F200 M800 D100/X50  
If the stopover function is used in this way, an error will be generated by CX-Motion.

#### Operation Example



After the D code or M code, place a “/” followed by the axis name and the amount of travel.

Axis name: Specify X, Y, Z, or U.

Amount of travel: Specify the amount of travel, without sign, in the direction of the demand position (determined by the present position). The amount of travel can be written as follows:

- Number (0 to 39,999,999)
- A0000 to A1999
- (E00) to (E31)

## CPU Unit Interrupt Processing

### Overview

**Mode:** Automatic; **Method:** G language (D code output)

It is possible to set a D code in the G-language program related to positioning as an interrupt to the CPU Unit. The specified D code is output after positioning is completed, and the CPU Unit executes an interrupt task taking the D code (0 to 255) as the task number.

When the stopover function is used, this D code can be output during operation without stopping the operation. For details on the stopover function, refer to Stopover Function.

**Note** This interrupt function can be used only when the MC Unit is mounted to the CPU Backplane. It cannot be used if the MC Unit is mounted to an Expansion I/O Rack.


When an interrupt task is used in the CPU Unit, a setting must be made in the PC Setup. For details, refer to the manual for the CPU Unit.

Case 1: N010 D100

Case 2: N010 G01 X100 F200 D100

Case 3: N010 G01 X100 F100 M001 D100

## Case 3 Operation



## Override Function

## Overview

**Mode:** Automatic or Manual; **Method:** Bit designation

The override function is designed to change the operation speed by multiplying the speed that is set in the system parameters or G commands by a specified factor. Setting methods are different depending on whether the PTP control is used or interpolation is used.

The override function can be used for the following G codes:

G00: PTP CONTROL POSITIONING

G01: LINEAR INTERPOLATION

G02/G03: CIRCULAR INTERPOLATION

G26: REFERENCE ORIGIN RETURN

G27: WORKPIECE ORIGIN RETURN

G28: ORIGIN SEARCH (but only for movement for an origin offset)


G30: SPEED CONTROL

G31: INTERRUPT FEEDING

G32: TRAVERSE

## Override in PTP Control

The override in the PTP control can be set to a value between 0.1% and 100.0%. “100%” means the maximum feed rate designated by the feed rate parameter. The override function is used when the maximum feed rate is too fast. For example, if the override is set to 50%, the travel speed drops to half the maximum feed rate.




The acceleration remains constant even if the speed is changed by using the override function. As a result, both the acceleration time and the deceleration time are proportionally reduced.



**Override in CP Control**

In interpolation control, the designated interpolation feed rate is used as the maximum feed rate. The override for the interpolation feed rate can be set to a value between 0.1% and 199.9%. If the result set by using the override function to over 100% exceeds the maximum interpolation feed rate, the maximum interpolation feed rate is used instead.

**Example: Execution in Stop Mode**

**Note** With linear or circular interpolation in either the Pass Mode or the In-position Check OFF Mode, the speed cannot be changed in real time during operation.

**Setting an Override**

To execute an override, set the override in the PC Interface Area and turn ON the Override Setting Bit. The override will then be applied to subsequent operations.

**PC Interface Area**

Name	MCU Model	Word				Bits	Description
		X axis	Y axis	Z axis	U axis		
Override	MC421 MC221	n+10 n+6	n+12 n+8	n+14 ---	n+16 ---	00 to 15	Override(4 digits Hex) Setting range: 0000 to 07CF Hex (0000 to 1999: 0 to 199.9%)
Override setting	MC421 MC221	n+11 n+7	n+13 n+9	n+15 ---	n+17 ---	12	1: Override enabled 2: Override disabled

Even if an override is set for a given axis, it will be disabled if the Override Setting Bit is turned OFF.

## Resetting the Error Counter

**Overview**


**Mode:** Automatic or Manual; **Method:** Bit designation

The error counter reset function resets the error counter to 0 and stops axis operation. This function is enabled when no speed reference is being provided to the Servo Driver (after an deceleration command is output). It can be used for molding applications (machine press control).


This function can be used with the MC Unit in either Automatic or Manual Mode, and it is executed from the PC Interface Area. In the examples shown here, the Automatic Mode is used.

**Stop Mode**


N000 P000 X  
 N010 G11 ← Specifies the Stop Mode.  
 N020 G01 X100 F100  
 tN030 G01 X200 F100  
 N040 G01 X300 F100

**Pass Mode**

N000 P000 X  
 N010 G01 X100 F100 ← Initial value: Pass Mode  
 N020 G01 X400 F150  
 N030 G11 ← Specifies the Pass Mode.  
 N040 G01 X100 F50

**In-position Check OFF Mode**

N000 P000 X  
 N010 G13 ← Specifies the In-position Check OFF Mode.  
 N020 G01 X100 F100  
 N030 G01 X200 F100  
 N040 G11 ← Stop Mode designation  
 N050 G01 X300 F100




- Notes**
1. The program cannot be executed while the error counter is ON.
  2. The error counter reset can be used when jogging, origin search, and other operations are executed in Manual Mode.

In the following example, linear interpolation is executed in Stop Mode on the X axis. The operation and timing would be the same for either linear or circular interpolation using two or more axes.

```

N000 P000 X
N010 G11 ← Specifies the Stop Mode.
N020 G01 X100 F100
N030 G01 X-100 F100
...

```



#### PC Interface Area

Name	MCU Model	Word				Bits	Description
		X axis	Y axis	Z axis	U axis		
Error Counter Reset	MC421	n+11	n+13	n+15	n+17	04	0 to 1: Error counter reset 2: Functions can be received.
	MC221	n+7	n+9	---	---		

# Servo Lock and Unlock

## Overview

**Mode:** Automatic (servo lock); Automatic or Manual (servo unlock);

**Method:** Bit designation

This function creates (servo lock) or releases (servo unlock) an MC Unit position loop. In addition to the servo lock and unlock operations available for earlier MC Unit models, it is also possible to set general outputs as brake signal outputs and to turn them ON and OFF in sync with servo lock and unlock. The ON and OFF times can also be set as required.

If the machine parameters are set for a wiring check to be performed, it will be performed at power up and with the first servo lock. If everything is normal, the wiring check will not be performed with the next servo lock. Servo lock and unlock are executed from the PC Interface Area.


## PC Interface Area

Name	MCU Model	Word				Bits	Description
		X axis	Y axis	Z axis	U axis		
Servo Lock	MC421	n+11	n+13	n+15	n+17	09	↑ : Begin servo lock
Servo Unlock	MC221	n+7	n+9	---	---	10	↓ : Begin servo unlock


## 1 Timing Charts

The following timing charts show the servo lock and servo unlock functions when the brake signal is set and the wiring check is enabled.

### Servo Lock



## Servo Unlock



## 2 Related System Parameters

The system parameters required for the output port settings and the wiring check are all set using CX-Motion. The IORD instruction can be used for reading only. Refer to the addresses shown in the following tables.

## Unit Parameters

Address		R/W	Name	Configuration
MC221	MC421			
0FA6 (4006)	0FA6 (4006)	R	Output port setting	<div style="text-align: center;"> <p>Output port setting</p> </div> <p>Specifies whether the output ports will be used for general output or brake signal output. Bits 00 to 03 correspond to output ports 1 to 4 if the ports are used for general output, and to axes X through U if the ports are used for brake signal output.</p> <div style="text-align: center;"> <p>Output port 1 (X axis) Output port 2 (Y axis) Output port 3 (Z axis) Output port 4 (U axis)</p> </div> <p>X = 0: General output, X = 1: Brake signal output</p>

## Unit Parameters


Address				R/W	Name	Configuration
MC221		MC421				
X axis	Y axis	Z axis	U axis			
107B (4219)	1094 (4244)	10AD (4269)	10C6 (4294)	R	Wiring check	<div>15 L+1 00 15 L 03 00</div> <div><div>0000000X</div></div> <div>Specifies whether the wiring check function is used. X = 0: The wiring check function is not used. X = 1: The wiring check function is used.</div>
107C (4220)	1095 (4245)	10AE (4270)	10C7 (4295)	R	Wiring check time	<div>15 L+1 03 00 15 L 07 00</div> <div><div>000000</div></div> <div>Wiring check time</div> <div>Specifies the wiring check time within a range of 0 to 99 (x 10 ms). Range: 00 to 63 Hex (0 to 99 [x 10 ms])</div>
107D (4221)	1096 (4246)	10AF (4271)	10C8 (4296)	R	Wiring check pulses	<div>15 L+1 03 00 15 11 L 00</div> <div><div>00000</div></div> <div>Wiring check time</div> <div>Specifies the number of pulses to check the wiring within a range of 0 to 999 pulses. Range: 000 to 3E7 Hex (0 to 999 [pulses])</div>

## Backlash Correction

## Overview


**Mode:** Automatic or Manual; **Method:** Command Area designation, CX-Motion

A backlash is a sudden backward movement of a driving axis that may be caused due to mechanical looseness as shown in the following illustration.




The positioning of a machine cannot be performed precisely if there is backlash.

As shown in the following illustration, for example, the position of a machine moved by 100 mm in the forward direction is different from that of the same machine moved by 100 mm in the reverse direction if there is a 1-mm backlash, even though there is no difference in position between the driving axes.



Backlash correction is a function for pre-registering the backlash space within a range of 0 to 10,000 pulses to minimize the positioning errors of machines moving in the forward or reverse direction to the same position, as shown in the following illustration. The setting is made with the backlash correction value in the servo parameters.



Backlash correction is executed either at power up or when the axis is moved in the opposite direction from the direction in which it first moves after a restart.

## 1 Setting Backlash Correction

Either CX-Motion or the IOWR instruction can be used to set backlash correction.

### Using CX-Motion

For details on using CX-Motion to make this setting, refer to the Section 1.

Using IOWR

To use IOWR to set the backlash correction, set the backlash correction address in the IOWR control code (C) and then transfer the backlash correction value to the MC Unit.

X axis: Address 11FC Hex (4604)


Y axis: Address 1215 Hex (4629)

Z axis: Address 122E Hex (4654)

U axis: Address 1247 Hex (4679)

**Specifications**

The following is a basic explanation of the IOWR instruction specifications for setting the backlash correction.




C: Control code, S: First source word, D: Destination unit number and total number of words to transfer.

Operand	Description
C	<div style="border: 1px solid black; padding: 5px; margin: 5px 0;">MC Unit address (Hex)</div> <p>Specifies the first address in the MC Unit to which data will be written.</p> <p>X axis: Address 11FC Hex (4604)  Y axis: Address 1215 Hex (4629)  Z axis: Address 122E Hex (4654)  U axis: Address 1247 Hex (4679)</p>
S	<div style="border: 1px solid black; padding: 5px; margin: 5px 0;">First source word</div> <p>Specifies the first word in the CPU Unit from which data is to be transferred.</p>
D	<div style="display: flex; justify-content: space-around; align-items: center; margin: 5px 0;"> <div style="border: 1px solid black; padding: 5px; text-align: center;">D+1 Total number of words to transfer (Hex)</div> <div style="border: 1px solid black; padding: 5px; text-align: center;">D Destination unit number (Hex)</div> </div> <p>Specify the destination unit number to which data will be transferred and the total number of words to transfer.</p> <p>Number of words to transfer:  Always 0002 Hex. (Refer to Transfer Data below.)</p> <p>Destination unit number:  MC221: 0000 to 005D Hex (Unit numbers 0 to 93)  MC421: 0000 to 005B Hex (Unit numbers 0 to 91)  Example: #0002003, when two words of data are transferred to Unit #3</p>

**Transfer Data**

Set the following data in the words beginning at the first source word, and execute the IOWR instruction.




Set the backlash correction value for the X and Y axes between 0000 and 2710 Hex (1 to 10,000).



**Programming Example**

In the following example for transferring data, the MC Unit is mounted to a CS1 PC and assigned unit number 0. In this example, the backlash correction value is set to 1,000 pulses, and the IOWR operands and the data to be transferred are assumed to be normal. When debugging, check the Error Flags from the ladder program.

**Ladder Program****Transfer Data (DM)**

D00100	03E8	← Backlash correction: 1000
D00101	0000	


**Automatic Loading****Overview**

**Mode:** Automatic or Manual; **Method:** Command Area designation, CX-Motion

A maximum of 100 programs and up to 2,000 blocks in all programs total can be saved. The automatic loading function is provided for additional programs in order to support applications requiring more program capacity. This function allows more programs or program blocks to be executed by treating external memory devices connected to a personal computer running CX-Motion as MC Unit memory.

The automatic loading function is executed by the IOWR instruction for the Command Area. Either Automatic Mode or Manual Mode can be used.

Any number from 1 to 10,000 can be specified as the job number. CX-Motion must be used to create MC programs and position data in advance for job numbers that are to be used.





**Explanation**

- 1,2,3...
1. The MC Unit's job number is always monitored by CX-Motion.
  2. Using the IOWR instruction, a new job number is written to the job number currently in the MC Unit.
  3. When CX-Motion detects the specified job number, the program and position data are downloaded to the MC Unit from the file for that job number created by CX-Motion.
  4. Before downloading the program and position data, CX-Motion deletes from the MC Unit all of the programs for all tasks. Then it downloads the program and position data for the specified job number.
  5. When the downloading has been completed, the CPU Unit is notified from the MC Unit. While the program and position are being downloaded, the Autoloading Bit in the PC Interface Area turns from OFF to ON, and when the downloading is completed normally it turns from ON to OFF.

## 1 Executing Automatic Loading

To execute automatic loading, set one of the following addresses for the control code (C) of the IOWR instruction and then transfer the job number to the MC Unit.

The Autoloading Time Up time is set with CX-Motion. The IORD instruction can be used for reading only.


Address		R/W	Name	Configuration
MC221	MC421			
17D8 (6104)	17D8 (6104)	R/W	Specifying automatic loading	 <p>This parameter is used when batch downloading programs and position data to an MC Unit from the external memory device of a personal computer with CX-Motion.</p> <p>X (Job No.) Specifies a job number within a range from 0001 to 2710 Hex (1 to 10,000).</p> <p>The following contents can be read from this address using an IORD instruction.</p> <p>X = 0000: Power supply ON, automatic loading completed normally X = 0001 to 2710 Hex (1 to 10,000): Specified job number or executing job number</p>
0FA9 (4009)	0FA9 (4009)	R	Teaching Box language/ autoload timeout	 <p>T.Box language Specifies whether the T.Box message is displayed in English or Japanese. (Only bit 0 is valid) X = 0: English, X = 1: Japanese</p> <p>Autoload timeout Specifies whether the time up time is displayed when the automatic loading function is used. Range: 00 to B4Hex (0 to 180 s) Time up will not be monitored if 00 is set.</p>

**Note** Programs and position data will not be properly downloaded to the MC Unit if the personal computer cable is disconnected or CX-Motion downloading is interrupted during execution of the automatic downloading function. If that occurs, perform the operation again.

### Ladder Programming Example

In this example, job number 100 is specified. The MC Unit is mounted to a CS1 PC and assigned unit number 0, and the job number to be transferred (job number 100) is stored in words D00100 and D00101. Both the IOWR operands and the data to be transferred are assumed to be normal.

When debugging, check the Error Flags from the ladder program.



### Transfer Data (DM)

D00100	0064	← Job number: 100
D00101	0000	


## 2

### Related Bits in the PC Interface Area

Bit name	Model	Words	Bit	Description
Autoloading Error Reset Bit	MC421 MC221	n n	05	↑: Error reset for automatic loading
Autoloading Flag	MC421 MC221	n+10 n+18	04	↑: Automatic loading begun. ↓: Automatic loading finished.
Autoloading Error Flag	MC421 MC221	n+10 n+18	05	↑: Error occurred during automatic loading ↓: Automatic loading error reset turned ON.

### Autoloading Flag


This flag turns ON when the data for the specified job number begins to be down-loaded as the result of executing the IOWR instruction. It turns OFF when all of the data for that job number has been downloaded.



### Autoloading Error Flag and Error Reset Bit

The Autoloading Error Flag turns ON when an error occurs during automatic loading. When the Autoloading Error Reset Bit is turned ON, the Autoloading Error Bit will turn OFF. Unless the cause of the error has been cleared, however, the Autoloading Error Flag will turn back ON again the next time the automatic loading is executed.

If communications are not restarted by the time the Autoloading Time Up set in the Unit parameters has elapsed, an error will occur and the Autoloading Error Flag will turn ON. If that occurs, the data transferred up to that point will be discarded.



**Note** The MC Unit does not monitor the time from when it receives the automatic loading command until the Autoloading Flag turns ON. There may be cases where the power to the personal computer is turned OFF or a cable is disconnected, so monitor this time from the ladder program.

## Present Position Preset

### Overview

**Mode:** Manual; **Method:** Command Area designation

The present position preset function is used to preset the preset position to any given value. With previous MC Unit models, it was executed from the PC Inter-face Area, but with the MC221 and MC421 it is executed by an IOWR instruction using the Command Area. It can only be used in Manual Mode, and will be ignored if used in Automatic Mode.

After the present position has been preset, the reference origin is established automatically, so there is no need to execute an origin search. It is also possible to set the present position as the origin by using the present position preset function to set the present position to "0."




### Caution

When present position preset is executed for an axis for which an absolute encoder is used, only the present position stored in the MC Unit will be preset. The present position stored in the absolute encoder will not be preset, and it will be automatically updated with the next servo-lock.

## 1 Executing Present Position Preset


To execute present position preset, set the following addresses for the IOWR instruction's control code (C) and then transfer the present position preset value to the MC Unit. For details on the Command Area, refer to 3-6 Command Area. For details on IOWR specifications, refer to 4 Data Transfer and Storage.

Address		R/W	Name	Configuration
MC221	MC421			
17DE (6110)	17DE (6110)	W	Presetting the X-axis present position	 <p>Sets the X-axis present position to any value and establishes the origin. The data is 32-bit signed binary data. L+1: Leftmost 16 bits, L: Rightmost 16 bits Range: FD9DA601 to 026259FF Hex (–39999999 to 39999999) The minimum setting unit is set to 2 (for 0.01), the display unit is set to 0 (for mm), and the reference origin offset is 3.99 [mm] (i.e., 399 x 0.01) if the data is 399.</p>
17DF (6111)	17DF (6111)	W	Presetting the Y-axis present position	Sets the Y-axis present position to any value and establishes the origin. The data configuration is the same as that for presetting the X-axis present position.
---	17E0 (6112)	W	Presetting the Z-axis present position	Sets the Z-axis present position to any value and establishes the origin. The data configuration is the same as that for presetting the X-axis present position.
---	17E1 (6113)	W	Presetting the U-axis present position	Sets the U-axis present position to any value and establishes the origin. The data configuration is the same as that for presetting the X-axis present position.

### Ladder Programming Example

In this example, the X-axis present position is set to 10,000. The MC Unit is mounted to a CS1 PC and assigned unit number 0, and the data to be transferred (i.e., the present position) is stored in words D00100 and D00101. Both the IOWR operands and the data to be transferred are assumed to be normal.

When debugging, check the Error Flags from the ladder program.




D00100	2710	← Present position preset value: 10000
D00101	0000	

## Electronic Gear Function

### Overview

**Mode:** Manual; **Method:** System parameter setting (IOWR or CX-Motion)

The electronic gear function is provided for operations such as using a Manual Pulse Generator (MPG) for handle feeding or using an absolute encoder for synchronizing axis feeding with a conveyer. Both the numerator and denominator can be specified, so this electronic gear function enables more precise feed control than was possible with previous MC Unit models.



## 1 Setting the System Parameters

### Setting MPG or Sync Encoder

Using CX-Motion, make the setting in the Unit parameters to determine whether an MPG or a sync encoder is to be used for pulse inputs.

The IORD instruction can also be used to read the parameter settings

This setting specifies the ratio for pulse input devices connected to the MPG or sync encoder. For the MPG, it is used to maintain a ratio of one. When it is set for a sync encoder, the ratio can be specified as 1, 2, or 4.

### Setting the Electronic Gear Ratio

When an MPG is used, the electronic gear ratio is the same as it was for previous MC Unit models.

The gear ratio for the MC221 and MC421 is set by CX-Motion or by an IOWR instruction. There are two ways to change the electronic gear ratio:

- Change the electronic gear combination using the PC Interface Area. (A maximum of four can be changed in this way.)
- Specifying the electric gear combination in the PC Interface Area, and then using an IOWR instruction to change that value directly. (The number of combinations is unlimited.)

Regardless of which of these methods is used, the change will go into effect immediately.

**Note** With the electronic gear function, when there is a remainder in the total when the input pulses are multiplied by the gear ratio, it is possible to achieve highly accurate synchronization by adding the remaining pulses to the next input pulses. If the electronic gear ratio is changed during a synchronized operation, however, the remainder will be taken as 0 and the calculation will begin with the new electronic gear ratio. For that reason there will be a temporary drop in speed from that which was in effect before the gear ratio was changed.

### Using CX Motion

For details on using CX-Motion to set the electronic gear ratio, refer to the Section 1.

### Using IOWR


Use the IOWR instruction to specify the following addresses for the control code, and set the numerator and denominator in any area. (Refer to the ladder programming example provided below.) The addresses are shown in hexadecimal, with their decimal number equivalents shown underneath in parentheses.

				R/W	Name	Configuration	Default setting
MC221		MC421					
113A (4410)	1153 (4435)	116C (4460)	1185 (4485)	R/W	MPG ratio numerator (1)/electronic gear numerator (1)	<div><div><div>15</div><div>L+1</div><div>00</div><div>15</div><div>L</div><div>00</div></div><div><div>0</div><div>0</div><div>0</div><div>0</div><div>MPG ratio numerator (1)/ electronic gear numerator (1)</div></div></div>	0000 0001 (1)
113B (4411)	1154 (4436)	116D (4461)	1186 (4486)	R/W	MPG denominator(1)/ electronic denominator(1)      ratio gear	<div><div><div>15</div><div>L+1</div><div>00</div><div>15</div><div>L</div><div>00</div></div><div><div>0</div><div>0</div><div>0</div><div>0</div><div>MPG ratio denominator (1)/ electronic gear denominator (1)</div></div></div> <p>Sets the ratio for an MPG/electronic gear pulse for setting 1. Range (numerator): D8F0 to 2710 Hex (–10000 to 10000) Range (denominator): 0001 to 2710 Hex (1 to 10000) <math>0.0001 \leq   \text{Numerator/denominator}   \leq 10000</math></p>	0000 0001 (1)
113C (4412)	1155 (4437)	116E (4462)	1187 (4487)	R/W	MPG ratio numerator (2)/electronic      gear numerator (2)	Sets the ratio for an MPG/electronic gear pulse for setting 2. The data configuration and range are the same as those for MPG ratio/electronic gear numerator (1)/denominator (1).	0000 000A (10)
113D (4413)	1156 (4438)	116F (4463)	1188 (4488)	R/W	MPG ratio denominator (2)/electronic      gear denominator (2)		0000 0001 (1)
113E (4414)	1157 (4439)	1170 (4464)	1189 (4489)	R/W	MPG ratio numerator (3)/electronic      gear numerator (3)	Sets the ratio for an MPG/electronic gear pulse for setting 3. The data configuration and range are the same as those for MPG ratio/electronic gear numerator (1)/denominator (1).	0000 0064 (100)
113F (4415)	1158 (4440)	1171 (4465)	118A (4490)	R/W	MPG ratio denominator (3)/electronic      gear denominator (3)		0000 0001 (1)
1140 (4416)	1159 (4441)	1172 (4466)	118B (4491)	R/W	MPG ratio numerator (4)/electronic      gear numerator (4)	Sets the ratio for an MPG/electronic gear pulse for setting 4. The data configuration and range are the same as those for MPG ratio/electronic gear numerator (1)/denominator (1).	0000 00C8 (200)
1141 (4417)	115A (4442)	1173 (4467)	118C (4492)	R/W	MPG ratio denominator (4)/electronic      gear denominator (4)		0000 0001 (1)

### Ladder Programming Example

In this example, the electronic gear ratio for set value 1 of the X axis (address 113A Hex) is set to 0.1 (1/10). The MC Unit is mounted to a CS1 PC and assigned unit number 0, and the data to be transferred (i.e., the numerator and denominator) is stored in words D00100 to D00103. Both the IOWR operands and the data to be transferred are assumed to be normal.

When debugging, check the Error Flags from the ladder program.



## 2 Related Bits

The following table shows the methods for selecting set values 1 to 4 and enabling the selected set value.

Bit name	MCU Model	Word				Bit	Description
		X axis	Y axis	Z axis	U axis		
Enable MPG Sync Encoder	MC421 MC221	n+11 n+7	n+13 n+9	n+15 ---	n+17 ---	08	↑:Begin MPG operation 1:Continue MPG operation ↓:Stop MPG operation
MPG Sync Encoder Ratio Specifier 1						14	MPG ratio specifier 2 1
MPG Sync Encoder Ratio Specifier 2						15	0 0 Select MPG ratio 1 0 1 Select MPG ratio 2 1 0 Select MPG ratio 3 1 1 Select MPG ratio 4

## Acceleration and Deceleration Curves

### Overview

**Mode:** Automatic or Manual; **Method:** System parameters (CX-Motion only)

In positioning operations, the speed is accelerated gradually at the beginning and decelerated gradually toward the end to achieve smooth movement. For the MC Unit, either a trapezoidal curve or an S curve can be used as the acceleration and deceleration curve for the starting and stopping operations for each axis.




The acceleration time and deceleration time can be set separately.

Refer to the CX-Motion operation manual for details on setting the acceleration and deceleration curve and the acceleration and deceleration times. The acceleration and deceleration times can also be set from the ladder program using the IOWR instruction.


### Trapezoidal Curve

With the trapezoidal curve, acceleration is constant during the acceleration time and deceleration time.




### S Curve

With the S curve, acceleration during the acceleration time and deceleration time changes with time. When the initial acceleration speed is reduced for acceleration or deceleration, the acceleration or deceleration time can be shortened using the S curve if there is a leeway in the maximum acceleration speed.



**Note** If the acceleration time or the deceleration time is the same, the maximum acceleration in the S curve is 1.5 times that in the trapezoidal curve. Therefore, when using a program set for a trapezoidal curve for an S curve, the acceleration and deceleration times set for the trapezoidal curve must be multiplied by 1.5. The maximum acceleration in the S curve will then fall within the acceleration set for the trapezoidal curve, allowing the motor to be driven smoothly.

The S curve used by the MC Unit uses a tertiary function, as shown in the following diagram.




## Unlimited Feeding

### Overview

**Mode:** Automatic or Manual; **Method:** System parameters (CX-Motion only)

The unlimited feeding function makes it possible to control axes for applications such as turntables or one-direction conveyers, which require unlimited feeding. With axes set for unlimited feeding, the present position can be updated for any set range. In the case of a turntable, for example, the present position will be updated as shown in the following diagram if a range of 0° to 360° is set. The number of turns will be remembered.



**Note** Setting these machine parameters will set unlimited feeding.

## 1 Setting System Parameters

The following system parameter must be set when using the unlimited feeding function:

- Axis mode (machine parameter): Unlimited Feed Mode

This parameter must be set using the CX-Motion. The IORD instruction can only be used to read the parameter setting.

When Unlimited Feed Mode is set as the axis mode, the software limits will not operate regardless of whether or not the origin has been determined.

The present position is set by the ring counter method at the value determined by the positive and negative software limits, using the minimum setting unit, so in the Unlimited Feed Mode be sure to set the origin (0) between the positive and negative software limits. (Refer to the examples below.)

The positive and negative software limits are set in the same way by CX-Motion. The IORD instruction can be used to read the parameter settings.

#### Example 1

In this example, the display unit is degrees, the minimum setting unit is 0.1, the negative software limit is 00, and the positive software limit is 360.0. The present position will be between 0.0 and 359.9.

#### Example 2

In this example, the display unit is degrees, the minimum setting unit is 0.1, the negative software limit is 360.0, and the positive software limit is 360.0. The present position will be between -360.0 and 359.9.

All axis operation commands can be used with the Unlimited Feed Mode. For example, an error would normally be generated for G01 if the origin is not determined, but that command can be used if the axis mode is set to Unlimited Feed Mode.

**Note** When the present position update range is converted to pulses, select a gear ratio and encoder resolution such that it will be expressed in integers. If it is not in integers, the errors will accumulate whenever the present position update range is exceeded, and correct positioning will not be possible.

For example, when controlling a turntable, suppose that the present position up-date range is 0° to 360°. If the gear ratio is 7/99 and the encoder resolution is 1,000 pulses, the following error will be accumulated with each 360-degree turn.

$$\begin{aligned} \text{Gear ratio (degrees/pulse)} \\ &= 7 \times 360^\circ / (99 \times 1,000 \text{ pulses}) \\ &= 2,520 / 99,000 \text{ pulses} \end{aligned}$$

$$360^\circ \times 99,000 / 2,520 = 14,142.857 \text{ pulses}$$

Thus an error of 0.857 pulses will be accumulated with each turn.

## 2 Stopping

The MC Unit has various ways of stopping axis operation, as shown in the following table.

Method	Activation timing	Remarks
Manual/Automatic Bit	Upon input.	Each axis is decelerated to a stop upon input. During interpolation operations, axis operation is stopped after moving from the interpolation locus.
Cycle Start OFF	When G-language program interpretation is started.	This bit is checked when interpretation of the G-language is started (at the beginning of a block). If it is OFF, the G-language program is not executed. In In-position Check OFF Mode or Pass Mode, however, this bit is not checked until the next block.
Pause ON	Upon input.	Each axis is decelerated to a stop upon input. During interpolation, axis operation is stopped at the interpolation locus.
Forced Block End	Upon input.	Each axis is decelerated to a stop upon input. During interpolation operations, axis operation is stopped after moving from the interpolation locus.
Optional End	Upon input.	Each axis is decelerated to a stop upon input. During interpolation operations, axis operation is stopped after moving from the interpolation locus.

Method	Activation timing	Remarks
Emergency Stop	Upon input.	Each axis is stopped immediately upon input. There are two methods for stopping: accumulated-pulse stop and servo-off stop. The selection is made in the system parameters.
CCW, CW Limits Inputs	Upon input.	Each axis is stopped immediately upon input. There are two methods for stopping: accumulated-pulse stop and servo-unlock stop. The selection is made in the system parameters.
Software Limit ON	When a software limit is exceeded.	Each axis is decelerated to a stop when a software limit is exceeded. During interpolation operations, axis operation is stopped after moving from the interpolation locus.
Other errors	Refer to Section 12 Troubleshooting (W359-E1-1)	

