



Digital Temperature Controller with 11-segment Display







**User's Manual** 

# E5CZ/E5CZ-U/E5AZ/E5EZ Digital Temperature Controller

# **User's Manual**

Produced September 2008

# **Preface**

OMRON products are manufactured for use according to proper procedures by a qualified operator and only for the purposes described in this manual.

The E5CZ, E5CZ-U, E5AZ, and E5EZ are Digital Temperature Controllers. The E5CZ and E5CZ-U are both compact temperature controllers, with the E5CZ featuring screw terminal connections, and the E5CZ-U featuring socket pin connections. The main functions and characteristics of these Digital Temperature Controllers are as follows:

- Any of the following types of input can be used: thermocouple, platinum resistance thermometer, infrared sensor, analog voltage, or analog current.
- Depth of only 78mm
- Either standard or heating/cooling control can be performed.
- Both auto-tuning and self-tuning are supported.
- Event inputs can be used to switch set points (multi-SP function), switch between RUN and STOP status, and switch between automatic and manual operation. (Event input are not applicable to the E5CZ-U.)
- Heater burnout detection and HS alarms are supported. (Applicable to E5CZ, E5AZ, and E5EZ models with heater burnout detection function.)
- Communications are supported. (Applicable to E5CZ, E5AZ, and E5EZ models with communications.)
- The structure of the E5CZ,E5AZ, and E5EZ is waterproof (IP66: indoor use). (Not applicable to the E5CZ-U).
- Conforms to UL, CSA, and IEC safety standards and EMC Directive. When using the E53-AZB, E53-AZ01 or E53-AZ03 Option Unit with the E5AZ-□3□M□□ to satisfy the immunity burst requirements in the EN61326 standard, always connect a ZCAT2035-0930 Clamlp Filter (manufactured by TDK) to the cable for terminals 11,12 and 13.

This manual describes the E5CZ, E5CZ-U, E5AZ, and E5EZ. Read this manual thoroughly and be sure you understand it before attempting to use the Digital Temperature Controller and use the Digital Temperature Controller correctly according to the information provided. Keep this manual in a safe place for easy reference. Refer to the following manual for further information on communications: E5CZ/E5AZ/E5EZ Digital Temperature Controller Communications Manual (Cat. No. H208).

# Visual Aids

The following headings appear in the left column of the manual to help you locate different types of information.

**Note** Indicates information of particular interest for efficient and convenient operation of the product.

1,2,3... 1. Indicates lists of one sort or another, such as procedures, checklists, etc.

# © OMRON, 2008

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

# Read and Understand this Manual

Please read and understand this manual before using the product. Please consult your OMRON representative if you have any questions or comments.

# **Warranty and Limitations of Liability**

### **WARRANTY**

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year (or other period if specified) from date of sale by OMRON.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

### LIMITATIONS OF LIABILITY

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY.

In no event shall the responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.

IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR, OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED, AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE, OR INAPPROPRIATE MODIFICATION OR REPAIR.

# **Application Considerations**

### SUITABILITY FOR USE

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of products in the customer's application or use of the products.

At the customer's request, OMRON will provide applicable third party certification documents identifying ratings and limitations of use that apply to the products. This information by itself is not sufficient for a complete determination of the suitability of the products in combination with the end product, machine, system, or other application or use.

The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of the products, nor is it intended to imply that the uses listed may be suitable for the products:

- Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this manual.
- Nuclear energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations.
- Systems, machines, and equipment that could present a risk to life or property.

Please know and observe all prohibitions of use applicable to the products.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCTS ARE PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

### PROGRAMMABLE PRODUCTS

OMRON shall not be responsible for the user's programming of a programmable product, or any consequence thereof.

# **Disclaimers**

### **CHANGE IN SPECIFICATIONS**

Product specifications and accessories may be changed at any time based on improvements and other reasons.

It is our practice to change model numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the products may be changed without any notice. When in doubt, special model numbers may be assigned to fix or establish key specifications for your application on your request. Please consult with your OMRON representative at any time to confirm actual specifications of purchased products.

### **DIMENSIONS AND WEIGHTS**

Dimensions and weights are nominal and are not to be used for manufacturing purposes, even when tolerances are shown.

### PERFORMANCE DATA

Performance data given in this manual is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of OMRON's test conditions, and the users must correlate it to actual application requirements. Actual performance is subject to the OMRON Warranty and Limitations of Liability.

### **ERRORS AND OMISSIONS**

The information in this document has been carefully checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical, or proofreading errors, or omissions.

# **Safety Precautions**

# ■ Definition of Precautionary Information

The following notation is used in this manual to provide precautions required to ensure safe usage of the product.

The safety precautions that are provided are extremely important to safety. Always read and heed the information provided in all safety precautions.

The following notation is used.



Indicates a potentially hazardous situation which, if not avoided, is likely to result in minor or moderate injury or in property damage.

# Symbols

Symbol		Meaning
Caution	$\triangle$	General Caution Indicates non-specific general cautions, warnings, and dangers.
	A	Electrical Shock Caution Indicates possibility of electric shock under specific conditions.
Prohibition	$\bigcirc$	General Prohibition Indicates non-specific general prohibitions.
Mandatory Caution	0	General Caution Indicates non-specific general cautions, warnings, and dangers.

# **■**Safety Precautions

<b>⚠ CAUTION</b>	
Do not touch the terminals while power is being supplied.  Doing so may occasionally result in minor injury due to electric shock.	A
Do not allow pieces of metal, wire clippings, or fine metallic shavings or filings from installation to enter the product. Doing so may occasionally result in electric shock, fire, or malfunction.	
Do not use the product where subject to flammable or explosive gas. Otherwise, minor injury from explosion may occasionally occur.	
Never disassemble, modify, or repair the product or touch any of the internal parts. Minor electric shock, fire, or malfunction may occasionally occur.	
CAUTION - Risk of Fire and Electric Shock  a) This product is UL recognized as Open Type Process Control Equipment. It must be mounted in an enclosure that does not allow fire to escape externally.  b) More than one disconnect switch may be required to deenergize the equipment before servicing the product.  c) Signal inputs are SELV, limited energy.*1  d) Caution: To reduce the risk of fire or electric shock, do not interconnect the outputs of different Class 2circuits.*2	
If the output relays are used past their life expectancy, contact fusing or burning may occasionally occur.  Always consider the application conditions and use the output relays within their rated load and electrical life expectancy. The life expectancy of output relays varies considerably with the output load and switching conditions.	

- \*1 A SELV circuit is one separated from the power supply with double insulation or reinforced insulation, that does not exceed 30 V r.m.s. and 42.4 V peak or 60 VDC.
- \*2 A class 2 power supply is one tested and certified by UL as having the current and voltage of the secondary output restricted to specific levels.

# **A** CAUTION

Tighten the terminal screws to between 0.74 and 0.90 N⋅m. Loose screws may occasionally result in fire. (See note.)

Set the parameters of the product so that they are suitable for the system being controlled. If they are not suitable, unexpected operation may occasionally result in property damage or accidents.

A malfunction in the Temperature Controller may occasionally make control operations impossible or prevent alarm outputs, resulting in property damage. To maintain safety in the event of malfunction of the Temperature Controller, take appropriate safety measures, such as installing a monitoring device on a separate line.



When inserting the body of the Temperature Controller into the case, confirm that the hooks on the top and bottom are securely engaged with the case. If the body of the Temperature Controller is not inserted properly, faulty contact in the terminal section or reduced water resistance may occasionally result in fire or malfunction.

Note The tightening torque for E5CZ-U is 0.5 N·m.

# Precautions for Safe Use

Be sure to observe the following precautions to prevent operation failure, malfunction, or adverse affects on the performance and functions of the product. Not doing so may occasionally result in unexpected events.

- 1) The product is specifically designed for indoor use only. Do not use the product outdoors or in any of the following places.
  - Places directly subject to heat radiated from heating equipment.
  - Places subject to splashing liquid or oil atmosphere.
  - Places subject to direct sunlight.
  - Places subject to dust or corrosive gas (in particular, sulfide gas and ammonia gas).
  - Places subject to intense temperature change.
  - Places subject to icing and condensation.
  - Places subject to vibration and large shocks.
- 2) Use and store the Digital Temperature Controller within the rated ambient temperature and humidity. Gang-mounting two or more temperature controllers, or mounting temperature controllers above each other may cause heat to build up inside the temperature controllers, which will shorten their service life. In such a case, use forced cooling by fans or other means of air ventilation to cool down the Digital Temperature Controllers.
- 3) To allow heat to escape, do not block the area around the product. Do not block the ventilation holes on the product.
- 4) Be sure to wire properly with correct polarity of terminals.
- 5) Use the specified size (M3.5, width 7.2 mm or less) crimped terminals for wiring. For open-wired connection, use stranded or solid copper wires with a gage of AWG24 to AWG14 (equal to a cross-sectional area of 0.205 to 2.081 mm<sup>2</sup>). (The stripping length is 5 to 6 mm.) Up to two wires of the same size and type or two crimp terminals can be inserted into a single terminal.
- 6) Do not wire the terminals which are not used.
- 7) To avoid inductive noise, keep the wiring for the Digital Temperature Controller's terminal block away from power cables carry high voltages or large currents. Also, do not wire power lines together with or parallel to Digital Temperature Controller wiring. Using shielded cables and using separate conduits or ducts is recommended.
  - Attach a surge suppressor or noise filter to peripheral devices that generate noise (in particular, motors, transformers, solenoids, magnetic coils or other equipment that have an inductance component).
  - When a noise filter is used at the power supply, first check the voltage or current, and attach the noise filter as close as possible to the temperature controller.
  - Allow as much space as possible between the Digital Temperature Controller and devices that generate powerful high frequencies (high-frequency welders, high-frequency sewing machines, etc.) or surge.
- 8) Use this product within the rated load and power supply.
- 9) Make sure that the rated voltage is attained within 2 seconds of turning ON the power by using a switch or relay contact. If the voltage is applied gradually, the power may not be reset or output malfunctions may occur.
- 10) Make sure that the Temperature Controller has 30 minutes or more to warm up after turning ON the power before starting actual control operations to ensure the correct temperature display.
- 11) When executing self-tuning, turn ON power for the load (e.g., heater) at the same time as or before supplying power to the Digital Temperature Controller. If power is turned ON for the Digital Temperature Controller before turning ON power for the load, self-tuning will not be performed properly and optimum control will not be achieved.
- 12) A switch or circuit breaker should be provided close to this unit. The switch or circuit breaker should be within easy reach of the operator, and must be marked as a disconnecting means for this unit.
- 13) Always turn OFF the power supply before pulling out the interior of the product, and never touch nor apply shock to the terminals or electronic components. When inserting the interior of the product, do not allow the electronic components to touch the case.

- 14) Do not use paint thinner or similar chemical to clean with. Use standard grade alcohol.
- 15) Design system (control panel, etc) considering the 2 seconds of delay that the controller's output to be set after power ON.
- 16) The output may turn OFF when shifting to certain levels. Take this into consideration when performing control.
- 17) The number of EEPROM write operations is limited. Therefore, use RAM write mode when frequently overwriting data during communications or other operations.
- 18) Always touch a grounded piece of metal before touching the Digital Temperature Controller to discharge static electricity from your body.
- 19) Control output that is voltage output is not isolated from the internal circuits. When using a grounded thermocouple, do not connect any of the control output terminals to ground. (Doing so may result in an unwanted circuit path, causing error in the measured temperature.)
- 20) When replacing the body of the Digital Temperature Controller, check the condition of the terminals. If corroded terminals are used, contact failure in the terminals may cause the temperature inside the Digital Temperature Controller to increase, possibly resulting in fire. If the terminals are corroded, replace the case as well.
- 21) Use suitable tools when taking the Digital Temperature Controller apart for disposal. Sharp parts inside the Digital Temperature Controller may cause injury.
- 22) Check the orientation of the connectors on the Conversion Cable before connecting the Conversion Cable.

  Do not force a connector if it does not connect smoothly. Using excessive force may damage the connector.
- 23) Do not place heavy object on the Conversion Cable, bend the cable past its natural bending radius, or pull on the cable with undue force.
- 24) Do not connect or disconnect the Conversion Cable while communications are in progress. Product faults or malfunction may occur.
- 25) Make sure that the Conversion Cable's metal components are not touching the external power terminals.
- 26) Do not touch the connectors on the Conversion Cable with wet hands. Electrical shock may result.

### Service Life

Use the Temperature Controller within the following temperature and humidity ranges:

Temperature: -10 to 55°C (with no icing or condensation), Humidity: 25% to 85%

If the Controller is installed inside a control board, the ambient temperature must be kept to under 55°C, including the temperature around the Controller.

The service life of electronic devices like Temperature Controllers is determined not only by the number of times the relay is switched but also by the service life of internal electronic components. Component service life is affected by the ambient temperature: the higher the temperature, the shorter the service life and, the lower the temperature, the longer the service life. Therefore, the service life can be extended by lowering the temperature of the Temperature Controller.

When two or more Temperature Controllers are mounted horizontally close to each other or vertically next to one another, the internal temperature will increase due to heat radiated by the Temperature Controllers and the service life will decrease. In such a case, use forced cooling by fans or other means of air ventilation to cool down the Temperature Controllers. When providing forced cooling, however, be careful not to cool down the terminals sections alone to avoid measurement errors.

### Ambient Noise

To avoid inductive noise, keep the wiring for the Digital Temperature Controller's terminal block wiring away from power cables carrying high voltages or large currents. Also, do not wire power lines together with or parallel to Digital Temperature Controller wiring. Using shielded cables and using separate conduits or ducts is recommended.

Attach a surge suppressor or noise filter to peripheral devices that generate noise (in particular, motors, transformers, solenoids, magnetic coils or other equipment that have an inductance component). When a noise filter is used at the power supply, first check the voltage or current, and attach the noise filter as close as possible to the Temperature Controller.

Allow as much space as possible between the Digital Temperature Controller and devices that generate powerful high frequencies (high-frequency welders, high-frequency sewing machines, etc.) or surge.

# Ensuring Measurement Accuracy

When extending or connecting the thermocouple lead wire, be sure to use compensating wires that match the thermocouple types.

When extending or connecting the lead wire of the platinum resistance thermometer, be sure to use wires that have low resistance and keep the resistance of the three lead wires the same.

Mount the Temperature Controller so that it is horizontally level.

If the measurement accuracy is low, check to see if input shift has been set correctly.

# Waterproofing

The degree of protection is as shown below. Sections without any specification on their degree of protection or those with  $IP\square 0$  are not waterproof.

E5CZ	Front panel: IP66 (Indoor Use).
E5AZ	Rear case: IP20, Terminal section: IP00
E5EZ	
E5CZ-U	Front panel: Equivalent to IP50, rear case: IP20, Terminals: IP00

# **Precautions for Operation**

- 1) It takes approximately 2 seconds for the outputs to turn ON from after the power supply is turned ON. Due consideration must be given to this time when incorporating Temperature Controllers into a control panel or similar device.
- 2) Make sure that the Temperature Controller has 30 minutes or more to warm up after turning ON the power before starting actual control operations to ensure the correct temperature display.
- 3) When executing self-tuning, turn ON power for the load (e.g., heater) at the same time as or before supplying power to the Temperature Controller. If power is turned ON for the Temperature Controller before turning ON power for the load, self-tuning will not be performed properly and optimum control will not be achieved. When starting operation after the Temperature Controller has warmed up, turn OFF the power and then turn it ON again at the same time as turning ON power for the load. (Instead of turning the Temperature Controller OFF and ON again, switching from STOP mode to RUN mode can also be used.)
- 4) Avoid using the Controller in places near a radio, television set, or wireless installing. The Controller may cause radio disturbance for these devices.

# **Preparations for Use**

Be sure to thoroughly read and understand the manual provided with the product, and check the following points.

Timing	Check point	Details
Purchasing the product	Product appearance	After purchase, check that the product and packaging are not dented or otherwise damaged. Damaged internal parts may prevent optimum control.
	Product model and specifications	Make sure that the purchased product meets the required specifications.
Setting the Unit	Product installation location	Provide sufficient space around the product for heat dissipation. Do not block the vents on the product.
Wiring	Terminal wiring	Do not subject the terminal screws to excessive stress (force) when tightening them.  Make sure that there are no loose screws after tightening terminal screws to the specified torque of 0.74 to 0.90 N·m.(See note.)
		Be sure to confirm the polarity for each terminal before wiring the terminal block and connectors.
	Power supply inputs	Wire the power supply inputs correctly. Incorrect wiring will result in damage to the internal circuits.
Operating environment	Ambient temperature	The ambient operating temperature for the product is $-10$ to $55^{\circ}$ C (with no condensation or icing). To extend the service life of the product, install it in a location with an ambient temperature as low as possible. In locations exposed to high temperatures, if necessary, cool the products using a fan or other cooling method.
	Vibration and shock	Check whether the standards related to shock and vibration are satisfied at the installation environment. (Install the product in locations where the conductors will not be subject to vibration or shock.)
	Foreign particles	Install the product in a location that is not subject to liquid or foreign particles entering the product.

**Note** The tightening torque for E5CZ-U is 0.5 N·m.

# Upgraded Functions

The functions of the Controller have been upgraded in models manufactured in October 2008 or later. The design of the front panel can be used to differentiate between the previous and upgraded models.

### E5CZ

The upgraded Controllers are basically compatible with the previous Controllers. Terminal arrangements, terminal sizes, and panel mounting depth have not been changed. The E5CZ-U plug-in type is newly released.

# • E5AZ/EZ

Although the upgraded Controllers are compatible with the previous Controllers, terminal arrangements have been changed. Terminal sizes and panel mounting depth have not been changed.

Other changes outlined in the following tables. Refer to relevant pages in the manual for details.

	Previous models	Improved function models
E5CZ/CZ-U	ALM1 ALM2 HB  OUT1 STOP OUT2 CMW	ALM1 % V V V V ALM3 HA OUT1 STOP On V V V V V OUT2 CMW MANU
E5AZ	ALMI ALM2 ALMS HB OUT1 OUT2 STOP CMW	ALMI ALME ALME HA  OUTT   STOP © TH  OUTZ   CHAY   MANU
E5EZ	OUT1 OUT2 STOP CMW	ALIMI JALMZ  H.A. JALMS  °E VI VI VI VI  OUT1 © TT  OUT2 STOP  CMMY MANUE  CMMY MANUE  OUT MANUE  O

# **■**Ratings

Item		Previous models	Improved models
Power consumption	E5CZ	7 VA (100 to 240 VAC, 50/60 Hz) 4 VA/3 W (24 VAC, 50/60 Hz or 24 VDC)	7.5 VA (100 to 240 VAC, 50/60 Hz) 5.5 VA/3.5 W (24 VAC, 50/60 Hz or 24 VDC)
	E5CZ-U	(No models with plug-in type)	6 VA (100 to 240 VAC, 50/60 Hz) 4.5 VA/2.5 W (24 VAC, 50/60 Hz or 24 VDC)
	E5AZ	9 VA (100 to 240 VAC, 50/60 Hz) 5 VA/4 W (24 VAC, 50/60 Hz or 24 VDC)	8.5 VA 6 VA/4 W
	E5EZ	9 VA (100 to 240 VAC, 50/60 Hz) 5 VA/4 W (24 VAC, 50/60 Hz or 24 VDC)	8.5 VA 6 VA/4 W
Sensor input		(No models with analog inputs)	E5□Z-□□□□L□(Models with analog inputs added.)
			Current input: 4 to 20 mA or 0 to 20 mA Voltage input: 1 to 5 V, 0 to 5 V, or 0 to 10 V

li	em	Previous models	Improved models
Control	Relay	E5CZ-R□□□	E5CZ-R
output 1		SPST-NO, 250 VAC, 3 A (resistive load)	SPST-NO, 250 VAC, 3 A (resistive load)
		Electrical life: 100,000 operations.	Electrical life: 100,000 operations.
		(No models with plug-in type)	E5CZ-R□□□U
			SPDT, 250 VAC, 3 A (resistive load)
			Electrical life: 100,000 operations.
		E5AZ-R□□□	E5AZ-R□□□□□
		SPST-NO, 250 VAC, 5 A (resistive load)	SPST-NO, 250 VAC, 5 A (resistive load)
		Electrical life: 100,000 operations.	Electrical life: 100,000 operations.
		E5EZ-R□□□	E5EZ-R
		SPST-NO, 250 VAC, 5 A (resistive load)	SPST-NO, 250 VAC, 5 A (resistive load)
		Electrical life: 100,000 operations.	Electrical life: 100,000 operations.
	Voltage	E5CZ-Q□□□	E5CZ-Q□□□□
		12 VDC ±15% (PNP)	12 VDC ±15% (PNP)
		Max. load current: 21 mA	Max. load current: 21 mA
		With short-circuit protection	With short-circuit protection
		(No models with plug-in type)	E5CZ-Q□□□U
		( a measie mar prog m sype)	12 VDC ±15% (PNP)
			Max. load current: 21 mA
			With short-circuit protection
		E5AZ-Q□□□	E5AZ-Q□□□□
		12 VDC +15%/–20% (PNP)	12 VDC +15%/-20% (PNP)
		Max. load current: 40 mA	Max. load current: 40 mA
		With short-circuit protection	With short-circuit protection
		E5EZ-Q	E5EZ-Q□□□□
		12 VDC +15%/-20% (PNP)	12 VDC +15%/-20% (PNP)
		Max. load current: 40 mA	Max. load current: 40 mA
		With short-circuit protection	With short-circuit protection
	Current	E5CZ-C□□□	
		4 to 20 mA DC	4 to 20 mA DC,0 to 20 mA DC.
		Load: 600 Ω max.	Load: $600 \Omega$ max.
		Resolution: Approx. 2,600	Resolution: Approx. 2,700
		E5AZ-C□□□	E5AZ-C□□□□
		4 to 20 mA DC	4 to 20 mA DC,0 to 20 mA DC.
		Load: 600 Ω max.	Load: $600 \Omega$ max.
		Resolution: Approx. 2,600	Resolution: Approx. 2,700
		E5EZ-C□□□	E5EZ-C□□□□
		4 to 20 mA DC	4 to 20 mA DC,0 to 20 mA DC.
		Load: $600 \Omega$ max.	Load: $600 \Omega$ max.
		Resolution: Approx. 2,600	Resolution: Approx. 2,700
Display	E5CZ/CZ-U	7-segment digital display and single-LED	11-segment digital display and single-LED indica-
method		indicators	tor (Improved visibility)
			(A 7-segment digital display also possible.)
	E5AZ/EZ	7-segment digital display and single-LED	11-segment digital display and single-LED indica-
		indicators	tor (Improved visibility)
T		(No mondate with the reference to	(A 7-segment digital display also possible.)
Transfer ou	itput	(No models with transfer outputs)	
			Allocated to current output
			4 to 20 mA DC,0 to 20 mA DC.
			Load: 600 Ω max.
			Resolution: Approx. 2,700 (4 to 20 mA DC)

# **■**Other Functions

Item	Previous models	Improved models
Display		Display character switch (7-segment/11-segment)
Input	Temperature input shift (1-point shift for temperature input)	Temperature input shift (2-point shift also possible for temperature input)
Output		Manual outputs
		Loop break alarm
Control	Control period: 1 to 99 s	Control period: 0.5 or 1 to 99 s
Alarm		Alarm delays

# Characteristics

Item	Previous models	Improved models	
Sampling period	500 ms	250 ms	

# **■**Communications Specifications

Item	Previous models	Improved models
Communications proto- cols	CompoWay/F (SYSWAY)	CompoWay/F (SYSWAY), Modbus
Communications baud rate	1200, 2400, 4800, 9600, 19200 bps	1200, 2400, 4800, 9600, 19200, 38400 bps

# Heater Burnout/HS Alarm Characteristics

Item		Previous models	Improved models
Maximum	E5CZ	E5CZ-□□M□ with E53-CNH□N	E5CZ-□□M□□ with E53-CZH□
heater		Single-phase 50 A AC	Single-phase 50 A AC
current	E5AZ/EZ	E5□Z-A3 + E53-AZM + E53-AZH,	E5□Z-□□H□□□
		E5□Z-R3 + E53-AZM + E53-AZH,	Single-phase 50 A AC
		E5□Z-Q3 + E53-AZM + E53-AZH	
		Single-phase 50 A AC	
HS alarm			HS alarm

# Conventions Used in This Manual

# **Meanings of Abbreviations**


The following abbreviations are used in parameter names, figures and in text explanations. These abbreviations mean the following:

Symbol	Term
PV	Process value
SP	Set point
SV	Set value
AT	Auto-tuning
ST	Self-tuning
НВ	Heater burnout
HS	Heater short (See note 1.)
LBA	Loop burnout alarm
EU	Engineering unit (See note 2.)

- **Note: (1)** A heater short indicates that the heater remains ON even when the control output from the Temperature Controller is OFF because the SSR has failed or for any other reason.
  - (2) "EU" stands for Engineering Unit. EU is used as the minimum unit for engineering units such as °C, m, and g. The size of EU varies according to the input type.
    - For example, when the input temperature setting range is –200 to +1300°C, 1 EU is 1°C, and when the input temperature setting range is –20.0 to +500.0°C, 1 EU is 0.1°C.
    - For analog inputs, the size of EU varies according to the decimal point position of the scaling setting, and 1 EU becomes the minimum scaling unit.


# **How to Read Display Symbols**


The following tables show the correspondence between the symbols displayed on the displays and alphabet characters. The default is for 11-segment displays.



M	ū	F		F	5	F		1/	M	\/ /\	4	7 4
N	O	P	Q	R	S	T	U	V	W	X	Y	Z

The "character select" parameter in the advanced function setting level can be turned OFF to display the following 7-segment characters.





# **TABLE OF CONTENTS**

SEC	TION 1
Intro	oduction
1-1	Names of Parts
1-2	I/O Configuration and Main Functions
1-3	Setting Level Configuration and Key Operations
1-4	Communications Function
SEC'	TION 2
	arations
2-1	Installation
2-2	Wiring Terminals.
2-3	Using the Support Software Port
SEC.	TION 3
	C Operation
3-1	Initial Setting Examples
3-2	Setting the Input Type
3-3	Selecting the Temperature Unit
3-4	Selecting PID Control or ON/OFF Control
3-5	Setting Output Specifications
3-6	Setting the Set Point (SP)
3-7	Using ON/OFF Control
3-8	Determining PID Constants (AT, ST, Manual Setup)
3-9	Alarm Outputs
3-10	Using HB and HS Alarms
SEC'	TION 4
_	ications Operations
4-1	Shifting Input Values
4-2	Alarm Hysteresis
4-3	Setting Scaling Upper and Lower Limits for Analog Inputs
4-4	Executing Heating/Cooling Control
4-5	Using Event Inputs
4-6	Setting the SP Upper and Lower Limit Values
4-7	Using the SP Ramp Function to Limit the SP Change Rate
4-8	Moving to the Advanced Function Setting Level
4-9	Using the Key Protect Level
4-10	Alarm Delays
	Loop Break Alarm
	Performing Manual Control
	Using the Transfer Output
	Output Adjustment Functions

# **TABLE OF CONTENTS**

# **SECTION 5**

Para	ımeters	93
5-1	Conventions Used in this Section	94
5-2	Protect Level	95
5-3	Operation Level	97
5-4	Adjustment Level	106
5-5	Manual Control Level	117
5-6	Initial Setting Level	118
5-7		129
5-8	Communications Setting Level	149
App	endix A	151
Inde	<b>x</b>	177
Revi	sion History	183

# About this Manual:

This manual describes the E5CZ/CZ-U/AZ/EZ Digital Temperature Controllers and includes the sections described below.

Please read this manual carefully and be sure you understand the information provided before attempting to set up or operate an E5CZ/CZ-U/AZ/EZ Digital Temperature Controller.

# Overview

**Section 1** introduces the features, components, and main specifications of the E5CZ/CZ-U/AZ/EZ Digital Temperature Controllers.

# Setup

**Section 2** describes the work required to prepare the E5CZ/CZ-U/AZ/EZ Digital Temperature Controllers for operation, including installation and wiring.

# Basic Operations

**Section 3** describes the basic operation of the E5CZ/CZ-U/AZ/EZ Digital Temperature Controllers, including key operations to set parameters and descriptions of display elements based on specific control examples.

Section 5 describes the individual parameters used to set up, control, and monitor operation.

# Operations for Applications

**Section 4** describes scaling, the SP ramp function, and other special functions that can be used to make the most of the functionality of the E5CZ/CZ-U/AZ/EZ Digital Temperature Controllers.

Section 5 describes the individual parameters used to setup, control, and monitor operation.

# Appendices

The *Appendix* provides information for easy reference, including lists of parameters and settings.

**WARNING** Failure to read and understand the information provided in this manual may result in personal injury or death, damage to the product, or product failure. Please read each section in its entirety and be sure you understand the information provided in the section and related sections before attempting any of the procedures or operations given.

# **SECTION 1 Introduction**

This section introduces the features, components, and main specifications of the E5CZ and E5CZ-U Digital Temperature Controllers.

1-1	Names	of Parts	2
	1-1-1	Front Panel	2
	1-1-2	Meanings of Indicators	3
	1-1-3	Using the Keys	4
1-2	I/O Co	nfiguration and Main Functions	5
	1-2-1	I/O Configuration	5
	1-2-2	Main Functions	8
1-3	Setting	Level Configuration and Key Operations	10
	1-3-1	Selecting Parameters	12
	1-3-2	Fixing Settings	12
1-4	Commi	unications Function	13


Names of Parts Section 1-1

# 1-1 Names of Parts


# 1-1-1 Front Panel

E5CZ/CZ-U

The front panel is the same for the E5CZ and E5CZ-U.




# E5AZ



Names of Parts Section 1-1

### E5EZ



# 1-1-2 Meanings of Indicators

No. 1 Display

Displays the process value or parameter type.

Lights for approximately one second during startup.

No. 2 Display

Displays the set point, parameter operation read value, or the variable input value.

Lights for approximately one second during startup.

### **Operation Indicators**

**1,2,3...** 1. ALM1 (Alarm 1)

Lights when the alarm 1 output is ON.

ALM2 (Alarm 2)

Lights when the alarm 2 output is ON.

ALM3 (Alarm 3)

Lights when the alarm 3 output is ON.

- 2. HA (Heater burnout and HS indicator)
  - Lights when a heater burnout or HS occurs.
- 3. OUT1, OUT2 (control output 1, heating/cooling output (It depends on the assigned function.)

Lights when control output 1 or heating/cooling output (It depends on the assigned function.) is ON.

For a current output, however, OFF for a 0% output only.

4. STOP

Lights when operation is stopped.

During operation, this indicator lights when operation is stopped by an event or by using the RUN/STOP function.

5. CMW (Communications Writing)

Lights when communications writing is enabled and is not lit when it is disabled.

Names of Parts Section 1-1

> 6. MANU (Manual Mode) Lights when the auto/manual mode is set to manual mode.

7. **O□** (Key)

Lights when settings change protect is ON (i.e., when the  $\ensuremath{\mathsf{U}}$  and  $\ensuremath{\mathsf{D}}$  keys are disabled by protected status.

**Temperature Unit** 

The temperature unit is displayed when parameters are set to display a temperature. The display is determined by the currently selected "temperature unit" parameter set value. c indicates °C and f indicates °F.

Flashes during ST operation.

#### 1-1-3 Using the Keys

This section describes the basic functions of the front panel keys.

O Key Press this key to move between setting levels. The setting level is selected in the following order: operation level: adjustment level, initial setting level, com-

munications setting level.

M Key Press this key to change parameters within a setting level.

The parameters can be reversed by holding down the key (moving one per

second in reverse order).

U Key Each press of this key increments the value displayed on the No. 2 display or

advances the setting. Holding the key down speeds up the incrementation.

D Key Each press of this key decrements values displayed on the No. 2 display or

reverses the setting. Holding the key down speeds up the incrementation.

Press these keys to change to the protect level. For details on operations O + M Keys

> involving holding these keys down simultaneously, refer to 1-3 Setting Level Configuration and Key Operations. For details on the protect level, refer to

SECTION 5 Parameters.

O + U Keys To restrict set value changes (in order to prevent accidental or incorrect oper-O + D Keys


ations), these key operations require simultaneously pressing the O key

along with U or D key.

# 1-2 I/O Configuration and Main Functions


# 1-2-1 I/O Configuration

E5CZ



**Note** Functions can be assigned individually for each output by changing the set values for the control output 1 assignment, the alarm output 1 assignment, and the alarm output 2 assignment in the advanced function setting level.

### E5CZ-U



Note

Functions can be assigned individually for each output by changing the set values for the control output 1 assignment, the alarm output 1 assignment, and the alarm output 2 assignment in the advanced function setting level

# **Model Number Structure**

# **Model Number Legend**

C	o	n	tr	O	II	٩r	S

1 2 3 4 5

# 1. Control Output 1

R: Relay output

Q: Voltage output (for driving SSR)

C: Current output

# 2. Number of Alarms

2: Two alarms

### 3. Option

M: Option Unit can be mounted.

# 4. Input Type

T: Thermocouple, infrared sensor /platinum resistance thermometer

L: Analog current/voltage input

# 5. Power Supply Voltage

Blank: 100 to 240 VAC

D: 24 VAC/VDC

# E5CZ-<u>2 T U U</u>

1 2 3 4 5

### 1. Output Type

R: Relay output

Q: Voltage ouput (for driving SSR)

# **Option Units**

E53-<u>CZ</u> \_ \_

1 2 3

### 1. Applicable Controller

CZ: E5CZ

### 2. Function 1

Blank: None

H: Heater burnout/Heater short detection(CT1)

### 3. Function 2

B: Two event inputs

03: RS-485 communications

### 2. Number of Alarms

2: Two alarms

### 3. Input Type

T: Thermocouple, infrared sensor /platinum resistance thermometer

# 4. Power Supply Voltage

Blank: 100 to 240 VAC

D: 24 VAC/VDC

# 5. Plug-in type

U: Plug-in type

**Note** Not all combinations of function 1 and function 2 specifications are possible for Option Units (E53-CZ $\square$ ).

A functional explanation is provided here for illustration, but models are not necessarily available for all possible combinations. Refer to the catalog when ordering.


Examples:

Communications function E5CZ-\(\sigma 2MT\) with E53-CZ03

Alarm output (with 2 alarm outputs, HB alarm,

and event inputs): E5CZ-□2MT with E53-CZHB

### E5AZ/EZ



**Note** Functions can be assigned individually for each output by changing the set values for the control output 1 assignment, the alarm output 1 assignment, the

alarm output 2 assignment, and the alarm output 3 assignment in the advanced function setting level.

**Option Units** 

1 2

AZ: E5AZ/E5EZ

1. Applicable Controller

B: Two event inputs

01: RS-232C communications

03: RS-485 communications

**E53-AE** □

# **Model Number Structure**

# **Model Number Legend**

Controllers

E5AZ/EZ- <u>3</u> <u>0</u> <u>0</u> <u>0</u> <u>0</u> <u>0</u>

1 2 3 4 5 6

1. Control Output 1

R: Relay output

Q: Voltage output (for driving SSR) 2. Function

C: Current output

2. Number of Alarms

3: Three alarms

3. Heater Burnout/Heater Short

Blank: None

H: Heater burnout/Heater short detection(CT1)

4. Option

Blank: None

M: Option Unit can be mounted.

5. Input Type

T: Thermocouple, infrared sensor /platinum resistance thermometer

L: Analog current/voltage input

6. Power Supply Voltage

Blank: 100 to 240 VAC

D: 24 VAC/VDC

# 1-2-2 Main Functions

This section introduces the main E5CZ/CZ-U/AZ/EZ functions. For details on particular functions and how to use them, refer to *SECTION 3 Basic Operation* and following sections.

# **Input Sensor Types**

• The following input sensors can be connected for temperature input:

Thermocouple: K, J, T, E, L, U, N, R, S, B

Infrared temperature sensor: ES1B

10 to 70°C 60 to 120°C, 115 to 165°C,

140 to 260°C

Platinum resistance thermometer:Pt100, JPt100 Analog input: 0 to 50 mV

• Inputs with the following specifications can be connected for analog input.

Current input: 4 to 20 mA DC, 0 to 20 mA DC

Voltage input: 1 to 5 VDC, 0 to 5 V DC, 0 to 10 V DC

### **Control Outputs**

- A control output can be relay, voltage, or current output, depending on the model
- With the E5CZ-□2M□□, alarm output 2 is used as control output (cooling) when heating/cooling control is selected. Therefore, use alarm 1 if an alarm is required while using heating/cooling control.
- With the E5AZ/E5EZ-\(\sigma\) \(\sigma\), alarm output 3 is used as control output (cooling) when heating/cooling control is selected. Therefore, use alarms 1 and 2 if an alarm is required while using heating/cooling control.

### **Alarms**

- Alarms can be used with the E5CZ-□2M□□, or E5CZ-□2T□U. Set the alarm classification and alarm value or the alarm's upper and lower limits.
- If necessary, a more comprehensive alarm function can be achieved by setting the standby sequence, alarm hysteresis, close in alarm/open in alarm, and alarm latch parameters.
- When the "input error output" parameter is set to ON, alarm output 1 turns ON when an input error occurs.

# **Control Adjustment**

• Optimum PID constants can be set easily by performing AT (auto-tuning) or ST (self-tuning).

### **Event Inputs**

 The following functions can be executed using event inputs: switching set points (multi-SP, 4 pts. max.), and switching RUN/STOP status, and switching between automatic and manual operation.

E5CZ-□2M□□ with E53-CZB or E53-CZHB

# Heater Burnout and HS Alarms

 The heater burnout detection function and the HS alarm function can be used.

E5CZ-□2M□□ with E53-CZH03 or E53-CZHB

E5AZ-□3HM□□ E5EZ-□3HM□□

# Communications Functions

 Communications functions utilizing CompoWay/F (See note 1.), SYSWAY (See note 2.), or Modbus (See note 3.) can be used.

RS-485 Interface

E5CZ-□2M□□ with E53-CZH03 or E53-CZ03


### Note

- (1) CompoWay/F is an integrated general-purpose serial communications protocol developed by OMRON. It uses commands compliant with the well-established FINS, together with a consistent frame format on OMRON Programmable Controllers to facilitate communications between personal computers and components.
- (2) SYSWAY communications do not support alarm 3 output.
- (3) Modbus is a communications control method conforming to the RTU Mode of Modicon Inc.'s Modbus Protocol.
- (4) The E5CZ and E5CZ-U do not support the RS-232C interface.

# 1-3 Setting Level Configuration and Key Operations

Parameters are divided into groups, each called a "level." Each of the set values (setting items) in these levels is called a "parameter." The parameters on the E5CZ/CZ-U/AZ/EZ are divided into the following seven levels.

When the power is turned ON, all of the display lights for approximately 1 second



# Note

- (1) Operation level entered for software reset.
- (2) From the manual control level, key operations can be used to move to the operation level only.

Level	Control in progress	Control stopped
Protect level	Can be set.	
Operation level	Can be set.	
Adjustment level	Can be set.	
Manual control level	Can be set.	
Initial setting level		Can be set.
Advanced function setting level		Can be set.
Communications setting level		Can be set.

Of these levels, the initial setting level, communications setting level, and advanced function setting level can be used only when control is stopped. Control outputs are stopped when any of these three levels is selected.

### **Protect Level**

To switch to the protect level from either the operation level or the adjustment level, simultaneously hold down the ○ and M keys for at least 3 seconds. (See note.) This level is for preventing unwanted or accidental modification of parameters. Protected levels will not be displayed, and so the parameters in that level cannot be modified.

**Note** The key pressing time can be changed in "move to protect level time" parameter (advanced function setting level).

### **Operation Level**

- The operation level is displayed when the power is turned ON. You can move to the protect level, initial setting level, or adjustment level from this level.
- Normally, select this level during operation. While operation is in progress, items such as the PV and manipulated variable (MV) can be monitored, and the set points, alarm values, and alarm upper and lower limits can be monitored and changed.

# **Adjustment Level**

- To move to the adjustment level, press the O key once (for less than 1 s).
- This level is for entering set values and offset values for control. In addition to AT (auto-tuning), communications write enable/disable switching, hysteresis settings, multi-SP settings, and input offset parameters, it includes HB alarm, HS alarm, and PID constants. From the adjustment level, it is possible to move to the top parameter of the initial setting level, protect level, or operation level.

### **Manual Control Level**

- When the O key is pressed for at least 3 seconds from the operation level's auto/manual switching display, the manual control level will be displayed. (The MANU indicator will light.)
- This is the level for changing the MV in manual mode.
- To return to the operation level, press the key for at least 1 second.

### **Initial Setting Level**

• To move to the initial setting level from the operation level or the adjustment level, press the O key for at least 3 seconds. The PV display flashes after 1 second. This level is for specifying the input type and selecting the control method, control period, setting direct/reverse action, and setting the alarm types. You can move to the advanced function setting level or communications setting level from this level. To return to the operation level, press the O key for at least 1 second. To move to the communications setting level, press the O key for less than 1 second. (When moving from the initial setting level to the operation level, all the indicators will light.)

**Note** Pressing the O key for at least 3 seconds in the operation level's auto/manual switching display will move to the manual control level, and not the initial setting level.

# Advanced Function Setting Level

- To move to the advanced function setting level, set the "initial setting/ communications protect" parameter in the protect level to 0 and then, in the initial setting level, input the password (–169).
- From the advanced function setting level, it is possible to move to the initial setting level.
- This level is for setting the automatic display return time, event input assignments, standby sequence, and alarm hysteresis.


### 11

# Communications Setting Level

 To move to the communications setting level from the initial setting level, press the O key once (for less than 1 s). When using the communications function, set the communications conditions in this level. Communicating with a personal computer (host computer) allows set points to be read and written, and manipulated variables (MV) to be monitored.

# 1-3-1 Selecting Parameters

 Within each level, the parameter is changed in order (or in reverse order) each time the M key is pressed. For details, refer to SECTION 5 Parameters.




# 1-3-2 Fixing Settings

- If you press the M key at the final parameter, the display returns to the top parameter for the current level.
- To change parameter settings, specify the setting using the U or D key, and either leave the setting for at least 2 seconds or press the M key. This fixes the setting.
- When another level is selected after a setting has been changed, the contents of the parameter prior to the change are fixed.
- When you turn the power OFF, you must first fix the settings (by pressing the M key). The settings are sometimes not changed by merely pressing the U or D keys.

# 1-4 Communications Function

The E5CZ/AZ/EZ is provided with a communications function that enables parameters to be checked and set from a host computer. If the communications function is required, use a model that has that function(E5CZ- $\square$ 2M $\square$  with E53-CZH03 or E53-CZ03, E5AZ- $\square$ 3 $\square$ M $\square$  with E53-AZ01 or E53-AZ03, E5EZ- $\square$ 3 $\square$ M $\square$  with E53-AZ01 or E53-AZ03). For details on the communications function, see the separate *Communications Manual*. Use the following procedure to move to the communications setting level.

- 1,2,3...
   Press the key for at least 3 seconds to move from the operation level to the initial setting level.
  - 2. Press the O key for less than 1 second to move from the initial setting level to the communications setting level.
  - 3. Select the parameters as shown below by pressing the M key.
  - 4. Press the U or D key to change the parameter setting.



Note

The "protocol setting" parameter is displayed only when CompoWay/F communications are being used.

# **Setting Communications Data**

Match the communications specifications of the E5CZ/AZ/EZ and the host computer. If a 1:N connection is being used, ensure that the communications specifications for all devices in the system (except the communications Unit No.) are the same.

Parameter	Symbol	Setting (monitor) value	Selection symbols	Default	Unit
Protocol setting	psel	CompoWay/F (SYSWAY), Modbus	cwf, mod	CompoWay/F (SYSWAY)	None
Communications Unit No.	u-no	0 to 99		1	None

Parameter	Symbol	Setting (monitor) value	Selection symbols	Default	Unit
Communications baud rate	bps	1.2, 2.4, 4.8, 9.6, 19.2, 38.4	1.2, 2.4, 4.8, 9.6, 19.2, 38.4	9.6	kbps
Communications data length	I en	7, 8		7	Bits
Communications stop bits	sbi t	1, 2		2	Bits
Communications parity	prty	None, Even, Odd	none, even, odd	Even	None
Send data wait time	sdwe	0 to 99		20	ms

# **SECTION 2 Preparations**

This section describes the work required to prepare the E5CZ and E5CZ-U Digital Temperature Controllers for operation, including installation and wiring.


2-1	Installation				
	2-1-1	Dimensions	16		
	2-1-2	Panel Cutout	17		
	2-1-3	Mounting	18		
	2-1-4	Removing the Temperature Controller from the Case	20		
2-2	Wiring	Terminals	21		
	2-2-1	Terminal Arrangement	21		
	2-2-2	Precautions when Wiring	22		
	2-2-3	Wiring	22		
2-3	Using t	he Support Software Port	27		

### 2-1 Installation

### 2-1-1 Dimensions


Unit: mm

E5CZ




**Note:** Do not remove the terminal block. Doing so may result in failure or malfunction.


### E5CZ-U



E5AZ



### E5EZ




### 2-1-2 Panel Cutout


Unit: mm

### E5CZ/CZ-U






### **Group Mounting**




E5AZ


**Individual Mounting** 



### **Group Mounting**



E5EZ




- Waterproofing is not possible when group mounting several Controllers.
- The recommended panel thickness is 1 to 5 mm for E5CZ/E5CZ-U, and 1 to 8 mm for E5AZ/E5EZ.
- Units must not be closely mounted vertically. (Observe the recommended mounting space limits.)
- When group mounting several Controllers, ensure that the surrounding temperature does not exceed the ambient operating temperature listed in the specifications.

### 2-1-3 Mounting

For the Wiring Socket, purchase the P2CF-11 or PG3A-11 separately.

### E5CZ/CZ-U




#### Mounting to the Panel

- For waterproof mounting, waterproof packing must be installed on the Controller. Waterproofing is not possible when group mounting several Controllers. Waterproof packing is not necessary when there is no need for the waterproofing function. There is no waterproof packing included with the E5CZ-U.
  - 2. Insert the E5CZ/E5CZ-U into the mounting hole in the panel.
  - 3. Push the adapter from the terminals up to the panel, and temporarily fasten the E5CZ/E5CZ-U.
  - 4. Tighten the two fastening screws on the adapter. Alternately tighten the two screws little by little to maintain a balance. Tighten the screws to a torque of 0.29 to 0.39 N·m.

#### **Mounting the Terminal Cover**

For the E5CZ, make sure that the "UP" mark is facing up, and then fit the terminal cover into the holes on the top and bottom.

#### E5AZ/EZ



### **Mounting to the Panel**

- For waterproof mounting, waterproof packing must be installed on the Controller. Waterproofing is not possible when group mounting several Controllers. Waterproof packing is not necessary when there is no need for the waterproofing function.
  - 2. Insert the E5AZ/E5EZ into the square mounting hole in the panel (thickness: 1 to 8 mm). Attach the Mounting Brackets provided with the product to the mounting grooves on the top and bottom surfaces of the rear case.
  - 3. Use a ratchet to alternately tighten the screws on the top and bottom Mounting Brackets little by little to maintain balance, until the ratchet turns freely.


### **Mounting the Terminal Cover**

Fit the E53-COV11 Terminal Cover over the upper hook. Mount it in the direction shown in the above diagram. If the terminal cover is mounted in the opposite direction, proper mounting of the fixtures may not be possible.

### 2-1-4 Removing the Temperature Controller from the Case

The Temperature Controller can be removed from the case to perform maintenance without removing the terminal leads. This is possible for only the E5CZ, E5AZ, and E5EZ, and not for the E5CZ-U. Check the specifications of the case and Temperature Controller before removing the Temperature Controller from the case.

#### E5CZ/AZ/EZ




- Insert a flat-blade screwdriver into the two tool insertion holes (one on the top and one on the bottom) to release the hooks.
  - Insert the flat-blade screwdriver in the gap between the front panel and rear case, and pull out the front panel slightly. Hold the top and bottom of the front panel and carefully pull it out toward you, without applying unnecessary force.
  - 3. When inserting the E5CZ/AZ/EZ, check to make sure that the sealing rubber is in place and push the E5CZ/AZ/EZ toward the rear case until it snaps into position. While pushing the E5CZ/AZ/EZ into place, push down on the hooks on the top and bottom surfaces of the rear case so that the hooks are securely locked in place. Be sure that electronic components do not come into contact with the case.


### 2-2 Wiring Terminals

### 2-2-1 Terminal Arrangement

### E5CZ




### E5CZ-U




**Note** For the Wiring Socket, purchase the P2CF-11 or PG3A-11 separately.

#### E5AZ/EZ



### 2-2-2 Precautions when Wiring

- Separate input leads and power lines in order to prevent external noise.
- Use AWG24 (cross-sectional area: 0.205 mm<sup>2</sup>) to AWG14 (cross-sectional area: 2.081 mm<sup>2</sup>) twisted-pair cable (stripping length: 5 to 6 mm).
- Use crimp terminals when wiring the terminals.
- Tighten the terminal screws to a torque of 0.74 to 0.90 N·m, except for the E5CZ-U, which is 0.5 N·m.
- Use the following types of crimp terminals for M3.5 screws.



Note

Do not remove the terminal block. Doing so may result in malfunction or failure.

### **2-2-3** Wiring

In the connection diagrams, the left side of the terminal numbers represents the inside of the Controller and the right side represents the outside.

**Power supply** 


• With the E5CZ, connect to terminals 9 and 10; with the E5CZ-U, connect to pins 10 and 11; with the E5AZ and E5EZ, connect pins 1 and 2. The following table shows the specifications.

Input power supply	E5CZ	E5CZ-U	E5AZ/EZ
100 to 240 VAC, 50/60 Hz	7.5 VA	6 VA	8.5 VA
24 VAC, 50/60 Hz	5.5 VA	4.5 VA	6 VA
24 VDC (no polarity)	3.5 W	2.5 W	4 W

 Reinforced insulation is applied between the input power supply, the relay outputs, and other terminals.

Input


 Make the connections as shown below, using terminals 3 to 5 for the E5CZ, pins 1 to 3 for the E5CZ-U, and pins 18 to 20 for the E5AZ/EZ, and matching the input types.




E5AZ/EZ

### **Control Output 1**

Outputs are sent from terminals 1 and 2 with the E5CZ, from pins 4 to 6
with the E5CZ-U, and from pins 3 and 4 with the E5AZ/EZ. The following
diagrams show the available outputs and their internal equalizing circuits.





E5AZ/EZ

• The following table shows the specifications for each output type.

### E5CZ/CZ-U

Output type	Specifications
Relay	250 VAC, 3 A (resistive load), electrical durability: 100,000 operations
Voltage (PNP)	PNP type, 12 VDC $\pm$ 15%, 21 mA (with short-circuit protection)
Current (Not for E5CZ-U)	DC 4 to 20 mA, resistive load: 600 $\Omega$ max. Resolution: Approx. 2,700


### E5AZ/EZ

Output type	Specifications		
Relay	250 VAC, 5 A (resistive load), electrical durability: 100,000 operations		
Voltage (PNP)	PNP type, 12 VDC +15%/–20%, 40 mA (with short-circuit protection)		
Current	DC 4 to 20 mA, resistive load: 600 $\Omega$ max. Resolution: Approx. 2,700		

- A voltage output (control output) is not electrically isolated from the internal circuits. When using a grounding thermocouple, do not connect any of the control output terminals to the ground. If control output terminals are connected to the ground, errors will occur in the measured temperature values as a result of leakage current.
- Control output 1 (Voltage output) is not isolated.

#### Alarm Outputs 1, 2, and 3

- On the E5CZ-□2M□□, alarm output 1 (ALM1) is output across terminals 7 and 8, and alarm output 2 (ALM2) is output across terminals 6 and 8.
- On the E5CZ- $\square$ 2T $\square$ U, alarm output 1 (ALM1) is output across terminals 7 and 8, and alarm output 2 (ALM2) is output across terminals 7 and 9.
- On the E5AZ/EZ- $\square 3 \square \square \square$ , alarm output 1 (ALM1) is output across terminals 9 and 10, alarm output 2 (ALM2) is output across terminals 7 and 8, and alarm output 3 (ALM3) is output across terminals 5 and 6.
- When the "input error output" parameter is set to ON, alarm output 1 turns ON when an input error occurs.
- When the HB alarm or the HS alarm is used with the E5CZ-□2M□□ with E53-CZH03 or E53-CZHB alarms are output across terminals 7 and 8.
- When the HB alarm or the HS alarm is used with the E5AZ-□3H□□□or the E5EZ-□3H□□□, alarms are output across terminals 9 and 10.
- On the E5CZ and E5CZ-U, when heating/cooling control is used, alarm output 2 becomes control output (cooling).
- On the E5AZ and E5EZ, when heating/cooling control is used, alarm output 3 becomes control output (cooling).
- For models that have a heater burnout alarm, an OR of alarm output 1 and the HB alarm/HS alarm is output. If ALM1 is to be used for HB alarm only, set the alarm 1 type to 0 and do not use alarm output 1.
- The following diagrams show the internal equalizing circuits for alarm outputs 1, 2, and 3.



ALM 1, 2, 3 can be output to alarm output 1, 2, 3, or changed with the advanced function setting level.

• The relay specifications are as follows:

E5CZ/CZ-U	SPST-NO 250 VAC 1 A		
E5AZ/EZ	SPST-NO 250 VAC 2 A		


**CT Inputs** 

- When the HB alarm or the HS alarm is to be used with the E5CZ-□2M□□ with E53-CZH03 or E53-CZHB, connect a current transformer (CT1) across terminals 14 and 15 (no polarity).
- When the HB alarm or the HS alarm is to be used with the E5AZ/EZ-□3H□□□, connect a current transformer (CT1) across terminals 14 and 15 (no polarity).



### **Event Inputs**


 When event inputs are to be used with the following models, connect to terminals 11 to 13. Option unit with two event inputs is required to be mounted.



- Use event inputs under the following conditions:
- The outflow current is approximately 7 mA.

Contact input	ON: 1 k $\Omega$ max., OFF: 100 k $\Omega$ min.
No-contact input	ON: Residual voltage 1.5 V max.; OFF: Leakage current 0.1 mA max.


Polarities during no-contact input are as follows:



### **Communications**

#### RS-485


 When communications are to be used with the following models, connect communications cable across terminals 11 and 12. Option unit with RS-485 communications is required to be mounted.




Specify both ends of the transmission path including the host computer as end nodes (that is, connect terminators to both ends).

The minimum terminal resistance is 54  $\Omega$ .

### **Communications Unit Connection Diagram**





The RS-485 connection can be either one-to-one or one-to-N. A maximum of 32 Units (including the host computer) can be connected in one-to-N systems. The maximum total cable length is 500 m. Use AWG24 (cross-sectional area: 0.205 mm²) to AWG14 (cross-sectional area: 2.081 mm²) shielded twisted-pair cable.




### RS-232C (E5AZ/E5EZ Only)

 When communications are to be used with the following models, connect communications cable across terminals 11 to 13. Option unit with RS-232C communications is required to be mounted.





- A 1:1 connection is used. The maximum cable length is 15 m. To extend the transmission path, use the OMRON Z3R RS-232C Optical Interface.
- Use AWG24 (cross-sectional area: 0.205 mm<sup>2</sup>) to AWG14 (cross-sectional area: 2.081 mm<sup>2</sup>) shielded twisted-pair cable.



### 2-3 Using the Support Software Port

Use the communications port for Support Software to connect the personal computer to the Temperature Controller when using Thermo-Mini or other Support Software. The E58-CIFQ1 USB-Serial Conversion Cable is required to make the connection.

For information concerning the models that can be used with Thermo-Mini, contact your OMRON sales representative.

Use the following procedure to connect the Temperature Controller to the personal computer using the USB-Serial Conversion Cable. The USB-Serial Conversion Cable is used to communicate with the COM port of the personal computer. To perform communications using USB-Serial Conversion Cable, set the communications port (COM port) number to be used for the software to the COM port assigned to the Cable.

**1.2.3...** 1. Turn ON the power to the Temperature Controller.


**Procedure** 

**Note** If the Cable is connected when the power to the Temperature Controller is OFF, power will be supplied from the personal computer and impose a load on the internal circuits of the Temperature Controller.

#### 2. Connect the Cable.

Connect the personal computer's USB port with the Support Software port on the Temperature Controller using the Cable.

• Temperature Controller Connection Method



**Note** Hold the connector when inserting or disconnecting the Cable.

#### 3. Install the driver.

Install the driver to enable the Cable to be used with the personal computer.

### Installation

When the Cable is connected with the personal computer, the OS detects the product as a new device. At this time, install the driver using the installation wizard. For details on installation methods, refer to the user's manual for the E58-CIFQ1 USB-Serial Conversion Cable.

### 4. Setting Setup Tool Communications Conditions

Set the communications port (COM port) number to be used for the Thermo-Mini Setup Tool to the COM port number assigned to the USB-Serial Conversion Cable.

Refer to the E58-CIFQ1 USB-Serial Conversion Cable *Instruction Manual* and *Setup Manual* for details on how to check the COM port assigned to the USB-Serial Conversion Cable.

The communications conditions for Setup Tool COM ports are fixed as shown in the table below. Set the communications conditions for the Thermo-Mini Setup Tool according to the following table.

### • Models without communications

Parameter	Set value
Communications Unit No	01
Communications baud rate	9.6 (kbps)
Communications data length	7 (bits)
Communications stop bits	2 (bits)
Communications parity	Even

### • Models with communications

The communications conditions for Setup Tool COM ports are not fixed. Set the communications conditions for the Thermo-Mini Setup Tool according to the set value of the Temperature controller.

## SECTION 3 Basic Operation

This section describes the basic operation of the E5CZ and E5CZ-U Digital Temperature Controllers, including key operations to set parameters and descriptions of display elements based on specific control examples.


3-1	Initial S	al Setting Examples		
3-2	Setting	the Input Type	34	
	3-2-1	Input Type	34	
3-3	Selectin	g the Temperature Unit	36	
	3-3-1	Temperature Unit	36	
3-4	Selectin	g PID Control or ON/OFF Control	36	
3-5	Setting Output Specifications			
	3-5-1	Control Periods	36	
	3-5-2	Direct and Reverse Operation	37	
	3-5-3	Assigned Output Functions	38	
3-6	Setting	the Set Point (SP)	40	
	3-6-1	Changing the SP	40	
3-7	Using C	ON/OFF Control	40	
	3-7-1	ON/OFF Control	40	
	3-7-2	Settings	41	
3-8	Determi	ining PID Constants (AT, ST, Manual Setup)	43	
	3-8-1	AT (Auto-tuning)	43	
	3-8-2	ST (Self-tuning)	44	
	3-8-3	Manual Setup	46	
3-9	Alarm (	Outputs	47	
	3-9-1	Alarm Types	47	
	3-9-2	Alarm Values	49	
3-10	Using H	IB and HS Alarms	50	
	3-10-1	HB and HS Alarm Operations	50	
	3-10-2	Installing Current Transformers (CT)	51	
	3-10-3	Calculating Detection Current Values	51	
	3-10-4	Application Examples	52	
	3-10-5	Settings (HB alarm)	53	
	3-10-6	Settings (HS Alarm)	54	

### 3-1 Initial Setting Examples


Initial hardware setup, including the sensor input type, alarm types, control periods, and other settings is done using parameter displays. The  $\bigcirc$  and  $\bowtie$  keys are used to switch between parameters, and the amount of time that you press the keys determines which parameter you move to.

This section describes two typical examples.


### **Explanation of Examples**




### Example 1



### Example 2





### 3-2 Setting the Input Type

The Controller supports four input types: platinum resistance thermometer, thermocouple, infrared temperature sensor, and analog inputs. Set the input type that matches the sensor that is used. In the product specifications, there are models with thermocouple/resistance thermometer inputs (universal-input) and models with analog input. The settings differ depending on the model. Check to make sure which model you are using.

### 3-2-1 Input Type

The following example shows how to set a K thermocouple for -20.0 to  $500.0^{\circ}\text{C}$ .

### **Operating Procedure**

Operation Level



1. Press the O key for at least three seconds to move from the operation level to the initial setting level.

Initial Setting Level



Input type



2. Press the U key to enter the set value of the desired sensor. When you use a K thermocouple (−20.0 to 500.0°C), enter 6 as the set value.

**Hint:** The key operation is fixed two seconds after the change, or by pressing the ○ or M key.

### **List of Input Types**

	Input type	Specifications	Set value	Input temperature setting range
Controllers	Platinum resistance	Pt100	0	-200 to 850 (°C)/-300 to 1,500 (°F)
with Ther-	thermometer		1	-199.9 to 500.0 (°C)/-199.9 to 900.0 (°F)
mocouple/ Resistance			2	0.0 to 100.0 (°C)/0.0 to 210.0 (°F)
Thermome-		JPt100	3	-199.9 to 500.0 (°C)/-199.9 to 900.0 (°F)
ter Univer- sal-input			4	0.0 to 100.0 (°C)/0.0 to 210.0 (°F)
Sal-Iliput	Thermocouple	K	5	-200 to 1,300 (°C)/-300 to 2,300 (°F)
			6	−20.0 to 500.0 (°C)/0.0 to 900.0 (°F)
		J	7	-100 to 850 (°C)/-100 to 1,500 (°F)
			8	−20.0 to 400.0 (°C)/0.0 to 750.0 (°F)
		Т	9	-200 to 400 (°C)/-300 to 700 (°F)
			10	-199.9 to 400.0 (°C)/-199.9 to 700.0 (°F)
		E	11	0 to 600 (°C)/0 to 1,100 (°F)
		L	12	-100 to 850 (°C)/-100 to 1,500 (°F)
		U	13	-200 to 400 (°C)/-300 to 700 (°F)
			14	-199.9 to 400.0 (°C)/-199.9 to 700.0 (°F)
		N	15	-200 to 1,300 (°C)/-300 to 2,300 (°F)
		R	16	0 to 1,700 (°C)/0 to 3,000 (°F)
		S	17	0 to 1,700 (°C)/0 to 3,000 (°F)
		В	18	100 to 1,800 (°C)/300 to 3,200 (°F)
	Infrared temperature	10 to 70°C	19	0 to 90 (°C)/0 to 190 (°F)
	sensor ES1B	60 to 120°C	20	0 to 120 (°C)/0 to 240 (°F)
		115 to 165°C	21	0 to 165 (°C)/0 to 320 (°F)
		140 to 260°C	22	0 to 260 (°C)/0 to 500 (°F)
	Analog input	0 to 50 mV	23	Either of the following ranges, by scaling: -1,999 to 9,999 -199.9 to 999.9

- The default is 5.
- If a platinum resistance thermometer is mistakenly connected while a setting for other than a platinum resistance thermometer is in effect, S.ERR will be displayed. To clear the S.ERR display, check the wiring and then turn the power OFF and back ON.

	Input type	Specifications	Set value	Input temperature setting range
	Current input	4 to 20 mA	0	Either of the following ranges, by scaling:
analog		0 to 20 mA	1	-1,999 to 9,999  -199.9 to 999.9
input -	Voltage input	1 to 5 V	2	-19.99 to 99.99
		0 to 5 V	3	-1.999 to 9.999
		0 to 10 V	4	

• The default is 0.

#### 3-3 Selecting the Temperature Unit

#### 3-3-1 **Temperature Unit**

- Either °C or °F can be selected as the temperature unit.
- Set the temperature unit in the "temperature unit" parameter of the initial setting level. The default is c (°C).

### **Operating Procedure**


The following example shows how to select °C as the temperature unit.

Operation Level



Press the O key for at least three seconds to move from the operation level to the initial setting level.

Initial Setting Level




Input type

Select the "temperature unit" parameter by pressing the M key. Press the U or D key to select either °C or °F.

c: °C

f: °F



To return to the operation level, press the O key for at least one second. Temperature unit 3.

#### Selecting PID Control or ON/OFF Control 3-4

Two control methods are supported: 2-PID control and ON/OFF control. Switching between 2-PID control and ON/OFF control is executed by means of the "PID ON/OFF" parameter in the initial setting level. When this parameter is set to pi d, 2-PID control is selected, and when set to onof, ON/OFF control, is selected. The default is onof.

2-PID Control

PID control is set by AT (auto-tuning), ST (self-tuning), or manual setting. For PID control, set the PID constants in the "proportional band" (P), "integral


time" (I), and "derivative time" (D) parameters.

**ON/OFF Control** 

In ON/OFF control, the control output is turned ON when the process value is lower than the current set point, and the control output is turned OFF when the process value is higher than the current set point (reverse operation).

#### 3-5 **Setting Output Specifications**

#### 3-5-1 Control Periods




- Set the output periods (control periods). Though a shorter period provides better control performance, it is recommended that the control period be set to 20 seconds or longer for a relay output to preserve the service life of the relay. After the settings have been made in the initial setup, readjust the control period, as required, by means such as trial operation.
- Set the control periods in the "control period (heating)" and "control period (cooling)" parameters in the initial setting level. The default is 20 seconds.
- The "control period (cooling)" parameter is used only for heating/cooling control.
- When control output 1 is used as a current output, "control period (heating)" cannot be used.

### 3-5-2 Direct and Reverse Operation



• "Direct operation" increases the manipulated variable whenever the process value increases. "Reverse operation" decreases the manipulated variable whenever the process value increases.



Direct operation

Reverse operation

For example, when the process value (PV) is lower than the set point (SP) in a heating control system, the manipulated variable increases according to the difference between the PV and SP. Accordingly, reverse operation is used in a heating control system. Direct operation is used in a cooling control system, in which the operation is the opposite of a heating control system.

• Direct/reverse operation is set in the "direct/reverse operation" parameter in the initial setting level. The default is or-r (reverse operation).

#### **Operating Procedure**

In this example, the input type, temperature unit, direct/reverse operation, and control period (heating) parameters are checked.

Input type = s (K thermocouple)

Temperature unit = C (°C)

Direct/reverse operation = or-r (reverse operation)


Control period (heating) = 20 (seconds)

Operation Level



 Press the O key for at least three seconds to move from the operation level to the initial setting level.

Initial Setting Level



 The input type is displayed. When the input type is being set for the first time, s (K thermocouple) is set. To select a different sensor, press the U or D key.



Temperature unit 3.

Select the "temperature unit" parameter by pressing the M key. The default is c (°C). To select f (°F), press the U key.



 Select the "control period (heating)" parameter by pressing the M key. The default is 20.

### Setting Output Specifications



Select the "direct/reverse operation" parameter by pressing the M key.
 The default is or-r (reverse operation). To select or-d (direct operation), press the U key.

Operation Level



6. To return to the operation level, press the O key for at least one second.

### 3-5-3 Assigned Output Functions

- Function assignments can be changed by changing the settings for control and alarm assignments.
- The default function assignments for each output are shown below.

Parameter name	Symbol	Initial status
Control output 1 assignment	out1	Control output (heating)
Alarm output 1 assignment	alm1	Alarm 1
Alarm output 2 assignment	alm2	Alarm 2
Alarm output 3 assignment (E5AZ/EZ only)	alm3	Alarm 3

 Each output is automatically initialized as shown below by changing the control mode.

### **Example: E5CZ**

Parameter name	Symbol	Standard	Heating/cooling
Control output 1 assignment	out1	Control output (heating)	Control output (heating)
Alarm output 1 assignment	alm1	Alarm 1	Alarm 1
Alarm output 2 assignment	alm2	Alarm 2 (See note.)	Control output (cooling) (See note.)

Note

For the E5AZ/EZ, alarm 3 is assigned for control output (cooling) (alarm output 2 is assigned for alarm 2).

In this manual, assigned control outputs and alarm outputs are indicated as follows: "Control output 1 must be assigned" or "Alarm 1 must be assigned."

### **Operating Procedure**


The following example sets the following control and alarm assignments. Control output 1: Control output (heating); Alarm output 1: Alarm 1; Alarm output 2: Control output (cooling).

Operation Level



1. Press the O key for at least 3 seconds to move from the operation level to the initial setting level.

Initial Setting Levell




Select the "standard or heating/cooling" parameter by pressing the M key.

Initial Setting Level



Initial Setting Level



Move to advanced function setting level

3. Press the U key to set the parameter to h-c.

**Note** The following output assignments do not need to be set because they are set automatically by changing the control mode, but they are shown here as a reference for checking the assignments for each output.

Select the "move to advanced function setting level" parameter by pressing the M key.

Advanced Function Setting Level



Parameter initialization

5. Press the D key to enter the password ("–169"), and move from the initial setting level to the advanced function setting level.

Advanced Function Setting Level



Control output 1 assignment

6. Select the "alarm output 1 assignment" parameter by pressing the M key.



7. Press the U or D key to set o. (The default is o.)

Advanced Function Setting Level



Select the "alarm output 1 assignment" parameter by pressing the M key.



Press the U or D key to set al m1. (The default is al m1.)

Advanced Function Setting Level E5CZ



Alarm output 2 assignment

10. Select the "alarm output 2 assignment" parameter by pressing the M key.

(The default of the E5CZ is c-o.)

E5AZ/EZ



(The default of the E5AZ/EZ is al m2.)



11. Press the U or D key to set c-o.

Initial Setting Level



Input type

12. Press the ○ key for at least one second to move from the advanced function setting level to the initial setting level.

#### Operation Level



13. Press the O key for at least one second to move from the initial setting level to the operation level.

### 3-6 Setting the Set Point (SP)

#### Operation Level



The operation level is displayed when the power is turned ON. The process value (PV) is at the top of the display, and the set point (SP) is at the bottom.

### 3-6-1 Changing the SP

- The set point cannot be changed when the "operation/adjustment protect" parameter is set to 3. For details, refer to 4-9 Using the Key Protect Level.
- To change the set point, press the U or D key in the "process value/set point" parameter (in the operation level), and set the desired set value.
   The new set point is selected two seconds after you have specified the new value.
- Multi-SP is used to switch between two or four set points. For details, refer to 4-5 Using Event Inputs for details.

### **Operating Procedure**

In this example, the set point is changed from 0°C to 200°C.

Operation Level





1. Normally, the "process value/set point" parameter is displayed. The set point is 0°C.

2. Use the U and D keys to set the set point to 200°C.

### 3-7 Using ON/OFF Control


In ON/OFF control, the control output turns OFF when the temperature being controlled reaches the preset set point. When the manipulated variable turns OFF, the temperature begins to fall and the control turns ON again. This operation is repeated over a certain temperature range. At this time, how much the temperature must fall before control turns ON again is determined by the "hysteresis (heating)" parameter. Also, what direction the manipulated variable must be adjusted in response to an increase or decrease in the process value is determined by the "direct/reverse operation" parameter.

### 3-7-1 ON/OFF Control

• Switching between 2-PID control and ON/OFF control is performed using the "PID ON/OFF" parameter in the initial setting level. When this parameter is set to pi d, 2-PID control is selected, and when it is set to onof, ON/OFF control is selected. The default is onof.


### **Hysteresis**

- With ON/OFF control, hysteresis is used to stabilize operation when switching between ON and OFF. The control output (heating) and control output (cooling) functions are set in the "hysteresis (heating)" and "hysteresis (cooling)" parameters, respectively.
- In standard control (heating or cooling control), the setting of the "hysteresis (heating)" parameter in the adjustment level is used as the hysteresis regardless of whether the control type is heating control or cooling control.



# Three-position Control

• In heating/cooling control, a dead band (an area where both control outputs are 0) can be set to either the heating or cooling side. This makes it possible to use 3-position control.



#### <u>Parameters</u>

Symbol	Parameter: Level	Application
s-hc	Standard or heating/cooling: Initial setting level	Specifying control method
cntl	PID ON/OFF: Initial setting level	Specifying control method
orev	Direct/reverse operation: Initial setting level	Specifying control method
c-db	Dead band: Adjustment level	Heating/cooling control
C-SC	Cooling coefficient: Adjustment level	Heating/cooling control
hys	Hysteresis (heating): Adjustment level	ON/OFF control
chys	Hysteresis (cooling): Adjustment level	ON/OFF control

### 3-7-2 Settings

To execute ON/OFF control, set the "set point," "PID ON/OFF," and "hysteresis" parameters.

### Setting the "PID ON/OFF" Parameter

### **Operating Procedure**

Confirm that the "PID ON/OFF" parameter is set to onof in the initial setting level.

Operation Level




1. Press the O key for at least three seconds to move from the operation level to the initial setting level.

### Using ON/OFF Control

### Section 3-7

Initial Setting Level



2. The "input type" parameter is displayed in the initial setting level.



3. Select the "PID ON/OFF" parameter by pressing the M key.

- 4. Check that the set value is onof (i.e., the default).
- 5. To return to the operation level, press the O key for at least one second. Next, set the set point value.

### **Setting the SP**

### **Operating Procedure**

In this example, the set point is set to 200. The set value (i.e., the SP) is shown at the bottom of the display.

Operation Level



1. Select the "process value/set point" parameter in the operation level.



2. Use the U and D keys to set the SP. (In this example, it is set to 200.) The new set value can be fixed by pressing the M key, or it will go into effect after two seconds have elapsed.

Next, set the hysteresis.

### **Setting the Hysteresis**

### **Operating Procedure**

Set the hysteresis to 2.0°C.

Operation Level



1. Press the O key to move from the operation level to the adjustment level.



AT execute/ cancel 2. The "AT execute/cancel" parameter will be displayed in the adjustment level.



Hysteresis (heating)

3. Select the "Hysteresis (heating)" parameter by pressing the M key.




- 4. Press the U and D keys to set the hysteresis (2.0 in this example). Either press the M key or wait for at least two seconds after setting the hysteresis value to confirm the setting.
- 5. To return to the operation level, press the O key for at least one second.

### 3-8 Determining PID Constants (AT, ST, Manual Setup)

### 3-8-1 AT (Auto-tuning)



- When AT is executed, the optimum PID constants for the set point at that time are set automatically. A method (called the limit cycle method) for forcibly changing the manipulated variable and finding the characteristics of the control object is employed.
- To execute AT, specify on (AT execute), and to cancel AT, specify off (AT cancel).
- AT cannot be executed when control has stopped or during ON/OFF control.
- The results of AT are reflected in the "proportional band" (P), "integral time" (I), and "derivative time" (D) parameters in the adjustment level.



### **AT Operations**

AT is started when the "AT execute/cancel" parameter is set to ON. During execution, the "AT execute/cancel" parameter on the No. 1 display flashes. When AT ends, the "AT execute/cancel" parameter turns OFF, and the No. 1 display stops flashing.



AT execution in progress

If you move to the operation level during AT execution, the No. 2 display flashes to indicate that AT is being executed.



Only the "communications writing," "RUN/STOP," and "AT execution/cancel" parameters can be changed during AT execution. Other parameters cannot be changed.

### **Operating Procedure**

This procedure executes auto-tuning (AT).

Adjustment Level



1. Press the O key to move from the operation level to the adjustment level.




2. Press the U key to start execution of AT (auto-tuning). on will be displayed during AT execution.



3. off will be displayed when AT ends.





4. To return to the operation level, press the O key.

### 3-8-2 ST (Self-tuning)



ST (auto-tuning) is a function that finds PID constants by using step response tuning (SRT) when Controller operation begins or when the set point is changed.

Once the PID constants have been calculated, ST is not executed when the next control operation is started as long as the set point remains unchanged.

ST (self-tuning) is enabled when the "ST" parameter is set to ON in the initial setting level.

When the ST function is in operation, be sure to turn the power supply of the load connected to the control output ON simultaneously with or before starting Controller operation.

When executing self-tuning, turn ON power for the load (e.g., heater) at the same time as or before supplying power to the Digital Temperature Controller. If power is turned ON for the Digital Temperature Controller before turning ON power for the load, self-tuning will not be performed properly and optimum control will not be achieved.

#### Note


#### PID Constants

When control characteristics are already known, PID constants can be set directly to adjust control. PID constants are set in the "proportional band" (P), "integral time" (I), and "derivative time" (D) parameters in the adjustment level.


#### **Operating Procedure**

This procedure executes self-tuning (ST).

Initial Setting Level



1. Press the O key for at least three seconds to move from the operation level to the initial setting level.



- 2. Select the "ST" parameter by pressing the M key.
- 3. Press the U key to select on. ON is the default.



4. To return to the operation level, press the ○ key. The temperature display flashes during self-tuning (ST) execution.

### **Startup Conditions**

Self-tuning by step response tuning (SRT) is started when the following conditions are met after program execution is started and the set point is changed.

At start of operation	When set point is changed
<ol> <li>The set point at the start of operation differs from the set point when the previous SRT was executed. (See note 1.)</li> <li>The difference between the temperature at the start of operation and the set point is greater both of the following: (Present proportional band × 1.27 +</li> </ol>	<ol> <li>The new set point differs from the set point used when the previous SRT was executed. (See note 1.)</li> <li>The set point change width is greater both of the following: (Present proportional band × 1.27 + 4°C) and the ST stable range.</li> </ol>
<ul> <li>4°C) and the ST stable range.</li> <li>3. The temperature at the start of operation is lower than the set point during reverse operation, and is larger than the set point during direct operation.</li> <li>4. There is no reset from input errors.</li> </ul>	<ul> <li>3. During reverse operation, the new set point is larger than the set point before the change; and during direct operation, the new set point is smaller than the set point before the change.</li> <li>4. The temperature is stable. (See note 2.) (Equilibrium with the output amount at 0% when the power is turned ON is also all right.) (See note 3.)</li> </ul>

Note

- (1) The previous SRT-implemented set point is the set point that was used for calculating the PID constants for the previous SRT.
- (2) In this state, the measurement point is within the ST stable range.
- (3) In this state, the change width of the PV every 60 seconds is within the ST stable range or less.

In the following instances, PID constants are not changed by self-tuning (ST) for the present set point.

1,2,3...

- 1. When the PID constants have been changed manually with ST set to ON.
- 2. When auto-tuning (AT) has been executed.


### ST Stable Range

### **Operating Procedure**

The ST stable range determines the condition under which ST (self-tuning) functions.

This procedure sets the ST stable range to 20°C..

Advanced Function Setting Level



. Select the "ST stable range" parameter by pressing the M key in the advanced function setting level.



2. Use the U key to set the parameter to 20°C.

### 3-8-3 Manual Setup

Individual PID constants can be manually set in the "proportional band," "integral time," and "derivative time" parameters in the adjustment level.

### **Operating Procedure**

In this example, the "proportional band" parameter is set to 10.0, the "integral time" parameter to 250, and the "derivative time" parameter to 45.


Adjustment Level




1. Press the O key to move from the operation level to the adjustment level.



2. Press the M key to select the "proportional band" parameter.



3. Use the U and D keys to set 10.0.



4. Press the M key to select the "integral time" parameter.



5. Use the U and D keys to set 250.



6. Select the "derivative time" operation by pressing the M key.




- 7. Use the U and D keys to set 45.
- 8. To return to the operation level, press the O key.

### **Note** Proportional Action

When PID constants I (integral time) and D (derivative time) are set to 0, control is executed according to proportional action. As the default, the center value of the proportional band becomes the set point.

Related parameter: Manual reset value (adjustment level)

### When P (Proportional Band) Is Adjusted




Alarm Outputs Section 3-9

### When I (Integral Time) Is Adjusted

Increased	Set value	It takes a long time to reach the set point. It takes time to achieve a stable state, but overshooting, undershooting, and hunting are reduced.
Decreased	Set Value	Overshooting and undershooting occur. Hunting occurs. The Controller starts up faster.

### When D (Derivative Time) Is Adjusted



### 3-9 Alarm Outputs

- Alarms can be used by the E5CZ-□2M□□ (2 alarm outputs), E5AZ/EZ-□3□□□□ (3 alarm outputs), or the E5CZ-□2T□U (2 alarm outputs).
   Alarm outputs are determined by a combination of "alarm type," "alarm value," and "alarm hysteresis" alarm output conditions. For details, refer to 4-2 Alarm Hysteresis.
- This section describes the "alarm type," "alarm value," "upper-limit alarm" and "lower-limit alarm" parameters.

### 3-9-1 Alarm Types


Set value	Alarm type	Alarm output operation		
		When alarm value X is positive	When alarm value X is negative	
0	Alarm function OFF	Output OFF		
1(See note 1.)	Upper- and lower-limit	ON OFF SP	See note 2.	
2	Upper-limit	ON OFF SP	ON → X ← OFF SP	
3	Lower-limit	ON SP	ON OFF SP	
4 (See note 1.)	Upper- and lower-limit range	ON JL H	See note 3.	
5 (See note 1.)	Upper- and lower-limit with standby sequence	ON SP SP See note 5.	See note 4.	
6	Upper-limit with standby sequence	ON SP	ON → X : OFF SP	
7	Lower-limit with standby sequence	ON -XX-	ON SP	

Alarm Outputs Section 3-9


Set value	Alarm type	Alarm output operation		
		When alarm value X is positive	When alarm value X is negative	
8	Absolute-value upper- limit	ON OFF 0	ON OFF 0	
9	Absolute-value lower- limit	ON OFF 0	ON OFF 0	
10	Absolute-value upper- limit with standby sequence	ON OFF 0	ON OFF 0	
11	Absolute-value lower- limit with standby sequence	ON OFF 0	ON OFF 0	
12	LBA (alarm 1 type only)			

#### Note

- (1) With set values 1, 4, and 5, the upper- and lower-limit values can be set independently for each alarm type, and are expressed as "L" and "H."
- (2) Set value: 1 (Upper- and lower-limit alarm)



(3) Set value: 4 (Upper-and lower-limit range)



- (4) Set value: 5 (Upper- and lower-limit with standby sequence)
  - For the upper-and lower-limit alarms in cases 1 and 2 above, the alarm is always OFF if upper- and lower-limit hysteresis overlaps.
  - In case 3, the alarm is always OFF.
- (5) Set value: 5 (Upper- and lower-limit with standby sequence)
  - The alarm is always OFF if upper- and lower-limit hysteresis overlaps.
- Set the alarm type independently for each alarm in the "alarm 1 to 3 type" parameters in the initial setting level. The default is 2 (Upper-limit alarm).

Alarm Outputs Section 3-9

lower limit" parameters in the operation level.

### 3-9-2 Alarm Values
















### **Operating Procedure**

This procedure sets alarm 1 as an upper-limit alarm. The related parameters and settings are shown below. The alarm is output when the set point exceeds  $10^{\circ}$ C. (In this example, the temperature unit is  $^{\circ}$ C.)

Alarm values are indicated by "X" in the table on the previous page. When

upper limit values, and "L" is displayed for lower limit values.


the upper and lower limits are set independently, "H" is displayed for

• To set the alarm value upper and lower limits for deviation, set the upper and lower limits in each of the "alarm 1 to 3 upper limit," and "alarm 1 to 3


Alarm 1 type = 2 (Upper-limit alarm)

Alarm value 1= 10

Initial Setting Level




1. Press the O key for at least three seconds to move from the operation level to the initial setting level.



 Select the "alarm 1 type" parameter by pressing the M key. Confirm that the set value is 2. The default value is 2 (Upper-limit alarm).



3. To return to the operation level, press the O key for at least one second.



4. Select the "alarm value 1" parameter by pressing the M key.



5. Use the  $\cup$  key to set the parameter to 10.


# 3-10 Using HB and HS Alarms

# 3-10-1 HB and HS Alarm Operations

 Heater burnout detection is executed by measuring heater current while the control output for heating is ON, and HS detection is executed by measuring heater current while it is OFF. For details, refer to the following table

(Heater burnout detection and HS detection cannot be used with the control output for cooling.)


Heating control output status		Power to heater	HB alarm output	HS alarm output
Control output (heating)	Operation indicator			
ON	Lit	Yes (Normal) (See note 1.)	OFF	
		No (Heater burnout)	ON	
OFF	Not lit	Yes (HS alarm)		ON
		No (Normal) (See note 2.)		OFF



Note

- (1) In the above diagram, power is considered to be ON (normal) if the heater current is greater than the heater burnout detection current during the Ton interval. If the heater is burned out, the measured current decreases and falls below the heater burnout detection value. The output is then activated as the heater burnout alarm.
- (2) In the above diagram, power is considered to be OFF (normal) if the leakage current is less than the HS alarm current during the Toff interval. If the SSR output is short-circuited, the measured current increases beyond the HS alarm value. The output is then activated as the HS alarm.
- (3) Heater burnouts are not detected if the control output (heating) ON time (Ton) is 190 ms or less.
- (4) HS are not detected if the control output (heating) OFF time (Toff) is 190 ms or less.
- For models with HB and HS alarms, an OR output is established between the ALM 1 function and the HB/HS alarm. If the ALM1 function is to be used for HB and HS alarms only, set 0 as the ALM1 type and do not use ALM1.
- Turn the heater power ON simultaneously or before turning ON the E5□Z power. If the heater power is turned ON after turning ON the E5□Z power, the HB alarm will be activated.
- Control is continued even when the HB or HS alarm is active.
- The rated current value may sometimes differ slightly from the actual current flowing to the heater.
  - Use the "heater current 1 value monitor," and "leakage current 1 monitor," parameters to check the actual current being used.

 If there is little difference between the current in normal and abnormal states, detection may become unstable. To stabilize detection, set a current value difference of at least 1.0 A for heaters of less than 10.0 A, and at least 2.5 A for heaters of 10.0 A or more. If the heater current is too low, loop the load line several times through a CT, as shown in the diagram below. Looping it through once will double the detection current.



# 3-10-2 Installing Current Transformers (CT)


 This function can be used with E5□Z models that have the HB alarm and HS alarm.

For the E5CZ, connect the CT in advance to terminals 14 and 15 (CT1). For the E5AZ/EZ, connect the CT in advance to terminals 14 and 15 (CT1). Then pass the heater power line through the CT's hole.

For specifications, models and dimensions of current transformers that can be used with this Controller, see *Appendix A Current Transformer* (CT) page 153.

**Single-phase Heaters** 

For single-phase heaters, install the CT in the position shown in the following diagram.



# 3-10-3 Calculating Detection Current Values

• Calculate the set value using the following equation:

HS Alarm 1 set value = Leakage current value (output OFF) + HS current value 2

- To set the current for heater burnout when two or more heaters are connected through the CT, use the value from when the heater with the smallest current burns out. If all of the heaters have the same current, use the value from when any one of them burns out.
- Make sure that the following conditions are satisfied:

Heater with a current of less than 10.0 A:

(Current value at normal operation) – (Current value at heater burnout)  $\geq$  1 A

When the difference is less than 1 A, detection is unstable.

Heater with a current of 10.0 A or more:

(Current value at normal operation) – (Current value at heater burnout)  $\geq$  2.5 A

When the difference is less than 2.5 A, detection is unstable.


- The setting range is 0.1 to 49.9 A. Heater burnout and HS are not detected when the set value is 0.0 or 50.0.
  - When the set value is 0.0, the heater burnout alarm is always OFF, and the HS alarm is always ON.
  - When the set value is 50.0, the heater burnout alarm is always ON, and the HS alarm is always OFF.
- Set the total current value for normal heater operation to 50 A or less.
   When a current value of 55.0 A is exceeded, ffff is displayed in the "heater current 1 value monitor" and "leakage current 1 monitor" parameters.


# 3-10-4 Application Examples

Single-phase Heaters

Example: Using a 200-VAC, 1-kW Heater

Burnout






The heater power supply provides 5 A when the current is normal, and 0 A when there is a burnout, so the heater burnout detection current is calculated as follows:

Heater burnout detection current =  $\frac{\text{(Normal current)} + \text{(Heater burnout current)}}{2}$ =  $\frac{5+0}{2}$  = 2.5 [A]

Example: Using Three 200-VAC, 1-kW Heaters



The heater power supply provides 15 A when the current is normal, and 10 A when there is a burnout, so the heater burnout detection current is calculated as follows:

Heater burnout detection current = 
$$\frac{\text{(Normal current)} + \text{(Heater burnout current)}}{2}$$
  
=  $\frac{15 + 10}{2}$  = 12.5 [A]

# 3-10-5 Settings (HB alarm)

To activate the heater burnout alarm, set the "heater burnout detection" parameter to ON in the advanced function setting level and set the "heater burnout detection 1" parameter in the adjustment level.

#### **Operating Procedure**

This procedure sets the "heater burnout detection 1" parameter to 2.5.

#### Moving to the Advanced Function Setting Level


The "heater burnout detection" parameter setting is already ON by default, so set the "heater burnout detection 1" parameter.

#### Operation Level



Move to the advanced function setting level.
 Press the O key for at least three seconds to move from the operation level to the initial setting level.

#### Initial Setting Level



2. Select "move to advanced function setting level" by pressing the M key.

#### Initial Setting Level



3. Press the D key to enter the password (−169), and move from the initial setting level to the advanced function setting level.

Advanced Function Setting Level

The top parameter in the advanced function setting level is displayed.





 Select the "heater burnout detection" parameter by pressing the M key. Check that this parameter is set to ON (the default). Next, set the "heater current 1 value monitor" parameter.

#### **Setting Heater Burnout Detection**

#### Operation Level



5. Press the O key for at least one second to move from the advanced function setting level to the initial setting level and then to the operation level.

#### Adjustment Level



Press the ○ key for less than one second to move from the operation level to the adjustment level.



Heater current 1 value monitor Select the "heater current 1 value monitor" parameter by pressing the M
key. Check the current value. Next, set the "heater burnout detection 1"
parameter.



8. Select the "heater burnout detection 1" parameter by pressing the M key. Refer to 3-10-3 Calculating Detection Current Values on page 51 when making the settings.



9. For this example, set 2.5. To return to the operation level, press the O key for less than one second.

# 3-10-6 Settings (HS Alarm)

To activate the HS alarm, set the "HS alarm use" parameter to ON in the advanced function setting level and set the "HS alarm 1" parameter in the adjustment level.

#### **Operating Procedure**

This procedure sets the "HS alarm 1" parameter to 2.5.

#### Moving to the Advanced Function Setting Level


The "HS alarm use" parameter setting is already ON by default, so set the "HS alarm 1" parameter.

#### Operation Level



Move to the advanced function setting level.
 Press the O key for at least three seconds to move from the operation level to the initial setting level.

Initial Setting Level



2. Select "move to advanced function setting level" by pressing the  $\ensuremath{\mathsf{M}}$  key.

Initial Setting Level



3. Press the D key to enter the password (−169), and move from the initial setting level to the advanced function setting level.

Advanced Function Setting Level

The top parameter in the advanced function setting level is displayed.





 Select the "HS alarm use" parameter by pressing the M key. Check that this parameter is set to ON (the default). Next, set the "leakage current 1 monitor" parameter.

#### **HS Alarm Settings**

#### Operation Level



5. Press the O key for at least one second to move from the advanced function setting level to the initial setting level and then to the operation level.

#### Adjustment Level



6. Press the O key for less than one second to move from the operation level to the adjustment level.




Leakage current 1 monitor

7. Select the "leakage current 1 monitor" parameter by pressing the M key. Check the current value. Next, set the "HS alarm 1" parameter.



HS alarm 1





9. For this example, set 2.5. To return to the operation level, press the O key for less than one second.

# **SECTION 4 Applications Operations**

This section describes scaling, the SP ramp function, and other special functions that can be used to make the most of the functionality of the E5CZ and E5CZ-U Digital Temperature Controllers.

4-1	Shifting	g Input Values
	4-1-1	Shifting Inputs
	4-1-2	How to Calculate Input Shift Values for a 2-point Shift
4-2	Alarm 1	Hysteresis
	4-2-1	Standby Sequence
	4-2-2	Alarm Latch
	4-2-3	Close in Alarm/Open in Alarm
4-3	Setting	Scaling Upper and Lower Limits for Analog Inputs
	4-3-1	Analog Input
4-4	Executi	ng Heating/Cooling Control
	4-4-1	Heating/Cooling Control
	4-4-2	Settings
4-5	Using I	Event Inputs
	4-5-1	Event Input Settings
	4-5-2	How to Use the Multi-SP Function
	4-5-3	Settings
	4-5-4	Executing Run/Stop Control
	4-5-5	Switching between Auto and Manual Control
4-6	Setting	the SP Upper and Lower Limit Values
	4-6-1	Set Point Limiter
	4-6-2	Setting
4-7	Using t	he SP Ramp Function to Limit the SP Change Rate
	4-7-1	SP Ramp
4-8	Moving	to the Advanced Function Setting Level
4-9	Using t	he Key Protect Level
	4-9-1	Protection
4-10	Alarm 1	Delays
	4-10-1	Alarm Delays
4-11	Loop B	reak Alarm
	4-11-1	Loop Break Alarm (LBA)
4-12	Perforn	ning Manual Control
	4-12-1	Manual Operation

4-13	Using th	e Transfer Output	88
	4-13-1	Transfer Output Function	88
4-14	Output A	Adjustment Functions	91
	4-14-1	Output Limits	91

# 4-1 Shifting Input Values

# 4-1-1 Shifting Inputs


The input shift matched to the sensor currently selected in the "input type" parameter is displayed.

- A 2-point shift is applied for infrared temperature sensors. A 2-point shift can also be used if the "input shift type" parameter (advanced function setting level) is set to INS2 for a thermocouple or platinum resistance thermometer.
- There is no shift for analog inputs. Use scaling for fine adjustments.

#### One-point shift



With a 1-point shift, the value set for the "temperature input shift" parameter (adjustment level) is applied to each point in the entire temperature input range. For example, if the input shift value is set to 1.2°C, the process value is treated as 201.2°C after the input shift is applied when the measured process value is 200°C.



#### **Operating Procedure**

In this example, the input from a K sensor is shifted by 1°C using a 1-point input shift.

Operation Level



Operation Level


Adjustment Level



1. Press the O key to move from the operation level to the adjustment level.



2. Select the "temperature input shift" parameter by pressing the  $\ensuremath{\mathsf{M}}$  key.




3. Press the U or D key to set 1.0.






4. To return to the operation level, press the ○ key. The process value is 1°C larger than before the shift was applied.

#### **Two-point shift**



input shift value

- Separate shift values can be set for the upper limit and lower limit of the sensor input range for an infrared sensor as well as for a thermocouple or platinum resistance thermometer with the "input shift type" set to INS2. If different shift values are set for the upper limit and lower limit, then the slope of the line will be different before and after applying the input shift. For example, if the upper-limit value is set to 2°C and the lower-limit value is set to 1°C, the input temperature will be shifted by 1.5°C for a 50% input, i.e., by the average of the upper-limit and lower-limit values.
- Set the upper-limit value in the "upper-limit temperature input shift value" parameter and the lower-limit value in the "lower-limit temperature input shift value" parameter.



# 4-1-2 How to Calculate Input Shift Values for a 2-point Shift

When an ES1B Infrared Temperature Sensor is connected to the E5CZ, an offset of several degrees to several tens of a degree can occur.

For this reason, offset the readout value using a 1-point or 2-point shift as described in this section. This offset occurs because a bias current for detecting a Controller sensor error flows to the output impedance of the infrared temperature sensor.

#### **Preparations**

- Set a temperature range matching the input specifications of the infrared temperature sensor. (The ES1B can be used with the E5AZ only for a thermocouple/resistance thermometer Universal-input type input.)
  - 2. Prepare a thermometer capable of measuring the temperature of the control target as shown in *Figure 1* so that a 1-point shift or 2-point shift can be carried out.
  - 3. When ES1B is used, provide a separate power supply for the Infrared Temperature Sensors.




Figure 1 Offset Configuration for an Infrared Temperature Sensor

#### Method for a 1-point Shift

1,2,3...

1. In the configuration shown in *Figure 1*, bring the set point to near the value at which the temperature of the control target is to be controlled. Assume that the control target temperature (C) and the thermocouple temperature (B) are the same.





- 2. Check the control target temperature (B) and the Controller readout (A). Subtract the Controller readout temperature (A) from the control target temperature (B), and set i nsl and i nsh to the result as the input shift value. The shift is illustrated in *Figure 2*.
- After setting the input shift values, check the Controller readout (A) and the
  control target temperature (B). If they are almost the same, this completes
  shifting the temperature input.




Figure 2 Illustration of 1-Point Shift

# Method for a 2-point Shift

Use a 2-point input shift if you want to increase the accuracy of the readout values across the range of the sensor.

Shift the Controller readout at two points, near room temperature and near the value at which the temperature of the control target is to be controlled. For this reason, check the control target temperature (B) and Controller readout (A) with the control object temperature near room temperature and

Use the following formulas with the readouts checked above and the desired temperature values to calculate the input shift values for the upper-limit and lower-limit temperatures of the measurement range and set the upper-limit and lower-limit temperature input shift values.

The shift is illustrated in Figure 3.

near the set point.




Figure 3 Illustration of 2-Point Shift

a. Lower-limit temperature input shift value

$$IN5L = \frac{YL - Y1}{Y2 - Y1} \times \{(X2 - Y2) - (X1 - Y1)\} + (X1 - Y1)$$

b. Upper-limit temperature input shift value

$$\overline{L}N5H = \frac{YH - Y1}{Y2 - Y1} \times \{(X2 - Y2) - (X1 - Y1)\} + (X1 - Y1)$$

- 3. After setting the calculated values to i nsl and i nsh, check the Controller readout (A) and control target temperature (B).
- 4. Here, offsets are set at two points, near room temperature and near the set point. To improve accuracy within the measurement temperature range, another point in the measurement temperature range other than the set point should be set instead of room temperature.

# Example of a 2-point Temperature Input Shift

In this example, we use the ES1B K 140 to 260°C specification. In equations 1 and 2, the set temperature lower limit YL is 0°C and the set temperature upper limit YH is 260°C. Check the temperature of the control target.

The temperature input offset values can be calculated as shown below when the Controller readout Y1 is 40°C for a room temperature X1 of 25°C and when the Controller readout Y2 is 105°C for a set point temperature X2 of 110°C.

Alarm Hysteresis Section 4-2

Lower-limit Temperature Input Shift Value

$$IN5L = \frac{0-40}{105-40} \times \{(110-105) - (25-40)\} + (25-40) = -27.3 \ (^{\circ}\text{C})$$

Upper-limit Temperature Input Shift Value




$$\overline{L}N5H = \frac{260 - 40}{105 - 40} \times \{(110 - 105) - (25 - 40)\} + (25 - 40) = 52.7 \, (^{\circ}C)$$

# 4-2 Alarm Hysteresis



 The hysteresis of alarm outputs when alarms are switched ON/OFF can be set as follows:



- Alarm hysteresis is set independently for each alarm in the "alarm hysteresis 1" to "alarm hysteresis 3" parameters (advanced function setting level).
- The default is 0.2 (°C/°F) for Controllers with Thermocouple/Resistance Thermometer Universal-inputs and 0.02% FS for Controllers with Analog Inputs.

# 4-2-1 Standby Sequence

- The standby sequence can be used so that an alarm will not be output until the process value leaves the alarm range once and then enters it again.
- For example, with a lower limit alarm, the process value will normally be below the set point, i.e., within the alarm range, when the power supply is turned ON, causing an alarm to be output.

If the lower limit alarm with a standby sequence is selected, an alarm will not be output until the process value increases above the alarm set value, i.e., until it leaves the alarm range, and then falls back below the alarm set value.

Restart

 The standby sequence is canceled when an alarm is output. It is, however, restarted later by the "standby sequence reset" parameter (advanced function setting level). For details, refer to the "standby sequence reset" parameter in SECTION 5 Parameters.

#### 4-2-2 Alarm Latch

- The alarm latch can be used to keep the alarm output ON regardless of the temperature once the alarm output has turned ON. The alarm output will turn OFF when the power is turned OFF.
- The alarm output can also be turned OFF by switching to the initial setting level, communications setting level, or advanced function setting level.

Alarm Hysteresis Section 4-2

# 4-2-3 Close in Alarm/Open in Alarm

 When "close in alarm" is set, the status of the alarm output function will be output as is. When "open in alarm" is set, the status of the alarm output function will be reversed before being output.


- Close in alarm/open in alarm can be set separately for each alarm.
- Close in alarm/open in alarm is set in the "alarm 1 open in alarm" to "alarm 3 open in alarm" parameters (advanced function setting level).
- The default is n-o (close in alarm).
- When "alarm 1 open in alarm" (advanced function setting level) is set to "open in alarm," the heater burnout alarm and input error output are also set to "open in alarm."

Setting	Alarm output function	Alarm output	Alarm indicator
Close in alarm	ON	ON	Lit
	OFF	OFF	Not lit
Open in alarm	ON	OFF	Lit
	OFF	ON	Not lit

• The alarm outputs will turn OFF (i.e., the relay contacts will open) when power is interrupted and for about two seconds after the power is turned ON regardless of the close in alarm/open in alarm setting.

# Summary of Alarm Operation

The following figure summarizes the operation of alarms when the alarm type is set to "lower-limit alarm with standby sequence" and "close in alarm" is set.



#### **Parameters**

Symbol	Parameter: Level	Description
al h*	Alarm 1 to 3 hysteresis: Advanced function setting level	Alarm
rest	Standby sequence: Advanced function setting level	Alarm
al *n	Alarm 1 to 3 open in alarm: Advanced function setting level	Alarm

**Note** \* = 1 to 3

# 4-3 Setting Scaling Upper and Lower Limits for Analog Inputs


# 4-3-1 Analog Input

Scaling upper limit

Scaling lower limit


Decimal point

- When an analog input is selected, scaling can be performed as needed by the control application.
- Scaling is set in the "scaling upper limit," "scaling lower limit," and "decimal point" parameters (initial setting level). These parameters cannot be used when a temperature input is selected.
- The "scaling upper limit" parameter sets the physical quantity to be expressed by the upper limit value of input, and the "scaling lower limit" parameter sets the physical quantity to be expressed by the lower-limit value of input. The "decimal point" parameter specifies the number of digits below the decimal point.
- The following figure shows a scaling example for a 4 to 20 mV input.
   After scaling, the humidity can be directly read. Here, one place below the decimal point is set.





#### **Operating Procedure**

Initial Setting Level



Scaling upper limit







100

In this example scaling is set to display 4 to 20 mA as 10.0% to 95.0%.

- 1. Press the O key for three seconds to move from the operation level to the initial setting level.
- 2. Select "scaling upper limit" by pressing the M key.
- 3. Use the  $\cup$  and  $\square$  keys to set the parameter to 950.
- 4. Select the "scaling lower limit" parameter by pressing the M key.
- 5. Press the U and D keys to set 100.
- 6. Select the "decimal point" parameter by pressing the M key.



7. Press the U and D keys to set 1.

8. To return to the operation level, press the O key for one second.

# 4-4 Executing Heating/Cooling Control

# 4-4-1 Heating/Cooling Control

Heating/cooling control operates when h-c (heating/cooling) is selected for the "standard or heating/cooling" parameter.

The following functions are assigned to outputs in the initial status.

Parameter name	Symbol	Initial status
Control output 1 assignment	out1	Control output for heating
Alarm output 1 assignment	alm1	Alarm 1
Alarm output 2 assignment	al m2	Alarm 2
Alarm output 3 assignment (E5AZ/EZ only)	alm3	Alarm 3

Each output is automatically initialized as shown below when the control mode is changed.

#### **Example: E5CZ**

Parameter name	Symbol	Standard	Heating/cooling
Control output 1 assignment	out1	Control output for heating	Control output for heating
Alarm output 1 assignment	alm1	Alarm 1	Alarm 1
Alarm output 2 assignment	alm2	Alarm 2 (See note.)	Control output for cooling (See note.)

Note


For the E5AZ/EZ, alarm 3 is assigned for control output (cooling) (alarm output 2 is assigned for alarm 2).

- The heating/cooling operation of the control outputs will switch when the "direct/reverse operation" parameter is set to "direct."
- When heating/cooling control is selected, the "dead band" and "cooling coefficient" parameters can be used.

In this manual, assigned control outputs and alarm outputs are indicated as follows: "Control output 1 must be assigned" or "Alarm 1 must be assigned."

#### **Dead Band**

- For heating/cooling control, the dead band is set with the set point as its center. The dead band width is the set value of the "dead band" parameter (adjustment level). Setting a negative value produces an overlapping band.
- If an overlapping band is set, the bumpless function may not operate when switching between manual operation and automatic operation.
- The default is 0.0 EU for Controllers with Thermocouple/Resistance Thermometer Universal-inputs and 0.00% FS for Controllers with Analog Inputs.




#### **Cooling Coefficient**

If the heating characteristics and cooling characteristics of the control object are very different and good control characteristics cannot be achieved with the same PID constants, the cooling coefficient can be used to adjust the proportional band (P) for the control output assigned to the cooling side. Use this to achieve balanced control between the heating side and cooling side. The proportional bands (P) for the control outputs assigned to the heating/cooling sides can be calculated using the following equations.

P for control output assigned to heating side = P

P for control output assigned to cooling side = P for control output assigned to heating side  $\times$  cooling coefficient

The cooling coefficient is multiplied by the P for the control output assigned to the heating side to obtain control with characteristics that differ from those of the control output assigned to the heating side.



# 4-4-2 Settings

To set heating/cooling control, set the "standard or heating/cooling," "dead band," and "cooling coefficient" parameters.

### **Setting Heating/Cooling Control**

### **Operating Procedure**

Standard or heating/cooling = Heating/cooling

Initial Setting Level



1. Press the O key for at least three seconds to move from the operation level to the initial setting level.

2. Select "heating/cooling control" in the initial setting level.

1. Select the "cooling coefficient" in the adjustment level.

1. Select the "dead band" parameter in the adjustment level.

stnd: Standard control

h-c: Heating/cooling control

# **Setting the Cooling Coefficient**

#### **Operating Procedure**

Cooling Coefficient = 10

Adjustment Level



Cooling coefficient



2. Use the  $\cup$  key to set the parameter to 10.00.

# **Setting the Dead Band**

#### **Operating Procedure**

Dead Band = 5

Adjustment Level



Dead band



2. Use the U key to set the parameter to 5.0.

Using Event Inputs Section 4-5

# 4-5 Using Event Inputs

# 4-5-1 Event Input Settings

Event inputs can be used for the multi-SP function, starting/stopping operation (RUN/STOP), and switching between auto/manual.

- Of these, the multi-SP function, event inputs are used only for the number (0 to 2) set in the "number of multi-SP uses" parameter (advanced function setting level).
- Event inputs (1 and 2) that are not used for the multi-SP function are assigned using the "event input assignment 1" and "event input assignment 2" parameters (advanced function setting level).
- Event inputs can be used on the following Controllers:

E5CZ-□2M□□ with E53-CZB or E53-CZHB


E5AZ-□3□M□□ with E53-AZB

E5EZ-\(\sigma\) M\(\sigma\) with E53-AZB

Parameter		Set	ting	Event inputs	
		Event input assignment 1	Event input assignment 2	Function of event input 1	Function of event input 2
Number of multi-SP	0 (See note.)	NONE, STOP, MANU		None, or switching RUN/STOP, or switching auto/manual	
uses	1	(Not displayed.)	NONE, STOP, MANU	Multi-SP, 2 points (switching set points 0 and 1)	None, or switching RUN/STOP, or auto/ manual
	2	(Not displayed.)		Multi-SP, 4 points (swit 3)	ching set points 0, 1, 2,

Note

If the "number of multi-SP uses" is set to 0, and both input assignments 1 and 2 can be set. Once "STOP" (RUN/STOP), or "MANU" (auto/manual) has been assigned to one event input, the other event can be assigned only to either of the remaining two settings.



When you are setting two externally input set points, set in the "number of multi-SP uses" parameter.

• Switching is possible between two set points (0 and 1) by setting the "number of multi-SP uses" parameter to 1.

The default setting is 1 and does not need to be changed to switch between two set points.

Set point 0 or 1 is specified by the ON/OFF state of event input 1.

#### 4-5-2 How to Use the Multi-SP Function

The multi-SP function allows you to set up to four set points (SP 0 to 3) in the adjustment level. The set point can be switched by operating the keys on the front panel or by using external input signals (event inputs).

#### **Using Event Inputs**

Event inputs can be used if the Controller supports the event input function and if the "number of multi-SP uses" parameter is set to 1 or 2.

Using Event Inputs Section 4-5

#### Number of Multi-SP Uses = 1

Event input 1	Selected set point	
OFF	Set point 0	
ON	Set point 1	

#### Number of Multi-SP Uses = 2

Event input 1	Event input 2	Selected set point
OFF	OFF	Set point 0
ON	OFF	Set point 1
OFF	ON	Set point 2
ON	ON	Set point 3

Note

Event inputs can be used on the following Controllers. E5CZ- $\square$ 2M $\square$  $\square$  with E53-CZB or E53-CZHB, E5AZ- $\square$ 3 $\square$ M $\square$  $\square$  with E53-AZB, E5EZ- $\square$ 3 $\square$ M $\square$  $\square$  with E53-AZB. Turn the event inputs ON or OFF while the E5AZ is turned ON. Event input ON/OFF changes are detected for inputs of 50 ms or longer.

#### **Using Key Operations**

You can select any of the set points 0 to 3 by changing the set value of the "multi-SP uses" parameter. The "multi-SP uses" display conditions are as follows:

- If the Controller does not support event inputs, the "multi-SP uses" parameter must be set to ON.
- If the Controller supports event inputs, the "number of multi-SP uses" parameter must be set to 0 and the "multi-SP uses" parameter must be set to ON.

The following table shows the relationship between the "multi-SP uses" parameter set value and the selected set point.

Multi-SP	Selected set point
0	Set point 0
1	Set point 1
2	Set point 2
3	Set point 3

**Note** The set point can also be switched using communications.

**Using Event Inputs** Section 4-5

#### 4-5-3 **Settings**

#### Switching between Set Points 0, 1, 2, and 3

#### **Operating Procedure**


The following example sets the "number of multi-SP uses" parameter to 2.

Operation Level



Press the O key for at least three seconds to move from the operation level to the initial setting level.

Initial Setting Level



Select the "move to advanced function setting level" parameter by pressing the M key.



3. Use the D key to enter "-169" (the password).

Advanced Function Setting Level




Parameter initialization Move to the advanced function setting level by pressing the M key or leaving the setting for at least two seconds.

Number of Multi-SP Uses Setting

4. Select the "number of multi-SP uses" parameter by pressing the M key.




Number of multi-SP uses




5. Use the  $\cup$  key to set the parameter to 2.

- To return to the initial setting level, press the O key for at least one second.
- 7. To return to the operation level, press the O key for at least one second.

Set points 0, 1, 2 and 3 will be set according to the ON/OFF states of event inputs 1 and 2.





Using Event Inputs Section 4-5

Event input assignments 1 and 2 are as follows according to the setting of the "number of multi-SP uses" parameter:

Paramet	er	Set	ting	Event	inputs
		Event input assignment 1	Event input assignment 2	Function of event input 1	Function of event input 2
Number of multi-SP	0	Event input assignment (See note.)	Event input assignment (See note.)	Specified event input function	Specified event input function
uses		NONE	Event input assignment	None	Specified event input function
		Event input assignment	NONE	Specified event input function	None
		NONE	NONE	None	None
	1	(Setting data not displayed.)	Event input assignment	Multi-SP, 2 points (switching set points 0 and 1)	Specified event input function
		(Setting data not displayed.)	NONE	Multi-SP, 2 points (switching set points 0 and 1)	None
	2	(Setting data not displayed.)	(Setting data not displayed.)	Multi-SP, 4 points (switching set points 0, 1, 2, 3	

**Note** One of the settings.

# 4-5-4 Executing Run/Stop Control

When the "event input assignment 1" or "event input assignment 2" parameter is set to STO (RUN/STOP), control is started when event input 1 or 2 turns OFF. Control is stopped when the input turns ON. Alarm outputs, however, will be according to the process value.

The STOP indicator will light while control is stopped.

Setting	Input contact	Status
Event input 1 or 2	ON	STOP
Event input 1 or 2	OFF	RUN

# 4-5-5 Switching between Auto and Manual Control

When the "event input assignment 1" or "event input assignment 2" parameter is set to MANU (auto/manual), manual control will start when event input 1 or 2 turns ON. Auto control will start when the input turns OFF.

The MANU indicator will light during manual control.

Setting	Input contact	Status
Event input 1 or 2	OFF	Automatic
Event input 1 or 2	ON	Manual


#### **Parameters**

Symbol	Parameter: Level	Description
ev-1	level	Function of event input func-
ev-2	Event input assignment 2: Advanced function setting level	tion
ev-m	Number of multi-SP uses: Advanced function setting level	

# 4-6 Setting the SP Upper and Lower Limit Values

#### 4-6-1 Set Point Limiter

The setting range of the set point is limited by the set point limiter. The set point limiter is used to prevent the control target from reaching abnormal temperatures. The upper- and lower-limit values of the set point limiter are set using the "set point upper limit" and "set point lower limit" parameters in the initial setting level. When the set point limiter is reset, the set point is forcibly changed to the upper- or lower-limit value of the set point limiter if the set point is out of the limiter range. Also, when the input type and temperature unit are changed, the set point limiter is forcibly reset to the sensor setting range.




#### **Parameters**

Symbol	Parameter: Level	Description
sl -h	Set point upper limit: Initial setting level	To limit the SP setting
sl -l	Set point lower limit: Initial setting level	To limit the SP setting

# 4-6-2 Setting


Set the set point upper and lower limits in the "set point upper limit" and "set point lower limit" parameters in the initial setting level. In this example, it is assumed that the input type is set to a K thermocouple with a temperature range of -200 to  $1300^{\circ}$ C.




# Setting the Set Point Upper-limit Value

**Operating Procedure** 

Set Point Upper Limit = 1000



1. Press the O key for at least three seconds to move from the operation level to the initial setting level.



2. Select the "set point upper limit" parameter.




3. Use the U and D keys to set the parameter to 1000.

#### Setting the Set Point Lower-limit Value

#### **Operating Procedure**

Set Point Lower Limit = −100



1. Select the "set point lower limit" parameter in the initial setting level.




2. Use the  $\cup$  and  $\square$  keys to set the parameter to -100.

# 4-7 Using the SP Ramp Function to Limit the SP Change Rate

# 4-7-1 SP Ramp

The SP ramp function is used to restrict the width of changes in the set point as a rate of change. When the SP ramp function is enabled and the change width exceeds the specified rate of change, an area where the set point is restricted will be created, as shown in the following diagram.

During the SP ramp, control will be performed not for the specified set point but rather for the set point restricted by the rate of change set for the SP ramp function.



The rate of change during SP ramp is specified using the "SP ramp set value" and "SP ramp time unit" parameters. The "SP ramp set value" parameter is set to OFF by default, i.e., the SP ramp function is disabled.

Changes in the set point during SP ramp can be monitored in the "Set point during SP ramp" parameter (operation level). Use this parameter when monitoring SP ramp operation.


The SP ramp function operates in the same way when switching the set point using the multi-SP function.

#### **Parameters**

Symbol	Parameter: Level	Description
ol -h	MV upper limit: Adjustment level	To limit the manipulated variable
ol -l	MV lower limit: Adjustment level	To limit the manipulated variable
sl -h	Set point upper limit: Initial setting level	To limit the SP setting
sl -l	Set point lower limit: Initial setting level	To limit the SP setting
sprt	SP ramp set value: Adjustment level	To limit the SP rate of change
spru	SP ramp time unit: Advanced function setting level	Unit for setting the SP

#### **Operation at Startup**

If the SP ramp function is enabled when the Controller is turned ON or when switching from STOP to RUN mode, the process value reaches the set point using the SP ramp function in the same way as when the set point is changed. In this case, operation is carried out with the process value treated as the set point before the change was made. The direction of the SP ramp changes according to the relationship between the process value and the set point.




# Restrictions during SP Ramp Operation

- Execution of auto-tuning starts after the end of the SP ramp.
- When control is stopped or an error occurs, the SP ramp function is disabled.

# Alarms during SP Ramp Operation

The operation of alarms during SP ramp operation is illustrated as follows.



# 4-8 Moving to the Advanced Function Setting Level

To move to the advanced function setting level, you must first cancel the protection applied by the "initial setting/communications protect" parameter.

In the default setting, the advanced function setting level is protected and you cannot move to this setting level.

1,2,3...


1. Press the ○ and M keys simultaneously for at least three seconds in operation level.

**Note** The key pressing time can be changed in the "move to protect level time" parameter (advanced function setting level).

Protect Level



2. The Controller moves to the protect level, and the "operation/adjustment protect" parameter is displayed.



Press the M key once to move to the "initial setting/communications protect" parameter.




4. Set the set value to 0.

#### Operation Level



5. Press the ○ and M keys simultaneously for at least one second to return to the operation level.

#### Initial Setting Level



Input type

Move to the advanced function setting level.
 Press the O key for at least three seconds to move from the operation level to the initial setting level.

#### Initial Setting Level



7. Select the "move to advanced function setting level" parameter by pressing the M key.


#### Advanced function setting level



Parameter initialization

8. Press the D key, enter the password (–169), and then either press the M key or leave the setting for at least two seconds to move to the advanced function setting level from the initial setting level.

#### Initial Setting Level



To return to the initial setting level, press the O key for at least one second.

#### Operation Level



10. To return to the operation level, press the ○ key for at least one second.

# 4-9 Using the Key Protect Level

#### 4-9-1 Protection

• To move to the protect level, press the O and M keys simultaneously for at least three seconds in operation level or adjustment level. (See note.)

**Note** The key pressing time can be changed in the "move to protect level time" parameter (advanced function setting level).

 The protect level protects parameters that are not changed during Controller operation until operation is started to prevent them from being modified unintentionally.

There are three types of protection: operation/adjustment protect, initial setting/communications protect, and setting change protect.

 The protect level settings restrict the range of parameters that can be used.

# Operation/Adjustment Protect



The following table shows the relationship between set values and the range of protection.

Level		Set value			
		0	1	2	3
Operation level	PV	Can be dis- played	Can be dis- played	Can be dis- played	Can be dis- played
	PV/SP	Can be dis- played and changed	Can be dis- played and changed	Can be dis- played and changed	Can be dis- played
	Others	Can be dis- played and changed	Can be dis- played and changed	Cannot be displayed and moving to other levels is not possible	Cannot be displayed and moving to other levels is not possible
Adjustment level		Can be dis- played and changed	Cannot be displayed and moving to other levels is not possible	Cannot be displayed and moving to other levels is not possible	Cannot be displayed and moving to other levels is not possible

- Parameters are not protected when the set value is set to 0.
- The default is 0.

#### Initial Setting/ Communications Protect



This protect level restricts movement to the initial setting level, communications setting level, and advanced function setting level.

Set value	Initial setting level	Communications setting level	Advanced function setting level
0	Movement possible	Movement possible	Movement possible
1	Movement possible	Movement possible	Movement not possible
2	Movement not possible	Movement not possible	Movement not possible

• The default is 1.

# Setting Change Protect



This protect level restricts key operations.

Set value	Description		
OFF	Settings can be changed using key operations.		
ON	Settings cannot be changed using key operations. (The protect level settings, however, can be changed.)		

- The default is OFF.
- The all protect indication ( ) will light when setting change protect is set.


Alarm Delays Section 4-10

# 4-10 Alarm Delays

# 4-10-1 Alarm Delays

• Delays can be set for the alarm outputs. ON and OFF delays can be set separately for alarms 1, 2, and 3. The ON and OFF delays for alarm 1 function only for the alarm function. If the alarm output 1 is set to be output as an OR with other alarm functions (i.e., the heater burnout alarm, HS alarm, or input error output alarm), the delays will not function for the other alarms. The ON and OFF delays for alarms 1, 2, and 3 also apply to the individual ALM1, ALM2, and ALM3 indicators and to communications status. The alarm ON delays will also function when power is turned ON or when moving from initial setting level to operation level (i.e., to software resets). All outputs will turn OFF and the OFF delays will not function when moving to the initial setting level or when an alarm is output for a heater burnout error.

### Operation of Alarm ON and OFF Delays (for an Upper-limit Alarm)



- The alarm will not turn ON if the time that the alarm is ON is equal to or less than the ON delay set time. Also, the alarm will not turn OFF if the time that the alarm is OFF is equal to or less than the OFF delay set time.
- If an alarm turns OFF and then back ON during the ON delay time, the time will be remeasured from the last time the alarm turns ON. Also, if an alarm turns ON and then back OFF during the OFF delay time, the time will be remeasured from the last time the alarm turns OFF.

#### Parameters Related to Alarm Delays

Parameter name	Symbol	Set (monitor) values
Alarm 1 ON delay	a1on	0 to 999 (s)
Alarm 2 ON delay	a2on	0 to 999 (s)
Alarm 3 ON delay	a3on	0 to 999 (s)
Alarm 1 OFF delay	a1of	0 to 999 (s)
Alarm 2 OFF delay	a2of	0 to 999 (s)
Alarm 3 OFF delay	a3of	0 to 999 (s)

Alarm Delays Section 4-10

Note

- (1) The defaults are 0, i.e., the ON and OFF delays are disabled.
- (2) The parameters are displayed when alarm outputs are assigned and when the alarm type is set to any type but 0 (none).


#### **Operating Procedure**

Use the following procedure to set ON and OFF delays for the alarm 1 output. An ON delay of 5 seconds and an OFF delay of 10 s will be set.

#### Operation Level



Initial Setting Level



1. Press the O key for at least three seconds to move from the operation level to the initial setting level.

#### Initial Setting Level



2. Select the "move to advanced function setting level" parameter by pressing the M key.

Advanced Function Setting Level



3. Press the D key to enter the password (−169) and move from the initial setting level to the advanced function setting level.

Advanced Function Setting Level

4. Press the M key to select the "alarm 1 ON delay" parameter.





5. Press the U key to set the parameter to 5.

Advanced Function Setting Level


6. Press the M key to select the "alarm 1 OFF delay" parameter.





7. Press the  $\cup$  key to set the parameter to 10.

#### Initial Setting Level



8. Press the O key for at least one second to move from the advanced function setting level to the initial setting level.

#### Operation Level



9. Press the O key for at least one second to move from the initial setting level to the operation level.


Loop Break Alarm Section 4-11

# 4-11 Loop Break Alarm

# 4-11-1 Loop Break Alarm (LBA)

 With a loop break alarm, there is assumed to be an error in the control loop if the control deviation (SP – PV) is greater than the threshold set in the "LBA level" parameter and if the control deviation is not reduced by at least the value set in the "LBA detection band" parameter within the LBA detection time.

Loop break alarms are detected at the following times.



If the control deviation is reduced in the area between 1 and 2 (i.e., the set point is approached) and the amount the control deviation is reduced is at least equal to the LBA band, the loop break alarm will remain OFF.

The process value is within the LBA level between 3 and 4, and thus loop break alarms will not be detected. (The loop break alarm will remain OFF.)

If the process value is outside the LBA level between 4 and 5 and the control deviation is not reduced by at least the LBA band within the LBA detection time, the loop break alarm will turn ON.

If the control deviation is reduced in the area between 5 and 6 (i.e., the set point is approached) and the amount the control deviation is reduced is at least equal to the LBA band, the loop break alarm will turn OFF.

If the control deviation is reduced in the area between 6 and 7 (i.e., the set point is approached) and the amount the control deviation is reduced is less than the LBA band, the loop break alarm will turn ON.

- If the LBA detection time, LBA level, LBA detection band, and PID settings are not appropriate, alarms may be detected inappropriately or alarms may not be output when necessary.
- Loop break alarms may be detected if unexpectedly large disturbances occur continuously and a large deviation does not decrease.
- If a loop break occurs when the set point is near the ambient temperature, the temperature deviation in a steady state may be less than the LBA level, preventing detection of the loop break.
- If the set point is so high or low that it cannot be reached even with a saturated manipulated variable, a temperature deviation may remain even in a steady state and a loop break may be detected.

Loop Break Alarm Section 4-11

- Detection is not possible if a fault occurs that causes an increase in temperature while control is being applied to increase the temperature (e.g., an SSR short-circuit fault).
- Detection is not possible if a fault occurs that causes a decrease in temperature while control is being applied to decrease the temperature (e.g., a heater burnout fault).

#### Parameters Related to Loop Break Alarms

Parameter name	Symbol	Setting	g range	Remarks
LBA detection time	I ba	0 to 9999 (s)		Setting 0 disables the LBA function.
LBA level	I bal	Controllers with Thermo- couple/Resistance Ther- mometer Universal-inputs	0.1 to 999.9 (°C/°F) (See note.)	Default: 8.0 (°C/°F)
		Controllers with Analog Inputs	0.01 to 99.99 (%FS)	Default: 10.00% FS
LBA band	I bab	Controllers with Thermo- couple/Resistance Ther- mometer Universal-inputs	0.0 to 999.9 (°C/°F) (See note.)	Default: 3.0 (°C/°F)
		Controllers with Analog Inputs	0.00 to 99.99 (%FS)	Default: 0.20% FS

**Note** Set "none" as the unit for analog inputs.


- A loop break alarm can be output by setting the alarm 1 type to 12 (LBA).
- The ALM1 indicator will light when a loop break is detected.
- Loop breaks are not detected during SP ramp operation.
- Loop breaks are not detected during auto-tuning, manual operation, or while stopped.
- If the alarm 1 latch is set to ON, the latch will be effective for the loop break alarm.

# Automatically Setting the LBA Detection Time

- The LBA detection time is automatically set by auto-tuning. (It is not set automatically, however, for heating/cooling control.)
- If the optimum LBA detection time is not obtained by auto-tuning, set the "LBA detection time" parameter (advanced function setting level).

# Determining the LBA Detection Time

- To manually set the LBA detection time, set the "LBA detection time" parameter to twice the LBA reference time given below.
- **1,2,3...** 1. Set the output to the maximum value.
  - 2. Measure the time required for the width of change in the input to reach the LBA band.



Loop Break Alarm Section 4-11

3. Set the "LBA detection time" parameter to two times the measured time.

#### **LBA Level**

- Set the control deviation when the control loop is working properly.
- The default is 8.0 (°C/°F) for Controllers with Thermocouple/Resistance Thermometer Universal-inputs and 10.00% FS for Controllers with Analog Inputs.

#### **LBA Band**

- There is assumed to be an error in the control loop if the control deviation is greater than the threshold set in the "LBA level" parameter and if the control deviation does not change by at least the value set in the "LBA band" parameter.
- The default is 3.0 (°C/°F) for Controllers with Thermocouple/Resistance Thermometer Universal-inputs and 0.20% FS for Controllers with Analog Inputs.

#### **Operating Procedure**


Perform the following procedure to use the loop break alarm.

In this example, the LBA detection time is set to 10, the LBA level is set to 8.0, and the LBA band is set to 3.0.

#### Operation Level




Initial Setting Level



1. Press the O key for at least three seconds to move from the operation level to the initial setting level.

Initial Setting Level

2. Select the "alarm 1 type" parameter by pressing the  $\ensuremath{\mathsf{M}}$  key.



Initial Setting Level



3. Press the U key to set the parameter to 12.





4. Select the "move to advanced function setting level" parameter by pressing the M key.


Advanced Function Setting Level



5. Press the D key to enter the password (−169), and move from the initial setting level to the advanced function setting level.




6. Select the "LBA detection time" parameter by pressing the M key.



LBA detection time

#### **Performing Manual Control**



7. Press the U key to set the parameter to 10.

Advanced Function Setting Level

8. Select the "LBA level" parameter by pressing the M key.



LBA level



9. Press the U key to set the parameter to 8.0. (The default is 8.0.)

Advanced Function Setting Level

10. Select the "LBA band" parameter by pressing the M key.




LBA band



11. Press the U or D key to set the parameter to 3.0. (The default is 3.0.)





12. Press the ○ key for at least one second to move from the advanced function setting level to the initial setting level.





13. Press the O key for at least one second to move from the initial setting level to the operation level.

# 4-12 Performing Manual Control


# 4-12-1 Manual Operation

- The manipulated variable can be set in manual mode if the "PV/MV" parameter is displayed in the manual control level. The final MV used in automatic mode will be used as the initial manual MV when moving from automatic mode to manual mode. In manual mode, the change value will be fixed immediately and reflected in the actual MV.
- The automatic display return function will not operate in manual mode.
- Balanceless-bumpless operation will be performed for the MV when switching from manual operation to automatic operation. (See note.)
- If a power interruption occurs during manual operation, manual operation will be restarted when power is restored using the same MV as when power was interrupted.
- Switching between automatic and manual operation is possible for a maximum of one million times.
- Manual operation can be used only for PID control.

**Note** 

In balanceless-bumpless operation, the MV before switching is used initially after the switch and then gradually changed to achieve the proper value after switch to prevent radical changes in the MV after switching operation.

The overall manual operation is illustrated in the following figure.




#### **Related Displays and Parameters**

Parameter name	Symbol	Level	Remarks
PV/MV (manual MV)		Manual Control Level	-5.0 to 105.0 (heating/cooling control: -105.0 to 105.0)
Auto/manual switch	a-m	Operation Level	Switches between automatic and manual modes.
Auto/manual select addition	amad	Advanced Function Setting Level	Enables switching between automatic and manual modes.

**Note** Refer to *4-14 Output Adjustment Functions* for information on the priority for the MV.

# Moving to the Manual Control Level

• When the O key is pressed for at least 3 seconds in the operation level's auto/manual switching display, the manual mode will be entered and the manual control level will be displayed. It is not possible to move to any displays except for the "PV/MV" parameter during manual operation. Press the O key for at least one section from the "PV/MV" display in manual control level to return to automatic mode and display the top parameter in the operation level.



• If an event input is set to "MANU" (auto/manual), the "auto/manual switch" parameter will not be displayed. Use the event input to switch between automatic and manual modes.

#### <u>Auto/Manual Select</u> Addition

• The "auto/manual select addition" parameter must be set to ON in the advanced function setting level before it is possible to move to manual mode. The default is OFF.

#### Note

- (1) Priority of Manual MV and Other Functions
  Even when operation is stopped, the manual MV is given priority.
  Auto-tuning and self-tuning will stop when manual mode is entered.
- (2) Manual MV and SP Ramp If operating, the SP ramp function will continue even when manual mode is entered.

#### **Operating Procedure**

Use the following procedure to set the manipulated variable in manual mode.

Operation Level



Initial Setting Level



Input type



1. Press the O key for at least three seconds to move from the operation level to the initial setting level.

2. Select the "PID ON/OFF" parameter by pressing the M key.


Initial Setting Level



Move to advanced function setting level

3. Select the "move to advanced function setting level" parameter by pressing the M key.

Advanced Function Setting Level



Parameter initialization

4. Press the D key to enter the password (−169), and move from the initial setting level to the advanced function setting level.

Advanced Function Setting Level



Auto/manual select addition

Select the "auto/manual select addition" parameter by pressing the M key.



6. Use the U key to set the parameter to ON.

Initial Setting Level




Input type

7. Press the O key for at least one second to move from the advanced function setting level to the initial setting level.

8. Press the O key for at least one second to move from the initial setting level to the operation level.

Operation Level



9. Select the "auto/manual switch" parameter by pressing the M key.

Manual Control Level



10. Press the ○ key for at least three seconds to move from the operation level to the manual control level.



11. Press the  $\cup$  or  $\square$  key to set the manual MV. (In this example, the MV is set to 500%.)

Note

The manual MV setting must be fixed (see page 12), but values changed with key operations are reflected in the control output immediately.

Operation Level



12. Press the O key for at least one second to move from the manual control level to the operation level.

# 4-13 Using the Transfer Output

### 4-13-1 Transfer Output Function

• If a control output is a linear current output it can be used as a transfer output. To use the transfer output, set the "transfer output type" parameter to any setting other than OFF.

(When the "transfer output type" parameter is set to any setting other than OFF, the "transfer output upper limit" and "transfer output lower limit" parameters will be enabled.)

#### **Transfer Output Type**


Transfer output type	Symbol	Setting range
OFF (See note 1.)	off	
Set point	sp	SP lower limit to SP upper limit
Set point during SP ramp	sp-m	SP lower limit to SP upper limit
PV	pv	Sensor setting range lower limit to Sensor setting range upper limit or Scaling lower limit to Scaling upper limit
MV monitor (heating)	mv	-5.0 to 105.0 (heating/cooling control: 0.0 to 105.0) (See note 2.)
MV monitor (cooling)	C-MV	0.0 to 105.0 (See note 2.)

Note

- (1) The default is OFF. If the transfer type is set to OFF, the item assigned in the "control output 1 assignment" parameter will be output on control output 1.
- (2) The difference between the transfer output value and the linear current output value is illustrated in the following figure.

If the linear output is used as the transfer output when the linear current output type is set to 4 to 20 mA, 4.0 mA will be output for 0% and 20.0 mA will be output for 100%.


When a linear output is used for the control output, 3.7 mA is output for 0% and 20.3 mA is output for 100% when the control output for heating is selected to ensure that the control object is controlled at 0% and 100%.



(The above graph is for when the linear current output type is set to 4 to 20 mA.)

#### **Transfer Scaling**

- Reverse scaling is possible by setting the "transfer output lower limit" parameter larger than the "transfer output upper limit" parameter. If the "transfer output lower limit" and "transfer output upper limit" parameters are set to the same value when 4 to 20 mA is set, the transfer output will be output continuously at 0% (4 mA).
- If the SP, SP during SP ramp, or PV is selected, the "transfer output lower limit" and "transfer output upper limit" parameters will be forcibly initialized to the respective upper and lower setting limits for changes in the upper and lower limits of the SP limiter and the temperature unit.
  If the MV for heating or MV for cooling is selected, the "transfer output lower limit" and "transfer output upper limit" parameters will be initialized to 100.0 and 0.0, respectively, when a switch is made between standard control and heating/cooling control using the "standard or heating/cooling" parameter.
- The output current when the linear current type is set to 4 to 20 mA, the transfer output upper limit is set to 90.0, and the transfer output lower limit is set to 10.0 is shown in the following graph.
- For scaling from 0.0% to 100.0%, the output for -5.0 to 0.0 will be the same value as for 0.0%, and the output for 100.0 to 105.0 will be the same value as for 100.0%



(The above graph is for when the linear current output type is set to 4 to 20 mA.)

#### **Operating Procedure**

The following procedure sets the transfer output for an SP range of -50 to 200.

#### Operation Level




Initial Setting Level



Input type

1. Press the O key for at least 3 seconds to move from the operation level to the initial setting level.

Initial Setting Level





Transfer output type

3. Press the  $\ensuremath{\mathsf{U}}$  key to select sp (set point).

Initial Setting Level



4. Select the "transfer output upper limit" parameter by pressing the M key.



5. Use the  $\ \ \ \ \$  key to set the parameter to 200. The default is 1300.

Initial Setting Level

6. Select the "transfer output lower limit" parameter by pressing the M key.



Transfer output lower limit



7. Use the  $\cup$  key to set the parameter to -50. The default is -200.

Operation Level




8. To return to the operation level, press the O key for at least 1 second.


# **4-14 Output Adjustment Functions**

# 4-14-1 Output Limits

- Output limits can be set to control the output using the upper and lower limits to the calculated MV.
- The following MV takes priority over the MV limits.
   Manual MV



• For heating/cooling control, upper and lower limits are set of overall heating/cooling control. (They cannot be set separately for heating/cooling.)



# **SECTION 5 Parameters**

This section describes the individual parameters used to setup, control, and monitor operation.

5-1	Conver	ntions Used in this Section	94
	5-1-1	Meanings of Icons Used in this Section	94
	5-1-2	About Related Parameter Displays	94
	5-1-3	About the Order in Which Parameters Are Described in This Section	94
5-2	Protect	Level	95
5-3	Operati	ion Level	97
5-4	Adjusti	ment Level	106
5-5	Manua	l Control Level	117
5-6	Initial S	Setting Level	118
5-7	Advand	ced Function Setting Level	129
5-8	Comm	unications Setting Level	149

#### 5-1 Conventions Used in this Section

# 5-1-1 Meanings of Icons Used in this Section



Describes the functions of the parameter.



Describes the setting range and default of the parameter.



Used to indicate parameters used only for monitoring.



Describes the parameter settings, such as those for Operation Commands, and procedures.



Used to indicate information on descriptions in which the parameter is used or the names of related parameters.

#### 5-1-2 About Related Parameter Displays

Parameters are displayed only when the conditions for use given on the right of the parameter heading are satisfied. Protected parameters are not displayed regardless of the conditions for use, but the settings of these parameters are still valid.



# 5-1-3 About the Order in Which Parameters Are Described in This Section


Parameters are described level by level.

The first page of each level describes the parameters in the level and the procedure to switch between parameters.

Protect Level Section 5-2


#### 5-2 Protect Level

Three levels of protection are provided on the E5CZ, operation/adjustment protect, initial setting/communications protect, and setting change protect. These protect levels prevent unwanted operation of the keys on the front panel in varying degrees.



To move from the operation level to the protect level, press  $\bigcirc$  and M keys for three seconds (See note.) or more.

**Note** The time taken to move to the protect level can be adjusted by changing the "Move to protect level time" parameter setting.



Parameters that are protected will not be displayed and their settings cannot be changed.

Protect Level Section 5-2

oapt Operation/Adjustment Protect
i cpt Initial Setting/Communications Protect
wtpt Setting Change Protect

These parameters specify the range of parameters to be protected. Shaded settings indicate the defaults.





#### **Operation/Adjustment Protect**

The following table shows the relationship between set values and the range of protection.

Level		Set value			
		0	1	2	3
Operation	PV	Can be displayed	Can be displayed	Can be displayed	Can be displayed
Level PV/SP	PV/SP	Can be displayed and changed	Can be displayed and changed	Can be displayed and changed	Can be displayed
	Others	Can be displayed and changed	Can be displayed and changed	Cannot be displayed and moving to other levels is not possible	Cannot be displayed and moving to other levels is not possible
Adjustment I	_evel	Can be displayed and changed	Cannot be dis- played and moving to other levels is not possible	Cannot be displayed and moving to other levels is not possible	Cannot be displayed and moving to other levels is not possible

• Parameters are not protected when the set value is set to 0.

#### **Initial Setting/Communications Protect**

This protect level restricts movement to the initial setting level, communications setting level, and advanced function setting level.

Set value	Initial setting level	Communications setting level	Advanced function setting level
0	Movement possible	Movement possible	Movement possible
1	Movement possible	Movement possible	Movement not possible
2	Movement not possible	Movement not possible	Movement not possible

#### **Setting Change Protect**

Changes to settings using key operations are restricted.


Set value	Description
OFF	Settings can be changed using key operations.
ON	Settings cannot be changed using key operations. (The protect level settings, however, can be changed.)

• The all protect indication (On) will light when setting is ON.


# 5-3 Operation Level

Display this level to perform control operations on the E5CZ. You can set alarm values, monitor the manipulated variable, and perform other operations in this level.

In the advanced function setting level, you can set a parameter to hide or show the set points.



This level is displayed immediately after the power is turned ON. To move to other levels, press the O key or the O and M keys.



#### **Process Value**

The "additional PV display" parameter must be set to ON.





Monitor



The process value is displayed on the No. 1 display, and nothing is displayed (blank) on the No. 2 display.

	Monitor range	Unit
Process value	Input indication range (See page 172.)	EU

During temperature input, the decimal point position depends on the currently selected sensor, and during analog input it depends on the "decimal point" parameter setting.

#### **Related Parameters**

Input type: Page 119, Set point upper limit, Set point lower limit: Page 122 (initial setting level)

#### **Process Value/Set Point**



The process value is displayed on the No. 1 display, and the set point is displayed on the No. 2 display.

	Monitor range	Unit
Process value	Input indication range (See page 172.)	EU

	Setting range	Unit
Set point	SP lower limit to SP upper limit	EU

During temperature input, the decimal point position depends on the currently selected sensor, and during analog input it depends on the "decimal point" parameter setting.

Refer to the "process value" parameter.



#### a-m Auto/Manual Switch

The "event input assignment 1/2" parameters must not be set to "auto/manual" and the "auto/manual select addition" parameter must be set to ON.

The control must be set to 2-PID control.



- This parameter switches the Controller between automatic and manual modes.
- If the O key is pressed for at least 3 seconds when the "auto/manual switch" parameter is displayed, the manual mode will be entered and the manual control level will be displayed.
- This parameter will not be displayed if an event input is set to "MANU" (auto/manual).



#### **Related Parameters**

PID ON/OFF (initial setting level): Page 122

Auto/manual select addition (advanced function setting level): Page 143

# Multi-SP Set Point Setting (Set Points 0 to 3)

The "multi-SP uses" parameter must be set to ON.



To use the multi-SP function, preset the four set points (SP 0 to 3) in the adjustment level, and then switch the set point either by operating the keys or by using external input signals (event inputs).

This parameter is used to select set points 0 to 3.

#### sp-m Set Point During SP Ramp

The "SP ramp set value" parameter must not be set to OFF.
The "ST" parameter must be set to OFF.



This parameter monitors the set point during SP ramp operation.

A ramp is used to restrict the change width of the set point as a rate of change.

This parameter is displayed when a set value is input for the "SP ramp set value" (adjustment level).

When not in ramp operation, the set point will be the same as the one displayed for the "process value/set point" parameter.

Monitor range	Unit
SP: SP lower limit to SP upper limit	EU



#### **Related Parameters**

Process value/set point (operation level): Page 99 SP ramp set value (adjustment level): Page 116

Set point upper limit, Set point lower limit (initial setting level): Page 122



ct1

#### **Heater Current 1 Value Monitor**

Heater burnout and HS alarms must be supported. Alarm 1 must be assigned. The "heater burnout detection" parameter must be set to ON.



This parameter measures the heater current from the CT input used for detecting heater burnout.

This parameter measures and displays the heater current value.

 Heater burnouts are not detected if the control output (heating) ON time is 190 ms or less.



Monitor range Unit
0.0 to 55.0 A

- ffff is displayed when 55.0 A is exceeded.
- If a heater burnout is detected, the HA indicator will light, and the relative setting level will flash on the No. 1 display.



#### **Related Parameters**


Heater burnout detection 1 (adjustment level): Page 110 HB ON/OFF (advanced function setting level): Page 135

Error Displays ct1: Page 158

#### I cr1 Leakage Current 1 Monitor

Heater burnout and HS alarms must be supported. Alarm 1 must be assigned. The "HS alarm use" parameter must be set to ON.





The heater current is measured and the leakage current 1 monitor is displayed.

• HS are not detected if the control output (heating) OFF time is 190 ms or less.

Monitor range	Unit
0.0 to 55.0	Α

- ffff is displayed when 55.0 A is exceeded.
- If an SSR short-circuit is detected, the HA indicator will light, and the relative setting level will flash on the No. 1 display.



#### **Related Parameters**

HS alarm 1(adjustment level): Page 110

HS alarm use (advanced function setting level): Page 143

Error Displays I cr1: Page 156



#### r-s **RUN/STOP**

The run/stop function must not be set for the "event input assignment 1/2" parameter.



This parameter starts and stops the control operation.

When run (RUN) is selected, control is started. When stop (STOP) is selected, control is stopped. The STOP indicator will light when control.

The default is run.



This parameter will not be displayed if an event input is set to "RUN/STOP."

#### al -1 Alarm Value 1

Alarm 1 must be assigned. The "alarm 1 type" parameter must not be set to an upper/lower limit alarm and a loop break alarm must not be set.



This parameter is set to one of the input values "X" in the alarm type list.

• This parameter sets the alarm value for alarm output 1.



During temperature input, the decimal point position depends on the currently selected sensor, and during analog input it depends on the "decimal point" parameter setting.

Setting range	Unit	Default
-1999 to 9999	EU	0



#### **Related Parameters**

Input type: Page 119, Scaling upper limit, Scaling lower limit, Decimal point (initial setting level): Page 121

Alarm 1 type (initial setting level): Page 124

Standby sequence reset: Page 133, Alarm 1 open in alarm: Page 134, Alarm 1 hysteresis: Page 135, Alarm 1 latch: Page 139 (advanced function setting level)

#### al -2 Alarm Value 2

Alarm 2 must be assigned. The alarm 2 type must be set to other than an upper and lower limit alarm.







See

This parameter is set to one of the input values "X" in the alarm type list.

- This parameter sets the alarm value for alarm output 2.
- During temperature input, the decimal point position depends on the currently selected sensor, and during analog input it depends on the "decimal point" parameter setting.

Setting range	Unit	Default
-1999 to 9999	EU	0

#### **Related Parameters**

Input type: Page 119, Scaling upper limit, Scaling lower limit, Decimal point (initial setting level): Page 121

Alarm 2 type (initial setting level): Page 126

Standby sequence reset: Page 133, Alarm 2 open in alarm: Page 134, Alarm 2 hysteresis: Page 135, Alarm 2 latch: Page 139 (advanced function setting level)

#### al -3 Alarm Value 3

Alarm 3 must be assigned. The alarm 3 type must be set to other than an upper and lower limit alarm.



Function



This parameter is set to one of the input values "X" in the alarm type list.

This parameter sets the alarm value for alarm output 3.

During temperature input, the decimal point position depends on the currently selected sensor, and during analog input it depends on the "decimal point" parameter setting.

Setting range	Unit	Default
-1999 to 9999	EU	0



#### **Related Parameters**

Input type: Page 119, Scaling upper limit, Scaling lower limit, Decimal point (initial setting level): Page 121

Alarm 3 type (initial setting level): Page 126


1 type" parameter (initial setting level).

Standby sequence reset: Page 133, Alarm 3 open in alarm: Page 134, Alarm 3 hysteresis: Page 135, Alarm 3 latch: Page 139 (advanced function setting level)

al 1h	Alarm Value Upper Limit 1
al 1I	Alarm Value Lower Limit 1


Alarm 1 must be assigned. Alarm 1 type must be set to upper and lower limits, upper and lower limit range, or upper- and lower-limit with standby sequence.





These parameters independently set the alarm value upper and lower limits when the mode for setting the upper and lower limits is selected for the "alarm

 During temperature input, the decimal point position depends on the currently selected sensor, and during analog input it depends on the "deci-









#### **Related Parameters**

Input type: Page 119, Scaling upper limit, Scaling lower limit, Decimal point: Page 121, Alarm 1 type: Page 124 (initial setting level), Standby sequence reset: Page 133, Alarm 1 open in alarm: Page 134, Alarm 1 hysteresis: Page 135, Alarm 1 latch: Page 139 (advanced function setting level).

al 2h	Alarm Value Upper Limit 2	Alarm 2 must be assigned. Alarm 2 type must be set to upper
al 2l	Alarm Value Lower Limit 2	and lower limits, upper and lower limit range, or upper- and lower-limit alarm with standby sequence.



These parameters independently set the alarm value upper and lower limits when the mode for setting the upper and lower limits is selected for the "alarm 2 type" parameter (initial setting level).

• This parameter sets the upper and lower limit values of alarm 2.



 During temperature input, the decimal point position depends on the currently selected sensor, and during analog input it depends on the "decimal point" parameter setting.

Setting range	Unit	Default
-1999 to 9999	EU	0



#### **Related Parameters**

Input type: Page 119, Scaling upper limit, Scaling lower limit, Decimal point: Page 121, Alarm 2 type: Page 126 (initial setting level), Standby sequence reset: Page 133, Alarm 2 open in alarm: Page 134, Alarm 2 hysteresis: Page 135, Alarm 2 latch: Page 139 (advanced function setting level)

al 3h	Alarm Value Upper Limit 3
al 3l	Alarm Value Lower Limit 3

Alarm 3 must be assigned. Alarm 3 type must be set to upper and lower limits, upper and lower limit range, or upper- and lower-limit alarm with standby sequence.

These parameters independently set the alarm value upper and lower limits when the mode for setting the upper and lower limits is selected for the "alarm 3 type" parameter (initial setting level).

- This parameter sets the upper and lower limit values of alarm 3.
- During temperature input, the decimal point position depends on the currently selected sensor, and during analog input it depends on the "decimal point" parameter setting.

Setting range	Unit	Default
-1999 to 9999	EU	0







#### **Related Parameters**

Input type: Page 119, Scaling upper limit, Scaling lower limit, Decimal point: Page 121, Alarm 3 type: Page 126 (initial setting level), Standby sequence reset: Page 133, Alarm 3 open in alarm: Page 134, Alarm 3 hysteresis: Page 135, Alarm 3 latch: Page 139 (advanced function setting level)

#### **MV Monitor (Heating)** 0

The "MV display" parameter must be set to ON.







This parameter is used to check the manipulated variable for the heating control output during operation.

- This parameter cannot be set.
- During standard control, the manipulated variable is monitored. During heating/cooling control, the manipulated variables on the heating control output is monitored.
- The default is OFF and the manipulated variable is not displayed.

Control	Monitor range	Unit
Standard	-5.0 to 105.0	%
Heating/cooling	0.0 to 105.0	%



#### **Related Parameters**

MV display (advanced function setting level): Page 138

c-o MV Monitor (Cooling)

The control system must be set to heating/cooling control.
The "MV display" parameter must be set to ON.

This parameter is used to check the manipulated variable for the cooling control output during operation.

- This parameter cannot be set.
- During heating/cooling control, the manipulated variable on the cooling control output is monitored.
- The default is OFF and the manipulated variable is not displayed.

Control	Monitor range	Unit
Heating/cooling	0.0 to 105.0	%





Monitor




#### **Related Parameters**

Standard or heating/cooling (initial setting level): Page 123 MV display (advanced function setting level): Page 138

# 5-4 Adjustment Level


This level is for executing AT (auto-tuning) and other operations, and for set control parameters.

This level provides the basic Controller parameters for PID control (proportional band, integral time, derivative time) and heating/cooling control.



To move to the adjustment level from the operation level, press the  $\ensuremath{\bigcirc}$  key once.

- The set points 0 to 3 in the adjustment level are the set values for switching the set point during multi-SP input.
- The following parameters are displayed for Controllers with CT Inputs: Heater current monitors, Leakage current monitors, heater burnout detections, and HS alarms.
- Adjustment level parameters can be changed after setting the "operation/ adjustment protect" parameter to 0. Displays and changing levels are not possible if the "operation/adjustment protect" parameter is set to 1 to 3.
   Protection is set in the protect level.




#### at AT Execute/Cancel


The E5CZ must be in operation, and control must be 2-PID control.







- The MV is forcibly increased and decreased around the set point to find the characteristics of the control object. From the results, the PID constants are automatically set in the "proportional band" (P), "integral time" (I), and "derivative time" (D) parameters.
- This parameter is normally off. If you press the U key, the parameter is turned ON and AT is executed. AT cannot be executed when control is stopped or during ON/OFF control.
- When AT execution ends, the parameter setting automatically returns to off.



Proportional band, Integral time, Derivative time (adjustment level): Page 113 PID ON/OFF (initial setting level): Page 122



cmwt

## Communications Writing

Communications must be supported.



Function





This parameter enables/disables writing of parameters to the E5CZ from the host (personal computer) using communications.

ON: Writing enabled
OFF: Writing disabled
• Default: OFF

#### **Related Parameters**

MB command logic switching (advanced function setting level): Page 141 Communications Unit No., Communications baud rate, Communications data length, Communications parity, Communications stop bits (communications setting level): Page 149

#### ct1 Heater Current 1 Value Monitor

Heater burnout and HS alarms must be supported. Alarm 1 must be assigned. The "heater burnout detection" parameter must be set to ON.

This parameter measures the heater current from the CT input used for detecting heater burnout.

This parameter measures and displays the heater current value.

 Heater burnouts are not detected if the control output (heating) ON time is 190 ms or less.

Monitor range	Unit
0.0 to 55.0	Α

- ffff is displayed when 55.0 A is exceeded.
- If a heater burnout is detected, the HA indicator will light, and the relative setting level will flash on the No. 1 display.

#### **Related Parameters**

Heater burnout detection 1 (adjustment level): Page 110 HB ON/OFF (advanced function setting level): Page 135

Error Displays ct1: Page 158





Monitor



# l cr1 Leakage Current 1 Monitor

Heater burnout and HS alarms must be supported. Alarm 1 must be assigned. The "HS alarm" parameter must be set to ON.





Monitor

This parameter measures the heater current from the CT input used for detecting SSR short-circuits.

This parameter measures and displays the heater current when the heater is OFF.

 HS are not detected if the control output (heating) OFF time is 190 ms or less.

Monitor range	Unit
0.0 to 55.0	Α

- ffff is displayed when 55.0 A is exceeded.
- If an SSR short-circuit is detected, the HA indicator will light, and the relative setting level will flash on the No. 1 display.

#### **Related Parameters**

HS alarm 1 (adjustment level): Page 110

HS alarm use (advanced function setting level): Page 143

Error Displays I cr1: Page 158



#### hb1 Heater Burnout Detection 1

Heater burnout and HS alarms must be supported. Alarm 1 must be assigned. The "heater burnout detection" parameter must be set to ON.







This parameter sets the current for the heater burnout alarm to be output.

- The heater burnout alarm is output when the heater current value falls below the setting of this parameter.
- When the set value is 0.0, the heater burnout alarm is turned OFF. When the set value is 50.0, the heater burnout alarm will turn ON.

Setting range	Unit	Default
0.0 to 50.0	Α	0.0

#### **Related Parameters**

Heater current 1 value monitor (adjustment level): Page 109

HB ON/OFF: Page 135, Heater burnout latch, Heater burnout hysteresis: Page 136 (advanced function setting level)

#### hs1 HS Alarm 1

Heater burnout and HS alarms must be supported. Alarm 1 must be assigned. The "HS alarm" parameter must be set to ON.







This parameter sets the current for the HS alarm to be output.

- The HS alarm is output when the leakage current value goes above the setting of this parameter.
- When the set value is 50.0, the HS alarm is turned OFF. When the set value is 0.0, the HS alarm will turn ON.

Setting range	Unit	Default
0.0 to 50.0	Α	50.0

#### **Related Parameters**

Leakage current 1 monitor (adjustment level): Page 109

HS alarm use, HS alarm latch: Page 143, HS alarm hysteresis: Page 144 (advanced function setting level): Page 143

sp-0	SP 0
sp-1	SP 1
sp-2	SP 2
sn-3	SP 3

The "number of multi-SP uses" parameter must be set to 1 or 2. The "multi-SP uses" parameter must be set to ON.



These parameters set the set points when the multi-SP function is used.

The values set in these parameters can be selected by operating the keys on the front panel or by using event inputs.

- When the set point has been changed, the set value of the set point (0 to 3) selected by the multi-SP inputs is also changed to the same value.
- The decimal point position depends on the selected sensor. During analog input, it depends on the "decimal point" parameter setting.

Setting range	Unit	Default
SP lower limit to SP upper limit	EU	0





#### **Related Parameters**

Process value/set point (operation level): Page 99

Input type (initial setting level): Page 119

Number of multi-SP uses: Page 131, Event input assignment 1 and Event input assignment 2, Multi-SP uses: Page 132 (advanced function setting level)

#### i ns

#### **Temperature Input Shift**

The "input type" parameter must be set for a thermocouple or resistance thermometer, and the "input shift type" parameter must be set to a one-point shift.

Sometimes an error occurs between the set point and the actual temperature. To offset this, a compensated value can be obtained by adding an input shift value to the input. The compensated value is displayed as the measurement value and used for control.

The entire input range is shifted by a fixed rate (1-point shift). If the input shift value is set to  $-1^{\circ}$ C, control will be performed for a value  $1^{\circ}$ C lower than the measured temperature.







Setting range	Unit	Default
-199.9 to 999.9	°C or °F	0.0

#### **Related Parameters**

Input type (initial setting level): Page 119

Input shift type (advanced function setting level): Page 142

#### i nsh Upper-limit Temperature Input Shift Value The "input type" parameter must be

# Lower-limit Temperature Input Shift Value point shift, or the "input type" param-

The "input type" parameter must be set for a thermocouple or resistance thermometer and the "input shift type" parameter must be set to a 2-point shift, or the "input type" parameter must be set for an infrared sensor.

These parameters are used to shift the input temperature at two points: an upper-limit temperature and a lower-limit temperature (as opposed to the "temperature input shift" parameter, which shifts the input temperature by setting the shift for only one point). A 2-point shift enables more accurate offset of the input range compared with a 1-point shift if the input shift values at the upper and lower limits differ.

This parameter sets input shift values for the upper and lower limits (2-point shift) of the input range.

Setting range	Unit	Default
-199.9 to 999.9	°C or °F	0.0

Function

i nsl





#### **Related Parameters**

Input type (initial setting level): Page 119

Input shift type (advanced function setting level): Page 142

p	<b>Proportional Band</b>
i	Integral Time
d	<b>Derivative Time</b>

The control must be set to 2-PID control.



These parameters set PID control constants. PID constants are automatically set when AT or ST is executed.

P action: Refers to control in which the MV is proportional to the deviation (control error).

I action: Refers to a control action that is proportional to the time integral of the deviation. With proportional control, there is normally an offset (control error). Proportional action is thus used in combination with integral action. As time passes, this control error disappears, and the control temperature (process value) comes to agree with the set point.

D action: Refers to a control action that is proportional to the time derivative of the control error. The proportional control and integral control correct for errors in the control result, and thus the control system is late in responding to sudden changes in temperature. The derivative action increases the MV in proportion to the slope of the change in the temperature as a corrective action.



Parameters	Models	Setting range	Unit	Default
Proportional band	Controllers with Thermocouple/ Resistance Thermometer Univer- sal-inputs	0.1 to 999.9	°C or °F (See note.)	8.0
	Controllers with Analog Inputs		%FS	10.0
Integral time		0 to 3999	Second	233
Derivative time		0 to 3999	Second	40

**Note** Set "none" as the unit for Controllers with Analog Inputs.



#### **Related Parameters**

AT execute/cancel (adjustment level): Page 108

#### c-sc Cooling Coefficient

The control must be heating/cooling control and 2-PID control.





If the heating characteristics and cooling characteristics of the control object are very different and good control characteristics cannot be achieved with the same PID constants, the cooling coefficient can be used to adjust the proportional band (P) for the control output assigned to the cooling side.

In heating/cooling control, the proportional band P for the cooling control output is calculated using the following formula to set the cooling coefficient:

Cooling control output side  $P = Cooling coefficient \times P$  (proportional band)

Setting range	Unit	Default
0.01 to 99.99	None	1.00



#### **Related Parameters**

Proportional band (adjustment level): Page 113

#### c-db Dead Band

The control system must be set to heating/cooling control.

This parameter sets the output dead band width for heating/cooling control. A negative setting sets an overlapping band.

- This parameter sets an area in which the control output is 0 centering around the set point for a heating/cooling control.
- During temperature input, the decimal point position depends on the currently selected sensor, and during analog input it depends on the "decimal point" parameter setting.

Model	Setting range	Unit	Default
Controllers with Thermocouple/Resistance Thermometer Universal-inputs	-199.9 to 999.9	°C or °F (See note.)	0.0
Controllers with Analog Inputs	-19.99 to 99.99	%FS	0.00

Note

Set "none" as the unit for Controllers with Analog Inputs.

#### of-r Manual Reset Value

The control must be standard control and 2-PID control.

The "integral time" parameter must be set to 0.



Function



 This parameter sets the required manipulated variable to remove offset during stabilization of P or PD control.

Setting range	Unit	Default
0.0 to 100.0	%	50.0



#### **Related Parameters**

Integral time (adjustment level): Page 113 PID ON/OFF (initial setting level): Page 122

hys	Hysteresis (Heating)
chys	Hysteresis (Cooling)

The control must be ON/OFF control. For the "hysteresis (cooling)" parameter, the control must be heating/cooling control.



This parameter sets the hysteresis for ensuring stable operation at the ON/ OFF switching point.

• For standard control, use the "hysteresis (heating)" parameter. The "hysteresis (cooling)" parameter cannot be used.



 For heating/cooling control, the hysteresis can be set independently for heating/cooling. The "hysteresis (heating)" parameter is used for the heating side, and the "hysteresis (cooling)" parameter is used for the cooling side.

Parameters	Model	Setting range	Unit	Default
Hysteresis (heating)	Controllers with Thermocouple/Resistance Thermometer Universal-inputs	0.1 to 999.9	°C or °F (See note.)	1.0
	Controllers with Analog Inputs	0.01 to 99.99	%FS	0.10
Hysteresis (cooling)			°C or °F (See note.)	1.0
	Controllers with Analog Inputs	0.01 o 99.99	%FS	0.10

**Note** Set "none" as the unit for Controllers with Analog Inputs.



#### **Related Parameters**

PID ON/OFF:Page 122, Standard or heating/cooling: Page 123 (initial setting level)

#### sprt SP Ramp Set Value

The "ST" parameter must be set to OFF.



• This parameter sets the rate of change during SP ramp operation. Set the maximum permissible change width per unit of time as the SP ramp set value. The SP ramp function is disabled if this parameter is set to OFF.

 During temperature input, the decimal point position of the SP ramp set value is dependent on the currently selected sensor, and during analog input it is dependent on scaling.

Setting range	Unit	Default
OFF or 1 to 9999	EU/s or EU/minute	off





#### **Related Parameters**

Input type: Page 119, Scaling upper limit, Scaling lower limit, Decimal point (initial setting level): Page 121, ST: Page 123 (initial setting level)

SP ramp time unit (advanced function setting level): Page 132

ol -h	<b>MV Upper Limit</b>
ol -l	<b>MV</b> Lower Limit

The control must be set to 2-PID control.

The "ST" parameter must be set to OFF.





- The "MV upper limit" and "MV lower limit" parameters set the upper and lower limits of the manipulated variable. When the calculated manipulated variable exceeds the upper or lower limit value, the upper or lower limit value will be the output level.
- MV Upper Limit

The setting ranges during standard control and heating/cooling control are different.

The manipulated variable for the cooling control output side during heating/cooling control is expressed as a negative value.

Control method	Setting range	Unit	Default
Standard	MV lower limit + 0.1 to 105.0	%	105.0
Heating/cooling	0.0 to 105.0		

#### MV Lower Limit

The setting ranges during standard control and heating/cooling control are different. The manipulated variable for the cooling control output side during heating/cooling control is expressed as a negative value.

Control method	Setting range	Unit	Default
Standard	-5.0 to MV upper limit - 0.1	%	-5.0
Heating/cooling	-105.0 to 0.0		-105.0



#### **Related Parameters**


PID ON/OFF: Page 122, ST: Page 123 (initial setting level)

Manual Control Level Section 5-5

#### 5-5 Manual Control Level

The manipulated variable can be set in manual mode if the "PV/MV" parameter is displayed.

The final MV used in automatic mode will be used as the initial manual MV when moving from automatic mode to manual mode. In manual mode, the change value will be fixed immediately and reflected in the actual MV.



To move from the operation level to the manual control level, press the O key for at least three seconds with the "auto/manual switch" parameter displayed.

- The MANU indicator will light during manual control.
- It is not possible to move to any displays except for the "PV/MV" parameter during manual operation.
- To return to the operation level, press the O key in the manual control level for at least one second.

#### PV/MV (Manual MV)



The process value is displayed on the No. 1 display, and the manipulated variable (manual MV) is displayed on the No. 2 display.

	Monitor range	Unit
Process value	Input indication range (See page 172.)	EU

	Setting range	Unit	
MV (manual MV)	Standard control	-5.0 to 105.0	%
	Heating/cooling control	-105.0 to 105.0	




#### **Related Parameters**

Standard or heating/cooling (initial setting level): Page 123


# 5-6 Initial Setting Level

This level is used to set up the basic Temperature Controller specifications. In this level, you can set the "input type" parameter to set the sensor input to be connected, limit the setting range of set points, set the alarm modes, and perform other operations.



To move from the operation level to the initial setting level, press the O key for at least 3 seconds with any parameter displayed except for the "auto/manual switch" parameter.

- The initial setting level is not displayed when the "initial/communications protect" parameter is set to 2. It can be used when the "initial/communications protect" parameter is set to 0 or 1.
- If the "input type" parameter is set for an analog input, the following parameters will be set: Scaling upper limit, Scaling lower limit, and Decimal point.



#### in-t Input Type





- This parameter sets the type of sensor.
- When this parameter is changed, the set point limiter is changed to the defaults. If the input type must be changed, set the "SP upper limit" and "SP lower limit" parameters (initial setting level).
- Set one of the set values from the following table.

The defaults are as follows:

Controllers with Thermocouple/Resistance Thermometer Universal-inputs:

5 (K thermocouple)

Controllers with Analog Inputs: 0 (current input, 4 to 20 mA)

 If a platinum resistance thermometer is mistakenly connected while a setting for other than a platinum resistance thermometer is in effect, S.ERR will be displayed. To clear the S.ERR display, check the wiring and then cycle the power.

	Input type	Specifications	Set value	Input temperature range
Controllers	Platinum resistance	Pt100	0	−200 to 850 (°C)/−300 to 1500 (°F)
with Ther- mocouple/	thermometer		1	-199.9 to 500.0 (°C)/-199.9 to 900.0 (°F)
Resistance			2	0.0 to 100.0 (°C)/0.0 to 210.0 (°F)
Thermome-		JPt100	3	-199.9 to 500.0 (°C)/-199.9 to 900.0 (°F)
ter Univer- sal-inputs			4	0.0 to 100.0 (°C)/0.0 to 210.0 (°F)
sai-ii iputs	Thermocouple	К	5	-200 to 1300 (°C)/-300 to 2300 (°F)
			6	-20.0 to 500.0 (°C)/0.0 to 900.0 (°F)
		J	7	-100 to 850 (°C)/-100 to 1500 (°F)
			8	-20.0 to 400.0 (°C)/0.0 to 750.0 (°F)
		Т	9	-200 to 400 (°C)/-300 to 700 (°F)
			10	-199.9 to 400.0 (°C)/-199.9 to 700.0 (°F)
		E	11	0 to 600 (°C)/0 to 1100 (°F)
		L	12	-100 to 850 (°C)/-100 to 1500 (°F)
		U	13	-200 to 400 (°C)/-300 to 700 (°F)
			14	-199.9 to 400.0 (°C)/-199.9 to 700.0 (°F)
		N	15	-200 to 1300 (°C)/-300 to 2300 (°F)
		R	16	0 to 1700 (°C)/0 to 3000 (°F)
		S	17	0 to 1700 (°C)/0 to 3000 (°F)
		В	18	100 to 1800 (°C)/300 to 3200 (°F)
	Infrared Tempera-	10 to 70 (°C)	19	0 to 90 (°C)/0 to 190 (°F)
	ture Sensor	60 to 120 (°C)	20	0 to 120 (°C)/0 to 240 (°F)
	ES1B	115 to 165 (°C)	21	0 to 165 (°C)/0 to 320 (°F)
		140 to 260 (°C)	22	0 to 260 (°C)/0 to 500 (°F)
	Analog input	0 to 50 mV	23	One of the following ranges depending on the scaling.  -1999 to 9999  -199.9 to 999.9

	Input type	Specifications	Set value	Input temperature range
Controllers	Current input	4 to 20 mA	0	One of the following ranges depending on the scal-
with Ana- log Inputs		0 to 20 mA	1	ing. -1999 to 9999
log inputs	Voltage input	1 to 5 V	2	-199.9 to 999.9
		0 to 5 V	3	-19.99 to 99.99
		0 to 10 V	4	_1.999 to 9.999



#### **Related Parameters**

Temperature unit: Page 121, SP upper limit, SP lower limit: Page 122 (initial setting level)

i n-h	Scaling Upper Limit
i n-l	Scaling Lower limit
dp	<b>Decimal Point</b>

The input type must be set for an analog input.



- These parameters can be used when the input type is set for an analog input.
- When an analog input is used, scaling is performed. Set the upper limit in the "scaling upper limit" parameter and the lower limit in the "scaling lower limit" parameter.
- The "decimal point" parameter specifies the decimal point position of parameters (set point, etc.) whose unit is EU.
- Scaling Upper Limit, Scaling Lower Limit

Parameters	Setting range	Unit	Default
Scaling upper limit	Scaling lower limit + 1 to 9999	None	100
Scaling lower limit	-1999 to scaling upper limit - 1	None	0

#### Decimal Point

Parameters	Model	Setting range	Default
Decimal Point	Controllers with Thermocouple/Resistance Thermometer Universal-inputs	0 to 1	0
	Controllers with Analog Inputs	0 to 3	0

Set value	Settings	Example
0	0 digits past decimal point	1234
1	1 digits past decimal point	123.4
2	2 digits past decimal point	12.34
3	3 digits past decimal point	1.234



#### **Related Parameters**

Input type (initial setting level): Page 119

### d-u **Temperature Unit**

The input type must be set for a temperature input.



• Set the temperature input unit to either °C or °F.



Setting range	Default
c: °C, f: °F	С



#### **Related Parameters**

Input type (initial setting level): Page 119

sl-h **SP Upper Limit** 

sl-l **SP Lower Limit** 



• These parameters set the upper and lower limits of the set points. A set point can be set within the range defined by the upper and lower limit set values in the "SP upper limit" and "SP lower limit" parameters. If these parameters are reset, any set point that is outside of the new range will be forcibly changed to either the upper limit or the lower limit.

- When the temperature input type and temperature unit have been changed, the set point upper limit and set point lower limit are forcibly changed to the upper and lower limits of the sensor.
- During temperature input, the decimal point position depends on the currently selected sensor, and during analog input it depends on the "decimal point" parameter setting.

Controllers with Thermocouple/Resistance Thermometer Universal-inputs

Parameters		Setting range	Unit	Default
Set point upper limit	Temperature	SP lower limit + 1 to Input range upper limit	EU	1300
	Analog	SP lower limit + 1 to scaling upper limit	EU	100
Set point lower limit	Temperature	Input range lower limit to SP upper limit – 1	EU	-200
	Analog	Scaling lower limit to SP upper limit – 1	EU	0

#### Controllers with Analog Inputs

Parameters	Setting range	Unit	Default
Set point upper limit   SP lower limit + 1 to scaling upper limit		EU	100
Set point lower limit	point lower limit Scaling lower limit to SP upper limit – 1		0

#### **Related Parameters**

Input type: Page 119, Temperature unit: Page 121 (initial setting level)

# See

#### cntl PID ON/OFF







- This parameter selects 2-PID control or ON/OFF control.
- The auto-tuning and self-tuning functions can be used in 2-PID control.

Setting range	Default
pi d: 2-PID, onof: ON/OFF	onof



#### **Related Parameters**

AT execute/cancel: Page 108, Manual reset value, Hysteresis (heating), and Hysteresis (cooling): Page 114 (adjustment level)

ST stable range (advanced function setting level): Page 137

#### s-hc

# Standard or Heating/Cooling



Function



- This parameter selects standard control or heating/cooling control.
- With the E5CZ and E5CZ-U, when heating/cooling control is selected, alarm output 2 terminal (ALM2) is used as a control output (cooling), so alarm 2 cannot be used.
- With the E5AZ and E5EZ, when heating/cooling control is selected, alarm output 3 terminal (ALM3) is used as a control output (cooling), so alarm 3 cannot be used.

Setting range	Default
stnd: Standard, h-c: Heating/cooling	stnd



#### **Related Parameters**

MV monitor (heating): Page 104, MV monitor (cooling): Page 105 (operation level)

Cooling coefficient: Page 113, Dead band, Hysteresis (heating), Hysteresis (cooling): Page 114 (adjustment level)

Control period (heating), Control period (cooling) (initial setting level): Page 124

Control output 1 assignment: Page 146, Alarm output 1 assignment: Page 146, Alarm output 2 assignment: Page 147, Alarm output 3 assignment: Page 148 (advanced function setting level)

#### st

# ST (self-tuning)

The control must be set to a temperature input, standard control, and 2-PID control.



- The ST (self-tuning) function executes tuning from the start of program execution to calculate PID constants matched to the control target. When the ST function is in operation, be sure to turn ON the power supply of the load connected to the control output simultaneously with or before starting Controller operation.
- Auto-tuning can be started during self-tuning.



Parameter	Setting range	Unit	Default
ST	off: ST function OFF, on: ST	None	on
	function ON		



#### **Related Parameters**

Control Period (Cooling)

Input type: Page 119, PID ON/OFF: Page 122 (initial setting level), ST stable range (advanced function setting level): Page 137

cp Control Period (Heating)

The cooling control output and heating control output must be assigned to relay/voltage outputs.

The control must be set to 2-PID

control.

For the "control period (cooling)" parameter, the control must be set to

heating/cooling control.



c-cp

- These parameters set the output periods. Set the control periods taking the control characteristics and the electrical durability of the relay into consideration.
- For standard control, use the "control period (heating)" parameter. The "control period (cooling)" parameter cannot be used.
- Whenever the heating control output is a current output, the "control period (heating)" parameter cannot be used.
- For heating/cooling control, the control period can be set independently for heating and cooling. The "control period (heating)" parameter is used for the heating control output, and the "control period (cooling)" parameter is used for the cooling control output.







## **Related Parameters**

PID ON/OFF (initial setting level): Page 122

# orev Direct/Reverse Operation





• "Direct operation" refers to control where the manipulated variable is increased when the process value increases. Alternatively, "reverse operation" refers to control where the manipulated variable is increased when the process value decreases.

Setting range	Default
or-r: Reverse operation, or-d: Direct operation	or-r

# al t1 Alarm 1 Type

Alarm 1 must be assigned.




Select one of the following three alarm 1 types:
 Deviation, Deviation range, or Absolute value




Set values	Alarm type	Alarm outp	ut operation
	,,	When alarm value X is positive	When alarm value X is negative
0	Alarm function OFF	Output OFF	
1 (See note 1.)	Upper- and lower-limit	ON SP	See note 2.
2	Upper-limit	ON OFF SP	ON OFF SP
3	Lower-limit	ON SP	ON OFF SP
4 (See note 1.)	Upper- and lower-limit range	ON → L : H;— OFF SP	See note 3.
5 (See note 1.)	Upper- and lower-limit with standby sequence	ON SP SP See note 5.	See note 4.
6	Upper-limit with standby sequence	ON → X ← SP	ON →¦X;← OFF SP
7	Lower-limit with standby sequence	ON SP	ON SP
8	Absolute-value upper- limit	ON OFF 0	ON OFF 0
9	Absolute-value lower- limit	ON OFF 0	ON OFF 0
10	Absolute-value upper- limit with standby sequence	ON OFF 0	ON OFF 0
11	Absolute-value lower- limit with standby sequence	ON OFF 0	ON OFF 0
12	LBA (alarm 1 type only)		

Note

- (1) With set values 1, 4 and 5, the upper- and lower- limit values can be set independently for each alarm type, and are expressed as "L" and "H."
- (2) Set value: 1 (Upper- and lower-limit alarm)



(3) Set value: 4 (Lower limit range)



(4) Set value: 5 (Upper- and lower-limit with standby sequence)

- For the lower-limit alarms in cases 1 and 2 above, the alarm is normally OFF if upper- and lower-limit hysteresis overlaps.
- In case 3, the alarm is always OFF.
- (5) Set value: 5 (The alarm is always OFF if upper- and lower-limit alarm hysteresis with standby sequence overlaps.)
- Set the alarm type independently for each alarm in the "alarm 1 to 3 type" parameters in the initial setting level. The default is 2 (Upper-limit alarm).



#### **Related Parameters**

Alarm value 1: Page 101, Alarm value upper limit 1, Alarm value lower limit 1: Page 103 (operation level)

Standby sequence reset: Page 133, Alarm 1 open in alarm: Page 134, Alarm 1 hysteresis: Page 135, Alarm 1 latch: Page 139 (advanced function setting level)

# al t2 Alarm 2 Type

Alarm 2 must be assigned.



 Select one of the following three alarm 2 types: Deviation, Deviation range, or Absolute value



Refer to the alarm 1 type list.



## **Related Parameters**

Alarm value 2: Page 102, Alarm value upper limit 2, Alarm value lower limit 2: Page 103 (operation level)

Standby sequence reset: Page 133, Alarm 2 open in alarm: Page 134, Alarm 2 hysteresis: Page 135, Alarm 2 latch: Page 139 (advanced function setting level)

# al t3 Alarm 3 Type

Alarm 3 must be assigned.



 Select one of the following three alarm 3 types: Deviation, Deviation range, or Absolute value



Refer to the alarm 1 type list.



# **Related Parameters**

Alarm value 3: Page 102, Alarm value upper limit 3, Alarm value lower limit 3: Page 104 (operation level)


Standby sequence reset: Page 133, Alarm 3 open in alarm: Page 134, Alarm 3 hysteresis: Page 135, Alarm 3 latch: Page 139 (advanced function setting level)

# tr-t Transfer Output Type

A current output must be assigned.



• When current output is to be used as transfer output, this parameter sets the transfer output type.



Transfer output ty	Default	
OFF	off	off
Set point	sp	
Set point during SP ramp	sp-m	
PV	pv	
MV monitor (heating)	m∨	
MV monitor (cooling)	C-MV	



#### **Related Parameter**

Transfer output upper limit, Transfer output lower limit (initial setting level): Page 127

# tr-h Transfer Output Upper Limit tr-l Transfer Output Lower Limit

A current output must be assigned. The transfer output type must not be set to OFF.



• This parameter sets the upper and lower limit values of transfer outputs.



Transfer	Setting range		Default		Unit
output type			Transfer output lower limit	Transfer output upper limit	
Set point	SP lower limit	to SP upper limit	SP lower limit	SP upper limit	EU
Set point during SP ramp	SP lower limit to SP upper limit				
PV	Temperature	Senor setting range lower limit to sensor setting range upper limit	Sensor setting range lower limit	Sensor setting range upper limit	
	Analog	Analog scaling lower limit to analog scaling upper limit	Scaling lower limit	Scaling upper limit	
MV monitor	Standard	-5.0 to 105.0	0.0	100.0	%
(heating)	Heating/ cooling	0.0 to 105.0			
MV monitor (cooling)	0.0 to 105.0				



## **Related Parameter**

Transfer output type (initial setting level): Page 127

# o1-t Linear Current Output

A current output must be assigned.



This parameter selects the output type for linear current outputs.

 Select either 4 to 20 mA or 0 to 20 mA when control output 1 is a current output.



Linear current output	Default
4-20: 4 to 20 mA 0-20: 0 to 20 mA	4-20

**Note** Even when control output 1 is used as a control output or a simple transfer output, 0 to 20 mA can be used.

Transfer output type (initial setting level): Page 127



amov

# **Move to Advanced Function Setting Level**

The "initial setting/communications protect" parameter must be set to 0.



Function

- Set the "move to advanced setting level" parameter set value to "-169."
- Move to the advanced setting level either by pressing the M key or O key or by waiting for 2 seconds to elapse.

#### **Related Parameter**

**Related Parameter** 

Initial setting/communications protect (protect level): Page 96





# 5-7 Advanced Function Setting Level

The advanced function setting level is used for optimizing Controller performance. To move to this level, input the password ("–169") from the initial setting level.

To be able to enter the password, the "initial setting/communications protect" parameter in the protect level must be set to 0.

- The parameters in this level can be used when the "initial setting/communications protect" parameter is set to 0.
- To switch between setting levels, press the key.
- To change set values, press the U and D keys.





#### i ni t Parameter Initialization





- This parameter returns all parameter settings to their defaults.
- After the initialization, the set value automatically turns off.

Setting range	Default
off: Initialization is not executed.	off
fact: Initializes to the factory settings described in the manual.	

#### ev-m

#### Number of Multi-SP Uses

Event inputs must be supported.




Multi-SP is a function for setting set points 0 to 3 in advance, and switching between these set points using the ON/OFF combinations of event inputs 1 and 2.

The "number of multi-SP uses" parameter is used when the number of preset set points is either two or four.

This parameter determines whether the "event input assignment 1" and "event input assignment 2" parameters are displayed.

The "number of multi-SP uses" parameter displays which functions are assigned to event inputs 1 and 2.





Note

If the "number of multi-SP uses" parameter is set to 0, both input assignments 1 and 2 can be set. Once "STOP" (RUN/STOP), or "MANU" (auto/manual) has been assigned to one event input, the other event can be assigned only to either of the remaining two settings.

#### • Default: 1

Multi-SP switching by event inputs can be used with Controllers that have event inputs, when the "number of multi-SP uses" parameter is set to 1 or 2.

The following tables show the relationships between ON/OFF combinations of event inputs 1 and 2 and selected set points.

#### Number of Multi-SP Uses: 1

Event input 1	Selected set point
OFF	Set point 0
ON	Set point 1

#### Number of Multi-SP Uses: 2

Event input 1	Event input 2	Selected set point
OFF	OFF	Set point 0
ON	OFF	Set point 1
OFF	ON	Set point 2
ON	ON	Set point 3

Note

Event inputs can be used on the following Controllers. E5CZ- $\square$ 2M $\square$  $\square$  with E53-CZB or E53-CZHB, E5AZ- $\square$ 3 $\square$ M $\square$  $\square$  with E53-AZB, E5EZ- $\square$ 3 $\square$ M $\square$  $\square$  with E53-AZB. Turn the event inputs ON or OFF while the power is turned ON. Event input ON/OFF changes are detected for inputs of 50 ms or longer.



#### **Related Parameters**

SP 0 to SP 3 (adjustment level): Page 111

Event input assignment 1, Event input assignment 2, Multi-SP uses: Page 132 (advanced function setting level)

ev-1 Event Input Assignment 1 ev-2 Event Input Assignment 2

Event inputs must be supported. The "number of multi-SP uses" parameter must be set to 0 or 1.



• The following functions are assigned for event input 1 and event input 2. RUN/STOP

Auto/manual switch

 Defaults:Event input assignment 1: none Event input assignment 2: stop

Settings	Function
none	None
stop	RUN/STOP
manu	Auto/manual switch



#### **Related Parameters**

SP 0 to SP 3 (adjustment level): Page 111,

Number of multi-SP uses (advanced function setting level): Page 131

# mspu Multi-SP Uses

The model must not support event inputs, or the number of multi-SP uses must be 0.



This parameter enables switching between set points 0 to 3 by operating the keys on the front panel.

Prerequisites

- · A model without event inputs
- The "number of multi-SP uses" parameter set to 0 on a model with event inputs

on: Set points 0 to 3 can be selected.

off: Set points 0 to 3 cannot be selected.

• Default : OFF



#### **Related Parameters**

Multi-SP set point setting (operation level): Page 99

Number of multi-SP uses (advanced function setting level): Page 131

# \_\_\_\_\_

spru

See

# **SP Ramp Time Unit**

The "ST" parameter must be set to OFF.



 This parameter sets the time unit for the rate of change during SP ramp operation.



Setting range	Default
s: EU/s, m: EU/min	m



#### **Related Parameters**


Set point during SP ramp (operation level): Page 100 SP ramp set value (adjustment level): Page 116

# rest Standby Sequence Reset


The alarm 1/2/3 type must be set to a type with a standby sequence.



- This parameter selects the conditions for enabling reset after the standby sequence of the alarm has been canceled.
- Output is turned OFF when switching to the initial setting level, communications setting level, or advanced function setting level.
- Condition A
   Control started (including power ON), and set point, alarm value (alarm value upper/lower limit), or input shift value (upper/lower-limit temperature input shift value) changed.
- Condition B Power ON
- The following example shows the reset action when the alarm type is lower-limit alarm with standby sequence.









#### **Related Parameters**

Alarm 1 to 3 type (initial setting level): Page 124 to 126 Alarm 1 to 3 latch (advanced function setting level): Page 139

# al 1n Alarm 1 Open in Alarm

Alarm 1 must be assigned.



- This parameter sets the output status for alarm 1.
- When "close in alarm" is set, the status of the alarm output function will be output as is. When "open in alarm" is set, the status of the alarm output function will be reversed before being output. The following table shows the relationship between alarm output functions, alarm output and output LCDs.
- When "open in alarm" is set, the "open in alarm" status is also applied to heater burnout and HS alarm outputs, and to input error outputs.

	Alarm output operation	Alarm output	Output LCDs
Close in alarm	ON	ON	Lit
	OFF	OFF	Not lit
Open in alarm	ON	OFF	Lit
	OFF	ON	Not lit

Setting range	Default
n-o: Close in alarm, n-c: Open in alarm	n-o



#### **Related Parameters**

Alarm value 1: Page 101, Alarm value upper limit 1, Alarm value lower limit 1: Page 103 (operation level)

Alarm 1 type (initial setting level): Page 124

Standby sequence reset: Page 133, Alarm 1 hysteresis: Page 135, Alarm 1 latch: Page 139 (advanced function setting level)

al 2n	Alarm 2 Open in Alarm
al 3n	Alarm 3 Open in Alarm

Alarm 2 must be assigned.

Alarm 3 must be assigned.



- These parameters set the output status for alarm 2 and alarm 3 settings.
- When "close in alarm" is set, the status of the alarm output function will be output as is. When "open in alarm" is set, the status of the alarm output function will be reversed before being output. The following table shows the relationship between alarm output functions, alarm output and output LCDs.

	Alarm output operation	Alarm output	Output LCDs
Close in alarm	ON	ON	Lit
	OFF	OFF	Not lit
Open in alarm	ON	OFF	Lit
	OFF	ON	Not lit

Setting range	Default
n-o: Close in alarm, n-c: Open in alarm	n-o





#### **Related Parameters**

Alarm value 2 and 3: Page 102, Alarm value upper limit 2 and 3, Alarm value lower limit 2 and 3: Page 103 to 104 (operation level)

Alarm 2 to 3 type (initial setting level): Page 126

Alarm 2 and 3 hysteresis: Page 135, Standby sequence reset: Page 133,

Alarm 2 and 3 latch: Page 139 (advanced function setting level)

al h1	Alarm 1 Hysteresis	Alarm 1 must be assigned, and the alarm 1 type must not be 0 or 12.
al h2	Alarm 2 Hysteresis	Alarm 2 must be assigned, and the alarm 2 type must not be 0.
al h3	Alarm 3 Hysteresis	Alarm 3 must be assigned, and the alarm 3 type must not be 0.



These parameters set alarm 1, 2, and 3 hysteresis.



Models	Setting range	Unit	Default
Controllers with Thermocouple/Resistance Thermometer Universal-inputs	0.1 to 999.9	°C or °F (See note.)	0.2
Controllers with Analog Inputs	0.01 to 99.99	%FS	0.02

Note

Set "none" as the unit for Controllers with Analog Inputs.



#### **Related Parameters**

Alarm value 1 to 3: Page 101 to 102, Alarm value upper limit 1 to 3: Page 103 to 104, Alarm value lower limit 1 to 3: Page 103 to 104 (operation level)

Alarm 1 to 3 type (initial setting level): Page 124 to 126

Standby sequence reset: Page 133, Alarm 1 to 3 open in alarm: Page 134, Alarm 1 to 3 latch: Page 139 (advanced function setting level)

# hbu HB ON/OFF

Heater burnout and HS alarms must be supported. Alarm 1 must be assigned.



Set to use the heater burnout alarm.



Setting range	Default
on: Enabled, off: Disabled	on

#### hbl Heater Burnout Latch

Heater burnout and HS alarms must be supported. Alarm 1 must be assigned. The "heater burnout detection" parameter must be set to ON.



- When this parameter is set to ON, the heater burnout alarm is held until either of the following conditions is satisfied.
  - a Heater burnout detection is set to 0.0 A.
  - b The power is turned OFF then back ON again (i.e., power is reset).
- Output is turned OFF when switching to the initial setting level, communications setting level, or advanced function setting level.

Setting range	Default
on: Enabled, off: Disabled	off





#### **Related Parameter**

HB ON/OFF (advanced function setting level): Page 135

# hbh Heater Burnout Hysteresis

The "heater burnout" parameter must be set to ON.

The "heater burnout latch" parameter must be set to OFF.

Heater burnout and HS alarms must be supported.

Alarm 1 must be assigned.



Function





• This parameter sets hysteresis for heater burnout detection.

Setting range	Unit	Default
0.1 to 50.0	Α	0.1

#### **Related Parameter**

HB ON/OFF (advanced function setting level): Page 135

#### **ST Stable Range** st-b

ST must be ON and temperature input, standard control, 2-PID control must be set.



• The setting of this parameter determines when ST operates. This parameter cannot be used when ST is set to OFF.

5	ottina

Setting range	Unit	Default
0.1 to 999.9	°C or °F	15.0



## **Related Parameters**

Input type: Page 119, PID ON/OFF: Page 122, ST: Page 123 (initial setting level)

al fa  $\alpha$  ST must be OFF and 2-PID control must be set.





- Normally, use the default for this parameter.
- $\bullet$  This parameter sets the 2-PID control  $\alpha$  constant.

Setting range	Unit	Default
0.00 to 1.00	None	0.65




## **Related Parameters**

PID ON/OFF: Page 122, ST: Page 123 (initial setting level)

# inf Input Digital Filter



• This parameter sets the time constant for the input digital filter. The following diagram shows the effect on data after passing through the digital filter:



Settir	ig

Setting range	Unit	Default
0.0 to 999.9	Second	0.0

# pvad Additional PV Display



Function



This parameter adds a display at the beginning of the operation level for the process value (PV). If there is no need to display the set point, use this to display only the present temperature.

Set to ON to display, and OFF to not display.

Setting range	Default
on: Displayed, off: Not displayed	off

# o-dp MV Display



Function





This parameter is used to display the manipulated variable (MV).

The manipulated variable is displayed when the "MV monitor (heating) and (cooling)" parameters are set to ON, and not displayed when these parameters are set to OFF.


Setting range	Default
on: Displayed, off: Not displayed	off


#### **Related Parameters**

MV monitor (heating): Page 104, MV monitor (cooling): Page 105 (operation level)

# ret Automatic Display Return Time







Setting range	Unit	Default
OFF, 1 to 99	Second	off



a1l t	Alarm 1 Latch	Alarm 1 must be assigned, and the alarm 1 type must not be 0.
a2l t	Alarm 2 Latch	Alarm 2 must be assigned, and the alarm 2 type must not be 0.
a3l t	Alarm 3 Latch	Alarm 3 must be assigned, and the alarm 3 type must not be 0.



- When a parameter is set to ON, once the alarm function has turned ON it
  is held until the power is turned OFF. The latch can be canceled, however, by switching to the initial setting level, communications setting level,
  or advanced function setting level.
- If alarm outputs are set to "close in alarm," the outputs are kept closed. If they are set to "open in alarm," they are kept open.

Setting range	Default
on: Enabled, off: Disabled	off





#### **Related Parameters**

Alarm value 1 to 3: Page 101 to 102, Alarm value upper limit 1 to 3: Page 103 to 104, Alarm value lower limit 1 to 3: Page 103 to 104 (operation level)

Alarm 1 to 3 type (initial setting level): Page 124 to 126

Standby sequence reset: Page 133, Alarm 1 to 3 open in alarm: Page 134, Alarm 1 to 3 hysteresis: Page 135 (advanced function setting level)

# prl t Move to Protect Level Time



• This parameter sets the key pressing time required to move to the protect level from the operation level or the adjustment level.



Setting range	Unit	Default
1 to 30	Second	3



## **Related Parameters**

Operation/adjustment protect, initial setting/communications protect, setting change protect (protect level): Page 96

# sero Input Error Output

Alarm 1 must be assigned.



 When this parameter is set to ON, alarm 1 output turns ON for input errors.

The alarm 1 operation indicator will not light.

**Note** For details on input errors, refer to *Error Displays* on page 156.

- The alarm 1 output is an OR output of alarm 1, HB alarm burnout/HS alarm, and input error.
- Output is turned OFF when switching to the initial setting level, communications setting level, or advanced function setting level.

Setting range	Default
on: Enabled, off: Disabled	off



# **Cold Junction Compensation Method**

Input type must be thermocouple or infrared temperature sensor



cj c

- Specifies whether cold junction compensation is to be performed internally by the Controller or to be performed externally when the input type setting is to between 5 and 22.
- The cold junction compensation external setting is enabled when the temperature difference is measured using two thermocouples or two ES1B Sensors.

Setting range	Default
on: Internally, off: Externally	on



# See

# **Related Parameter**


Input type (initial setting level): Page 119

## rl rv

# **MB Command Logic Switching**

Communications must be supported. CompoWay/F must be selected as the protocol.





- The MB command (communications writing switch) is the equivalent of the MB command (remote/local switch) of the E5 J.
- The setting indicated by the shaded area is the default (same logic as E5□J).

Set	Text data of MB command		
value	0000	0001	
OFF	Communications writing enabled (remote mode selection)	Communications writing disabled (local mode selection)	
ON	Communications writing disabled (local mode selection)	Communications writing enabled (remote mode selection)	

(Terms in parentheses () are the terms used on the E5 $\square$ J.)



#### **Related Parameters**

Communications writing (adjustment level): Page 108 Protocol setting (communications setting level): Page 149



a1on	Alarm 1 ON Delay	Alarm 1 must be assigned, and the alarm 1 type must not be 0 or 12.
a2on	Alarm 2 ON Delay	Alarm 2 must be assigned, and the alarm 2 type must not be 0.
a3on	Alarm 3 ON Delay	Alarm 3 must be assigned, and the alarm 3 type must not be 0.

Alarm 1, 2, or 3 outputs are prevented from turning ON until after the delay times set in these parameters have elapsed.

- Set the time for which the ON delay is to be enabled.
- To disable the ON delay, set 0.

<b>~~</b>	
Function	



Setting range	Unit	Default
0 to 999	Second	0



## **Related Parameters**

Alarm 1 to 3 type (initial setting level): Page 124 to 126

a1of	Alarm 1 OFF Delay	Alarm 1 must be assigned, and the alarm 1 type must not be 0 or 12.
a2of	Alarm 2 OFF Delay	Alarm 2 must be assigned, and the alarm 2 type must not be 0.
a3of	Alarm 3 OFF Delay	Alarm 3 must be assigned, and the alarm 3 type must not be 0.

Alarm 1, 2, or 3 outputs are prevented from turning OFF until after the delay times set in these parameters have elapsed.

- Set the time for which the OFF delay is to be enabled.
- To disable the OFF delay, set 0.

Setting range	Unit	Default
0 to 999	Second	0







#### **Related Parameters**

Alarm 1 to 3 type (initial setting level): Page 124 to 126

istp	Input Shift	Type
------	-------------	------


The input type must be thermocouple or resistance thermometer.

This parameter sets the shift method for thermocouple or resistance thermometer inputs.

• When the input type is thermocouple or resistance thermometer, set either a 1-point shift or a 2-point shift.









#### **Related Parameters**

Temperature input shift: Page 111, Upper-limit temperature input shift value, Lower-limit temperature input shift value: Page 112 (adjustment level) Input type (initial setting level): Page 119

#### amad

#### **Auto/Manual Select Addition**

The control must be set to 2-PID control.

**~** 

This parameter sets whether the "auto/manual switch" parameter is to be displayed.

• Set whether the "auto/manual switch" parameter is to be displayed.



Se	ettina	

Setting range	Default
on: Displayed, off: Not displayed	off



#### **Related Parameter**

Auto/manual switch (operation level): Page 99

# hsu HS Alarm Use

Heater burnout and HS alarms must be supported. Alarm 1 must be assigned.



• Set this parameter to use HS alarms.



Setting range	Default
on: Enabled, off: Disabled	on

#### hsl

## **HS Alarm Latch**

Heater burnout and HS alarms must be supported. Alarm 1 must be assigned. The "HS alarm" parameter must be



- When this parameter is set to ON, the HS alarm is held until either of the following conditions is satisfied.
  - a The HS alarm current is set to 50.0 A.
  - b The power is turned OFF then back ON again (i.e., power is reset).

set to ON.

• Output is turned OFF when switching to the initial setting level, communications setting level, or advanced function setting level.

Setting range	Default
on: Enabled, off: Disabled	off



#### **Related Parameter**

HS alarm use (advanced function setting level): Page 143



#### hsh **HS Alarm Hysteresis**

Heater burnout and HS alarms must be supported.

Alarm 1 must be assigned.

The "HS alarm" parameter must be set to ON.

The "HS alarm latch" must be set to





• This parameter sets the hysteresis for HS alarm.



Setting range	Unit	Default
0.1 to 50.0	Α	0.1



#### **Related Parameter**

HS alarm use (advanced function setting level): Page 143

**LBA Detection Time** I ba


Alarm 1 must be assigned. The alarm type must be set to 12 (LBA).

This parameter enables or disables the LBA function and sets the detection time interval.

- Set the time interval for detecting loop burnouts.
- To disable the LBA function, set 0.









## **Related Parameters**

Alarm 1 type (initial setting level): Page 124

LBA level, LBA band: Page 145 (advanced function setting level)

#### I bal **LBA Level**

Alarm 1 must be assigned. The alarm type must be set to 12 (LBA). The LBA detection time must not be 0.



• This parameter sets the LBA level.



• If the deviation between the SP and PV exceeds the LBA level, a loop burnout is detected.

	Models	Setting range	Unit	Default
ng	Controllers with Thermocouple/Resistance Thermometer Universal-inputs	0.1 to 999.9	°C or °F (See note.)	8.0
•	Controllers with Analog Inputs	0.01 to 99.99	%FS	10.00

Note Set "none" as the unit for Controllers with Analog Inputs.

# See

#### **Related Parameters**

Process value/set point (operation level): Page 99

Alarm 1 type (initial setting level): Page 124


LBA detection time: Page 144, LBA band: Page 145 (advanced function setting level)

#### I bab **LBA Band**


Alarm 1 must be assigned. The alarm type must be set to 12 (LBA).

The LBA detection time must not be 0.





• If a control deviation greater than the LBA band is not reduced when the LBA level is exceeded, an loop burnout is detected.





Note Set "none" as the unit for Controllers with Analog Inputs.



#### **Related Parameters**

Process value/set point (operation level): Page 99

Alarm 1 type (initial setting level): Page 124

LBA detection time: Page 144, LBA level: Page 145 (advanced function setting level)

# out1 Control Output 1 Assignment

The transfer output type must be set to OFF when the control output is a current output.



• This parameter sets the function to be assigned to control output 1.



	Setting range	Default
none:	No function is assigned to control output 1.	0
0:	Heating control output is output.	
C-0:	Cooling control output is output. (See note 1.)	
alm1:	Alarm 1 is output. (See note 2.)	
alm2:	Alarm 2 is output. (See note 2.)	
alm3:	Alarm 3 is output. (See note 2.)	

**Note** 

- (1) If c-o is assigned for standard control, a value equivalent to 0% is output.
- (2) Can be selected for relay and voltage outputs only.

#### **Related Parameters**

Standard or heating/cooling: Page 123, Transfer output type: Page 127 (initial setting level)



# al m1 Alarm output 1 Assignment

Alarm output 1 must be assigned.



Function



• This parameter sets the function to be assigned to alarm output 1.

Setting range	Default			
none: No function is assigned to alarm output 1.	alm1			
o: Heating control output is output.				
c-o: Cooling control output is output. (See note.)				
al m1: Alarm 1 is output.				
al m2: Alarm 2 is output.				
al m3: Alarm 3 is output.				

Note

If c-o is assigned for standard control, a value equivalent to 0% will be output.

# al m2 Alarm output 2 Assignment

Alarm output 2 must be assigned.

• This parameter sets the function to be assigned to alarm output 2.

	Setting range	Default
none:	No function is assigned to alarm output 2.	al m2
0:	Heating control output is output.	(See note
C-0:	Cooling control output is output. (See note 1.)	2.)
alm1:	Alarm 1 is output.	
al m2:	Alarm 2 is output.	
alm3:	Alarm 3 is output.	

Note

- (1) If c-o is assigned for standard control, a value equivalent to 0% will be output.
- (2) If the "standard or heating/cooling" parameter is set to heating/cooling control when there is E5CZ/CZ-U, control automatically switches to c-o.

#### **Related Parameters**

Standard or heating/cooling: Page 123, (initial setting level)



## al m3

# **Alarm output 3 Assignment**

Alarm output 3 must be assigned (E5AZ and E5EZ only).



• This parameter sets the function to be assigned to alarm output 3.



	Setting range	Default
none:	No function is assigned to alarm output 3.	al m3
0:	Heating control output is output.	(See note 2.)
C-0:	Cooling control output is output. (See note 1.)	2.)
alm1:	Alarm 1 is output.	
alm2:	Alarm 2 is output.	
alm3:	Alarm 3 is output.	

Note

- (1) If c-o is assigned for standard control, a value equivalent to 0% will be output.
- (2) If the "standard or heating/cooling" parameter is set to heating/cooling control when there is E5AZ/EZ, control automatically switches to c-o.



#### **Related Parameters**

Standard or heating/cooling: Page 123, (initial setting level)

## csel

## **Character Select**





This parameter switches the characters to be displayed.
 The following two types of characters can be displayed.
 11-segment display
 7-segment display


Setting range	Default
on: 11-segment display, off: 7-segment display	on

When set to on, an 11-segment display is used.


# 5-8 Communications Setting Level

psel	Protocol Setting	Communications must be supported.
u-no	Communications Unit No.	
bps	<b>Communications Baud Rate</b>	
l en	Communications Data Length	CompoWay/F must be selected as the protocol.
sbi t	Communications Stop Bits	CompoWay/F must be selected as the protocol.
prty	<b>Communications Parity</b>	
sdwt	Send Data Wait Time	






Match the communications specifications of the E5
 Z and the host computer. If multiple devices are connected, ensure that the communications specifications for all devices in the system (except the Communications unit number) are the same.







Communications writing (adjustment level): Page 108



# Appendix A

# **Specifications**

# Ratings

Supply voltage		100 to 240 VAC, 50/60 Hz		24 VAC, 50/60 Hz/24 VDC	
Operating voltage range		85 to 110% of rated supply v		voltage	
Power consump-	E5CZ	7.5 VA		5.5 VA/3.5W	
tion	E5CZ-U	6 VA		4.5VA/2.5W	
	E5AZ	8.5 VA		6 VA/4 W	
	E5EZ	8.5 VA		6 VA/4 W	
Sensor input (See note 1.)		Thermocoup Platinum resi Infrared temp Voltage input	Temperature input type Thermocouple: K, J, T, E, L, U, N, R, S, B Platinum resistance thermometer: Pt100, JPt100 Infrared temperature sensor: 10 to 70°C, 60 to 120°C, 115 to 165°C, 140 to 260°C Voltage input: 0 to 50 mV		
		Controllers with Analog Inputs Current input: 4 to 20 mA, 0 to 20 mA (Input impedance: 150 $\Omega$ max.) Voltage input: 1 to 5 V, 0 to 5 V, 0 to 10 V (Input impedance: 1 M $\Omega$ max.) (See note 2			
Control output		Relay output	E5CZ	Relay output: SPST-NO, 250 VAC, 3 A (resistive load), electrical durability: 100,000 operations Min. applicable load: 5 V, 10 mA	
			E5CZ-U	SPDT, 250 VAC, 3A (resistive load), electrical durability: 100,000 operations Min. applicable load 5 V 10 mA	
			E5AZ E5EZ	Relay output: SPST-NO, 250 VAC, 5 A (resistive load), electrical durability: 100,000 operations Min. applicable load: 5 V, 10 mA	
		Voltage output	E5CZ E5CZ-U	Output voltage 12 VDC ±15% (PNP), max. load current 21 mA, with short-circuit protection circuit	
			E5AZ E5EZ	Output voltage 12 VDC +15%/–20% (PNP), max. load current 40 mA, with short-circuit protection circuit	
		Current output	4 to 20 mA DC, 0 to 20 mA DC, Load: 600 $\Omega$ max., Resolution: appro 2,700		
Alarm output		E5CZ E5CZ-U	SPST-NO, 250 VAC, 1 A (resistive load), electrical durability: 100,00 operations Min. applicable load: 5 V, 10 mA		
		E5AZ E5EZ	SPST-NO, 250 VAC, 2 A (resistive load), electrical durability: 100,00 operations Min. applicable load: 5 V, 10 mA		
Control method		2-PID or ON/OF	F control		
Setting method		Digital setting using front panel keys			
Indication method		11-segment/7-segment digital display and single-lighting indicator			
Other functions		Depend on the model			
Ambient temperatur	re	-10 to 55°C (with no condensation or icing)			
Ambient humidity		25% to 85%			
Storage temperatur	е	-25 to 65°C (with no condensation or icing)			
Altitude		2,000 m or less			
Recommended fuse	9	T2A, 250 VAC, time lag, low shut-off capacity			
Installation environr	ment	Installation Category II, Pollution Class 2 (IEC 61010-1 compliant)			

**Note** (1) For the setting ranges for each sensor input, see page 172.

(2) When connecting the ES2, connect it 1:1.

# **HB and HS Alarms (for Controller with Heater Burnout and HS Alarms)**

Max. heater current	50 A AC	
Input current indication accuracy	±5% FS ±1 digit max.	
Heater burnout alarm setting range	0.1 to 49.9 A (in units of 0.1A) 0.0 A: Heater burnout alarm output turns OFF. 50.0 A: Heater burnout alarm output turns ON. Min. detection ON time: 190 ms (See note 1.)	
HS alarm setting range	0.1 to 49.9 A (in units of 0.1A) 0.0 A: HS alarm output turns ON. 50.0 A: HS alarm output turns OFF. Min. detection OFF time: 190 ms (See note 2.)	

## Note

- (1) When the control output 1 ON time is less than 190 ms, heater burnout detection and heater current measurement are not performed.
- (2) When the control output 1 OFF time is less than 190 ms, HS alarm and leakage current measurement are not performed.

# **Characteristics**

La di a di a di a di a di a di a	The amount of (2)		
Indication accuracy (ambient temperature of 23°C)	Thermocouple (See note 1.): E5CZ/AZ/EZ: $(\pm 0.5\%$ of indication value or $\pm 1$ °C, whichever is greater) $\pm 1$ digit max. E5CZ-U: $(\pm 1\%$ of indication value or $\pm 2$ °C, whichever is greater) $\pm 1$ digit max.		
	Platinum resistance thermom (±0.5% of indication value	eter: or ±1°C, whichever is greater) ±1 digit max.	
	Analog input: ±0.5% FS ±1 digit max.		
	CT input: ±5% FS ±1 digit ma	X.	
Temperature variation influence (See note 2.)	Thermocouple (R, S, B) (±1% of PV or ±10°C, whichever is greater) ±1 digit max. (E5CZ) (±2% of PV or ±10°C, whichever is greater) ±1 digit max. (E5CZ-U)		
Voltage variation influence	Other thermocouples: (±1% of PV or ±4°C, whichever is greater) ±1 digit max. (E5CZ) (±2% of PV or ±4°C, whichever is greater) ±1 digit max. (E5CZ-U)		
(See note 2.)	*K thermocouple at -100°C r	max: ±10°C max.	
,	Platinum resistance thermometer: (±1% of PV or ±2°C, whichever is greater) ±1 digit max.		
	Analog input: ±1% FS ±1 digi		
Hysteresis	Controllers with Thermocouple/Resistance Thermometer Universal-inputs	0.1 to 999.9°C or °F) (in units of 0.1°C or °F) (See note 3.)	
	Controllers with Analog Inputs	0.01% to 99.99% FS (in units of 0.01% FS)	
Proportional band (P)	Controllers with Thermocouple/Resistance Thermometer Universal-inputs	0.1 to 999.9°C or °F) (in units of 0.1 EU) (See note 3.)	
	Controllers with Analog Inputs	0.1% to 999.9% FS (in units of 0.1% FS)	
Integral time (I)	0 to 3,999 s (in units of 1 s)		
Derivative time (D)	0 to 3,999 s (in units of 1 s)		
Control Period	0.5, 1 to 99 s (in units of 1 s)		
Manual reset value	0.0% to 100.0% (in units of 0.	· · · · · · · · · · · · · · · · · · ·	
Alarm setting range		nt position depends on input type)	
Sampling period	250 ms		
Affect of signal source resis-	Thermocouple:0.1°C/ max.(100 max.)(See note 4.)		
tance	Platinum resistance thermometer:0.4°C/ max.(10 max.)		
Insulation resistance	20 MΩ min. (at 500 VDC)		
Dielectric strength	2,000 VAC, 50/60 Hz for 1 min between terminals of different charge		
Malfunction vibration	10 to 55 Hz, 20 m/s <sup>2</sup> for 10 min each in X, Y and Z directions		
Vibration resistance	10 to 55 Hz, peak height amplitude of 0.75 mm for 2 hr each in X, Y, and Z directions		
Malfunction shock	100 m/s <sup>2</sup> , 3 times each in X, Y, and Z directions		
li-	1		

Shock resistance		300 m/s <sup>2</sup> , 3 times each in X,	Y, and Z directions		
Weight	E5CZ	Approx. 150 g	Adapter: approx. 10 g	Terminal cover: approx. 10 g	
	E5CZ-U	Approx. 110 g			
	E5AZ	Approx. 300 g	Adapter: approx. 100 g	Terminal cover: approx. 20 g	
	E5EZ	Approx. 250 g			
Degree of protection	E5CZ	Front panel: IP66 ( Indoor Use),rear case: IP20, terminals: IP00			
	E5AZ	Front panel: IP66 (Indoor Use), rear case: IP20, terminals: IP00			
	E5EZ				
	E5CZ-U	Front panel: equivalent to IP50, rear case: IP20, terminals: IP00 (See note 5.)			
Memory protection		EEPROM (non-volatile memory) (number of writes: 1,000,000)			

#### Note

- (1) The indication of K thermocouples in the –200 to 1,300°C range, T and N thermocouples at a temperature of –100°C or less, and U and L thermocouples at any temperature is ±2°C ±1 digit maximum. The indication of B thermocouples at a temperature of 400°C or less is not specified. The indication of R and S thermocouples at a temperature of 200°C or less is ±3°C ±1 digit maximum
- (2) Ambient temperature: -10°C to 23°C to 55°C Voltage range: -15 to +10% of rated voltage
- (3) Set "none" as the unit for Controllers with Analog Inputs.
- (4) B,R, and S sensors: 0.2°C/ max.(100 max.)
- (5) There is no waterproof function for the E5CZ-U.

# **Current Transformer (CT)**


# **Specifications**

Item	Specifications		
Model number	E54-CT1	E54-CT3	
Max. continuous current	50 A	120 A (See note.)	
Dielectric strength	1,000 VAC (for 1 min)		
Vibration resistance	50 Hz, 98 m/s <sup>2</sup>		
Weight	Approx. 11.5 g	Approx. 50 g	
Accessories	None	Armature (2) Plug (2)	


**Note** The maximum continuous current of the E5 $\square$ Z is 50 A.

# **External Dimensions**

# E54-CT1



# E54-CT3



# E58-CIFQ1 USB-Serial Conversion Cable

# **Specifications**

Item	Specifications	
Applicable OS	Windows 2000/XP/vista	
Applicable software	Thermo Mini	
Applicable models	OMRON E5CZ/CZ-U Digital Temperature Controllers	
USB interface rating	Conforms to USB Specification 1.1	
DTE speed	38,400 bps	
Connector specifications	Computer end: USB (type A plug) Temperature Controller end: setup tool port (on bottom of controller)	
Power supply	Bus power (5 VDC supplied from USB host controller)	
Current consumption	70 mA	
Ambient operating temperature	0 to 55°C (with no condensation or icing)	
Ambient operating humidity	10% to 80%	
Storage temperature	-20 to 60°C (with no condensation or icing)	
Storage humidity	10% to 80%	
Altitude	2,000 m max.	
Weight	Approx. 100 g	


# **Compatible Operating Environment**

A personal computer that includes the following specifications is required.

- USB port
- CD-ROM drive
- Windows 2000/XP/Vista

# **Appearance and Nomenclature**

# **Appearance**



## **LED Indicator Display**

Indicator	Color	Status	Meaning
SD	Yellow	Lit	Sending data from USB-Serial Conversion Cable
		Not lit	Not sending data from USB-Serial Conversion Cable
RD	Yellow	Lit Sending data from USB-Serial Conversion Cable	
		Not lit	Not sending data from USB-Serial Conversion Cable

# **Error Displays**

When an error occurs, the error contents are shown on the No. 1 display.

This section describes how to check error codes on the display, and the actions to be taken to remedy the problems.

S.ERR

**Input Error** 

# Meaning

The input value has exceeded the control range. (See note.)

Note Control Range

ES1B input:

Analog input

Resistance thermometer, thermocouple input: Temperature setting lower limit  $-20^{\circ}\text{C}$  to temperature

setting upper limit + 20°C

(Temperature setting lower limit – 40°F to temperature

setting upper limit + 40°F)
Same as input indication range
–5% to +105% of scaling range

## Action

Check the wiring of inputs for miswiring, disconnections, and short-circuits and check the input type.

If no abnormality is found in the wiring and input type, turn the power OFF then back ON again.

If the display remains the same, the Controller must be replaced. If the display is restored, then the probable cause is electrical noise affecting the control system. Check for electrical noise.

# **Operation at Error**

After an error occurs, the error is displayed and the alarm outputs function as if the upper limit has been exceeded.

When the "input error output" parameter in the advanced function setting level is set to ON, the alarm 1 output turns ON whenever an input error occurs.

An error message is displayed when the PV, PV/SP, or PV/MV is displayed.

**Note** When the manual MV is set, the control output corresponds to the set value.



# **Display Range Exceeded**

## **Meaning**

Though this is not an error, it is displayed if the process value exceeds the display range when the control range is larger than the display range.


The display ranges are shown below (with decimal points omitted).

• When less than –1999 [[[[

When more than 9999 ]]]]

#### **Action**

Control continues, allowing normal operation. The message is displayed when the PV, PV/SP, or PV/MV is displayed.



Note: The display range is shown in numbers with decimal points omitted.

H.ERR

HB Error (See note.)

## **Meaning**

There is an error in internal circuits.

#### Action

First, turn the power OFF then back ON again. If the display remains the same, the Controller must be repaired. If the display is restored, then the probable cause is electrical noise affecting the control system. Check for electrical noise.


#### **Operation at Error**

The control outputs and alarm outputs turn OFF. An error message is displayed when the PV, PV/SP, or PV/MV is displayed.

When the manual MV is set, the control output corresponds to the set value.

For alarm outputs, the operation indicators and status normally turn OFF, but they will turn ON if the "Open in alarm" parameter for alarms 1, 2, or 3 in the advanced function setting level is set to n-c (Open in alarm).

**Note** Applies to the E5CZ- $\square$ 2M $\square$  $\square$  with E53-CZH03 or E53-CZHB, E5AZ- $\square$ 3HM $\square$  $\square$ , E5EZ- $\square$ 3HM $\square$  $\square$ .



**Memory Error** 

## **Meaning**

Internal memory operation is in error.

#### **Action**

First, turn the power OFF then back ON again. If the display remains the same, the Controller must be repaired. If the display is restored, then the probable cause is electrical noise affecting the control system. Check for electrical noise.

### **Operation at Error**

Control output and alarm output turn OFF. (Current output is approx. 0 mA).



### **Current Value Exceeds**

#### Meaning

This error is displayed when the heater current value exceeds 55.0 A.

#### **Action**

Control continues, allowing normal operation. An error message is displayed when the following items are displayed.

Heater current 1 value monitor Leakage current 1 monitor



Heater Burnout HS Alarm

#### **Meaning**

When heater burnout or an HS alarm occurs, the No. 1 display in the applicable setting level flashes.

#### **Action**

When either heater burnout or HS is detected, the HA indicator lights and the No. 1 display flashes for the applicable "heater current 1 value monitor," or "leakage current 1 monitor" parameters in the operation level and adjustment level. Control continues, allowing normal operation.

# **Troubleshooting**

#### **Checking Problems**

If the Temperature Controller is not operating normally, check the following points before requesting repairs. If the problem persists, contact your OMRON representative for details on returning the product.

Timing	Status	Meaning	Countermeasures	Page
Turning ON the power for the first time	Temperature unit (°C/°F) is flashing.	ST (self-tuning) is in progress (default setting: ON).	This is not a product fault. The temperature unit (°C/°F) flashes while ST (self-tuning) is being performed	44
	Temperature error is large.	Input type mismatch	Check the sensor type and reset the input type correctly.	34
	Input error (S.Err display)	Thermometer is not installed properly.	Check the thermometer installation location and polarity and install correctly.	21
	Communications are not possible.	Non-recommended adapter is being used.	Make sure that the connected device is not faulty.	Section 1 of Communi- cations Manual

# Appendix A

Timing	Status	Meaning	Countermeasures	Page
During operation	Overshooting Undershooting Hunting	ON/OFF control is enabled (default: ON/OFF control selected).	Select PID control and execute either ST (self-tuning) or AT (auto-tuning). When using self-tuning, turn ON the power supply to the Temperature Controller and load (heater, etc.) at the same time, or turn ON the load power supply first. Accurate self-tuning and optimum control will not be possible if the power supply to the load is turned ON after turning ON the power supply to the Temperature Controller.	43
		Control cycle is longer compared with the speed of rise and fall in tempera- ture	Shorten the control cycle. A shorter control cycle improves control performance, but a cycle of 20 ms minimum is recommended in consideration of the service life of the relays.	36
		Unsuitable PID constant	Set appropriate PID constants using either of the following methods.  • Execute AT (autotuning).  • Set PID constants individually using manual settings.	43
		HS alarm operation fault	Use breeder resistance if the problem is due to leakage current. Also investigate the errors detected by the HS alarm function.	50
	Temperature is not rising	Specified operation is unsuitable for required control (default: Reverse operation)	Select either direct or reverse operation depending on the required control. Reverse operation is used for heating operations.	36
		Heater is burnt out or deteriorated.	Check whether heater burnout or deteriora- tion have occurred. Also investigate the errors detected by the heater burnout alarm.	50
		Insufficient heater capacity	Check whether the heater's heating capacity is sufficient.	
		Cooling system in operation.	Check whether a cooling system is operating.	
		Peripheral devices have heat prevention device operating.	Set the heating prevention temperature set- ting to a value higher than the set tempera- ture of the Temperature Controller.	
	Output will not turn ON	Set to STOP (default: RUN)	Set the RUN/STOP mode to RUN. If STOP is lit on the display, control is stopped.	101
		Specified operation is unsuitable for required control (default: Reverse operation)	Select either direct or reverse operation depending on the required control. Reverse operation is used for heating operations.	37
		A high hysteresis is set for ON/OFF operation (default: 1.0°C)	Set a suitable value for the hysteresis.	41
	Temperature Controller will not operate	Set to STOP (default: RUN)	Set the RUN/STOP mode to RUN. If STOP is lit on the display, control is stopped.	101

# Appendix A

Timing	Status	Meaning	Countermeasures	Page
During operation (continued)	Temperature error is large Input error (S.err dis-	Thermometer has burnt out or short-circuited.	Check whether the thermometer has burnt out or short-circuited	
	play)	Thermometer lead wires and power lines are in the same conduit, causing noise from the power lines (generally, display values will be unstable).	Wire the lead wires and power lines in separate conduits, or wiring using a more direct path.	
		Connection between the Temperature Controller and ther- mocouple is using copper wires.	Connect the thermocouple's lead wires directly, or connect a compensating conductor suitable for the thermocouple.	
		Installation location of thermometer is unsuitable.	Check whether the location of the thermometer is suitable.	
		Input shift is not set correctly (default: 0°C)	Set a suitable input shift. If input shift is not required, set the input shift value to 0.0.	59
	Keys will not operate	Setting change protect is ON.	Turn OFF setting change protect.	78
	Cannot shift levels	Operations limited due to protection.	Set the operation/adjustment protect, initial setting/communications protect, and setting change protect values as required.	78
After long ser- vice life	Control is unstable	Terminal screws may be loose.	Retighten terminal screws to a torque of 0.74 to 0.90 N·m. (See Note.)	22
		The internal components have reached the end of their service life.	The Temperature Controller's internal electrolytic capacitor depends on the ambient temperature, and load rate. The structural life depends on the ambient environment (shock, vibration). The life expectancy of the output relays varies greatly with the switching capacity and other switching conditions. Always use the output relays within their rated load and electrical life expectancy. If an output relay is used beyond its life expectancy, its contacts may become welded or burned. Replace the Temperature Controller and all other Temperature Controllers purchased in the same time period.	

Note The tightening torque for E5CZ-U is 0.5 N·m.

# **Symptom: Cannot Communicate or a Communications Error Occurs**

Meaning	Countermeasures
The communications wiring is not correct.	Correct the wiring.
The communications line has become disconnected	Correct the communications line securely and tighten the screws.
The communications cable is broken.	Replace the cable.
The communications cable is too long.	The total cable length is 500 m maximum for RS-485 and 15 m maximum for RS-232C communications. To extend the communications distance for RS-232C communications, use OMRON's Z3R Optical Interface.
The wrong communications cable has been used.	Use a shielded, twisted-pair AWG24 to AWG14(cross-sectional area of 0.205 to 2.081 mm <sup>2</sup> )cable for the communications cable.
More than the specified number of communications devices are connected to the same communications path for RS-485 communications.	When 1:N RS-485 communications are used, a maximum of 32 nodes(including the host node) can be connected.
An end node has not been set at each end of the communications line for RS-485 communications.	Set or connect terminating resistance at each end of the line. If the E5CZ, E5AZ,or E5EZ is the end node, use 120- (1/2-W) terminating resistance. The combined terminating resistance with the host device must be at least 54
The specified power supply voltage is not being supplied to the Controller.	Supply the specified power supply voltage.
The specified power supply voltage is not being supplied to an Interface Converter (such as the K3SC) .	Supply the specified power supply voltage.
The same baud rate and communications method are not being used by all of the Controllers, host devices, and other devices on the same communications line.	Set the same values for the baud rate, protocol, data length, stop bits, and parity on all nodes.
The unit number specified in the command frame is different from the unit number set by the Controller.	Use the same unit number.
The same unit number as the Controller is being used for another node on the same communications line for RS-485 communications.	Set each unit number for only one node.
There is a mistake in programming the host device.	Use a line monitor to check the commands. Check operation using a sample program.
The host device is detecting the absence of a response as an error before it receives the response from the Controller.	Shorten the send data wait time in the Controller or increase the response wait time in the host device.
The host device is detecting the absence of a response as an error after broadcasting a command(except for SYSWAY).	The Controller does not return responses for broadcast commands.
The host device sent another command before receiving a response from the Controller.	The response must always be read after sending a command (except for broadcast commands).
The host device sent the next command too soon after receiving a response from the Controller.	After receiving a response, wait at least 2 ms before sending the next command.

Meaning	Countermeasures
The communications line became unstable when Controller power was turned ON or interrupted, and the host device read the unstable status as data.	Initialize the reception buffer in the host device before sending the first command and after turning OFF the power to the Controller.
The communications data was corrupted	Try using a slower baud rate.
from noise from the environment.	Separate the communications cable from the source of noise.
	Use a shielded, twisted-pair cable for the communications cable.
	Use as short a communications cable as possible, and do not lay or loop extra cable.
	To prevent inductive noise, do not run the communications cable parallel to a power line.
	If noise countermeasures are difficult to implement, use an Optical Interface.

**Note** For details on errors, refer to *E5CZ/E5AZ/E5EZ Digital Temperature Controllers Communications Manual*(Cat. No. H208).

# **Parameter Operation Lists**

Universal-input:Controllers with Thermocouple/Resistance Thermometer Universal-inputs Analog input:Controllers with Analog Inputs

## **Operation Level**

Parameters	Characters	Setting (monitor) value	Display	Default	Unit	Set value
Process Value		Sensor input indication range			EU	
Set Point		SP lower limit to SP upper limit		0	EU	
Auto/Manual Switch	a-m					
Multi-SP Set Point Setting	m-sp	0 to 3		0	None	
Set Point During SP Ramp	sp-m	SP lower limit to SP upper limit			EU	
Heater Current 1 Value Monitor	ct1	0.0 to 55.0			А	
Leakage Current 1 Monitor	I cr1	0.0 to 55.0			А	
RUN/STOP	r-s	RUN/STOP	run, stop	Run	None	
Alarm Value 1	al -1	-1999 to 9999		0	EU	
Alarm Value Upper- Limit 1	al 1h	-1999 to 9999		0	EU	
Alarm Value Lower- Limit 1	al 1l	-1999 to 9999		0	EU	
Alarm Value 2	al -2	-1999 to 9999		0	EU	
Alarm Value Upper- Limit 2	al 2h	-1999 to 9999		0	EU	
Alarm Value Lower- Limit 2	al 2l	-1999 to 9999		0	EU	
Alarm Value 3	al -3	-1999 to 9999		0	EU	
Alarm Value Upper- Limit 3	al 3h	-1999 to 9999		0	EU	
Alarm Value Lower- Limit 3	al 3l	-1999 to 9999		0	EU	
MV Monitor (Heat-ing)	0	-5.0 to 105.0 (standard) 0.0 to 105.0 (heating/cooling)			%	
MV Monitor (Cooling)	C-0	0.0 to 105.0			%	

# Adjustment Level

Parameters	Characters	Setting (monitor) value	Display	Default	Unit	Set value
AT Execute/Cancel	at	OFF, ON	off, on	OFF	None	
Communications Writing	cmwt	OFF, ON	off, on	OFF	None	
Heater Current 1 Value Monitor	ct1	0.0 to 55.0			А	
Leakage Current 1 Monitor	I cr1	0.0 to 55.0			А	
Heater Burnout Detection 1	hb1	0.0 to 50.0		0.0	А	
HS Alarm 1	hs1	0.0 to 50.0		50.0	Α	
SP 0	sp-0	SP lower limit to SP upper limit		0	EU	
SP 1	sp-1	SP lower limit to SP upper limit		0	EU	
SP 2	sp-2	SP lower limit to SP upper limit		0	EU	
SP 3	sp-3	SP lower limit to SP upper limit		0	EU	
Temperature Input Shift	ins	-199.9 to 999.9		0.0	°C or °F	
Upper-Limit Temper- ature Input Shift Value	i nsh	-199.9 to 999.9		0.0	°C or °F	
Lower-Limit Temper- ature Input Shift Value	i nsl	-199.9 to 999.9		0.0	°C or °F	
Proportional Band	р	Universal-input: 0.1 to 999.9		8.0	°C or °F (See note.)	
		Analog input: 0.1 to 999.9		10.0	%FS	
Integral Time	i	0 to 3,999		233	Second	
Derivative Time	d	0 to 3,999		40	Second	
Cooling Coefficient	C-SC	0.01 to 99.99		1.00	None	
Dead Band	c-db	Universal-input: -199.9 to 999.9		0.0	°C or °F (See note.)	
		Analog input: -19.99 to 99.99		0.00	%FS	
Manual Reset Value	of-r	0.0 to 100.0		50.0	%	
Hysteresis (Heating)	hys	Universal-input: 0.1 to 999.9		1.0	°C or °F (See note.)	
		Analog input: 0.01 to 99.99		0.10	%FS	
Hysteresis (Cooling)	chys	Universal-input: 0.1 to 999.9		1.0	°C or °F (See note.)	
		Analog input: 0.01 to 99.99		0.10	%FS	
SP Ramp Set Value	sprt	OFF or 1 to 9,999	off, 1 to 9999	OFF	EU/s, EU/ min	
MV Upper Limit	ol -h	MV lower limit +0.1 /105.0 (standard) 0.0 to 105.0 (heating/cooling)		105.0	%	
MV Lower Limit	ol -l	-5.0 to MV upper limit -0.1 (standard) -105.0 to 0.0 (heating/cooling)		-5.0 (standard) -105.0 (heating/cooling)	%	

Note Set "none" as the unit for Controllers with Analog Inputs.

# **Initial Setting Level**

Parameters	Characters	Setting (mo	onitor) value	Display	Default	Unit	Set value
Input Type	in-t	20: 21: 22:	E L U N R S		5	None	
		Analog 0: input 1: 2: 3: 4:	4 to 20 mA 0 to 20 mA 1 to 5 V 0 to 5 V 0 to 10 V		0	None	
Scaling Upper Limit	i n-h	Scaling lower I 9,999	limit + 1 to		100	None	
Scaling Lower Limit	i n-l	−1,999 to scali −1	ing upper limit		0	None	
Decimal Point	dp	Universal-inpu	t: 0 to 1		0	None	
		Analog input: (	) to 3		0	None	
Temperature Unit	d-u	°C, °F		c, f	°C	None	
SP Upper Limit	sl -h	SP lower limit range upper lir ture)  SP lower limit	mit (tempera-		1300	EU	
		upper limit (an					
SP Lower Limit	sl -l	Input range lov upper limit – 1			-200	EU	
		Scaling lower I upper limit – 1			0		
PID ON/OFF	intl	ON/OFF 2-PID	)	onof, pi d	ON/OFF	None	
Standard or Heating/ Cooling	s-hc	Standard or he	eating/cooling	stnd, h-c	Standard	None	
ST	st	OFF, ON		off, on	ON	None	
Control Period (Heating)	ср	0.5 or 1 to 99		0.5, 1 to 99	20	Second	
Control Period (Cooling)	с-ср	0.5 or 1 to 99		0.5, 1 to 99	20	Second	
Direct/Reverse Operation	orev	Reverse operation	ation, direct	or-r, or-d	Reverse operation	None	

Parameters	Characters	Setting (monitor) value	Display	Default	Unit	Set value
Alarm 2 Type	al t1	O: Alarm function OFF  1: Upper and lower-limit alarm  2: Upper-limit alarm  3: Lower-limit alarm  4: Upper and lower-limit range alarm  5: Upper and lower-limit alarm with standby sequence  6: Upper-limit alarm with standby sequence  7: Lower-limit alarm with standby sequence  8: Absolute-value upper-limit alarm  9: Absolute-value lower-limit alarm  10: Absolute-value upper-limit alarm with standby sequence  11: Absolute-value lower-limit alarm with standby sequence  12: LBA (Loop Break Alarm)		2	None	
Alarm 2 Type	al t2	<ol> <li>O: Alarm function OFF</li> <li>1: Upper and lower-limit alarm</li> <li>2: Upper-limit alarm</li> <li>3: Lower-limit alarm</li> <li>4: Upper and lower-limit range alarm</li> <li>5: Upper and lower-limit alarm with standby sequence</li> <li>6: Upper-limit alarm with standby sequence</li> <li>7: Lower-limit alarm with standby sequence</li> <li>8: Absolute-value upper-limit alarm</li> <li>9: Absolute-value lower-limit alarm</li> <li>10: Absolute-value upper-limit alarm with standby sequence</li> <li>11: Absolute-value lower-limit alarm with standby sequence</li> </ol>		2	None	
Alarm 3 Type	al t3	Same settings as the alarm 2 type		2	None	
Transfer Output Type	tr-t	OFF: OFF SP: Set point SP-M: Set point during SP ramp PV: Process value MV: Manipulated variable (heating) C-MV: Manipulated variable (cooling)	off sp sp-m pv mv C-mv	OFF	None	
Transfer Output Upper Limit	tr-h	See note.		See note.	See note.	
Transfer Output Lower Limit	tr-I	See note.		See note.	See note.	

#### Note

Transfer output type	Setting (monitor) range	Default (transfer output upper/lower limits) (See note 1)	Unit
Set point	SP lower limit to SP upper limit	SP upper limit/lower limit	EU
Set point during SP ramp	SP lower limit to SP upper limit	SP upper limit/lower limit	EU
PV	Temperature: Sensor setting range lower limit to sensor setting range upper limit	Sensor setting range upper/ lower limit	EU
	Analog: Scaling lower limit to scaling upper limit	Scaling upper/lower limit	EU
MV monitor (heating)	Standard: -5.0 to 105.0 Heating/cooling: 0.0 to 105.0	100.0/0.0	%
MV monitor (cooling)	0.0 to 105.0	100.0/0.0	%

(1) Initialized when the transfer output type is changed.
Initialized if the input type, temperature unit, scaling upper/lower limit, or SP upper/lower limit is changed when the transfer output type is SP, ramp SP, or PV.
(When initialized by the initializing settings, it is initialized to 100.0/0.0.)

Parameters	Characters	Setting (monitor) value	Display	Default	Unit	Set value
Linear Current Output	o1-t	4-20: 4 to 20 mA 0-20: 0 to 20 mA	4-20, 0-20	4-20	None	
Move to Advanced Function Setting Level	amov	-1999 to 9,999		0	None	

## **Manual Control Level**

Parameters	Characters	Setting (monitor) value	Display	Default	Unit	Set value
Manual MV		-5.0 to 105.0 (standard) -105.0 to 105.0 (heating/cooling)		0.0	%	

## **Advanced Function Setting Level**

Parameters	Characters	Setting (monitor) value	Display	Default	Unit	Set value
Parameter Initializa- tion	init	OFF, FACT	off, fact	OFF	None	
Number of Multi-SP Uses	ev-m	0 to 2		1	None	
Event Input Assignment 1	ev-1	NONE: None STOP: RUN/STOP MANU: Auto/manual switch	none, stop, manu	NONE	None	
Event Input Assignment 2	ev-2	NONE: None STOP: RUN/STOP MANU: Auto/manual switch	none, stop, manu	STOP	None	
Multi-SP Uses	mspu	OFF, ON	off, on	OFF	None	
SP Ramp Time Unit	spru	S: EU/second M: EU/minute	s, m	М	None	
Standby Sequence Reset	rest	Condition A, Condition B	a, b	Condition A	None	
Alarm 1 Open In Alarm	al 1n	N-O: Close in alarm N-C: Open in alarm	n-o, n-c	N-O	None	
Alarm 1 Hysteresis	al h1	Universal-input: 0.1 to 999.9		0.2	°C or °F (See note.)	
		Analog input: 0.01 to 99.99		0.02	%FS	
Alarm 2 Open In Alarm	al 2n	N-O: Close in alarm N-C: Open in alarm	n-o, n-c	N-O	None	
Alarm 2 Hysteresis	al h2	Universal-input: 0.1 to 999.9		0.2	°C or °F (See note.)	
		Analog input: 0.01 to 99.99		0.02	%FS	
Alarm 3 Open In Alarm	al 3n	N-O: Close in alarm N-C: Open in alarm	n-o, n-c	N-O	None	
Alarm 3 Hysteresis	al h3	Universal-input: 0.1 to 999.9		0.2	°C or °F (See note.)	
		Analog input: 0.01 to 99.99		0.02	%FS	
HB ON/OFF	hbu	OFF, ON	off, on	ON	None	
Heater Burnout Latch	hbl	OFF, ON	off, on	OFF	None	
Heater Burnout Hysteresis	hbh	0.1 to 50.0		0.1	А	
ST Stable Range	st-b	0.1 to 999.9		15.0	°C or °F	
α	al fa	0.00 to 1.00		0.65	None	
Input Digital Filter	inf	0.0 to 999.9		0.0	Second	
Additional PV Display	pvad	OFF, ON	off, on	OFF	None	
MV Display	o-dp	OFF, ON	off, on	OFF	None	

**Note** Set "none" as the unit for Controllers with Analog Inputs.

# Appendix A

Parameters	Characters	Setting (monitor) value	Display	Default	Unit	Set value
Automatic Display return Time	ret	OFF or 1 to 99	off, 1 to 99	OFF	Second	
Alarm 1 Latch	a1l t	OFF, ON	off, on	OFF	None	
Alarm 2 Latch	a2l t	OFF, ON	off, on	OFF	None	
Alarm 3 Latch	a3l t	OFF, ON	off, on	OFF	None	
Move to Protect Level Time	prlt	1 to 30		3	Second	
Input Error Output	sero	OFF, ON	off, on	OFF	None	
Cold Junction Compensation Method	сј с	OFF, ON	off, on	ON	None	
MB Command Logic Switching	rlrv	OFF, ON	off, on	OFF	None	
Alarm 1 ON Delay	a1on	0 to 999 (0: ON delay disabled)		0	Second	
Alarm 2 ON Delay	a2on	0 to 999 (0: ON delay disabled)		0	Second	
Alarm 3 ON Delay	a3on	0 to 999 (0: ON delay disabled)		0	Second	
Alarm 1 OFF Delay	a1of	0 to 999 (0: OFF delay disabled)		0	Second	
Alarm 2 OFF Delay	a2of	0 to 999 (0: OFF delay disabled)		0	Second	
Alarm 3 OFF Delay	a3of	0 to 999 (0: OFF delay disabled)		0	Second	
Input Shift Type	istp	INS1: Temperature input 1- point shift INS2: Temperature input 2- point shift	i ns1, i ns2	INS1	None	
Auto/Manual Select Addition	amad	OFF, ON	off, on	OFF	None	
HS Alarm Use	hsu	OFF, ON	off, on	ON	None	
HS Alarm Latch	hsl	OFF, ON	off, on	OFF	None	
HS Alarm Hysteresis	hsh	0.1 to 50.0		0.1	А	
LBA Detection Time	I ba	0 to 9999 (0: LBA function disabled)		0	Second	
LBA Level	l bal	Universal-input: 0.1 to 999.9		8.0	°C or °F (See note.)	
		Analog input: 0.01 to 99.99		10.00	%FS	
LBA Band	I bab	Universal-input: 0.0 to 999.9		3.0	°C or °F (See note.)	
		Analog input: 0.00 to 99.99		0.20	%FS	

**Note** Set "none" as the unit for Controllers with Analog Inputs.

Parameters	Characters	Setting (monitor) value	Display	Default	Unit	Set value
Control Output 1	out1	When control output 1 is a		0	None	
Assignment		pulse output (See note.):				
		NONE: No assignment	none			
		O: Control output (heat-	0			
		ing)				
		C-O: Control output (cool-	C-0			
		ing)				
		ALM1: Alarm 1	al m1			
		ALM2: Alarm 2 ALM3: Alarm 3	alm2 alm3			
			ai m3			
		When control output 1 is a lin-				
		ear output (See note.):				
		NONE: No assignment	none			
		O: Control output (heat-	0			
		ing) C-O: Control output (cool-	C-0			
		ing)	C-0			
		<u> </u>				
Alarm Output 1	al m1	NONE: No assignment	none	ALM1	None	
Assignment		O: Control output (heat-	О			
		ing) C-O: Control output (cool-	C-0			
		ing)	C-0			
		ALM1: Alarm 1	alm1			
		ALM2: Alarm 2	al m2			
		ALM3: Alarm 3	al m3			
Alarm Output 2	al m2	NONE: No assignment	none	ALM2	None	
Assignment	ar iiiz	O: Control output (heat-	0	7 (21012	110110	
7 toolgriment		ing)				
		C-O: Control output (cool-	C-0			
		ing)				
		ALM1: Alarm 1	alm1			
		ALM2: Alarm 2	alm2			
		ALM3: Alarm 3	alm3			
Alarm Output 3	al m3	NONE: No assignment	none	ALM3	None	
Assignment (E5AZ /		O: Control output (heat-	0			
E5EZ Only)		ing)				
		C-O: Control output (cool-	C-0			
		ing)	, ,			
		ALM1: Alarm 1	al m1			
		ALM2: Alarm 2	al m2			
		ALM3: Alarm 3	alm3			
Character Select	csel	OFF, ON	off, on	ON	None	

**Note** The setting range depends on whether control output 1 is a linear output or pulse output.

### **Protect Level**

Parameters	Characters	Setting (monitor) value	Display	Default	Unit	Set value
Operation/Adjust- ment Protect	oapt	0 to 3		0	None	
Initial Setting/Com- Munications Protect	icpt	0 to 2		1	None	
Setting Change Protect	wtpt	OFF, ON	off, on	OFF	None	

## **Communications Setting Level**

Parameters	Characters	Setting (monitor) value	Display	Default	Unit	Set value
Protocol Setting	psel	CompoWay/F (SYSWAY), Modbus (See note.)	cwf, mod	Compo- Way/F (SYSWAY)	None	
Communications Unit No.	u-no	0 to 99		1	None	

**Note** When setting CWF, either CompoWay/F or SYSWAY can be used as the communications protocol. (CompoWay/F and SYSWAY are automatically identified by the command frames.)

# Appendix A

Parameters	Characters	Setting (monitor) value	Display	Default	Unit	Set value
Communications Baud Rate	bps	1.2, 2.4, 4.8, 9.6, 19.2, or 38.4	1.2, 2.4, 4.8, 9.6, 19.2, 38.4	9.6	kbps	
Communications Data Length	I en	7, 8		7	Bit	
Communications Stop Bits	sbi t	1, 2		2	Bit	
Communications Parity	prty	None, Even, Odd	none, even, odd	Even	None	
Send Data Wait Time	sdwt	0 to 99		20	ms	

# **Sensor Input Setting Range, Indication Range, Control Range**

	Input type	Specifications	Set value	Input temperature range	Input indication range
Control- lers with	Resistance ther- mometer	Pt100	0	−200 to 850 (°C)/−300 to 1,500 (°F)	−220 to 870 (°C)/−340 to 1,540 (°F)
Thermo- couple/ Resis- tance Ther-			1	-199.9 to 500.0 (°C)/-199.9 to 900.0 (°F)	-199.9 to 520.0 (°C)/-199.9 to 940.0 (°F)
			2	0.0 to 100.0 (°C)/0.0 to 210.0 (°F)	-20.0 to 120.0 (°C)/-40.0 to 250.0 (°F)
mome- ter		JPt100	3	-199.9 to 500.0 (°C)/-199.9 to 900.0 (°F)	-199.9 to 520.0 (°C)/-199.9 to 940.0 (°F)
Univer- sal-			4	0.0 to 100.0 (°C)/0.0 to 210.0 (°F)	-20.0 to 120.0 (°C)/-40.0 to 250.0 (°F)
inputs	Thermocouple	К	5	-200 to 1,300 (°C)/-300 to 2,300 (°F)	-220 to 1,320 (°C)/-340 to 2,340 (°F)
			6	-20.0 to 500.0 (°C)/0.0 to 900.0 (°F)	-40.0 to 520.0 (°C)/-40.0 to 940.0 (°F)
		J	7	-100 to 850 (°C)/-100 to 1,500 (°F)	-120 to 870 (°C)/-140 to 1,540 (°F)
			8	-20.0 to 400.0 (°C)/0.0 to 750.0 (°F)	-40.0 to 420.0 (°C)/-40.0 to 790.0 (°F)
		Т	9	-200 to 400 (°C)/-300 to 700 (°F)	-220 to 420 (°C)/-340 to 740 (°F)
			10	-199.9 to 400.0 (°C)/-199.9 to 700.0 (°F)	-199.9 to 420.0 (°C)/-199.9 to 740.0 (°F)
		Е	11	0 to 600 (°C)/0 to 1,100 (°F)	-20 to 620 (°C)/-40 to 1,140 (°F)
		L	12	-100 to 850 (°C)/-100 to 1,500 (°F)	-120 to 870 (°C)/-140 to 1,540 (°F)
		U	13	-200 to 400 (°C)/-300 to 700 (°F)	-220 to 420 (°C)/-340 to 740 (°F)
			14	-199.9 to 400.0 (°C)/-199.9 to 700.0 (°F)	-199.9 to 420.0 (°C)/-199.9 to 740.0 (°F)
		N	15	-200 to 1,300 (°C)/-300 to 2,300 (°F)	-220 to 1,320 (°C)/-340 to 2,340 (°F)
		R	16	0 to 1,700 (°C)/0 to 3,000 (°F)	-20 to 1,720 (°C)/-40 to 3,040 (°F)
		S	17	0 to 1,700 (°C)/0 to 3,000 (°F)	-20 to 1,720 (°C)/-40 to 3,040 (°F)
		В	18	100 to 1,800 (°C)/300 to 3,200 (°F)	0 to 1,820 (°C)/0 to 3,240 (°F)
	ES1B Infrared Temperature	10 to 70°C	19	0 to 90 (°C)/0 to 190 (°F)	-20 to 130 (°C)/-40 to 270 (°F)
	Sensor	60 to 120°C	20	0 to 120 (°C)/0 to 240 (°F)	-20 to 160 (°C)/-40 to 320 (°F)
		115 to 165°C	21	0 to 165 (°C)/0 to 320 (°F)	-20 to 205 (°C)/-40 to 400 (°F)
		140 to 260°C	22	0 to 260 (°C)/0 to 500 (°F)	-20 to 300 (°C)/-40 to 580 (°F)
	Analog input	0 to 50 mV	23	Any of the following ranges, by scaling: -1,999 to 9,999 -199.9 to 999.9	-5% to 105% of setting range. The display shows - 1999 to 9999 (numeric range with decimal point omitted).

	Input type	Specifications	Set value	Input temperature range	Input indication range
Control-	Current input	4 to 20 mA	0	Any of the following ranges,	-5% to 105% of setting
lers with Analog		0 to 20 mA	1	by scaling: -1999 to 9999	range. The display shows -1999 to 9999 (numeric
Inputs	Voltage input	1 to 5 V	2	-199.9 to 999.9	range with decimal point
		0 to 5 V	3	-19.99 to 99.99	omitted).
		0 to 10 V		1–1.999 to 9.999	

- The default is 5 (°C/°F) for Controllers with Thermocouple/Resistance Thermometer Universal-inputs and 0 for Controllers with Analog Inputs.
- The applicable standards for each of the above input ranges are as follows:

K, J, T, E, N, R, S, B: JIS C1602-1995, IEC 584-1 L: Fe-CuNi, DIN 43710-1985 U: Cu-CuNi, DIN 43710-1985

JPt100: JIS C 1604-1989, JIS C 1606-1989

Pt100: IEC 751

#### **Control Range**

• Resistance thermometer and thermocouple input

Temperature lower limit  $-20^{\circ}$ C to temperature upper limit  $+20^{\circ}$ C, or temperature lower limit  $-40^{\circ}$ C to temperature upper limit  $+40^{\circ}$ C

• ES1B input:

Same as input indication range


Analog input

-5% to +105% of scaling range

## **Setting Levels Diagram**


This diagram shows all of the setting levels. To move to the advanced function setting level , you must enter passwords. Some parameters are not displayed depending on the protect level setting and the conditions of use.


Control stops when you move from the operation level to the initial setting level.



**Note** (1) Moves to operation level by software reset.

(2) From the manual control level, key operations can be used to move to the operation level only.





Numerics	parameter operation lists, 169
2-PID control, 36, 122	control outputs, 9, 38
, ,	control outputs 1
•	wiring, 23
Α	control periods, 36, 124
adjustment level, 11, 106	cooling coefficient
parameter operation lists, 164	setting, 68
advanced function setting level, 11, 129	current transformer
moving to, 76, 128	calculating detection current values, 51
parameter operation lists, 167	Current Transformers (CT), 51, 153
alarm delays, 79	CT inputs
alarms, 9	wiring, 25
alarm output 1 assignment, 146	external dimensions, 154
alarm output 2 assignment, 147	E54-CT1, 154
alarm output 3 assignment, 148	E54-CT3, 154
alarm delays, 79	specifications, 153
alarm hysteresis, 63	Current Value Exceeds (error display), 158
alarm latch, 63	
alarm outputs 1, 2 and 3	_
wiring, 24	D
alarm types, 47	dead band, 67
alarm values, 49	setting, 68
operation, 64	_
analog input, 8, 65	derivative time, 46
AT (auto-tuning), 43	detection current, 51
AT execute/cancel, 43	dimensions, 16
auto control, 72	E5AZ, 16
auto/manual select addition, 86, 143	E5CZ, 16
auto/manual switch, 99	E5CZ-U, 16
auto/manual switch, 55	E5EZ, 17
	direct operation, 37, 124
В	Display Range Exceeded (error display), 156
	down key, 4
basic model	
E5AZ, 7	E
E5CZ, 5	L
E5CZ-U, 6	error displays, 156
E5EZ, 7	Current Value Exceeds, 158
	Display Range Exceeded, 156
C	HB Error, 157
•	Heater Burnout, 158
characteristics, 152	HS Alarm, 158
close in alarm, 64	Input Error, 156
wiring	Memory Error, 157
RS-232C, 27	ESIB, 60
RS-485, 26	event inputs, 9, 25, 69
communications function, 9	wiring, 25
	external dimensions

Current Transformer (CT), 153	one-point shift, 59
	two-point shift, 60
F	calculating, 60
Г	input types, 34
front panel	default values, 173
E5AZ, 2	list, 35
E5CZ, 2	setting, 34
E5CZ-U, 2	inputs
E5EZ, 3	wiring, 23
	installation, 16, 18
Ш	E5AZ/E5EZ
Н	mounting the terminal cover, 19
HB Error (error display), 157	mounting to the panel, 19
HB alarm (heater burnout alarm), 50	E5CZ/E5CZ-U
settings, 53	mounting the terminal cover, 18
Heater Burnout (error display), 158	mounting to the panel, 19
	panel cutout
heater burnout alarm, 9, 136, 152	E5AZ, 17 E5CZ, 17
heater burnout hysteresis, 136	E5CZ-U, 17
heating/cooling control, 66, 113, 116, 123	E5EZ, 18
cooling coefficient, 67, 113	removing from case
dead band, 67, 114	E5AZ, 20
setting, 68	E5CZ, 20
HS alarm, 9, 50, 152	E5EZ, 20
settings, 55	integral time, 46
HS Alarm (error display), 158	micgiai tino, 10
hysteresis, 41, 42	
	K
	leave
•	keys
I/O configuration, 5	down key, 4 key operations, 10
basic model	level key, 4
E5AZ, 7	mode key, 4
E5CZ, 5	operations, 4
E5CZ-U, 6	up key, 4
E5EZ, 7	1 7/
main functions, 8	
indicators	L
meanings, 3	IDA (loon brook alarm) 91
operation, 3	LBA (loop break alarm), 81
initial setting level, 11, 118	band, 83 detection time, 82
parameter operation lists, 165	level, 82, 83
initial setting/communications protect, 78	
initial settings, 32	level key, 4
examples, 32, 33	loop break alarm (LBA), 81
initialization, 130	
Input Error (error display), 156	M
input sensor types, 8, 119	
input shift, 59	main functions, 8

manual control, 72, 84	advanced function setting level, 167
manual control level, 11	communications setting level, 169
moving to, 85	initial setting level, 165
parameter operation lists, 167	protect level, 169
	parameters
manual setup, 46	additional PV display, 138
Memory Error (error display), 157	alarm output 1 assignment, 146
mode key, 4	alarm 1 hysteresis, 135
mounting, 18	alarm 1 latch, 139
terminal cover	alarm 1 OFF delay, 142
E5AZ/E5EZ, 19	alarm 1 ON delay, 141
E5CZ/E5CZ-U, 18	alarm 1 open in alarm, 134
to panel	alarm 1 type, 124
E5AZ/E5EZ, 19	alarm output 2 assignment, 147
E5CZ/E5CZ-U, 19	alarm 2 hysteresis, 135
multi-SP, 69, 99, 131	alarm 2 latch, 139
	alarm 2 OFF delay, 142
N	alarm 2 ON delay, 141
IN	alarm 2 open in alarm, 134
No. 1 display, 3	alarm 2 type, 126
No. 2 display, 3	alarm output 3 assignment, 148
	alarm 3 hysteresis, 135
_	alarm 3 latch, 139
0	alarm 3 OFF delay, 142
01/077	alarm 3 ON delay, 141
ON/OFF control, 36, 122	alarm 3 open in alarm, 134
setting, 41	alarm 3 type, 126
one-point shift, 61	alarm value 1, 101
open in alarm, 64	alarm value 2, 102
operation level, 11, 97	alarm value 3, 102 alarm value lower limit 1, 103
parameter operation lists, 163	alarm value lower limit 1, 103 alarm value lower limit 2, 103
operation/adjustment protect, 78	alarm value lower limit 2, 103
output functions	alarm value upper limit 1, 103
assignments, 38	alarm value upper limit 1, 100
output limits, 91	alarm value upper limit 3, 104
output specifications	alpha, 137
setting, 36	AT execute/cancel, 108
0,	auto/manual select addition, 143
_	auto/manual switch, 99
P	automatic display return time, 139
	character select, 148
panel cutout	cold junction compensation method, 140
E5AZ, 17 E5CZ/E5CZ-U, 17	communications baud rate, 149
E5EZ, 18	communications data length, 149
	communications parity, 149
parameter flow, 175	communications stop bits, 149
parameter operation list, 163	communications Unit No., 149
adjustment level, 164	communications writing, 108
manual control level, 67	control output 1 assignment, 146
operation level, 163	control period (cooling), 124
parameter operation lists	control period (heating), 124

cooling coefficient, 113	send data wait time, 149
dead band, 114	set point during SP ramp, 100
decimal point, 121	setting change protect, 96
derivative time, 113	SP 0, 111
direct/reverse operation, 124	SP 1, 111
event input assignment 1, 132	SP 2, 111
event input assignment 2, 132	SP 3, 111
HB ON/OFF, 135	SP lower limit, 122
heater burnout detection 1, 110	SP ramp set value, 116
heater burnout lysteresis, 136	SP ramp time unit, 132
heater burnout latch, 136	SP upper limit, 122
heater current 1 value monitor, 100, 109	ST (self-tuning), 123
HS alarm 1, 110	ST stable range, 137
HS alarm latch, 143	standard or heating/cooling, 123
hysteresis (cooling), 114	standby sequence reset, 133
hysteresis (heating), 114	temperature input shift, 111
initial setting/communications protect, 96	temperature unit, 121
input digital filter, 138	transfer output lower limit, 127
input error output, 140	transfer output type, 127
input shift type, 142	transfer output upper limit, 127
input type, 119	upper-limit temperature input shift value, 112
integral time, 113	part names
LBA band, 145	functions, 2
LBA detection time, 144	PID constants, 43, 44
LBA level, 145	setting manually, 46
leakage current 1 monitor, 101, 109	PID control
lower-limit temperature input shift value, 112	setting, 41
manual reset value, 114	power supply
MB command logic switching, 141	wiring, 22
move to advanced function setting level, 128	G.
move to protect level time, 140	precautions
multi-SP set point setting, 99	wiring, 22
multi-SP uses, 132	process value (PV), 98
MV (manual MV), 117	proportional action, 46
MV display, 138	proportional band, 46
MV lower limit, 116	protect level, 11, 77, 95
MV monitor (cooling), 105	moving to, 140
MV monitor (heating), 104	parameter operation lists, 169
MV upper limit, 116	protection, 77
number of multi-SP uses, 131	initial setting/communications, 78, 96
operation/adjustment protect, 96	operation/adjustment, 78, 96
parameter initialization, 130	setting change, 78, 96
PID ON/OFF, 122	
process value, 98	PV/MV, 117
process value/set point, 99	
proportional band, 113	R
protocol setting, 149	11
PV/MV (manual MV), 117	ratings, 151
RUN/STOP, 101	removing from case
scaling lower limit, 121	E5AZ/E5EZ, 20
scaling upper limit, 121	E5CZ, 20
selecting, 12	2002, 20

reverse operation, 37, 124	output, 36
run/stop control, 72	USB-Serial Conversion Cable, 155
	ST (self-tuning), 44
•	ST stable range, 45
S	startup conditions, 45
cealing	standard control, 123
scaling upper and lower limits for analog inputs, 65	standby sequence, 63
	startup
self-tuning (ST), 44, 123	conditions, 45
sensor input	operation, 75
control range, 172	support software port, 27
indication range, 172	support software port, 27
setting range, 172	
sensor types, 119	T
set point (SP), 40	
limiter, 73	temperature input, 8
limiting change rate, 74	shift values, 62
lower limit, 74	temperature unit, 4, 36
ramp, 74	terminals
setting, 40, 41	arrangement
setting upper and lower limits, 73	E5AZ/E5EZ, 22
switching between SPs, 71	E5CZ, 21
upper limit, 73	E5CZ-U, 21
setting change protect, 78	wiring, 22
setting level configuration, 10	three-position control, 41
setting levels	transfer output, 88
diagram, 174	type, 88
settings	troubleshooting, 158, 159, 160
cooling coefficient, 68	two-point shift, 60, 62
dead band, 68	calculating, 60
event input, 69	8, 11
fixing, 12	
HB alarm (heater burnout alarm), 53	U
moving to advanced function setting level, 53	1 4
heating/cooling control, 68	up key, 4
HS alarm, 55	USB-Serial Conversion Cable
moving to advanced function setting level, 54	specifications, 155
hysteresis, 42	
LBA detection time, 82	W
PID ON/OFF, 41	**
SP lower limit, 74	wiring, 22
SP upper limit, 73	alarm outputs 1, 2, and 3, 24
switching between SPs, 72	communications
shifting input values, 59	RS-232C, 27
SP ramp, 74	RS-485, 26
alarm operations, 76	control output 1, 23
operation at startup, 75	CT inputs, 25
restrictions, 75	event inputs, 25
specifications, 151	inputs, 23
Current Transformer (CT), 153	power supply, 22

precautions, 22 terminal arrangement, 21 terminals, 21

# **Revision History**

A manual revision code appears as a suffix to the catalog number on the front cover of the manual.



The following table outlines the changes made to the manual during each revision. Page numbers refer to the previous version.

	Revision code	Date	Revised content
I	01	September 2008	Original production